





USER GUIDE

PMP Synchronization Solutions Release 9.0



Accuracy

While reasonable efforts have been made to assure the accuracy of this document, Cambium Networks assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. Cambium reserves the right to make changes to any products described herein to improve reliability, function, or design, and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Cambium does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others. It is possible that this publication may contain references to, or information about Cambium products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Cambium intends to announce such Cambium products, programming, or services in your country.

Copyrights

This document, Cambium products, and 3rd Party software products described in this document may include or describe copyrighted Cambium and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Cambium, its licensors, and other 3rd Party supplied software certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Cambium, its licensors, or the 3rd Party software supplied material contained in the Cambium products described in this document may not be copied, reproduced, reverse engineered, distributed, merged or modified in any manner without the express written permission of Cambium. Furthermore, the purchase of Cambium products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Cambium or other 3rd Party supplied software, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

Restrictions

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Cambium.

License Agreements

The software described in this document is the property of Cambium and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

High Risk Materials

Components, units, or 3rd Party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities). Cambium and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

© 2018 Cambium Networks Limited. All Rights Reserved.

Safety and regulatory information

This section describes important safety and regulatory guidelines that must be observed by personnel installing or operating Cambium wireless equipment.

Important safety information

WARNING

To prevent loss of life or physical injury, observe the safety guidelines in this section.

Deployment in Restricted Access Area

Cambium Synchronization equipment including the CMM4 and CMM5 are to be deployed in areas with access restricted to authorized personnel only. The equipment must not be accessible to public access. Gaining access to the equipment must require special security access, physical locks and/or tool access.

Equipment is intended for installation in Restricted Access Area" /"Les matériels sont destinés à être installés dans des EMPLACEMENTS À ACCÈS RESTREINT.

Power lines

Exercise extreme care when working near power lines.

Working at heights

Exercise extreme care when working at heights.

Grounding and protective earth

Units must be properly grounded to protect against lightning. It is the user's responsibility to install the equipment in accordance with national regulations. In the USA, follow Section 810 of the *National Electric Code, ANSI/NFPA No.70-1984* (USA). In Canada, follow Section 54 of the *Canadian Electrical Code*. These codes describe correct installation procedures for grounding the outdoor unit, mast, lead-in wire and discharge unit, size of grounding conductors and connection requirements for grounding electrodes. Other regulations may apply in different countries and therefore it is recommended that installation of the outdoor unit be contracted to a professional installer.

Powering down before servicing

Always power down and unplug the equipment before servicing.

Primary disconnect device

The AP, SM, or BHs unit's power supply is the primary disconnect device.

External cables

Safety may be compromised if outdoor rated cables are not used for connections that will be exposed to the outdoor environment.

RF exposure near the antenna

Radio frequency (RF) fields will be present close to the antenna when the transmitter is on. Always turn off the power to the unit before undertaking maintenance activities in front of the antenna.

Minimum separation distances

Install the AP/SM/BH so as to provide and maintain the minimum separation distances from all persons.

The minimum separation distances for each frequency variant are specified in the product's corresponding User Guide.

Contents

Safety and reg	ulatory information	i
Importa	Int safety information	i
General info	prmation	xi
Versior	information	xi
Contac	ting Cambium Networks	xi
Caring for t	ne environment	xii
Chapter 1:	Introduction to synchronization	1-1
Interference	and reliability	
Exclusi	vity and free use of spectrum	
Source	s of interference	
Neutralizing	interference	
GPS sy	nchronization	1-4
Configu	Iration options for TDD synchronization	1-5
Alterna	tive to GPS synchronization	1-6
Cambium's	synchronization solutions	1-7
Univers	al GPS (UGPS)	1-7
CMM5		1-8
CMM4	(Rack Mount) – No Longer Available for Sale (November 2018)	1-8
CMM4	(Cabinet with switch) – No longer for sale as of November 1st, 2018	1-9
CMM4	(Cabinet without switch) No longer for sale as of November 1st, 2018	1-9
CMMm	icro (CMM3) – Product is End of Life and no longer available for new shipments	1-10
Chapter 2:	Cambium Cluster Management Module (CMM5)	2-11
Product Ov	erview	2-12
Cluster	Management: Scenario 1	2-12
Cluster	Management: Scenario 2	2-13
CMM5	Controller Module	
CMM5	Injector Module	
CMM5	Injector Compatibility Matrix	2-15
CMM5	56V Injector Specifications	
CMM5	29V Injector Specifications	
Power	Supply Options	
Power	Supply Selection (When to use Each One)	
Power	Line Filter	
Ferrite	Beads	
What's	in Each Box	
Providi	ng Sync to CMM5 via uGPS Module	
CMM5 Plan	ning	
Injector	Cabling	2-23

Controller Cabling	2-23
CMM5 Controller Initial Startup	
Controller Initial Startup	2-24
CMM5 Injector Initial Startup	2-25
Injector Initial Startup	2-25
CMM5 Injector Configuration	2-26
Install the Device Drivers to Connect Serially to Injector from a PC	2-26
Configure the Terminal Emulator	2-28
Connect to the CMM5 Injector	2-30
Read and Modify the CMM5 Chassis Name and Port Names	2-32
CMM5 Controller Configuration	2-35
Log In	2-35
Change Password	2-35
View and Configure Network Interfaces	2-36
Configure System Properties and Time Synchronization	2-43
Configure SNMP	2-50
Configure Injectors	2-58
Backup and Restore Configuration	2-62
CMM5 Injector Operation	2-66
Blink the CMM5 Injector LEDs	
Read the CMM5 Injector Status	2-67
Read and Modify the CMM5 Injector Parameters	
Display the CMM5 Injector Serial Number	2-70
CMM5 Controller Operation.	
View Controller Status	2-72
Controller System Operations	2-73
Controller Services	
Controller Network Operations	2-85
Logout and Shutdown Operations	2-87
CMM5 Error Conditions	
CMM5 Firmware Upgrade	2-91
CMM5 Firmware Update Procedure Flow	2-91
Update Controller Firmware	2-91
Update Master Injector Firmware	2-94
Update Slave/Standalone Injector Firmware	2-96
Installing the CMM5	2-98
Avoiding Hazards	2-98
Grounding Equipment	
Conforming to Regulations	2-99
Protecting Cables and Connections	2-99
Testing the Components	2-99
Unpacking Components	2-99
Installing a uGPS Antenna	2-99
Installing a Single Controller	2-99

Installing a Single Injector	
Installing Two Injectors Side by Side	
Installing a Controller/Injector Side by Side	
Installing a 600 Watt Power Supply	
Installing a Split DC Power Line	
Cabling the CMM5	
Replaceable Fuses	
Class A Emissions Requirements	
Chapter 3: Cambium Cluster Management Module (CMM4) – No Longer Available	3-111
CMM4 and Controller Board	
Power	
Ethernet Switch	
Specifications	
Providing sync to CMM via UGPS Module	
CMM Planning	
Typical Ethernet Cabling	
Standard Ethernet Cabling Configuration	3-121
Power Planning	
Syncing Two Co-located CMMs Together	3-128
Cables	3-130
EtherWAN Switch Information	3-134
Configuring a CMM4	3-136
Configuring IP Communications Parameters	
Overriding Forgotten IP Addresses, Usernames, or Passwords	3-137
Log In	
User Update	
Add User	
Delete User	
Configuring the CMM4 ports	
Configuring General CMM4 Parameters	
Configuring the SNMP parameters	
Configuring VLAN	
Configuring the Unit Settings	
Viewing the ARP Table (Statistics)	3-150
Viewing General Status	3-151
Viewing Sync Status	3-154
Viewing the System Log	3-155
Viewing the Network Interface	3-156
Viewing Layer 2 neighbors	3-156
Installing a CMM4	3-157
Avoiding hazards	3-157
Grounding Equipment	3-157
Conforming to Regulations	
Protecting Cables and Connections	3-158

Testing the Components	3-158
Unpacking Components	
Cables	
Installing a GPS Antenna	
Installing the power supply for the CMM4 (30 VDC or 54 VDC)	
Temperature Range	
Installing a CMM4 (Models 1090CKHH and 1091HH)	
Installing a Rackmount CMM4 (Model 1092HH)	
Cabling a CMM4 (Models 1090CKHH and 1091HH)	
Cabling a Rackmount CMM4	
Power Faults	
Chapter 4: Universal Global Positioning System Module	
UGPS Product Description and Overview.	
UGPS Power Source Configurations	4-4
External Power Only	4-4
Power from the Radio via UGPS Timing Port 1 or UGPS Timing Port 2	4-8
UGPS and CMM Configurations	4-14
Product Specifications	4-15
LIGPS installation and operation	4-16
LIGPS Installation Procedure	/-18
CPS status and location data readout	
Betrieving CPS Status and Leastian Date via Padia Web Management CLU	
Retrieving GPS Status and location data via SNMP	
LICES Dever Port and Timing Port Discute	
Chapter 5. CMM Regulatory and Logal Nations	
Important Note on Medifications	5-1
Important Note on Modifications	
National and Regional Regulatory Notices	
U.S. Federal Communication Commission (FCC) Notification	
Industry Canada (IC) Notification	
Equipment Disposal	
EU Declaration of Conformity for RoHS Compliance	
Labeling and Disclosure Table for China	
RF Exposure Separation Distances	5-5
Legal Notices	5-6
Software License Terms and Conditions	5-6
Hardware Warranty in U.S.	5-9
Limit of Liability	5-9
Chapter 6: UGPS Regulatory, Legal, and Safety Notices	6-1
IMPORTANT NOTE ON MODIFICATIONS	6-1
Universal GPS module label	6-1
NATIONAL AND REGIONAL REGULATORY NOTICES	6-1
Equipment Disposal	6-3
LIMIT OF LIABILITY	

List of Figures

Figure 1 GPS Synchronization	1-4
Figure 2 One unsynchronized AP in cluster resulting in self-interference	1-6
Figure 3 Universal GPS (UGPS)	1-7
Figure 4: CMM5 Controller	1-8
Figure 5: CMM5 56V Injector	1-8
Figure 6: CMM5 29V Injector	1-8
Figure 7 CMM4 Rack Mount	1-9
Figure 8 Cabinet (with switch)	1-9
Figure 9 CMMmicro (CMM3)	1-10
Figure 10: Cluster Management: Scenario 1	2-13
Figure 11: Cluster Management: Scenario 2	2-14
Figure 12: Controller Module	2-14
Figure 13: Injector Module	2-15
Figure 14: DC Line Filter	2-20
Figure 15: UGPS Module	2-22
Figure 16 Injector ODU Port LEDs Illuminated	2-67
Figure 17 Injector ODU Port LEDs Illuminated	2-77
Figure 18 Installing a Single Controller	2-100
Figure 19 Installing a Single Injector	2-101
Figure 20 Two Injectors with Joining Bar	2-102
Figure 21 Rear Attaching Screw	2-103
Figure 22 Injector/Controller Combination	2-104
Figure 23 600 Watt Power Supply Installation	2-105
Figure 24 600 Watt Power Supply Installation (rear view)	2-106
Figure 25 Installing a Split DC Power Line	2-107
Figure 26 Injector Front Panel	2-107
Figure 27 Injector/Controller Combination Cabling	2-108
Figure 28 Wiring the Power Connector	2-109
Figure 29 CMM4 internal view, including cable glands	3-113
Figure 30 Rackmount CMM4	3-114
Figure 31 GPS Antenna	3-115
Figure 32 CMM4 Standard Configuration	3-122
Figure 33 Rackmount CMM4 Standard Configuration	3-122
Figure 34 CMM4 cabled to use Gigabit Ethernet feed	3-124
Figure 35 CMM4 cabled to support PTP 500/600	3-125
Figure 36 Location of pin 1	3-131
Figure 37 CMM sync cable pinout	3-133
Figure 38 Location of pin 1	3-133
Figure 39 IP tab of CMM4	3-136

Figure 40	Login page of CMM4	3-140
Figure 41	Changer Users Password tab of CMM4	3-141
Figure 42	Add User tab of CMM4	3-142
Figure 43	Delete User tab of CMM4	3-143
Figure 44	Port Configuration tab of CMM4	3-143
Figure 45	CMM4 Configuration tab	3-144
Figure 46	SNMP tab of CMM4	3-146
Figure 47	VLAN tab of CMM4	3-148
Figure 48	Unit Settings Tab of CMM4	3-149
Figure 49	ARP table	3-150
Figure 50	General status tab of CMM4	3-151
Figure 51	Sync Status tab of CMM4	3-154
Figure 52	System Log tab of the CMM	3-155
Figure 53	Network Interface tab of the CMM	3-156
Figure 54	Layer 2 Neighbors Log	3-156
Figure 55	Detail of GPS antenna mounting	3-159
Figure 56	Weatherproofing an N-type antenna connector	3-160
Figure 57	AP/BHM to UGPS cable	3-161
Figure 58	Power supply DC connection	3-162
Figure 59	Power supply AC connection	3-163
Figure 60	CMM4 line filter installation (EU only)	3-164
Figure 61	Rackmount CMM line filter installation (EU only)	3-165
Figure 62	Resistor when using both 56 VDC and 30 VDC power	3-167
Figure 63	CMM4 V-bracket to pole mounting	3-169
Figure 64	Attaching the rackmounting brackets	3-170
Figure 65	Rackmount CMM4 rack screws	3-171
Figure 66	Ethernet port connections	3-172
Figure 67	Staggered Ethernet cables	3-172
Figure 68	CMM4 LED indicators	3-174
Figure 69	LED indicators - rackmount CMM4	3-176
Figure 70	CMM port status showing power fault	3-177
Figure 71	UGPS connector interface	4-3
Figure 72	Power Pinout - UGPS Ethernet Power Cable	4-4
Figure 73	PMP 100 AP receiving synchronization from external-powered UGPS	4-5
Figure 74	PMP 320 receiving synchronization from external-powered UGPS	4-6
Figure 75	One PMP 400/430 AP and one PMP 100 AP receiving synchronization from external-powered U	GPS
		4-7
Figure 76	Power Pinout - UGPS to AP/BHM Timing Port (6-pin RJ-11)	4-8
⊢igure /7	AP/BHIM TO UGP'S Cable	4-9
Figure 78	PTP 230 backnaul master powering UGPS and receiving synchronization	4-10
⊢igure /9	PINP 450 AP powering UGPS and receiving synchronization	4-11
Figure 80	I wo PTP 230 backhaul master units powering UGPS and receiving synchronization	4-12
Figure 81 synch	PTP 230 backhaul master powering UGPS/receiving synchronization and PMP 100/430 receivin ronization	g 4-13
Figure 82	UGPS to CMM cable pin configuration	4-17

Figure 83	Location of pin 1	
Figure 84 18	Configuring the sync input and disabling UGPS power - PMP 100/400/430 and	PTP 100/200 series . 4-
Figure 85	Configuring the sync source - PMP 320 series	
Figure 86	Configuring the sync input and enabling UGPS power - PTP 230 series	
Figure 87	CMM port configuration for UGPS power	
Figure 88	IP default bypass - default radio on timing port 1	
Figure 89	IP default bypass - default radio on timing port 2	
Figure 90	GPS status and location data - PMP 430 example	
Figure 91	GPS status and location data - PMP 320	
Figure 92	UGPS label	
Figure 93	Waste disposal of electronic and electric equipment	

List of Tables

Table 1 CMM5 Power and Sync Injector Cables	2-23
Table 2 CMM5 Controller Cables	2-23
Table 3 CMM5 Cable Requirements	2-107
Table 4 CMM4 model numbers and Ethernet switch configurations	3-112
Table 5 Power supply part numbers	3-116
Table 6 CMM4 specifications	3-118
Table 7 Rackmount CMM4 specifications	3-119
Table 8 Recommended Ethernet cables	3-130
Table 9 RJ-45 pinouts for straight-through Ethernet cable - 30 VDC	3-130
Table 10 RJ-45 pinouts for straight-through Ethernet cable - 56 VDC	3-131
Table 11 Recommended antenna cable	3-131
Table 12 Wire size for CMM4 DC cable	3-132
Table 13 EtherWAN switch details	3-134
Table 14 IP tab attributes	3-136
Table 15 Change User Password tab attributes	3-141
Table 16 Add User attributes	3-142
Table 17 Delete User attributes	3-143
Table 18 Port Configuration attributes	3-144
Table 19 CMM tab attributes	3-145
Table 20 Link Speed selections for CMM4	3-145
Table 21 SNMP tab attributes	3-147
Table 22 VLAN tab attributes	3-148
Table 23 Unit Settings tab attributes	3-149
Table 24 ARP Table tab attributes	3-150
Table 25 General Status tab attributes	3-152
Table 26 Sync Status tab attributes	3-154
Table 27 Network Interface tab attributes	3-156
Table 28 AP/BHM to UGPS cable pinout	3-161
Table 29 AP/BHM to UGPS cable pinout	4-9
Table 30 Compatible 30V Power Supplies and Cords	4-16
Table 31 Cable Length Specification	4-17
Table 32 UGPS IP default bypass wiring	4-22
Table 33 UGPS IP default bypass wiring	4-22
Table 34 GPS SNMP OIDs - PMP 100/400/430 and PTP 100/200/230 series	4-26
Table 35 GPS SNMP OIDs - PMP 320 series	4-27
Table 36 UGPS Power Port Pinout	4-28
Table 37 UGPS Timing Port Pinout	4-28
Table 38 Disclosure Table for China	5-4
Table 39 Exposure separation distances	5-5

General information

Version information

The following shows the issue status of this document since it was first released:

Issue	Date of issue	Remarks	
001v000	January 2013	First issue	
002v000	April 2013	Formatting updates, rack-mount power supply cabling update	
003v000	April 2012	Pinout details for UGPS powering	
004v000	April 2013	Instructions for weatherproofing an N-type connector	
005v000	January 2016	Discontinue 30 VDC and 56 VDC CMM power supplies, introduce new power supplies Update UGPS power supply information	
006v000	February 2016	ePMP Updates	
007v000	January 2017	Adds CMM5	
008v000	May 2018	Changes to hardware and kit information to meet UL requirements	
009v000	September 2018	Add CMM5 system release 1.4 features and update procedures	

Contacting Cambium Networks

PMP support website: <u>http://www.cambiumnetworks.com/support</u> Cambium main website: <u>http://www.cambiumnetworks.com/</u> Sales enquiries: <u>sales@cambiumnetworks.com</u> Email support: <u>support@cambiumnetworks.com</u> Telephone numbers: For full list of Cambium support telephone numbers, see: <u>http://www.cambiumnetworks.com/support/contact-support</u>

Address:

Cambium Networks 3800 Golf Road, Suite 360 Rolling Meadows, IL 60008

Caring for the environment

The following information describes national or regional requirements for the disposal of Cambium Networks supplied equipment and for the approved disposal of surplus packaging.

In EU countries

The following information is provided to enable regulatory compliance with the European Union (EU) directives identified and any amendments made to these directives when using Cambium equipment in EU countries.



Disposal of Cambium equipment

European Union (EU) Directive 2002/96/EC Waste Electrical and Electronic Equipment (WEEE)

Do not dispose of Cambium equipment in landfill sites. In the EU, Cambium in conjunction with a recycling partner ensures that equipment is collected and recycled according to the requirements of EU environmental law.

Disposal of surplus packaging

Do not dispose of surplus packaging in landfill sites. In the EU, it is the individual recipient's responsibility to ensure that packaging materials are collected and recycled according to the requirements of EU environmental law.

In non-EU countries

In non-EU countries, dispose of Cambium equipment and all surplus packaging in accordance with national and regional regulations.

Chapter 1: Introduction to synchronization

Interference and reliability

In the unlicensed wireless environment, interference can be defined as unwanted, competing radio signals in the same frequency band. These interfering signals can disrupt, delay and reduce the reliability and quality of your network traffic and performance. In licensed frequency bands where no outside signals are competing, the issue is self-interference, i.e., your own network's signals competing with each other. In either case, the results go beyond lower quality transmission; they extend to customer dissatisfaction, loss of competitive advantage and decreased return on investment.

Exclusivity and free use of spectrum

There are two types of frequency bands in which wireless networks operate: the licensed and unlicensed bands. Characteristics of each include:

Licensed frequencies

Licensed frequencies are bands reserved for the exclusive use of a public/private entity. Since the spectrum is clean and clear with no RF emitters (controlled by other entities) operating in the same frequency, wireless system reliability is greatly improved. Interference issues are largely confined to self-interference problems.

Unlicensed frequencies

Frequently described as a "Free Use" environment, unlicensed frequencies provide spectrum that is available to virtually anyone that wants to use it. Signals from different transmitting organizations and entities may compete with one another for space, creating an environment in which interference and ambient noise — as well as self-interference — can be significant impairments to reliable communications. The sheer number of the competing signals in unlicensed spectrum places a premium on ensuring that the equipment you use is of exceptionally high quality and design.

Sources of interference

In general, there are three basic categories of interference:

Self-interference

Emanating from an organization's own operating environment, self-interference is a factor in both licensed and unlicensed frequencies. In either band, self-interference occurs when distinct signals come from a network under your control, whether from the same tower location or from several miles away. Furthermore, the larger and denser the network grows, the more it will be exposed to self-interference and the reliability and performance issues it may cause.

In most cases, it is best dealt with self-interference the network planning stage. In building or extending a wireless network, proper product design, advanced technology (such as Cambium's industry leading use of GPS synchronization) and the ability to reuse a frequency band within the spectrum can in most cases combine to reduce self-interference to a point at which it does not have a significant impact on network performance and reliability.

External interference

In unlicensed frequencies, interference is more difficult to manage, since the interference comes from networks and technology not under your control. Because a single access point can support hundreds of subscribers or end users, interference can have a substantial impact.

Other networks aren't the only culprits; more and more network interference is coming from a wide range of consumer devices — such as surveillance cameras, Wi-Fi hotspots, and microwave ovens — that may operate in or near the same frequency. Furthermore, a network must be designed to not only deal with present interference sources, but must also be pre- pared to deal with potential future sources as the wireless environment evolves and usage of the spectrum expands.

Ambient Noise

Also called the noise floor, ambient noise is simply background noise that is always present in a frequency band. It is caused by the growing numbers of wireless devices — from garage door openers to other wireless networks — operating in the same unlicensed frequency. These all crowd the spectrum and can be a significant factor in degrading signal and bandwidth. Ambient noise levels increase as more devices and networks are deployed in the spectrum.

Neutralizing interference

GPS synchronization

Cambium leads the wireless industry in its usage of powerful GPS synchronization capabilities in all its PMP networks. This valuable capability dramatically reduces self-interference in licensed or unlicensed frequency bands. GPS synchronization allows all sites to be set to the exact same clock so network timing is very precise. As shown in the diagram, GPS satellite timing signals reach the GPS receivers in each of the network's access point radios establishing a common timing reference. This allows all the access point radios in the network — whether hundreds or thousands — to transmit at the same time and alter natively receive as all of the subscriber modules in the network transmit at the same time in turn. This helps prevent radio signals transmitted by an access point transceiver to interfere with reception of a user signal by another access point transceiver, perhaps the most onerous kind of self-interference in time-division duplex radio networks. With GPS synchronization, you can be certain your network can scale and grow elegantly to serve increasing numbers of users and applications.



Figure 1 GPS Synchronization

The Navigation Satellite Timing and Ranging (NAVSTAR) and Global Navigation Satellite System (GLONASS) Global Positioning Systems (GPS) each use 24 satellites to relay information for precise derivation of position and time.

The cluster management module (CMM) contains a Cambium GPS Receiver. The CMM is a critical element in the operation of the system. At one AP cluster site or throughout an entire wireless system, the CMM provides a GPS timing pulse to each module, synchronizing the network transmission cycles.

The Oncore GPS Receiver tracks eight or more NAVSTAR or GLONASS satellites. The CMM uses the signal from at least four of these satellites to generate a one-second interval clock that has a rise time of 100 nsec. This clock directly synchronizes APs and which, in turn, synchronize the SMs in the network.

The Oncore GPS Receiver also provides

- the latitude and longitude of the GPS antenna (co-located with the CMM)
- the number of satellites that are being tracked
- the number of satellites that are available
- the date
- the time in Universal Coordinated Time (UCT)
- the altitude of the GPS antenna
- other information that can be used to diagnose network problems.

Configuration options for TDD synchronization

Cambium PMP systems use Time Division Duplexing (TDD) - one channel alternately transmits and receives - rather than using one channel for transmitting and a second channel for receiving. To accomplish TDD, the AP must provide sync to its SMs – it must keep them in sync. Furthermore, co-located APs must be synced together - an unsynchronized AP that transmits during the receive cycle of a co-located AP can prevent that second AP from being able to decode the signals from its SMs. In addition, across a geographical area, APs that can "hear" each other benefit from using a common sync to further reduce self-interference within the network.

For more information on each product series' synchronization configuration options, refer to the corresponding user guide, available here: https://support.cambiumnetworks.com/files

Alternative to GPS synchronization

A link can operate without *GPS* sync, but cannot operate without sync. The alternative to GPS sync is to configure the AP in the link to generate a sync pulse to pass to the SM. Depending on the RF environment in which the link operates, this latter alternative may or may not be plausible.

For example, in Figure 2, AP4

- is not synchronized with any of the other APs.
- is transmitting nearby the other APs while they are expecting to receive SM transmissions from a maximum distance.



Figure 2 One unsynchronized AP in cluster resulting in self-interference

The result is self-interference. In this scenario, the self-interference can be avoided only by synchronizing the TDD transmit cycles of all APs that operate in the same frequency band.

An AP that is isolated by at least 5 miles (8 km) from any other equipment can generate and pass sync pulse without GPS timing and not risk that interference will result from the generated sync. In any other type of link, sync should be derived from GPS timing.

Although the embedded timing generation capability of the AP keeps a precise clock (configuration parameter Sync Source set to **Generate Sync Signal**), no trigger exists to start the clock at the same moment in each AP of a cluster. So, the individual AP can synchronize communications between itself and registered SMs, but cannot synchronize itself with other modules, except by GPS timing.

Cambium's synchronization solutions

Cambium's entire Point-to-Multipoint (PMP) technology portfolio offers GPS synchronization to limit the network's own self-interference. The Cluster Management CMM provides Global Positioning System (GPS) synchronization to the Access Point (AP) and all associated Subscriber Modules (SM). Network operators have a choice of CMM solutions to select the option that works best for the environment.

Universal GPS (UGPS)

The UGPS provides network synchronization for smaller networks where a CMM may not be cost effective. The UGPS provides synchronization for one or two modules so that even remote areas at the edge of the network can operate with synchronization for improved performance. The UGPS works with all Cambium PMP radios. The UGPS has a small footprint and is easy to deploy.

Figure 3 Universal GPS (UGPS)



CMM5

The CMM5 (Cluster Management Module) is the latest generation of solutions for the distribution of TDD Sync signals and "Power-over-Ethernet (PoE)" in the field.

Figure 4: CMM5 Controller



Figure 5: CMM5 56V Injector



Figure 6: CMM5 29V Injector



CMM4 (Rack Mount) – No Longer Available for Sale (November 2018)

The cluster management module (CMM) is the heart of the Cambium system's synchronization capability, which allows network operators to reuse frequencies and add capacity while ensuring consistency in the quality of service to customers. For operators who prefer indoor CMM mounting, Cambium offers the Rack-Mounted Cluster Management Module 4. The unit is

designed to be mounted onto a standard 19-inch telecommunications rack and to allow the Cambium CMM4 to be co-located with other telecommunications equipment.

Figure 7 CMM4 Rack Mount



CMM4 (Cabinet with switch) – No longer for sale as of November 1st, 2018

Designed to deliver consistent and reliable wireless broadband service, the PMP system gracefully scales to support large deployments. The cluster management module is the heart of the system's synchronization capability which allows network operators to re-use frequencies and add capacity while ensuring consistency in the quality of service to customers. As a result, subscribers can experience carrier-grade service even those at the outer edge of the network.

Figure 8 Cabinet (with switch)

CMM4 (Cabinet without switch) --No longer for sale as of November 1st, 2018

This CMM includes all of the functionality listed above but there is no switch included. This provides the network operator the flexibility to use the switch of their choice with the power and synchronization capabilities of the CMM4.

CMMmicro (CMM3) – Product is End of Life and no longer available for new shipments

The Cluster Management Module 3 (CMM3), also known as the CMMmicro, allows network operators to reduce the time and labor cost of system installation and maintenance in AP Clusters. This management module reduces cabling between system modules and provides reliable network synchronization. There is only one cable going from the CMM3 to each module carrying the Ethernet connection, synchronization pulse and GPS data.



Figure 9 CMMmicro (CMM3)

Chapter 2: Cambium Cluster Management Module (CMM5)

The CMM5 consists of four subsystems, described in the following sections:

- CMM5 Controller Module
- CMM5 Injector (29 volt and 56 volt versions)
- Power supply(s) (240/480/600 watt)
- UGPS

Product Overview

The CMM5 (Cluster Management Module) is the latest generation of solutions for the distribution of TDD Sync signals and "Power-over-Ethernet (PoE)" in the field. The CMM5 is a modular design with individual 4-port power injectors and an optional controller used for remote management.

Key features of the CMM5 include:

- Support for Gigabit Ethernet (1000BaseT)
- Modular and scalable from 4 ports to 32 ports
- Direct +/- 48VDC input (optional AC/DC power supplies are available from Cambium Networks)
- High-power output support for 5 GHz PMP 450m (cnMedusa™)
- Uses Cambium Networks uGPS for a synchronization source
- Dual resilient power inputs
- Rack mountable
- Secure remote management when used with the optional CMM5 Controller Module
- Future support for integration into (cnMedusa[™]) for cloud or NOC-based management

Cluster Management: Scenario 1

The following is a CMM5 Cluster Management scenario using four PMP 450i Access Points.

Scenario	Equipment Needed	Features
Four PMP 450i Access Points	56 Volt Injector	 Gigabit Ethernet Local Management Interface +/- 48VDC Input Broad Device Support Rack Mountable
 48 VDC Available No management or resilience required 	uGPS	

Figure 10: Cluster Management: Scenario 1



Cluster Management: Scenario 2

The following is a CMM5 Cluster Management scenario using four PMP 450i Access Points and four PMP 450 Access Points.

Scenario	Equipment Needed Features	
Four PMP 450i Access	56 Volt Injector	Gigabit Ethernet support
Points	 29 Volt Injector 	Local Management Interface
	 1 CMM5 Controller 	 +/- 48VDC Input
Four PMP 450 Access	One uGPS	Broad Device Support
Points		Rack Mountable
AC only environments	Two AC-to-48VDC Power Supplies	Resilient power sources
Management required.		Secure, Remote
Resilience required.		Management (https)
·		Scalable to 32 devices



Figure 11: Cluster Management: Scenario 2

CMM5 Controller Module

The major features of the CMM5 Controller Module are:

- Auto-detect/control up to 8 Power Injectors
- Monitor SYNC/Power/GPS status
- Manage (up/down ports)
- Web (HTTPS) and SNMPv2/v3 management
- 1U/ half-width rack-mount

Figure 12: Controller Module



CMM5 Injector Module

The CMM5 Injector Module has the following features:

- Stand-alone mode or used with controller for mgmt.
- +/- 48VDC input with green/amber LED's for status
- Injects SYNC pulse from uGPS
- 2U / half-width rack-mount

Note that there are two different versions of the injector module (56V and 29V). You must select the correct injector for the types of radios that you will be powering. In both cases the injectors use the same 48-56V input power supplies or can be powered with +/- 48VDC. The output power is different and the type of SYNC signal used is different between the two types of injectors.

The 29V injector uses a physical layer sync signal that interrupts one of the pins every second to pass the 1PPS information to the radio.

The 56V injector uses a different physical layer sync signal that induces the 1PPS signal onto the drop cable. This new physical layer sync signal is compatible with 1000BaseT.

Systems can have 29V and 56V injectors deployed alongside each other.

Figure 13: Injector Module



CMM5 Injector Compatibility Matrix

Product	Power/Injector Model	Sync
PMP/PTP 450i	Yes/56V	Yes
PMP 450m	Yes/56V	Yes
ePMP 2000	Yes/56V	Roadmap
PTP 670	Yes/56V Rev. B	Yes
PTP 700	Yes/56V Rev. B	Yes
PMP 450/PTP 450	Yes/29V	Yes
PMP 100/PTP 100	Yes/29V	Yes

CMM5 56V Injector Specifications

The following table provides specifications for the CMM5 Power & Sync Injector (56 Volts).

CMM5 Power and Sync Injector 56 Volts	
Model Number	C00000L556B
Data Interface	4 each RJ45 Gigabit Powered output ports "To Radios"
	4 each RJ45 Gigabit Data input ports "To Switch Array"
	1 each GPS timing port (RJ-12)
	1 each CMM5 USB Serial port for local administration
	1 each RJ12 Daisy Chain port "IN"
	1 each RJ12 Daisy Chain port "OUT"
Surge Suppression	Lightning Suppression for each "To Radios" RJ45 Port
Power	Input Voltage: + or - 48 VDC
	Input Power Consumption: up to 400 watts
	Output Voltage: 56 VDC power over Ethernet
	Output Current: 0 - 1.8A per channel
	Output Power: 0 - 90 Watts per channel
Cabinet Temperature	-40° C to +55°C (-40° F to +131° F), 90% humidity, condensing
Physical	Max Distance from Managed Radios: 328 cable feet (100m)
	Max Distance to GPS Antenna: 100 cable feet (30.5m)
Dimensions	8.85" W x 15.75" D x 1.65" H (225mm x 400mm x 42mm)
Unit Weight	6.6 pounds (3kg)
Power Interface Terminals	2 Power input ports for 48 VDC Power (<i>Power supplies sold separately</i>)

CMM5 29V Injector Specifications

The following table provides specifications for the CMM5 Power & Sync Injector (29 Volts).

CMM5 Power and Sync Injector 29 Volts		
Model Number	C00000L529A	
Data Interface	4 each RJ45 Gigabit Powered output ports "To Radios"	
	4 each RJ45 Gigabit Data input ports "To Switch Array"	
	1 each GPS timing port (RJ-12)	
	1 each CMM5 USB Serial port for local administration	
	1 each RJ12 Daisy Chain port "IN"	
	1 each RJ12 Daisy Chain port "OUT"	
Surge Suppression	Lightning Suppression for each "To Radios" RJ45 Port	
Power	Input Voltage: + or - 48 VDC	
	Input Power Consumption: 240 watts	
	Output Voltage: +29 VDC power over Ethernet	
	Output Current: 0 - 1.0A per channel	
	Output Power: 0 - 30 Watts per channel	
Cabinet Temperature	-40° C to +55°C (-40° F to +131° F), 90% humidity, condensing	
Physical	Max Distance from Managed Radios: 328 cable feet (100m)	
	Max Distance to GPS Antenna: 100 cable feet (30.5m)	
Dimensions	8.85" W x 13.25" D x 1.75" H (225mm x 337mm x 45mm)	
Unit Weight	3.6 pounds (1.6 kg)	
Power Interface Terminals	2 Power input ports for 48 VDC Power (<i>Power supplies sold separately</i>)	

Power Supply Options

There are four optional DC power supplies available The CMM5 240 watt power supply Cambium Networks part number: N000000L054B



The CMM5 600 watt power supply. Cambium Networks part number: N000000L101A



There are also two options for DIN-rail mounted power supplies that meet full UL approvals.

N000000L111A 240W DIN-Rail Power Supply N000000L112A 480W DIN-Rail Power Supply



Power Supply Selection (When to use Each One)



IMPORTANT!

The power supply or supplies for the CMM5 must be separately ordered. Alternatively, if a +/-48 VDC source is available the CMM5 can be powered directly from that DC source.

You can use Cambium power supplies or an existing +/-48 VDC supply.

Equipment Configuration	Power Supplies Required	Notes
One to Four PMP 450i APs	240 watt (48-55V)	With accessories
Two 5GHz PMP 450m	240 watt (48-55V)	With accessories
Four 5GHz PMP 450m	480 or 600 watt (48-55V)	With accessories
Two 5GHz PMP 450m and two PMP 450i	480 or 600 watt (48-55V)	With accessories

Power Line Filter

In order to meet regulatory requirements in certain deployment scenarios, a power line filter module is recommended to be installed on the DC side of the power supply. This module may be ordered from Cambium Networks (part number N00000L056A).

Figure 14: DC Line Filter



Ferrite Beads

Ferrite beads are recommended to be attached to RJ-45 Ethernet cables to suppress noise and EMI.



What's in Each Box

The following paragraphs describe the contents (product and accessories) for each ordered component of the CMM5.

Quantity	Description
1	Injector (56 Volt)
2	Rack Mount Ears (short)
1	Rack Mount Ear (long)
1	6 Foot (1.8 Meter) USB Cable
1	8/32 SS Screw & Nut

Injector (56 Volt) Part Number: C00000L556B

1	Connector Bar
8	6/32 SS Countersunk Screws
2	Phoenix Input Connector
8	Ferrite beads for RJ-45 Connectors
1	Ferrite bead for Controller cable

Injector (29 Volt) Part Number: C000000L529A

Quantity	Description	
1	Injector (29 Volt)	
2	Rack Mount Ears (short)	
1	Rack Mount Ear (long)	
1	6 Foot (1.8 Meter) USB Cable	
1	8/32 SS Screw & Nut	
1	Connector Bar	
8	6/32 SS Countersunk Screws	
2	Phoenix Input Connector	

Providing Sync to CMM5 via uGPS Module

The uGPS module provides sync to the CMM5. See Section 4: UGPS for additional details.

CMM5 provides power to the uGPS module. You only need one uGPS for the entire chain.

Cable straight-Through RJ-12 (6-pins) from SYNC-OUT (uGPS) to the uGPS port on the first Injector of the Daisy-Chain.

You can procure your own cable or purchase this cable from Cambium Networks.

N00000L103A	CMM5 to uGPS Shielded Cable (20 meter)

Figure 15: UGPS Module


CMM5 Planning

The following paragraphs describe planning for the CMM5 module.

Injector Cabling

The following table describes Injector cables.

 Table 1
 CMM5 Power and Sync Injector Cables

Nomenclature	Function	Cable Required
PRIMARY	Primary 48VDC	Power connector
SECONDARY	Optional Secondary 48 VDC input for backup/resilience	Power connector
TO RADIOS	To Access Points	RJ-45 connector
TO SWITCH ARRAY	To Network	RJ-45 connector
OUT	Sync signal out	RJ-12 connector
IN	Sync signal in	RJ-12 connector
UGPS	Universal GPS	RJ-12 connector
USB	Daisy Chain other Injectors	USB Female

Controller Cabling

The following table describes Controller cables.

Table 2CMM5 Controller Cables

Nomenclature	Function	Cable Required
NETWORK	To Network	RJ-45
USB	Daisy-Chain Controllers	USB
48 – 56 VDC	DC Power Input	Power connector

CMM5 Controller Initial Startup

The following paragraphs describe the CMM5 Controller initial startup procedure.

Controller Initial Startup

Perform the following steps to bring up the Controller after the Master Injector and any Slave Injectors have been connected and powered on.

Procedure 1 Initial Startup of the Controller

- **1** Connect the Controller to the Master Injector using the supplied USB cable.
- 2 Connect the power supply to the Controller power port.
- **3** A green LED on the front panel indicates the device is powered on.
- 4 The Controller boots within 30 seconds.
- **5** Configure the PC Ethernet interface to an unused IP address on the 169.254.1.1/24 subnet.
- **6** Open a browser window and connect to the Controller using the default IP address:
 - 169.254.1.1

The CMM5 Controller implements a "fallback" IP address of 169.254.1.1 This address is always available to connect to the device regardless of the configuration of the network interface in the GUI. The subnet mask for this address is fixed at 255.255.255.0.

7 Log in to the Controller GUI using the default username and password.

- Default username: root
- Default password: password

If the browser cannot access the Controller GUI and instead displays an error, clear the browser cache and try again. This can happen if the browser was previously used to access another device, such as a Cambium Networks AP, and retains the AP's home page URL in the cache.

CMM5 Injector Initial Startup

The following paragraphs describe the initial startup procedure for the CMM5 Injector.

Injector Initial Startup

Perform the following steps to bring up the Injector for the first time.

Procedure 2 Configure the Injector

- **1** Connect the uGPS antenna to the uGPS port on the front of the CMM5.
- 2 Connect the power to the CMM5 Power Ports marked "Primary" and optionally for "Secondary".
- **3** Once the unit is powered the uGPS light will flash green momentarily then yellow for approximately thirty seconds then go back to green. Once it turns green the unit is ready to supply timing to the radios.
- 4 Connect the devices to be timed and powered to the ports marked "TO RADIOS".
- **5** Connect the CMM5 Ports to your switch or router via the ports marked "TO SWITCH ARRAY".
- 6 The CMM5 ships with all four RJ45 "To Radio" ports enabled for power and sync.
- 7 The CMM5 ships with one long rack mount ear and 2 short rack mount ears. When installing a single CMM5 in a rack, install one long ear and one short ear on the unit. If you are flush mounting your CMM5 on a wall or in a cabinet install the two short ears rotated 90 degrees toward the bottom of the unit.

CMM5 Injector Configuration

The following paragraphs describe the tasks necessary to configure a CMM5 Injector in standalone mode (Controller not present).

By default each injector is configured to generated power and sync on all four output ports. If this default configuration is satisfactory, there is no need for any configuration of the injector. It can simply be installed and powered up..

When a Controller is present the Injector can be configured entirely from the Controller GUI interface and the user should skip this section (Refer to the CMM5 Controller Configuration section for details.) in this case the procedures in this section are needed only when upgrading slave Injector firmware.

Install the Device Drivers to Connect Serially to Injector from a PC

It is only necessary to connect a PC to the injector if it is desired to modify the default configuration of the injector. By default the injector provides power and sync on all four outputs.

Alternatively, the CMM5 Controller module can be used to provide local and remote management of the CMM5 Injectors.

Perform the following steps to prepare the control PC for communication with the Injector. This procedure must be run before the PC is first connected to the Injector:

The procedure assumes that a PC running the Windows OS is used.

Procedure 3 Configure the Control PC

Download the FTDI Virtual COM Port (VCP) drivers from the website below. For ease of 1 installation it is recommended to use the setup executable option. http://www.ftdichip.com/Drivers/VCP.htm 2 Extract the setup executable from the zip archive and run it. Follow the setup instructions given by the installation wizard. 3 Connect the PC to the Injector USB port using the cable provided. 4 The PC detects the presence of the Injector in its USB port and starts the installation of the device drivers automatically, as indicated by a pop-up box. Installing device driver software 🔦 🗴 Click here for status. 5:55 PM 🖿 🧏 📶 🗟 🔁 🐂 ሌ 7/19/2018 5 Click on the pop-up box to show the detailed installation status. This action is recommended to track the progress and to confirm that the installation was successful. Driver Software Installation Installing device driver software FT232R USB UART Searching Windows Update... Obtaining device driver software from Windows Update might take a while. Skip obtaining driver software from Windows Update Close The PC begins by installing the FT232R USB UART driver. To speed up the installation 6 click "Skip obtaining driver software from Windows Update", then click Yes to confirm.

Driver So	oftware Installation
<u>^</u>	Do you want to skip getting driver software from Windows Update?
	Windows Update provides the latest available driver software which may work better for your device. You can check Windows Update later for the latest driver software. If you skip your device may not function at all.
	Yes No

7 After installation of the first driver is complete the PC will begin installation of the second driver.

Driver Software Installation		×
Your device is ready to use		
USB Serial Converter USB Serial Port	Ready to use Searching Windows Update	
You have skipped obtaining driver so	oftware from Windows Update.	
		Close

8

Verify that both drivers are installed successfully, as indicated by the green check marks in the progress window.

U Driver Software Installation		×
Your device is ready to use		
USB Serial Converter USB Serial Port (COM23)	Ready to use Ready to use	
		Close

Configure the Terminal Emulator

Perform the following steps to configure the terminal emulator for communication over the Injector CLI interface. This procedure must be run whenever the PC is connected to the Injector:

The TeraTerm terminal emulator is recommended for this application. The procedure assumes that TeraTerm is being installed on a PC running the Windows OS.

Procedure 4 Configure the PC Terminal Emulator

- **1** Download and install the latest version of the TeraTerm terminal emulator on the PC.
- 2 Run the program and start a serial session to the Injector COM port if it is connected. Alternatively, cancel the session to revert to the TeraTerm main window.
- **3** From the Setup menu select Terminal.. to open the Terminal setup window.

4 Change the Transmit setting under New-line to CR+LF. Also enable the Local Echo setting by checking the box.

Tera Term: Terminal setup	X
Terminal size 80 × 24	New-line Receive: CR •
Term size = win size Auto window resize	Transmit: CR+LF Cancel
Terminal ID: VT100 -	Help Local echo
Answerback:	Auto switch (VT<->TEK)
Coding (receive)	Coding (transmit)
UTF-8 🔻	UTF-8 💌
locale: american	CodePage: 65001

Select Serial Port from the Setup menu to open the Serial port setup window.

Set the Baud rate to 38400 and ensure that the Data, Parity, Stop and Flow control fields are set to 8 bit, none, 1 bit and none respectively.

Tera Term: Serial port setup		X
Port:	COM1 -	οκ
Baud rate:	38400 🗸	
Data:	8 bit 🔹	Cancel
Parity:	none 🔹	
Stop:	1 bit 🔹	Help
Flow control:	none 🔹	
Transmit delay 0 msec/	shar 0 m	sec/line

7

5

6

Make additional setting changes as desired to customize the emulator configuration (e.g. font size, text and background color, etc.).

8 It is recommended to save the terminal emulator configuration so that it can be quickly restored when needed. This may be done using the Save setup... and Restore setup... options in the Setup menu.

Connect to the CMM5 Injector

Perform the following steps to connect to the CMM5 Injector CLI interface via the USB port:

The TeraTerm terminal emulator is recommended for this application. The procedure assumes that TeraTerm is being run on a PC running the Windows OS.

Procedure 5 Connect to the CMM5 Injector

1 Open the Device Manager on the PC and expand the Ports (COM & LPT) entry.

🚔 Device Manager	<u> </u>
File Action View Help	
CJN037-01	
Human Interface Devices General IDE ATA/ATAPI controllers General Keyboards Mice and other pointing devices Mice and other pointing devices	
 Network adapters NI GPIB Interfaces Portable Devices Ports (COM & LPT) Communications Port (COM1) 	
Processors Proce	

2 Connect the PC to the Injector USB port using the cable provided.

Close any open TeraTerm windows before connecting the Injector. If this is not done then the COM port instance may not be created for the Injector.

3 Monitor the Device Manager and make a note of the COM port associated with the Injector connection.



4

Run the TeraTerm terminal emulator and start a serial session to the Injector COM port.

If the COM port assigned to the Injector does not appear in the TeraTerm pull-down list, check the application's teraterm.ini configuration file to ensure that the maximum number of COM ports is not limited. It is recommended to set the maximum ports to 256.

💆 Tera Term - [disconnect	ted] VT		x
File Edit Se Tera Term:	New connection	22	
© тср	YIP Host: 10.120.210.201 Image: I		
• Seri	ial Port: COM15: USB Serial Port (COM15) OK Cancel Help	•	Ŧ

- **5** Configure the TeraTerm options as described in the Configure the PC terminal emulator procedure above. Alternatively if the setup was previously saved, run Restore setup... from the Setup menu to recall the settings.
- 6 CLI commands may now be sent to the Injector from the TeraTerm window.



Read and Modify the CMM5 Chassis Name and Port Names

Perform the following steps to read the current Injector chassis name and ODU port names, and modify them if desired:

Procedure 6 Read and Modify the Injector Chassis Name and Port Names



2 Execute the following query command to display the current Injector chassis name and port names:

&0mA

3 The Injector responds with the current chassis name and port names as shown below:

In this example the names have not been changed from the default values.

🔟 Tera Term - COM22 VT	
File Edit Setup Control Window Help	
&@mA <u>&@mA,S/N=-1721B012K,Name=Name_not_set,S</u> tatus=OK &@mA,S/N=-1721B012K,Port1=Port_1 &@mA,S/N=-1721B012K,Port2=Port_2 &@mA,S/N=-1721B012K,Port3=Port_3 &@mA,S/N=-1721B012K,Port4=Port_4	

4

To change the chassis name, use the following command format:

&0n0<New chassis name>

Where the new chassis name is a string of up to 12 characters in length, with no leading or in-between spaces.

Leading or in-between spacing may be achieved using underscores. Strings less than 12 characters long will be padded with trailing underscores.



To change the name of one of the Injector ports, use the following command format:
 &0n#<New port name>

Where # is in the range 1 through 4, representing ports 1 through 4 respectively

In this example four separate commands are run to rename each of the four ports.



6

Execute the **&0mA** command again to verify that the chassis and port names have been updated to the new values:



CMM5 Controller Configuration

The following paragraphs describe the tasks necessary to configure the CMM5. The Controller must be running version 1.4 or later firmware in order to support all of the functionality described below. In addition the master Injector must be upgraded to version 00.21 or later firmware to support the GPS data feature.

Log In

Perform the following steps to log into the CMM5.

Procedure 7 Log In to the CMM5



- Enter the Username ("root").
- 2 Enter your Password.

NOTE The default password is "password".

3 Click "Login".

The "Reset" button allows you to clear the password field and retype the password. It does not reset the password to default.

	Cambium Networks	
C	IM5 Controller vRP3B12.1.2 49970	
A Ple	thorization Required ase enter your username and password.	
	Username	Sroot .
	Password	P ••••••
·		🧐 Reset 📴 Login

Change Password

Perform the following steps to change your password on the CMM5 Controller.



The Controller username defaults to "root" and cannot be changed by the operator.



Procedure 8 Change Password on CMM5

- **1** From the System screen, select Administration.
- 2 Enter your new password in the "Password" field.
- **3** Type your new password again in the "Confirmation" field.
- 4 Click "Save & Apply".
- **5** Use your new password the next time you log into the CMM5.

Cambium Networks	Unsaved Ch
MMS Controller vBP3B12.1.2 49970	
Status System Services Network Locaut. System Shutdown	
System Administration SNNP Backup / Flash Firmware Reboot	
Router Password	
Changes the administrator password for accessing the device	
Password	() ()
Confirmation	· · · · · · · · · · · · · · · · · · ·
SSH Access	
Dronbear offers SSH network shell access and an integrated S/CP server	
Dropbear Instance	
	x)Delete
Interrace	
	· unspeciee
But	Uter only on the given interface or, if unspecified, on all
POR .	Specifies the listening port of this Dropbear instance
Password authentication	🗭 💿 Allow S2H password authentication
Allow root logins with password	🗭 🥃 Allow the root user to login with password
Gateway ports	🔲 🕒 Allow remote heats to connect to local SSH forwarded ports
* Add	
SSH-Keys	
Here you can paste public SSH-Keys (one per line) for SSH public-key authentication.	
Reset	Save U Save A Acc

View and Configure Network Interfaces

The Network page includes four tabs, Interfaces, Static Routes, Firewall and Diagnostics. The Interfaces tab is used to configure the Controller Ethernet interface. This screen displays the status of an existing interface:

- Uptime
- MAC address

- IPv4 address
- Rx packets
- Tx packets

	Cambium Ne	tworks							Unsaved Changes: (
CMM5	Controller vRP3B12.1.2	9970							
Statu	s System Services	Network							
Inter	faces Static Routes	Firewall Diagnostics	_		_	_	_		
Inter	faces								
Inte	erface Overview								
	Network	Status				A	ctions		
	LAN E eth0	Uptime: 18h 40m 15 MAC-Address: B8:27:EB:CC:18:64 RX: 90.04 MB (132702 Pkts.) TX: 4.43 MB (33096 Pkts.) IPv4: 10.120.210.111/24	2	Connect	8	Stop		Edit	X Delete
🖹 A	dd new interface							Save 2	Save & Apply

You can perform the following actions from this screen:

- Connect
- Stop
- Edit
- Delete
- Add new interface

By default the Controller is provisioned with a single Ethernet interface which is configured to use DHCP to assign an IP address. If your network does not support DHCP you must configure a static IP address on the Controller. This can be done in either of two ways: edit the existing interface or add a new interface.

Reconfigure an Existing Network Interface

Perform the following steps to reconfigure the default network interface on the Controller. The same procedure can also be used to change the configuration on any provisioned interface at a later date:

This procedure is written assuming that an IPv4 address will be used. If the interface is to be configured as IPv6 then the IPv6 address, IPv6 gateway and IPv6 routed prefix fields will need to be entered instead.

Procedure 9 Reconfigure an Existing Network Interface



Log into the Controller GUI using your password.

2 From the Interfaces tab under the Network page, click the Edit button to edit the configuration of an existing interface.

	Cambium Net	works							Un	saved Changes
CMM5	Controller vRP3B12.1.2 49	970								
Statu	is System Services	Network Logout System Shutdo								
Inte	rfaces Static Routes	Firewall Diagnostics	_	_	_	_	_	_	_	_
Inter	faces									
Int	erface Overview									
	Network	Status				A	Actions			
	LAN	Uptime: 0h 0m 0s MAC-Address: 88:27:58:42:30:09		-		-		-		
	eth0	RX: 97.33 KB (1605 Pkts.) TX: 254 82 KB (750 Pkts.)	1	Connect		Stop	. <	Edit	*	Delete
1	dd new interface									
Res	set							Sa	ive 💷 S	Save & Apply

3

From the Protocol pull-down menu select Static address.

Cambium Networks	Unsaved Chan
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network	agout System Shutdown
Interfaces Static Routes Firewall Diagno	25
LAN	
Interfaces - LAN	
On this page you can configure the network interfive VLAN notation INTERFACE.VLANNR (e.g.: eth0.1).	5. You can bridge several interfaces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also use
Status	Uptime: 0h 0m 0s Mc-Address: 88:27:EB:A2:30:09 etho RX: 123.98 KB (1905 PMts.) TX: 314.98 KB (1024 PMts.)
Protocol	Static address
Really switch protocol?	Switch protocol
Back to Overview Reset	🕲 Save 🛽 🛛 Save & Appl

4

Click the Switch Protocol button to confirm the change from DHCP to Static address.

Cambium Networks	Unsaved Ch	ange
4M5 Controller vRP3B12.1.2 49970		
Status Sustan Sanisas Naturak Laseut Sustan Shutday		
Interfaces Static Routes Firewall Diagnostics	"	
LAN		
nterfaces - LAN		
n this page you can configure the network interfaces. You can bridge several interfac LAN notation INTERFACE.VLANNR (e.g.: eth0.1).	es by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also us	se
Common Configuration		
General Setup		
Status	Uptime: 0h 0m 0s #MAC-Address: B8:27:EB:A2:30:09 etho RX: 134 75 KB (2136 PMs.) TX: 326.10 KB (1095 PMs.)	
Protocol	Static address	
Really switch protocol?	Switch protocol	
Back to Overview @Reset	Save Save Save	pply

5

Enter the desired static IP address in the IPv4 address field.

Cambium Networks	Unsaved Changes
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdo	wn _
Interfaces Static Routes Firewall Diagnostics	
LAN	
Interfaces - LAN	
On this page you can configure the network interfaces. You can bridge several interfaces <u>VLAN</u> notation INTERFACE.VLANNR (e.g.: eth0.1).	ces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also
Common Configuration	
General Setup Advanced Settings Physical Settings Firewall Settings	
Status	Uptime: 0h 0m 0s MAC-Address: 88:27:E8:A2:3D:09 etto RX: 211.2X E8 (3168 Pkts.) TX: 445.63 KB (1684 Pkts.)
Protocol	Static address
IPv4 address	10.120.210.201
IPv4 netmask	▼
IPv4 gateway	
IPv4 broadcast	
Use custom DNS servers	

6 Choose the preferred IPv4 netmask from the pull-down menu. Alternatively select – custom – and enter a custom mask, if desired.

Cambium Networks	Unsaved Change
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdo	wn .
Interfaces Static Routes Firewall Diagnostics	
LAN	
Interfaces - LAN	
On this page you can configure the network interfaces. You can bridge several interfaces vLaNn notation INTERFACE.VLANNR (e.g.: eth0.1).	aces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also
Common Configuration	
General Setup Advanced Settings Physical Settings Firewall Settings	
Status	Uptime: 0h 0m 0s #MAC-Address: B2:0727E3:A2:3D:09 etho RX: 2027.1 KB (3057 PKts.) TX: 436.28 KB (1625 Pkts.)
Protocol	Static address
IPv4 address	10.120.210.201
IPv4 netmask	255.255.255.0
IPv4 gateway	
IPv4 broadcast	
Use custom DNS servers	

7

Enter the IPv4 gateway address.

Cambium Networks	Unsaved Changes
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shut	lown
Interfaces Static Routes Firewall Diagnostics	
LAN	
Interfaces - LAN	
On this page you can configure the network interfaces. You can bridge several inter use <u>VLAN</u> notation INTERFACE.VLANNR (e.g.: eth0.1).	faces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also
Common Configuration	
General Setup Advanced Settings Physical Settings Firewall Settings	
Status	Uptime: 0h 0m 05 MAC-Address: 88:27:EB:A2:3D:09 etb 0X: 222.42 KB (3317 PMs.) TX: 457.95 KB (1762 PMs.)
Protocol	Static address
IPv4 address	10.120.210.201
IPv4 netmask	255.255.255.0
IPv4 gateway	10.120.210.254
IPv4 broadcast	
Use custom DNS servers	

8

Click Save & Apply to save the newly entered configuration.

9 Log into the Controller at the newly configured static IP address and initiate a reboot from the System page.

After applying the configuration the Controller will be accessible at the new static IP address but will no longer be reachable from the fallback IP address. After the reboot it can be accessed using either the new static IP or the fallback IP.

Configure a New Network Interface

Perform the following steps to configure a new network interface on the Controller:

This procedure is written assuming that an IPv4 address will be used.

Procedure 10 Configure a New Network Interface

- **1** Log into the Controller GUI using your password.
- 2 From the Interfaces tab under the Network page, click the Add new interface... button to add a new interface.

16														Ur	saved Cha	anges:
	Cambium	n Networks														
CMM5	Controller vRP3B12	2.1.2 49970														
Statu	is System Se	rvices Network	Logout	System Shutdown												
Inte	rfaces Static Ro	outes Firewall	Diagnostics													
Inter	faces															_
Int	erface Overvie	N														
	Network	Status									А	ctions				
	LAN	Uptime	: 0h 0m 0s													
	eth0	MAC-A0 RX: 97. TX: 254	ddress: 88:27:EB:A2:30 .33 KB (1605 Pkts.) 4.82 KB (750 Pkts.)	2:09				2	Conne	:t 🧯	Stop		Edit	*	Delete	
<u>A</u>	dd new interface]														
Res	set												Sa	ve 💷	Save & Ap	oply

- 3
 - On the Create Interface page enter the chosen name for the new interface.

	U	Jnsaved Change
Cambium Networks		
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout System Shutdow		
Interfaces Static Routes Firewall Diagnostics		
Create Interface		
Name of the new interface	Demo_Static_IP ↓ The allowed characters are: λ-2, s-2, s-3 and _	
Note: interface name length	Ø Maximum length of the name is 15 characters including the automatic protocol/bridge prefix (br-, 6in4-, pppoe- etc.)	
Protocol of the new interface	Static address	
Create a bridge over multiple interfaces		
Cover the following interface	○ Ethernet Adapter: 'etho' (lan)	
Back to Overview		Submit
		- Subinit

4 Select the protocol from the pull-down menu.

Cambium Networks		Unsaved Change
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout	System Shutdown	
Interfaces Static Routes Firewall Diagnostics		
Create Interface		
Name of the new interface	Demo_Static_IP The allowed characters are: A-2, a-2, 0-5 and _	
Note: interface name length	Maximum length of the name is 15 characters including the automatic protocol/bridge prefix (br-, 6in4-, pppoe- etc.)	
Protocol of the new interface	Static address	
Create a bridge over multiple interfaces		
Cover the following interface	○ Ethernet Adapter: "etho" (lan) ○ ¿ Custom Interface:	
Back to Overview		Submit

5

Select the eth0 interface to associate the new interface with the Controller Ethernet adapter.

		Unsaved Change
Cambium Networks		
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout System Shutdow		
Interfaces Static Routes Firewall Diagnostics		
Create Interface		
Name of the new interface	Demo_Static_IP The allowed characters are: x-2, x-2, 0-9 and _	
Note: interface name length	Ø Maximum length of the name is 15 characters including the automatic protocol/bridge prefix (br-, 6in4-, pppoe- etc.)	
Protocol of the new interface	Static address	
Create a bridge over multiple interfaces		
Cover the following interface	● Z Ethernet Adapter: "eth0" (<u>lan</u>) ○ Z Custom Interface:	
Back to Overview		Submit

6

Click Submit to create the new interface.

7

Enter the desired static IP address in the IPv4 address field.

Cambium Networks	Unsaved Changes:
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdown	
Interfaces Static Routes Firewall Diagnostics	
DEMO_STATIC_IP LAN	
Interfaces - DEMO_STATIC_IP	
On this page you can configure the network interfaces. You can bridge several interface use \underline{VLAN} notation INTERFACE.VLANNR (e.g.: eth0.1).	as by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also
Common Configuration	
General Setup Advanced Settings Physical Settings Firewall Settings	
Status	Uptime: 0h 0m 0s MC-Address: B8:27:E8:42:3D:09 etho RX: 102.01 K8 (1602 Pkts.) TX: 224.78 K8 (745 Pkts.)
Protocol	Static address
IPv4 address	10.120.210.201
IPv4 netmask	×
IPv4 gateway	
IPv4 broadcast	
Use custom DNS servers	*

8 Choose the preferred IPv4 netmask from the pull-down menu. Alternatively select – custom – and enter a custom mask, if desired.

Cambium Networks	Unsaved Change
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdow	wn .
Interfaces Static Routes Firewall Diagnostics	
DEMO_STATIC_IP LAN	
Interfaces - DEMO_STATIC_IP	
On this page you can configure the network interfaces. You can bridge several interfa use VLAN notation INTERFACE.VLANNR (e.g.: eth0.1).	ces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by spaces. You can also
Common Configuration	
General Setup Advanced Settings Physical Settings Firewall Settings	
Status	Uptime: 0h 0m 0s #MAC-Address: 08:27:08:A2:30:09 etho RX: 1002 KB (1730 Pkts.) TX: 235.16 KB (912 Pkts.)
Protocol	Static address
IPv4 address	10.120.210.201
IPv4 netmask	255 255 255 0
IPv4 gateway	
IPv4 broadcast	
Use custom DNS servers	

9

Enter the IPv4 gateway address.

Cambi	um Networks		Unsaved Changes
CMM5 Controller vRF	23B12.1.2 49970		
Status System	Services Network Logout System Shutdow	n -	<u> </u>
Interfaces Sta	tic Routes Firewall Diagnostics		_
DEMO_STATIC_I	P LAN		_
Interfaces - DE	MO_STATIC_IP		
On this page you ca use VLAN notation 1	n configure the network interfaces. You can bridge several interface. INTERFACE.VLANNR (e.g.: eth0.1).	ces by ticking the "bridge interfaces" field and enter the names of several network interfaces separated by space	s. You can also
Common Conf	iguration		
General Setup	Advanced Settings Physical Settings Firewall Settings		
Status		Uptime: 0h 0m 0s WAC-Address: B8:27:EB:A2:3D:09 etho RX: 128.25 KB (1981 Pkts.) TX: 255.57 KB (945 Pkts.)	
Protocol		Static address	
IPv4 address		10.120.210.201	
IPv4 netmask		255.255.255.0	
IPv4 gateway		10.120.210.254	
IPv4 broadcast			
Use custom DNS	servers		



Click Save & Apply to save the newly entered configuration.

11 Log into the Controller at the new static IP address to confirm it was successfully added to the Controller network configuration.

The Controller remains accessible on the fallback IP address (169.254.1.1). If the Controller is not accessible at the new IP address, check the Uptime field for the new interface to ensure it is incrementing. If it is not, click the Connect button to initialize it.

Configure System Properties and Time Synchronization

The System page includes five tabs, System, Administration, SNMP, Backup / Flash Firmware and Reboot. The System tab is used to configure the System Properties and the Time Synchronization. From the System screen, you can perform the following:

- Set the Hostname
- Set the Timezone
- Synchronize the Local Time with the browser
- Configure operation as an NTP client or server
- Configuration operation with UGPS

When first booted up the Controller's local time display will revert to the last value saved in flash memory. To show the correct time it is necessary to synchronize it to your browser time, or preferably to configure the Controller to use either an NTP server or the GPS data provided by the UGPS module as a time source.

Cambium Networks		Unsaved Chang
MM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout System Shu	down	
System Administration SNMP Backup / Flash Firmware Reboot		
System		
Here you can configure the basic aspects of your device like its hostname or the	imezone.	
System Properties		
General Settings Logging Language and Style		
Local Time	Sun Oct 16 01:17:36 2016 D Sync with browser	
Hostname	CMM5	
Timezone	UTC •	
Time Synchronization		
Verify GPS Message Checksum		
Use GPS or NTP:	GPS NTP	
Reset	Save Save	Save & Apply

Configure System Properties

Perform the following steps to configure the System Properties on the Controller:

Procedure 11 Configure the System Properties



Log into the Controller GUI using your password.

2 From the System tab under the System page, enter the desired Hostname.

Cambium Networks	Unsaved Change
CMMS Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdown	
System Administration SNMP Backup / Flash Firmware Reboot	
System	
————————————————————————————————————	
System Properties	
General Settings Logging Language and Style	
Local Time	Sun Oct 16 01:30:37 2016 Sync with browser
Hostname	ChMi5_Demo
Timezone	UTC •
Time Synchronization	
Verify GPS Message Checksum	
Use GPS or NTP:	GPS
	~ arr
1	
Reset	Save Save & Apply

Select the local timezone from the Timezone pull-down menu.

The Controller defaults to UTC time. The available time zones are listed by region followed by the city or country.

Cambium Networks	Unsa	wed Change
CMMS Controller vRP3B12.1.2 49970		
Status System Services Network Logout System Shutdown		
System Administration SNMP Backup / Flash Firmware Reboot		
System		
Here you can configure the basic aspects of your device like its hostname or the timezone		
System Properties		
General Settings Logging Language and Style		
Local Time	Sun Oct 16 01:31:17 2016 Sync with browser	
Hostname	CMM5_Demo	
Timezone	America/Chicago •	
Time Synchronization		
Verify GPS Message Checksum		
Use GPS or NTP:	GPS NTP	
Reset	Save Dave Save	e & Apply

4

Click Save & Apply to save the configured settings.

³

5

The Controller local time may be synchronized with your browser by clicking the Sync with browser button.

It is suggested that synchronization with the browser time is used only as a temporary means to set the local time until the Controller is configured to use either an NTP server or GPS data as a synchronization source, as described in the procedures below. These sources are tracked continuously and will maintain a more accurate local time setting.

Cambium Networks	Unsaved Changes
CMMS Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdown	
System Administration SNMP Backup / Flash Firmware Reboot	
System	
Here you can configure the basic aspects of your device like its hostname or the timezone.	
System Properties	
General Settings Logging Language and Style	
Local Time	Sun Oct 16 01:31:17 2016 Sync with browser
Hostname	CMM5_Demo
Timezone	America/Chicago •
Time Synchronization	
Verify GPS Message Checksum	0
Use GPS or NTP:	© GPS ◎ NTP
Reset	Save Save & Apply

Configure GPS Time Synchronization

Perform the following steps to configure Local Time on the Controller to be synchronized to the GPS data sourced from the UGPS module:

Procedure 12 Configure GPS Time Synchronization

1 Log into the Controller GUI using your password.

2 From the System tab under the System page, check the Verify GPS Message Checksum box.

Checking this box will cause the controller to verify that the checksum is correct for each GPS message that is received from the UGPS module. A count of invalid messages is kept and may be used for troubleshooting purposes.

Combium Networks	Un	saved Change
CMM5 Controller vRP3812.1.2 49970		
Status System Services Network Logout System Shutdown		l .
System Administration SNMP Backup / Flash Firmware Reboot		
System		
Here you can configure the basic aspects of your device like its hostname or the timezone	a.	
System Properties		
General Settings Logging Language and Style		
Local Time	Sat Oct 15 21:46:05 2016 2 Sync with browser	
Hostname	CMM5_Demo	
Timezone	America/Chicago •	
Time Synchronization		
Verify GPS Message Checksum	8	
Use GPS or NTP:		
l		
Reset	Save 2 St	ave & Apply

3

Click the GPS button to select GPS as the source for local time synchronization.

Cambium Networks	Unsaved Change
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdown	
System Administration SNMP Backup / Flash Firmware Reboot	
System	
Here you can configure the basic aspects of your device like its hostname or the timezone.	
System Properties	
General Settings Logging Language and Style	
Local Time	Sat Oct 15 21:46:40 2016 🔯 Sync with browser
Hostname	CMM/5_Demo
Timezone	AmericalChicago
Time Synchronization	
Verify GPS Message Checksum	2
Use GPS or NTP:	© GPS © NTP
Enable Time Sync using GPS Data (if available)	
Reset	Save 3 Save & Apply

4 Check the Enable Time Sync using GPS Data box. This checkbox appears when the GPS synchronization source is selected.

Cambium Networks	
MM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System	hutdown
System Administration SNMP Backup / Flash Firmware Reboot	
System	
Here you can configure the basic aspects of your device like its hostname or t	e timezone.
System Properties	
General Settings Logging Language and Style	
Local Time	Sat Oct 15 21:47:10 2016 🔯 Sync with browser
Hostname	CMM5_Demo
Timezone	AmericalChicago •
Time Synchronization	
Verify GPS Message Checksum	2
Use GPS or NTP:	® GPS ◎ NTP
Enable Time Sync using GPS Data (if available)	8
Reset	Save & App

5

Click Save & Apply to save the newly entered configuration.

6 After a short time the Local Time display will be synchronized with the GPS time from the UGPS module.

Cambium Networks		Unsaved Change
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout System Shutdown		i
System Administration SNMP Backup / Flash Firmware Reboot		
System		
Here you can configure the basic aspects of your device like its hostname or the timezone.		
System Properties		
General Settings Logging Language and Style		
Local Time	Mon Aug 20 19:12:19 2018 Sync with browser	
Hostname	CMM5_Demo	
Timezone	America/Chicago v	
Time Synchronization		
Verify GPS Message Checksum	8	
Use GPS or NTP:	® GPS ○ NTP	
Enable Time Sync using GPS Data (if available)	8	
@ Devel		nun III Caux & Annha
a Kazar	08	Ive Save & Apply

Configure NTP Time Synchronization

Perform the following steps to configure Local Time on the Controller to be synchronized to an NTP server. Note that as of this version of CMM5 firmware, the use of the CMM5 Controller as an NTP server is not supported.:

Procedure 13 Configure NTP Time Synchronization



Log into the Controller GUI using your password.

2 Click the NTP button to select an NTP server as the source for local time synchronization.

Cambium Networks	Unsaved Chang
CMM5 Controller vRP3812.1.2 49970	
Status System Services Network Logout System Shutdown	
System Administration SNMP Backup / Flash Firmware Reboot	
System	
Here you can configure the basic aspects of your device like its hostname or the timezone.	
System Properties	
General Settings Logging Language and Style	
Local Time	Sat Oct 15 22:10:40 2016 Sync with browser
Hostname	CMM5_Demo
Timezone	America/Chicago •
Time Synchronization	
Verify GPS Message Checksum	
Use GPS or NTP:	© GPS ● NTP
Enable NTP client	0
Reset	Save Save & Apply

3

Check the Enable NTP client button to configure the Controller as an NTP client.

Depending on the circumstances the Enable NTP client box may already be checked.

Cambium Networks			Unsaved Chang
MMS Controller vRP3B12 1 2 49970			
Status System Services Network Logout System Shutde	own		
System Administration SNMP Backup / Flash Firmware Reboot			
Sustan			
system			
Here you can configure the basic aspects of your device like its hostname or the tim	nezone.		
System Properties			
General Settings Logging Language and Style	Eat Out 15 22-11-00 2016	Come with hermone	
Local Time	Sat Oct 15 22:11:00 2016	Sync with browser	
Hostname	CMM5_Demo		
Timezone	America/Chicago	Ŧ	
Time function			
Verify GPS Message Checksum			
Uro GDE or NTD:	C CDC		
use or 5 of Mir.	NTP		
Enable NTP client	8		
Provide NTP server			
NTP server candidates	0.pool.ntp.org	×	
	1.pool.ntp.org	<u> </u>	
	3.pool.ntp.org	<u></u>	
Beset			Save Save & Apply

4 Delete any unneeded rows in the NTP server candidates list by clicking the red 'X' next to each row. In this example only one server is to be configured so three rows are deleted.

Deleting the unused rows is not mandatory, but removes unnecessary clutter from the NTP server candidates list.

Cambium Networks	Unsaved Changer
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdown	
System Administration SNMP Backup / Flash Firmware Reboot	
System	
Here you can configure the basic aspects of your device like its hostname or the timezone.	
System Properties	
General Settings Logging Language and Style	
Local Time	Sat Oct 15 22:13:23 2016 Sync with browser
Hostname	CNM/5_Demo
Timezone	America/Chicago •
- Time Synchronization	
Verify GPS Message Checksum	0
Use GPS or NTP:	© GPS ® NTP
Enable NTP client	8
Provide NTP server	8
NTP server candidates	3. pool.ntp.org
Reset	Save Dave & Apply

5

Enter the IP address of each NTP server to be configured in the candidates list.

Cambium Networks	Unsaved Chang
CMMS Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdown	
System Administration SNMP Backup / Flash Firmware Reboot	
System	
Here you can configure the basic aspects of your device like its hostname or the timezone.	
System Properties	
General Settings Logging Language and Style	
Local Time	Sat Oct 15 22:13:53 2016 DSync with browser
Hostname	CMM5_Demo
Timezone	America/Chicago v
Time Synchronization	
Verify GPS Message Checksum	0
Use GPS or NTP:	© GPS ● NTP
Enable NTP client	2
Provide NTP server	
NTP server candidates	10.120.12.31
2 Reset	Save a Apply

6

Click Save & Apply to save the newly entered configuration.

7 After a short time the Local Time display will be synchronized with the NTP time from the NTP server.

Cambium Networks	Unsaved Chang
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Shutdown	
System Administration SNMP Backup / Flash Firmware Reboot	
System	
Here you can configure the basic aspects of your device like its hostname or the timezone.	
System Properties	
General Settings Logging Language and Style	
Local Time	Mon Aug 20 19:13:15 2018 Sync with browser
Hostname	CMM5_Demo
Timezone	America/Chicago •
Time Synchronization	
Verify GPS Message Checksum	0
Use GPS or NTP:	© GPS ® NTP
Enable NTP client	8
Provide NTP server	0
NTP server candidates	10.120.12.31
Reset	🥝 Save 😰 Save & Apply

Configure SNMP

The CMM5 Controller incorporates an SNMP agent which supports the following remote management capabilities:

- Querying of CMM5 configuration parameters via the SNMP GetRequest
- Querying of CMM5 basic performance measurements via the SNMP GetRequest
- Sending of unsolicited trap notifications in response to detection or clearing of various state changes and error conditions
- SNMP v2c and v3 protocols

NOTE

Remote modification of CMM5 configuration parameters via the SNMP SetRequest is not supported.

Configuration of SNMP operations is accomplished from the SNMP tab on the System GUI page.

Basic SNMP Configuration

The basic SNMP configuration includes the following settings:

- SNMP protocol version
- Default port numbers for queries and trap notifications
- SNMP accessing IP address list
- SNMP trap IP address list
- Sync status trap enable
- Site information

Perform the following steps to configure the basic SNMP settings:

Procedure 14 Basic SNMP Configuration

- **1** Log into the Controller GUI using your password.
- 2 Choose the desired SNMP protocol version from the SNMP Version pull-down menu. The available options are SNMPv2c Only, SNMPv3 Only, or SNMPv2c and SNMPv3.

If the SNMPv2c and SNMPv3 option is selected the Controller will respond to a GetRequest sent with either protocol version, but trap notifications will be sent using only the only SNMPv3 protocol.

Cambium Networks	Unsaved Ch
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network	Logout System Shutdown
System Administration SNMP Back	up / Flash Firmware Reboot
SNMP Version:	SNMPv2c Only
Default Port:	161
Trap Port:	162

3

Change the Default Port and Trap Port, if desired.

Under most circumstances the default settings can be used. The port numbers must match the configuration of the tool used to send SNMP queries and receive query responses and trap notifications.

Cambium Networks		Unsaved Changes:
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network	Logout System Shutdown	
System Administration SNMP Bac	kup / Flash Firmware Reboot	
SNMP Version:	SNMPv2c Only	
Default Port:	161	
Trap Port:	162	

4 Configure the IP addresses and associated subnet masks in the Accessing IP list, if desired. Each row defines a range of IP addresses containing the specified IP address and constrained by the associated mask. A maximum of 10 IP addresses and subnets are supported.

If no IP addresses are specified then the Controller will respond to SNMP queries from any valid IP address. If an address is entered without a mask then it defines a single IP address (effectively defaulting to a /32 mask).

SNMP IP					
Accessing IP / Subnet Mask 1:	10.120.210.1	/	24		
Accessing IP / Subnet Mask 2:	0.0.0	/	0		
Accessing IP / Subnet Mask 3:	0.0.0	/	0		
Accessing IP / Subnet Mask 4:	0.0.0.0]/	0		
Accessing IP / Subnet Mask 5:	0.0.0.0]/	0		
Accessing IP / Subnet Mask 6:	0.0.0.0	/	0		
Accessing IP / Subnet Mask 7:	0.0.0.0	/	0		
Accessing IP / Subnet Mask 8:	0.0.0.0	/	0		
Accessing IP / Subnet Mask 9:	0.0.0.0	/	0		
Accessing IP / Subnet Mask 10:	0.0.0.0]/	0		

5 Enter the IP address of each trap received to be configured in the Trap Addresses list. A maximum of 10 IP addresses are supported.

If no IP addresses are specified then the Controller will not send any trap notifications.

Trap Addresses				
Trap Address 1:	10.120.210.1			
Trap Address 2:	0.0.0.0			
Trap Address 3:	0.0.0.0			
Trap Address 4:	0.0.0.0			
Trap Address 5:	0.0.0.0			
Trap Address 6:	0.0.0.0			
Trap Address 7:	0.0.0			
Trap Address 8:	0.0.0.0			
Trap Address 9:	0.0.0			
Trap Address 10:	0.0.0.0			

6 Click the Enable button in the Trap Enable section to turn on Sync Status trap notifications, if desired.

Trap Enable			
Sync Status:	● Enable ● Disable		

Site Information			
Site Name:	No Site Name		
Site Contact:	No Site Contact		
Site Location:	No Site Location		

7

Enter the Site Name, Site Contact and Site Location details in the Site Information section.

Trap Enable			
Sync Status:			
	Site Information		
Site Name: CMM5_Demo			
Site Contact: Cambium Networks			
Site Location:	Classroom		

8

Click Save to save the newly entered configuration.

Configure SNMPv2c Operation

Perform the following steps to configure the Controller for SNMPv2c operation:

Procedure 15 Configure SNMPv2c Operation

- **1** Log into the Controller GUI using your password.
- **2** Check that the SNMPv2c protocol is selected in the SNMP Version pull-down menu. Either the SNMPv2c Only or the SNMPv2c and SNMPv3 option may be used.

If the SNMPv2c and SNMPv3 option is selected the Controller will respond to a GetRequest sent with either protocol version, but trap notifications will be sent using only the SNMPv3 protocol.

Cambium Networks			Unsaved Changes
CMM5 Controller vRP3B12.1.2 49970			
Status System Services Network	Logout System Shutdown		
System Administration SNMP Back	up / Flash Firmware Reboot		
SNMP Version:	SNMPv2c Only		
Default Port:	161		
Trap Port:	162		
· · · · · · · · · · · · · · · · · · ·			

3 Set the SNMP Community String 1 value and Permissions. Typically this is configured as the read/write community string that is used for remote network management.

The Controller does not support SNMP write operations. The Read/Write option for community string 1 is provided to maintain consistency with other Cambium Networks platforms.

Cambium Networks		Unsaved Change
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network	Logout System Shutdown	
System Administration SNMP Bac	kup / Flash Firmware Reboot	
SNMP Version:	SNMPv2c Only	
Default Port:	161	[]
Trap Port:	162	
u		
	SNMPv2c Settings	
SNMP Community String 1:	Canopy	
SNMP Community String 1 Permissions:	Read Only Read/Write	
SNMP Community String 2 (Read Only):	Canopyro	

4

Set the SNMP Community String 2 value. This is typically configured as the read only community string.

Cambium Networks		Unsaved Change
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network	Logout System Shutdown	
System Administration SNMP Bac	kup / Flash Firmware Reboot	
SNMP Version:	SNMPv2c Only]
		d
Default Port:	161	1
Trap Port:	162	
		a 2
	SNMPv2c Settings	
SNMP Community String 1:	Canopy	i i i i i i i i i i i i i i i i i i i
SNMP Community String 1 Permissions:	Read Only Read/Write	
SNMP Community String 2 (Read Only):	Canopyro	
		•

5

Click Save to save the newly entered configuration.

Configure SNMPv3 Operation

Perform the following steps to configure the Controller for SNMPv3 operation:

Procedure 16 Configure SNMPv3 Operation

1 Log into the Controller GUI using your password.

2 Check that the SNMPv3 protocol is selected in the SNMP Version pull-down menu. Either the SNMPv3 Only or the SNMPv2c and SNMPv3 option may be used.

If the SNMPv2c and SNMPv3 option is selected the Controller will respond to a GetRequest sent with either protocol version, but trap notifications will be sent using only the SNMPv3 protocol. This configuration is less secure than the SNMPv3 Only option.



3

Configure the EngineID string if the default value is not being used. Enter a string of between 1 and 27 characters in length.

The Controller automatically generates an EngineID string based on its MAC address, but a custom value can be entered to override this default value if required.

	SNMPv3 Settings	
EngineID:	0x80001f8803b827eba23d09 DemoString	Use MAC Address
SNMPv3 Security Level:	noAuth,noPriv 🔹	
SNMPv3 Authentication Protocol:	MD5 T	
SNMPv3 Privacy Protocol:	AES	

4

Select the SNMP authorization and privacy security settings from the SNMPv3 Security Level pull-down menu. The available options are as follows: noAuth, noPriv; Auth, noPriv; Auth, Priv.

SNMPv3 Settings						
EngineID:	0x80001f8803b827eba23d09 DemoString Use MAC Address					
SNMPv3 Security Level:	Auth,Priv 🔹					
SNMPv3 Authentication Protocol:	MD5 •					
SNMPv3 Privacy Protocol:	AES •					

5 Set the protocols to be used for authentication and privacy, if these security levels were enabled during the previous step. Available protocol options for authentication are MD5 and SHA. Privacy protocol options are DES and AES.

SNMPv3 Settings							
EngineID:	0x80001f8803b827eba23d09 DemoString Use MAC Address						
SNMPv3 Security Level:	Auth,Priv •						
SNMPv3 Authentication Protocol:	MD5 T						
SNMPv3 Privacy Protocol:	AES v						

6

Configure the SNMPv3 Read-Only User and Read/Write User details. For each user enter the username and specify the authentication key and privacy key if these security levels are to be enabled.

The Controller gives the option to disable the Read/Write User if preferred. Because the Controller does not support SNMP write operations, doing so has the sole effect of blocking the use of the Read/Write Username for SNMPv3 transactions.

	SNMPv3 S	Settings
EngineID:	0x80001f8803b8 DemoString	327eba23d09 Use MAC Address
SNMPv3 Security Level:	Auth,Priv	¥
SNMPv3 Authentication Protocol:	MD5	¥
SNMPv3 Privacy Protocol:	AES	¥
SNMPv3 Read-Only User:	Username: Authorization Key: Privacy Key:	DemoUserRO
SNMPv3 Read/Write User:	Enable R/W User Disable R/W User Username: Authorization Key:	DemoUserRW
	Privacy Key:	••••••

7 Up to three additional users may be configured if required. Enter the username for each user and enable or disable the read/write mode as desired. Also specify the authentication keys and privacy keys, if applicable.

	Username:	DemoUser1RW
	Enable User Disable User	
Additional SNMPv3 User 1:	Authorization Key:	•••••
	Privacy Key:	•••••
	Read Only Read/Write	
	Username:	DemoUser2RO
	Enable User Disable User	
Additional SNMPv3 User 2:	Authorization Key:	
	Privacy Key:	•••••
	Read Only Read/Write	
	Username:	DemoUser3RO
	Enable User Disable User	
Additional SNMPv3 User 3:	Authorization Key:	······
	Privacy Key:	••••••
	Read Only Read/Write	
SNMPv3 Trap Configuration:	Disabled	¥

8 Select the trap behavior from SNMPv3 Trap Configuration pull-down menu. Available options are Disabled, Enabled for Read-Only User, and Enabled for Read/Write User. The choice of enabled option determines if the Controller will use the read-only username or the read/write username when sending trap notifications.

Additional SNMPv3 User 1:	Username: Enable User Disable User Authorization Key: Privacy Key:	DemoUser1RW
	 Read Only ● Read/Write 	
	Username:	DemoUser2RO
	Enable User Disable User	
Additional SNMPv3 User 2:	Authorization Key:	•••••
	Privacy Key:	•••••
Additional SNMPv3 User 2: Additional SNMPv3 User 3:	Read Only Read/Write	
	Username:	DemoUser3RO
	Enable User Disable User	
Additional SNMPv3 User 3:	Authorization Key:	•••••
	Privacy Key:	•••••
	Read Only Read/Write	
SNMPv3 Trap Configuration:	Enabled for Read-	Dnly User 🔹

Click Save to save the newly entered configuration.

9

Configure Injectors

The Injectors may be configured from the CMM5 tab on the Services page. From the CMM5 screen, you can perform the following:

- Discover new or replacement Injectors
- Set the chassis name for each Injector
- Set the port name for each ODU port

When first powered on the Controller's will check for connected Injectors and populate the CMM5 tab with each chassis detected. The Injector which is connected directly to the Controller via the USB cable is automatically assigned as the master Injector and is shown at the top of the Injector table. Additional daisy-chained Injector modules are designated as slave Injectors and are shown on successive rows in the table.

The order in which the slave Injectors are shown on the CMM5 screen is determined by the Controller and does not necessarily match the daisy-chain connection sequence.

controller vRP3	B12.1.2 499	970										
s System	Services	Network	Logout Syste	em Shutdown								
5 GPS												
										Force D	iscover Que	ery All 🜍
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watt
Identify	Query		Name	Serial	Letter	FW	1	Master_Port1	ON	ON	55	21
Blink	Query	CMM5_Demo_1	_	-1830B0001	А	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	ON	ON	55	9
56		40	ок	ок	NF		4	Master_Port4	ON	ON	55	14
dentify	Query		Name	Serial	Letter	FW	1	Slave_Port1_	ON	ON	56	8
Blink	Query	CMM5_Demo_2	_	-1723B020W	в	00.13	2	Slave_Port2_	ON	ON	56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8
56		36	ок	ок	NP		4	Slave_Port4_	ON	ON	56	9

Discover Injectors

In the event that changes are made to the physical inventory of Injectors connected to the Controller, a command must be run to rediscover the connected modules. This is required when any of the following scenarios applies:

- Expansion adding a new slave injector to the CMM5
- Replacement swapping an existing Injector with a new module (e.g. due to hardware failure)
- Deletion removing an unused slave Injector from the CMM5
Discovery may also be necessary during initial deployment of the CMM5 if the Controller is powered on before all of the Injectors are connected. Perform the following steps to discover or rediscover the Injectors connected to the Controller:

Procedure 17 Discover Injectors

- **1** Log into the Controller GUI using your password.
- **2** Add, delete or replace the Injectors connected to the Controller as required. Power down any units to be removed, before disconnection. Install the new or replacement unit, if applicable, and reconnect the cables as needed before applying power to the module.
- **3** On the CMM5 screen, click the Force Discover button to start the discovery process on the Controller.

ntroller vRP3	B12.1.2 499	70											
System	Services	Network Logout	System S	Shutdown									
GPS													
											Force D	Discover Qu	ary All 🧧
		ci	nassis Info				Port		Port Name	Port Status	Sync Status	Volts	Watt
entify	Query	Na	me	Serial	Letter	FW	1	Master_Port1		ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	А	00.21	2	Master_Port2		ON	ON	56	9
Туре		Temp	Sync	PS1	PS:	2	3	Master_Port3		ON	ON	55	9
56		40	ок	ок	NP		4	Master_Port4		ON	ON	55	14
												_	
entify	Query	Nar	ne	Serial	Letter	FW	1	Slave_Port1_		ON	ON	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_		ON	ON	56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_		ON	ON	56	8
56		36	OK	ок	NP		4	Slave_Port4_		ON	ON	56	9
												_	

4 The Controller starts a scan to identify all connected Injector modules. This process takes a few seconds to complete, during which time the Controller displays a message indicating that the command is in progress.



5 When the command execution is complete the CMM5 screen is refreshed to show all discovered Injectors. In this example a new slave Injector has been added.

um Net	works										Unsaved C
3B12.1.2 499	970										
Services	Network Lo	cout System 5	Shutdown								
					_	_			Force	iscover Oue	
									POICE L	acover Que	aly Ali 🖉 d
		Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Query	CLARK Dama 4	Name	Serial	Letter	FW	2	Master_Port1	ON	ON	55	0
Query	CMMS_Demo_1_	-	-183080001	Α	00.21	2	Master Port3	ON	ON	50	9
	Temp	Sync	PSI	PS2		4	Master Dort4	ON	ON	55	14
	39	UK UK	UK	102		-	master_r one	0.0	0.4		14
Query		Namo	Forial	Letter	EW	1	Slave Port1	ON	ON	56	8
	CMM5 Demo 2	nome	-1723B020W	R	00.13	2	Slave Port2	ON	ON	56	8
	Temp	Sync	PS1	- 852		3	Slave_Port3_	ON	ON	56	8
	37	OK	OK	NP		4	Slave Port4	ON	ON	56	9
Query		Name	Serial	Letter	FW	1	Port_1	ON	ON	55	0
Query	Name_not_set		-1721B01ZK	с	00.21	2	Port_2	ON	ON	55	0
		0	PS1	PS2		3	Port_3	ON	ON	55	0
	Temp	Sync									
	Um Net B12.1.2.499 Services Query Query Query Query Query Query	UN Networks IBI2.1.2.49970 Services Network to Query Query Query Query Query Query Query 21MM5_Demo 1_ Temp 39 Query 21MM5_Demo 2_ Temp 37 Query 20 Query	Im Networks IBJ2.1.2.49970 Services Network Logant System Query Query Chassis Info Temp Sync 39 Oct 29 Oct 29 Oct 29 Oct 29 Oct 29 Oct 29 Oct 20 Oct 27 Temp Sync 37 Oct 27 Temp Sync 37 Oct 27 Temp Sync 37 Oct 27 Name	In Networks BIT.1 2 49970 Services Network Lopole System Shutdown Chassis Info Genry Chassis Info Genry Neme Serial Chassis Office String Chassis Info Chassis Inf	Im Networks BID L1 2 49970 Services Network Lopole System Shuddwor Chassis Info Query Chassis Info Query Name Serial Letter Query Name Serial Letter Temp Sync PS1 PS2 37 Oct 07 B 27 PS1 PS2 17239020W B	Unit Networks BIZ.1.2.49970 Biz.1.2.49970 Example System Studious General Testend Easternal Letter FW Query MM45_Demo_1 -183080001 A 0.021 Temp Sync PS1 PS2 Query MM65_Demo_2 -17230920W B 0.013 Temp Sync PS1 PS2 0.013	Immetworks BIT.1.2.49970 Services National Coppert System Studioun Query Materia Service Letter PW 1 Query Chassis Info Port 1 2 2 Temp Sync PS1 PS2 3 3 20 Guery Mane Service Name 1 1 Query Name Service Name 1 2 3 20 Cuery Mate Service Name Service 1 2 21 Temp Sync PS1 PS2 3 3 2 3 22 Cuery Name Service PS1 PS2 3 3 2 32 Cuery Name Service PS1 PS2 3 3 2 3 3 2 3 3 2 3 3 2 3 3 2 3 3 3 3 3 3 <td>Operation of the second of the second</td> <td>Operative Standsom Operative Standsom</td> <td>Im Networks BDI: 1.2 + 49970 Services Network Lagoon Status Generation Status Operation Status</td> <td>Im Networks BDI 1. 2 + 9970 Services Network Lagoont Studies Force Discover Quarks Chassis Info Force Discover Quarks Genery Name Service Name Port Name Port Name Port Status Volts Query Name Service Name Port Port Name Port Status Volts Query Name Service Na Port Name Port Port Name Port Status Volts Query Name Service PS2 3 Master Port2 Colspan="2">Colspan="2">Colspan="2" Query Name Service PS2 3 Master Port2 Colspan="2" Query Name Service PS2 3 Sinter Port2</td>	Operation of the second	Operative Standsom Operative Standsom	Im Networks BDI: 1.2 + 49970 Services Network Lagoon Status Generation Status Operation Status	Im Networks BDI 1. 2 + 9970 Services Network Lagoont Studies Force Discover Quarks Chassis Info Force Discover Quarks Genery Name Service Name Port Name Port Name Port Status Volts Query Name Service Name Port Port Name Port Status Volts Query Name Service Na Port Name Port Port Name Port Status Volts Query Name Service PS2 3 Master Port2 Colspan="2">Colspan="2">Colspan="2" Query Name Service PS2 3 Master Port2 Colspan="2" Query Name Service PS2 3 Sinter Port2

6 If a new or replacement Injector has been added it may now be configured as needed.

Configure the Injector Chassis and Port Names

Perform the following steps to configure the System Properties on the Controller:

Procedure 18 Configure Injector Chassis and Port Names



- Log into the Controller GUI using your password.
- **2** From the CMM5 tab under the Services page, enter the desired chassis name for each Injector. The name can be a string up to 12 characters in length, with no spaces.

Any characters following a space are ignored by the Controller and will be discarded. It is recommended to use underscore characters to separate groups of characters if desired. Strings of less than 12 characters in length will be automatically padded with underscores by the Controller upon saving.

	3812.1.2 499	70										
s System	Services	Network Logo	ut System St	hutdown								
5 GPS	-						_					_
										Force D	liscover Qui	ery All 🜍
		c	hassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query		ame	Serial	Letter	FW	1	Port_1	ON	ON	55	21
Blink	Query	CMM5_Demo_1		-1830B0001	А	00.21	2	Port_2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Port_3	ON	ON	55	9
56		39	ок	ок	NP	6 - C	4	Port_4	ON	ON	55	14
Identify	Query	Ne	ame	Serial	Letter	FW	1	Port_1	ON	ON	56	8
	Query	CMM5_Demo_2		-1723B020W	в	00.13	2	Port_2	ON	ON	56	7
Blink		Temp	Sync	PS1	PS:	2	3	Port_3	ON	ON	56	8
Blink							4	Port 4	ON	ON	50	

3 Enter the desired name for the four ODU ports on each Injector.

As above, the name for each port can be a string up to 12 characters in length, with no spaces. Underscores may be used to separate groups of characters.

Controller vRP	3B12.1.2 499) 70										
tus System	Services	Network Log	jout System S	Shutdown								
M5 GPS												
										Force D	iscover Que	ery All 🔘
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query	101 M 15 0	Name	Serial	Letter	FW	1	Master_Port1	ON	ON	55	20
Blink	Query	CMM5_Demo_1		-1830B0001	A	00.21	2	Master_Port2	UN	UN	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	ON	ON	55	9
56		39	OK	OK	NF		4	Master_Port4	ON	ON	55	14
Identify	Query		Name	Serial	Letter	FW	1	Slave_Port1	ON	ON	56	8
Blink	Query	CMM5_Demo_2		-1723B020W	в	00.13	2	Slave_Port2	ON	ON	56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3	ON	ON	56	8
56		36	OK	OK	NF		4	Slave_Port4	ON	ON	56	9

4 Click Save to save the new chassis and port names.

Cambiu	im Noti	works										Unsaved Ch
	inneu	WORKS										
5 Controller vRP3	B12.1.2 499	70										
atus System	Services	Network Logo	sut System S	hutdown								
MM5 GPS												
										Force D	Discover Que	ery All 🕝 Sa
		,	Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query		łame	Serial	Letter	FW	1	Master_Port1	ON	ON	55	20
Blink	Query	CMM5_Demo_1		-1830B0001	А	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	ON	ON	55	9
56		39	OK	ОК	NF		4	Master_Port4	ON	ON	55	14
Identify	Query	N	lame	Serial	Letter	FW	1	Slave_Port1	ON	ON	56	8
Blink	Query	CMM5_Demo_2		-1723B020W	в	00.13	2	Slave_Port2	ON	ON	56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3	ON	ON	56	8
56		36	OK	ок	NF)	4	Slave_Port4	ON	ON	56	9

5

The new chassis and port names are displayed on the CMM5 tab. Note that Controller has added underscores to the end of the chassis names and slave Injector port names to meet the 12 character length requirement.

16														Unsaved Ch	anges
	ambiu	im Net	works												
CMM5 Cont	roller vRP3	B12.1.2 499	70												
Statue	System	Services	Network	Logout	System Shutdown										
Jucus	ayacum	Services	Notifolk .	Logour	System Shataonn										
СММ5	GPS														
												Force D	scover Que	ry All 🙄 Sa	ave
r															
				Chassis Info					Port	Port Name	Port Status	Sync Status	Volts	Watts	
Ide	ntify	Query		Name	Se	rial Le	tter	FW	1	Master_Port1	ON	ON	55	21	
() E	Blink	Query	CMM5_Demo_1	_	-1830	B0001	A 0	00.21	2	Master_Port2	ON	ON	56	9	
	Туре		Temp	Syr	c Pi	51	PS2		3	Master_Port3	ON	ON	55	9	
	56		40	01	0	к	NP		4	Master_Port4	ON	ON	55	14	
Ide	ntify	Query		Name	Ser	rial Le	tter	FW	1	Slave_Port1_	ON	ON	56	8	
0 E	Blink	Query	CMM5_Demo_2	_	-17238	3020W	в	00.13	2	Slave_Port2_	ON	ON	56	8	
	Туре		Temp	Syr	c PS	51	PS2		3	Slave_Port3_	ON	ON	56	8	
	56		36	01	0	к	NP		4	Slave_Port4_	ON	ON	56	9	
												Force D	iscover Que	iry All 🕝 Se	ave

Backup and Restore Configuration

The Controller offers the ability to archive the configuration in the form of a backup file. The file may be used to restore the saved configuration at a later date.

The backup file preserves only the Controller configuration. The Injector configuration, which includes the chassis and port names as well as the current ODU port states, is stored on the Injector and is not archived in the Controller backup file.

Backup Configuration

Perform the following steps to save a backup file for the current Controller configuration:

Procedure 19 Backup Controller Configuration

1 From the Backup / Flash Firmware tab on the System screen, click the Generate archive button to create the backup file.

Cambium Networks		Unsaved Changes
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout	System Shutdown	
System Administration SNMP Backup / Flash Firmware	Reboot	
Flash operations		
Actions		
Backup / Restore Click "Generate archive" to download a tar archive of the current of	infiguration files.	
Download backup:	Generate archive	
To restore configuration files, you can upload a previously generate	d backup archive here.	
Restore backup:	Choose File No file chosen	archive
Flash new firmware image Upload a sysupgrade-compatible image here to replace the running	firmware. Check "Keep settings" to retain the current configuration (requires a compatit	ie firmware image).
Keep settings:	8	
Image:	Choose File No file chosen	mage
Flash new CMM5 Injector firmware image Upload firmware to the Master Injector (injector with USB connecti	n)	
FW File:	Choose File No file chosen	le Firmware

2 Save the backup file to a suitable location.

The process for saving the backup file may vary depending on your browser settings.

🥏 Save As							x
🕞 🕞 – 📙 « Loo	cal Disk (C:) 🕨	CMM5 ►	Controller_Configurati	on_Backups	🔻 🍫 Sea	rch Controller_Con	fi 🔎
Organize 🔻 Nev	w folder					-	0
 Favorites Downloads Desktop Recent Places Dropbox Libraries Documents Music 			Name	No items match y	Date modified our search.	Туре	
 Sector Pictures Videos 		~	٠				4
File name:	backup-CMM	5_Demo-2	018-08-29.tar.gz				•
Save as type:	GZ File (.gz)						-
🔿 Hide Folders					Save	e Cance	

3

The Controller backup file is saved as a gzip archive. The default file name includes a date stamp for ease of identification.

Restore Configuration

Perform the following steps to restore the Controller configuration from a previously archived backup file:

Procedure 20 Restore Controller Configuration

1

From the Backup / Flash Firmware tab on the System screen, click the Choose File button in the Backup / Restore section of the page.

Cambium Networks		Unsaved Cha
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout System Shutdown		
System Administration SNMP Backup / Flash Firmware Reboot		
Flash operations		
Actions		
Backup / Restore - Click "Generate archive" to download a tar archive of the current configuration files.		
Download backup:	Generate archive	
To restore configuration files, you can upload a previously generated backup archive here.		
Restore backup:	Choose File No file chosen	Upload archive
Flash new firmware image Upload a sysupgrade-compatible image here to replace the running firmware. Check "Keep	o settings" to retain the current configuration (requ	uires a compatible firmware image).
Keep settings:	2	
Image:	Choose File No file chosen	I Flash image
Flash new CMM5 Injector firmware image Upload firmware to the Master Injector (injector with USB connection)		
FW File:	Choose File No file chosen	Dpgrade Firmware

2 Select the archived backup file to be restored.

🦻 Open		
🕞 🕘 🗕 🗼 « Local Disk (C:) 🕨 CN	IM5 Controller_Configuration_Backups	 ✓ ✓ Search Controller_Confi
Organize 🔻 New folder		III - 🚺 🔞
Downloads	Name	Date modified Type Siz
 Desktop Recent Places Dropbox 	backup-CMM5_Demo-2018-08-29.tar.gz	8/29/2018 5:04 PM GZ File
 □ Libraries □ Documents ■ Music ■ Pictures ■ Videos 		
Scomputer		
w Local Disk (C:) w PHN_Common (\\uk01srv01.c →	•	•
File name: backup	-CMM5_Demo-2018-08-29.tar.gz	 ✓ All Files ✓ Open ✓ Cancel

3 Confirm that the chosen backup file name is visible next to the Choose File button and click the Upload archive button to apply the saved configuration to the Controller.

Cambium Networks		nisaveu ch
MS Controller vRP3B12.1.2 49970		
itatus System Services Network Logout	System Shutdown	
ystem Administration SNMP Backup / Flash Firm	rre Reboot	_
ash operations		
ctions		
Backup / Restore Click "Generate archive" to download a tar archive of the cu	int configuration files.	
Download backup:	Generate archive	
To restore configuration files, you can upload a previously g	erated backup archive here.	
Restore backup:	Choose File backup-CMM529 tar.gz	
Flash new firmware image Upload a sysupgrade-compatible image here to replace the	nning firmware. Check "Keep settings" to retain the current configuration (requires a compatible firmware image).	
Keep settings:	8	
Image:	Choose File No file chosen	
Flash new CMM5 Injector firmware image Upload firmware to the Master Injector (injector with USB o	nedion)	
and the second sec	Object Bits March 19 (1997)	

4

The Controller reboots to apply the archived configuration from the backup file.

ystem - Rebooting
Changes applied.

5 Log back into the Controller using your password and confirm that the archived configuration has been restored.

CMM5 Injector Operation

The following paragraphs describe the operating procedures for a CMM5 Injector in standalone mode (Controller not present).

When a Controller is present the Injector operations can be run entirely from the Controller GUI interface. (Refer to the CMM5 Controller Operation section for details.)

Blink the CMM5 Injector LEDs

Perform the following steps to cause the Injector port LEDs to blink:

This procedure can be used to quickly verify communication with the Injector.

Procedure 21 Blink the Injector LEDs

- **1** Run the TeraTerm terminal emulator and start a serial session to the Injector COM port.
- 2 Execute the following query command to blink the Injector LEDs:

&0w

🚾 Tera Term - COM17 VT		×
File Edit Setup Control Window Help		
8.9w		*

3 The green and red LEDs will illuminate for one second on each of the four ODU ports will illuminate for one second.



Figure 16 Injector ODU Port LEDs Illuminated

Read the CMM5 Injector Status

Perform the following steps to read the current status of the Injector:

Procedure 22 Read the Injector Status

- 1
- Run the TeraTerm terminal emulator and start a serial session to the Injector COM port.
- 2 Execute the following query command to read the Injector status:

&0qA

3 The Injector responds with the current status as shown below:



4 The Injector type (56V or 29V), chassis temperature, sync status and power supply status are shown on the second and third rows:



5

The remaining four rows detail the status for each power port, including the port status, voltage and power drain, fault status and fault count, as described in the key below:

- Port status:
 - S = power and sync enabled
 - E = power enabled, sync disabled
 - D = power and sync disabled
- Fault status:
 - 1 = fault condition present
 - 0 = normal status (no fault)
- Fault count:
 - 0 3 = number of faults recorded since last port reset

🔟 Tera Term - COM17 VT		Х	
File Edit Setup Control Window Help			
&0qA ACCESS_LEVEL=00 &0qA,Type=56,Temp=43,Sync=0K &0qA,PriSup=0K,SecSup=NP,5v=50,Comm=0K &0qA,p1=S,v=56,w=011,fs=0,fc=00 &0qA,p2=E,v=56,w=008,fs=0,fc=00 &0qA,p3=S,v=55,w=009,fs=0,fc=00 &0qA,p4=D,v=46,w=000,fs=0,fc=00		*	

Read and Modify the CMM5 Injector Parameters

Perform the following steps to read the current parameter values from the Injector, and modify them if desired:

Procedure 23 Read and Modify the Injector Parameters



Run the TeraTerm terminal emulator and start a serial session to the Injector COM port.

2 Execute the following query command to read the Injector parameters:

&0p

3 The Injector responds with the current parameter settings as shown below:

- There are 20 parameters in total, of which the first 8 are settable by the user
- Three values are shown on each row, representing the current parameter setting, the minimum value, and the maximum value in the range respectively
- Parameters 1 through 4 represent the power states for each of the 4 ODU ports
 - \circ +0001 = enabled
 - \circ +0000 = disabled
- Parameters 5 through 8 represent the sync states for the 4 ODU ports
 - \circ +0001 = enabled
 - \circ +0000 = disabled

🧧 Tera Term - COM17 VT		x
File Edit Setup Control Window Help		
<pre>&0p &pIDNumber.Name.SetUalue.MinUalue.MaxUalue &0p01,port 1 enable.+0001.+0000,+0001 &0p02,port 2 enable.+0001.+0000,+0001 &0p03,port 3 enable.+0001.+0000,+0001 &0p05.sync enable 1,+0001.+0000,+0001 &0p06.sync enable 2,+0000,+0000,+0001 &0p07.sync enable 3,+0001.+0000,+0001 &0p09.sync parm 1,+0000,+0000,+0100 &0p19.sync parm 2,+0000,+0000,+0100 &0p11.chassis voltage.+0056.+0029,+0056 &0p12.fault reset delay.+0015.+0005.+0030 &0p13.fault reset limit.+0003.+0000,+0010 &0p15.unused15.+0001.+0001 &0p16.unused16.+0001.+0001 &0p17.unused17.+0001.+0001 &0p19.unused18.+00010001.+0001 &0p19.unused18.+00010001.+0001 &0p19.unused18.+00010001.+0001 &0p19.unused18.+00010001.+0001 &0p19.unused19.+0001.+0001</pre>		~

4

To enable power on one of the Injector ports, use the following command format:

&0p##,0001

Where ## is in the range 01 through 04, representing ports 1 through 4 respectively



5 To disable power on one of the Injector ports, use the following command format:

&0p##,0000

Where ## is in the range 01 through 04, representing ports 1 through 4 respectively



6

To enable sync on one of the Injector ports, use the following command format:

&0p##,0001

Where ## is in the range 05 through 08, representing ports 1 through 4 respectively



7

To disable sync on one of the Injector ports, use the following command format:

&0p##,0000

Where ## is in the range 05 through 08, representing ports 1 through 4 respectively



Display the CMM5 Injector Serial Number

Perform the following steps to view the serial number of the Injector:

Procedure 24 Display the Injector Serial Number

- **1** Run the TeraTerm terminal emulator and start a serial session to the Injector COM port.
- **2** Execute the following query command to display the Injector serial number:
 - &0s

3 The Injector responds with its serial number. The chassis name and current status are also shown.

Tera Term - COM22 VT	
File Edit Setup Control Window Help	
&@s &@mA,S/N=-1721B012K,Name=CMM5_Demo,Status=OK]	•

CMM5 Controller Operation

The following paragraphs describe the operating procedures for a CMM5 Controller operating with one or more Injectors.

View Controller Status

The Status page includes three tabs, Overview, Firewall and Routes. These tabs provide information about the Controller and its network connection.

Status – Overview

The Overview tab shows the basic system status. Important information displayed on this screen includes the following:

- Firmware Version the firmware version currently running on the Controller
- Uptime time that the Controller has been running since the last reboot or power cycle
- Network Information basic network connection configuration and connection uptime

Cambium Networks	Unsaved Changes
CMM5 Controller vRP3B12.1.2 49970	
Status System Services Network Logout System Sh	utdown
Overview Firewall Routes	
Status	
System	
Hostname	CMM5_Demo
Model	CMMS Controller RP3B12.1.2
Firmware Version	CMMS Controller: (Version 1.4)
Kernel Version	4.4.14
Local Time	Wed Aug 22 14:36:55 2018
Uptime	0h 37m 38s
Load Average	0.69, 0.61, 0.60
Memory	
Total Available	912808 kB / 952100 kB (95%)
Free	911776 kB / 952100 kB (95%)
Buffered	1032 kB / 952100 kB (0%)
Network	
TD-4 WAN Century	
1Pv4 WAR Status	Type: static
	Etho Netmask: 255.255.255.0
	Goteway: 10.120.210.254 Connected: th 37m 29s
IPv6 WAN Status	-
THE WHIT STOLES	Not connected
Active Connections	8 / 15384 (06)
Active connections	0 / 10309 (070)

Status – Firewall

The Status – Firewall screen displays the current firewall configuration for either IPv4 or IPv6, depending on which sub-tab is selected. The firewall policies and traffic data may be viewed on this screen.

Cam	nbium Netw	orks						Unsaved Chang
CMM5 Controller	vRP3B12.1.2 49970							
Status Syst	tem Services	Network Longuit System Shutde	wn					
		refleat and a selfeat						
Overview	Firewall Routes							
Firewall Sta	atus							
IPv4 Firewall								Reset Counters Restart Firewall
Table: Filter								Reset Counters Restart Filowan
Chain INPUT	(Policy: ACCEPT, Pa	ackets: 0, Traffic: 0.00 B)						
Pkts.	Traffic	Target	Prot.	In	Out	Source	Destination	Options
0	0.00 B	ACCEPT	all	lo		0.0.0/0	0.0.0/0	ID:66773300
3	679.00 B	input_rule	all			0.0.0/0	0.0.0/0	ID:66773300 /* user chain for input */
2	80.00 B	ACCEPT	all	*		0.0.0/0	0.0.0/0	ID:66773300 ctstate RELATED,ESTABLISHED
0	0.00 B	DROP	all			0.0.0/0	0.0.0/0	ID:66773300 ctstate INVALID
0	0.00 B	syn flood	tcp			0.0.0/0	0.0.0/0	ID:66773300 tcp flags:0x17/0x02
1	599.00 B	zone lan input	all	eth0		0.0.0.0/0	0.0.0.0/0	ID:66773300
Chain FORW	ARD (Policy: DROP,	Packets: 0, Traffic: 0.00 B)						
Pkts.	Traffic	Target	Prot.	In	Out	Source	Destination	Options
0	0.00 B	forwarding_rule	all			0.0.0/0	0.0.0/0	ID:66773300 /* user chain for forwarding */
0	0.00 B	ACCEPT	all	+		0.0.0.0/0	0.0.0/0	ID:66773300 ctstate RELATED,ESTABLISHED
0	0.00 B	DROP	all			0.0.0/0	0.0.0/0	ID:66773300 ctstate INVALID
	0.00.0	and her forward	- 11			0.0.0.00	0.0.0/0	

Status – Routes

The Status - Routes screen displays the routing rules currently in effect.

Cambium Networks				Unsaved Ch
Controller vRP3B12.1.2 49970				
System Services Network Logout	System Shutdown			
erview Firewall Routes				
ites				
following rules are currently active on this system.				
RP				
IPv4-Address		MAC-Address	In	erface
10.120.210.1		00:1b:21:cd:8c:5f		eth0
10.120.210.254		00:22:be:6e:40:00		eth0
Network	Target	IPv4-Gateway	Metric	Table
Demo_Static_IP	0.0.0/0	10.120.210.254	0	main
Demo_Static_IP	169 254 1 0/24		0	main
ctive IPv6-Routes	**	0	•• •• •• •	X-11
Network	Target	Source	Metric	Table
Demo_Static_IP	#00::/8		256	local
Pv6 Neighbours				
IPv6-Address		MAC-Address	Inter	face

Controller System Operations

The System page includes five tabs, System, Administration, SNMP, Backup / Flash Firmware and Reboot. These tabs provide information about the Controller and its network connection. Use of the System, Administration, and SNMP tabs is described in the CMM5 Controller Configuration section while the Backup / Flash Firmware tab is covered in the CMM5 Firmware Upgrade section.

System – Reboot

The Reboot tab allows the operator to manually reboot the Controller. Perform the following steps to reboot the Controller:

The configuration on both the Controller and the Injectors is preserved through the reboot and there is no interruption to the Injector operation.

Procedure 25 Reboot the Controller

- **1** From the System screen, select Reboot.
- 2 Click the Perform reboot button to initiate the reboot.

Cambium Networks	Changes:
Status System Services Network Logout System Skutdown	<u> </u>
System Administration SNMP Backup / Flash Firmware Reboot	
Reboot	
Reboots the operating system of your device	

3

The Controller indicates that the reboot is in progress.

The reboot process takes approximately 30 seconds to complete.



4

Log into the Controller as root using your password.

CAMB Controller vRP3812.1.2 49970		
Authorization Required Please enter your username and password.		
Username	root	
Password		Reset I Login

Controller Services

The Services page includes two tabs, CMM5 and GPS. The CMM5 tab shows the current state of each connected Injector in a table format, with the master module occupying the top row and the slave units on successive rows below. The chassis state and the status of each of the four ODU ports are displayed for each Injector. In the example below the Controller is connected to two Injectors, one master and one slave:

Cambi	um Net	works										Unsaved Ch	anges
CMM5 Controller vRP	3B12.1.2 499	070											
Status System	Services	Network	Logout System S	ihutdown									
CMM5 GPS													
										Force D	scover Que	erv All 🖸 Sa	ave
			Chassis Info				Port	Dort Name	Dort Status	Sync Status	Volte	Watte	
Identify	Query		Name	Serial	Letter	EW	1	Master Port1	ON	ON	55	21	
Blink	Query	CMM5 Demo 1		-1830B0001	A	00.21	2	Master_Port2	ON	ON	56	9	
Type	-	Temp	Sync	PS1	PS	2	3	Master_Port3	ON	ON	55	9	
56		36	ок	ок	NF		4	Master_Port4	ON	ON	55	14	
Identify	Query		Name	Serial	Letter	FW	1	Slave_Port1_	ON	ON	56	8	
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON	ON	56	8	
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8	
56		34	ок	ок	NF		4	Slave_Port4_	ON	ON	56	9	
										Force D	scover Que	ary All 🕝 Sa	ave

Control of the ODU port power and sync states is also possible from this tab.

The GPS tab shows the GPS data received from the UGPS module, and includes the following information:

- Current UTC time
- Location expressed as latitude, longitude and altitude. A horizontal accuracy estimate is also displayed
- The number of GPS satellites visible (Satellites In View) and the number currently being tracked (Satellite Count)
- The receiver tracking mode (e.g. 2D FIX, 3D FIX)
- A count of GPS messages received with an invalid CRC field (Invalid Message Count)
- UGPS receiver information, including the model number, capability (GPS Only or GPS + GLONASS), software version, revision and date.

The Invalid Message Count field is active only when the Verify GPS Message Checksum box is checked in the Time Synchronization configuration section of the System tab.

M5 Controller vRP3B12.1.2 4	9970	
Status System Service	Network Logout Sy	stem Shutdown
CMM5 GPS		
UTC Time:	17:39:04	
Date:	08/23/2018	
Latitude:	42° 3' 12.02" N	
Longitude:	88° 1' 31.91" W	
Satellites In View:	20	
Satellite Count:	11	
Tracking Mode:	3D FIX	
Altitude:	237.00 meters	
Horizontal Accuracy:	0.90 meters	
Invalid Message Count:	0	
Receiver Model:	GNSS_EXTRF_9600	
Capability:	Canopy UGPS(GPS + GLONASS)	
Software Version:	AXN_5.1.1	
Software Revision:	8512	
Software Date:	012-11-2017	

Identify a Chassis (Blink)

In larger CMM5 configurations with multiple Injectors it is helpful to be able to identify which physical Injector module corresponds to each chassis displayed on the CMM5 Services tab. A chassis identification function is provided for this purpose. Perform the following steps to identify a chassis:

The order in which the slave Injectors are shown on the CMM5 screen is determined by the Controller and does not necessarily match the daisy-chain connection sequence.

Procedure 26 Identify a Chassis

1 From the CMM5 tab screen, click the Blink button corresponding to the chassis to be identified.

	Combin		vorka											Unsaved C	hange
	Campic	mneu	NORKS												
CMM5 Cor	troller vRP3	B12.1.2 499	70												
Status	System	Services	Network	.ogout Sys	tem Shutdown		<u> </u>								
CMM5	GPS														
												Force [Discover Qu	ery All 🕝 S	ave
				Chassis Info				Port		Port Name	Port Status	Sync Status	Volts	Watts	
Id	entify	Query		Name	Serial	Letter	FW	1	Master_Port1		ON	ON	55	21	
	Blink	Query	CMM5_Demo_1_	-	-1830B0001	А	00.21	2	Master_Port2		ON	ON	56	9	
	Туре		Temp	Sync	PS1	PS	2	3	Master_Port3		ON	ON	55	9	
	56		36	ок	ОК	N	,	4	Master_Port4		ON	ON	55	14	
Id	entify	Query		Name	Serial	Letter	FW	1	Slave_Port1_		ON	ON	56	8	
	Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_		ON	ON	56	8	
_	Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_		ON	ON	56	8	
	56		34	ок	ок	N	>	4	Slave_Port4_		ON	ON	56	9	
												Force I	Discourar Ou		aun
												TOICEL	ISCOVEL QU	Siy Ali	040

2 The green and red LEDs for the four ODU ports on the selected chassis will light for one second, allowing the physical Injector to be identified.

TO RADIOS 1 2 3 4 Power Sec Secondary Pri 1 2 3 4 Pri 1 2 3 4 Description D



View Chassis Information and Status

The Chassis Information section of the CMM5 tab shows the chassis name, serial number and current firmware version for each Injector connected to the Controller. A chassis letter is also displayed ("A" through "H"), and is used by the Controller firmware to uniquely identify each physical chassis.

System	Services	Network Logo	ut System	Shutdown								
GPS												
										Force D	iscover Qu	ery All 🧧
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watte
dentify	Query	N	łame	Serial	Letter	FW	1	Master_Port1	ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	А	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	ON	ON	55	9
56		36	ок	ок	N	P	4	Master_Port4	ON	ON	55	14
lentify	Ouerv	N	ame	Serial	Letter	FW	1	Slave Port1	ON	ON	56	8
Blink	Query	CMM5 Demo 2		-1723B020W	B	00.13	2	Slave_Port2_	ON	ON	56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8
56		34	ок	ок	N	P	4	Slave_Port4_	ON	ON	56	9

The Chassis Information section of this tab also displays the chassis type (56V or 29V), current temperature, and the status of the sync signal input and the redundant power supply inputs (PS1 and PS2). The sync and power supply status indicators display either "OK" (present) or "NP" (not present). The sync, power supply and temperature information is updated automatically every few seconds as the display refreshes.

ontroller vkP	B12.1.2 499	70											
System	Services	Network Logou	it System	Shutdown									
GPS													
											Force [iscover Qu	ery All (
		c	hassis Info				Port		Port Name	Port Status	Sync Status	Volts	Wat
dentify	Query	N	ame	Serial	Letter	FW	1	Master_Port1		ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	А	00.21	2	Master_Port2		ON	ON	56	9
Туре		Temp	Sync	PS1	PS2	1	3	Master_Port3		ON	ON	55	9
56		36	ок	ок	NP		4	Master_Port4		ON	ON	55	14
								Playa Dortt		ON	ON		0
dentify	Query	Na	.me	Serial	Letter	FW	-	Slave_Port1_		ON	ON	50	0
Blink	Query	CMM5_Demo_2_		-1723B020W	В	00.13	2	Slave_Port2_		ON	ON	56	8
Туре		Temp	Sync	PS1	PS2		3	Slave_Ports_		ON	ON	56	8
56		34	OK	OK	NP		4	Slave_Port4_		UN	UN	56	9

View ODU Port Status

Status information for each ODU port is shown in table form to the right of the Chassis Information section of the CMM5 tab. The power and sync states are displayed in two color-coded columns, ON with a green background representing the enabled state and OFF with a red background corresponding to the disabled state. If the power for a particular port is disabled then the sync status will be shown with a gray background to indicate the sync state that would be applied if the port was enabled.

When the port power is disabled ("OFF") the sync signal will not be generated even if the sync state is enabled ("ON").

ntroller vRP	3812.1.2 499	970										
System	Services	Network Lo	agout System S	shutdown		_						_
GPS												
										Force D	liscover Que	ery All 🖉
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watt
entify	Query	Charles Dama d	Name	Serial	Letter	FW	2	Master_Port1	ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	A	00.21	2	Master_Port2	ON	ON	50	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Ports	ON	ON	55	7
56		36	UK	OK	NP		-	Master_Port4		ON	55	14
antifu	0		Manua	Contat	Latter	C 144	1	Slave Port1	ON	ON	56	8
Blink	Query	CMM5 Demo 2	Hume	+1723B020W	R	00.13	2	Slave Port2	ON	ON	56	8
Turne	Course of the second se	Tama	6			00.15	3	Slave Port3	ON	ON	56	8
se se		24	Sync	PS1 OK	P5.	£	4	Slave Port4	ON	ON	56	9
50		54	OK .	UK	116			plane_i enti_				

The two rightmost columns show the current ODU port voltage and power drain measurements. This information is updated automatically every few seconds as the display refreshes.

Caml	bium Net	works											Unsaved Char	iges
CMM5 Controller v	RP3B12.1.2 49	970												
Status Syste	m Services	Network	Logout System S	hutdown										
CMM5 GPS														
											Force D	iscover Que	rv All 🙆 Sav	e
														1
r														
			Chassis Info				Port		Port Name	Port Status	Sync Status	Volts	Watts	
Identify	Query		Name	Serial	Letter	FW	1	Master_Port1		ON	ON	55	21	
Blink	Query	CMM5_Demo_1	_	-1830B0001	A	00.21	2	Master_Port2		ON	ON	56	9	
Тур	e	Temp	Sync	PS1	PS	2	3	Master_Port3		ON	ON	55	9	
56		36	ок	ок	N	P	4	Master_Port4		ON	ON	55	14	
Identify	Query		Name	Serial	Letter	FW	1	Slave_Port1_		ON	ON	56	8	
ØBlink	Query	CMM5_Demo_2	_	-1723B020W	в	00.13	2	Slave_Port2_		ON	ON	56	8	
Тур	e	Temp	Sync	PS1	PS	2	3	Slave_Port3_		ON	ON	56	8	
56		34	ок	ок	N	р	4	Slave_Port4_		ON	ON	56	9	
L														-1
											Force D	iscover Que	ry All 🥝 Sav	0

Query Chassis and ODU Port Status

The chassis information and ODU port status shown on the CMM5 tab is updated automatically every few seconds. It is also possible to initiate a query manually using the Query and Query All commands. These commands can be useful to ensure that the data displayed is being updated. Perform the following steps to execute a query operation:

Procedure 27 Query Chassis and ODU Port Status

1 To query the status for an individual Injector, click the Query button for the corresponding chassis on the CMM5 tab.

49970 25 Network Logout	System Shutdown								
es Network Logout	System Shutdown								
								l .	
						Force D	iscover Que	ry All 🕝 Sav	
Chassis Infe	2		Port	Port Name	Port Status	Sync Status	Volts	Watts	
Name	Serial	Letter FW	1	Master_Port1	ON	ON	55	21	
y CMM5_Demo_1_	-183080001	A 00.21	2	Master_Port2	ON	ON	56	9	
Temp Syr	nc PS1	PS2	3	Master_Port3	ON	ON	55	9	
36 01	с ок	NP	4	Master_Port4	ON	ON	55	14	
						011			
Name	Serial	Letter FW	1	Slave_Port1_	UN	UN	56	8	
y CMM5_Demo_2_	-1723B020W	B 00.13	2	Slave_Port2_	UN	UN	56	8	
Temp Syr	ic PS1	PS2	3	Slave_Port3_	ON	UN	56	8	
34 01	с ок	NP	4	plave_Port4_	ON	ÜN	56	9	
	Chassis Trift Name Name Temp Syr Temp Syr Y Chillifs_Demo_1_ Y Chillifs_Demo_2_ Temp Syr Y Chillifs_Demo_2_ Temp Syr 3 O	Chassis Info Name Serial Temp Sync PS1 36 OK OK Y EMM5_Demo_2_ -17238020W Temp Sync PS1 34 OK OK	Chassis Info Name Serial Letter FW [2MM5_Demo_1] -48068001 A 00.21 Temp Sync PS1 PS2 30 OK I/IV I/IV Y [2MM5_Demo_2] -1/230020W B 00.13 Temp Sync PS1 PS2 34 OK OK I/IV	Chassis Info Port Name Serial Letter PW 1 ChMd5_Demo_1_ -18/360001 A 0.021 2 Temp Sync PS1 PS2 3 36 OK OK HP 4 Meme Serial Letter FW 1 Temp Sync 93 0.03 2 34 OK OK 10 4	Chassis Info Port Port Name Name Serial Letter PW 1 Master_Port2 CMM5_Demo_1_ -18/040001 A 0.011 2 Master_Port2 Temp Sync PS1 PS2 3 Master_Port3 36 OK NP 4 Master_Port4 y Name Serial Letter FW 1 Sinve_Port1, y CMM5_Demo_2_ -17238020W 8 00.13 2 Sinve_Port1, Temp Sync PS1 PS2 3 Sinve_Port1, 3 34 OK OK NP 4 Sinve_Port4, 3	Chassis Info Port Port Name Port Status Name Serial Letter PW 1 Master_Port1 CNI Q CMM5_Demo_1_ -180468001 A 0.021 2 Master_Port2 CNI Temp Sync PS1 PS2 3 Master_Port3 CNI 36 OK NP 4 Master_Port4 CNI y Name Serial Letter FW 1 Sinve_Port1, CNI y CMM5_Demo_2_ -17238020W 8 00.13 2 Sinve_Port1, CNI Y CMM5_Demo_2_ -17238020W 8 00.13 2 Sinve_Port1, CNI Y OK NF 4 Sinve_Port1, CNI CNI	Chassis Info Port Port Name Port Name Port Status Syn Citation Y Name Serial Letter PV 1 Mader Port1 ONI ON	Port Port Name Port Name Port Name Port Name Port Status Synce Port Name Port Name Port Status Synce Port Name Port Name Port Status Synce PSI PSI Synce PSI PSI Synce PSI PSI Synce PSI Synce PSI Synce PSI Synce <th colspa="2" port4<="" sinvp="" td=""></th>	

2

The chassis information and ODU port status information for the selected chassis is updated.

Generally the displayed information is refreshed with minimal delay, but on occasion the Controller may briefly show a message indicating that the command is in progress.

3 To query the status for all connected Injectors at the same time, click the Query All button.

Cambi	um Netv	works										Unsaved Char
S Controller vRP	3812 1 2 499	70										
atus System	Services	Network Log	gout System S	hutdown								
MM5 GPS												
										Force D	iscover Que	erv All 🖾 Sav
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query		Name	Serial	Letter	FW	1	Master_Port1	ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	A	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	ON	ON	55	9
56		36	ок	ок	NF	2	4	Master_Port4	ON	ON	55	14
Identify	Query		Name	Serial	Letter	FW	1	Slave_Port1_	ON	ON	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON	ON	56	8
Type		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8
56		34	ок	ок	NF	2	4	Slave_Port4_	ON	ON	56	9
										F		
										Force D	iscover Que	ary All 💟 Sav

4

The chassis information and ODU port status information for all connected Injectors is updated. This process takes a few seconds to complete, during which time the Controller displays a message indicating that the command is in progress.



Modify ODU Port Status

The CMM5 tab is also used to modify the power and sync states of the ODU ports. Perform the following steps to enable or disable power or sync on a given port:

Procedure 28 Modify ODU Port Status

1 To enable or disable the power to an ODU port, click the center of the Port Status box on the CMM5 tab corresponding to the chosen port. In the example below power is to be disabled on port 3 of the master Injector.

You must click directly on the text within the box in order for the command to take effect.



2 The Port Status and Sync Status boxes will change to yellow for a few seconds while the command executes.

Additional commands cannot be run from this screen while the current command is in progress.

Controller vRP	3B12.1.2 499	70										
tus System	Services	Network Log	jout System S	ihutdown								<u> </u>
M5 GPS												
			Comm	and In Progr	ess: Plea	ise be	patie	nt! SYA				iry All 🙆 S
				5			1	214				
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query		Name	Serial	Letter	FW	1	Master_Port1	ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	А	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	OFF	ON	55	9
56		37	OK	ОК	NF		4	Master_Port4	ON	ON	55	14
Identify	Query		Name	Serial	Letter	FW	1	Slave_Port1_	ON	ON	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON	ON	56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8
56		35	OK	ок	NF		4	Slave_Port4_	ON	ON	56	9

3 Once the command is completed, the Port Status box for the selected port will change to "OFF" (red) or "ON" (green) as applicable.

A gray background is displayed for the sync status of the disabled port, indicating the sync state that would be in effect if the port power was enabled.

ontroller vRP3	812.1.2 499	70											
s System	Services	Network Logou	t System S	ihutdown									
5 GPS													
											Force (iscover Qu	erv All
		c	hassis Info				Port		Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query	Na	ime	Serial	Letter	FW	1	Master_Port1		ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	A	00.21	2	Master_Port2		ON	ON	56	9
Туре		Temp	Sync	PS1	PS:	2	3	Master_Port3		OFF	ON	33	0
56		37	OK	ок	NP		4	Master_Port4		ON	ON	55	14
dentify	Query	Na	me	Serial	Letter	FW	1	Slave_Port1_		ON	ON	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_		ON	ON	56	8
Type		Temp	Sync	PS1	PS:	2	3	Slave_Port3_		ON	ON	56	8
56		36	OK	ОК	NP		4	Slave_Port4_		ON	ON	56	9
												-	

4

To enable or disable the sync signal to an ODU port, click the center of the Port Status box on the CMM5 tab corresponding to the chosen port. In the example below sync is to be disabled on port 2 of the slave Injector.

The sync state can only be changed if the power is currently enabled (Port Status is "ON") for the selected port.

otroller vPP3	812 1 2 400	70										
	012.1.2 495											
System	Services	Network Logo	sut System 5	Shutdown								
GPS												
										Force [liscover Qu	erv All
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watt
dentify	Query	P. C.	tame	Serial	Letter	FW	1	Master_Port1	ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	А	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	OFF	ON	33	0
56		37	OK	OK	NF		4	Master_Port4	ON	ON	55	14
fentify	Query	N	ame	Serial	Letter	FW	1	Slave_Port1_	ON	ON	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON	ON	56	8
Type		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8
56		36	OK	OK	NF		4	Slave_Port4_	ON	ON	56	9

5 The Port Status and Sync Status boxes will change to yellow for a few seconds while the command executes.

Additional commands cannot be run from this screen while the current command is in progress.



6 Once the command is completed, the Sync Status box for the selected port will change to "OFF" (red) or "ON" (green) as applicable.

ntroller vRP3	B12.1.2 499	70										
System	Services	Network Logo	out System	Shutdown								
GPS						_	_					
										Force D	liscover Que	ery All 🥰
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watt
lentify	Query	,	tame	Serial	Letter	FW	1	Master_Port1	ON	ON	55	21
Blink	Query	CMM5_Demo_1_		-1830B0001	А	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS:	2	3	Master_Port3	OFF	ON	33	0
56		36	ОК	ОК	NP		4	Master_Port4	ON	ON	55	14
lentify	Query	N	ame	Serial	Letter	FW	1	Slave_Port1_		UN	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON	OFF	56	8
Туре		Temp	Sync	PS1	PS2	2	3	Slave_Port3_	ON	ON	56	8
56		34	OK	OK	NP		4	Slave_Port4_	ON	ÖN	56	9

Change GPS Measurement Units

By default the altitude and horizontal accuracy measurements on the GPS tab are given in meters. Perform the following steps to change the units:

Procedure 29 Change GPS Measurement Units

1 To change the measurement units used for GPS altitude and horizontal accuracy, select the desired units from the Units pull-down menu at the bottom of the GPS screen. Available selections are Feet or Meters.

Cambium Ne	tworks	
CMM5 Controller vRP3B12.1.2 4	9970	
Status System Services	Network Logout Sys	tem Shutdown
CMM5 GPS		_
UTC Time:	23:33:07]
Date:	08/23/2018	
Latitude:	42° 3' 12.02" N	
Longitude:	88° 1' 31.91" W	
Satellites In View:	20	
Satellite Count:	9	
Tracking Mode:	3D FIX	
Altitude:	237.00 meters	
Horizontal Accuracy:	0.94 meters	
Invalid Message Count:	0	
		-
Receiver Model:	GNSS_EXTRF_9600	
Capability:	Canopy UGPS(GPS + GLONASS)	
Software Version:	AXN_5.1.1	
Software Revision:	8512	
Software Date:	012-11-2017	
Units: Meters 🔹		

2

After a few seconds the Altitude and Horizontal Accuracy fields will be displayed in the chosen units.

During the transition to the new units the measurement fields may briefly display no data.

Cambium Ne	tworks
CMM3 Controller VRP3B12.1.2 4	9970
Status System Services	Network Logout System Shutdown
CMM5 GPS	
UTC Time:	23:34:46
Date:	08/23/2018
Latitude:	42° 3' 12.02" N
Longitude:	88° 1' 31.91" W
Satellites In View:	20
Satellite Count:	9
Tracking Mode:	3D FIX
Altitude:	777.56 ft
Horizontal Accuracy:	3.12 ft
Invalid Message Count:	0
Receiver Model:	GNSS_EXTRF_9600
Capability:	Canopy UGPS(GPS + GLONASS)
Software Version:	AXN_5.1.1
Software Revision:	8512
Software Date:	012-11-2017
Units: Feet •	

Controller Network Operations

The Network page includes four tabs, Interfaces, Static Routes, Firewall and Diagnostics. Provisioning and editing of the network interfaces using the Interfaces page is covered in the Controller Configuration section of this document. The Static Routes and Firewall tabs can be used to view details about the network configuration of the Controller, while the Diagnostics tab supports basic troubleshooting tools.

View and Add Static Routes

The Static Routes tab shows the IPv4 or IPv6 static routes configured on the Controller, if any are present. New static routes can also be provisioned from this screen.

It is not expected that the operator would need to add static routes for normal CMM5 operation.

Cambium Networks						Unsav	ed Changes:
CMM5 Controller vRP3B12.1.2 49970							
Status System Services Network	Logout System Shutdown						
Interfaces Static Routes Firewall Di	agnostics						
Routes							
Routes specify over which interface and gatew	ay a certain host or network can be reached.						
Static IPv4 Routes							
Interface 🖷	Target	IPv4-Netmask	IPv4-Gateway	Metric	мти	Route type	
	Host- <u>IP</u> or Network	if target is a network					
		This section contains	no values yet				
Add							
Static IPv6 Routes							
Interface 🔳	Target		IPv6-Gateway	Metric	мти	Route type	
	<u>IPv6</u> -Address or Netwo	rk (CIDR)					
		This section contains	no values yet				
Add							

View and Modify Firewall Settings

The Firewall tab shows details of the current Controller firewall configuration on the Controller. There are four sub-tabs on this screen: General Settings, Port Forwards, Traffic Rules and Custom Rules. The following modifications may be made to the firewall configuration:

- Basic firewall settings
- Add, edit and delete zones
- Add, edit and delete traffic rules
- Configure router ports and port forwarding rules
- Configure source NAT
- Define custom rules

It is not expected that the operator would need to edit the firewall settings for normal CMM5 operation.

Cambium Networks						Unsaved Chang
CMMS Controller vRP3B12.1.2 49970						
Status System Services Network Logout	System Shutdown					
Interfaces Static Routes Firewall Diagnostics						
General Settings Port Forwards Traffic Rules Cust	om Rules					
Firewall - Zone Settings						
The firewall creates zones over your network interfaces to c	ontrol network traffic flow.					
General Settings						
Enable SYN-flood protection		2				
Drop invalid packets		8				
Input		accept	,			
Output		accept	,	-		
Forward		reject	,			
Zones						
Zone ⇒ Forwardings	Input	Output	Forward	Masquerading	MSS clamping	
lan: lan: 💒 👄 wan	accept •	accept *	accept •			Edit Edit
wan: (empty) => REJECT	reject 🔻	accept •	reject •	2	2	Edit Delete
Add						
Reset						Save Save & Apply

Diagnostic Utilities

The Diagnostics tab provides several utilities for network troubleshooting on the Controller. The following diagnostic operations are available:

- Ping
- Traceroute
- NS lookup

Perform the following steps to use one of the diagnostic utilities:

Procedure 30 Run Diagnostic Utilities

1 Enter the desired IP address in the field corresponding to the diagnostic operation to be performed. In the example below the ping tool is selected:

Cambium Networks		Unsaved Change
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout System S	hutdown	
Interfaces Static Routes Firewall Diagnostics		
Diagnostics		
- Network Utilities		
[10.120.210.1 [Pv4 v] [] Ping	openwrt org	opernwrt org Raiochup

2

Click the appropriate button to run the utility.

Cambium Networks			Unsaved Change
CMMS Controller vRP3B12.1.2 49970			
Status System Services Network Logout System Shutdow	n		
Interfaces Static Routes Firewall Diagnostics			
Diagnostics			
Network Utilities			
10.120.210.1 [Pv4 •] Ppg [P	enwrt.org v4 🔻 🔁 Traceroute	openwrt org Nslookup	

3 The results of the operation are displayed on the Diagnostic screen upon completion:

Cambium Networks		Unsaved Chan
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout	System Shutdown	
Interfaces Static Routes Firewall Diagnostics		
Diagnostics		
Network Utilities		
10.120.210.1 IPv4 • 2 Ping	openwrt.org IPv4 •) G Traceroute	Copenvert org
PTM0 10.120.210.1 (10.120.210.1): 56 data bytes 64 bytes from 10.120.210.1: seq=0 ttl=128 time=1.55 ms 64 bytes from 10.120.220.1: seq=1 ttl=128 time=1.200 ms 64 bytes from 10.120.220.1: seq=1 ttl=128 time=1.100 ms 64 bytes from 10.120.210.1: seq=1 ttl=128 time=1.104 ms 64 bytes from 10.120.210.1: seq=1 ttl=128 time=1.104 ms		
10.120.210.1 ping statistics 5 packets transmitted, 5 packets received, 0% packet loss round-trip min/avg/max = 1.115/1.209/1.355 ms		

- 4 Once you have selected an image, click Flash Image to upload it to the controller. This will take a few seconds to complete.
- 5

After the controller uploads the selected image file the Flash Firmware – Verify screen is displayed.

Logout and Shutdown Operations

The Controller offers two additional functions on the main page, Logout and Shutdown. Both functions take effect immediately and should be used with caution.

Logout

The Logout function will end the current session and log out the user. The Controller will return directly to the login screen:

CAMPS Controller vRP3B12.1.2 49970		
Authorization Required Please enter your username and password.		
Username	root	
Password		@Reset @Login

Shutdown

The Shutdown function performs a graceful shutdown of the Controller in preparation for powering off. This function should be always be executed prior to disconnection of the power supply in order to guard against potential corruption of the file system. The operator should wait least one minute after performing the shutdown before disconnecting the power.

Caution: the Controller must be power cycled in order to boot up after the shutdown function is invoked. This will generally require a site visit.

System - Shutting Down... The system is shutting down. To prevent issue, please wait 1 minute before removing power from the controlle

CMM5 Error Conditions

The Controller tracks various error conditions which may occur on the connected Injectors and displays warning notifications as appropriate. Common error conditions are described in the following paragraphs.

Master Injector Communications Lost

The Controller periodically checks communications with the Master Injector. If communications are lost, the Controller GUI will display an error message as shown below:

System	Services	Network Lo	gout System	Shutdown								
GPS												
			Master injector	has lost comr	nunicatio	on, ple	ase ve	erify connection!				ery All 🧧
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watt
dentify	Query		Name	Serial	Letter	FW	1	Master_Port1	UN	ON	55	20
Blink	Query	CMM5_Demo_1_		-1830B0001	A	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	ON	ON	55	9
56		39	ОК	ок	NF		4	Master_Port4	ON	ON	55	14
dentify	Query		Name	Serial	Letter	FW	1	Slave_Port1_	ON	ON	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON	ON	56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8
56		36	ок	ок	NF		4	Slave_Port4_	ON	ON	56	9

This condition may be caused by a loss of power to the Master Injector or by an internal hardware fault.

Slave Injector Communications Lost

The Controller periodically checks communications with any Slave Injectors that are present in the CMM5 configuration. If communications are lost, the data for the affected Injector(s) will be grayed out in the Controller CMM5 Services tab, as shown below:

Cambi	um Net	works										Ulisaveu C
Controller vRP	3B12.1.2 499	970										
us System	Services	Network Log	gout Sys	stem Shutdown								
45 GPS												
										Force D	iscover Que	erv All 🚳
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query		Name	Serial	Letter	FW	1	Master_Port1	ON	ON	55	20
Blink	Query	CMM5_Demo_1_		-1830B0001	Α	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	ON	ON	55	9
56		36	ОК	ок	N	P	4	Master_Port4	ON	ON	55	14
Identify	Query		Name	Serial	Letter	FW	1	Slave_Port1_	ON		56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON	ON	56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON		56	8
56		36	OK	OK	N	P	4	Slave_Port4_	ON		56	9

Commands cannot be initiated on the affected Slave Injector(s) when the Controller indicates that communication has been lost.

This condition may be due to loss of power to the affected Slave Injector, disconnection of the daisychain communication cable to that Injector, or by an internal hardware fault in the unit.

USB Connection Lost

The Controller monitors communications with the Master Injector over the USB cable and displays the following error message if the communications are interrupted:

Cambi	um Net	works										Unsaved Chang
1M5 Controller vRP3	3B12.1.2 499	970										
Status System	Services	Network	gout System S	Shutdown								
CMM5 GPS												
	Master injector has lost communication, please verify connection! USB connection lost!											
			Chassis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query		Name	Serial	Letter	FW	1	Master_Port1	ON	ON	55	20
Blink	Query	CMM5_Demo_1_		-1830B0001	А	00.21	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS	2	3	Master_Port3	ON		55	9
56		37	OK	ок	NP		4	Master_Port4	ON	ON	55	14
Identify	Query		Name	Serial	Letter	FW	1	Slave_Port1_	ON	ON	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON		56	8
Туре		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8
56		36	OK	ок	NP	i	4	Slave_Port4_	ON	ON	56	9
										Force Di	scover) (Que	ry Ali) 🙋 Save

The error message indicating loss of communications with the Master Injector is also displayed in this case.

If this error occurs check the integrity of the USB cable connection between the Controller and the Master Injector.

ODU Port Tripped

The Controller indicates if any of the ODU ports have tripped due to triggering of the overcurrent protection mechanism. Ports for which this is the case will be highlighted in red on the CMM5 Services screen and the Port Status and Sync Status will be displayed as "TRIPPED".

C C	ambiu		vorke												Unsaved C	hang
	ampiu	im Netv	NOLKS													
MM5 Contro	oller vRP3	B12.1.2 499	70													
Status	System	Services	Network	Logout	System Shutdown											
CMM5	GPS	_								_						
													Eorce D	iscover Qu	erv All	ave
													101001	1300101 40	uly rul 🖉 d	uro
				Chassis Info					Port		Port Name	Port Status	Sync Status	Volts	Watts	
Ident	tify	Query		Name	Sei	ial Le	tter	FW	1	Master_Port1		TRIPPED	TRIPPED	9	0	
😂 Bl	link	Query	CMM5_Demo_1	-	-1830	B0001	Α	00.21	2	Master_Port2		ON	ON	56	9	
	Туре		Temp	Syne	c PS	1	PS2		3	Master_Port3		ON	ON	55	9	
	56		38	OK	0	ĸ	NP		4	Master_Port4		ON	ON	55	14	
Ident	tify	Query		Name	Ser	ial Le	tter	FW	1	Slave_Port1_		ON	ON	56	8	
S BF	link	Query	CMM5_Demo_2_	-	-17238	020W	в	00.13	2	Slave_Port2_		ON	ON	56	8	
	Туре		Temp	Syne	: P5	1	PS2		3	Slave_Port3_		ON	ON	56	8	
	56		35	OK	0	ĸ	NP		4	Slave_Port4_		ON	ON	56	9	
													Force D	liscovor Ou		avo
													FOICEL	acordi Qu		0.46

This condition can be caused by a short circuit in the wiring to the radio, connection of inappropriate equipment (e.g. plugging a 29V radio into a 56V injector), or by an internal fault in the radio itself.

The ODU port overcurrent protection algorithm is implemented as follows:

- When a fault condition is detected on an ODU port, the port is immediately shut down and the port status is displayed as TRIPPED.
- After 15 seconds the Controller attempts to re-enable the port. If the fault condition is resolved then the port is enabled automatically and port status changes from TRIPPED to ON.
- If another fault condition is detected within two minutes of the previous trip event, or if the previous fault is still present, the port is again shut down and the status reverts to TRIPPED. As before, the Controller will attempt to re-enable the port after 15 seconds.
- If more than three faults are detected consecutively at intervals of less than two minutes, the port will shut down and the status will change to TRIPPED as above, but the Controller will wait for a full two minutes before attempting to reset the port again.
- After the two minute waiting period is up, the port is reset and all internal counters and timers are cleared. The process above is then repeated for any further error conditions which may occur.

The above description applies to version 00.21 Injector firmware. Versions 00.14 and earlier differ in that the ODU ports are not automatically reset by the Controller. Instead the operator must manually reset tripped ports by clicking the port status button for the affected port after resolving the physical error condition.

CMM5 Firmware Upgrade

CMM5 Firmware Update Procedure Flow

The CMM5 firmware is upgraded in the following sequence:

When upgrading firmware on a standalone Master Injector, skip steps (1) and (2) and follow the procedure referenced in step (3).

Procedure 31 Update CMM5 Firmware

- **1** Upgrade the Controller first by following the Update Controller Firmware procedure below.
- 2 Upgrade the Master Injector firmware from the Controller GUI using the Update Master Injector Firmware procedure below.
- **3** Upgrade any Slave Injectors that are installed by following the Upgrade Slave/Standalone Injector Firmware procedure below.

Update Controller Firmware

Perform the following steps to update the Controller firmware:

Procedure 32 Update Controller Firmware



From the System screen, select Backup/Flash Firmware.

2 In the Flash new firmware image section, click Choose File and select a *.img firmware image file.

If the firmware was supplied in the form of a zip archive, extract the file before attempting to load it.

			Unsaved Changes:
CMMS Controller vDP3B12.1.2.40070			
Children Carrieren Carrieren Hickwardt Longard Cardon Chuldren			
Status System Services Network Logout System Statuown			
System Automiscration SHIPP Backup / Frash Firthware Report			
Flash operations			
Actions			
Backup / Restore Click "Generate archive" to download a tar archive of the current configuration files.			
Download backup:	Generate archive		
To restore configuration files, you can upload a previously generated backup archive here.			
Restore backup:	Choose File No file chosen	Upload archive	
Flash new firmware image Upload a sysupgrade-compatible image here to replace the running firmware. Check "Keep setting	s" to retain the current configuration (requires	a compatible firmware image).	
Keep settings:	8		
Image:	Choose File No file chosen	I Flash image	
Flash new CMMS Injector firmware image Upload firmware to the Master Injector (injector with USB connection) FW File:	Choose File No file chosen	Upgrade Firmware	

3

Verify that a check mark is present in the "Keep Settings" box to preserve the current configuration, if desired.

Cambium Networks		Unsaved Changes
CMM5 Controller vRP3B12.1.2 49970		
Status System Services Network Logout System Shutdown		
System Administration SNMP Backup / Flash Firmware Reboot		
Flash operations		
Actions		
Backup / Restore Click "Generate archive" to download a tar archive of the current configuration files.		
Download backup:	Generate archive	
To restore configuration files, you can upload a previously generated backup archive here.		
Restore backup:	Choose File No file chosen	Upload archive
Flash new firmware image Upload a sysupgrade-compatible image here to replace the running firmware. Check "Keep setting	s" to retain the current configuration (requires	a compatible firmware image).
Keep settings:	2	
Image:	Choose File CMM5 Controller v1.4.img	I Flash image
Flash new CMMS Injector firmware image Upload firmware to the Master Injector (injector with USB connection)		
FW File:	Choose File No file chosen	Upgrade Firmware

4 Once you have selected an image the file name will be shown next to the Choose File button. Click Flash Image to upload it to the controller. This will take a few seconds to complete.

Cambium Networ	Unsaved Char
CMMS Controller vDP3B12 1 2 49970	
Claims Contoner via Sofficial 43570	
Sustem Administration SNMP	lon Logon System Southann
Flash operations	under / read findered
Actions	
Backup / Restore Click "Generate archive" to downloa	I a tar archive of the current configuration files.
Download backup:	Generate archive
To restore configuration files, you ca	n upload a previously generated backup archive here.
Restore backup:	Choose File No file chosen
Flash new firmware image Upload a sysupgrade-compatible im	ige here to replace the running firmware. Check "Keep settings" to retain the current configuration (requires a compatible firmware image).
Keep settings:	8
Image:	Choose File CMMS Controller v1.4 img
Flash new CMM5 Injector fi Upload firmware to the Master Inject	mware image or (injector with USB connection)
FW File:	Choose File No file chosen

5

After the controller uploads the selected image file the Flash Firmware – Verify screen is displayed. Confirm that the filesize and checksum are correct for the selected image and verify the configuration file setting.

The checksum is specified in the downloads section of the Cambium Networks support website. If the displayed checksum is zero or does not match the specified value for the release, repeat the file upload process and check again.



6 Click Proceed to initiate the upgrade. The upgrade will take approximately 30 seconds to complete. The controller displays the System – Flashing... screen while the upgrade is in progress.

!	<i>IMPORTANT!</i> Do not interrupt power to the controller during the upgrade process.
vetom - Elashing	
ystem - Flashing The system is flashing now. Do NOT POWER OFF THE DEVICE! Wait a few minutes before you try to reconn	ect. It might be necessary to renew the address of your computer to reach the device again, depending on your settings.

8 When the upgrade is complete, log into the controller using the username and password. The new firmware version will be shown in the Overview tab under the Status screen.

Cambium Networks				
MM5 Controller vR93812.1.2 49970				
Status System Services Network Logout System Shaldown				
Overview Firewall Routes				
Status				
System				
Hostname	CMM5_Demo			
Model	CMM5 Controller RP3B12.1.2			
Firmware Version	CMMS Controller: (Version 1.4)			
Kernel Version	4.4.14			
Local Time	Wed Aug 29 18:57:51 2018			
Uptime	1h 46m 10s			
Load Average	1.02, 1.08, 1.00			
Memory				
Total Available	873536 kB / 952100 kB (91%)			
Free	872524 k8 / 952100 k8 (91%)			
Buffered	1012 kB / 952100 kB (0%)			

Update Master Injector Firmware

Perform the following steps to update Master Injector firmware from the Controller GUI:

This procedure requires that version 1.4 or later firmware is installed on the Controller. When using older firmware the Master Injector must be upgraded via the USB connection using the Slave Injector upgrade procedure.

Procedure 33 Update Master Injector Firmware



From the System screen, select Backup/Flash Firmware.
2 In the Flash new CMM5 Injector firmware image section, click Choose File and select the *.hex file for the release version to be loaded.

Be sure to select the *.hex file as opposed to the *.ttl bootloader macro. If the firmware was supplied in the form of a zip archive, extract the file before attempting to load it.

Cambium Networks			Unsaved Changes:
CMM5 Controller vRP3B12.1.2 49970			
Status System Services Network Logout System Shutdown			
System Administration SNMP Backup / Flash Firmware Reboot			
Flash operations			
Actions			
Backup / Restore Click "Generate archive" to download a tar archive of the current configuration files.			
Download backup:	Generate archive		
To restore configuration files, you can upload a previously generated backup archive here.			
Restore backup:	Choose File No file chosen	Upload archive	
Flash new firmware image Upload a sysupgrade-compatible image here to replace the running firmware. Check "Keep setting	s" to retain the current configuration (requires	a compatible firmware image).	
Keep settings:	2		
Image:	Choose File No file chosen	I Flash image	
Flash new CMM5 Injector firmware image Upload firmware to the Master Injector (injector with USB connection)]		
FW File:	Choose File No file chosen	Upgrade Firmware	

3

Once you have selected a *.hex file the file name will be shown next to the Choose File button. Click Upgrade Firmware... to upgrade the Master Injector.

Cambium Networks		Unsaved Chan
MS Controller VRP3B12.1.2 49970		
Status System Services Network Logout System	Shutdown	
System Administration SNMP Backup / Flash Firmware Reboot		
lash operations		
Actions		
Backup / Restore	n files.	
Download backup:	Generate archive	
To restore configuration files, you can upload a previously generated backup a	rchive here.	
Restore backup:	Choose File No file chosen	Upload archive
Flash new firmware image Upload a sysupgrade-compatible image here to replace the running firmware.	Check "Keep settings" to retain the current configuration (require	res a compatible firmware image).
Keep settings:	8	
Image:	Choose File No file chosen	Flash image
Flash new CMMS Injector firmware image Upload firmware to the Master Injector (injector with USB connection)		
FW File:	Choose File LMG_FW_001124A.h	ex 🔟 Upgrade Firmware

4 The upgrade process takes approximately 3 to 4 minutes to complete. The Controller will display a message while the upgrade is in progress.



IMPORTANT!

Do not interrupt power to the Controller or the Master Injector during the upgrade process.

controller vice.	3812.1.2 499	70										
us System	Services	Network Logout	System	Shutdown								
45 GPS												
		Anoton injector fir	muoro io bo	ing undeted.	losso bo	notice	at Th	is may take 3 to 4 minutes	340			erv All 🙆
		luster injector in	inware is be	ing updated. I	icuse be	putier	ic. 111	is may take 5 to 4 minutes.	115			
		Ch	assis Info				Port	Port Name	Port Status	Sync Status	Volts	Watts
Identify	Query	Nan	ne	Serial	Letter	FW	1	Master_Port1	ON	ON	56	21
Blink	Query	CMM5_Demo_1_		-1830B0001	A	00.13	2	Master_Port2	ON	ON	56	9
Туре		Temp	Sync	PS1	PS:	2	3	Master_Port3	ON	ON	56	9
56		38	OK	ок	NP		4	Master_Port4	ON	ON	56	14
Identify	Query	Nam	ie	Serial	Letter	FW	1	Slave_Port1_	ON	ON	56	8
Blink	Query	CMM5_Demo_2_		-1723B020W	в	00.13	2	Slave_Port2_	ON	ON	56	8
Type		Temp	Sync	PS1	PS	2	3	Slave_Port3_	ON	ON	56	8
56		36	OK	ок	NP		4	Slave_Port4_	ON	ON	56	9

5 When the upgrade is complete the new Master Injector firmware version will be shown on the CMM5 tab under the Services screen.

It may take a few seconds for the Services screen to be updated with the new Master Injector firmware version.



Update Slave/Standalone Injector Firmware

Perform the following steps to update the firmware on the Slave Injectors or on a Standalone Master Injector via the USB connection:

Before executing this procedure the FTD drivers must be installed on the PC that is used to perform the upgrade. The TeraTerm terminal application must also be installed and configured for serial communication with the Injector.

Procedure 34 Update Slave/Standalone Injector Firmware

- **1** Create a directory on the PC and copy over the firmware (*.hex) and TeraTerm macro (*.ttl) files for the release to be loaded.
- **2** Bring up a TeraTerm terminal window and establish communication with the CMM5 serial port.
- **3** From the TeraTerm window, run the macro from the Control -> Macro menu.
- 4 A file selection dialog box will open. Select the macro that was copied over and run it.
- 5 Another dialog box will open, from which the firmware file to be uploaded is selected.
- **6** The macro will automatically write the contents of the firmware to the CMM5, which boots on the new image. The previous Injector module configuration is carried over unchanged.
- 7 If the upgrade fails, the CMM5 module will display an error message and will come up in the bootloader state. In this case disconnect all cables except the USB connection and rerun the macro.

Installing the CMM5

Ensure that you comply with standard local or national electrical and climbing procedures when you install the CMM5.



WARNING!

Installing a CMM involves electrical power and can involve height and exposure to RF (Radio Frequency) energy. To avoid personal injury, know and follow applicable national and local safety regulations and industry best practices, and follow the specific guidelines in this document

Equipment is intended for installation in Restricted Access Area" /"Les matériels sont destinés à être installés dans des EMPLACEMENTS À ACCÈS RESTREINT.

Avoiding Hazards

Use simple precautions to protect staff and equipment. Hazards include exposure to RF waves, lightning strikes, power lines, and power surges. This section specifically recommends actions to abate these hazards.

Grounding Equipment

Effective lightning protection diverts lightning current safely to ground, Protective Earth (PE) \downarrow . It neither attracts nor prevents lightning strikes.

Grounding Infrastructure Equipment

To protect both your staff and your infrastructure equipment, implement lightning protection as follows:

Observe all local and national codes that apply to grounding for lightning protection.

Before you install your modules, perform the following steps:

- Engage a grounding professional if you have any questions on grounding.
- Install lightning arrestors to transport lightning strikes away from equipment. For example, install a lightning rod on a tower leg other than the leg to which you mount your module.
- Connect your lightning rod to ground.
- Plan to use an appropriate surge suppressor on any Ethernet cable at the point where it enters any building or structure.

Install your modules at least 2 feet (0.6 meters) below the tallest point on the tower, pole, or roof.

Conforming to Regulations

For all electrical purposes, ensure that your network conforms to applicable country and local codes, such as the NEC (National Electrical Code) in the U.S.A. If you are uncertain of code requirements, engage the services of a licensed electrician.

In particular, many codes require that wired electrical devices like the 54 VDC power supply either terminate in a plug connection or be wired with an on/off switch, and not be hard-wired to AC/mains.

Protecting Cables and Connections

Cables that move in the wind can be damaged, impart vibrations to the connected device, or both. At installation time, prevent these problems by securing all cables with cable ties, cleats, or weather-resistant tape.

The cable can be a path for water to follow to enter the cable connector or even the module. You can prevent this problem by including and securing a drip loop where the cable enters the module enclosure.

Testing the Components

The best practice is to connect all the components - BHs, APs, uGPS antenna, and CMM5 - in a test setting and initially configure and verify them before deploying them to an installation. However, circumstances or local practice may require a different practice.

Unpacking Components

When you receive products, carefully inspect all shipping boxes for signs of damage. If you find damage, immediately notify the transportation company.

As you unpack the equipment, verify that all the components that you ordered have arrived. Save all the packing materials to use later, as you transport the equipment to and from installation sites.

Installing a uGPS Antenna

Please refer to page 4-16 for instructions on installing a uGPS antenna. Note that the CMM5 Injector provides power to the uGPS.

Installing a Single Controller

Perform the following procedure to install a single CMM5 Controller:

Procedure 35 Installing the Controller

- **1** Ensure that the following hardware is available:
 - (2) standard mounting ears for a 19-inch rack
 - (2) spacers
 - (4) mounting screws for each mounting ear
- **2** Use 4 mounting screws to secure the mounting ear to the Controller.
- **3** Use 2 mounting screws to secure the other end of the mounting ear to the rack.

Figure 18 Installing a Single Controller



Installing a Single Injector

Perform the following procedure to install a single CMM5 Injector. Note that the 56V Injector requires 2U of rackspace to account for the heat dissipation. The heat sink extends into the second unit of rackspace.

Procedure 36 Installing a Single Injector



Ensure that the following hardware is available:

- (2) standard mounting ears for a 19-inch rack
- (2) spacers
- (4) mounting screws for each mounting ear

- 2 Use 4 mounting screws to secure the mounting ear to the Injector.
- **3** Use 2 mounting screws to secure the other end of the mounting ear to the rack.

Figure 19 Installing a Single Injector



Installing Two Injectors Side by Side

Perform the following procedure to install two 56V Injectors side by side in a 19" rack.

Due to the differences in the mounting hardware, a 56V Injector cannot be mounted side by side with a 29V injector. Only like Injector models can be mounted side by side in a rack.

Procedure 37 Installing Two Injectors

- **1** Ensure that the following hardware is available:
 - (2) standard mounting ears for a 19-inch rack
 - (2) spacers
 - (4) mounting screws for each mounting ear
 - (1) joining bar (w/attaching hardware)
 - (1) joining screw (mounted in rear)
- 2 Use 4 mounting screws to secure a mounting ear to the left side of the injector.
- **3** Use 4 mounting screws to secure a mounting ear to the right side of the injector.
- 4 Attach the joining bar (with hardware) to the Injectors as shown.
- **5** Use 2 mounting screws to secure the other end of the mounting ear to the rack.
- **6** Install the rear joining screw as shown.

Figure 20 Two Injectors with Joining Bar





Figure 21 Rear Attaching Screw

Installing a Controller/Injector Side by Side

Perform the following procedure to install a Controller/Injector combination.

Due to the differences in the mounting hardware, a 29V Injector cannot be mounted side by side with a Controller. The Controller can only be mounted side by side with the 56V Injector in a rack.

Procedure 38 Installing a Controller/Injector Combination

- **1** Ensure that the following hardware is available:
 - (2) standard mounting ears for a 19-inch rack
 - (2) spacers
 - (4) mounting screws for each mounting ear
 - (1) joining bar (w/attaching hardware)
 - (1) joining screw (mounted in rear)

Use 4 mounting screws to secure a mounting ear to the injector.

2

- **3** Use 2 mounting screws to secure the other end of the mounting ear to the rack.
- 4 Attach the joining bar (with hardware) as shown.
- **5** Install the rear joining screw as shown.

Figure 22 Injector/Controller Combination



Installing a 600 Watt Power Supply

Perform the following procedure to install a 600 Watt Power Supply.

The 600W PSU is equipped with two sets of DC output cables. The positive and negative wires of each of these cables are connected together internally to the PSU. Either or both sets of cables may be used to power one or more CMM5 modules as required. Multiple CMM5 modules may be powered from a single 600W PSU by using a split DC power line, as described in the <u>Installing a Split DC Power Line</u> section, provided that the capacity of the PSU is not exceeded.

Procedure 39 Installing a 600W PSU

1 Ensure that the following hardware is available:

- (1) 600W Power Supply
- (1) DC Line Filter
- (1) DC power connector
- (1) AC Line Adapter

2 Apply suitable insulation to the brown, yellow and black wires of the remote on/off control cable (e.g. using heat-shrink tubing).

This procedure step assumes that the remote on/off control function is not used. If this function is to be utilized, refer to the MeanWell PSU specifications for detailed information.

- **3** Connect the Red and Black power wires from one of the DC output cables to the Line side of the DC Line Filter.
- **4** Insert the Red and Black leads of the Load side of the DC Line Filter into the power connector supplied with the CMM5 module, as shown in the <u>Cabling the CMM5</u> section.
- **5** Repeat steps 3 and 4 above for the second DC output cable, if required.

If the second DC cable is not being used, apply suitable insulation to the Red and Black wires (e.g. using heat-shrink tubing).



Figure 23 600 Watt Power Supply Installation



Figure 24 600 Watt Power Supply Installation (rear view)

Installing a Split DC Power Line

A split DC power line is used in situations where you have one injector and one controller.

Procedure 40 Installing a Split DC Power Line

1

Ensure that the following hardware is available:

- (1) 240 Watt Power Supply
- (1) DC Line Filter
- (1) Junction Box
- (1) Connector (Injector)
- (1) Connector (Controller)
- (2) Wire Nuts
- (1) AC Line Adapter
- 2 Connect the Red and Black leads of the 240 Watt Power Supply to the Line side of the DC Line Filter.

3 Connect the Red and Black leads of the Load side of the DC Line Filter to junction box.

4 Connect the Injector and Controller leads to the other side of the junction box.



Figure 25 Installing a Split DC Power Line

Cabling the CMM5

Refer to the following table for cabling requirements for the CMM5 Injector.



Table 3	CMM5	Cable	Requirements
---------	------	-------	--------------

Nomenclature	Function	Cable Required

PRIMARY	Primary 48VDC	Power connector
SECONDARY	Optional: Secondary 48 VDC	Power connector
TO RADIOS	To Access Points	RJ-45 connector
TO SWITCH ARRAY	To Network	RJ-45 connector
OUT	Sync signal out	RJ-12 connector
IN	Sync signal in	RJ-12 connector
UGPS	Universal GPS	RJ-12 connector
USB		USB Female

The following graphic shows a fully cabled Injector/Controller combination with Ferrite beads for EMI suppression.



Figure 27 Injector/Controller Combination Cabling



Figure 28 Wiring the Power Connector

Replaceable Fuses

Each CMM5 Injector and Controller has a replaceable fuse accessible from the front-panel. If the CMM5 is not responsive (no LED's indications or response on the data ports), it is possible that the fuse has blown. Use the following procedure to replace the fuse:

Procedure 41 Replacing Injector/Controller Fuse

- **1** Remove power from the CMM5 Injector/Controller.
- **2** Remove the replaceable fuse from its holder by turning counter-clockwise and extracting from the housing.
- **3** Visually inspect the fuse for indications that it has blown.
- **4** If the fuse needs replacing, use the following specification fuse or equivalent as a replacement:
 - For CMM5 injector: Eaton BK/ABC-10-R; 125VDC, 10A
 - For CMM5 controller: LITTELFUSE 0314002; 125VDC, 2A
- 5 Re-insert the fuse into the fuse holder and the fuse holder into the opening on the chassis.
- **6** Re-apply power to the CMM5 Injector/Controller and check for restoration of normal operation.

Class A Emissions Requirements

The following are the major requirements for the CMM5 to meet Class A Emission requirements when fully loaded with access points.

- 240W and 600W AC Power supplies: It is recommended to use a DC line filter as described above.
- **CMM5 56V Injectors:** In some cases it may be necessary to install Ferrite beads on the input and output CAT5 Ethernet cables. Refer to the installation photos above for the recommended locations of these beads. Recommended device is a large snap on bead with inside dia. 6.3mm, to be used on all 8 pin RJ45 and 6 pin RJ25 within three inches of the CMM5.

Chapter 3: Cambium Cluster Management Module (CMM4) – No Longer Available

The CMM4 consists of 3 subsystems, described in the following sections:

- The CMM4 enclosure and controller board
- Power supply(s)
- An EtherWAN switch (contained only in 1090CKHH models mounted in the CMM4)

CMM4 and Controller Board

The Cluster Management Module 4 (CMM4) provides power, sync, and network connectivity for up to eight APs, backhauls, and Ethernet terrestrial feeds in a variety of configurations. The CMM4 provides

- Sync over Power over Ethernet and integrated surge suppression on the controller board for up to 8 APs or BHs. Both a custom 30 VDC power scheme and a custom 56 VDC power scheme are available. Neither is the same as the later IEEE Standard 802.3af, and neither is compatible with it.
- Managed switching using a hardened EtherWAN switch (1090CKHH models). The CMM4 ships with a 14-port EtherWAN switch and is also available without a switch. The CMM4 originally shipped with a 9-port EtherWAN switch.
- A weather-tight enclosure with either 4 or 7 glands/ports for Ethernet and power cables (1090 and 1091 models).
- Surge suppression on the controller board for the incoming 30V DC and 54V DC power lines and GPS coax cable.
- Auto-negotiation on the Ethernet ports. Ports will auto-negotiate to match inputs that are either 100Base-T or 10Base-T, and either full duplex or half duplex, when the connected device is set to auto-negotiate. Alternatively, these parameters are settable.
- An always-on NTP (Network Time Protocol) server that can provide date and time to any radio that can reach the CMM's management IP address.

Table 4 shows model numbers and Ethernet switch configurations.

CMM4			EtherWAN Switch		
CMM4 Model No.	4 Extended No. Model No.		10/100 Base- TX Ports	10/100/1000 Base-TX Ports	Cable glands (ports)
400001/	1090CKHH (current units)	14	12	2	7
1090CK	1090CKAA (earlier units)	9	8	1	4
1091HH	_	No Switch			7
1092HH (Rackmount)	_	No Switch		-	

Table 4 CMM4 model numbers and Ethernet switch configurations

Inside the CMM4 enclosure is a **controller board**, an **EtherWAN switch** (model 1090CKHH only), and a GPS coax surge suppressor.

The **controller board** injects power and synchronization on up to eight Ethernet ports and provides the equivalent of 600SS surge suppression on each of the eight ports. The controller board is managed using a web browser, Telnet, or SNMP, and is supported by the Prizm Element Management System (EMS). The controller board receives 30 VDC power and/or 54 VDC from external power supplies, and provides 20 VDC power for the EtherWAN switch and other auxiliary equipment. The controller board includes a GPS module, which provides sync and GPS information to the CMM, a management port, an override toggle switch, and an auxiliary sync port for connecting to another CMM.



IMPORTANT!

The controller board does not convert 30 VDC to 56 VDC or 56 VDC to 30 VDC. To power 56 VDC equipment from a CMM4 you must provide a 54 VDC power supply, and to power 30 VDC equipment from a CMM4 you must provide a 30 VDC power supply.

The hardened, managed **EtherWAN switch** (model 1090CKHHonly) provides a full array of networking features. For details on the EtherWAN switch, see page 3-134.



Figure 29 CMM4 internal view, including cable glands



Figure 30 Rackmount CMM4



Outside the enclosure the CMM4 requires a GPS antenna and a power supply.

The **GPS antenna** requires a good view of the sky, and should not be mounted at the highest point of the tower. For best satellite tracking results a clear view of the southern horizon is required. It is included with the CMM4 and is also available as a replacement item using part number GPSANTPNM03D.

Figure 31 GPS Antenna



The model 1090CKHHand model 1091HH CMM4 as shipped includes:

- Weatherized enclosure containing the controller board, EtherWAN Ethernet Switch, and GPS coax surge suppressor. See page 3-117 for details on EtherWAN switch options.
- Patch cables between the controller board and the EtherWAN Ethernet Switch
- U-bolts and V-brackets for pole-mounting the CMM4
- GPS Antenna
- GPS antenna pole-mount kit
- A 1-hole cable gland insert for use on the DC power cable

The model 1092HH Rackmount CMM4 as shipped includes:

- Rackmounting accessories
- GPS Antenna and pole mount accessories

The CMM4 (all models) as shipped does not include:

- Any power supply. The appropriate power supply(s), 30 VDC and/or 54 VDC, must be ordered separately.
- Ethernet cables to connect the CMM4 to APs, backhauls, or terrestrial feeds
- Coax cable connecting the CMM4 to the GPS antenna

Power

The power supply or supplies, 30 VDC and/or 54 VDC, are ordered separately. See Table 5 for pictures of the 30 VDC and 54 VDC supplies and for power supply part numbers.

The **30 VDC power supply N000000L055A** and the **54 VDC power supply N000000L054A** are equipped with a screw terminal and come with no cables.

Table 5 Power supply part numbers

Name	Part Number	
30 VDC Power Supply (no cables or cords)	N00000L055A	
54 VDC Power Supply (no cables or cords)	N000000L054A	54 VDC shown, 30 VDC model features same design

The 30 VDC power supply **N000000L055A** is now included with CMMmicros (Cluster Management Module micro). Previously, CMMmicros shipped with a 24-Volt DC power supply, but all 24 VDC modules and radios are compatible with a 30 Volt system. Note that a 54 VDC CMM power supply will not properly power on 24 VDC radio modules.

Ethernet Switch

The model 1090CKHH CMM4 is available with a hardened, full-featured Ethernet switch made by EtherWAN Systems mounted inside the CMM4 enclosure. The CMM4 ships with a 14-port EtherWAN switch. Earlier units shipped with a 9-port EtherWAN switch.

For details on the EtherWAN switch, including the download site for its separate manual, see page 3-134.

Currently CMM4s ship as model number 1090CKHH and include a 14-port EtherWAN switch. Twelve ports support 10/100Base-T Ethernet and two ports supports 1000Base-T (Gigabit) Ethernet. Typically, eight ports are connected to the eight ports on the controller board via eight Ethernet patch cables, one port is connected to the management port of the controller board, and the remaining ports are available for connecting to high speed backhauls, terrestrial feeds, or for local access.

Earlier CMM4s shipped as model number 1090CKHH and included a 9-port EtherWAN switch. Eight ports support 10/100Base-T Ethernet and one port supports 1000Base-T (Gigabit) Ethernet. Typically, eight ports are connected to the eight ports on the controller board via eight Ethernet patch cables, and the Gigabit Ethernet port is connected to the management port of the controller board if the port isn't needed for Gigabit Ethernet.

Regardless of CMM4 option chosen, one of the ports on the switch must be cabled to the management port of the controller board or other access to the controller must be provided. The eight Ethernet lines pass through the controller board and have power and sync injected, but do not themselves provide network access to management of the controller board.

CMM4 models 1091HH and 1092HH do not contain an EtherWAN switch, and operators may supply an external switch for Ethernet traffic management (such as switch-based VLAN, MAC-based trunking, port security, port mirroring, QoS, etc.)

Specifications

Table 6 CMM4 specifications

Specification	System Range
Max length from CMM to any radio	328 cable feet (100 meters)
Max length from CMM to GPS antenna	100 cable feet (30.5 meters)
Max length from CMM to another CMM, if GPS sync cable is used	100 cable feet (30.5 meters)
Dimensions	20.75" x 14.75" x 7.75" (52.7 cm x 37.5 cm x 19.7)
Weight	14.0 lbs. (6.4 kg)
Operation Temperature	-40°F to +131°F (-40°C to +55°C)
Humidity	100% condensing
Ethernet, GPS Sync, and GPS Coax Cables	The use of cables that conform to the operational temperature of the product as well as being UV light protected is mandatory. Shielded Ethernet cables are strongly recommended
Input Power	29 VDC or 56 VDC, max 10.6A (-40°C)

Specification	System Range
Max length from CMM to any radio	328 cable feet (100 meters)
Max length from CMM to GPS antenna	100 cable feet (30.5 meters)
Max length from CMM to another CMM, if GPS sync cable is used	100 cable feet (30.5 meters)
Dimensions	19" x 9.5" x 1.75" or 1 Rack Space (48.25 cm x 24 cm x 4.5 cm)
Weight	6.8 lbs. (3 kg)
Ethernet, GPS Sync, and GPS Coax Cables	The use of cables that conform to the operational temperature of the product as well as being UV light protected is mandatory. Shielded Ethernet cables are strongly recommended
Input Power	29 VDC or 56 VDC, max 10.6A (-40°C)

Table 7	Rackmount	CMM4	specifications
---------	-----------	------	----------------

Providing sync to CMM via UGPS Module

A UGPS module may also be used as a GPS synchronization source (or backup GPS synchronization source) for the CMM4 units. The UGPS provides GPS synchronization to the CMM unit via the CMM's Aux Sync port (location data is not provided by the UGPS module). This allows any access points or backhaul masters connected to the CMM to receive sync. *This configuration requires that the CMM4 be configured to "Slave" mode via the CMM GUI*. When using the UGPS as a synchronization source for a CMM4, a special sync cable must be used. This cable may be constructed from an RJ-11 cable using the pin configuration in Figure 37.

CMM Planning

The following sections discuss Ethernet cabling, power, syncing two co-located CMMs together, and engineering and ordering cables.

Typical Ethernet Cabling

Physical connectivity and cabling of the CMM4 is variable and is done per the specific requirements of a given installation. The following sections depict several variations for specific network configurations. Based on these typical layouts, operators should design connectivity and cabling that best meets their site-specific needs.

CMM4 models 1091HH and 1092HH do not contain an EtherWAN switch, and operators may supply an external switch for Ethernet traffic management (such as switch-based VLAN, MAC-based trunking, port security, port mirroring, QoS, etc.). This external switch may be cabled similar to the EtherWAN switch in the diagrams below.

Standard Ethernet Cabling Configuration

Figure 32 and Figure 33 show the CMM4's internal ports connected in a standard cabling configuration. In this configuration there are four Ethernet connections to radios and one connection to a terrestrial feed. The four Ethernet ports that are powered (indicated by a red light for 29V or a green light for 56V) were configured using the CMM4 configuration web page. The Ethernet connection to the terrestrial feed is not powered (no red or green light). An Ethernet cable connects the controller board management port to the EtherWAN switch. Four of the eight Ethernet ports to radios are shown as unpowered and unused in this configuration. Local access during local maintenance could be gained by connecting an Ethernet cable from a local computer to any of the unpowered ports or to an unused port on the EtherWAN switch.



Figure 32 CMM4 Standard Configuration







The 30 VDC CMM4 power supply is labeled as 30 VDC and typically measures 30 VDC at its output. The associated CMM4 terminal blocks are marked 29 VDC, and some associated SM power supplies are labeled 29.5 VDC. All of these components are elements of a nominal 30 VDC system, and can be considered "30 VDC" elements.

The 54 VDC CMM4 power supply is labeled as 54 VDC and typically measures 54 VDC at its output. The associated CMM4 terminal blocks are marked 56 VDC, and associated SM power supplies are labeled 56 VDC. All of these components are elements of a nominal 56 VDC system, and can be considered "56 VDC" elements.

When powering PMP 450i AP, ePMP 1000 Connectorized with GPS Sync, or Force 110 PTP devices with a 56 V powered CMM, a crossover cable must be used, or Cambium dongle N000045L001A may also be used (these devices require pins 8,7 +Vcc and pins 4, 5 DC return).

Configured for 1000Base-T (Gigabit) Ethernet Terrestrial Feed



IMPORTANT!

The surge suppression provided by the controller board does not efficiently pass 1000Base-T (Gigabit) Ethernet. Connections required to support Gigabit Ethernet should not pass through the controller board portion of the CMM4 and should have separate surge suppression.

Figure 34 shows typical cabling for supporting a Gigabit Ethernet feed. A Gigabit port of the EtherWAN switch is used for a terrestrial Gigabit Ethernet feed. The surge suppression on the controller board does not efficiently pass 1000Base-T (Gigabit) Ethernet, so the Gigabit Ethernet from the EtherWAN switch needs to

- Be cabled so as not to go through the controller board
- Have surge suppression provided using a HyperLink Technologies AL-CAT6HPJW surge suppressor available from L-Com (<u>http://www.l-com.com</u>) or equivalent.

The AL-CAT6HPJW surge suppressor can be either mounted

- inside the CMM4 enclosure (using stick-and-rip tape like Velcro or other secure mounting), with the ground lug on the surge suppressor connected to the ground lug on the inside of the enclosure with 10 AWG (6 mm²) green ground wire.
- outside the CMM4 enclosure, with the ground lug on the surge suppressor connected to known-good ground/protective earth with 10 AWG (6 mm²) green ground wire.
- in the case where the CMM4 is located in a telecommunication hut, mounted outside the hut at the point of cable penetration, with the ground lug on the surge suppressor connected to known-good ground/protective earth with 10 AWG (6 mm²) green ground wire.



Figure 34 CMM4 cabled to use Gigabit Ethernet feed

Configured for Cambium PTP 400, 500, and 600 Series Ethernet Bridges

PTP 400, 500, and 600 Series Ethernet bridges can use the CMM4's EtherWAN switch for their network connectivity.

These units use a different powering scheme and must be powered using their external PIDU (Powered InDoor Unit), not the powering option of the controller board in the CMM4. The PIDU must be located between the CMM4 and the ODU (OutDoor Unit – the radio), so as not to put power on ports of the EtherWAN switch.



IMPORTANT!

The surge suppression provided by the controller board does not efficiently pass 1000BaseT (Gigabit) Ethernet. Connections required to support Gigabit Ethernet should not pass through the controller board portion of the CMM4 and should have separate surge suppression.

PTP 500 and PTP 600 Series bridges operate at greater than 100 Mbit speeds and so should not be cabled to the controller board portion of the CMM4. Surge suppression to protect the EtherWAN switch should be provided by a Hyperlink Technologies AL-CAT6HP-JW surge suppressor, cabled as shown in Figure 35. The surge suppressor should be mounted

- within 3 ft. (1 m) of the CMM4 if the CMM4 is located outdoors
- on the outside of the building or communications hut at the point of cable penetration if the CMM4 is located indoors.



Figure 35 CMM4 cabled to support PTP 500/600

PTP 400 Series bridges operate at less than 100 Mbit speeds and so can be cabled to one of the eight Ethernet ports on the controller board, thus taking advantage of the controller board for surge suppression. The port must be configured to be unpowered. The PTP 400 Series bridge is powered by its own externally located PIDU.



PTP 450 devices do not support synchronization over power port.

Power Planning

IMPORTANT!

The power supply or supplies for the CMM4 must be separately ordered – no power supplies are included under model numbers 1090CK, 1091, or 1092. (This differs from the CMMmicro where the power supply is included when model number 1070CK is ordered.) See Table 5 for pictures of the 30 VDC and 54 VDC supplies and for power supply part numbers.

A 30 VDC power supply is needed for the following equipment:

- PMP 100 FSK regular and Advantage APs
- PMP 54400 OFDM APs
- PTP 100 FSK BHs
- PTP 54200 OFDM BHs
- PMP 450 Series OFDM APs
- ePMP Series

A 54 VDC power supply is needed for the following equipment:

- PMP 320 802.16e APs
- PMP 430 OFDM APs
- PMP 49400 OFDM APs
- PTP 49200 OFDM BHs
- PMP 450i OFDM APs (requires crossover cable N000045L001A for Ethernet
- connection)

	NOTE: In most cases SMs use the same voltage as their associated APs. Three exceptions to be aware of are
_ <u>i</u> _	 PMP 320 SMs use 802.3af power supplies
	 PMP 430 SMs use 30 VDC power supplies.
	 PMP 450 900 MHz SMs use 30 VDC power supplies

There are four input power terminal blocks inside the CMM4. Two of them are for 29/30 VDC input, and the other two are for 56 VDC input. The two 29 VDC terminal blocks and the two 56 VDC terminal blocks allow the CMM4 to be powered from redundant power supplies, if so desired.

The 30 VDC CMM4 power supply is labeled as 30 VDC and typically measures 30 VDC at its output. The associated CMM4 terminal blocks are marked 29 VDC, and some associated SM power supplies are labeled 29.5 VDC. All of these components are elements of a nominal 30 VDC system, and can be considered "30 VDC" elements.

The 54 VDC CMM4 power supply is labeled as 54 VDC and typically measures 54 VDC at its output. The associated CMM4 terminal blocks are marked 56 VDC, and associated SM power supplies are labeled 56 VDC. *All of these components are elements of a nominal 56 VDC system, and can be considered "56 VDC" elements.*

One of the CMM 56 VDC blocks has 2 terminals while the other has 3. The third terminal provides an additional grounding point, if needed.

If you are using a CMM4 to power both 30 VDC and 56 VDC systems, then you must install both 30 VDC and 54 VDC power supplies along with the CMM4. These power supplies must be wired to the correct terminal blocks (marked 29 VDC and 56 VDC).

IMPORTANT!

This advisory only affects operators using a CMM4 that supplies power to both 30V devices (PMP100 radios) and 56V devices (PMP430 or PMP320 radios) via discontinued ACPS120WA power supplies. This configuration does NOT require a 1k 5W resistor on the CMM4 29V terminals (This 30V power supply was made available for order around December 3, 2010). The phased out 30V model ACPS112WA power supply will always require a 1k 5W resistor when a 56V supply is present. Since both power supplies look identical, see the label under the power supply to identify the model.



Power supply model ACPS112WA requires a 1k 5W resistor across the 30V DC input terminal of the CMM4 when both 30V AND 56V are present. Doing so will prevent the 30V power supply to not always come out of sleep mode with a light load. The power supply will attempt to come out of sleep mode, and if it does not see sufficient load it goes into a sleep/recovery cycle that is observable by watching the 30V LED on the port connector turn on and off.

Power supply Model ACPS120WA satisfies the European Union's Energy Level 5 requirement and DOES NOT require a 1k 5W resistor.

See Procedure 47 Installing a special resistor for dual-powered CMM4s for more information.

The 30 VDC and 54 VDC power supplies are rated for outdoor temperatures, but are not weather tight and so must be mounted in a communications hut or enclosure provided by the operator. They should not be mounted inside the CMM4 enclosure, as it is not designed to handle the additional heat load of the power supplies. (Although it appears there is space for the power supplies, the key constraint is the surface area of the enclosure for dissipating heat, not the volume of the enclosure.)

With most of the 30 VDC radios, the radio uses up to 10 W and the input voltage as measured at the "29 VDC" terminals on the CMM4 must be between 22 and 32 VDC to support 8 APs at the maximum 100 m (328 ft.) Ethernet cable length.

With PMP 54400 APs, the radio uses up to 12 W at 30 VDC and the input voltage as measured at the "29 VDC" terminals on the CMM4 must be between 28 and 32 VDC to support 8 APs at the maximum 100 m (328 ft.) Ethernet cable length.

When supporting 56 VDC systems, the input voltage as measured at the "56 VDC" terminals on the CMM4 must be between 44 and 59 VDC.

The CMM4 controller board provides two 20 VDC outputs – one for the EtherWAN switch, and one optionally available for powering another low power device mounted in the enclosure by the operator, such as a fiber-to-copper media converter. Total 20 VDC accessory power should not exceed 20 W.

In cases where -48 VDC power is available and powering from the -48 VDC is desired (for example, in some telecommunications huts), procure a -48 VDC to +56 VDC converter such as a Mean Well Model SD-350C-48 and install between the -48 VDC source and the +56 VDC power supply.

EU Countries Only

To enable regulatory compliance with the European Union (EU) directives, a power line filter module must be installed on the DC side of the power supply. This module may be ordered from Cambium Networks (part number N000000L056A). Please reference section EU countries only – power line filter module installation on page 3-164.



Syncing Two Co-located CMMs Together

Two CMMs can be synced together to meet either of the following goals:

- Case 1 One GPS antenna for two CMMs: Use a single GPS antenna to support two CMMs. This
 can be advantageous for a site with 2 CMMs where the site owner is charging per antenna and the
 operator wishes to minimize site costs by only installing one GPS antenna.
- Case 2 Redundant Sync: Take advantage of co-located CMMs, each with its own antenna, to provide "warm spare" redundant sync. If one GPS antenna, coax cable, or GPS module has problems, remote re-configuration can re-establish sync to that CMM.

The CMMs can be any combination of CMMs - either two CMM4s, two CMMmicros, or a CMM4 and a CMMmicro.

Syncing two CMMs together requires connecting their RJ-11 auxiliary ports together with a 6-wire cable and configuring each CMM appropriately. The location of the RJ-11 auxiliary port is shown in Figure 29.

The connection cable is a special cable, not a straight-through cable. See page 3-133 3-133 for information on the cable and Figure 37 for cable pinouts.

Case 1 – Redundant Sync

In this case, each CMM is connected to its own GPS antenna via coax in the standard way, and the two CMMs are connected via a special cable between the auxiliary sync RJ-11 ports of each CMM. If one CMM loses sync due to problems with its GPS antenna, coax cable, or GPS module, that CMM can be re-configured remotely over the network to get sync from the other CMM by going to the **Configuration** > **CMM** web page and setting the sync source to **Slave (RJ11 Port)**.

In normal operation, the appropriate web pages of each CMM will display GPS information, as will the appropriate pages of connected APs and BHMs. Each CMM can be used as a NTP (Network Timing Protocol) server for time-of-day information for APs and BHMs, configured at the AP or BHM.

Once reconfigured to get sync over the auxiliary sync RJ-11 Port, a CMM and its connected APs and BHMs will no longer display GPS information. That CMM will no longer be providing NTP server functions, and any AP or BHM configured to point to it for time-of-day will need to be re-configured to point to a different NTP server to get accurate time-of-day information.

Depending on network design and other equipment in the network, the two CMMs may be connected with an Ethernet cable, or may be each fed separately.

Case 2 – One GPS antenna for two CMMs

A typical scenario for the use of Case 2 would be where a site or building owner is charging per antenna, the site requires 2 CMMs, and the operator wishes to minimize site costs by only installing one GPS antenna.

In this case, the GPS antenna connects to one CMM via coax cable, and the two CMMs are connected via a cable between the auxiliary sync RJ11 ports of each CMM. Sync is passed from one CMM to the other via this cable. The Sync Source on the Configuration > CMM page of the CMM connected to the GPS antenna should be set to **Master (GPS Module)**, and the Sync Source on the **Configuration** > **CMM** page of the other CMM should be set to **Slave (RJ11 Port)**.

The slave CMM and its connected APs and BHMs will not display GPS information and the slave CMM will not function as an NTP (Network Time Protocol) server.

Depending on network design and other equipment in the network, the two CMMs may be connected with an Ethernet cable, or may be each fed separately.

Cables

Ethernet Cables

The operator provides the Ethernet cables between the CMM4 and the radios it supports. They must be engineered to length and are not included with the CMM4. The cable length from the CMM4 to any radio must be under 100 m (328 ft.).

Cables are available from Best-Tronics, Inc., <u>http://best-tronics.com/</u>. These cables can be ordered in lengths up to 328 ft. (100 m) and are listed in Table 8.

Typical Use	Best- Tronics Part #	Description
Infrastructure Ethernet cable	BT-0781S-XXX	RJ-45 to RJ-45 straight, shielded, UV-resistant Ethernet cable using outdoor STP Cat 5e cable, lower cost than plenum-rated, available only in black.
Infrastructure Ethernet cable for plenums	BT-0562S-XXX	RJ-45 to RJ-45 straight, shielded, UV-resistant, plenum- rated Ethernet cable using outdoor STP Cat 5e cable, available in beige, blue, grey, or white.

 Table 8
 Recommended Ethernet cables



IMPORTANT!

Shielded Ethernet cable is strongly recommended for AP and BH installations.

Alternatively, equivalent cables may be procured by the operator, fabricated by the operator in a depot, or fabricated at site. The modules have auto MDX/MDIX and so either straight-through or crossover Ethernet cables may be used. Pinouts for straight-through cables are shown in Table 9 and Table 10. Figure 36 shows the location of Pin 1, relative to the lock tab on the connector.

 Table 9
 RJ-45 pinouts for straight-through Ethernet cable - 30 VDC


Pin 1 \rightarrow	white / orange	← Pin 1	Pin	RJ-45 Straight-thru	Pin
Pin 2 \rightarrow	orange	← Pin 2	TX+ 1	_	1 R X+
Pin 3 \rightarrow	white / green	← Pin 3	TX 2		
Pin 4 \rightarrow	blue	← Pin 4			2 RA-
Pin 5 \rightarrow	white / blue	← Pin 5	RX+ 3 🚞		3 TX-
Pin 6 \rightarrow	green	← Pin 6	+Vreturn 4		4 +Vreturn
Pin 7 \rightarrow	white / brown	← Pin 7	+V 5 🚃		5 +V
Pin 8 \rightarrow	brown	← Pin 8	RX- 6		6 TX-
Pins 5 and	8 carry power to the	modules.	+Vreturn 7 📻		= 7 +∨return
			+V 8		8 +V

Table 10 RJ-45 pinouts for straight-through Ethernet cable - 56 VDC

Figure 36 Location of pin 1	Figure	36	Location	of	pin	1
-----------------------------	--------	----	----------	----	-----	---



(Lock tab underneath)



- CA-0287S: (shielded, plenum rated)
- CA-0367S: (lower cost, shielded, nonplenum-rated)

GPS Antenna Coaxial Cable

The operator provides the GPS antenna coaxial cable between the CMM4 and the GPS antenna. It must be engineered to length and is not included with the CMM4. In most cases, the cable length from the CMM4 to the GPS antenna must be under 30 m (~100 ft.).

Antenna cables can be ordered from Best-Tronics, Inc., http://best-tronics.com/. Antenna cables can be ordered in lengths up to 100 ft. (30.4 m), as listed in Table 11.

Table 11	Recommended	antenna	cable
----------	-------------	---------	-------

Best- Tronics Part #	Description
BT-0564	N to N GPS antenna cable

Alternatively, equivalent cables may be procured by the operator, fabricated by the operator in a depot, or fabricated at site using

- Up to 100 feet (30.4 meters) of LMR200 coaxial cable
- 2 Times Microwave N-male connectors (Times Microwave P/N TC-200-NM) or equivalent connectors



NOTE:

The CMM4 has a female N-type coax connector on the outside of the enclosure, whereas the CMMmicro has a female BNC-type connector inside the enclosure. Take this into account when ordering or fabricating cables, and when replacing a CMMmicro with a CMM4.

DC Cables

Cambium recommends the use of flame-retardant, moisture and sunlight-resistant cable rated to 75° C wet and bendable at -25° C for the DC cable between the power supply(s) and the CMM4. Examples of such cable include General Cable (http://www.generalcable.com), catalog number 234580 for 12 AWG cable and catalog number 236300 for 10 AWG cable, found in the Telecommunications Catalog.

Recommended wire size for the CMM4's DC cable in most systems is shown in Table 12. These wire sizes support up to 8 radios (30 VDC or 56 VDC radios) at up to 100 m (328 ft.) Ethernet cable length from the CMM4.

DC Power Cord Length	Wire Gauge
Under 12 ft. (12.6 m)	14 AWG (2 mm²)
12 - 90 ft. (3−25 m)	12 AWG (4 mm ²)
91-145 ft. (26-45 m)	10 AWG (6 mm ²)
146-230 ft. (46-70 m)	8 AWG (10 mm²)

Table	12	Wire	size	for	CMM4	DC	cable
Table		VVII C	SIZC	101	CUIUT		cubic

For supporting 8 PMP 54400 APs or PTP 54200 BHs (which are 12 W 30 VDC radios), reduce either the maximum DC cable length or the Ethernet cable length by half. For example, if the Ethernet cable length from CMM4 to 8 PMP 54400 APs is 50 m (164 ft.) or less, the DC lengths in Table 12 can be used. If the Ethernet cable length from CMM4 to 8 PMP 54400 APs is 100 m (328 ft.), then halve the lengths shown in Table 12.

CMM Sync and UGPS Sync Cable

As described in on page 3-128, two CMMs (two CMMmicros, two CMM4s, or a CMMmicro and a CMM4) can be connected together with a CMM sync cable to provide either

- The ability to have one GPS antenna support two CMMs
- "Warm spare" redundant sync

Pinouts for the CMM sync cable are shown in Figure 37. Figure 38 shows the location of Pin 1, relative to the lock tab on the connector. When using a UGPS module for providing synchronization pulses to a CMM4 unit, use the pinout configuration shown in Figure 51.

RJ-11, 6 pin 6 connector



NOTE:

The CMM sync cable used to connect two CMMs for sync purposes has different pinouts than the straight-through sync cable used to connect a "remote AP" to an SM, or an AP or BHM to a CMM2.

Figure 37 CMM sync cable pinout

RJ-11, 6 pin 6 connector



Note: Only 2 pairs are used

Figure 38 Location of pin 1



(Lock tab is on other side)

EtherWAN Switch Information

This section includes key information on the EtherWAN switch. For full details and configuration information, EtherWAN switch manuals are downloadable from http://www.etherwan.com/support-mo.php. Consult Table 13 to obtain the appropriate model number for your EtherWAN switch to use to download the correct manual.

EtherWAN switch management may be accessed in one of three ways:

- Standard web-based browser interface
- External SNMP-based network management using SNMP commands or an Element Management System such as Prizm or One Point Wireless Manager
- Administration console via the switch's RS-232 serial port using Windows Hyperterminal or equivalent

The EtherWAN switch as provided has the IP address, login ID, and password as shown in Table 13.

CMM4		Eth	erWAN Switch					
Extended Model No.	Total Ports	otal Base- TX Ports Ports Ports EtherWAN		EtherWAN Model No.	Default IP address	Login ID	Default password	
1090CKHH	14	12	2	EX72129A	169.254.1.1	root (not changeable by user)	No password	
1090CKAA (earlier versions)	9	8	1	EX96000	192.168.1.10	admin (not changeable by user)	No password	

Table 13 EtherWAN switch details

The 14-port EtherWAN switch may be reset (rebooted) either remotely or after gaining physical access to the CMM4:

- remotely: access the CMM4 controller board web page, navigate to Configuration > CMM and click the Reset OEM Switch button to power cycle the switch.
- after gaining physical access to the inside of the CMM4 enclosure: press the inset Reset button on the EtherWAN switch's faceplate using a nail or similar tool.

Either process reboots the switch but *does not* reset it to factory defaults.

The 9-port EtherWAN switch may be reset (rebooted) remotely by accessing the CMM4 controller board web page, navigating to **Configuration** > **CMM** and clicking the **Reset OEM Switch** button. This button power cycles the EtherWAN switch but *does not* reset it to factory defaults.

If you lose or forget the IP address of the EtherWAN switch after configuring it to an address other than the default IP address, gain physical access to the CMM4, access the EtherWAN switch via its RS-232 serial port (which doesn't require an IP address), and proceed to view or set the IP address. Alternatively, you may wish to use Wireshark, Angry IP Scanner, or other tools to discover the missing IP address. If after configuring a password you lose or forget it, contact Technical Support for assistance, using the contact information on page xi.

Configuring a CMM4

Web pages on the CMM4 provide status information and support configuration. The eight Ethernet ports can be configured, and information is provided on GPS status, Port configuration, FPGA and software revision.

For information on configuring the EtherWAN switch, see the *EtherWAN Switch Manual*. The manual is available for download as described in on page 3-134.

Configuring IP Communications Parameters

An example of the CMM4 IP tab is displayed in Figure 39.

Figure 39 IP tab of CMM4

IP Settings		
IP Address :	10.120.216.33	
Subnet Mask :	255.255.255.0	
Default Gateway :	10.120.216.254	

The IP tab allows you to set the IP communications parameters for management of the CMM4.

Attribute	Meaning
IP Address	This is the IP address of the CMM4 controller board. The EtherWAN Switch has a separate and distinct IP address that is set using the EtherWAN Switch web or serial interface.
	The default value for this parameter is 169.254.1.1.
Subnet Mask	This is the subnet mask of the CMM4 (controller board). The EtherWAN Switch has a separate subnet mask that is set using the Ethernet Switch web or serial interface.
	The default value for this parameter is 255.255.255.0.

Table 14IP tab attributes

Attribute	Meaning
Default Gateway	This is the default gateway of the CMM4 (controller board). The EtherWAN Switch has a separate default gateway setting that is set using the Ethernet Switch web or serial interface.
	The default for this parameter is 169.254.0.0.
	Since both the controller board and the 14-port EtherWAN switch have the same default IP address, either may respond when using IP address 169.254.1.1 from your PC. You can configure first whichever unit responds first, as easily determined by the distinctive web pages of the controller board or the EtherWAN switch, or you can use Procedure 42 to more deterministically access and configure the EtherWAN switch's and controller board's IP addresses.

Procedure 42 Configuring EtherWAN switch and Controller Board IP Addresses

- **1** Connect an Ethernet cable between your PC and the EtherWAN switch.
- 2 Disconnect the patch cable between the controller board management port and the EtherWAN switch.
- **3** Enter the EtherWAN switch's web pages using your browser and IP address 169.254.1.1 and proceed to configure the EtherWAN switch.
- **4** Reconnect the patch cable between the controller board management port and the EtherWAN switch.
- **5** Enter the controller board's web pages using your browser and IP address 169.254.1.1 and proceed to configure the CMM4 controller board.
- 6 Disconnect your PC from the EtherWAN switch.

Overriding Forgotten IP Addresses, Usernames, or Passwords

By using the toggle switch on the CMM4 controller board, you can temporarily override a lost or unknown IP address, username, or password as follows:

- When the toggle switch is in the "Default" position (up or towards the operator), a power cycle causes the CMM4 to boot with the default IP address and no username or password required. The CMM GUI displays a message indicating that the unit has been powered up in default mode.
- When the toggle switch is in the "Normal" position (down or away from the operator) a power cycle causes the CMM4 to boot with your operator-set IP address, username(s) and password(s).

To override a lost or unknown IP address or password, perform the following steps.

Procedure 43 Overriding forgotten IP addresses, usernames, or passwords

IMPORTANT!

When rebooted into override mode the ports on the CMM4 are temporarily unpowered. APs or BHs connected to the CMM4 will not have power, so you will temporarily lose the ability to access the CMM4 through those APs or BHs.

- **1** Gain physical access to the inside of the CMM4 enclosure.
- 2 Establish direct Ethernet connectivity to the CMM4 (not through an AP or BH).
- **3** Flip the toggle switch to the "Default" position (normally up, toward you).
 - Power cycle the CMM4.
 RESULT: The module can now be accessed with the default IP address of 169.254.1.1, no username, and no password. Ports are not currently powered due to toggle switch override and are shown unpowered on the Configuration > Ports tab.
- View the current IP address or set a new IP address on the Configuration > IP tab, view users on the Account > Change Users Password tab, add users on the Account > Add User tab, or set a new password on the Account > Change Users Password tab.
- 6 Change any other configuration values if desired. If you change ANY parameters on the **Configuration** > **Ports** tab then the displayed parameters (including any unpowered ports) will be used when rebooted with the toggle switch in the "Normal" position. Leave ALL unchanged and the previous port configuration will be used.

IMPORTANT!

If you leave the parameters on the **Configuration** > **Ports** tab unchanged, the ports will return to the state they were in before the override. Those that were powered before will be powered again. However, if you click "Save Changes" on the **Configuration** > **Ports** page before rebooting then the next boot will come up with the displayed port configuration.

- 7 Click the **Save Changes** button.
- 8 Flip the toggle switch to the "Normal" position (nominally down, away from you).
- 9 Click the **Reboot** button.



RECOMMENDATION:

Note or print the IP settings from the **Configuration** > IP tab. Ensure that you can readily associate these IP settings with the module for future use.

-			
-	-	_	
5	1		
5	-		1

NOTE:

An override/default plug (an RJ-11 connector with pins 4 and 6 tied together) inserted into the auxiliary port before booting the CMM4 is equivalent to using the toggle switch and will also temporarily override a lost or unknown IP address, username, or password.

Log In

An example of the CMM4 Login page is displayed in Figure 40.



Cambi	um Ne	etwork	S						
Home Copyright Username: Password:	General Sta	atus		Home CMM	→ Gener 4 0a-00-3e-4	r al Status e8-04-03			
Login	Port	1	2	3	4	5	6	7	8
Account: none Level: GUEST	Port Text	Port 1 Description	Port 2 Description	Port 3 Description	Port 4 Description	Port 5 Description	Port 6 Description	Port 7 Description	Port 8 Description
CANOPY° CMM4	Power		0	•	•	•	0	• • V	• • V
	Device Type	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V
	Device information CMM4 0a-00-3e-e8-04-03 Device : CMM4 0a-00-3e-e8-04-03 Software Version : 0a1107 CMM4 FPGA Version : 0a1107 CMM4 FPGA Platform : 05 PLD Version : 1 (CMM4) MAC Address : 0a-00-3e-e8-04-03 System Time : 01:06:46 01/01/2001 System Up Time : 01:06:46 Ethernet Status : 100Base-TX Full Duplex								
	Sync Statu SYNC Puls SYNC Puls Satellites V Satellites T Antenna C Tracking M Latitude : Longitude : Height :	IS e Status : e Source : isible : racked : onnection : ode :		No Ma 0 Uni Re 0° 0°	SYNC ster (GPS Mod known served 0' 0.00" N 0' 0.00" E neters	dule)			
	Site Inform Site Name Site Location Site Contact	ation : on : ct :		Blu No No	e CMM4 Site Location Site Contact				

With a new CMM4 or one that has been reset to factory defaults, a user can access all web pages and tabs without using a username or password. This unsecure state should be remedied by creating users and passwords as described in on page 3-142.

After users have been added, to access the web pages other than the **Home** > **General Status** tab available to GUESTS you must use the Login page to enter a user name and password.

The left side of the web page displays the current user name as **Account** and the permissions level of that user as **Level**.

All CMM user accounts are local to the device.

User Update

An example of the CMM4 User Update tab is displayed in Figure 41.

Figure 41	Changer	Users	Password	tab	of CMM4
-----------	---------	-------	----------	-----	---------

Update Password		
User :	admin 💌	
New Password :		
Confirm Password :		
	Change Password	

The Change Users Password tab provides the following options:

	Table 15	Change	User	Password	tab	attributes
--	----------	--------	------	----------	-----	------------

Attribute	Meaning
New Password	Type the new password (up to 32 alphanumeric characters) that you want to use for management access to this CMM4.
Confirm Password	Retype what you typed into the New Password parameter. If the password differs from the password you typed into the New Password field a failure message will be displayed in the Account Status field.
Change Password	To put the new password for the user into immediate effect, click this button.
Account Status	This is a read-only field that provides information on the current activity for that screen. For instance, if changing the password was successful a message will be displayed indicating the new password is active.

Add User

An example of the CMM4 Add User tab is displayed in Figure 42.

```
Figure 42 Add User tab of CMM4
```

Add User		
User Name :	admin	
Level :	INSTALLER 💌	
New Password :		
Confirm Password :		
	Add	
Account Status		
<u></u>		

If you are of ADMINISTRATOR level, the Add User Tab provides the following options to you.

Attribute	Meaning
User Name	Type the user name that you want to assign to the user you are adding.
Level	Use the down arrow to select the desired permission level for the user you are adding. Choices include INSTALLER and ADMINISTRATOR with the difference being that a user with INSTALLER permissions can only change their own password and cannot add or delete users, whereas a user with ADMINISTRATOR permissions can change any user's password and can add and delete users.
New Password	Type the new password (up to 32 alphanumeric characters) for management access to this CMM4 by the user you are adding. Leaving this field blank means no password is needed and any password (or no password) will allow the user to log in.
Confirm Password	Retype what you typed into the New Password parameter. If there is a failure the "Account Status" will indicate that the new password failed.
Account Status	This is a read-only field that provides information on the current activity for that screen. For instance, if adding a new user was successful a message will be displayed indicating the user has been added.

Table 16 Add User attributes

Delete User

An example of the CMM4 Delete User tab is displayed in Figure 43.

Figure 43 Delete User tab of CMM4

Delete User		
User :	admin 💌	
l	Delete	J
Account Status		

If you are of ADMINISTRATOR level and want to remove a user, the Delete Users Password tab allows you to do so as follows:

Attribute	Meaning
User	Use the down arrow to select the user you want to remove. Note that the username used to log into the radio may not be deleted
Delete	Ensure that the intended user is selected. Then click this button.
Account Status	This is a read-only field that provides information on the current activity for that screen. For instance, if deleting the user was successful a message will be displayed indicating the user has been deleted.

 Table 17
 Delete User attributes

Configuring the CMM4 ports

An example of the CMM4 Port Configurations tab is displayed in Figure 44.

	Figure 44	Port	Configuration	tab	of	CMM4
--	-----------	------	---------------	-----	----	------

Po	rt Configurat	ion							[
P	ort Number	1	2	3	4	5	6	7	8	
P	ort Text	Port 1 Descrip	Port 2 Descrip	Port 3 Descrip	Port 4 Descrip	Port 5 Descrip	Port 6 Descrip	Port 7 Descrip	Port 8 Descrip	
P	ower) On) On) On) On) On) On	On	On	
		Off Reset	Off Reset	Off Reset	Off Reset	Off Reset	Off Reset	Off	Off	
D	evice Type	29 V 💌								

The Port Configurations tab provides the following parameters.

 Table 18
 Port Configuration attributes

Attribute	Meaning
Port 1 to 8: Description	This is a user-defined field that identifies the port. It appears in the Home -> General Status page.
Port 1 to 8: Power On or Off	Select Power On to restore power over Ethernet to the device that is connected to this port or Power Off to remove power from it.
Ports 1 to 8: Power Cycle	A button to invoke this feature is visible only when the port is powered up.
Ports 1 to 8: Device Type	Select 29 V or 56 V to identify the type of power supplied to that port. The red light indicates 29 V and the green light indicates 56V on the port status bar.

Configuring General CMM4 Parameters

An example of the CMM4 Configuration tab is displayed in Figure 45.

Figure 45 CMM4 Configuration tab

General Configurations	
Session Timeout :	600
Webpage Auto Update :	3 Seconds (0 = Disable Auto Update)
Ethernet Switch Power	
	Reset OEM Switch
Svpc Source	
Sync Source	Master (OBS Matula)
	Master (GPS Module)
Verify GPS Message Checksum	Enabled
Verify of o message offectioum.	O Disabled
Link Speeds	
Link Speeds :	Auto Negotiation
IP Access Filtering	
	IP Access Filtering Enabled - Only allow access from IP addresses
IP Access Control :	specified below
	IP Access Filtering Disabled - Allow access from all IP addresses
Allowed Source IP 1 :	0.0.0.0
Allowed Source IP 2 :	0.0.0.0
Allowed Source IP 3 :	0.0.0.0

The CMM4 Configuration tab provides the following parameters.

Table 19CMM tab attributes

Attribute	Meaning			
Session Timeout	Enter the expiry in set telnet, or ftp access	econds for remote management sessions via HTTP, to the CMM4 up to a maximum of 2592000 seconds.		
Webpage Auto Update	Enter the frequency refresh the web-bas causes the web-bas	(in seconds) for the web browser to automatically ed interface. The default setting is 0. The 0 setting ed interface to never be automatically refreshed.		
Ethernet Switch Power	If you change this value and then click Save Changes , the change becomes effective immediately and the previous value is lost.			
Sync Source	Specify how the CM	M4 should receive timing, either		
	• Master (GPS M	odule)		
	 Slave (RJ11 Po 	rt)		
	For additional information on using the Slave sync source, page 3-128.			
Verify GPS Message Checksum	When enabled, the device validates GPS messaging to ensure that the radio is properly receiving data from the GPS source. If a GPS source is not calculating and sending checksum data properly, the AP will still receive synchronization pulses but not GPS data (location, data, etc.) and the Invalid Message counter will increase on the radio's Home > GPS Status page. If an AP is receiving synchronization properly from a GPS unit but is not receiving GPS data, operators may set Verify GPS Message Checksum to "Disabled" to ignore checksum failures and to allow the AP to process the GPS data.			
Link Speeds	If you wish to force the CMM4 to a speed or duplex state, or to return the module to auto-negotiating speed and duplex state, change the selection for the port. The range of selections is defined below:			
	Table 20 Link Speed selections for CMM4			
	Selection	Result		
	Auto Negotiation	The CMM4 attempts to auto-negotiate speed and duplex state. (This is the default and recommended setting for most network configurations.)		
	10Base T Half Duplex	The CMM4 is forced to 10 Mbps and half duplex.		
	10Base T Full Duplex	The CMM4 is forced to 10 Mbps and full duplex.		
	100Base T Half Duplex	The CMM4 is forced to 100 Mbps and half duplex.		
	100Base T Full Duplex	The CMM4 is forced to 100 Mbps and full duplex.		
	If you change this va change becomes eff	alue for a port and then click Save Changes , the rective immediately and the previous value is lost.		

Attribute	Meaning
IP Access Control	You can permit access to the CMM4 from any IP address (IP Access Filtering Disabled) or limit it to access from only one, two, or three IP addresses that you specify (IP Access Filtering Enabled). If you select IP Access Filtering Enabled , then you must populate at least one of the three Allowed Source IP parameters or have no access permitted from any IP address, including access and management by Prizm.
Allowed Source IP 1 to 3	If you selected IP Access Filtering Enabled for the IP Access Control parameter, then you must populate at least one of the three Allowed Source IP parameters or have no access permitted to the CMM4 from any IP address. You may populate as many as all three.

Configuring the SNMP parameters

An example of the CMM4 SNMP tab is displayed in Figure 46.

SIMP IP		-	
Community String :		Canopy	
Accessing IP / Subr	net Mask 1 :	0.0.0.0	/ 0
Accessing IP / Subr	net Mask 2 :	0.0.0.0	/ 0
Accessing IP / Subr	net Mask 3 :	0.0.0.0	/ 0
Accessing IP / Subr	net Mask 4 :	0.0.0.0	/ 0
Accessing IP / Subr	net Mask 5 :	0.0.0.0	/ 0
Accessing IP / Subr	net Mask 6 :	0.0.0.0	/ 0
Accessing IP / Subr	net Mask 7 :	0.0.00	/ 0
Accessing IP / Subr	net Mask 8 :	0.0.00	/ 0
Accessing IP / Subr	net Mask 9 :	0.0.0	/ 0
Accessing IP / Subr	net Mask 10 :	0.0.0.0	/ 0
Permissions			
		Read Only	
Read Permissions :		Read / Write	2
Trap Addresses			
Trap Address 1 :		0.0.0.0	
Trap Address 2 :		0.0.0.0	
Trap Address 3 :		0.0.0.0	
Trap Address 4 :		0.0.0.0	
Trap Address 5 :		0.0.0.0	
Trap Address 6 :		0.0.0.0	
Trap Address 7 :		0.0.0.0	
Trap Address 8 :		0.0.0.0	
Trap Address 9 :		0.0.0.0	
Trap Address 10 :		0.0.0.0	
Trap Enable			
Sync Status		Enabled	
		Disabled	
Site Information			
Site Information	Enabled		
Viewable to Guest Users :	 Disabled 		
Site Name :	Blue CMM4		
Site Contact :	No Site Contact		
Site Location :	No Site Location		

Figure 46 SNMP tab of CMM4

CMM supports up to SNMPv2.

The SNMP tab provides the following parameters.

Table 21 SNMP tab attributes

Attribute	Meaning		
Community String	Specify a control string that allows Prizm or an Element Management System (EMS) to access the CMM4 via SNMP. No spaces are allowed in this string. The default string is Canopy . The value is clear text and is readable by a packet monitor. You can attain additional security by configuring the Accessing Subnet and Read Permissions parameters.		
Accessing Subnet	 Specify the addresses that are allowed to send SNMP requests to this CMM4. The EMS must have an address that is among these addresses (this subnet). You must enter both The network IP address in the form xxx.xxx.xxx The CIDR (Classless Interdomain Routing) prefix length in the form /xx For example the /16 in 198.32.0.0/16 specifies a subnet mask of 255.255.0.0 (the first 16 bits in the address range are identical among all members of the subnet). 192.168.102.0/24 specifies that any device whose IP address is in the range 192.168.102.0 to 192.168.102.254 can send SNMP requests to the CMM4, presuming that the device supplies the correct Community String value. The default treatment is to allow all networks access. 		
Read Permissions	Select Read Only if you wish to disallow any parameter value changes by Prizm or an NMS.		
Trap Address 1 to 10	 Specify the IP address (xxx.xxx.xxx) of one to ten servers (Prizm or NMS) to which trap information should be sent. Traps inform the monitoring systems that something has occurred. For example, trap information is sent after a reboot of the module. when Prizm or an NMS attempts to access agent information but either supplied an inappropriate community string or SNMP version number. is associated with a subnet to which access is disallowed. 		
Trap Enable for Sync Status	Variable to enable/disable GPS sync/out-sync traps.		

Attribute	Meaning
Site Name	Enter a name for the physical module. What you enter here will be shown on the General Status tab in the Home page of the CMM4. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Contact	Enter contact information for the physical module. What you enter here will be shown on the General Status tab in the Home page of the CMM4. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Location	Enter site information for the physical module. What you enter here will be shown on the General Status tab in the Home page of the CMM4.

Configuring VLAN

An example of the CMM4 802.1Q VLAN tab is displayed in Figure 47.

Figure 47 VLAN tab of CMM4

802.1Q VLAN Configuration	
Enable 802 10 VI AN Tagging :	© Enabled
	Oisabled
802.1Q Management VLAN ID (1-4094) :	1 (Range : 1 4094)
Active Configuration	
Active Configuration VLAN Not Active	

The VLAN tab provides the following parameters.

Table 22	VLAN tab	attributes
----------	----------	------------

Attribute	Meaning	
Enable VLAN Tagging	If this parameter is set to Enabled and a Management VLAN ID is set in the next parameter, then the controller board's management interface will accept only frames that are VLAN tagged with the configured tag value. All frames outgoing from the management interface will have a VLAN tag, set to the configured VLAN ID.	
Management VLAN ID	If Enable VLAN Tagging is set to Enabled and this parameter is set, then the management interface will accept only frames that are VLAN tagged with the configured tag value. All frames outgoing from the management interface of the CMM4 will have a VLAN tag, set to the configured Management VLAN ID .	

Attribute	Meaning			
Active Configuration	This field indicates the status of the current configuration. For example, VLAN tagging enabled with "1" set as the management VLAN tag would display the following:			
	Untagged Ingress VID: 1			
	Management VID: 1			
	Current VID Member Set:			
	VID Number Type Age			
	1 Permanent 0			
	Note that Management VLAN "1" has special properties that allow untagged VLAN frames to communicate with the device (CMM4 or radio). If the Management VLAN ID is set to 1 the local stack of the unit will accept VLAN 1 or untagged. If the Management VLAN is set to anything but 1, it will only allow that specific VLAN tag to enter the stack; it will not accept untagged frames.			

Configuring the Unit Settings

An example of the CMM4 Unit Settings tab is displayed in Figure 48.

Figure 48 Unit Settings Tab of CMM4

Unit-Wide Changes		E,
Undo Unit-Wide Saved Changes	Set to Factory Defaults	J

The Unit Settings tab provides the following buttons.

Table 23 Unit Settings tab attributes

Attribute	Meaning
Undo Unit-Wide Saved Changes	When you click this button, any changes that you made in any tab but did not commit by a reboot of the module are undone.
Set to Factory Defaults	When you click this button, <i>all configurable parameters on all tabs</i> are reset to the factory settings.

Viewing the ARP Table (Statistics)

The ARP table provides information on the data devices connected to the CMM4. The ARP Table maps the IP address to the MAC address. The table also shows the age of the entry in the table, the interface (in this case it will always be Ethernet "et1"), and whether the packets are "pending."

Figure 49 ARP table

	ARP Table						E
	IP Address	Physical Address	Interface	Pending	Create Time	Last Time	
l	10.120.216.254	00-22-be-6e-40-00	et1	Ν	01:10:20 01/01/2001	01:13:50 01/01/2001	

This ARP table example displays information on the laptop computer attached to the CMM4 for the purpose of Internet access.

Attribute	Meaning
IP Address	This field displays the IP address of the device connected to the CMM4.
Physical Address	This field displays the machine address of the device connected to the CMM4. A physical address cannot be changed. The ARP table is used by the system to translate the logical address into a physical address.
Interface	This field displays the type of interface. In the case of the CMM4, the interface will always be an Ethernet interface.
Pending	This field indicates whether the packets are pending "Y" or "N."
Create Time/Last Time	These fields are used to "age out" the entry in the table in the case where there has been no communication for a period of time.

 Table 24
 ARP Table tab attributes

Viewing General Status

An example of the CMM4 General Status tab is displayed in Figure 50.

Figure 50 General status tab of CMM4

Port Statu	S							E
Port Number	1	2	3	4	5	6	7	8
Port Text	Port 1 Description	Port 2 Description	Port 3 Description	Port 4 Description	Port 5 Description	Port 6 Description	Port 7 Description	Port 8 Descriptic
Power	0	0	0	0	0	0	0 V	• • V
Device Type	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V	Canopy 29 V
•				111				•
Doution	ormation			_		_		
Device Inf Device : Software V FPGA Ver FPGA Plat PLD Versii MAC Addr System Tii System Up Ethernet S Sync Statt SYNC Puls SYNC Puls	/ersion : sion : form : on : ess : me : o Time : status : us ese Status : se Source : (isible :		CMM 4.1 (0a1 05 1 (C 0a-C 01:1 01:1 1001 No S Mas	M4 0a-00-3e- (Build 1) 107 CMM4 (MM4) 00-3e-e8-04-(4:26 01/01/2 4:26 Base-TX Full SYNC ter (GPS Mod	e8-04-03 03 001 Duplex dule)			
Satellites Visible . 0 Satellites Tracked : 0 Antenna Connection : Unknown Tracking Mode : Reserved Latitude : 0° 0' 0.00" N Longitude : 0° 0' 0.00" E								
Height : Site Inform	nation		0 me	eters				
Site Name	:		Blue	CMM4				
Site Locati Site Conta	ion : ict :		No S No S	Site Location Site Contact]

The General Status tab provides information on the operation of the CMM4. This is the tab that opens by default when you access the GUI. The General Status tab provides the following read-only fields.

Attribute	Meaning
Device	This field indicates the type of module and provides its MAC address.
Software Version	This field indicates the CMM4 release and the time and date of the release. If you request technical support, provide the information from this field.
FPGA Version	This field indicates the version of the field-programmable gate array (FPGA) on the module. When you request technical support, provide the information from this field.
FPGA Platform	This field indicates the hardware platform that the field-programmable gate array (FPGA) runs on.
PLD Version	This field indicates the version of the version of the programmable logic device (PLD).
MAC Address	This field displays the MAC address (or electronic serial number) of the CMM4.
System Time	This field provides GMT (Greenwich Mean Time) and date to all connected devices, which they in turn pass to devices that register to them. Data for this field is from the GPS device.
System Up Time	This field indicates how long the module has operated since power was applied.
Ethernet Status	This field indicates the speed and duplex state of the Ethernet interface to the CMM4.
SYNC Pulse Status	This field indicates the status of synchronization as follows:
	SYNC OK indicates that the module is receiving a sync pulse.
	No SYNC indicates that the module is not receiving a sync pulse.
SYNC Pulse Source	This field indicates the source of sync as follows:
	Master (GPS Module) indicates that the module is configured to receive sync from its GPS unit.
	Slave (RJ11 Port) indicates that the module is configured to receive sync through its auxiliary port from another CMM.
Satellites Visible	This field displays the number of satellites whose signals are received by the connected GPS antenna.
Satellites Tracked	This field displays the number of satellites whose signals the CMM4 uses.
Antenna Connection	This field indicates the health of the connection between the CMM4 and the GPS antenna. For example, a value of "BAD – Under Current" indicates that there is a lack of signaling due to a bad cable or GPS module.
Tracking Mode	If the CMM4 receives the signals from a GPS antenna, then this field describes the degree to which the CMM4 is accurately computing position information, given the satellites that it is tracking.

 Table 25
 General Status tab attributes

Attribute	Meaning
Latitude	If the CMM4 receives the signal from a GPS antenna, then this field displays the latitude of the site.
Longitude	If the CMM4 receives the signal from a GPS antenna, then this field displays the longitude of the site.
Height	If the CMM4 receives the signal from a GPS antenna, then this field displays the elevation (above sea level) of the GPS antenna.
Site Name	This field indicates the name of the physical module. You can assign or change this name in the SNMP tab of the CMM4 Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Location	This field indicates site information for the physical module. You can provide or change this information in the SNMP tab of the CMM4 Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Contact	This field indicates contact information for the physical module. You can provide or change this information in the SNMP tab of the CMM4 Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.

Viewing Sync Status

An example of the CMM4 Sync Status tab is displayed in Figure 51.

Figure 51 Sync Status tab of CMM4

Sync Status	
SYNC Pulse Status :	No SYNC
SYNC Pulse Source :	Master (GPS Module)
Satellites Visible :	0
Satellites Tracked :	0
Date from GPS :	00/00/0000
Time from GPS :	00:00:00
Antenna Connection :	Unknown
Tracking Mode :	Reserved
Latitude :	0° 0' 0.00" N
Longitude :	0° 0' 0.00" E
Height :	0 meters
Invalid Message Count :	0
Restart Count :	0
Relnit Count :	0
Man NOTE: This is only an approximati	on on the physical location
Site Man :	Insufficient GPS Information to generate man. Must have 3D fix
Conce map :	insumerent of o information to generate map. Must have ob fix.
GPS Log	
No entries.	
GPS Receiver Information	

GPS Receiver Information Unknown

The Sync Status tab provides information on the GPS receiver in the CMM4 and the signals that it is receiving.

Attribute	Meaning
SYNC Pulse Status	This field indicates the status of synchronization as follows:
	SYNC OK indicates that the module is receiving a sync pulse from an outside source and is receiving the pulse.
	No SYNC indicates that the module is set to <i>receive</i> a sync pulse from an outside source and is not receiving the pulse.
SYNC Pulse	This field indicates the source of sync as follows:
Source	Master (GPS Module) indicates that the module is configured to receive sync from its GPS unit.
	Slave (RJ11 Port) indicates that the module is configured to receive sync through its auxiliary port from another CMM.
Satellites Visible	This field displays the number of satellites from which the connected GPS antenna <i>receives</i> a signal.
Satellite Tracked	This field displays the number of satellites whose signals the CMM4 uses.

Attribute	Meaning
Date from GPS	This field displays the month, day, and year that the CMM4 receives.
Time from GPS	This field displays the hour, minute, and second that the CMM4 receives.
Antenna Connection	This field indicates the health of the connection between the CMM4 and the GPS antenna. For example, a value of "BAD – Under Current" indicates that there is a lack of signaling due to a bad cable or GPS module.
Tracking Mode	If the CMM4 receives the signals from a GPS antenna, then this field indicates the degree to which the CMM4 is accurately computing position information, given the satellites that it is tracking. For example
	2D Fix indicates that the CMM4 has a lock on information that is sufficient to compute position.
	Bad Geometry indicates that it does not.
Latitude	If the CMM4 receives the signal from a GPS antenna, then this field displays the latitude of the site.
Longitude	If the CMM4 receives the signal from a GPS antenna, then this field displays the longitude of the site.
Height	If the CMM4 receives the signal from a GPS antenna, then this field displays the elevation (above sea level) of the GPS antenna.
Invalid Message Count	Number of messages sent from the GPS receiver for which there is no match.
Restart Count	It is incremented when the CMM4 is having difficulty communicating with the GPS module
Reinit Count	The number of times the GPS device has been completely reinitialized

Viewing the System Log

An example of the CMM4 System Log tab is displayed in Figure 52.

Figure 52	System	Log tab	of the	CMM
				-

System Log 🗖
04:38:53 UT : Mon Jan 01 2001 : System Log Cleared
04:39:07 UT : Mon Jan 01 2001 : Reboot from Webpage.
00:00:06 UT : Mon Jan 01 2001 :
******System Startup*****
System Reset Exception Watchdog Reset
Software Version : Cmm4 4.1 (Build 1)
FPGA Version : 0a1107 CMM4
Clear System Log

The System Log tab provides a record of events that have been significant to this CMM4.

Viewing the Network Interface

Figure 53 Network Interface tab of the CMM

LAN1 Network Interface		E
Ethernet Interface :	100Base-TX Full Duplex	
IP Address :	10.120.216.33	
Subnet Mask :	255.255.255.0	
Default Gateway :	10.120.216.254	

The Network Interface screen allows the operator to view the LAN settings for the CMM4 device. It is a read-only screen.

Table 27 Network Interface tab attribu	tes
--	-----

Attribute	Meaning
Ethernet Interface	This field displays the Ethernet mode of the LAN port.
IP Address	This field displays the IP address that the operator has set for the CMM4 controller board. This field is set in the CMM4 Configuration tab. The Ethernet Switch has a separate IP address.
Subnet Mask	This field displays the address of the subnet mask. Subnetting allows the network to be logically divided without regard to the physical layout of the network.
Default Gateway	This field displays the address of the default gateway. A default gateway is a node on the network that serves as an access point to another network.

Viewing Layer 2 neighbors

This screen provides information on all of the layer 2 devices communicating with the CMM4 including any devices on an Ethernet connected hub that support LLDP (Link Layer Discovery Protocol).

Figure 54 Layer 2 Neighbors Log



Installing a CMM4

Ensure that you comply with standard local or national electrical and climbing procedures when you install the CMM4.



WARNING!

Installing a CMM involves electrical power and can involve height and exposure to RF (Radio Frequency) energy. To avoid personal injury, know and follow applicable national and local safety regulations and industry best practices, and follow the specific guidelines in this document

Avoiding hazards

Use simple precautions to protect staff and equipment. Hazards include exposure to RF waves, lightning strikes, power lines, and power surges. This section specifically recommends actions to abate these hazards.

Grounding Equipment

Effective lightning protection diverts lightning current safely to ground, Protective Earth (PE) \downarrow . It neither attracts nor prevents lightning strikes.

Grounding Infrastructure Equipment

To protect both your staff and your infrastructure equipment, implement lightning protection as follows:

Observe all local and national codes that apply to grounding for lightning protection.

Before you install your modules, perform the following steps:

- Engage a grounding professional if you have any questions on grounding.
- Install lightning arrestors to transport lightning strikes away from equipment. For example, install a lightning rod on a tower leg other than the leg to which you mount your module.
- Connect your lightning rod to ground.
- Plan to use an appropriate surge suppressor on any Ethernet cable at the point where it enters any building or structure.

Install your modules at least 2 feet (0.6 meters) below the tallest point on the tower, pole, or roof.

Conforming to Regulations

For all electrical purposes, ensure that your network conforms to applicable country and local codes, such as the NEC (National Electrical Code) in the U.S.A. If you are uncertain of code requirements, engage the services of a licensed electrician.

In particular, many codes require that wired electrical devices like the 54 VDC power supply either terminate in a plug connection or be wired with an on/off switch, and not be hard-wired to AC/mains.

Protecting Cables and Connections

Cables that move in the wind can be damaged, impart vibrations to the connected device, or both. At installation time, prevent these problems by securing all cables with cable ties, cleats, or weather-resistant tape.

The cable can be a path for water to follow to enter the cable connector or even the module. You can prevent this problem by including and securing a drip loop where the cable enters the module enclosure.

Testing the Components

The best practice is to connect all the components - BHs, APs, GPS antenna, and CMM4 - in a test setting and initially configure and verify them before deploying them to an installation. However, circumstances or local practice may require a different practice.

Unpacking Components

When you receive products, carefully inspect all shipping boxes for signs of damage. If you find damage, immediately notify the transportation company.

As you unpack the equipment, verify that all the components that you ordered have arrived. Save all the packing materials to use later, as you transport the equipment to and from installation sites.

Cables

Information on cable planning, ordering, and design is covered on page 3-126.

Installing a GPS Antenna

The following information describes the recommended tools and procedures to mount the GPS antenna.

Recommended Tools for GPS Antenna Mounting

The following tools may be needed for mounting the GPS antenna:

- 3/8" nut driver
- 12" adjustable wrench
- 7/16" wrench
- Needle-nose pliers

Mounting a GPS Antenna

Perform the following procedure to mount a GPS antenna.

Procedure 44 Mounting the GPS antenna

- **1** Ensure that the mounting position
 - has an unobstructed view of the sky to 20° above the horizon.
 - is not the highest object at the site. (The GPS antenna does not need to be particularly high on a site, which would give it more exposure to lightning. It just needs to have an unobstructed view of the sky.)
 - is not further than 100 feet (30.4 meters) of cable from the CMM.
- 2 Select a pole that has an outside diameter of 1.25 to 1.5 inches (3 to 4 cm) to which the GPS antenna bracket can be mounted.
- **3** Place the U-bolts (provided) around the pole as shown in Figure 55.
- 4 Slide the GPS antenna bracket onto the U-bolts.
- **5** Slide the ring washers (provided) onto the U-bolts.
- 6 Slide the lock washers (provided) onto the U-bolts.
- 7 Use the nuts (provided) to securely fasten the bracket to the U-bolts.

Figure 55 Detail of GPS antenna mounting



Cabling the GPS Antenna

Connect the GPS coax cable to the female N-connector on the GPS antenna. Information on the coax cable is covered on page 3-131. Weatherproof the connection following Weatherproofing an N-type antenna connector.

Weatherproofing an N-type antenna connector

The following procedure should be used to weatherproof the N type connectors fitted to the GPS module and outdoor CMM installation connectors. This procedure must be followed to ensure that there is no moisture ingress at the N-type port.

N type connectors should be tightened using a torque wrench, set to 15 lb. in or 1.7 Nm. If a torque wrench is not available, N type connectors may be finger tightened.

To weatherproof an N type connector, proceed as follows:

Figure 56 Weatherproofing an N-type antenna connector

- **1** Ensure the connection is tight. A torque wrench should be used if available:
- 2 Wrap the connection with a layer of 19 mm (0.75 inch) PVC tape, starting 25 mm (1 inch) below the connector body. Overlap the tape to half-width and extend the wrapping to the body of the AP. Avoid making creases or wrinkles
- **3** Smooth tape edges
- **4** Cut a 125mm (5 inches) length of rubber tape (Scotch 3M Professional Grade: D.C.J. No. 06147 or equivalent)
- **5** Expand the width of the tape by stretching it so that it will wrap completely around the connector and cable
- 6 Press the tape edges together so that there are no gaps. The tape should extend 25mm (1inch) beyond the PVC tape
- 7 Wrap a layer of 50 mm (2 inch) PVC tape from bottom to top, starting from 25 mm (1 inch) below the edge of the self-amalgamating tape, overlapping at half width
- 8 Repeat with a further four layers of 19 mm (0.75 inch) PVC tape, always overlapping at half width. Wrap the layers in alternate directions:
 - Second layer: top to bottom.
 - Third layer: bottom to top.
 - Fourth layer: top to bottom.
 - Fifth layer: bottom to top.

The bottom edge of each layer should be 25 mm (1 inch) below the previous layer.

Cabling the UGPS Module

When using the UGPS as a synchronization source for a CMM4, a special sync cable must be used. This cable may be constructed from an RJ-11 cable using the pin configuration in Figure 51. Connect this cable from one of the UGPS module's sync ports to the Aux Sync port of the CMM4 unit.

450i Series AP/BHM to UGPS cable

The 450i Series requires a special cable to connect the AP or BHM to a UGPS module. The AP/BHM to UGPS cable can be constructed from RJ12 to RJ 45 cable using the pin configuration described in Table 28.

Figure 57 AP/BHM to UGPS cable



Table 28 AP/BHM to UGPS cable pinout

Pin	450i AP/BHM RJ 45 Connector	Pin	UGPS RJ 12 Connector	Connector
1	NC	1	8 on RJ 45	RJ45
2	NC	2	NC	
3	NC	3	5 on RJ 45	
4	4 on RJ 12	4	4 on RJ 45	
5	3 on RJ 12	5	NC	
6	NC	6	7 on RJ 45	
7	6 on RJ 12			
8	1 on RJ 12			

The AP/BHM will only power up the UGPS if it configured to do so.

Installing the power supply for the CMM4 (30 VDC or 54 VDC)



WARNING!

Although the output of the power supply is 30 VDC or 54 VDC, the power rating classifies the converter as a Class 2 electric device. For this reason, whenever you work on power in the CMM4, you must *first* disconnect the DC supply from the AC power source.

Procedure 45 Installing the CMM power supply

- 1 Install the CMM4 power supply in a hut, wiring closet, or weatherized NEMA-approved enclosure. It is designed for extreme temperatures but it is imperative to keep moisture away from the power converter.
- 2 Do not install the power supply within the CMM4 enclosure. The CMM4 enclosure is not large enough to provide surface area for heat dissipation without the use of forced convection fans, not to provide space for additional high-power electronics.
- 3 For the DC side of a 54 VDC power supply, engineer the DC cable, selecting the wire gauge from Table 12. Use either UV-resistant cable or shield the cable (as in a conduit) from UV rays.
- 4 Remove the clear plastic cover, then connect the DC cable as shown right. Insert the +V lead into the screw terminal clamp labeled "+V" and insert the GND (ground/return) lead into the screw terminal clamp labeled "-V". To insert a lead into a screw terminal clamp, first loosen the retaining screw, insert the wire into the terminal, then tighten the retaining screw. Once the cables are secure, reinstall the clear plastic cover.



Figure 58 Power supply DC

EU Countries Only

To enable regulatory compliance with the European Union (EU) directives, a power line filter module must be installed on the DC side of the power supply. This module may be ordered from Cambium Networks (part number N000000L056A). Please reference section EU countries only – power line filter module installation on page 3-164.



Figure 59 Power supply AC connection



5 For the AC side of the power supply, first ensure that the AC line is not energized. Next, remove the clear plastic

cover then connect an AC cable to the power supply using Ground/protective earth (),

Neutral (N), and Line (L) as shown right. To insert a lead into a screw terminal clamp, first loosen the retaining screw, insert the wire into the terminal, then tighten the retaining screw. Once the cables are secure, reinstall the clear plastic cover.

EU countries only – power line filter module installation

To enable regulatory compliance with the European Union (EU) directives, a power line filter module must be installed on the DC side of the power supply. This module may be ordered from Cambium Networks (part number N00000L056A).

Procedure 46 Installing the power line filter (EU only)

- **1** Ensure that all equipment is disconnected from main power.
- 2 The filter may be mounted inside the CMM4 enclosure on the upper shelf using two #6 pan-head screws, 3/8" long. (Top shelf must be removed to complete this operation). Ensure that no metal burrs are resident on the CMM circuit board after attaching the filter to the top shelf. As an alternative, adhesive-backed industrialized Velcro (for example, 3M Scotchmate MP-3526N/27N series) may be utilized to secure the filter (not included).



Figure 60 CMM4 line filter installation (EU only)

For rackmount CMM4 installations, the filter may be installed on the top of the rackmount unit using adhesive-backed industrialized Velcro (for example, 3M Scotchmate MP-3526N/27N series).



Figure 61 Rackmount CMM line filter installation (EU only)

3

Using spade lugs, connect the DC cables from the CMM DC input screw terminals to the "Load" side of the filter.

- (29V installations) The length of 14 AWG or 16 AWG cabling between the CMM and filter should be 10.5 in +/- 0.5 in (27 cm +/- 1 cm).
- (56V installations) The length of 14 AWG or 16 AWG cabling between the CMM and filter should be 11.5 in +/- 0.5 in (29 cm +/- 1 cm)

4 Using spade lugs, connect the DC cables from the power supply to the "Line" side of the filter. The filter has no DC polarity, ensure that polarity is maintained on the wiring going through the filter (for example, the positive wire must be connected to the same-side terminal on the "Line" and "Load" sides of the filter. Refer to Table 12 Wire size for CMM4 DC cable on page 3-132 for wire size recommendations.



Once the filter is secured and the wiring is connected, main power may be restored.

Discontinued power supply notice – ACPS112WA only

The following procedure is only applicable to operators using a CMM4 that supplies power to both 30V devices (PMP100 radios) and 56V devices (PMP430 or PMP320 radios). The discontinued 30V model ACPS120WA power supply does NOT require the 1k 5W resistor on the CMM4 29V terminals (This new 30V power supply was made available for order around December 3, 2010). The phased-out 30V model ACPS112WA power supply will always require a 1k 5W resistor when a 56V supply is present. Since both power supplies look identical, see the label under the power supply to identify the model.

Power supply model ACPS112WA (discontinued) requires a 1k 5W resistor across the 30V DC input terminal of the CMM4 when both 30V AND 56V are present. Doing so will prevent the 30V power supply to not always come out of sleep mode with a light load. The power supply will attempt to come out of sleep mode, and if it does not see sufficient load it goes into a sleep/recovery cycle that is observable by watching the 30V LED on the port connector turn on and off.

Power supply Model ACPS120WA (discontinued) satisfies the European Union's Energy Level 5 requirement and DOES NOT require a 1k 5W resistor.

If using both 30 VDC (discontinued model ACPS112WA only) and 56 VDC power, to ensure correct operation under all conditions a 1000 Ohm 5 W resistor must be installed across the 30 VDC +V and GND (ground/return) at the terminal block using Procedure 47. The resistor can be purchased locally or call technical support to obtain one.

The resistor prevents the model ACPS112WA 30 VDC converter (discontinued) from getting stuck in sleep mode which can occur in dual-powered CMM4s and result in 30 VDC radios getting low voltage and not booting.

If redundant 30 VDC power supplies are desired along with one or two 56 VDC power supplies, connect one power supply to each of the 29 VDC terminal blocks using the resistor in one of the 29 VDC terminal blocks.

Procedure 47 Installing a special resistor for dual-powered CMM4s (30V model ACPS112WA power supply only)
- **1** WARNING Make absolutely sure 30 VDC and 56 VDC converters are unpowered and disconnected from AC (Mains) before proceeding.
- **2** Ensure white and black 30 VDC leads have 1/2 in (1 cm) of stranded wiring exposed. Strip or cut to 1/2 inch if needed.
- **3** Wrap the stranded wires of the 30 VDC white lead around one of the leads of the 1000 Ohm 5 W resistor.
- **4** Wrap the stranded wires of the 30 VDC black lead around the other resistor lead.
- **5** Insert the wired resistor assembly into either terminal block labeled "+29 V" as shown below ensuring that the powered lead is inserted into the correct termination.

Figure 62 Resistor when using both 56 VDC and 30 VDC power



6 Screw terminal block screws down tight. The resistor dissipates 0.9 W and will run warm at room temperature.

Temperature Range

Install the CMM4 outside only when temperatures are above -4° F (-20° C). The gland openings and the bushings and inserts in the gland openings are rated for the full -40° to $+131^{\circ}$ F (-40° to $+55^{\circ}$ C) range of the CMM4. However, for dynamic operations (loosening, tightening, and inserting), they are compliant at, and rated for, only temperatures at or above -4° F (-20° C).

Installing a CMM4 (Models 1090CKHH and 1091HH)

Prizm and Wireless Manager treat the EtherWAN Switch in a CMM4 as a generic switch. For Prizm or Wireless Manager to correctly associate each EtherWAN Switch with its CMM4

- before you install the CMM4, read and note the MAC address of both the CMM4 controller and EtherWAN switch from the physical units.
- after you discover a CMM4 and its switch, use these MAC addresses for moving the switch to the place in your Prizm or Wireless Manager network view where the CMM4 was discovered.
- always maintain a record that associates these two MAC addresses.

IMPORTANT!

When an EMS discovers an EtherWAN switch in your network, it can't tell which CMM4 the switch is associated with, nor can it tell CMM4 EtherWAN switches from any other EtherWAN switches you may have in your network. The pair of MAC addresses you record directly from the CMM4 and its EtherWAN switch are the only means for you to establish the logical connection.

Perform the following procedure to install the CMM4.

Procedure 48 Mounting the CMM4

- **1** Ensure that the mounting position
 - *is not* further than 328 feet (100 meters) from the furthest AP or BH that the CMM4 will serve.
 - is not closer than 10 feet (3 meters) to the nearest AP or BH.
 - *is not* further than 100 feet (30.5 meters) of cable from the intended mounting position of the GPS antenna.
 - allows you to fully open the door for service.
- 2 Select a support structure to which the flanges can be mounted.

3 If the support structure is a wall, use screws or bolts (neither is provided) to attach the flanges to the wall.

If the support structure is an irregular-shaped object, use adjustable stainless steel bands (provided) to attach the CMM4 to the object.

If the support structure is a pole that has an outside diameter of 1.25 to 3 inches (3 to 8 cm), use a toothed V-bracket (provided) to

- attach the V-bracket to the pole as shown below.
- attach the CMM4 flanges to the V-bracket.

Figure 63 CMM4 V-bracket to pole mounting





Installing a Rackmount CMM4 (Model 1092HH)

Perform the following procedure to install the Rackmount CMM4.

Procedure 49 Mounting the Rackmount CMM4

- **1** Ensure that the mounting position
 - *is not* further than 328 feet (100 meters) from the furthest AP or BH that the CMM4 will serve.
 - is not closer than 10 feet (3 meters) to the nearest AP or BH.
 - *is not* further than 100 feet (30.5 meters) of cable from the intended mounting position of the GPS antenna.
- **2** Using a T10 Torx driver, attach the mounting two included mounting brackets to the front sides of the CMM4 module



Figure 64 Attaching the rackmounting brackets

3 Select a 19" rack space in which the CMM4 may be mounted and use the (4) provided Phillips head screws to attach the front of the CMM4 to the rack

Figure 65 Rackmount CMM4 rack screws



Cabling a CMM4 (Models 1090CKHH and 1091HH)

Perform the following procedure to cable the CMM4:

Procedure 50 Cabling the CMM4

- **1** Review the diagram inside the door of the CMM4.
- 2 Note that the inserts in the gland openings have precut holes.

3 Route Ethernet cables through the cable gland connectors to the Ethernet ports inside the CMM4 cabinet (see the grey cables in Figure 66). Stagger the cables (see Figure 67) to make it easier to feed them through the gland.

Figure 66 Ethernet port connections



Figure 67 Staggered Ethernet cables



- **4** Connect Ethernet cables as follows (see page 3-121 for typical diagrams and planning information):
 - APs, BH10s, or BH20s (PTP 100 Series bridges), PTP 230 Series bridges: cable to
 powered ports of the controller board. The controller board provides sync, power, and surge
 suppression for these connections. If the CMM4 is mounted inside a building or
 communications hut, a Cambium 600SS surge suppressor (model number 600SSC or later)
 should be mounted outside the building or communications hut on each line at the point of
 cable penetration to prevent over-voltages and over-currents from entering the building and
 potentially damaging other electronic equipment.
 - Terrestrial feeds under 100 Mbps (10/100BaseT): cable to an unpowered port of the controller board. The controller board provides surge suppression for these connections. If the CMM4 is mounted inside a building or communications hut, a Cambium 600SS surge suppressor (model number 600SSC or later) should be mounted outside the building or communications hut on each line at the point of cable penetration to prevent over-voltages and over-currents from entering the building and potentially damaging other electronic equipment.
 - Terrestrial feeds over 100 Mbps (1000BaseT Gigabit Ethernet): cable directly to the Gigabit port of the EtherWAN switch, and mount a Cambium PTP-LPU lightning protection unit or equivalent
 - o within 3 ft. (1 m) of the CMM4 if the CMM4 is located outdoors
 - on the outside of the building or communications hut at the point of cable penetration if the CMM4 is located indoors.
 - PTP 400 Series bridges: cable to an unpowered port of the controller board. If the CMM4 is inside a building or communication hut, install the bridge's PIDU (Powered InDoor Unit) also inside the building, and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent on the outside of the building or communications hut at the point of cable penetration. If the CMM4 is mounted outside, locate the PIDU in a weather-tight enclosure within 3 ft. (1 m) of the CMM4 and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent within 3 ft. (1 m) of the CMM4 and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent within 3 ft. (1 m) of the PIDU.
 - PTP 500 and 600 Series bridges: cable directly to the Gigabit port of the EtherWAN switch. If the CMM4 is inside a building or communication hut, install the bridge's PIDU (Powered InDoor Unit) also inside the building, and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent on the outside of the building or communications hut at the point of cable penetration. If the CMM4 is mounted outside, locate the PIDU in a weathertight enclosure within 3 ft. (1 m) of the CMM4 and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent within 3 ft. (1 m) of the PIDU.
- **5** On the door label, record the MAC and IP addresses of the CMM4 and all connected equipment.
- 6 Record also the MAC address of the EtherWAN switch.
- **7** Consistent with practices in your company, note the above information to add later to the company equipment database.

- **8** Connect the coax cable from the female N-connector on the GPS antenna to the female N-connector on the outside of the CMM4.
- **9** Ensure there is an Ethernet cable between the management port on the controller board and one of the Ethernet ports on the EtherWAN switch.
- **10** Feed the DC power cord through a cable gland. A 1-hole gland insert is provided, as the DC power cable is too thick to share a gland with other cables. The 1-hole insert is either connected to one of the patch cables or included in the parts bag.
- **11** For 29 V: Connect the white wire to +29V on either of the 29 VDC terminal blocks.
- 12 Connect the black wire to -V (GND) on the same 29 VDC terminal block.
- 13 For 56V: Connect the black and white wire to +56V on either of the 56 VDC terminal blocks.
- 14 Connect the black wire to -V (GND) on the same 56 VDC terminal block.
- **15** Plug the DC power supply into an AC receptacle (AC mains).
- **16** Verify that the LEDs light.

The indicator LEDs are shown in Figure 68. Color indicates position, but not state. For example, the red Power LED, in the left most position, lights when power is applied to the unit, but does not change color at any point.

Figure 68 CMM4 LED indicators





Cabling a Rackmount CMM4

Perform the following procedure to cable the Rackmount CMM4:

Procedure 51 Cabling the Rackmount CMM4

- **1** Connect Ethernet cables as follows (see page 3-121 for typical diagrams and planning information):
 - APs, BH10s, or BH20s (PTP 100 Series bridges), PTP 230 Series bridges: cable to
 powered ports of the controller board. The controller board provides sync, power, and surge
 suppression for these connections. A Cambium 600SS surge suppressor (model number
 600SSC or later) should be mounted outside the building or communications hut on each line
 at the point of cable penetration to prevent over-voltages and over-currents from entering the
 building and potentially damaging other electronic equipment.
 - Terrestrial feeds under 100 Mbps (10/100BaseT): cable to an unpowered port of the controller board. The controller board provides surge suppression for these connections. A Cambium 600SS surge suppressor (model number 600SSC or later) should be mounted outside the building or communications hut on each line at the point of cable penetration to prevent over-voltages and over-currents from entering the building and potentially damaging other electronic equipment.
 - Terrestrial feeds over 100 Mbps (1000BaseT Gigabit Ethernet): cable directly to the Gigabit port of the external switch, and mount a Cambium PTP-LPU lightning protection unit or equivalent on the outside of the building or communications hut at the point of cable penetration if the CMM4 is located indoors.
 - **PTP 400 Series bridges:** cable to an unpowered port of the controller board. Install the bridge's PIDU (Powered InDoor Unit) also inside the building, and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent on the outside of the building or communications hut at the point of cable penetration.
 - **PTP 500 and 600 Series bridges:** cable directly to the Gigabit port of the external switch. Install the bridge's PIDU (Powered InDoor Unit) also inside the building, and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent on the outside of the building or communications hut at the point of cable penetration.
- **2** Connect the coax cable from the female N-connector on the GPS antenna to the female N-connector on the outside of the CMM4.
- 3 For 29 V: Connect the white wire to +29V on either of the 29 VDC terminal blocks.
- 4 Connect the black wire to -V (GND) on the same 29 VDC terminal block.
- **5** For 56V: Connect the black and white wire to +56V on either of the 56 VDC terminal blocks.
- 6 Connect the black wire to –V (GND) on the same 56 VDC terminal block.
- **7** Plug the DC power supply into an AC receptacle (AC mains).
- 8 Verify that the LEDs light.

The indicator LEDs are shown in Figure 69. Color indicates position, but not state. For example, the red Power LED, in the left most position, lights when power is applied to the unit, but does not change color at any point.

Figure 69 LED indicators - rackmount CMM4



CAUTION! Surge suppressors should be installed on any cables where they enter a building to reduce the possibility of overvoltages or overcurrents damaging any equipment in the building. The following equipment, mounted outside of a communications hut or building at the point where the cables penetrate the building, is recommended:
Cambium 600SS surge suppressors for Ethernet cables
Cambium 200SS surge suppressors for DC cables
 A PolyPhaser DGXZ+06NFNF-A surge suppressor for the coaxial cable from the GPS antenna

Power Faults

If excessive current is drawn on a port, the analog circuitry reports a PoE fault. The system then turns the port power off. The power will be restored when the fault is removed.

In this power fault detection system, each port is designed with an electronic fuse that opens the DC circuit in 26ms if the 1A maximum limit is reached. Then, every 1.7 seconds the fuse will reconnect for 26ms. If the current is less than 1A during the 26ms sampling period, then the fuse will stay connected, and the port will operate as normal.

Figure 70 shows the port status screen with a power fault on port 1.

Port Status	;							
Port Number	1	2	3	4	5	6	7	8
Port Text	Port 1 Description	Port 2 Description	Port 3 Description	Port 4 Description	Port 5 Description	Port 6 Description	Port 7 Description	Port 8 Description
Power	Power Fault! 0 V	() 29 V	() 29 V) 29 V	() 29 V	() 29 V	() 29 V) 29 V
Device Type	Canopy	Canopy	Canopy	Canopy	Canopy	Canopy	Canopy	Canopy
Power fault on port:1 Please check the devices and port configurations.								

Figure 70 CMM port status showing power fault

Chapter 4: Universal Global Positioning System Module

UGPS Product Description and Overview

The Cambium Networks Universal Global Positioning System (UGPS) is a stand-alone GPS antenna and receiver with the capability to provide a 1PPS GPS synchronization signal to Cambium Networks access points (APs), backhaul masters (BHMs), or cluster management modules (CMMs).

The UPGS features two timing ports for sending GPS timing sync. One or two access points/backhaul masters/cluster management modules may be synchronized directly by the two timing ports.

The UGPS may be used with the following Cambium Networks equipment:

- PMP 100 FSK AP
- PTP 100 FSK BH
- PMP 430 OFDM AP
- PMP 400 OFDM AP
- PTP 200 OFDM BH
- PTP 230 OFDM BH (capable of sourcing power to the UGPS via PTP 230 timing port)
- PMP 320 WiMAX AP (AP Software version e2.2 and later)
- PMP 450 OFDM AP (capable of sourcing power to the UGPS via PMP 450 timing port)
- PTP 450 OFDM BH
- CMM3 (CMM3 in Slave mode, CMM3 will receive GPS synchronization pulse, but no GPS location data)
- CMM4 (CMM4 in Slave mode, CMM4 will receive GPS synchronization pulse, but no GPS location data)
- ePMP Series
- PMP 450i OFDM AP
- PTP 450i OFDM BH

The connector interface for the UGPS is detailed in Figure 71:

Figure 71 UGPS connector interface



UGPS Power Source Configurations

The UGPS module may be powered by an external source via the UGPS External Power Port. Alternately, the UGPS may be powered by a PTP 230 backhaul master or PMP 450 Platform AP via one of the UGPS Timing Ports. When the UGPS is powered by via one of the Timing Ports, the radio provides the necessary power to enable 1 PPS synchronization timing and serial GPS location data by the UGPS (which is sent back to the radio via the associated Timing Port). If the UGPS is receiving power on the External Power Port (via 30V DC power supply or CMM port) *and* power on Timing Port 1 or Timing Port 2 simultaneously, the UGPS defaults to using the external power supply.

External Power Only

Shown below are examples of external only powering for PMP 100 and PMP 400/430 units. In this case the UGPS is powered via straight-through RJ-45 cable connected to a Cambium approved 30V DC power supply see Table 30 **Compatible 30V Power Supplies** on page 4-16. The UGPS may also receive power through the RJ-45 Power Port via a power-over-Ethernet port on a CMM4. The radios receive their GPS synchronization through a straight-through 6-pin RJ-11 cable connected to either Timing Port 1 or Timing Port 2 of the UGPS.

RJ-45 Pinout for Straight-through Ethernet Power Cable



Figure 72 Power Pinout - UGPS Ethernet Power Cable



Figure 73 PMP 100 AP receiving synchronization from external-powered UGPS



Figure 74 PMP 320 receiving synchronization from external-powered UGPS





Power from the Radio via UGPS Timing Port 1 or UGPS Timing Port 2

Shown below is an example of a UGPS unit powered from a PTP 230 BHM through an RJ-11 cable connected to either Timing Port 1 or Timing Port 2 of the UGPS. The UGPS may be powered by either Timing Port, and up to two radios may receive synchronization over the Timing Ports when the UGPS is powered in this fashion.

This UGPS powering mode is currently supported only by PTP 230 BHM and PMP 450 Platform AP. Future Cambium Networks hardware releases will also support providing power to the UGPS.

When powering the UGPS via AP or BHM, the system uses a straight-through 6-pin RJ-11 cable to provide power to the UGPS and to retrieve GPS synchronization pulses and data from the UGPS. The following diagram shows the wiring of the cable for sync and power.

RJ-11 Pinout for Straight-through Sync / Power Cable



Figure 76 Power Pinout - UGPS to AP/BHM Timing Port (6-pin RJ-11)

450i Series AP/BHM to UGPS cable

The 450i Series requires a special cable to connect the AP or BHM to a UGPS module. The AP/BHM to UGPS cable can be constructed from RJ12 to RJ 45 cable using the pin configuration described in Table 29.

Figure 77 AP/BHM to UGPS cable



Table 29 AP/BHM to UGPS cable pinout

Pin	450i AP/BHM RJ 45 Connector	Pin	UGPS RJ 12 Connector	Connector
1	NC	1	8 on RJ 45	RJ45
2	NC	2	NC	1234567
3	NC	3	5 on RJ 45	
4	4 on RJ 12	4	4 on RJ 45	
5	3 on RJ 12	5	NC	RJ12
6	NC	6	7 on RJ 45	
7	6 on RJ 12			
8	1 on RJ 12			

The AP/BHM will only power up the UGPS if it configured to do so.



Figure 78 PTP 230 backhaul master powering UGPS and receiving synchronization



Figure 79 PMP 450 AP powering UGPS and receiving synchronization



Figure 80 Two PTP 230 backhaul master units powering UGPS and receiving synchronization





UGPS and CMM Configurations

The UGPS may be used as a GPS synchronization source for Cambium Networks CMM3 and CMM4 (Cluster Management Module) units. The UGPS provides GPS synchronization to the CMM unit via the CMM's sync port. This allows any access points or backhaul masters connected to the CMM to receive sync. This configuration requires that the CMM3 or CMM4 be configured to "Slave" mode via the CMM GUI. When using the UGPS as a synchronization source for a CMM3 or CMM4, a special sync cable must be used. This cable may be constructed from an RJ-11 cable using the pin configuration in Figure 37.

When using a CMM unit, the UGPS may also be used as a redundant sync source for the CMM. If a CMM encounters an issue with the primary, coaxial-connected GPS receiver an operator may remotely login to the CMM and set the synchronization source to "Slave" to begin receiving sync from the UGPS (connected via RJ-11 cable with the pin configuration in section UGPS installation and operation).

PMP 320 Systems - When using both the UGPS for timing and a CMM4 for timing in a PMP 320 network (same AP site or an adjacent AP site), timing discrepancies between the UGPS and CMM4 can cause interference between the sites. To address this issue, operators may opt to use one type of timing in the network (either UGPS *or* CMM4). Alternatively, operators may contact technical support to set up remote access to troubleshoot the AP units that are exhibiting the issue. A future PMP 320 software release will address this timing issue.

Product Specifications

Antenna

Frequency Band	L1 (1575.42 ±10 MHz)
Polarization	Patch

Receiver

Tracking Channels	12 (Min.) Continuous Tracking
Timing Accuracy (1PPS)	100ns RMS
Position Accuracy	<3 m (Vertical), <10m (Horizontal)

Data Interface

Communications Standard	NMEA-0183
Interface Technology	1PPS (8Vp-p Level-Shifted Pulse, 100ms Duty Cycle)
	TX GPS LOCATION DATA (8Vp-p Level-
	Shifted – Serial 8/N/1 9600bps)

Acquisition

Sensitivity

Acquisition	-148dBm
Tracking	-165dBm

Electrical

Voltage	
ç	10V - 30V DC (External Power Port: +Vext)
Power	
	500mW (2 APs Loaded; Vap=0V DC; Vext=30V
	DC)
Cable Length	
-	100m. (330 ft.) 2 APs Loaded; Vap=0V;
	Vext=30V DC

Environmental

Operating Temperature	-40C to +85C
Humidity	95%
Ingress Protection	IP67

Mechanical

Dimensions	. 6 inch(Length) x 3.5 inch(Width) x 4 inch(Dome Height)
Electrical Interface	. RJ11-6 Position Shielded(x2), RJ45-8 Position Shielded
Connector	. IP67 Rated Connector (Lapp Cord Grip Style)
Weight	. 15 Oz.

UGPS installation and operation

Observe the following guidelines when installing a UGPS module:

- The unit may be pole mounted or surface mounted (on a horizontal surface with an unobstructed view of the sky).
- The UGPS should NOT be installed as the highest object at the site.
- Orient the GPS antenna so that it has clear access to the southern horizon (if installed north of the equator) or clear access to the northern horizon (if installed south of the equator).
- Note locations of 600SS surge suppressors when installing the UGPS unit. Reference UGPS Power Source Configurations diagrams. Compatible power supplies for the UGPS are listed in Table 30.
- Observe cable length specifications in Table 31.
- Cambium Networks recommends using shielded Category 5E cables for outdoor installations.
- The UGPS Power over Ethernet pinout (External Power Port) differs from IEEE Standard 803.3af, and the two should not be intermixed. The UGPS Power over Ethernet pinout is the same as Cambium Networks FSK broadband radios.

Model	Description
N000900L001A	Gigabit Ethernet-Capable Power Supply
N000900L007A	Cable, UL PSU Cord Set, US
N000900L008A	Cable, UL PSU Cord Set, EU
N000900L009A	Cable, UL PSU Cord Set, UK
N000900L010A	Cable, UL PSU Cord Set, Brazil

Table 30 Compatible 30V Power Supplies and Cords

Configuration	Powering Method	Maximum Cable Length (feet)
External power source, up to two access points/backhaul masters	30V DC AC/DC Adapter (see Table 30) via UGPS Ext. Power Port	330
Access point/backhaul master power source, up to two access points/backhaul masters NOTE This UGPS powering mode is supported only by PMP 450 Platform AP and PTP 230 BHM . Future Cambium Networks hardware releases will also support providing power to the UGPS.	Access Point/Backhaul master RJ-11 GPS power via UGPS Timing Port	130

When using the UGPS as a synchronization source for a CMM3 or CMM4, a special sync cable must be used. This cable may be constructed from the an RJ-11 cable using the pin configuration below.

Figure 82 UGPS to CMM cable pin configuration



Note: Only 2 pairs are used

Figure 83 Location of pin 1



(Lock tab is on other side)

UGPS Installation Procedure

Use the following procedure to install the UGPS module and to verify operation.

Procedure 52 UGPS installation – external-powered

- **1** Pole mount or surface mount the GPS antenna following the installation guidelines and specifications listed in this chapter.
- 2 For PMP 100/400/430/450 and PTP 100/200 series, configure (via web management interface) the access points/backhaul masters to sync to received GPS signal (via the timing port). Navigate to Configuration > General and set the Sync Input to Sync to Received Signal (Timing Port/UGPS). Since the UGPS will be configured with an external power source, set the UGPS Power value to Disabled.
 - **Figure 84** Configuring the sync input and disabling UGPS power PMP 100/400/430 and PTP 100/200 series

Sync Setting		=
Sync Input :	Sync to Received Signal (Timing Port/uGPS)	
uGPS Power :	C Enabled	de.
	Disabled	
Verify GPS Message Checksum :	Enabled	
	C Disabled	

For PMP 320 series, configure (via web management interface) the access point to sync to received GPS signal (via the AP's RJ-11 port). Navigate to **Configuration** > **Settings** and set the **Sync Source** to **UGPS** and **Serial Type** to **uGPS**.

Operation mode	Internal AAA
CPE Isolation	Disable CPE Isolation
AP GUI access from PC below CPE	Air Mng Disable
Secial Type	ugps
Sync Source	uGPS
Location Statistics	Disabled
Sync Holdoff Interval [sec]	60
Maximum Supported CPEs	200
Maximum Service Flow per AP	800
Maximum Service Flow per CPE	8

Figure 85 Configuring the sync source - PMP 320 series

3 For PMP 100/400/430/450 and PTP 100/200 series, click **Save Changes** and reboot the radio.

For PMP 320 series, click Update, click the Save icon and reboot the radio.

- If connecting the UGPS to a CMM3 or CMM4, configure the CMM (via the CMM web management interface) to Slave mode (access points/backhaul masters connected to the CMM will need to be set to receive GPS sync signal from the power port). Navigate to Configuration > CMM and set Sync Source to Slave (RJ11 Port). A reboot on the CMM is required for these changes to take effect.
- **5** Connect an RJ-11 6 pin cable from Timing Port 1 of the UGPS to the RJ-11 utility port of the access point/backhaul master to receive GPS sync signal. If applicable, repeat this step for additional access points and backhaul masters. If the UGPS is to send sync to a CMM, use a special sync cable constructed per section UGPS installation and operation.
- **6** Install a 600SS surge suppressor between the power supply and the UGPS module. Reference the diagrams in section UGPS Power Source Configurations.
- **7** Connect an RJ-45 8 pin Ethernet cable from the UGPS power port to the 600SS surge suppressor.
- 8 Connect an RJ-45 8 pin Ethernet cable from the 600SS surge suppressor to the power supply.
- **9** Verify on the access point/backhaul master/CMM that the GPS synchronization signal is being received properly. Reference section GPS status and location data readout.

Procedure 53 UGPS Installation – Powered by AP/BH Timing Port (PMP 450/PTP 230 Only)

1 Pole mount or surface mount the GPS antenna following the installation guidelines and specifications listed in this chapter.

2 Configure (via the web management interface) the access point / backhaul master to sync to received signal (timing port). Navigate to Configuration > General and set the Sync Input to Sync to Received Signal (Timing Port/UGPS). Since the UGPS will be configured to receive power over the UGPS Timing Ports, set the UGPS Power value to Enabled to configure the radio to power the UGPS.

Figure 86 Configuring the sync input and enabling UGPS power - PTP 230 series

Sync Setting	Ξ
Sync Input :	Sync to Received Signal (Timing Port/uGPS)
uGPS Power :	Enabled
	© Disabled
Verify GPS Message Checksum :	Enabled
	C Disabled

3 Click Save Changes and reboot the radio.

4 Connect an RJ-11 6 pin cable from Timing Port 1 or 2 of the UGPS to the timing port of the access point/backhaul master providing power and receiving sync.

This UGPS powering mode is currently supported only by PMP 450 AP and PTP 230 BHM . Future Cambium Networks hardware releases will also support providing power to the UGPS.

5 Verify on the access point/backhaul master that the GPS synchronization signal is being received properly. Reference section GPS status and location data readout.

Procedure 54 UGPS installation – powered by CMM PoE port

- **1** Pole mount or surface mount the GPS antenna following the installation guidelines and specifications listed in this chapter.
- 2 Verify that the CMM is powered by a 30V Cambium Networks power supply. This ensures that the CMM can provide the proper power-over-Ethernet output via CMM ports.
- **3** Connect an RJ-45 8 pin Ethernet cable from the External Power Port of the UGPS to an Ethernet port on the CMM4.

4 On the CMM4 web management GUI navigate to **Configuration** > **Ports**. In this configuration the CMM4 port connected to the UGPS via RJ-45 cable must be configured with **Power On** and **Device Type Canopy 29V** as Port 1 in Figure 87.

The CMM Ethernet port will only provide 29V power to the UGPS if the CMM is powered by a 29V power supply. If the CMM is powered by a 56V power supply, it will not provide 29V power via the PoE ports.

Home Configuration Statistics Account	second second and a	and here is a second	and the second sec	Con	figuration =>	Ports			
		Configuration = 2 + 0 KG							
pyright	CMM4 0a-00-3e-e8-04-12								
Logoff Account: admin Level:	Changes take effect after clicking "Save Changes" (no Reboot needed)								
ang march									
	Port Number	1	2	3	4	5	6	7	8
	Port Text	Port 1 Description	Port 2 Description	Port 3 Description	Port 4 Description	Port 5 Description	Port 6 Description	Port 7 Description	Port 8 Description
	Power	•	•	OV	O V	•	•	•	•
	Device Type	Canopy 29 V	Canopy 56 V	Non-Powered	Non-Powered	Canopy 29 V	Canopy 56 V	Canopy 56 V	Canopy 29 V
	Port Configu	rations							
	Port 1 :			Des P O P Dev	cription Port 1 Desc ower On ower Off ice Type 29 v 😨	ription			

Figure 87 CMM port configuration for UGPS power

IP default bypass

Since the UGPS is connected to the access point/backhaul master timing port, the UGPS module provides a bypass to perform an IP Default to a device connected on UGPS Timing Port 1 or 2. To perform an IP Default for a radio connected to the UGPS follow the procedures below (*not applicable to 450i Series*):

Procedure 55 IP default procedure – UGPS receiving external power

- **1** Using the power supply providing UGPS power, plug an Ethernet cable into the power adapter's "Gigabit Data" port then pin out the opposite end of the cable
- 2 Jumper the loose-end RJ-45 pins per the wiring table below:

 Table 32
 UGPS IP default bypass wiring

AP to Default	Wiring on External Power Connector
UGPS Timing Port 1	Connect Pins 3 and 6
UGPS Timing Port 2	Connect Pins 1 and 2

3 For PMP 100/400/430/450 and PTP 100/200/230/450 series, reboot the radio to be defaulted while the RJ-45 pins are jumpered. After the radio has finished rebooting, the software will be restored to a factory default configuration.

For PMP 320 series, once the RJ-45 pins are jumpered while the radio is powered up, the pin contacts may then be separated and the radio may be rebooted. When the radio powers back up, the software will be restored to a factory default configuration.

Procedure 56 IP Default Procedure – UGPS receiving power from backhaul master timing port

1 With the UGPS unit powered by the backhaul master's timing ports, connect an RJ-45 8 pin Ethernet cable to the External Power Port on the UGPS and pin out the loose end of the cable.

2 Jumper the RJ-45 pins per the wiring table below:

Table 33 UGPS IP default bypass wiring

AP to Default	Wiring on External Power Connector
Timing Port 1	Connect Pins 3 and 6
Timing Port 2	Connect Pins 1 and 2

3 Reboot the radio to be defaulted while the RJ-45 pins are jumpered. After the radio has finished rebooting, the software will be restored to a factory default configuration.

Figure 88 IP default bypass - default radio on timing port 1



Figure 89 IP default bypass - default radio on timing port 2



GPS status and location data readout

The UGPS provides location data to connected synchronized devices and may be retrieved by the access point/backhaul/cluster management module web GUI or by SNMP. GPS status and location data readout is currently available on PMP 100/320/400/430, and PTP 100/200/230, series radios.

Retrieving GPS Status and Location Data via Radio Web Management GUI

Procedure 57 Retrieving GPS status and location data via radio web management GUI – PMP 100/400/430 and PTP 100/200/230 Series

1 With the UGPS powered and connected to the radio, navigate to **Home** > **GPS Status**.

2 GPS Location Data is displayed in section **GPS Status**.

Figure 90 GPS status and location data - PMP 430 example

Home	General Status Session Status Event Log Network Interface Layer 2 Neighbors GPS Status					
Configuration Statistics	ŀ	Home \rightarrow GPS Status				
Tools Account Quick Start	5.7GHz OFDM - Backhaul - Timing Master - 0a-00-3e-38-25-98					
Copyright Account none	GPS Status					
Level: ADMINISTRATOR	Pulse Status :	Receiving Sync				
	Satellites Visible :	15				
	Satellites Tracked :	7				
	GPS Date :	04/01/2011				
	GPS Time :	18:09:16				
	Tracking Mode :	3D Fix				
	Latitude :	42° 4' 1.96" N				
	Longitude :	88° 3' 24.00" W				
	Height :	275.4 meters				
	Invalid Message Count :	4				
	Map NOTE: This is only an	approximation on the physical location.				
	Site Map :	Map [UGPS TEST AP]				
	GPS Receiver Information	E				
	GPS Receiver Information :	Motorola uGPS				

Procedure 58 Retrieving GPS status and location data via radio web management GUI – PMP 320

- 1 With the UGPS powered and connected to the radio, navigate to **Configuration** > **General** > **Properties**.
- **2** GPS Location Data is displayed as below:

Figure 91 GPS status and location data - PMP 320

AP Configuration / General / Properties

Description	Motorola PMP 320 Access Point
Name	PMP320AP
Contact	No contact specified
Location	Cambium Networks
Sync Status	Sync
Tracking Mode	3D
Satellites Used	9
GPS Time	23:09:23
Satellites Visible	11
GPS Latitude	4203.1985 N
GPS Longitude	08801.5311 W
Altitude (m)	243.1
Speed (km/h)	0.00

Update

Retrieving GPS status and location data via SNMP

To retrieve GPS Status and Location Data via SNMP (Simple Network Management Protocol) from synchronized devices operators may use the following procedures.

Procedure 59 Retrieving GPS Status and Location Data via SNMP – PMP 100/400/430 and PTP 100/200/230 Series

1 With the UGPS powered and connected to the radio, on the radio web management GUI navigate to **Configuration** > **SNMP**.

2 Verify that the **Community String** and **Accessing Subnet** values are set as desired.
3 Perform a "snmpget" command for the OID desired based on Table 34.

Table 34 GPS SNMP OIDs - PMP 100/400/430 and PTP 100/200/230 series

Object Name, OID	Description
whispGPSStatus, .1.3.6.1.4.1.161.19.3.1.3.1	GPS synchronization info (1: GPS Synchronized, 2: GPS Lost Sync, 3: Generating Sync)
gpsSyncSource, .1.3.6.1.4.1.161.19.3.1.3.2	Source of GPS sync pulse
gpsSyncStatus, .1.3.6.1.4.1.161.19.3.1.3.3	Current GPS sync status
gpsTrackingMode, .1.3.6.1.4.1.161.19.3.1.3.4	GPS tracking mode
gpsTime, .1.3.6.1.4.1.161.19.3.1.3.5	GPS time
gpsDate, .1.3.6.1.4.1.161.19.3.1.3.6	GPS date
gpsSatellitesTracked, .1.3.6.1.4.1.161.19.3.1.3.7	Current number of satellites GPS is tracking
gpsSatellitesVisible, .1.3.6.1.4.1.161.19.3.1.3.8	Number of satellites visible to the GPS
gpsHeight, .1.3.6.1.4.1.161.19.3.1.3.9	GPS height
gpsLatitude, .1.3.6.1.4.1.161.19.3.1.3.11	GPS latitude
gpsLongitude, .1.3.6.1.4.1.161.19.3.1.3.12	GPS Longitude

Procedure 60 Retrieving GPS status and location data via SNMP – PMP 320

- **1** With the UGPS powered and connected to the radio, on the radio web management GUI navigate to **Administration** > **User Management** and verify SNMP user data.
- Perform a "snmpget" command for the OID desired based on Table 35.
 Table 35 GPS SNMP OIDs PMP 320 series

Object Name, OID	Description
danSyncStatus, .1.3.6.1.4.1.32584.1.1.3.2	Source of GPS sync pulse (0: No sync, 1: Sync present, 2: External sync missing – operating on internal clock, 3: Transition state - about to lose sync)
danLatitude, .1.3.6.1.4.1.32584.1.1.1.5	System installation Latitude, Range -90 to 90
danLongitude, .1.3.6.1.4.1.32584.1.1.1.6	System installation Longitude, Range -180 to 180

UGPS Power Port and Timing Port Pinouts

See Table 36 and Table 37 below for UGPS pinout information.

Pin	Function
1	Ground (for IP Default jumper to Pin 2)
2	Timing Port 2 AP IP Default Pin
3	Ground (For IP Default jumper to Pin 6)
4	Ground (+Vaux Return)
5	Ground (+Vaux Return)
6	Timing Port 1 AP IP Default Pin
7	+Vaux (10V-30V DC)
8	+Vaux (10V-30V DC)

Table 36 UGPS Power Port Pinout

Table 37 UGPS Timing Port Pinout

Pin	Function
1	1 PPS Sync Pulse (8Vo-p)
2	N/A
3	GPS Location Data – Serial 9600 bps (8Vo-p)
4	V+ (4V DC – 6V DC)
5	N/A
6	Ground (V+ Return)

Chapter 5: CMM Regulatory and Legal Notices

Important Note on Modifications

Intentional or unintentional changes or modifications to the equipment must not be made unless under the express consent of the party responsible for compliance. Any such modifications could void the user's authority to operate the equipment and will void the manufacturer's warranty.

National and Regional Regulatory Notices

U.S. Federal Communication Commission (FCC) Notification

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the US FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to correct the interference by one or more of the following measures:

- Increase the separation between the affected equipment and the unit;
- Connect the affected equipment to a power outlet on a different circuit from that which the receiver is connected to;
- Consult the dealer and/or experienced radio/TV technician for help.

Industry Canada (IC) Notification

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to RSS-210 of Industry Canada. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to correct the interference by one or more of the following measures:

- Increase the separation between the affected equipment and the unit;
- Connect the affected equipment to a power outlet on a different circuit from that which the receiver is connected to;
- Consult the dealer and/or experienced radio/TV technician for help.

To reduce potential radio interference to other users, the antenna type and its gain should be chosen so its Equivalent Isotropic Radiated Power (EIRP) is not more than that permitted for successful communication.

Equipment Disposal



Waste (Disposal) of Electronic and Electric Equipment

Please do not dispose of Electronic and Electric Equipment or Electronic and Electric Accessories with your household waste. In some countries or regions, collection systems have been set up to handle waste of electrical and electronic equipment. In European Union countries, please contact your local equipment supplier representative or service center for information about the waste collection system in your country.

EU Declaration of Conformity for RoHS Compliance

Cambium hereby, declares that these Cambium products are in compliance with the essential requirements and other relevant provisions of Directive 2002/95/EC, Restriction of the use of certain Hazardous Substances (RoHS) in electrical and electronic equipment.

The relevant Declaration of Conformity can be found at http://www.cambiumnetworks.com/doc.php

Labeling and Disclosure Table for China

The People's Republic of China requires that Cambium's products comply with China Management Methods (CMM) environmental regulations. (China Management Methods refers to the regulation *Management Methods for Controlling Pollution by Electronic Information Products.*) Two items are used to demonstrate compliance; the label and the disclosure table.

The label is placed in a customer visible position on the product.

- Logo 1 means that the product contains no substances in excess of the maximum concentration value for materials identified in the China Management Methods regulation.
- Logo 2 means that the product may contain substances in excess of the maximum concentration value for materials identified in the China Management Methods regulation, and has an Environmental Friendly Use Period (EFUP) in years, fifty years in the example shown.

Logo 1





The Environmental Friendly Use Period (EFUP) is the period (in years) during which the Toxic and Hazardous Substances (T&HS) contained in the Electronic Information Product (EIP) will not leak or mutate causing environmental pollution or bodily injury from the use of the EIP. The EFUP indicated by the Logo 2 label applies to a product and all its parts. Certain field-replaceable parts, such as battery modules, can have a different EFUP and are marked separately.

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价 铬 (Cr ⁶⁺)	多溴 联苯 (PBB)	多溴二苯 醚 (PBDE)
金属部件	×	0	×	×	0	0
电 路模 块	×	0	×	×	0	0
电缆 及 电缆组 件	×	0	×	×	0	0
塑料和聚合物部件	0	0	0	0	0	×
表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006标准规定的限量要求以下。 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。						

Table 38 Disclosure Table for China

The Disclosure Table is intended only to communicate compliance with China requirements; it is not intended to communicate compliance with EU RoHS or any other environmental requirements.

RF Exposure Separation Distances

To protect from overexposure to radio frequency (RF) energy, install Cambium radios so as to provide and maintain the minimum separation distances from all persons shown in Table 39.

Module Type	Separation Distance from Persons		
Radio Module with integrated antenna	At least 20 cm (approx. 8 in)		
Module with Reflector Dish	At least 1.5 m (approx. 60 in or 5 ft.)		
Module with LENS	At least 0.5 m (approx. 20 in)		
Antenna of connectorized 5.7 GHz AP	At least 30 cm (approx. 12 in)		
Antenna of connectorized or integrated 900 MHz module	At least 60 cm (24 in)		
Indoor 900 MHz SM	At least 10 cm (4 in)		
PMP 320 AP	At least 50 cm (20 in)		

 Table 39
 Exposure separation distances

For details and discussion of the associated calculations, see the Canopy System Release 9.4.2 User's Guide, available at http://www.cambiumnetworks.com/support

Legal Notices

Software License Terms and Conditions

ONLY OPEN THE PACKAGE, OR USE THE SOFTWARE AND RELATED PRODUCT IF YOU ACCEPT THE TERMS OF THIS LICENSE. BY BREAKING THE SEAL ON THIS DISK KIT / CDROM, OR IF YOU USE THE SOFTWARE OR RELATED PRODUCT, YOU ACCEPT THE TERMS OF THIS LICENSE AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, DO NOT USE THE SOFTWARE OR RELATED PRODUCT; INSTEAD, RETURN THE SOFTWARE TO PLACE OF PURCHASE FOR A FULL REFUND. THE FOLLOWING AGREEMENT IS A LEGAL AGREEMENT BETWEEN YOU (EITHER AN INDIVIDUAL OR ENTITY), AND CAMBIUM, INC. (FOR ITSELF AND ITS LICENSORS). THE RIGHT TO USE THIS PRODUCT IS LICENSED ONLY ON THE CONDITION THAT YOU AGREE TO THE FOLLOWING TERMS.

Now, therefore, in consideration of the promises and mutual obligations contained herein, and for other good and valuable consideration, the receipt and sufficiency of which are hereby mutually acknowledged, you and Cambium agree as follows:

Grant of License. Subject to the following terms and conditions, Cambium, Inc., grants to you a personal, revocable, non-assignable, non-transferable, non-exclusive and limited license to use on a single piece of equipment only one copy of the software contained on this disk (which may have been pre-loaded on the equipment) (Software). You may make two copies of the Software, but only for backup, archival, or disaster recovery purposes. On any copy you make of the Software, you must reproduce and include the copyright and other proprietary rights notice contained on the copy we have furnished you of the Software.

Ownership. Cambium (or its supplier) retains all title, ownership and intellectual property rights to the Software and any copies, including translations, compilations, derivative works (including images) partial copies and portions of updated works. The Software is Cambium's (or its supplier's) confidential proprietary information. This Software License Agreement does not convey to you any interest in or to the Software, but only a limited right of use. You agree not to disclose it or make it available to anyone without Cambium's written authorization. You will exercise no less than reasonable care to protect the Software from unauthorized disclosure. You agree not to disassemble, decompile or reverse engineer, or create derivative works of the Software, except and only to the extent that such activity is expressly permitted by applicable law.

Termination. This License is effective until terminated. This License will terminate immediately without notice from Cambium or judicial resolution if you fail to comply with any provision of this License. Upon such termination you must destroy the Software, all accompanying written materials and all copies thereof, and the sections entitled Limited Warranty, Limitation of Remedies and Damages, and General will survive any termination.

Limited Warranty. Cambium warrants for a period of ninety (90) days from Cambium's or its customer's shipment of the Software to you that (i) the disk(s) on which the Software is recorded will be free from defects in materials and workmanship under normal use and (ii) the Software, under normal use, will perform substantially in accordance with Cambium's published specifications for that release level of the Software. The written materials are provided "AS IS" and without warranty of any kind. Cambium's entire liability and your sole and exclusive remedy for any breach of the foregoing limited warranty will be, at Cambium's option, replacement of the disk(s), provision of downloadable patch or replacement code, or refund of the unused portion of your bargained for contractual benefit up to the amount paid for this Software License.

THIS LIMITED WARRANTY IS THE ONLY WARRANTY PROVIDED BY CAMBIUM, AND CAMBIUM AND ITS LICENSORS EXPRESSLY DISCLAIM ALL OTHER WARRANTIES, EITHER EXPRESS OF IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. CAMBIUM DOES NOT WARRANT THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT DEFECTS IN THE SOFTWARE WILL BE CORRECTED. NO ORAL OR WRITTEN REPRESENTATIONS MADE BY CAMBIUM OR AN AGENT THEREOF SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY. CAMBIUM DOES NOT WARRANT ANY SOFTWARE THAT HAS BEEN OPERATED IN EXCESS OF SPECIFICATIONS, DAMAGED, MISUSED, NEGLECTED, OR IMPROPERLY INSTALLED. BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF IMPLIED WARRANTIES, THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

Limitation of Remedies and Damages. Regardless of whether any remedy set forth herein fails of its essential purpose, IN NO EVENT SHALL CAMBIUM OR ANY OF THE LICENSORS, DIRECTORS, OFFICERS, EMPLOYEES OR AFFILIATES OF THE FOREGOING BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, SPECIAL OR SIMILAR DAMAGES WHATSOEVER (including, without limitation, damages for loss of business profits, business interruption, loss of business information and the like), whether foreseeable or unforeseeable, arising out of the use or inability to use the Software or accompanying written materials, regardless of the basis of the claim and even if Cambium or a Cambium representative has been advised of the possibility of such damage. Cambium's liability to you for direct damages for any cause whatsoever, regardless of the basis of the form of the action, will be limited to the price paid for the Software that caused the damages. THIS LIMITATION WILL NOT APPLY IN CASE OF PERSONAL INJURY ONLY WHERE AND TO THE EXTENT THAT APPLICABLE LAW REQUIRES SUCH LIABILITY. BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

Maintenance and Support. Cambium shall not be responsible for maintenance or support of the software. By accepting the license granted under this agreement, you agree that Cambium will be under no obligation to provide any support, maintenance or service in connection with the Software or any application developed by you. Any maintenance and support of the Related Product will be provided under the terms of the agreement for the Related Product.

Transfer. In the case of software designed to operate on Cambium equipment, you may not transfer the Software to another party except: (1) if you are an end-user, when you are transferring the Software together with the Cambium equipment on which it operates; or 2) if you are a Cambium licensed distributor, when you are transferring the Software either together with such Cambium equipment or are transferring the Software as a licensed duly paid for upgrade, update, patch, new release, enhancement or replacement of a prior version of the Software. If you are a Cambium licensed distributor, when you are transferring the Software as permitted herein, you agree to transfer the Software with a license agreement having terms and conditions no less restrictive than those contained herein. You may transfer all other Software, not otherwise having an agreed restriction on transfer, to another party. However, all such transfers of Software are strictly subject to the conditions precedent that the other party agrees to accept the terms and conditions of this License, and you destroy any copy of the Software you do not transfer to that party. You may not sublicense or otherwise transfer, rent or lease the Software without our written consent. You may not transfer the Software in violation of any laws, regulations, export controls or economic sanctions imposed by the US Government.

Right to Audit. Cambium shall have the right to audit annually, upon reasonable advance notice and during normal business hours, your records and accounts to determine compliance with the terms of this Agreement.

Export Controls. You specifically acknowledge that the software may be subject to United States and other country export control laws. You shall comply strictly with all requirements of all applicable export control laws and regulations with respect to all such software and materials.

US Government Users. If you are a US Government user, then the Software is provided with "RESTRICTED RIGHTS" as set forth in subparagraphs (c)(1) and (2) of the Commercial Computer Software-Restricted Rights clause at FAR 52 227-19 or subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013, as applicable.

Disputes. You and Cambium hereby agree that any dispute, controversy or claim, except for any dispute, controversy or claim involving intellectual property, prior to initiation of any formal legal process, will be submitted for non-binding mediation, prior to initiation of any formal legal process. Cost of mediation will be shared equally. Nothing in this Section will prevent either party from resorting to judicial proceedings, if (i) good faith efforts to resolve the dispute under these procedures have been unsuccessful, (ii) the dispute, claim or controversy involves intellectual property, or (iii) interim relief from a court is necessary to prevent serious and irreparable injury to that party or to others.

General. Illinois law governs this license. The terms of this license are supplemental to any written agreement executed by both parties regarding this subject and the Software Cambium is to license you under it, and supersedes all previous oral or written communications between us regarding the subject except for such executed agreement. It may not be modified or waived except in writing and signed by an officer or other authorized representative of each party. If any provision is held invalid, all other provisions shall remain valid, unless such invalidity would frustrate the purpose of our agreement. The failure of either party to enforce any rights granted hereunder or to take action against the other party in the event of any breach hereunder shall not be deemed a waiver by that party as to subsequent enforcement of rights or subsequent action in the event of future breaches.

Hardware Warranty in U.S.

Cambium's standard hardware warranty is for one (1) year from date of shipment from Cambium or a Cambium distributor. Cambium warrants that hardware will conform to the relevant published specifications and will be free from material defects in material and workmanship under normal use and service. Cambium shall within this time, at its own option, either repair or replace the defective product within thirty (30) days of receipt of the defective product. Repaired or replaced product will be subject to the original warranty period but not less than thirty (30) days.

For warranty assistance, contact the reseller or distributor.

Using non-Cambium parts for repair could damage the equipment or void warranty. Contact Cambium for service and repair instructions.

Portions of Cambium equipment may be damaged from exposure to electrostatic discharge. Use precautions to prevent damage.

Limit of Liability

IN NO EVENT SHALL CAMBIUM BE LIABLE TO YOU OR ANY OTHER PARTY FOR ANY DIRECT, INDIRECT, GENERAL, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR OTHER DAMAGE ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION OR ANY OTHER PECUNIARY LOSS, OR FROM ANY BREACH OF WARRANTY, EVEN IF CAMBIUM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.) IN NO CASE SHALL CAMBIUM'S LIABILITY EXCEED THE AMOUNT YOU PAID FOR THE PRODUCT.

Chapter 6: UGPS Regulatory, Legal, and Safety Notices

IMPORTANT NOTE ON MODIFICATIONS

Intentional or unintentional changes or modifications to the equipment must not be made unless under the express consent of the party responsible for compliance. Any such modifications could void the user's authority to operate the equipment and voids the manufacturer's warranty.

Universal GPS module label

MADE IN MEXICO MODEL: (F MSN: TIMING PORT 1 EXT. POWER **TIMING PORT 2** 4V-6V ----10V-30V ----4V-6V ----20mA 60mA CANADA 310 60mA

Figure 92 UGPS label

NATIONAL AND REGIONAL REGULATORY NOTICES

U.S. Federal Communication Commission (FCC) Notification

This device complies with Part 15 of the US FCC Rules and Regulations. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the US FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to correct the interference by one or more of the following measures:

- Increase the separation between the affected equipment and the unit;
- Connect the affected equipment to a power outlet on a different circuit from that which the receiver is connected to;
- Consult the dealer and/or experienced radio/TV technician for help.

Industry Canada Notification

This Category II radio communication device complies with Industry Canada Standard RSS-310. Ce dispositif de radiocommunication de catégorie II respecte la norme CNR-310 d'Industrie Canada. Operation is subject to the following two conditions:

- This device may not cause harmful interference and
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio-frequency energy and if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to correct the interference by one or more of the following measures:

- Increase the separation between the affected equipment and the unit;
- Connect the affected equipment to a power outlet on a different circuit from that which the receiver is connected to;
- Consult the dealer and/or experienced radio/TV technician for help

Equipment Disposal

Figure 93 Waste disposal of electronic and electric equipment



Please do not dispose of Electronic and Electric Equipment or Electronic and Electric Accessories with your household waste. In some countries or regions, collection systems have been set up to handle waste of electrical and electronic equipment. In European Union countries, please contact your local equipment supplier representative or service center for information about the waste collection system in your country.

LIMIT OF LIABILITY

IN NO EVENT SHALL CAMBIUM NETWORKS BE LIABLE TO YOU OR ANY OTHER PARTY FOR ANY DIRECT, INDIRECT, GENERAL, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR OTHER DAMAGE ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION OR ANY OTHER PECUNIARY LOSS, OR FROM ANY BREACH OF WARRANTY, EVEN IF CAMBIUM NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.) IN NO CASE SHALL CAMBIUM NETWORKS LIABILITY EXCEED THE AMOUNT YOU PAID FOR THE PRODUCT.