



User Guide

PTP 850E

System Release 10.9



Accuracy

While reasonable efforts have been made to assure the accuracy of this document, Cambium Networks assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. Cambium reserves the right to make changes to any products described herein to improve reliability, function, or design, and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Cambium does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others. It is possible that this publication may contain references to, or information about Cambium products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Cambium intends to announce such Cambium products, programming, or services in your country.

Copyrights

This document, Cambium products, and 3rd Party software products described in this document may include or describe copyrighted Cambium and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Cambium, its licensors, and other 3rd Party supplied software certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Cambium, its licensors, or the 3rd Party software supplied material contained in the Cambium products described in this document may not be copied, reproduced, reverse engineered, distributed, merged or modified in any manner without the express written permission of Cambium. Furthermore, the purchase of Cambium products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Cambium or other 3rd Party supplied software, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

Restrictions

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Cambium.

License Agreements

The software described in this document is the property of Cambium and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

High Risk Materials

Cambium and its supplier(s) specifically disclaim any express or implied warranty of fitness for any high risk activities or uses of its products including, but not limited to, the operation of nuclear facilities, aircraft navigation or aircraft communication systems, air traffic control, life support, or weapons systems ("High Risk Use"). Any High Risk is unauthorized, is made at your own risk and you shall be responsible for any and all losses, damage or claims arising out of any High Risk Use.

© 2019 Cambium Networks Limited. All Rights Reserved.

Contents

About This User Guide	1
Contacting Cambium Networks	2
Purpose	3
Cross references	3
Feedback	3
Problems and warranty	4
Reporting problems.....	4
Repair and service	4
Hardware warranty	4
Security advice	5
Warnings, cautions, and notes	6
Warnings	6
Cautions.....	6
Notes	6
Caring for the environment	7
In EU countries	7
In non-EU countries.....	7
Chapter 1: Introduction	1-1
System Overview	1-2
Configuration Tips	1-2
PTP 850E	1-3
PoE Injector Overview	1-3
The Web-Based Element Management System	1-3
Reference Guide to Web EMS Menu Structure	1-10
Chapter 2: Getting Started.....	2-1
Assigning IP Addresses in the Network.....	2-2
Establishing a Connection	2-3
PC Setup	2-4
Logging on.....	2-6
Changing Your Password.....	2-7
Performing Quick Platform Setup	2-9
Configuring In-Band Management.....	2-12
Changing the Management IP Address.....	2-13
Configuring the Activation Key	2-15
Activation Key Overview	2-15
Viewing the Activation Key Status Parameters	2-16
Entering the Activation Key	2-17

To activate demo mode:	2-17
Activation Key Reclaim	2-17
Displaying a List of Activation-Key-Enabled Features	2-18
Setting the Time and Date (Optional)	2-23
Enabling the Interfaces (Interface Manager)	2-25
Configuring the Radio (MRMC) Script(s)	2-27
Radio Profiles	2-30
Configuring the Radio Parameters	2-31
Creating Service(s) for Traffic	2-34
Chapter 3: Configuration Guide	3-1
Configuring a Link Using the Quick Configuration Wizard	3-1
Configuring a 1+0 Link Using the Quick Configuration Wizard	3-1
Chapter 4: Unit Management	4-1
Defining the IP Protocol Version for Initiating Communications	4-2
Configuring the Remote Unit's IP Address	4-3
Changing the Subnet of the Remote IP Address	4-4
Configuration SNMP	4-5
Configuring Trap Managers	4-8
Installing and Configuring an FTP or SFTP Server	4-11
Configuring the Internal Ports for FTP or SFTP	4-14
Upgrading the Software	4-15
Viewing Current Software Versions	4-15
Software Upgrade Overview	4-16
Downloading and Installing Software	4-16
Downloading Software Via HTTP or HTTPS	4-17
Downloading Software Via FTP or SFTP	4-18
Installing Software	4-21
Configuring a Timed Installation	4-22
Backing Up and Restoring Configurations	4-24
Configuration Management Overview	4-24
Viewing Current Backup Files	4-24
Setting the Configuration Management Parameters	4-25
Exporting a Configuration File	4-28
Importing a Configuration File	4-28
Deleting a Configuration File	4-29
Backing Up the Current Configuration	4-29
Restoring a Saved Configuration	4-29
Editing CLI Scripts	4-30
Setting the Unit to the Factory Default Configuration	4-31
Performing a Hard (Cold) Reset	4-32
Configuring Unit Parameters	4-33
Configuring NTP	4-35

Displaying Unit Inventory	4-37
Defining a Login Banner	4-38
Chapter 5: Radio Configuration	5-1
Viewing the Radio Status and Settings	5-2
Configuring the Remote Radio Parameters	5-4
Configuring and Viewing Radio PMs and Statistics	5-6
Configuring BER Thresholds and Displaying Current BER	5-6
Displaying MPMC Status	5-7
Displaying MPMC PMs	5-10
Displaying and Clearing Defective Block Counters	5-11
Displaying Signal Level PMs and Configuring Signal Level PM Thresholds	5-12
Displaying Modem BER (Aggregate) PMs	5-14
Displaying MSE PMs and Configuring MSE PM Thresholds	5-16
Chapter 6: Ethernet Services and Interfaces	6-1
Configuring Ethernet Service(s)	6-2
Ethernet Services Overview	6-2
General Guidelines for Provisioning Ethernet Services	6-3
The Ethernet Services Page	6-3
Adding an Ethernet Service	6-4
Editing a Service	6-6
Deleting a Service	6-6
Enabling, Disabling, or Deleting Multiple Services	6-6
Viewing Service Details	6-7
Configuring Service Points	6-7
Setting the MRU Size and the S-VLAN Ethertype	6-20
Configuring Ethernet Interfaces	6-21
Configuring Automatic State Propagation and Link Loss Forwarding	6-24
Viewing Ethernet PMs and Statistics	6-27
RMON Statistics	6-27
Egress CoS Statistics	6-28
Port TX Statistics	6-30
Port RX Statistics	6-33
Chapter 7: Quality of Service (QoS)	7-1
QoS Overview	7-2
Configuring Classification	7-4
Classification Overview	7-4
Configuring Ingress Path Classification on a Logical Interface	7-5
Modifying the C-VLAN 802.1Q UP and CFI Bit Classification Table	7-7
Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table	7-9
Modifying the DSCP Classification Table	7-10
Modifying the MPLS EXP Bit Classification Table	7-11
Configuring Policers (Rate Metering)	7-13

Policer (Rate Metering) Overview	7-13
Configuring Policer Profiles	7-13
Assigning Policers to Interfaces.....	7-16
Configuring the Ingress and Egress Byte Compensation	7-21
Configuring Marking	7-22
Marking Overview	7-22
Enabling Marking.....	7-22
Modifying the 802.1Q Marking Table	7-22
Modifying the 802.1AD Marking Table	7-24
Configuring WRED.....	7-25
WRED Overview	7-25
Configuring WRED Profiles	7-25
Assigning WRED Profiles to Queues	7-28
Configuring Egress Shaping.....	7-29
Egress Shaping Overview.....	7-29
Configuring Queue Shaper Profiles	7-29
Assigning a Queue Shaper Profile to a Queue.....	7-31
Configuring Scheduling	7-34
Scheduling Overview	7-34
Configuring Priority Profiles	7-34
Configuring WFQ Profiles	7-38
Assigning a Priority Profile to an Interface	7-40
Assigning a WFQ Profile to an Interface.....	7-40
Configuring and Displaying Queue-Level PMs	7-42
Chapter 8: Synchronization.....	8-1
Configuring the Sync Source	8-2
Viewing the Sync Source Status	8-2
Adding a Sync Source	8-3
Editing a Sync Source.....	8-4
Deleting a Sync Source	8-5
Configuring the Outgoing Clock and SSM Messages	8-6
Chapter 9: Access Management and Security	9-1
Configuring the General Access Control Parameters.....	9-2
Configuring the Password Security Parameters.....	9-4
Configuring the Session Timeout	9-5
Configuring Users.....	9-6
User Configuration Overview	9-6
Configuring User Profiles.....	9-6
Configuring Users	9-9
Configuring X.509 CSR Certificates and HTTPS	9-12
Generating a Certificate Signing Request (CSR) File.....	9-12
Downloading a Certificate	9-14

Blocking Telnet Access	9-16
Uploading the Security Log	9-17
Uploading the Configuration Log	9-19
Chapter 10: Alarm Management and Troubleshooting	10-1
Viewing Current Alarms	10-2
Viewing Alarm Statistics	10-4
Viewing and Saving the Event Log	10-5
Editing Alarm Text and Severity Disabling Alarms and Event	10-7
Displaying Alarm Information	10-7
Viewing the Probable Cause and Corrective Actions for an Alarm Type	10-8
Editing an Alarm Type and Disabling Alarms and Events	10-8
Setting Alarms to their Default Values	10-9
Configuring Voltage Alarm Thresholds and Displaying Voltage PMs	10-10
Uploading Unit Info	10-13
Performing Diagnostics	10-16
Performing Radio Loopback	10-16
Performing Ethernet Loopback	10-17
Configuring Service OAM (SOAM) Fault Management (FM)	10-17
Chapter 11: Web EMS Utilities	11-1
Restarting the HTTP Server	11-2
Calculating an ifIndex	11-2
Displaying, Searching, and Saving a list of MIB Entities	11-4
Chapter 12: Getting Started (CLI)	12-1
General (CLI)	12-2
Establishing a Connection (CLI)	12-2
PC Setup (CLI)	12-2
Logging On (CLI)	12-3
General CLI Commands	12-4
Changing Your Password (CLI)	12-5
Configuring In-Band Management (CLI)	12-6
Changing the Management IP Address (CLI)	12-7
Configuring the Activation Key (CLI)	12-9
Activation Key Overview (CLI)	12-9
Viewing the Activation Key Status Parameters (CLI)	12-9
Entering the Activation Key (CLI)	12-10
Activating a Demo Activation Key (CLI)	12-10
Displaying a List of Activation-Key-Enabled Features (CLI)	12-10
Setting the Time and Date (Optional) (CLI)	12-11
Setting the Daylight Savings Time (CLI)	12-12
Enabling the Interfaces (CLI)	12-13
Configuring the Radio (MRMC) Script(s) (CLI)	12-15
Displaying Available MRMC Scripts (CLI)	12-15

Assigning an MPMC Script to a Radio Carrier (CLI)	12-16
Configuring the Radio Parameters (CLI)	12-18
Entering Radio View (CLI)	12-18
Muting and Unmuting a Radio (CLI)	12-18
Configuring the Transmit (TX) Frequency (CLI)	12-19
Configuring the Transmit (TX) Level (CLI)	12-19
Enabling ACM with Adaptive Transmit Power (CLI)	12-19
Configuring the RSL Threshold Alarm (CLI)	12-21
Creating Service(s) for Traffic (CLI)	12-22
Chapter 13: Unit Management (CLI)	13-23
Defining the IP Protocol Version for Initiating Communications (CLI)	13-24
Configuring the Remote Unit's IP Address (CLI)	13-25
Configuring the Remote Radio's IP Address in IPv4 format (CLI)	13-25
Configuring the Remote Radio's IP Address in IPv6 format (CLI)	13-26
Configuring SNMP (CLI)	13-27
Configuring Basic SNMP Settings (CLI)	13-27
Configuring SNMPv3 (CLI)	13-28
Displaying the SNMP Settings (CLI)	13-29
Configuring Trap Managers (CLI)	13-30
Configuring the Internal Ports for FTP or SFTP (CLI)	13-32
Upgrading the Software (CLI)	13-33
Software Upgrade Overview (CLI)	13-33
Viewing Current Software Versions (CLI)	13-33
Configuring a Software Download (CLI)	13-34
Downloading a Software Package (CLI)	13-35
Installing and Upgrading Software (CLI)	13-36
Backing Up and Restoring Configurations (CLI)	13-37
Configuration Management Overview (CLI)	13-37
Setting the Configuration Management Parameters (CLI)	13-38
Backing up and Exporting a Configuration File (CLI)	13-39
Importing and Restoring a Configuration File (CLI)	13-40
Editing CLI Scripts (CLI)	13-40
Setting the Unit to the Factory Default Configuration (CLI)	13-42
Performing a Hard (Cold) Reset (CLI)	13-43
Resetting the Remote Unit (CLI)	13-44
Configuring Unit Parameters (CLI)	13-45
Configuring NTP (CLI)	13-46
Displaying Unit Inventory (CLI)	13-46
Chapter 14: Radio Configuration (CLI)	14-1
Viewing and Configuring the Remote Radio Parameters (CLI)	14-2
Displaying Communication Status with the Remote Radio (CLI)	14-2
Displaying Remote Radio's Location (CLI)	14-2

Muting and Unmuting the Remote Radio (CLI)	14-2
Displaying the Remote Radio's RX Level (CLI)	14-3
Configuring the Remote Radio's TX Level (CLI)	14-3
Displaying the Remote Unit's Most Severe Alarm (CLI)	14-3
Configuring and Viewing Radio PMs and Statistics (CLI).....	14-4
Displaying General Modem Status and Defective Block PMs (CLI)	14-4
Displaying Excessive BER (Aggregate) PMs (CLI)	14-4
Displaying BER Level and Configuring BER Parameters (CLI).....	14-6
Configuring RSL Thresholds (CLI)	14-7
Configuring TSL Thresholds (CLI)	14-7
Displaying RSL and TSL Levels (CLI).....	14-8
Configuring the Signal Level Threshold (CLI)	14-9
Configuring the MSE Thresholds and Displaying the MSE PMs (CLI).....	14-10
Displaying ACM PMs (CLI).....	14-12
Chapter 15: Ethernet Services and Interfaces (CLI)	15-1
Configuring Ethernet Services (CLI).....	15-2
Ethernet Services Overview (CLI)	15-2
General Guidelines for Provisioning Ethernet Services (CLI).....	15-2
Defining Services (CLI)	15-3
Configuring Service Points (CLI).....	15-8
Defining the MAC Address Forwarding Table for a Service (CLI).....	15-24
Setting the MRU Size and the S-VLAN Ethertype (CLI).....	15-28
Configuring the S-VLAN Ethertype (CLI)	15-28
Configuring the C-VLAN Ethertype (CLI).....	15-29
Configuring the MRU (CLI).....	15-29
Configuring Ethernet Interfaces (CLI)	15-29
Entering Interface View (CLI).....	15-30
Displaying the Operational State of the Interfaces in the Unit (CLI)	15-31
Viewing Interface Attributes (CLI)	15-31
Configuring an Interface's Media Type (CLI)	15-32
Configuring an Interface's Speed and Duplex State (CLI)	15-32
Configuring an Interface's Auto Negotiation State (CLI)	15-33
Configuring an Interface's IFG (CLI).....	15-33
Configuring an Interface's Preamble (CLI).....	15-34
Adding a Description for the Interface (CLI).....	15-34
Configuring Automatic State Propagation and Link Loss Forwarding (CLI).....	15-36
Viewing Ethernet PMs and Statistics (CLI)	15-40
Displaying RMON Statistics (CLI)	15-40
Configuring Ethernet Port PMs and PM Thresholds (CLI)	15-41
Displaying Ethernet Port PMs (CLI)	15-42
Clearing Ethernet Port PMs (CLI).....	15-45
Chapter 16: Quality of Service (QoS) (CLI)	16-1

Configuring Classification (CLI).....	16-2
Classification Overview (CLI)	16-2
Configuring Ingress Path Classification on a Logical Interface (CLI)	16-2
Configuring VLAN Classification and Override (CLI)	16-3
Configuring 802.1p Classification (CLI).....	16-4
Configuring DSCP Classification (CLI).....	16-5
Configuring MPLS Classification (CLI)	16-8
Configuring 802.1p Classification (CLI).....	16-10
Configuring a Default CoS (CLI)	16-14
Configuring Ingress Path Classification on a Service Point (CLI).....	16-14
Configuring Ingress Path Classification on a Service (CLI)	16-14
Configuring Policers (Rate Metering) (CLI).....	16-15
Overview of Rate Metering (Policing) (CLI)	16-15
Configuring Rate Meter (Policer) Profiles (CLI)	16-15
Displaying Rate Meter Profiles (CLI)	16-17
Deleting a Rate Meter Profile (CLI).....	16-17
Attaching a Rate Meter (Policer) to an Interface (CLI)	16-17
Configuring the Line Compensation Value for a Rate Meter (Policer) (CLI)	16-24
Configuring Marking (CLI)	16-26
Marking Overview (CLI)	16-26
Configuring Marking Mode on a Service Point (CLI).....	16-26
Marking Table for C-VLAN UP Bits (CLI).....	16-27
Marking Table for S-VLAN UP Bits (CLI)	16-29
Configuring WRED (CLI).....	16-31
WRED Overview (CLI)	16-31
Configuring WRED Profiles (CLI)	16-31
Assigning a WRED Profile to a Queue (CLI)	16-33
Configuring Shapers (CLI).....	16-35
Overview of Egress Shaping (CLI)	16-35
Configuring Egress Line Compensation for Shaping (CLI)	16-37
Configuring Scheduling (CLI)	16-38
Overview of Egress Scheduling (CLI).....	16-38
Configuring Queue Priority (CLI).....	16-38
Configuring Interface Priority Profiles (CLI).....	16-39
Attaching a Priority Profile to an Interface (CLI)	16-42
Configuring Weighted Fair Queuing (WFQ) (CLI)	16-43
Displaying Egress Statistics (CLI)	16-47
Displaying Queue-Level PMs (CLI)	16-47
Displaying Service Bundle-Level PMs (CLI)	16-48
Chapter 17: Synchronization (CLI)	17-1
Changing the ETSI/ANSI Mode (CLI).....	17-2
Configuring the Sync Source (CLI)	17-3

Configuring an Ethernet Interface as a Synchronization Source (CLI)	17-4
Configuring a Radio Interface as a Synchronization Source (CLI)	17-5
Configuring the Outgoing Clock (CLI)	17-8
Configuring SSM Messages (CLI)	17-10
Displaying Synchronization Status and Parameters (CLI)	17-11
Chapter 18: Access Management and Security (CLI)	18-1
Configuring the General Access Control Parameters (CLI)	18-2
Configuring the Inactivity Timeout Period (CLI)	18-2
Configuring Blocking Upon Login Failure (CLI)	18-2
Configuring Blocking of Unused Accounts (CLI)	18-3
Configuring the Password Security Parameters (CLI)	18-5
Configuring Password Aging (CLI)	18-5
Configuring Password Strength Enforcement (CLI)	18-5
Forcing Password Change Upon First Login (CLI)	18-6
Displaying the System Password Settings (CLI)	18-7
Configuring Users (CLI)	18-8
User Configuration Overview (CLI)	18-8
Configuring User Profiles (CLI)	18-8
Configuring User Accounts (CLI)	18-10
Configuring X.509 CSR Certificates and HTTPS (CLI)	18-12
Generating a Certificate Signing Request (CSR) File (CLI)	18-12
Downloading a Certificate (CLI)	18-14
Enabling HTTPS (CLI)	18-15
Configuring HTTPS Cipher Hardening (CLI)	18-17
Blocking Telnet Access (CLI)	18-18
Uploading the Security Log (CLI)	18-19
Uploading the Configuration Log (CLI)	18-21
Chapter 19: Alarm Management and Troubleshooting (CLI)	19-1
Viewing Current Alarms (CLI)	19-2
Viewing the Event Log (CLI)	19-3
Editing Alarm Text and Severity (CLI)	19-4
Displaying Alarm Information (CLI)	19-4
Editing an Alarm Type (CLI)	19-4
Setting Alarms to their Default Values (CLI)	19-5
Configuring a Timeout for Trap Generation (CLI)	19-6
Configuring Voltage Alarm Thresholds and Displaying Voltage PMs (CLI)	19-7
Uploading Unit Info (CLI)	19-9
Activating the Radio Logger (CLI)	19-12
Performing Diagnostics (CLI)	19-13
Performing Radio Loopback (CLI)	19-13
Performing Ethernet Loopback (CLI)	19-13
Configuring Service OAM (SOAM) Fault Management (FM) (CLI)	19-14

SOAM Overview (CLI)	19-15
Configuring MDs (CLI).....	19-15
Configuring MA/MEGs (CLI)	19-16
Configuring MEPs (CLI)	19-19
Working in CW Mode (Single or Dual Tone) (CLI)	19-30
Chapter 20: Maintenance.....	20-1
Temperature Ranges.....	20-2
Troubleshooting Tips.....	20-2
PTP 850E Connector Pin-outs	20-3
P2 (Eth 1) – MGT/PoE GbE Electrical Interface (RJ-45)	20-4
P3 (Eth 2) GbE Optical Interface (SFP).....	20-4
P4 (Eth 3, Eth 4, Eth 5, Eth 6) 40 GbE Optical Interface (QSFP)	20-4
P5 (Eth 7) 10G Optical Interface (SFP+).....	20-4
Protection/XPIC Port	20-5
RSL Interface.....	20-5
PTP 850E LEDs.....	20-6
P2 MGT/PoE GbE Electrical Interface (RJ-45) LEDs	20-6
P4/Eth3-7 40G Optical Interface (QSFP) LEDs	20-6
P5/Eth7 10G Optical Interface (SFP+) LEDs	20-6
Status LED.....	20-6
Protection LED.....	20-7
PoE Injector Pin-outs and LEDs – Standard PoE.....	20-8
PoE Injector Pin-outs and LEDs – Standard PoE	20-8
PoE Injector LEDs – Standard PoE	20-9
PoE Injector Pin-outs and LEDs – Passive PoE.....	20-11
PoE Injector Pin-outs and LEDs – Passive PoE	20-11
PoE Injector LEDs – Passive PoE	20-11
Chapter 21: Alarms List	21-12
Glossary.....	I

List of Figures

Figure 1 Main Web EMS Page	1-4
Figure 2 Displaying a Representation of the Front Panel	1-4
Figure 3 Main Web EMS Page with Representation of Front Panel	1-5
Figure 4 Related Pages Drop-Down List	1-6
Figure 5 Related Pages Drop-Down List	1-6
Figure 6 Unit Summary Page	1-7
Figure 7 Unit Summary Page – Customizing Columns	1-7
Figure 8 Radio Summary Page	1-8
Figure 9 Radio Summary Page- Customizing Columns	1-9
Figure 10 Internet Protocol Properties Window	2-5
Figure 11 Login Page	2-6
Figure 12 Change User Password Page	2-7
Figure 13 Quick Configuration – Platform Setup Page	2-9
Figure 14 Quick Configuration– Platform Setup Summary Page	2-11
Figure 15 Local Networking Configuration Page – In-Band Management	2-12
Figure 16 Local Networking Configuration Page	2-13
Figure 17 Activation Key Configuration Page	2-16
Figure 18 Activation Key Overview Page	2-18
Figure 19 Time Services Page	2-23
Figure 20 Interface Manager Page	2-25
Figure 21 Interface Manager – Edit Page	2-26
Figure 22 Multiple Selection Operation Section (Interface Manager Page)	2-26
Figure 23 MPMC Symmetrical Scripts Page	2-27
Figure 24 MPMC Symmetrical Scripts Page – Configuration	2-28
Figure 25 Radio Parameters Page	2-32
Figure 26 1+0 Quick Configuration Wizard – Page 1	3-1
Figure 27 1+0 Quick Configuration Wizard – Page 2	3-2
Figure 28 1+0 Quick Configuration Wizard – Page 3	3-3
Figure 29 1+0 Quick Configuration Wizard – Page 4	3-4
Figure 30 1+0 Quick Configuration Wizard – Page 5	3-5
Figure 31 1+0 Quick Configuration Wizard – Page 5 (In Band Management = Yes)	3-5
Figure 32 1+0 Quick Configuration Wizard – Page 6 (Summary Page)	3-6
Figure 33 Local Networking Configuration Page	4-2
Figure 34 Remote Networking Configuration Page	4-3
Figure 35 SNMP Parameters Page	4-5
Figure 36 V3 Users Page	4-6
Figure 37 V3 Users - Add Page	4-7
Figure 38 Trap Managers Page	4-8
Figure 39 Trap Managers - Edit Page	4-9
Figure 40 FileZilla Server User Configuration	4-12
Figure 41 FileZilla Server Shared Folder Setup	4-13
Figure 42 FTP Port Page	4-14
Figure 43 Versions Page	4-15
Figure 44 Download & Install Page – HTTP/ HTTPS Download – No File Selected	4-17

Figure 45 Download & Install page – HTTP/ HTTPS Download – File Selected	4-18
Figure 46 Download & Install Page - FTP	4-18
Figure 47 FTP Parameters Page	4-20
Figure 48 Install parameters Page.....	4-23
Figure 49 Install parameters page- Software Management Timer.	4-23
Figure 50 Backup Files Page	4-25
Figure 51 Configuration Management Page	4-26
Figure 52 FTP Parameters Page	4-26
Figure 53: Chassis Configuration Page	4-31
Figure 54 Unit Parameters Page	4-33
Figure 55 NTP Configuration Page	4-35
Figure 56 Inventory Page	4-37
Figure 57 Login Banner Page.....	4-38
Figure 59 Radio Parameters Page	5-2
Figure 61 Remote Radio Parameters Page.....	5-4
Figure 74 Radio BER Thresholds Page	5-7
Figure 76 MPMC Status Page	5-7
Figure 77 MPMC PM Report Page	5-10
Figure 78 Counters Page	5-11
Figure 81 Signal Level PM Report Page.....	5-12
Figure 82 Signal Level Thresholds Configuration - Edit Page	5-13
Figure 83 Aggregate PM Report Page	5-14
Figure 84 MSE PM Report Page	5-16
Figure 85 Modem MSE Thresholds Configuration – Edit Page.....	5-17
Figure 93 Ethernet Services Page.....	6-3
Figure 94 Ethernet Services - Add page	6-5
Figure 95 Multiple Selection Operation Section (Ethernet Services)	6-7
Figure 96 Ethernet Service Points Page	6-9
Figure 97 Ethernet Service Points Page – Ingress Attributes	6-12
Figure 98 Ethernet Service Points Page – Egress Attributes	6-13
Figure 99 Ethernet Service Points - Add Page	6-16
Figure 100 Attached VLAN List Page	6-17
Figure 101 Attached VLAN List - Add Page.....	6-18
Figure 102 Ethernet General Configuration Page	6-20
Figure 103 Physical Interfaces Page	6-21
Figure 104 Physical Interfaces - Edit Page.....	6-22
Figure 105 Automatic State Propagation Page	6-25
Figure 106 Automatic State Propagation - Add Page.....	6-25
Figure 107 RMON Page	6-27
Figure 108 RMON Page – Hiding and Displaying Columns.....	6-27
Figure 109 Egress Cos Statistics Page.....	6-29
Figure 110 Egress CoS Statistics – Edit Page	6-29
Figure 111 Ethernet Port TX PM Report Page.....	6-30
Figure 112 Ethernet PM Port Admin Page	6-32
Figure 113 Ethernet Port Tx Threshold Page	6-33
Figure 114: Ethernet Port RX PM Report Page	6-34

Figure 115 Ethernet PM Port Admin Page	6-35
Figure 116 Ethernet Port Rx Threshold Page	6-35
Figure 117 QoS Block Diagram.....	7-2
Figure 118 Logical Interfaces Page.....	7-5
Figure 119 Logical Interfaces - Edit Page.....	7-6
Figure 120 802.1Q Classification Page	7-8
Figure 121 802.1Q Classification - Edit Page.....	7-8
Figure 122 802.1AD Classification Page	7-9
Figure 123 802.1Q Classification - Edit Page.....	7-9
Figure 124 DSCP Classification Page	7-10
Figure 125 DSCP Classification - Edit Page	7-10
Figure 126 MPLS Classification Page	7-11
Figure 127 MPLS Classification - Edit Page.....	7-12
Figure 131 Policer Profile Page	7-14
Figure 132 Policer Profile - Add Page.....	7-14
Figure 133 Logical Interfaces – Policers Page – Unicast Policer (Default)	7-16
Figure 134 Logical Interfaces – Policers Page – Multicast Policer	7-17
Figure 109: Logical Interfaces – Policers Page – Multicast Policer	7-18
Figure 110: Logical Interfaces – Policers Page – Unknown Multicast Policer	7-19
Figure 135 Logical Interfaces – Policers Page – Broadcast Policer	7-19
Figure 136 Logical Interfaces – Policers Page – Ethertype Policer	7-20
Figure 137 802.1Q Marking Page.....	7-23
Figure 138 802.1Q Marking - Edit Page.....	7-23
Figure 139 802.1AD Marking Page.....	7-24
Figure 140 802.1AD Marking - Edit Page.....	7-24
Figure 141 WRED Profile Page	7-26
Figure 142 WRED Profile - Add Page.....	7-26
Figure 143 Logical Interfaces – WRED Page	7-28
Figure 120: Logical Interfaces – WRED - Edit Page.....	7-28
Figure 145 Queue Shaper Profile Page	7-30
Figure 146 Queue Shaper Profile – Add Page	7-30
Figure 149 Logical Interfaces – Shaper – Egress Queue Shaper.....	7-32
Figure 150 Logical Interfaces – Egress Queue Shaper Configuration – Add Page	7-32
Figure 153 Scheduler Priority Profile Page.....	7-35
Figure 154 Scheduler Priority Profile – Add Page	7-36
Figure 155 Scheduler WFQ Profile Page	7-38
Figure 156 Scheduler WFQ Profile – Add Page	7-39
Figure 157 Logical Interfaces – Scheduler – Egress Port Scheduling Priority	7-40
Figure 158 Logical Interfaces – Scheduler – Egress Port Scheduling WFQ.....	7-41
Figure 159 Egress CoS PM Configuration Page	7-43
Figure 160 Egress CoS PM Configuration – Add Page	7-44
Figure 161 Egress CoS PM Page	7-45
Figure 182 Sync Source Page	8-2
Figure 183 Sync Source – Add Page	8-3
Figure 184 Outgoing Clock Page	8-7
Figure 185 Outgoing Clock – Edit Page	8-7

Figure 189 Access Control General Configuration Page.....	9-2
Figure 190 Access Control User Accounts - Edit Page.....	9-3
Figure 191 Access Control Password Management Page	9-4
Figure 192 Protocols Control Page.....	9-5
Figure 193 Access Control User Profiles Page.....	9-7
Figure 194 Access Control User Profiles - Add Page	9-8
Figure 195 Access Control User Accounts Page.....	9-9
Figure 196 Access Control User Accounts - Add Page.....	9-10
Figure 218 Security Certificate Request Page	9-13
Figure 219 FTP Parameters Page (Security Certificate Request).....	9-14
Figure 220 Security Certification Download and Install Page	9-14
Figure 221 FTP Parameters Page (Security Certification Download & Install)	9-15
Figure 222 Protocols Control Page.....	9-16
Figure 223 Security Log Upload Page.....	9-17
Figure 224 FTP Parameters Page (Security Log Upload)	9-18
Figure 225 Configuration Log Upload Page.....	9-19
Figure 226 Configuration Log Upload Page.....	9-20
Figure 227 Current Alarms Page	10-2
Figure 228 Current Alarms - View Page	10-2
Figure 229 Alarm Statistics Page.....	10-4
Figure 230 Event Log.....	10-5
Figure 231 Alarm Configuration Page	10-7
Figure 232 Alarm Configuration Page – Expanded.....	10-8
Figure 233 Alarm Configuration - Edit Page.....	10-9
Figure 234 Voltage Alarm Configuration Page.....	10-10
Figure 235 Voltage Alarm Configuration – Edit Page.....	10-11
Figure 236 Voltage PM Report Page	10-11
Figure 237 Unit Info Page.....	10-13
Figure 238 Radio Loopbacks Page.....	10-16
Figure 240 Logical Interfaces – Loopback Page.....	10-17
Figure 241 SOAM MD Page.....	10-19
Figure 242 SOAM MD Page.....	10-19
Figure 243 SOAM MA/MEG Page.....	10-20
Figure 244 SOAM MA/MEG – Add Page	10-21
Figure 245 MEP List Page.....	10-23
Figure 246 Add MEP Page.....	10-24
Figure 247 SOAM MEP Page	10-24
Figure 248 Add SOAM MEP Wizard – Page 1	10-25
Figure 249 Add SOAM MEP Wizard – Page 2	10-25
Figure 250 Add SOAM MEP Wizard –Summary Page.....	10-26
Figure 251 SOAM MEP - Edit Page	10-28
Figure 252 SOAM MEP DB Table.....	10-29
Figure 253 MEP Last Invalid CCMS Page	10-30
Figure 254 SOAM MEP Loopback Page	10-32
Figure 255 Restart HTTP Page.....	11-2
Figure 256 ifIndex Calculator Page	11-3

Figure 257 MIB Reference Table Page 11-4

Figure 258 PTP 850E Interfaces..... 20-3

Figure 187: RSL Pins 20-5

Figure 188: PoE Injector Connectors..... 20-8

List of Tables

Table 1 Web EMS Menu Hierarchy – Platform Menu	1-10
Table 2 Web EMS Menu Hierarchy – Faults Menu	1-11
Table 3 Web EMS Menu Hierarchy – Radio Menu	1-12
Table 4 Web EMS Menu Hierarchy – Ethernet Menu	1-12
Table 5 Web EMS Menu Hierarchy – Sync Menu	1-14
Table 6 Web EMS Menu Hierarchy – Quick Configuration Menu	1-15
Table 7 Web EMS Menu Hierarchy – Utilities Menu	1-15
Table 8 PTP 850 Web EMS Menu Hierarchy	2-16
Table 9 Activation Key-Enabled-Features Table Parameters	2-18
Table 10 Activation Key-Enabled-Features Description	2-19
Table 11 Time Services Parameters	2-24
Table 12 MRMC Symmetrical Scripts Page Parameters	2-29
Table 13 Available Radio Profiles – PTP 850E	2-30
Table 14 SNMP V3 Authentication Parameters	4-7
Table 15 Trap Manager Parameters	4-9
Table 16 Versions Page Columns	4-15
Table 17 Download & Install Status Parameters	4-22
Table 18 Backup Files Page Columns	4-25
Table 19 Unit Parameters	4-33
Table 20 NTP Status Parameters	4-35
Table 21 Radio Status Parameters	5-3
Table 22 Remote Radio Parameters	5-4
Table 23 MRMC Status Parameters	5-9
Table 24 MRMC PMs	5-10
Table 25 Signal Level PMs	5-12
Table 26 Signal Level Thresholds	5-14
Table 27 Modem BER (Aggregate) PMs	5-14
Table 28 Modem MSE PMs	5-16
Table 29 Ethernet Services Page Parameters	6-4
Table 30 General Service Point Attributes	6-9
Table 31 Attached Interface Types	6-11
Table 32 Service Point Ingress Attributes	6-12
Table 33 Service Point Egress Attributes	6-13
Table 34 VLAN Classification Parameters	6-18
Table 35 Physical Interface Status Parameters	6-23
Table 36 Ethernet TX Port PMs	6-30
Table 37 Ethernet RX Port PMs	6-34
Table 38 Logical Interface Classification Parameters	7-6
Table 39 Policer Profile Parameters	7-15
Table 40 Queue Shaper Profile Parameters	7-31
Table 56 Sync Source Parameters	8-3
Table 57 Alarm Information	10-3
Table 58 Event Log Information	10-5
Table 59 Alarm Configuration Page Parameters	10-7
Table 60 Voltage PMs	10-12
Table 61 SOAM MA/MEG Configuration Parameters	10-21

Table 62 SOAM MA/MEG Status Parameters.....	10-23
Table 63 SOAM MEP Parameters.....	10-26
Table 64 SOAM MEP DB Table Parameters.....	10-29
Table 66 IP Address (IPv4) CLI Parameters.....	12-7
Table 67 IP Address (IPv6) CLI Parameters.....	12-8
Table 68 Local Time Configuration CLI Parameters.....	12-11
Table 69: Daylight Savings Time CLI Parameters.....	12-12
Table 70 Interface Configuration CLI Parameters.....	12-13
Table 56: MRMC Script CLI Parameters.....	12-15
Table 57: MRMC Script Assignment to Radio Carrier CLI Parameters	12-16
Table 83 Remote Unit IP Address (IPv4) CLI Parameters	13-25
Table 84 Remote Unit IP Address (IPv6) CLI Parameters	13-26
Table 85 Basic SNMP CLI Parameters.....	13-27
Table 86 SNMPv3 CLI Parameters.....	13-28
Table 87 Trap Managers CLI Parameters	13-30
Table 88 Software Download CLI Parameters.....	13-34
Table 89 Configuration Management CLI Parameters	13-38
Table 90 Configuration Backup and Restore CLI Parameters.....	13-39
Table 91 Configuration Import and Restore CLI Parameters	13-40
Table 92 Unit Parameters CLI Parameters.....	13-45
Table 93 NTP CLI Parameters	13-46
Table 94 Remote Radio Mute/Unmute CLI Parameters.....	14-2
Table 95 Remote Radio TX Level CLI Parameters	14-3
Table 99 Aggregate PMs (CLI).....	14-5
Table 100 Excessive BER CLI Parameters.....	14-7
Table 101 RSL Thresholds CLI Parameters	14-7
Table 102 TSL Thresholds CLI Parameters.....	14-8
Table 103 RSL and TSL PMs (CLI)	14-9
Table 104 Signal Level Threshold CLI Parameters	14-10
Table 105 MSE CLI Parameters	14-10
Table 106 MSE PMs (CLI)	14-12
Table 109 ACM PMs (CLI).....	14-13
Table 110 Adding Ethernet Service CLI Parameters	15-3
Table 111 Entering Ethernet Service View CLI Parameters	15-4
Table 112 Displaying Ethernet Service Details CLI Parameters.....	15-5
Table 113 Ethernet Service Operational State CLI Parameters	15-6
Table 114 Ethernet Service CoS Mode CLI Parameters	15-6
Table 115 Ethernet Service EVC CLI Parameters.....	15-7
Table 116 Deleting Ethernet Service CLI Parameters.....	15-8
Table 117 Service Points per Service Type.....	15-8
Table 118 Service Point Types per Interface	15-9
Table 119 Legal Service Point – Interface Type Combinations per Interface – SAP and SNP	15-10
Table 120 Legal Service Point – Interface Type Combinations per Interface – Pipe and MNG	15-11
Table 121 Add Service Point CLI Parameters.....	15-13
Table 122 Enable/Disable Broadcast Frames CLI Parameters	15-16
Table 123 Service Point CoS Preservation CLI Parameters	15-17
Table 124 Service Point Enable/Disable Flooding CLI Parameters.....	15-18
Table 125 C-VLAN CoS Preservation Mode CLI Parameters.....	15-19

Table 126 C-VLAN Preservation CLI Parameters.....	15-19
Table 127 S-VLAN CoS Preservation CLI Parameters.....	15-21
Table 128 Service Bundle CLI Parameters.....	15-22
Table 129 VLAN Bundle to Service Point CLI Parameters.....	15-23
Table 130 Display Service Point Attributes CLI Parameters.....	15-23
Table 131 Delete Service Point Attributes CLI Parameters.....	15-24
Table 132 MAC Address Forwarding Table Maximum Size CLI Parameters.....	15-24
Table 133 MAC Address Forwarding Table Aging Time CLI Parameters.....	15-25
Table 134 Adding Static Address to MAC Address Forwarding Table CLI Parameters.....	15-25
Table 135 Enabling MAC Address Learning CLI Parameters.....	15-27
Table 136 Configure S-VLAN Ethertype CLI Parameters.....	15-28
Table 137 Configure MRU CLI Parameters.....	15-29
Table 138 Entering Interface View CLI Parameters.....	15-30
Table 139 Interface Media Type CLI Parameters.....	15-32
Table 140 Interface Speed and Duplex State CLI Parameters.....	15-32
Table 141 Interface Auto Negotiation State CLI Parameters.....	15-33
Table 142 Interface IFG CLI Parameters.....	15-34
Table 143 Interface Preamble CLI Parameters.....	15-34
Table 144 Interface Description CLI Parameters.....	15-34
Table 146: Automatic State Propagation to an Ethernet Port CLI Parameters.....	15-37
Table 147 RMON Statistics CLI Parameters.....	15-41
Table 148 Port PM Thresholds CLI Parameters.....	15-41
Table 149 Ethernet Port PMs.....	15-43
Table 150 VLAN Classification and Override CLI Parameters.....	16-3
Table 151 802.1p Trust Mode CLI Parameters.....	16-5
Table 156 Trust Mode for DSCP CLI Parameters.....	16-6
Table 157 DSCP Classification Table Default Values.....	16-6
Table 158 Modify DSCP Classification Table CLI Parameters.....	16-8
Table 159 Trust Mode for MPLS CLI Parameters.....	16-9
Table 160 MPLS EXP Bit Classification Table Default Values.....	16-9
Table 161 MPLS EXP Bit Classification Table Modification CLI Parameters.....	16-9
Table 123: 802.1p Trust Mode CLI Parameters.....	16-11
Table 124: C-VLAN 802.1 UP and CFI Bit Classification Table Default Values.....	16-12
Table 125: C-VLAN 802.1 UP and CFI Bit Classification Table CLI Parameters.....	16-12
Table 126: S-VLAN 802.1 UP and DEI Bit Classification Table Default Values.....	16-13
Table 127: S-VLAN 802.1 UP and DEI Bit Classification Table CLI Parameters.....	16-13
Table 162 Default CoS CLI Parameters.....	16-14
Table 163 Rate Meter Profile CLI Parameters.....	16-15
Table 164 Assigning Rate Meter for Unicast Traffic CLI Parameters.....	16-19
Table 131: Assigning Rate Meter for Unknown Unicast Traffic CLI Parameters.....	16-19
Table 165 Assigning Rate Meter for Multicast Traffic CLI Parameters.....	16-21
Table 133: Assigning Rate Meter for Multicast Traffic CLI Parameters.....	16-21
Table 166 Assigning Rate Meter for Broadcast Traffic CLI Parameters.....	16-23
Table 167 Assigning Rate Meter per Ethertype CLI Parameters.....	16-24
Table 168 Assigning Line Compensation Value for Rate Meter CLI Parameters.....	16-25
Table 170 Marking Mode on Service Point CLI Parameters.....	16-26
Table 171 Marking Table for C-VLAN UP Bits.....	16-28
Table 172 802.1q CoS and Color to UP and CFI Bit Mapping Table CLI Parameters.....	16-28

Table 173 802.1ad UP Marking Table (S-VLAN)	16-29
Table 174 802.1ad UP Marking Table (S-VLAN) CLI Parameters	16-30
Table 175 WRED Profile CLI Parameters	16-32
Table 176 Assigning WRED Profile to Queue CLI Parameters	16-33
Table 178 Attaching Shaper Profile to Queue CLI Parameters	16-36
Table 181 Egress Line Compensation for Shaping CLI Parameters	16-37
Table 182 Interface Priority Profile Example	16-38
Table 183 Interface Priority Profile CLI Parameters	16-40
Table 184 Interface Priority Sample Profile Parameters	16-41
Table 185 Attaching Priority Profile to Interface CLI Parameters	16-42
Table 186 WFQ Profile Example	16-43
Table 187 WFQ Profile CLI Parameters	16-44
Table 188 WFQ Sample Profile Parameters	16-44
Table 189 Attaching WFQ Profile to Interface CLI Parameters	16-45
Table 190 Egress Queue Level PMs CLI Parameters	16-47
Table 191 Egress Service Bundle Level PMs CLI Parameters	16-48
Table 198 Sync Source Ethernet CLI Parameters	17-5
Table 199 Sync Source Radio CLI Parameters	17-6
Table 200 Outgoing Clock CLI Parameters	17-8
Table 203 Inactivity Timeout Period CLI Parameters	18-2
Table 204 Blocking Upon Login Failure CLI Parameters	18-3
Table 205 Blocking Unused Accounts CLI Parameters	18-4
Table 206 Password Aging CLI Parameters	18-5
Table 207 Password Strength Enforcement CLI Parameters	18-6
Table 208 Force Password Change on First Time Login CLI Parameters	18-6
Table 209 User Profile CLI Parameters	18-9
Table 210 User Profile Access Protocols CLI Parameters	18-9
Table 211 User Accounts CLI Parameters	18-11
Table 214 CSR Generation and Upload CLI Parameters	18-13
Table 215 Certificate Download and Install CLI Parameters	18-15
Table 216 Security Log CLI Parameters	18-19
Table 217 Configuration Log CLI Parameters	18-21
Table 218 Editing Alarm Text and Severity CLI Parameters	19-4
Table 219 Restoring Alarms to Default CLI Parameters	19-5
Table 220 Uploading Unit Info CLI Parameters	19-9
Table 221 Radio Loopback CLI Parameters	19-13
Table 222 Ethernet Loopback CLI Parameters	19-14
Table 223 Maintenance Domain CLI Parameters	19-16
Table 224 SOAM MEG CLI Configuration Parameters	19-17
Table 225 MEP CLI Configuration Parameters	19-21
Table 226 MEP and Remote MEP Status Parameters (CLI)	19-23
Table 227 Loopback CLI Parameters	19-28
Table 228 CW Mode CLI Parameters	19-30
Table 181: PTP 850E MGT Interface - RJ-45/ Pinouts	20-4
Table 182: PoE Injector PoE Port - RJ-45 Pinouts	20-8
Table 183: PoE Injector RJ-45 Data Port Supporting 10/100/1000Base-T	20-9

About This User Guide

This document explains how to configure and operate a PTP 850E system. This document applies to software version 10.9

The PTP 850 system is a modular system with a wide variety of configuration options. Not all configurations are described in this manual.

This guide covers the following sections of PTP 850E:

- Introduction
- Web EMS configuration
- CLI Configuration
- Maintenance
- Appendices

This guide contains the following Chapters:

- [Chapter 1: Introduction](#)
- [Chapter 2: Getting Started](#)
- [Chapter 3: Configuration Guide](#)
- [Chapter 4: Unit Management](#)
- [Chapter 5: Radio Configuration](#)
- [Chapter 6: Ethernet Services and Interfaces](#)
- [Chapter 7: Quality of Service \(QoS\)](#)
- [Chapter 8: Synchronization](#)
- [Chapter 9: Access Management and Security](#)
- [Chapter 10: Alarm Management and Troubleshooting](#)
- [Chapter 11: Web EMS Utilities](#)
- [Chapter 12: Getting Started \(CLI\)](#)
- [Chapter 13: Unit Management \(CLI\)](#)
- [Chapter 14: Radio Configuration \(CLI\)](#)
- [Chapter 15: Ethernet Services and Interfaces \(CLI\)](#)
- [Chapter 16: Quality of Service \(QoS\) \(CLI\)](#)
- [Chapter 17: Synchronization \(CLI\)](#)
- [Chapter 18: Access Management and Security \(CLI\)](#)
- [Chapter 19: Alarm Management and Troubleshooting \(CLI\)](#)
- [Chapter 23: Maintenance](#)
- [Chapter 24: Alarms List](#)

Contacting Cambium Networks

Support website:	https://support.cambiumnetworks.com
Main website:	http://www.cambiumnetworks.com
Sales enquiries:	solutions@cambiumnetworks.com
Support enquiries:	https://support.cambiumnetworks.com
Repair enquiries	https://support.cambiumnetworks.com
Telephone number list:	http://www.cambiumnetworks.com/support/contact-support
Address:	Cambium Networks Limited, Unit B2, Linhay Business Park, Eastern Road Ashburton, United Kingdom, TQ13 7UP

Purpose

Cambium Networks Point-To-Point (PTP) documents are intended to instruct and assist personnel in the operation, installation and maintenance of the Cambium Networks PTP equipment and ancillary devices. It is recommended that all personnel engaged in such activities be properly trained.

Cambium Networks disclaims all liability whatsoever, implied or express, for any risk of damage, loss or reduction in system performance arising directly or indirectly out of the failure of the customer, or anyone acting on the customer's behalf, to abide by the instructions, system parameters, or recommendations made in this document.

Cross references

References to external publications are shown in italics. Other cross references, emphasized in blue text in electronic versions, are active links to the references.

This document is divided into numbered chapters that are divided into sections. Sections are not numbered, but are individually named at the top of each page, and are listed in the table of contents.

Feedback

We appreciate feedback from the users of our documents. This includes feedback on the structure, content, accuracy, or completeness of our documents. Send feedback to support@cambiumnetworks.com.

Problems and warranty

Reporting problems

If any problems are encountered when installing or operating this equipment, follow this procedure to investigate and report:

- 1 Search this document and the software release notes of supported releases.
- 2 Visit the support website.
- 3 Ask for assistance from the Cambium Networks product supplier.
- 4 Gather information from affected units, such as any available diagnostic downloads.
- 5 Escalate the problem by emailing or telephoning support.

Repair and service

If unit failure is suspected, obtain details of the Return Material Authorization (RMA) process from the support website.

Hardware warranty

Cambium Networks's standard hardware warranty is for one (1) year from date of shipment from Cambium Networks or a Cambium distributor. Cambium Networks warrants that hardware will conform to the relevant published specifications and will be free from material defects in material and workmanship under normal use and service. Cambium shall within this time, at its own option, either repair or replace the defective product within thirty (30) days of receipt of the defective product. Repaired or replaced product will be subject to the original warranty period but not less than thirty (30) days.

To register PTP products or activate warranties, visit the support website. For warranty assistance, contact the reseller or distributor.

**Caution**

Using non-Cambium parts for repair could damage the equipment or void warranty. Contact Cambium for service and repair instructions.

Portions of Cambium equipment may be damaged from exposure to electrostatic discharge. Use precautions to prevent damage.

Security advice

Cambium Networks systems and equipment provide security parameters that can be configured by the operator based on their particular operating environment. Cambium recommends setting and using these parameters following industry recognized security practices. Security aspects to be considered are protecting the confidentiality, integrity, and availability of information and assets. Assets include the ability to communicate, information about the nature of the communications, and information about the parties involved.

In certain instances Cambium makes specific recommendations regarding security practices, however the implementation of these recommendations and final responsibility for the security of the system lies with the operator of the system.

Warnings, cautions, and notes

The following describes how warnings and cautions are used in this document and in all documents of the Cambium Networks document set.

Warnings

Warnings precede instructions that contain potentially hazardous situations. Warnings are used to alert the reader to possible hazards that could cause loss of life or physical injury. A warning has the following format:

**Warning**

Warning text and consequence for not following the instructions in the warning.

Cautions

Cautions precede instructions and are used when there is a possibility of damage to systems, software, or individual items of equipment within a system. However, this damage presents no danger to personnel. A caution has the following format:

**Caution**

Caution text and consequence for not following the instructions in the caution.

Notes

A note means that there is a possibility of an undesirable situation or provides additional information to help the reader understand a topic or concept. A note has the following format:

**Note**

Note text.

Caring for the environment

The following information describes national or regional requirements for the disposal of Cambium Networks supplied equipment and for the approved disposal of surplus packaging.

In EU countries

The following information is provided to enable regulatory compliance with the European Union (EU) directives identified and any amendments made to these directives when using Cambium equipment in EU countries.



Disposal of Cambium equipment

European Union (EU) Directive 2002/96/EC Waste Electrical and Electronic Equipment (WEEE)

Do not dispose of Cambium equipment in landfill sites. For disposal instructions, refer to <http://www.cambiumnetworks.com/support>

Disposal of surplus packaging

Do not dispose of surplus packaging in landfill sites. In the EU, it is the individual recipient's responsibility to ensure that packaging materials are collected and recycled according to the requirements of EU environmental law.

In non-EU countries

In non-EU countries, dispose of Cambium equipment and all surplus packaging in accordance with national and regional regulations.

Chapter 1: Introduction

This section includes:

- [System Overview](#)
- [Configuration tips](#)
- [The Web-Based Element Management System](#)
- [Reference Guide to Web EMS Menu Structure](#)

This user manual provides instructions for configuring and operating the following systems:

- [Configuration Tips](#)
- [PTP 850E](#)

Each of these systems can be used with a PoE ([PoE Injector Overview](#)).

Wherever applicable, the manual notes the specific distinctions between these products. The manual also notes when specific features are only applicable to certain products and not others.

System Overview

Configuration Tips

This section describes common issues and how to avoid them.

Ethernet Port configuration

- The Ethernet ports of a PTP 850E are not enabled by default in a new unit. You must manually enable the Ethernet port or ports in order for the unit to process Ethernet traffic. See [Enabling the Interfaces \(Interface Manager\)](#)
- For RJ-45 ports, it is recommended to enable Auto-Negotiation for both the local port and its peer in order to obtain optimal performance.
- For SFP ports, it is recommended to disable Auto-Negotiation.
- For instructions, see [Configuring Ethernet Interfaces](#).

SyncE Interface Configuration

- When configuring a Sync source or outgoing clock on an Ethernet interface, the Media Type of the interface must be RJ-45 or SFP, not Auto-Type. See [Synchronization](#).

In-Band Management

- In order to use in-band management with an external switch, it must be supported on the external switch.
- When configuring in-band management, be sure to tag the management traffic to avoid overflow of the CPU.
- For instructions on configuring in-band management on the PTP 850E, see [Configuring in-Band Management](#).

Link Aggregation

- If you are configuring LAG with an external switch, the switch must support LAG. For instructions on configuring LAG, see [Configuring Link Aggregation \(LAG\) and LACP](#).

Software Upgrade

- When upgrading software via HTTP, make sure the software package is *not* unzipped. For instructions, see [Upgrading the Software](#).

Configuration Management and Backup Restoration

- Configuration files can only be copied to the same PTP 850 hardware type with the same part number as the unit from which they were originally saved. For example, a PTP 850E configuration file can only be restored to a PTP 850E with the same part number as the unit from which it was saved.

PTP 850E

PTP 850E is a versatile high capacity backhaul Ethernet system which operates in the E-band (71-76 GHz, 81-86 GHz). Its light weight and small footprint make it versatile for many different applications. Thanks to its small footprint, low power consumption, and simple installation, PTP 850E can be installed in many different types of remote outdoor locations.


PTP 850E operates over 250, 500, 1000 and 2000 MHz channels to deliver up to 20 Gbps of Ethernet throughput in several system configurations.

For a full description of the PTP 850E, including supported features and specifications, refer to the *Technical Description for PTP 850E*.

PoE Injector Overview

The PoE injector box is designed to offer a single cable solution for connecting both data and the DC power supply to the PTP 850E. To do so, the PoE injector combines 48VDC input and GbE signals via a standard CAT5E cable using a proprietary design.

The PoE injector can be ordered with a DC feed protection and with +24VDC support, as well as EMC surge protection for both indoor and outdoor installation options. It can be mounted on poles, walls, or inside racks.



Two models of the PoE Injector are available:

- **N000082L022A** **PTP 820 PoE Injector all outdoor, redundant DC input, +24VDC support**
- **N000082L164A** **PTP 820C INDOOR AC POE INJECTOR, 90W**

The Web-Based Element Management System

This section includes:

- [Introduction to the Web EMS](#)
- [Web EMS Page Layout](#)
- [Unit Summary Page](#)
- [Radio Summary Page](#)

Introduction to the Web EMS

The Element Management System (Web EMS) is an HTTP web-based element manager that enables the operator to perform configuration operations and obtain statistical and performance information related to the system, including:

- **Configuration Management** – Enables you to view and define configuration data.
- **Fault Monitoring** – Enables you to view active alarms.
- **Performance Monitoring** – Enables you to view and clear performance monitoring values and counters.
- **Diagnostics and Maintenance** – Enables you to define and perform loop back tests and software updates.
- **Security Configuration** – Enables you to configure security features.

- **User Management** – Enables you to define users and user groups.

The Web EMS opens to a page that summarizes the key unit parameters. The next page, when scrolling down the Web EMS main menu, summarizes the key radio parameters. See [Unit Summary Page](#) and [Radio Summary Page](#).

A Web-Based EMS connection to the unit can be opened using a Web browser (Internet Explorer, Mozilla Firefox, or Google Chrome). The Web-Based EMS uses a graphical interface.

The Web-Based EMS shows the actual unit configuration and provides easy access to any interface. A wide range of configuration, testing, and system monitoring tasks can be performed through the Web EMS.



Note

The alarms and system configuration details shown in this manual do not necessarily represent actual parameters and values on a fully operating PTP 850E system. Some of the pages and tasks described in this Manual may not be available to all users, based on the actual system configuration, activation key, and other details.

Web EMS Page Layout

Each Web EMS page includes the following sections:




- The left section of the page displays the Web EMS menu tree:
 - Click  to display the sub-options under a menu item.
 - Click  to hide the sub-options under a menu item.
- The main section of the page provides the page's basic functionality.

Figure 1 Main Web EMS Page



Optionally, you can display a representation of the PTP 850 front panel by clicking either the arrow in the center or the arrow at the right of the bottom toolbar.

Figure 2 Displaying a Representation of the Front Panel






Figure 3 Main Web EMS Page with Representation of Front Panel



Related Pages Drop-Down List

Certain pages include a **Related Pages** drop-down list on the upper right of the main section of the page. You can navigate to a page related to the current page by selecting the page from this list.

Figure 4 Related Pages Drop-Down List



Export to CSV Option

Certain pages include an **Export to CSV** button on the lower right of the main section of the page. Click **Export to CSV** to save the data on the page to a .csv file.





Figure 5 Related Pages Drop-Down List

Unit Summary Page

The Unit Summary page is the first page that appears when you log into the Web EMS. It gathers the unit parameters, current alarms and unit inventory information on a single page for quick viewing.

Figure 6 Unit Summary Page




The Unit Summary page includes:

- **Unit Parameters** – Basic unit parameters such as the current software version, unit temperature, and voltage input level. For additional information, see [Configuring Unit Parameters](#).
- **Current Alarms** – All alarms currently raised on the unit. For additional information, see [Viewing Current Alarms](#).

The Unit Summary page can be customized to include only specific columns and tables. This enables you to hide information you do not need in order to focus on the information that is most relevant.

To hide a specific section of the Unit Summary page, click the section title. To display a section that has been hidden, click the section title again.


To customize which columns appear in a section, click ▼ next to the section title. A list of columns is displayed. Select only the columns you want to display and click ▼ again.



Note

When one or more columns are hidden, the ▼ icon turns white (▼).

Figure 7 Unit Summary Page – Customizing Columns



Radio Summary Page

The Radio Summary page gathers the key link and radio parameters on a single page for quick viewing. To display the Radio Summary page, select **Radio Summary** from the Web EMS main menu.

Figure 8 Radio Summary Page

Microwave radio: Radio Summary					
▼ Filter					
▼ Link Status					
Radio location	Link Id	Status	LAG	AMCC	
Radio: Slot 1, Port 1	1	Down			
▼ Radio Information					
Radio Location ▲	TX Frequency (MHz)	RX Frequency (MHz)	Frequency Separation (MHz)	Channel Bandwidth (MHz)	
Radio: Slot 1, Port 1	83500.000	73500.000	10000.000	250	
▼ Radio Transmitter					
Radio Location ▲	TX Mute Status	Maximum TX Level (dBm)	Operational TX Level (dBm)	TX QAM	TX bit-rate (Mbps)
Radio: Slot 1, Port 1		16	-20	2	0
▼ Radio Receiver					
Radio Location ▲	Defective Blocks	Modem MSE (dB)	RX Level (dBm)	RX QAM	RX bit-rate (Mbps)
Radio: Slot 1, Port 1	0	-99.00	-72	2	47.535

The Radio Summary page includes:

- **Link Status** – Link status per radio carrier, including whether or not the link is Up, groups to which the link is assigned (such as LAG, XPIC, protection, and/or Multi-Carrier ABC), and the IP address (both IPv4 and IPv6) of the remote carrier. For additional information, see [Configuring the Radio Parameters](#).
- **Radio Information** – The TX and RX frequencies, frequency separation, and channel bandwidth on which the link is operating. For additional information, see [Configuring the Radio Parameters](#).
- **Remote Radio Parameters** – Key information about the status of the remote carrier. For additional information, see [Configuring the Remote Radio Parameters](#).
- **Radio Transmitter** – Mute status, maximum and operational TX level, modulation, and bit rate. For additional information, see [Configuring the Radio Parameters](#).
- **Radio Receiver** – Receiver PMs and statistics, including defective blocks, modem MSE, and RX level, modulation, and bit rate. For additional information, see [Configuring the Radio Parameters](#) and [Configuring the Radio \(MRMC\) Script\(s\)](#).

The Radio Summary page can be customized to include only specific columns and tables. This enables you to hide information you do not need in order to focus on the information that is most relevant.

To hide a specific section of the Radio Summary page, click the section title. To display a section that has been hidden, click the section title again.

To customize which columns appear in a section, click ▼ next to the section title. A list of columns is displayed. Select only the columns you want to display and click ▼ again.



Note

When one or more columns are hidden, the ▼ icon turns white (▼).

Figure 9 Radio Summary Page- Customizing Columns

▼ Radio Information		
<input checked="" type="checkbox"/>	All columns	RX Frequency (MHz)
		12800.000
<input checked="" type="checkbox"/>	Radio Location	12800.000
<input checked="" type="checkbox"/>	TX Frequency (MHz)	
<input checked="" type="checkbox"/>	RX Frequency (MHz)	Local-Remote Channel
<input checked="" type="checkbox"/>	Frequency Separation (MHz)	Up
		Up
<input checked="" type="checkbox"/>	Channel Bandwidth (MHz)	
		Maximum TX Level (dBm)

Reference Guide to Web EMS Menu Structure

The following table shows the Web EMS menu hierarchy, with links to the sections in this document that provide instructions for the relevant menu item.



Note

Some menu items are only available if the relevant activation key or feature is enabled.

Table 1 Web EMS Menu Hierarchy – Platform Menu

Sub-Menus	For Further Information
Shelf Management > Chassis Configuration	<i>Performing a Hard (Cold) Reset</i> <i>Setting the Unit to the Factory Default Configuration</i>
Interfaces > Interface Manager	<i>Enabling the Interfaces (Interface Manager)</i>
Interfaces > SFP	<i>Planned for future release.</i>
Management > Unit Parameters	<i>Configuring Unit Parameters</i>
Management > NTP Configuration	<i>Configuring NTP</i>
Management > Time Services	<i>Setting the Time and Date (Optional)</i>
Management > Inventory	<i>Displaying Unit Inventory</i>
Management > Unit Info	<i>Uploading Unit Info</i>
Management > Login Banner	<i>Defining a Login Banner</i>
Management > Networking > Local	<i>Configuring In-Band Management</i> <i>Changing the Management IP Address</i> <i>Defining the IP Protocol Version for Initiating Communications</i>
Management > Networking > Remote	<i>Configuring the Remote Unit's IP Address</i>
Management > SNMP > SNMP Parameters	<i>Configuring SNMP</i>
Management > SNMP > Trap Managers	<i>Configuring Trap Managers</i>
Management > SNMP > V3 Users	<i>Configuring SNMP</i>
Software > Versions	<i>Viewing Current Software Versions</i>
Software > Download & Install	<i>Downloading and Installing Software</i> <i>Configuring a Timed Installation</i>
Configuration > Timer Parameters	<i>Planned for future release.</i>
Configuration > Backup Files	<i>Viewing Current Backup Files</i>
Configuration > Configuration Management	<i>Backing Up and Restoring Configurations</i>
Activation Key > Activation Key Configuration	<i>Configuring the Activation Key</i>

Sub-Menus	For Further Information
Activation Key > Activation Key Overview	<i>Displaying a List of Activation-Key-Enabled Features</i>
Security > General > Configuration	<i>Planned for future release.</i>
Security > General > Security Log Upload	<i>Uploading the Security Log</i>
Security > General > Configuration Log Upload	<i>Uploading the Configuration Log</i>
Security > X.509 Certificate > CSR	<i>Configuring X.509 CSR Certificates and HTTPS</i>
Security > X.509 Certificate > Download & Install	<i>Configuring X.509 CSR Certificates and HTTPS</i>
Security > Access Control > General	<i>Configuring the General Access Control Parameters</i>
Security > Access Control > User Profiles	<i>Configuring User Profiles</i>
Security > Access Control > User Accounts	<i>Configuring Users</i>
Security > Access Control > Password Management	<i>Configuring the Password Security Parameters</i>
Security > Access Control > Change Password	<i>Changing Your Password</i>
Security > Access Control > Radius > Radius Configuration	<i>Planned for future release.</i>
Security > Access Control > Radius > Radius Users	<i>Planned for future release.</i>
Security > Protocols Control	<i>Configuring the Session Timeout Blocking Telnet Access</i>
PM & Statistics > SFP	<i>Planned for future release.</i>
PM & Statistics > Voltage	<i>Configuring Voltage Alarm Thresholds and Displaying Voltage PMs</i>

Table 2 Web EMS Menu Hierarchy – Faults Menu

Sub-Menus	For Further Information
Current alarms	<i>Viewing Current Alarms</i>
Alarm Statistics	<i>Viewing Alarm Statistics</i>
Event Log	<i>Viewing and Saving the Event Log</i>
Alarm Configuration	<i>Editing Alarm Text and Severity and Disabling Alarms and Events</i>
Voltage Alarm Configuration	<i>Configuring Voltage Alarm Thresholds</i>

Table 3 Web EMS Menu Hierarchy – Radio Menu

Sub-Menus	For Further Information
Radio Parameters	<i>Configuring the Radio Parameters</i>
Remote Radio Parameters	<i>Configuring the Remote Radio Parameters</i>
Radio BER Thresholds	<i>Configuring BER Thresholds and Displaying Current BER</i>
Ethernet Interface > Configuration	<i>Planned for future release.</i>
Ethernet Interface > Counters	<i>Planned for future release.</i>
MRMC > Symmetrical Scripts > ETSI	<i>Configuring the Radio (MRMC) Script(s)</i>
MRMC > Symmetrical Scripts > FCC	<i>Configuring the Radio (MRMC) Script(s)</i>
MRMC > MRMC Status	<i>Displaying MRMC Status</i>
PM & Statistics > Counters	<i>Displaying and Clearing Defective Block Counters</i>
PM & Statistics > Signal Level	<i>Displaying Signal Level PMs</i>
PM & Statistics > Aggregate	<i>Displaying Modem BER (Aggregate) PMs</i>
PM & Statistics > MSE	<i>Displaying MSE PMs</i>
PM & Statistics > MRMC	<i>Displaying MRMC PMs</i>
PM & Statistics > Traffic > Capacity/Throughput	<i>Planned for future release.</i>
PM & Statistics > Traffic > Utilization	<i>Planned for future release.</i>
PM & Statistics > Traffic > Frame error rate	<i>Planned for future release.</i>
Diagnostics > Loopback	<i>Performing Radio Loopback</i>

Table 4 Web EMS Menu Hierarchy – Ethernet Menu

Sub-Menus	For Further Information
General Configuration	<i>Setting the MRU Size and the S-VLAN Ethertype</i>
Services	<i>Configuring Ethernet Service(s)</i>
Interfaces > Physical Interfaces	<i>Configuring Ethernet Interfaces</i>
Interfaces > Logical Interfaces	<i>Configuring Ingress Path Classification on a Logical Interface</i> <i>Assigning Policers to Interfaces</i> <i>Configuring the Ingress and Egress Byte Compensation</i> <i>Assigning WRED Profiles to Queues</i> <i>Assigning a Queue Shaper Profile to a Queue</i> <i>Assigning a Priority Profile to an Interface</i> <i>Assigning a WFQ Profile to an Interface</i> <i>Performing Ethernet Loopback</i>
Interfaces > ASP & LLF	<i>Configuring Automatic State Propagation and Link Loss Forwarding</i>

Sub-Menus	For Further Information
PM & Statistics > RMON	<i>RMON Statistics</i>
PM & Statistics > Port TX	<i>Port TX Statistics</i>
PM & Statistics > Port RX	<i>Port RX Statistics</i>
PM & Statistics > Egress CoS Statistics	<i>Egress CoS Statistics</i>
PM & Statistics > Egress CoS PM > Configuration	<i>Configuring and Displaying Queue-Level PMs</i>
PM & Statistics > Egress CoS PM > Egress CoS PM	<i>Configuring and Displaying Queue-Level PMs</i>
QoS > Classification > 802.1Q	<i>Modifying the C-VLAN 802.1Q UP and CFI Bit Classification Table</i>
QoS > Classification > 802.1AD	<i>Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table</i>
QoS > Classification > DSCP	<i>Modifying the DSCP Classification Table</i>
QoS > Classification > MPLS	<i>Modifying the MPLS EXP Bit Classification Table</i>
QoS > Policer > Policer Profile	<i>Configuring Policer Profiles</i>
QoS > Marking > 802.1Q	<i>Modifying the 802.1Q Marking Table</i>
QoS > Marking > 802.1AD	<i>Modifying the 802.1AD Marking Table</i>
QoS > WRED > WRED Profile	<i>Configuring WRED</i>
QoS > Shaper > Queue Profiles	<i>Configuring Queue Shaper Profiles</i>
QoS > Scheduler > Priority Profiles	<i>Configuring Priority Profiles</i>
QoS > Scheduler > WFQ Profiles	<i>Configuring WFQ Profiles</i>
Protocols > Bandwidth Notification	<i>Planned for future release.</i>
Protocols > LLDP > Remote Management	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Configuration > Parameters	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Configuration > Port Configuration	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Configuration > Destination Address	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Configuration > Management TLV	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Remote System > Management	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Remote System > Remote Table	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Local System > Parameters	<i>Planned for future release.</i>

Sub-Menus	For Further Information
Protocols > LLDP > Advanced > Local System > Port	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Local System > Management	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Statistic > General	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Statistic > Port TX	<i>Planned for future release.</i>
Protocols > LLDP > Advanced > Statistic > Port RX	<i>Planned for future release.</i>
Protocols > SOAM > MD	<i>Configuring Service OAM (SOAM) Fault Management (FM)</i>
Protocols > SOAM > MA/MEG	<i>Configuring Service OAM (SOAM) Fault Management (FM)</i>
Protocols > SOAM > MEP	<i>Configuring Service OAM (SOAM) Fault Management (FM)</i>
Protocols > LACP > Aggregation	<i>Planned for future release.</i>
Protocols > LACP > Port > Status	<i>Planned for future release.</i>
Protocols > LACP > Port > Statistics	<i>Planned for future release.</i>
Protocols > LACP > Port > Debug	<i>Planned for future release.</i>
Interfaces > Groups > LAG	<i>Planned for future release.</i>

Table 5 Web EMS Menu Hierarchy – Sync Menu

Sub-Menus	For Further Information
SyncE Regenerator	<i>Planned for future release.</i>
Sync Source	<i>Configuring the Sync Source</i>
Outgoing Clock	<i>Configuring the Outgoing Clock and SSM Messages</i>
1588 > General Configuration	<i>Planned for future release.</i>
1588 > Transparent Clock	<i>Planned for future release.</i>
1588 > Boundary Clock > Clock Parameters > Default	<i>Planned for future release.</i>
1588 > Boundary Clock > Clock Parameters > Advanced	<i>Planned for future release.</i>
1588 > Boundary Clock > Port Parameters	<i>Planned for future release.</i>
1588 > Boundary Clock > Port Statistics	<i>Planned for future release.</i>

Table 6 Web EMS Menu Hierarchy – Quick Configuration Menu

Sub-Menus	For Further Information
From CeraPlan	<i>Planned for future release.</i>
Platform Setup	<i>Performing Quick Platform Setup</i>
PIPE > Single Carrier	<i>Configuring a 1+0 Link Using the Quick Configuration Wizard</i>

Table 7 Web EMS Menu Hierarchy – Utilities Menu

Sub-Menus	For Further Information
Restart HTTP	<i>Restarting the HTTP Server</i>
ifIndex Calculator	<i>Calculating an ifIndex</i>
MIB Reference Guide	<i>Displaying, Searching, and Saving a list of MIB Entities</i>

Chapter 2: Getting Started

This section includes:

- [Assigning IP Addresses in the Network](#)
- [Establishing a Connection](#)
- [Logging on](#)
- [Changing Your Password](#)
- [Performing Quick Platform Setup](#)
- [Configuring In-Band Management](#)
- [Changing the Management IP Address](#)
- [Configuring the Activation Key](#)
- [Setting the Time and Date \(Optional\)](#)
- [Enabling the Interfaces \(Interface Manager\)](#)
- [Configuring the Radio \(MRMC\) Script\(s\)](#)
- [Radio Parameters](#)

Assigning IP Addresses in the Network

Before connection over the radio hop is established, it is of high importance that you assign the PTP 850E unit a dedicated IP address, according to an IP plan for the total network. See [Changing the Management IP Address](#).

By default, a new PTP 850E unit has the following IP settings:

- IP address: 192.168.1.1
- Subnet mask: 255.255.255.0

**Caution**

If the connection over the link is established with identical IP addresses, an IP address conflict will occur and remote connection may be lost.

Establishing a Connection

Connect the PTP 850E unit to a PC by means of a Twisted Pair cable. The cable is connected to the MGT port on the PTP 850E and to the LAN port on the PC. Refer to the Installation Guide for the type of unit you are connecting for cable connection instructions.


PC Setup

To obtain contact between the PC and the PTP 850E unit, it is necessary to configure an IP address on the PC within the same subnet as the PTP 850E unit. The default PTP 850E IP address is 192.168.1.1. Set the PC address to e.g. 192.168.1.10 and subnet mask to 255.255.255.0. Note the initial settings before changing.

**Note**

The PTP 850E IP address, as well as the password, should be changed before operating the system. See [Changing the Management IP Address](#) and [Changing Your Password](#).

1. Select **Control Panel > All Control Panel Items > Network and Sharing Center**.
2. Click **Change the adapter settings**.
3. Select **Local Area Connection > Properties > Internet Protocol Version 4 (TCP/IP)**, and set the following parameters:
 - IP address: 192.168.1.10
 - Subnet mask 255.255.255.0
 - No default gateway
4. Click **OK** to apply the settings.

Figure 10 Internet Protocol Properties Window

Logging on

1. Open an Internet browser (Internet Explorer or Mozilla Firefox).
2. Enter the default IP address “192.168.1.1” in the Address Bar. The Login page opens.

Figure 11 Login Page



The screenshot shows a web browser window with a title bar that says "Login". Inside the window, there are two text input fields. The first field is labeled "User Name" and the second field is labeled "Password". Below these fields are two buttons: "Apply" and "Clear".

3. In the Login window, enter the following:
 - User Name: **admin**
 - Password: **admin**
4. Click **Apply**.

Changing Your Password

It is recommended to change your default Admin password as soon as you have logged into the system.

In addition to the Admin password, there is an additional password protected user account, “root user”, which is configured in the system. The root user password and instructions for changing this password are available from Cambium Networks Customer Support. It is strongly recommended to change this password.

To change your password:

1. Select **Platform > Security > Access Control > Change Password**. The Change User Password page opens.

Figure 12 Change User Password Page

The screenshot shows the 'Microwave radio: Change User Password' page. On the left is a navigation tree with the following structure: Logout, Connection, Admin, Filter, Unit Summary, Radio Summary, Platform (expanded), Shelf Management, Interfaces, Management, Software, Configuration, Activation Key, Security (expanded), General, X.509 Certificate, Access Control (expanded), General (selected), User Profiles, User Accounts, Password Management, Change Password (selected), RADIUS, Protocols Control, PM & Statistics, Faults, Radio, Ethernet, Sync, Quick Configuration, and Utilities. The main content area is titled 'Change your password' and contains four input fields: 'User Name' (pre-filled with 'admin'), 'Old password', 'New Password', and 'Reenter Password'. Below these fields are 'Apply' and 'Clear' buttons.

2. In the **Old password** field, enter the current password. For example, upon initial login, enter the default password (**admin**).
3. In the **New password** field, enter a new password. If **Enforce Password Strength** is activated (see [Configuring the Password Security Parameters](#)), the password must meet the following criteria:
 - Password length must be at least eight characters.
 - Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
 - A password cannot be repeated within five changes of the password.
4. Click **Apply**.

In addition to the Admin password, there is an additional password protected user account, “root user”, which is configured in the system. The root user password and instructions for changing this password are available from Cambium Networks Customer Support. It is strongly recommended to change this password.

Performing Quick Platform Setup

The Platform Setup page in the Web EMS centralizes the main configurable items from several Web EMS pages in a single location:

- Unit Parameters (Name, Contact Person, Location, Longitude, and Latitude)
- IPv4 Address, Subnet Mask, and Default Gateway
- NTP Enable/Disable
- Demo Activation Key Enable/Disable
- SNMP Parameters

These items enable you to configure the basic platform parameters quickly, in a single Web EMS page. Combined with the quick link configuration wizards, this enables you to configure a new link in the field quickly and efficiently, to the point where the link is up and functioning and any necessary advanced configurations can be performed remotely without the need to physically access the PTP 850E unit.

To use the Platform Setup page:

1. Select **Quick Configuration > Platform Setup**. The Quick Configuration – Platform Setup page opens.

Figure 13 Quick Configuration – Platform Setup Page

1. The Unit Parameters section is optional. For details on each field, see [Configuring Unit Parameters](#).

2. In the IPv4 Address section, configure the unit's management IP address, subnet mask, and, optionally, a default gateway. If you want to use an IPv6 address, see [Changing the Management IP Address](#).
3. In the Date & Time section, you can enable Network Time Protocol (NTP). NTP distributes Coordinated Universal Time (UTC) throughout the system, using a jitter buffer to neutralize the effects of variable latency. If you select **Enable**, the **NTP version** and **NTP server IP address** fields are also displayed, enabling you to configure the NTP parameters. For details on these fields, see [Configuring NTP](#).

Date & Time

NTP Admin Enable ▼

NTP version NTPv4 ▼

NTP server IP address 0.0.0.0

4. In the Activation Key section, you can enable or disable Demo mode in the **Demo admin** field. Demo mode enables all features for 60 days. When demo mode expires, the most recent valid activation key goes into effect. The 60-day period is only counted when the system is powered up. 10 days before demo mode expires, an alarm is raised indicating that demo mode is about to expire. If you set **Demo admin** to **Disable**, the Activation Key field is displayed. Enter a valid activation key in this field. For a full explanation of activation keys, see [Configuring the Activation Key](#).

Activation Key

Demo admin Disable ▼

Activation Key 0758D2L0108T43BL1I7RJJNSP38BM4ASD1PIRD8735IRSG7M5N38MGP
NNJFL9T801UVOT17B7SPOJ0FFLL8VKH8E08IHI3ASD1PIRD8735IRSG
7M5N38MGPNNJFL9T801UVO

<< Back Finish

5. In the SNMP Parameters section, you can set whether to enable or disable SNMP monitoring in the Admin field, and set the SNMP Read Community and SNMP Write Community. For a full explanation of SNMP parameters, see [Configuring SNMP](#).

SNMP Parameters

Admin Enable ▼

SNMP Read Community public

SNMP Write Community private

SNMP Trap Version V1 ▼

V1V2 Blocked No ▼

- Click **Finish**. The Selection Summary page opens. To go back and change any of the parameters, click **Back**. To implement the new parameters, click **Submit**.

Figure 14 Quick Configuration— Platform Setup Summary Page

Logout ✓ Connection Admin

▼ Filter

[Unit & Radio Summary](#)

- ▶ Platform
- ▶ Faults
- ▶ Radio
- ▶ Ethernet
- ▶ Sync
- ▲ Quick Configuration
 - [From File](#)
 - [Platform Setup](#)**
 - ▶ PIPE
 - ▶ Utilities

IP-20N #1: Quick Configuration - Platform

Selection Summary

Name: Test Unit

Contact person: John Smith

Location:

Longitude:

Latitude:

IPv4 Address: 192.168.1.85

IPv4 Subnet Mask: 255.255.255.0

IPv4 Default Gateway: 0.0.0.0

NTP Admin: Enable

NTP version: NTPv4

NTP server IP address: 0.0.0.0

Demo admin: Enable

Admin: Enable

SNMP Read Community: public

SNMP Write Community: private

<< Back Next >> Submit

Configuring In-Band Management

You can configure in-band management in order to manage the unit remotely via its radio and/or Ethernet interfaces.



Note

Before configuring in-band management, it is recommended to review the configuration recommendations for in-band management listed in [Configuration Tips](#).

Each PTP 850E unit includes a pre-defined management service with Service ID 1025. The management service is a multipoint service that connects the two local management ports and the network element host CPU in a single service. In order to enable in-band management, you must add at least one service point to the management service, in the direction of the remote site or sites from which you want to access the unit for management.



Note

In order to use in-band management, it must be supported on the external switch.

For instructions on adding service points, see [Configuring Service Points](#).

After adding service points, you must enable in-band management. To enable in-band management:

1. Select **Platform > Management > Networking > Local**. The Local Networking Configuration page opens.

Figure 15 Local Networking Configuration Page – In-Band Management

The screenshot shows the 'Local Networking Configuration' page. On the left is a navigation tree with 'Local' selected under 'Networking'. The main content area is titled 'Microwave radio: Local Networking Configuration'. It contains three sections: 'In-Band Configuration' with a dropdown set to 'Enable' and an 'Apply' button; 'IP Family Configuration' with a dropdown set to 'IPv4' and an 'Apply' button; and 'IP Configuration' with fields for Name (eth0), Description, IPv4 Address (192.168.1.1), IPv4 Subnet Mask (255.255.255.0), IPv4 Default Gateway (0.0.0.0), IPv6 Address (fec0::c0:a8:1:1), IPv6 Prefix Length (120), and IPv6 Default Gateway (::). An 'Apply' button is at the bottom of the IP Configuration section.

2. In the **In-Band Admin** field, select **Enable**.
3. Click **Apply** underneath the **In-Band Admin** field.

Changing the Management IP Address

Related Topics:

- [Configuring In-Band Management](#)
- [Defining the IP Protocol Version for Initiating Communications](#)
- [Configuring the Remote Unit's IP Address](#)

To change the management IP address of the local unit:

1. Select **Platform > Management > Networking > Local**. The Local Networking Configuration page opens. IP address configuration is performed in the IP Configuration area of the page.

Figure 16 Local Networking Configuration Page

The screenshot shows the 'Microwave radio: Local Networking Configuration' page. The left sidebar contains a 'Filter' box and a list of navigation links: Unit Summary, Radio Summary, Platform (Shelf Management, Interfaces, Management), Unit Parameters, NTP Configuration, Time Services, Inventory, Unit Info, Login Banner, Networking (Local, Remote), SNMP, Software, Configuration, Activation Key, Security, PM & Statistics, Faults, Radio, Ethernet, Sync, Quick Configuration, and Utilities. The 'Local' link under 'Networking' is selected. The main content area is divided into three sections: 'In-Band Configuration' with an 'in-band admin' dropdown set to 'Enable' and an 'Apply' button; 'IP Family Configuration' with an 'IP address Family' dropdown set to 'IPv4' and an 'Apply' button; and 'IP Configuration' which is highlighted with a red box. The 'IP Configuration' section contains the following fields: Name (eth0), Description, IPv4 Address (192.168.1.1), IPv4 Subnet Mask (255.255.255.0), IPv4 Default Gateway (0.0.0.0), IPv6 Address (fec0::c0:a8:1:1), IPv6 Prefix Length (120) with a note '(1 ... 128)', and IPv6 Default Gateway (::). An 'Apply' button is at the bottom of this section.

2. Optionally, in the **Name** field, enter a name for the unit.
3. Optionally, in the **Description** field, enter descriptive information about the unit.
4. In the **IPv4 address** field, enter an IP address for the unit. You can enter the address in IPv4 format in this field, and/or in IPv6 format in the **IPv6 Address** field. The unit will receive communications whether they are sent to its IPv4 address or its IPv6 address.
5. If you entered an IPv4 address, in the **IPv4 Subnet mask** field, enter the subnet mask.
6. Optionally, in the **IPv4 Default gateway** field, enter the default gateway address.
7. Optionally, in the **IPv6 Address** field, enter an IPv6 address for the unit. You can enter the address in IPv6 format in this field, and/or in IPv4 format in the **IPv4 IP Address** field. The unit will receive communications whether they are sent to its IPv4 address or its IPv6 address.

8. If you entered an IPv6 address, enter the IPv6 prefix length in the **IPv6 Prefix-Length** field.
9. Optionally, if you entered an IPv6 address, enter the default gateway in IPv6 format in the **IPv6 Default Gateway** field.
10. Click **Apply**.

Configuring the Activation Key

This section includes:

- [Activation Key Overview](#)
- [Viewing the Activation Key Status Parameters](#)
- [Entering the Activation Key](#)
- [Activating a Demo Activation Key](#)
- [Displaying a List of Activation-Key-Enabled Features](#)[Activation Key Overview](#)

PTP 850 offers a pay-as-you-grow concept in which future capacity growth and additional functionality can be enabled with activation keys. Each device contains a single unified activation key cipher.

New PTP 850 units are delivered with a default activation key that enables you to manage and configure the unit. Additional feature and capacity support requires you to enter an activation key cipher in the Activation Key Configuration page. Contact your vendor to obtain your activation key cipher.

**Note**

To obtain an activation key cipher, you may need to provide the unit's serial number. You can display the serial number in the Web EMS Inventory page. See [Displaying Unit Inventory](#).

Activation Key Overview

PTP 850E offers a pay-as-you-grow concept in which future capacity growth and additional functionality can be enabled with activation keys. Each device contains a single unified activation key cipher.

New PTP 850E units are delivered with a default activation key that enables you to manage and configure the unit. Additional feature and capacity support requires you to enter an activation key cipher in the Activation Key Configuration page. Contact your vendor to obtain your activation key cipher.

**Note**

To obtain an activation key cipher, you may need to provide the unit's serial number. You can display the serial number in the Web EMS Inventory page. See [Displaying Unit Inventory](#).

Each required feature and capacity should be purchased with an appropriate activation key. It is not permitted to enable features that are not covered by a valid activation key. In the event that the activation-key-enabled capacity and feature set is exceeded, an Activation Key Violation alarm occurs and the Web EMS displays a yellow background and an activation key violation warning. After a 48-hour grace period, all other alarms are hidden until the capacity and features in use are brought within the activation key's capacity and feature set.

In order to clear the alarm, you must configure the system to comply with the activation key that has been loaded in the system. The system automatically checks the configuration to ensure that it complies with the activation-key-enabled features and capacities. If no violation is detected, the alarm is cleared.

When entering sanction state, the system configuration remains unchanged, even after power cycles. However, the alarms remain hidden until an appropriate activation key is entered or the features and capacities are re-configured to be within the parameters of the current activation key.

Demo mode is available, which enables all features for 60 days. When demo mode expires, the most recent valid activation key goes into effect. The 60-day period is only counted when the system is powered up. 10 days before demo mode expires, an alarm is raised indicating that demo mode is about to expire.

Viewing the Activation Key Status Parameters

To display the current activation key status parameters:

1. Select **Platform > Activation Key > Activation Key Configuration**. The Activation Key Configuration page opens.

Figure 17 Activation Key Configuration Page

Table 8 PTP 850 Web EMS Menu Hierarchy

Parameter	Definition
Type	Displays the current activation key type.
Validation number	Displays a random, system-generated validation number.
Date code	Displays a date code used for validation of the current activation key cipher.
Violation runtime counter (hours)	In the event of an Activation Key Violation alarm, this field displays the number of hours remaining in the 48-hour activation key violation grace period.

Parameter	Definition
Sanction state	If an Activation Key Violation alarm has occurred, and the 48-hour activation key violation grace period has expired without the system having been brought into conformance with the activation-key-enabled capacity and feature set, Yes appears in this field to indicate that the system is in an Activation Key Violation sanction state. All other alarms are hidden until the capacity and features in use are brought within the activation-key-enabled capacity and feature set.

Entering the Activation Key

1. To enter a new activation key:
2. Select **Platform > Activation Key > Activation Key Configuration**. The Activation Key Configuration page opens (Figure 17).
3. Enter the activation key cipher you have received from the vendor in the Activation Key field. The activation key cipher is a string that enables all features and capacities that have been purchased for the unit.
4. Click **Apply**.

If the activation key cipher is not legal (e.g., a typing mistake or an invalid serial number), an Activation Key Loading Failure event is sent to the Event Log. When a legal activation key cipher is entered, an Activation Key Loaded Successfully event is sent to the Event Log.

Activating a Demo Activation Key

To activate demo mode:

1. Select **Platform > Activation Key > Activation Key Configuration**. The Activation Key Configuration page opens (Figure 18).
2. In the **Demo admin** field, select **Enable**.
3. Click **Apply**.

The Demo timer field displays the number of hours that remain before the demo activation key expires.

Activation Key Reclaim

If it is necessary to deactivate an PTP 850E device, whether to return it for repairs or for any other reason, the device's activation key can be reclaimed for a credit that can be applied to activation keys for other devices.

Where the customer has purchased upgrade activation keys, credit is given for the full feature or capacity, not for each individual upgrade. For example, if the customer purchased two capacity activation keys for 300M and later purchased one upgrade activation key to 350M, credit is given as if the customer had purchased one activation key for 350M and one activation key for 300M.

Displaying a List of Activation-Key-Enabled Features

To display the status of activation key coverage for features and capacities in the PTP 850:

1. Select **Platform > Activation Key > Activation Key Overview**. The Activation Key Overview page opens.

Figure 18 Activation Key Overview Page

#	Feature Id	Feature name	Feature description	Activation key-enabled feature usage	Activation key-enabled feature credit	Activation key violation status
1	10	Per Usage	Post paid model for the activation key	Disable	Disable	OK
2	100	Services Mode	Service mode: Smart-Pipe, Edge-CET-Node, Agg-Lvl-1-CET-Node, Agg-Lvl-2-CET-Node	Not used	Only management	OK
3	200	Number of Services	Number of allowed Ethernet services	0	1	OK
4	300	H-QoS	Hierarchical QoS (Quality of Service)	Not used	Not allowed	OK
5	500	Network Resiliency	Network resiliency protocols (Smart-TDM Path Protection, G.8032)	Not used	Not allowed	OK
6	600	Ethernet OAM - Fault Management	Enables Connectivity Fault Management (CFM) per Y.1731/ 802.1ag and 802.3ah (CFM mode only)	Not used	Not allowed	OK
7	650	Ethernet OAM - Performance Monitoring	Ethernet OAM (Operation Administration and Maintenance) Performance Monitoring (PM) - Y.1731	Not used	Not allowed	OK
8	800	LACP	Link Aggregation Control Protocol (LACP)	Not used	Not allowed	OK
9	1100	Sync Unit	ITU-T G.8262 SyncE and ITU-T G.8264 ESMC (Ethernet Synchronization Message Control)	Not used	Not allowed	OK
10	1202	IEEE1588 Transparent Clock	Synchronization over Packet	Not used	Not allowed	OK
11	1300	IEEE1588 Ordinary Clock (quantity)	The allowed number of IEEE1588v2 (PTP - Precision Time Protocol) Ordinary Clocks (OC)	Not used	0	OK
12	1400	IEEE1588 Boundary Clock	IEEE1588v2 (PTP - Precision Time Protocol) Boundary Clocks (BC)	Not used	Not allowed	OK
13	1600	Main card redundancy	Redundancy of the main card	Not used	Not allowed	OK
14	1700	TDM Pseudowire	TDM Pseudowire support	Not used	Not allowed	OK
15	1800	Frame cut-through	Frame cut-through capability	Not used	Not allowed	OK
16	2100	Secured Management	Secured protocols: SSH, SFTP, HTTPS, RADIUS, SNMPv3	Not used	Not allowed	OK
17	2200	FE traffic ports (quantity)	The allowed number of FE (Fast Ethernet) ports	0	1	OK
18	2300	GbE traffic ports (quantity)	The allowed number of GbE (Gigabit Ethernet) ports	0	1	OK
19	2400	10GbE traffic ports (quantity)	The allowed number of 10GbE (10/Gigabit Ethernet) ports	0	0	OK

The Activation Key Overview page displays the activation-key-enabled features and capacities for the PTP 850, and indicates the activation key status of each feature according to the activation key currently implemented in the unit.



Note

Some of the features listed in the Activation Key Overview page may not be supported in the currently installed software version.

Table 9 Activation Key-Enabled-Features Table Parameters

Parameter	Definition
Feature ID	A unique ID that identifies the feature.
Feature name	The name of the feature.
Feature Description	A description of the feature.
Activation key-enabled feature usage	Indicates whether the activation-key-enabled feature is actually being used.
Activation key-enabled feature credit	Indicates whether the feature is allowed under the activation key that is currently installed in the unit.
Activation key violation status	Indicates whether the system configuration violates the currently installed activation key with respect to this feature.

Table 10 Activation Key-Enabled-Features Description

Activation Key Name	Description
Services Mode	<p>Enables a number of Ethernet services, depending on the type of activation key:</p> <ul style="list-style-type: none"> • Smart-Pipe –Smart Pipe (L1) services only (unlimited) and a single management service. • Edge-CET Node – Up to 8 services (all supported service types). • Agg-Lvl-1-CET-Node – Up to 64 services (all supported service types). • Agg-Lvl-2-CET-Node – Up to 1024 services (all supported service types). <p>Any CET activation key also enables the following:</p> <ul style="list-style-type: none"> • A GbE traffic port in addition to the port provided by the default activation key, for a total of 2 GbE traffic ports. • Full QoS for all services including basic queue buffer management (fixed queues buffer size limit, tail-drop only) and eight queues per port, no H-QoS.
Number of Services	Indicates how many services are allowed according to the Services Mode activation key, and how many are actually configured on the device.
H-QoS	Not relevant in the current release.
Network Resiliency	Not relevant for PTP 850E.
Ethernet OAM – Fault Management	Enables Connectivity Fault Management (FM) per Y.1731 (CET mode only).
Ethernet OAM – Performance Monitoring	Not relevant in the current release.
LACP	Not relevant in the current release.
Sync Unit	Enables the G.8262 synchronization unit. This activation key is required in order to provide end-to-end synchronization distribution on the physical layer. This activation key is also required to use SyncE.
IEEE 1588 Transparent Clock	Not relevant in the current release.
IEEE 1588 Ordinary Clock (quantity)	Not relevant in the current release.
IEEE 1588 Boundary Clock	Not relevant in the current release.
Main Card Redundancy	Not relevant for PTP 850E.
TDM Pseudowire	Not relevant for PTP 850E.
Frame cut-through	Not relevant in the current release.
Secured Management	Enables secure management protocols (SSH, HTTPS, SFTP, SNMPv3, and RADIUS).
FE traffic ports (quantity)	Displays the number of FE traffic ports allowed under the current activation key.
GbE traffic ports (quantity)	Displays the number of GbE traffic ports allowed under the current activation key.

Activation Key Name	Description
10GbE traffic ports (quantity)	Displays the number of 10G traffic ports allowed under the current activation key.
ACM (quantity)	Displays the number of radio carriers that are allowed to use ACM under the current activation key.
Narrow CHBW 1.75MHz script (quantity)	Not relevant for PTP 850E.
Header De-Duplication (quantity)	Not relevant in the current release.
XPIC (quantity)	Not relevant in the current release.
Multi-Carrier ABC (quantity)	Not relevant for PTP 850E.
MIMO	Not relevant for PTP 850E.
SD	Not relevant for PTP 850E.
ASD	Not relevant for PTP 850E.
AFR 1+0 (quantity)	Not relevant for PTP 850E.
ACMB Adaptive BW	Displays the number of radio carriers for which there is permission to use ACMB, which enables the use of radio profiles 1 and 2.
Payload Encryption AES-256 (quantity)	Not relevant in the current release.
Second core activation	Not relevant for PTP 850E.
Second core activation for RFU-D	Not relevant for PTP 850E.
Second core activation for HP	Not relevant for PTP 850E.
Second modem activation	Not relevant for PTP 850E.
RFU port activation key	Not relevant for PTP 850E.
Radio capacity level 1	Displays the number of radio carriers for which there is permission to use up to 10 Mbps. This is the default level, so every radio carrier on the device has this capacity level.
Radio capacity level 2	Displays the number of radio carriers for which there is permission to use up to 50 Mbps.
Radio capacity level 3	Displays the number of radio carriers for which there is permission to use up to 100 Mbps.
Radio capacity level 4	Displays the number of radio carriers for which there is permission to use up to 150 Mbps.
Radio capacity level 5	Displays the number of radio carriers for which there is permission to use up to 200 Mbps.

Activation Key Name	Description
Radio capacity level 6	Displays the number of radio carriers for which there is permission to use up to 225 Mbps.
Radio capacity level 7	Displays the number of radio carriers for which there is permission to use up to 250 Mbps.
Radio capacity level 8	Displays the number of radio carriers for which there is permission to use up to 300 Mbps.
Radio capacity level 9	Displays the number of radio carriers for which there is permission to use up to 350 Mbps.
Radio capacity level 10	Displays the number of radio carriers for which there is permission to use up to 400 Mbps.
Radio capacity level 11	Displays the number of radio carriers for which there is permission to use up to 450 Mbps.
Radio capacity level 12	Displays the number of radio carriers for which there is permission to use up to 500 Mbps.
Radio capacity level 13	Displays the number of radio carriers for which there is permission to use up to 650 Mbps.
Radio capacity level 14	Displays the number of radio carriers for which there is permission to use up to 1000 Mbps.
Radio capacity level 15	Displays the number of radio carriers for which there is permission to use up to 1600 Mbps.
Radio capacity level 16	Displays the number of radio carriers for which there is permission to use up to 2000 Mbps.
Radio capacity level 17	Displays the number of radio carriers for which there is permission to use up to 2500 Mbps.
Radio capacity level 18	Displays the number of radio carriers for which there is permission to use up to 3000 Mbps.
Radio capacity level 19	Displays the number of radio carriers for which there is permission to use up to 4000 Mbps.
Radio capacity level 20	Displays the number of radio carriers for which there is permission to use up to 5000 Mbps.
Radio capacity level 21	Displays the number of radio carriers for which there is permission to use up to 6000 Mbps.
Radio capacity level 22	Displays the number of radio carriers for which there is permission to use up to 7000 Mbps.
Radio capacity level 23	Displays the number of radio carriers for which there is permission to use up to 8000 Mbps.
Radio capacity level 24	Displays the number of radio carriers for which there is permission to use up to 9000 Mbps.

Activation Key Name	Description
Radio capacity level 25	Displays the number of radio carriers for which there is permission to use up to 10000 Mbps.
Auto State Propagation and LLF	Enables the use of Link Loss Forwarding (LLF) with Automatic State Propagation (ASP). Without the activation key, only one LLF ID can be configured. This means that only one ASP pair can be configured per radio interface or radio group.
Enhanced Multi-Carrier ABC (quantity)	Not relevant in the current release.

Setting the Time and Date (Optional)

Related Topics:

- [Configuring NTP](#)

PTP 850E uses the Universal Time Coordinated (UTC) standard for time and date configuration. UTC is a more updated and accurate method of date coordination than the earlier date standard, Greenwich Mean Time (GMT). Every PTP 850E unit holds the UTC offset and daylight savings time information for the location of the unit. Each management unit presenting the information uses its own UTC offset to present the information in the correct time.



Note

If the unit is powered down, the time and date are saved for 96 hours (four days). If the unit remains powered down for longer, the time and date may need to be reconfigured.

To display and configure the UTC parameters:

1. Select **Platform > Management > Time Services**. The Time Services page opens.

Logout

Connection

Admin

Filter

Unit Summary

Radio Summary

Platform

- Shelf Management
- Interfaces
- Management
 - Unit Parameters
 - NTP Configuration
 - Time Services
 - Inventory
 - Unit Info
 - Login Banner
- Networking
- SNMP
- Software
- Configuration
- Activation Key
- Security
- PM & Statistics

- Faults
- Radio
- Ethernet
- Sync
- Quick Configuration
- Utilities

Microwave radio: Time Services

Date & Time Configuration

UTC date and time

26-03-2000 04:29:54

Local date and time

26-03-2000 04:29:54

Offset from GMT

UTC offset hours

0

UTC offset minutes

0

Daylight Saving Start Time

Month

1

Day

1

Daylight Saving End Time

Month

1

Day

1

DST offset (hours)

0

Apply

Figure 19 Time Services Page

2. Configure the fields listed in [Table 11 Time Services Parameters](#).

phn-3963_008v000
Page 2-23

3. Click **Apply**.**Table 11** Time Services Parameters

	Parameter	Definition
Date & Time Configuration	UTC Date and Time	The UTC date and time.
	Local Current Date and Time	Read-only. The calculated local date and time, based on the local clock, Universal Time Coordinated (UTC), and Daylight Savings Time (DST) configurations.
Offset from GMT	UTC Offset Hours	The required hours offset (positive or negative) relative to GMT. This is used to offset the clock relative to GMT, according to the global meridian location.
	UTC Offset Minutes	The required minutes offset (positive or negative) relative to GMT. This is used to offset the clock relative to GMT, according to the global meridian location.
Daylight Saving Start Time	Month	The month when Daylight Savings Time begins.
	Day	The date in the month when Daylight Savings Time begins.
Daylight Saving End Time	Month	The month when Daylight Savings Time ends.
	Day	The date in the month when Daylight Savings Time ends.
	DST Offset (Hours)	The required offset, in hours, for Daylight Savings Time. Only positive offset is supported.

Enabling the Interfaces (Interface Manager)

By default:

- Ethernet traffic interfaces are disabled and must be manually enabled.
- The Ethernet management interface is enabled.
- Radio interfaces are enabled.



Note

In release 10.6, only Ethernet Slot 1, Port 7 is supported, along with the radio and management interfaces. In release 10.9, Ethernet Slot 1, Ports 3 through 7 are supported.

The QSFP port (Port 4), is displayed as follows.

- In a 4x1/10G configuration the QSFP port can provide four Ethernet interfaces: Eth3, Eth4, Eth 5, and Eth6. In this configuration, a QSFP transceiver is attached to the QSFP port, and an MPO-MPO cable is connected between the transceiver and a splitter on the other side of the link. The splitter splits the traffic between four Ethernet cables connecting the splitter to the customer equipment.

To enable or disable interfaces:

1. Select **Platform > Management > Interface Manager**. The Interface Manager page opens, displaying all of the system's traffic and management interfaces.

Figure 20 Interface Manager Page

Interface location	MAC address	Admin status	Operational Status
<input type="checkbox"/> Ethernet: Slot 1, Port 2	3C:4C:D0:D9:10:E3	Down	Down
<input type="checkbox"/> Ethernet: Slot 1, Port 3	3C:4C:D0:D9:10:E4	Up	Up
<input type="checkbox"/> Ethernet: Slot 1, Port 4	3C:4C:D0:D9:10:E5	Down	Down
<input type="checkbox"/> Ethernet: Slot 1, Port 5	3C:4C:D0:D9:10:E6	Down	Down
<input type="checkbox"/> Ethernet: Slot 1, Port 6	3C:4C:D0:D9:10:E7	Down	Down
<input type="checkbox"/> Ethernet: Slot 1, Port 7	3C:4C:D0:D9:10:E8	Up	Up
<input type="checkbox"/> Radio: Slot 1, Port 1	3C:4C:D0:D9:10:E9	Down	Down
<input type="checkbox"/> Management: Slot 1, Port 1	00:00:00:00:00:00	Up	Up

If an alarm is currently raised on an interface, an alarm icon appears to the left of the interface location. For example, in *Figure 20*, an alarm is raised on the Radio interface. To display details about the alarm or alarms in tooltip format, hover the mouse over the alarm icon.

To enable or disable an individual interface:

1. Select the interface in the Interface Manager table.
2. Click **Edit**. The Interface Manager – Edit page opens.

Figure 21 Interface Manager – Edit Page

Interface Manager - Status Parameters

Interface location

MAC address

Operational Status

Interface Manager - Configuration Parameters

Admin status

Page Refresh Interval (Seconds) Last Loaded: 11:25:31

3. In the Admin status field, select **Up** to enable the interface or **Down** to disable the interface.
4. Click **Apply**, then **Close**.

To enable or disable multiple interfaces:

1. Select the interfaces in the Interface Manager table or select all the interfaces by selecting the check box in the top row.
2. In the **Multiple Selection Operation** section underneath the Interface Manager Table, select Admin status – Up or Admin status – Down.

Figure 22 Multiple Selection Operation Section (Interface Manager Page)

Multiple Selection Operation

Admin status

3. Click **Apply**.

**Note**

The **Operational Status** field displays the current, actual operational state of the interface (**Up** or **Down**).

Configuring the Radio (MRMC) Script(s)

Related Topics:

- [Displaying MRMC Status](#)

Multi-Rate Multi-Constellation (MRMC) radio scripts define how the radio utilizes its available capacity. Each script is a pre-defined collection of configuration settings that specify the radio's transmit and receive levels, link modulation, channel spacing, and bit rate. Scripts apply uniform transmit and receive rates that remain constant regardless of environmental impact on radio operation.



Note

The list of available scripts reflects activation-key-enabled features. Only scripts within your activation-key-enabled capacity will be displayed.

To display the MRMC scripts and their basic parameters and select a script:

1. Select one of the following, depending on the regulatory framework in which you are operating:
 - To display ETSI scripts, select **Radio > MRMC > Symmetrical Scripts > ETSI**.
 - To display ANSI (FCC) scripts, select **Radio > MRMC > Symmetrical Scripts > FCC**.

The MRMC Symmetrical Scripts page opens. For a description of the parameters displayed in the MRMC Symmetrical Scripts page, see *Configuring the Radio (MRMC) Scripts (s)*.



Note

For detailed information on the exact scripts and profiles available per channel and configuration, refer to the Release Notes for the release version you are using.

Figure 23 MRMC Symmetrical Scripts Page

Microwave radio: MRMC Symmetrical ETSI Scripts (Radio: Slot 1, Port 1)

Radio interface: Radio: Slot 1, Port 1

▼ MRMC Symmetrical ETSI Scripts (Symmetrical ETSI Scripts)

Script ID	Channel Bandwidth (MHz)	Occupied Bandwidth (MHz)	Script Name	ACM Support	Supported QAM	Bit Rate (Mbps)
5703	250.000	230.000	mdN_A250250N_5_5703	Yes	2 .. 1024	47.535 .. 1911.410
5704	500.000	460.000	mdN_A500500N_5_5704	Yes	2 .. 1024	98.234 .. 3939.690
5706	1000.000	880.000	mdN_A10001000N_5_5706	Yes	2 .. 1024	189.163 .. 7578.440
5710	2000.000	1599.000	mdN_A20002000N_5_5710	Yes	2 .. 128	329.288 .. 9914.160

Configure script

Note: ✓ Indicates the current configured script

2. In the Select Radio Interface field, select the slot for which you want to configure the script.

3. Click **Configure Script**. A separate MRMC Symmetrical Scripts page opens similar to the page shown below.

Figure 24 MRMC Symmetrical Scripts Page – Configuration

4. In the **MRMC Script operational mode** field, select the ACM mode: **Fixed** or **Adaptive**.
- Fixed ACM mode applies constant Tx and Rx rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels.
 - In Adaptive ACM mode, Tx and Rx rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions. If you select **Adaptive**, two fields are displayed enabling you to select minimum and maximum ACM profiles.
5. Define the script profile or profiles
- If you selected **Fixed** ACM mode, select the ACM profile in the **MRMC Script profile** field.
 - If you selected **Adaptive** ACM mode, select the maximum and minimum ACM profiles in the **MRMC Script maximum profile** and the **MRMC Script minimum profile** fields.
6. Click **Apply**.



Note

Changing the script resets the radio interface and affects traffic. Changing the maximum or minimum profile does not reset the radio interface.

Table 12 MRMC Symmetrical Scripts Page Parameters

Parameter	Definition
Script ID	A unique ID assigned to the script in the system.
Channel Bandwidth (MHz)	The script's channel bandwidth (channel spacing).
Occupied Bandwidth (MHz)	The script's occupied bandwidth.
Script Name	The name of the script.
ACM Support	Indicates whether the script supports ACM. All PTP 850E scripts support ACM.
Supported QAM	MRMC Symmetrical Scripts Main Page only: Displays the range of modulation levels, in QAM, supported by the script.
Bit Rate (Mbps)	MRMC Symmetrical Scripts Main Page only: Displays the range of bit rates, in Mbps, supported by the script.
Symmetry	MRMC Symmetrical Scripts Configuration Page only: Indicates that the script is symmetrical (Normal). Only symmetrical scripts are supported in the current release.
Standard	MRMC Symmetrical Scripts Configuration Page only: Indicates whether the script is compatible with ETSI or FCC (ANSI) standards, or both.
MRMC Script operational mode	<p>MRMC Symmetrical Scripts Configuration Page only: The ACM mode: Fixed or Adaptive.</p> <ul style="list-style-type: none"> Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels. In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.
MRMC Script profile	MRMC Symmetrical Scripts Configuration Page, Fixed ACM mode only: The profile in which the system will operate.
MRMC Script maximum profile	MRMC Symmetrical Scripts Configuration Page, Adaptive ACM mode only: The maximum profile for the script. For example, if you select a maximum profile of 5, the system will not climb above profile 5, even if channel fading conditions allow it.
MRMC Script minimum profile	<p>MRMC Symmetrical Scripts Configuration Page, Adaptive ACM mode only: The minimum profile for the script. For example, if you select a minimum profile of 3, the system will not go below profile 3 regardless of the channel fading conditions. The minimum profile cannot be greater than the maximum profile, but it can be equal to it.</p> <p>Note: The default minimum profile is 2.</p>

Radio Profiles

Profiles 0 and 1 require a special activation key (SL-ACMB). These profiles are used with ACMB, which is an enhancement of ACM that provides further flexibility to mitigate fading at BPSK by reducing the channel spacing to one half or one quarter of the original channel bandwidth when fading conditions make this appropriate.


Note

Profiles 0 and 1 are not supported in release 10.6.


Table 13 Available Radio Profiles – PTP 850E

Profile	Modulation	Script 5703 (250 MHz)	Script 5704 (500 MHz)	Script 5706 (1000 MHz)	Script 5710 (2000 MHz)
Profile 0	BPSK – ¼ channel spacing	Yes	Yes	Yes	Yes
Profile 1	BPSK – ½ channel spacing	Yes	Yes	Yes	Yes
Profile 2	BPSK – full channel spacing	Yes	Yes	Yes	Yes
Profile 3	4 QAM	Yes	Yes	Yes	Yes
Profile 4	8 QAM	Yes	Yes	Yes	Yes
Profile 5	16 QAM	Yes	Yes	Yes	Yes
Profile 6	32 QAM	Yes	Yes	Yes	Yes
Profile 7	64 QAM	Yes	Yes	Yes	Yes
Profile 8	128 QAM	Yes	Yes	Yes	Yes
Profile 9	256 QAM	Yes	Yes	Yes	No
Profile 10	512 QAM	Yes	Yes	No	No
Profile 11	1024 QAM	Yes	No	No	No


Configuring the Radio Parameters

In order to establish a radio link, you must:

- 1. Verify that the radio is muted (the **TX Mute Status** should be **On**).
- 2. Configure the radio frequencies.

	<p>Note:</p> <p>Even if you are using the default frequencies, it is mandatory to actually configure the frequencies.</p>
---	--

- 3. Configure the TX level.
- 4. Click **Apply** to apply these configurations.

	<p>Note:</p> <p>If you are using the default values and did not change any other parameters on the Radio Parameters page, the Apply button will be grayed out. To activate the Apply button, change any parameter on the page, then change it back to the desired value.</p>
---	---

- 5. Set **TX Mute** to **Unmute**.
- 6. Click **Apply** to apply the unmute.
- 7. Verify that the radio is unmuted (the **TX Mute Status** should be **Off**).

You can do these tasks, perform other radio configuration tasks, and display the radio parameters in the Radio Parameters page.

To configure the radio parameters:

- 1. Select **Radio > Radio Parameters**. The Radio Parameters page opens.

Figure 25 Radio Parameters Page

2. For multi-carrier units, select the carrier in the Radio table and click **Edit**. A separate Radio Parameters page opens.
- i. In the **TX Frequency (MHz)** field, set the transmission radio frequency in MHz.
 - ii. i In the **RX Frequency (MHz)** field, set the received radio frequency in MHz.
 - iii. ii Click **Apply**. The system automatically calculates and displays the frequency separation in the **Frequency Separation (MHz)** field, based on the configured TX and RX frequencies.
 - iv. iii Optionally, select **Set also remote unit** to apply the frequency settings to the remote unit as well as the local unit.

Note:

Release 10.6 does not support the ability to configure the remote frequency settings.

3. Set the other radio parameters in the **Configuration parameters** section:
- i. i To mute the TX output of the radio carrier, select **Mute** in the **TX Mute** field. To unmute the TX output of the radio carrier, select **Unmute**. To configure a timed mute, select **Mute with Timer**.

If you select **Mute with Timer**, an additional field appears: **Mute timeout (minutes)**. This field defines a timer for the mute, in minutes (1-1440). When the timer expires, the mute automatically ends. This provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.


Configuration Parameters

TX Mute

Mute With Timer ▼

Mute timeout (minutes)

10 ▼




Note:

In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired.

- ii. In the **TX Level (dBm)** field, enter the desired TX signal level (TSL). The range of values depends on the frequency and RFU type. When **Adaptive TX power admin** is configured to **Enable**, this field determines the maximum TX level, as described below.
- iii. In the **Link ID** field, enter a unique link identifier from 1 to 65535. The Link ID identifies the link, in order to distinguish it from other links. If the Link ID is not the same at both sides of the link, a Link ID Mismatch alarm is raised.
- iv. The **Adaptive TX power admin** field enables or disables Adaptive TX Power. When Adaptive TX Power is enabled, the radio adjusts its TX power dynamically based on the current modulation. When the modulation is at a high level, the TX power is adjusted to the level required with the high modulation. If the modulation goes down to a lower level, the TX power increases to compensate for the lower modulation. The TX level configured in the **TX Level (dBm)** field determines the maximum TX level, but the actual TX level as shown in the **Operational TX Level (dBm)** field can be expected to be lower when the radio is operating at high modulations requiring less TX power.

To enable Adaptive TX power, select **Enable**. The **Adaptive TX power operational status** field should now indicate **Up** to indicate that the feature is fully functional.



Note:

Adaptive TX Power only operates when the MRMC script is configured to Adaptive mode. If the script is configured to Fixed mode (or Adaptive mode with the Minimum and Maximum Profile set to the same value), you can set **Adaptive TX Power** to **Enable**, but the **Adaptive TX power operational status** field will indicate **Down**.

Adaptive TX Power is not supported with release 10.6.

- v. In the **RSL degradation alarm** field, select **Enable** if you want the unit to generate an alarm in the event that the RSL falls beneath the threshold defined in the **RSL degradation threshold** field. The range of values is -99 to 0. By default, the alarm is disabled, with a default degradation threshold of -68 dBm. The RSL degradation alarm is alarm ID 1610, *Radio Receive Signal Level is below the configured threshold*.

The alarm is cleared when the RSL goes above the configured threshold. The alarm is masked if the radio interface is disabled, the radio does not exist, or a communication-failure alarm (Alarm ID #1703) is raised.

**Note:**

The **RSL Connector Source** field is not relevant for PTP 850E.

Creating Service(s) for Traffic

In order to pass traffic through the PTP 850E, you must configure Ethernet traffic services. For configuration instructions, see [Configuring Ethernet Service\(s\)](#).

Chapter 3: Configuration Guide

This section includes:

- [Configuring a Link Using the Quick Configuration Wizard](#)

Configuring a Link Using the Quick Configuration Wizard

The Web EMS provides wizards to configure radio links. The wizards guide you through configuration of the basic radio parameters and services necessary to establish a working pipe link. The following link types can be configured with the Quick Configuration wizard:

- **1+0** – Configures a 1+0 radio link consisting of a user-selected Ethernet and radio interface connected. This link passes traffic between the radio and Ethernet interfaces via a point-to-point pipe service. See [Configuring a 1+0 Link Using the Quick Configuration Wizard](#).

Because the Quick Configuration wizard creates Pipe links, you cannot add an interface to a link using the Quick Configuration wizard if any service points are attached to the interface prior to configuring the link. See [Deleting a Service Point](#).

Configuring a 1+0 Link Using the Quick Configuration Wizard

To configure a 1+0 link using the Quick Configuration wizard:

1. Select **Quick Configuration > PIPE > Single Carrier > 1+0**. Page 1 of the 1+0 Quick Configuration wizard opens.

Figure 26 1+0 Quick Configuration Wizard – Page 1

The screenshot displays the 'Microwave radio: Link Setup (PIPE) 1 + 0' configuration page. On the left, a sidebar contains navigation links: 'Unit Summary', 'Radio Summary', 'Platform', 'Faults', 'Radio', 'Ethernet', 'Sync', 'Quick Configuration' (expanded), 'From', 'Platform Setup', 'PIPE' (expanded), 'Single Carrier' (expanded), '1 + 0' (selected), and 'Utilities'. The main area shows a 'Link Setup Progress' bar at 0%. Below this is an illustration of a microwave radio unit with six ports. The configuration section, titled 'Ethernet Selection, 1 + 0', includes a 'PIPE Type' dropdown set to 'dot1q' and an 'Ethernet Interface' dropdown set to 'Ethernet: Slot 1, Port 7'. At the bottom are three buttons: '<< Back', 'Next >>', and 'Finish'.

2. In the **PIPE Type** field, select the Attached Interface type for the service that will connect the radio and Ethernet interfaces. Options are:
 - **dot1q** – All C-VLANs and untagged frames are classified into the service.
 - **s-tag** – All S-VLANs and untagged frames are classified into the service.

**Note**


For a full explanation of Ethernet Services, service types, and attached interface types, see [Configuring Ethernet Service\(s\)](#).

3. In the **Ethernet Interface** field, select an Ethernet interface for the link.
4. Click **Next**. Page 2 of the 1+0 Quick Configuration wizard opens

Figure 27 1+0 Quick Configuration Wizard – Page 2

5. In the **Radio Interface** field, select **Radio: Slot 1, Port 1**.
6. Click **Next**. Page 3 of the 1+0 Quick Configuration wizard opens.

Figure 28 1+0 Quick Configuration Wizard – Page 3



7. In the **TX Frequency (MHz)** field, set the transmission radio frequency in MHz.
8. In the **RX Frequency (MHz)** field, set the received radio frequency in MHz.
9. In the **TX Level (dBm)** field, enter the desired TX signal level (TSL). The range of values depends on the frequency and RFU type.
10. To mute the TX output of the radio, select **Mute** in the **TX mute** field. To unmute the TX output of the radio, select **Unmute**.
11. Click **Next**. Page 4 of the 1+0 Quick Configuration wizard opens.

Figure 29 1+0 Quick Configuration Wizard – Page 4

12. In the **Script ID** field, select the MPMC script you want to assign to the radio. For a full explanation of choosing an MPMC script, see *Configuring the Radio (MPMC) Script(s)*.
1. In the **Operational Mode** field, select the ACM mode: **Adaptive** or **Fixed**.
 - In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.
 - Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels.
 2. Do one of the following:
 - If you selected **Adaptive** in the **Operational Mode** field, the following two fields are displayed:
 - **Maximum profile** – Enter the maximum profile for the script. See *Configuring the Radio (MPMC) Script(s)*.
 - **Minimum profile** – Enter the minimum profile for the script. See *Configuring the Radio (MPMC) Script(s)*.



Note

The default minimum profile is 2.

- If you selected **Fixed** in the **Operational Mode** field, the next field is **Profile**. Select the ACM profile for the radio in the **Profile** field.
3. Click **Next**. Page 5 of the 1+0 Quick Configuration wizard opens.

Figure 30 1+0 Quick Configuration Wizard – Page 5

Logout ✓ Connection Admin

Filter

Unit Summary
Radio Summary

Platform
Faults
Radio
Ethernet
Sync
Quick Configuration
From
Platform Setup
PIPE
Single Carrier
1 + 0
Utilities

Microwave radio: Link Setup (PIPE) 1 + 0

Link Setup Progress 85%

Management Configuration, 1 + 0

In Band Management No

<< Back Next >> Finish

- 4 In the **In Band Management** field, select **Yes** to configure in-band management, or **No** if you do not need in-band management. If you select **Yes**, the **Management VLAN** field appears.

Figure 31 1+0 Quick Configuration Wizard – Page 5 (In Band Management = Yes)

Logout ✓ Connection Admin

Filter

Unit Summary
Radio Summary

Platform
Faults
Radio
Ethernet
Sync
Quick Configuration
From CeraPlan
Platform Setup
PIPE
Single Carrier
1 + 0
Utilities

Microwave radio: Link Setup (PIPE) 1 + 0

Link Setup Progress 85%

Management Configuration, 1 + 0

In Band Management Yes

Management VLAN 1

☐ In Band includes Ethernet interface

<< Back Next >> Finish

- 5 If you selected **Yes** in the **In Band Management** field, select the management VLAN in the **Management VLAN** field.
- 6 If you want to use the Ethernet interface as well as the radio interface for in-band management, select **In Band includes Ethernet interface**.
- 7 Click **Finish**. Page 6 of the 1+0 Quick Configuration wizard opens. This page displays the parameters you have selected for the link.

Figure 32 1+0 Quick Configuration Wizard – Page 6 (Summary Page)

Logout ✓ Connection Admin

▼ Filter

[Unit Summary](#)

[Radio Summary](#)

▶ Platform

▶ Faults

▶ Radio

▶ Ethernet

▶ Sync

▲ Quick Configuration

[From](#)

[Platform Setup](#)

 ▲ PIPE

 ▲ Single Carrier

1 + 0

▶ Utilities

Microwave radio: Link Setup (PIPE) 1 + 0

Link Setup Progress **100%**

Following are the parameters that you have selected, 1 + 0

PIPE Type: dot1q

Ethernet Interface: Ethernet: Slot 1, Port 7

Radio interface: Radio: Slot 1, Port 1

TX Frequency: 83500 MHz, RX Frequency: 73500 MHz

TX Level (dBm): 15, TX Mute: Mute

MRMC Script ID: 5703, Operational Mode: Adaptive, Maximum profile: 8, Minimum profile: 2

In Band Management: Yes, Management VLAN: 1, Ethernet included: No

Warning: After you click Submit, the system will be configured with these parameters and the interfaces will be reset. Traffic will be affected.

<< Back Next >> Submit

- 8 To complete configuration of the link, click **Submit**. If you want to go back and change any of the parameters, click **Back**. After you click **Submit**, the unit is reset.

Chapter 4: Unit Management

This section includes:

- [Defining the IP Protocol Version for Initiating Communications](#)
- [Configuring the Remote Unit's IP Address](#)
- [Configuration SNMP](#)
- [Configuring Trap Managers](#)
- [Installing and Configuring an FTP or SFTP Server](#)
- [Configuring the Internal Ports for FTP or SFTP](#)
- [Upgrading the Software](#)
- [Backing Up and Restoring Configurations](#)
- [Setting the Unit to the Factory Default Configuration](#)
- [Performing a Hard \(Cold\) Reset](#)
- [Configuring Unit Parameters](#)
- [Configuring NTP](#)
- [Displaying Unit Inventory](#)

Related topics:

- [Setting the Time and Date \(Optional\)](#)
- [Enabling the Interfaces \(Interface Manager\)](#)
- [Uploading Unit Info](#)
- [Changing the Management IP Address](#)

Defining the IP Protocol Version for Initiating Communications

You can specify which IP protocol the unit will use when initiating communications, such as downloading software, sending traps, pinging, or exporting configurations. The options are IPv4 or IPv6.

To set the IP protocol version of the local unit:

1. Select **Platform > Management > Networking > Local**. The Local Networking Configuration page opens.

Figure 33 Local Networking Configuration Page

2. In the **IP address Family** field, select the IP protocol the unit will use when initiating communications. The options are **IPv4** or **IPv6**.

Configuring the Remote Unit's IP Address

You can configure the IP address of a remote unit.

To configure the IP address of a remote unit:

1. Select **Platform > Management > Networking > Remote**. The Remote Networking Configuration page opens.

Figure 34 Remote Networking Configuration Page

Logout Connection Admin

Filter

Unit Summary
Radio Summary

Platform

- Shelf Management
- Interfaces
- Management
 - Unit Parameters
 - NTP Configuration
 - Time Services
 - Inventory
 - Unit Info
 - Login Banner
- Networking
 - Local
 - Remote
- SNMP
- Software
- Configuration
- Activation Key
- Security
- PM & Statistics
- Faults
- Radio
- Ethernet
- Sync
- Quick Configuration
- Utilities

Microwave radio: Remote Networking Configuration

Remote IP Configuration

Radio location: Radio: Slot 1, Port 1

Remote Radio Location: Unknown

Remote IPv4 Address: 0.0.0.0

Remote Subnet mask: 255.255.255.0

Remote default gateway: 0.0.0.0

Remote IPv6 Address: ::

Remote IPv6 Prefix-Length: 64 (1 ... 128)

Remote IPv6 Default Gateway: [Dropdown]

Apply

2. In the **Remote IPv4 address** field, enter an IPv4 address for the remote unit. You can enter the address in IPv4 format in this field, and/or in IPv6 format in the **IPv6 Address** field. The remote unit will receive communications whether they are sent to its IPv4 address or its IPv6 address.
3. In the **Remote Subnet mask** field, enter the subnet mask of the remote radio.
4. Optionally, in the **Remote default gateway** field, enter the default gateway address for the remote radio.
5. Optionally, in the **Remote IPv6 Address** field, enter an IPv6 address for the remote unit. You can enter the address in IPv6 format in this field, and/or in IPv4 format in the **Remote IPv4 Address** field. The unit will receive communications whether they are sent to its IPv4 address or its IPv6 address.
6. If you entered an IPv6 address, enter the IPv6 prefix length in the **Remote IPv6 Prefix-Length** field.
7. Optionally, if you entered an IPv6 address, enter the default gateway in IPv6 format in the **Remote IPv6 Default Gateway** field.
8. Click **Apply**.

Changing the Subnet of the Remote IP Address

If you wish to change the **Remote IPv4 Address** to a different subnet:

1. Change the address of the **Remote Default Gateway** to 0.0.0.0.
2. Click **Apply**.
3. Set the **Remote IPv4 Address** as desired, and the **Remote Default Gateway** as desired.

Similarly, if you wish to change the **Remote IPv6 Address** to a different subnet:

1. Change the address of the **Remote IPv6 Default Gateway** to 0:0:0:0:0:0:0:0.
2. Click **Apply**.
3. Set the **Remote IPv6 Address** as desired, and the **Remote IPv6 Default Gateway** as desired.

Configuration SNMP

PTP 850E support SNMP v1, V2c, and v3. You can set community strings for access to PTP 850 units.

PTP 850E support the following MIBs:

- RFC-1213 (MIB II).
- RMON MIB.
- Proprietary MIB.

Access to the unit is provided by making use of the community and context fields in SNMPv1 and SNMPv2c/SNMPv3, respectively.

To configure SNMP:

1. Select **Platform > Management > SNMP > SNMP Parameters**. The SNMP Parameters page opens.

Figure 35 SNMP Parameters Page

The screenshot shows a web-based configuration interface for a microwave radio. The top navigation bar includes 'Logout', 'Connection', and 'Admin' links. The left sidebar contains a tree view with categories: Platform (Shelf Management, Interfaces), Management (Unit Parameters, NTP Configuration, Time Services, Inventory, Unit Info, Login Banner), Networking, and SNMP (SNMP Parameters, Trap Managers, V3 Users). The main content area is titled 'Microwave radio: SNMP Parameters' and contains the following configuration fields:

- SNMP Parameters** (Section Header)
- Admin**: A dropdown menu set to 'Enable'.
- Operational Status**: A text field displaying 'Up'.
- SNMP Read Community**: A text field displaying 'public'.
- SNMP Write Community**: A text field displaying 'private'.
- SNMP Trap Version**: A dropdown menu set to 'V1'.
- SNMP MIB Version**: A text field displaying '1.10.7.3.3.2'.
- V1V2 Blocked**: A dropdown menu set to 'No'.
- Apply**: A button at the bottom of the configuration area.

2. In the **Admin** field, select **Enable** to enable SNMP monitoring, or **Disable** to disable SNMP monitoring.



Note

The **Operational Status** field indicates whether SNMP monitoring is currently active (**Up**) or inactive (**Down**).

3. In the **SNMP Read Community** field, enter the community string for the SNMP read community.
4. In the **SNMP Write Community** field, enter the community string for the SNMP write community
5. In the **SNMP Trap Version** field, select **V1**, **V2**, or **V3** to specify the SNMP version.

**Note**

The **SNMP MIB Version** field displays the current SNMP MIB version the unit is using.


6. In the **V1V2 Blocked** field, select **Yes** if you want to block SNMPv1 and SNMPv2 access so that only SNMPv3 access will be enabled.
7. Click **Apply**.

If you are using SNMPv3, you must also configure SNMPv3 users. SNMPv3 security parameters are configured per SNMPv3 user.

To add an SNMP user:

1. Select **Platform > Management SNMP > V3 Users**. The V3 Users page opens.

Figure 36 V3 Users Page



2. Click **Add**. The V3 Users - Add page opens.

Figure 37 V3 Users - Add Page

V3 Users

V3 Users - Add

Username

Password

Authentication Algorithm

MD5

Encryption (Privacy) mode

DES

Access mode

Read Write User

Apply

Last Loaded: 14:42:34

Refresh

Close

3. Configure the SNMP V3 Authentication parameters, as described below.
4. Click **Apply**, then **Close**.

Table 14 SNMP V3 Authentication Parameters

Parameter	Definition
User Name	Enter the SNMPv3 user name.
Password	Enter a password for SNMPv3 authentication. The password must be at least eight characters.
Authentication Algorithm	Select an authentication algorithm for the user. Options are: <ul style="list-style-type: none">NoneSHAMD5
Encryption (Privacy) Mode	Select an encryption (privacy) protocol for the user. Options are: <ul style="list-style-type: none">NoneDESAES
Access Mode	Select an access permission level for the user. Options are: <ul style="list-style-type: none">Read Write UserRead Only User


Configuring Trap Managers

You can configure trap forwarding parameters by editing the Trap Managers table. Each line in the Trap Managers table displays the setup for a manager defined in the system.

To configure trap managers:

- 1. Select **Platform > Management SNMP > Trap Managers**. The Trap Managers page opens.

Figure 38 Trap Managers Page



- 2. Select a trap manager and click Edit. The Trap Managers Edit page opens.

Figure 39 Trap Managers - Edit Page

3. Configure the trap manager parameters, as described in [Table 21 Trap Manager Parameters](#).
4. Click **Apply**, then **Close**.

Table 15 Trap Manager Parameters

Parameter	Definition
IPv4 Address	If the IP address family is configured to be IPv4, enter the destination IPv4 address. Traps will be sent to this IP address. See Defining the IP Protocol Version for Initiating Communications .
IPv6 Address	If the IP address family is configured to be IPv6, enter the destination IPv6 address. Traps will be sent to this IP address. See Defining the IP Protocol Version for Initiating Communications .
Description	<ul style="list-style-type: none"> Enter a description of the trap manager (optional).
Admin	<ul style="list-style-type: none"> Select Enable or Disable to enable or disable the selected trap manager.
Community	<ul style="list-style-type: none"> Enter the community string for the SNMP read community.
Port	<ul style="list-style-type: none"> Enter the number of the port through which traps will be sent.
Heartbeat Period	<ul style="list-style-type: none"> Enter the interval, in minutes, between each heartbeat trap.
CLLI	<ul style="list-style-type: none"> Enter a Common Language Location Identifier (CLLI). The CLI is free text that will be sent with the trap. You can enter up to 100 characters.

Parameter	Definition
V3 User Name	<p>If the SNMP Trap version selected in Figure 100 SNMP Parameters Page is V3, enter the name of a V3 user defined in the system.</p> <p>To view or define a V3 user, use the Figure 101 V3 Users Page page.</p> <p>Note: Make sure that an identical V3 user is also defined on the manager's side.</p>

Installing and Configuring an FTP or SFTP Server

Several tasks, such as software upgrade (except when performed using HTTP or HTTPS) and configuration backup, export, and import, require the use of FTP or SFTP. The PTP 850 can function as an FTP or SFTP client. If you wish to use FTP/SFTP, you must install FTP/SFTP server software on the PC or laptop you are using.

**Note**

For FTP, it is recommended to use FileZilla_Server software that can be downloaded from the web (freeware).

For SFTP, it is recommended to use SolarWinds SFTP/SFCP server (freeware).


If you are using IPv6 to perform the operation, make sure to use FileZilla version 0.9.38 or higher to ensure IPv6 support. If you are using another type of FTP or SFTP server, make sure the application version supports IPv6.

To install and configure FTP or SFTP server software on the PC or laptop:


1. Create a user and (optional) password on the FTP/SFTP server. For example, in FileZilla Server, perform the following:

From the Edit menu, select Users.

- I. In the Users window, click Add.
- II. In the Add user account window, enter a user name and click OK.
- III. In the Users window, select Enable account and, optionally, select Password and enter a password.
- IV. In the Users window, click OK.

Figure 40 FileZilla Server User Configuration

2. Create a shared FTP/SFTP folder on the PC or laptop you are using to perform the software upgrade (for example, `C:\FTPServer`).
3. In the FTP/SFTP server, set up the permissions for the shared FTP/SFTP folder. For example, in FileZilla Server:
 - I. From the **Edit** menu, select **Users**.
 - II. In the Users window, select **Shared folders**.
 - III. Underneath the Shared folders section, click **Add** and browse for your shared FTP folder.
 - IV. Select the folder and click **OK**.
 - V. In the Shared folders section, select your shared FTP folder.
 - VI. In the Files and Directories sections, select all of the permissions.
 - VII. Click Set as home directory to make the Shared folder the root directory for your FTP server
 - VIII. Click **OK** to close the Users window.

Figure 41 FileZilla Server Shared Folder Setup

Configuring the Internal Ports for FTP or SFTP

By default, the following PTP 850 ports are used for FTP and SFTP when the PTP 850 unit is acting as an FTP or SFTP client (e.g., software downloads, configuration file backup and restore operations):


- FTP – 21
- SFTP – 22

You can change either or both of these ports from the following pages:

- Platform > Software > Download & Install
- Platform > Configuration > Configuration Management
- Platform > Security > General > Security Log Upload
- Platform > Security > General > Configuration Log Upload
- Platform > Security > X.509 Certificate > CSR
- Platform > Security > X.509 Certificate > Download & Install

From any of these pages, click **FTP Port**. The FTP Port page opens.

Figure 42 FTP Port Page



File transfer protocol	File transfer port number
FTP	21
SFTP	22

Apply

Last Loaded: 15:35:32 Refresh Close

110%

Edit the **File transfer port number** for FTP and or SFTP and click **Apply**.

Upgrading the Software

PTP 850 software and firmware releases are provided in a single bundle that includes software and firmware for all components in the system. Software is first downloaded to the system, then installed. After installation, a reset is automatically performed on all components whose software was upgraded.

This section includes:

- [Viewing Current Software Versions](#)
- [Software Upgrade Overview](#)
- [Downloading and Installing Software](#)
- [Configuring a Timed Installation](#)

Viewing Current Software Versions

To display a list of software packages currently installed and running on the system modules:

1. Select **Platform > Software > Versions**. The Versions page opens. For a description of the information provided in the Versions page, see [Table 15 Versions Page Columns](#).

Figure 43 Versions Page

Package Name	Target Device	Running Version	Installed Version	Downloaded version	Reset Type
gnss	Cleared	10.6.0.0.0.76	10.6.0.0.0.76	10.6.0.0.0.76	Main board cold reset
gnss-fpga-fw-elic	LIC-X E4 Elec	N/A	1.8.4	1.8.4	Main board cold reset
gnss-fpga-fw-rmc	RMC-A	N/A	2.4	2.4	Main board cold reset
gnss-rmc-b	RMC-B	N/A	3.13.10	3.13.10	Main board cold reset
gnss-fpga-fw-tcc	TCC-B	19	1.55.6	1.55.6	Main board cold reset
gnss-atp	TCC-B	10.6.0.0.0.76	1.40.4	1.40.4	Main board cold reset
gnss-management	TCC-B	1.10.7.19	1.10.7.19	1.10.7.19	Main board cold reset
gnss-mcti	TCC-B	10.6.0.0.0.76	10.6.0.0.0.76	10.6.0.0.0.76	Main board cold reset
gnss-mrmc-scripts	RMC-A	N/A	7.16	7.16	Main board cold reset
gnss-mrmc-b-scripts	RMC-B	N/A	5.0	5.0	Main board cold reset
gnss-rfu	Cleared	N/A	3.0.11	3.0.11	Main board cold reset
gnss_tcc-config	TCC-B	N/A	1.0	1.0	Main board cold reset
gnss_tcc-kernel	TCC-B	2.6.34.8	v2.6.34.8	v2.6.34.8	Main board cold reset
gnss-modem-fw	RMC-A	N/A	3.40.2	3.40.2	Main board cold reset
gnss-pwc	LIC-T16 ACR	N/A	6.24	6.24	Main board cold reset
gnss-pwc-stm1	LIC-T155 ACR	N/A	6.25	6.25	Main board cold reset
gnss-vm-control	Cleared	N/A	1.0.2.12	1.0.2.12	Main board cold reset
gnss-fpga-fw-hrzn	Cleared	N/A	N/A	N/A	No Reset

Table 16 Versions Page Columns

Parameter	Definition
Package Name	The name of the software package.
Target Device	The specific component on which the software runs.
Running Version	The software version currently running on the component.
Installed Version	The software version currently installed for the component. If the installed version is not already the running version, it will become the running version after the next reset takes place.

Parameter	Definition
Downloaded Version	The version, if any, that has been downloaded from the server but not yet installed. Upon installation, this version will become the Installed Version.
Reset Type	The level of reset required by the component in order for the Installed Version to become the Active Version. A cold (hard) reset powers down and powers back up the component. A warm (soft) reset simply reboots the software or firmware in the component.

Software Upgrade Overview

The PTP 850 software installation process includes the following steps:

1. **Download** – The files required for the installation or upgrade are downloaded from a remote server.
2. **Installation** – The downloaded software and firmware files are installed in all modules and components of the PTP 850 that are currently running an older version.
3. **Reset** – The PTP 850 is restarted in order to boot the new software and firmware versions.

Software and firmware releases are provided in a single bundle that includes software and firmware for all components in the system. When you download a software bundle, the system verifies the validity of the bundle. The system also compares the files in the bundle to the files currently installed in the PTP 850 and its components, so that only files that need to be updated are actually downloaded. A message is displayed for each file that is actually downloaded.



Note

When downloading an older version, all files in the bundle may be downloaded, including files that are already installed.

Software bundles can be downloaded via HTTP, HTTPS, FTP or SFTP. After the software download is complete, you can initiate the installation.



Note

Before performing a software upgrade, it is important to verify that the system date and time are correct. See [Setting the Time and Date \(Optional\)](#).

When upgrading a node with unit protection, upgrade the standby unit first, followed by the active unit.

Downloading and Installing Software

You can download software using HTTP, HTTPS, FTP or SFTP.

When downloading software via HTTPS or HTTPS, the PTP 850E functions as the server, and you can download the software directly to the PTP 850E unit.

When downloading software via FTP or SFTP, the PTP 850E functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the software upgrade. For details, see [Installing and Configuring an FTP or SFTP Server](#).

Downloading Software Via HTTP or HTTPS

To download and install a new software version using HTTP or HTTPS:

1. Before performing a software upgrade, it is important to verify that the system date and time are correct. See [Setting the Time and Date \(Optional\)](#).
2. In the PTP 850's Web EMS, select **Platform > Software > Download & Install**. The Download & Install page opens.

Figure 44 Download & Install Page – HTTP/ HTTPS Download – No File Selected

The screenshot shows the 'Microwave radio: Download & Install' page. On the left is a navigation menu with links like 'Unit Summary', 'Radio Summary', 'Platform', 'Shelf Management', 'Interfaces', 'Management', 'Software', 'Versions', 'Download & Install', 'Configuration', 'Activation Key', 'Security', 'PM & Statistics', 'Faults', 'Radio', 'Ethernet', 'Sync', 'Quick Configuration', and 'Utilities'. The 'Download & Install' link is highlighted. The main content area is divided into two sections: 'Software Download' and 'Software Install'. In the 'Software Download' section, 'HTTP' is selected, 'Running Version' is '10.6.0.0.0.76', 'Download status' is 'Ready', 'Download progress' is '0%', and 'File name' is 'No file chosen for download'. There are 'Choose File', 'Abort', and 'Download' buttons. The 'Software Install' section shows 'Installation status' as 'Ready', 'Installation progress' as '0%', and 'Install Parameters' and 'Install' buttons.

3. Select **HTTP**
4. Click **Choose File**. A browser window opens.
5. Navigate to the directory in which the software file is located and selected the file. The selected file must be a ZIP file.
6. Click **Open**. The file name of the selected file appears in the **File Name** field.

Figure 45 Download & Install page – HTTP/ HTTPS Download – File Selected

- Click **Download**. The download begins. You can view the status of the download in the **Download Status** field.

**Note**

To Discontinue the download process, Click **Abort**.

- Once the download has been completed, verify that the version you want to install has been downloaded. You can check the downloaded version for each component by viewing the *Downloaded Version* column in the Versions page. See [Viewing Current Software versions](#).

Downloading Software Via FTP or SFTP

To download and install a new software version using FTP or SFTP:

- Before performing a software upgrade, it is important to verify that the system date and time are correct. See [Setting the Time and Date \(Optional\)](#).
- Install and configure FTP or SFTP server software on the PC or laptop you are using to perform the software upgrade, as described in [Installing and Configuring an FTP or SFTP Server](#).
- Unzip the new software package for PTP 850 into your shared FTP or SFTP folder.
- In the PTP 850's Web EMS, select **Platform > Software > Download & Install**. The Download & Install page opens.
- Select **FTP**.

Figure 46 Download & Install Page - FTP

Logout Connection Admin

Filter

[Unit & Radio Summary](#)

- Platform
 - Management
 - Software
 - [Versions](#)
 - [Download & Install](#)
 - Configuration
 - Activation Key
 - Security
 - Faults
 - Radio
 - Ethernet
 - Sync
 - Quick Configuration
 - Utilities

Microwave radio: Download & Install

Software Download

☐ HTTP ☒ FTP

Download status Ready

Download progress 0%

FTP Parameters FTP Port Download

Software Install

Installation status Ready

Installation progress 0%

Install Parameters Install

- Click **FTP Parameters** to view the FTP Parameters page.

Figure 47 FTP Parameters Page

7. In the **File Transfer Protocol** field, select the file transfer protocol you want to use (**FTP** or **SFTP**).
8. In the **Username** field, enter the user name you configured in the FTP server.
9. In the **password** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP/SFTP user, simply leave this field blank.
10. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP/SFTP server in the **Server IPv4 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
11. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP/SFTP server in the **Server IPv6 Address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
12. In the **Path** field, enter the directory path from which you are downloading the files. Enter the path relative to the FTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "//".
13. Click **Apply** to save your settings, and **Close** to close the FTP Parameters page.
14. Click **Download**. The download begins. You can view the status of the download in the **Download Status** field of the Download & Install page. See [Table 16 Download & Install Status Parameters](#).
15. Once the download has been completed, verify that the version you want to install has been downloaded. You can check the downloaded version for each component by viewing the *Downloaded Version* column in the Versions page. See [Viewing Current Software Versions](#).

Installing Software

**Note**

For Instructions on how to configure a timed installation, see [Configuring a Timed Installation](#).

To Install software:

1. Download the software version you want to install. See Downloading and installing Software.
2. Select **Platform > Software > Download & Install**. The Download & Install page opens. ([Figure 111](#)).
3. Click **Install**. The installation begins. You can view the status of the installation in the Download & Install - Status Parameters section of the Download & Install Download & Install page. See [Table 16 Download & Install Status Parameters](#).

Upon completion of the installation, the system performs an automatic reset.

**Note**

- DO NOT reboot the unit during the software installation process. As soon as the process is successfully completed, the unit will reboot itself.
- Sometimes the installation process can take up to 30 minutes.
- Only in the event that software installation was not successfully finished and more than 30 minutes have passed can the unit be rebooted..

Table 17 Download & Install Status Parameters


Parameter	Definition
Download status	<p>The status of any pending software download. Possible values are:</p> <ul style="list-style-type: none"> • Ready – The default value, which appears when no download is in progress. • Verifying download files – The system is verifying the files to be downloaded. • Download in progress – The download files have been verified, and the download is in progress. <p>If an error occurs during the download, an appropriate error message is displayed in this field.</p> <p>When the download is complete, one of the following status indications appears:</p> <ul style="list-style-type: none"> • Download Success • Download Failure • All components already found in the system <p>When the system is reset, the Download Status returns to Ready.</p>
Download progress	Displays the progress of the current software download.
Install status	<p>The status of any pending software installation. Possible values are:</p> <ul style="list-style-type: none"> • Ready – The default value, which appears when no installation is in progress. • Verifying installation files – The system is verifying the files to be installed. • Installation in progress – The installation files have been verified, and the installation is in progress. <p>If an error occurs during the installation, an appropriate error message is displayed in this field.</p> <p>When the installation is complete, one of the following status indications appears:</p> <ul style="list-style-type: none"> • Installation Success • Installation Partial Success • Installation Failure • incomplete-sw-version <p>When the system is reset, the Installation Status returns to Ready.</p>
Install progress	Displays the progress of the current software installation.

Configuring a Timed Installation

You can schedule a timed (deferred) software installation to take place at any time within 24 hours after you configure the installation.


To schedule a timed software installation:

1. Download the software version you want to install. See [Downloading and Installing Software](#).
2. Select **Platform > Software > Download & Install**. The **Download & Install** page opens.
3. Click **Install Parameters**. The **Install Parameters** page opens.

Figure 48 Install parameters Page.

The screenshot shows a web application window titled "Install Parameters". Inside the window, there is a section labeled "Install Parameters" with a "Timed installation" dropdown menu currently set to "No". Below this is an "Apply" button. At the bottom of the window, there is a status bar containing a "Page Refresh Interval (Seconds)" dropdown set to "None", a "Last Loaded: 15:30:40" timestamp, and "Refresh" and "Close" buttons.

4. Select **Yes** in the **Timed Installation** field.
5. Click **Apply**. The **Software Management timer** field appears.

Figure 49 Install parameters page- Software Management Timer.

The screenshot shows the "Install Parameters" window after the "Timed installation" field has been changed to "Yes". In addition to the "Timed installation" dropdown, there are now two text input fields: "Software management timer (00:00..23:59)" with the value "00:00" and "Time to installation (seconds)" with the value "0". The "Apply" button remains below these fields. The status bar at the bottom is identical to the previous screenshot, showing the refresh interval, last loaded time, and refresh/close buttons.

6. In the **Software management timer** field, enter the amount of time, in hours and minutes, you want to defer the installation. For example, in Figure 116, the timer is set for two hours after the timer was configured (02:00).
7. Click **Apply**, then **Close** to close the Install Parameters page.

Backing Up and Restoring Configurations

You can import and export PTP 850 configuration files. This enables you to copy the system configuration to multiple PTP 850 units. You can also backup and save configuration files.

Configuration files can only be copied between units of the same type, i.e., PTP 850E to PTP 850E to PTP 850E.

This section includes:

- [Configuration Management Overview](#)
- [Viewing Current Backup Files](#)
- [Setting the Configuration Management Parameters](#)
- [Exporting a Configuration File](#)
- [Importing a Configuration File](#)
- [Deleting a Configuration File](#)
- [Backing Up the Current Configuration](#)
- [Restoring a Saved Configuration](#)
- [Editing CLI Scripts](#)

Configuration Management Overview

System configuration files consist of a zip file that contains three components:

- A binary configuration file used by the system to restore the configuration.
- A text file which enables users to examine the system configuration in a readable format. The file includes the value of all system parameters at the time of creation of the backup file.
- An additional text file which enables you to write CLI scripts in order to make desired changes in the backed-up configuration. This file is executed by the system after restoring the configuration.

The system provides three restore points to manage different configuration files. Each restore point contains a single configuration file. Files can be added to the restore points by creating backups of the current system state or by importing them from an external server. For example, you may want to use one restore point to keep a last good configuration, another to import changes from an external server, and the third to store the current configuration.

You can apply a configuration file to the system from any of the restore points.

Viewing Current Backup Files

The system provides three restore points to manage different configuration files. Each restore point contains a single configuration file. Files can be added to the restore points by creating backups of the current system state or by importing them from an external server. For example, you may want to use one restore point to keep a last good configuration, another to import changes from an external server, and the third to store the current configuration.

To display the configuration files currently saved at the system restore points:

1. Select **Platform > Configuration > Backup Files**. The Backup Files page opens. For a description of the information provided in the Backup Files page, see [Table 17 Backup Files Page Columns](#).

Figure 50 Backup Files Page

The screenshot shows the 'Microwave radio: Backup Files' page. On the left is a sidebar with a 'Filter' box and a tree view containing links like 'Unit Summary', 'Radio Summary', 'Platform', 'Shelf Management', 'Interfaces', 'Management', 'Software', 'Configuration', 'Timer Parameters', 'Backup Files' (highlighted), 'Configuration Management', 'Activation Key', 'Security', 'PM & Statistics', 'Faults', 'Radio', 'Ethernet', 'Sync', 'Quick Configuration', and 'Utilities'. The main area displays a table titled 'Configuration management status table' with the following data:

File number ▲	Original system type	Software version	Time of creation	Original IP address	System ID	valid
1	N/A	0.0.0.0	01-01-1970 00:00:00	0.0.0.0	0	No
2	N/A	0.0.0.0	01-01-1970 00:00:00	0.0.0.0	0	No
3	N/A	0.0.0.0	01-01-1970 00:00:00	0.0.0.0	0	No

Table 18 Backup Files Page Columns

Parameter	Definition
File number	A number from 1 to 3 that identifies the restore point.
Original system type	The type of unit from which the backup configuration file was created.
Software version	The software version of the unit from which the backup configuration file was created.
Time of creation	The time and date on which the configuration file was created.
Original IP address	The IP address of the unit from which the configuration file was created.
System ID	The System ID, if any, of the unit from which the configuration file was created. This is taken from the Name field in the Unit Parameters page. See Configuring Unit Parameters .
Valid	Reserved for future use.

Setting the Configuration Management Parameters

When importing and exporting configuration files, the PTP 850 functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the import or export. For details, see [Installing and Configuring an FTP or SFTP Server](#).

Before importing or exporting a configuration file, you must perform the following steps:

1. Verify that the system date and time are correct. See [Setting the Time and Date \(Optional\)](#).
2. Install and configure an FTP server on the PC or laptop you are using to perform the import or export. See [Installing and Configuring an FTP or SFTP Server](#).
3. In the PTP 850E Web EMS, select **Platform > Configuration > Configuration Management**. The Configuration Management page opens.

Figure 51 Configuration Management Page

Logout ✓ Connection Admin

Microwave radio: Configuration Management

Filter [x]

Unit Summary
Radio Summary
Platform
Shelf Management
Interfaces
Management
Software
Configuration
Timer Parameters
Backup Files
Configuration Management
Activation Key
Security
PM & Statistics
Faults
Radio
Ethernet
Sync
Quick Configuration
Utilities

Export/Import file status
File transfer status: ready
File transfer progress: 0%

Backup file creation status
Backup file creation status: Ready
Backup file creation progress: 0%

Configuration restore status
Configuration restore status: ready

Configuration Parameters
File number: Restore point 1
Timed installation: No

Apply Export Import Delete Backup Restore FTP Parameters FTP Port

4. Click **FTP Parameters** to display the FTP Parameters page.

Figure 52 FTP Parameters Page

FTP Parameters

File transfer protocol: FTP
Username: anonymous
Password:
Server IP address: 0.0.0.0
Server IPv6 address: ::
Path:
File name:
Apply

Page Refresh Interval (Seconds): None Last Loaded: 15:49:42 Refresh Close

5. In the **File transfer protocol** field, select the file transfer protocol you want to use (**FTP** or **SFTP**).
6. In the **Username** field, enter the user name you configured in the FTP server.
7. In the **Password** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP user, simply leave this field blank.
8. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP server in the **Server IP address** field. See *Defining the IP Protocol Version for Initiating Communications*.

9. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP server in the **Server IPv6 Address** field. See *Defining the IP Protocol Version for Initiating Communications*.
10. In the **Path** field, enter the location of the file you are downloading or uploading. If the location is the root shared folder, it should be left empty. If the location is a sub-folder under the root shared folder, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".
11. In the **File name** field, enter the name of the file you are importing, or the name you want to give the file you are exporting.

**Note**

You must add the suffix **.zip** to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix **.zip** manually.

12. Click **Apply**, then **Close**, to save the FTP parameters and return to the Configuration Management page
13. In the **File number** field, select from three system restore points:
 - When you import a configuration file, the file is saved to the selected restore point, and overwrites whichever file was previously held in that restore point.
 - When you export a configuration file, the file is exported from the selected restore point.
 - When you back up the current configuration, the backup configuration file is saved to the selected restore point, and overwrites whichever file was previously held in that restore point.
 - When you restore a configuration, the configuration file in the selected restore point is the file that is restored.

**Note**

The **Timed installation** field is reserved for future use.

14. Click **Apply** to save your settings.

Exporting a Configuration File

You can export a saved configuration file from one of the system's three restore points to a PC or laptop.

To export a configuration file:

1. Verify that you have followed all the steps in [Setting the Configuration Management Parameters](#).
2. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens ([Figure 116](#)).
3. In the **File Number** field, select the restore point from which you want to export the file.
4. Click **Apply** to save your settings.
5. Click **Export**. The export begins. You can view the status of the export in the **File Transfer status** field in the Export/Import file status section. Possible values are:
 - **Ready** – The default value, which appears when no import or export is in progress.
 - **File-in-Transfer** – The file export is in progress.
 - If an error occurs during the import or export, an appropriate error message is displayed in this field.

When the import or export is complete, one of the following status indications appears:

- **Succeeded**
- **Failure**

The next time the system is reset, the **File Transfer status** field returns to **Ready**.

Importing a Configuration File

You can import a saved configuration file from a PC or laptop to one of the system's three restore points.

To import a configuration file:

1. Verify that you have followed all the steps in [Setting the Configuration Management Parameters](#).
2. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens ([Figure 116](#)).
3. In the **File Number** field, select the restore point to which you want to import the file.
4. Click **Apply** to save your settings.
5. Click **Import**. The import begins. You can view the status of the import in the **File Transfer status** field in the Export/Import file status section. Possible values are:
 - **Ready** – The default value, which appears when no import or export is in progress.
 - **File-in-Transfer** – The file import is in progress.
 - If an error occurs during the import or export, an appropriate error message is displayed in this field.

When the import or export is complete, one of the following status indications appears:

- **Succeeded**
- **Failure**

The next time the system is reset, the **File Transfer status** field returns to **Ready**.

After importing the configuration file, you can apply the configuration by restoring the file from the restore point to which you saved it. See [Restoring a Saved Configuration](#).

Deleting a Configuration File

You can delete a saved configuration file from any of the system's three restore points:

To delete a configuration file:

1. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens (Figure 116).
2. In the **File Number** field, select the restore point that holds the configuration file you want to delete.
3. Click **Delete**. The file is deleted.

Backing Up the Current Configuration

You can back up the current configuration file to one of the system's three restore points.

To back up a configuration file:

1. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens (Figure 116).
2. In the **File Number** field, select the restore point to which you want to back up the file. If another configuration file is already saved to that restore point, it will be overwritten by the file you back up.
3. Click **Backup**. The backup begins. You can view the status of the backup in the **Backup file creation status** field. Possible values in the status field are:
 - **Ready** – The default value, which appears when no backup is in progress.
 - **Generating file** – The system is verifying the files to be backed up.

If an error occurs during the backup, an appropriate error message is displayed in this field.

When the backup is complete, one of the following status indications appears:

- **Succeeded**
- **Failure**

The next time the system is reset, the **Backup file creation status** field returns to **Ready**.

Restoring a Saved Configuration

You can replace the current configuration with any configuration file saved to one of the system's three restore points by restoring the configuration file from the restore point.

To restore a configuration file:

1. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens (Figure 116 Configuration Management Page).
2. In the **File Number** field, select the restore point that holds the configuration you want to restore.
3. Click **Restore**. The configuration restoration begins. You can view the status of the restoration in the **Configuration restore status** field.



Note

While a configuration restoration is taking place, no user can make any changes to the configuration. All system configuration parameters are read-only during the configuration restoration.

Editing CLI Scripts

The configuration file package includes a text file that enables you to write CLI scripts in a backed-up configuration that are executed after restoring the configuration.

To edit a CLI script:

1. Back up the current configuration to one of the restore points. See [Backing Up the Current Configuration](#).
2. Export the configuration from the restore point to a PC or laptop. See [Exporting a Configuration File](#).
3. On the PC or laptop, unzip the file *Configuration_files.zip*.
4. Edit the *cli_script.txt* file using clish commands, one per line.
5. Save and close the *cli_script.txt* file, and add it back into the *Configuration_files.zip* file.
6. Import the updated *Configuration_files.zip* file back into the unit. See [Importing a Configuration File](#).
7. Restore the imported configuration file. See [Restoring a Saved Configuration](#). The unit is automatically reset. During initialization, the CLI script is executed, line by line.

**Note**

If any specific command in the CLI script requires reset, the unit is reset when that that command is executed. During initialization following the reset, execution of the CLI script continues from the following command.

Setting the Unit to the Factory Default Configuration

You can restore the unit to its factory default configuration, while retaining the unit's IP address settings and logs.

To restore the factory default settings:

1. Select **Platform > Shelf Management > Chassis Configuration**. The Chassis Configuration page opens.



Figure 53: Chassis Configuration Page

2. Click **Set to Factory Default**. The unit is restored to its factory default settings. This does not change the unit's IP address.

Performing a Hard (Cold) Reset

To initiate a hard (cold) reset on the unit:

1. Select **Platform > Shelf Management > Chassis Configuration**. The Chassis Configuration page opens (*Figure 53*).
2. Click **Reset**.
3. A prompt appears asking if you want to proceed with the reset. Click **Yes** to initiate the reset.

The unit is reset.

Configuring Unit Parameters

To view and configure system information:

1. Select **Platform > Management > Unit Parameters**. The Unit Parameters page opens.
2. [Table 25](#) describes the fields in the Unit Parameters page.

Figure 54 Unit Parameters Page

The screenshot shows a web interface for configuring unit parameters. The top navigation bar includes 'Logout', 'Connection', and 'Admin'. The left sidebar has a 'Filter' dropdown and a list of navigation links: 'Unit Summary', 'Radio Summary', 'Platform' (expanded), 'Shelf Management', 'Interfaces', 'Management' (expanded), 'Unit Parameters' (selected), 'NTP Configuration', 'Time Services', 'Inventory', 'Unit Info', 'Login Banner', 'Networking', 'SNMP', 'Software', 'Configuration', 'Activation Key', 'Security', 'PM & Statistics', 'Faults', 'Radio', 'Ethernet', 'Sync', 'Quick Configuration', and 'Utilities'. The main content area is titled 'Microwave radio: Unit Parameters' and contains the following fields:

- Name:** Microwave radio
- Description:** All outdoor E-band system
- System up time:** 2 hours, 2 minutes, 6 seconds
- Contact person:**
- Location:**
- Longitude:**
- Latitude:**
- WEB Language:** English
- Measurement format:** metric
- Unit Temperature:** 42°C, 107.6°F
- Voltage input (Volt):** 48
- User Comment:**

An 'Apply' button is located at the bottom of the form.

Table 19 Unit Parameters

Parameter	Definition
Name	A name for the unit (optional, up to 128 characters). This name appears at the top of every Web EMS page.
Description	Descriptive information about the unit. This information is used for debugging, and should include information such as the unit type.
System up time	The time since the system was last reinitialized.
Contact person	The name of the person to be contacted if and when a problem with the system occurs (optional).
Location	The actual physical location of the node or agent (optional).

Parameter	Definition
Longitude	The unit's longitude coordinates.
Latitude	The unit's latitude coordinates.
Web Language	Enables you to select the language in which the Web EMS is displayed. In release 10.9, the following languages are available: <ul style="list-style-type: none">• English (default)• Russian
Measurement format	The type of measurement you want the system to use: Metric or Imperial .
Unit Temperature	The current temperature of the unit. If the unit temperature goes lower than -40°C or higher than 90°C, the unit raises an extreme temperature alarm (Alarm ID 25). This alarm is cleared when the unit temperature rises above -37°C or goes below 87°C.
Voltage input (Volt)	The voltage input of the unit.
User Comment	A free text field for any information you want to record (up to 500 characters).

Configuring NTP

PTP 850E supports Network Time Protocol (NTP). NTP distributes Coordinated Universal Time (UTC) throughout the system, using a jitter buffer to neutralize the effects of variable latency.

To view and configure the NTP Parameters:

1. Select **Platform > Management > NTP Configuration**. The NTP Configuration page opens.

Figure 55 NTP Configuration Page

The screenshot shows the 'Microwave radio: NTP Configuration' page. The sidebar on the left contains a 'Filter' box and a list of navigation links: Unit Summary, Radio Summary, Platform (expanded), Shelf Management, Interfaces, Management (expanded), Unit Parameters, NTP Configuration (selected), Time Services, Inventory, Unit Info, Login Banner, Networking, SNMP, Software, Configuration, Activation Key, Security, PM & Statistics, Faults, Radio, Ethernet, Sync, Quick Configuration, and Utilities. The main configuration area is titled 'NTP Configuration - Edit' and contains the following fields:

- Poll interval (seconds): 0
- Sync on NTP server IP address: 0.0.0.0
- Client lock status: N/A
- NTP Admin: Disable (dropdown)
- NTP version: NTPv4 (dropdown)
- NTP server IP address: 0.0.0.0

An 'Apply' button is located at the bottom of the configuration area.

2. In the **NTP Admin** field, select **Enable**.
3. In the **NTP version** field, select the NTP version you want to use. Options are **NTPv3** and **NTPv4**. NTPv4 provides interoperability with NTPv3 and with SNTP.
4. In the **NTP server IP address** field, enter the IP address of the NTP server.
5. Click **Apply**.

Table 20 describes the status parameters that appear in the NTP Configuration page.


Table 20 NTP Status Parameters

Parameter	Definition
Poll interval	Displays the interval used by the NTP client to maintain synchronization with the current NTP server.
Sync on NTP server IP address	Displays the IP address of the remote NTP server on which the NTP client is currently locked.
Client lock status	<p>Indicates if the NTP client is locked on a remote NTP server. Possible values are:</p> <ul style="list-style-type: none">• LOCK – The NTP client is locked on the remote server.• LOCAL – The NTP client is locked on the local system clock (free running clock).• N/A – The NTP client is not locked on any clock.

Displaying Unit Inventory

To view the unit's part number and serial number:
Select **Platform > Management > Inventory**. The Inventory page opens, showing the unit's part number and serial number.

Figure 56 Inventory Page



Defining a Login Banner

You can define a login banner of up to 2,000 bytes. This banner will appear every time a user establishes a connection with the Web EMS. The banner appears before the login prompt, so that users will always see the login banner and must manually close the banner before logging in to the Web EMS.

To define a login banner:

- 1 Select **Platform > Management > Login Banner**. The Login Banner page opens.

Figure 57 Login Banner Page

The screenshot shows the Web EMS interface. At the top, there is a navigation bar with 'Logout', 'Connection', and 'Admin' icons. Below this is a sidebar menu with a 'Filter' box. The menu items include 'Unit Summary', 'Radio Summary', 'Platform' (expanded), 'Shelf Management', 'Interfaces', 'Management' (expanded), 'Unit Parameters', 'NTP Configuration', 'Time Services', 'Inventory', 'Unit Info', 'Login Banner' (selected), 'Networking', 'SNMP', 'Software', 'Configuration', 'Activation Key', 'Security', 'PM & Statistics', 'Faults', 'Radio', 'Ethernet', 'Sync', 'Quick Configuration', and 'Utilities'. The main content area is titled 'Microwave radio: Login Banner'. It contains a text input field with the placeholder text 'Text message that appears when connecting to unit'. Below the input field are two buttons: 'Apply' and 'Test Banner'.

- 2 Enter a text message of up to 2,000 bytes.
- 3 To display a test banner as it will appear to users, click **Test Banner**.
- 4 Click **Apply**.

Chapter 5: Radio Configuration

This section includes:

- [Viewing the Radio Status and Settings](#)
- [Configuring the Remote Radio Parameters](#)
- [Configuring and Viewing Radio PMs and Statistics](#)

Related topics:

- [Configuring the Radio Parameters](#)
- [Configuring the Radio \(MRMC\) Script\(s\)](#)
- [Configuring the Remote Radio Parameters](#)

Viewing the Radio Status and Settings

You can configure the radios and display the radio parameters in the Radio Parameters page.



Note

For instructions how to configure the radio parameters, see [Configuring the Radio Parameters](#).

To display the radio parameters:

1. Select **Radio > Radio Parameters**. The Radio Parameters page opens.

Figure 58 Radio Parameters Page

The screenshot shows the 'Microwave radio: Radio Parameters' page. The left sidebar contains a navigation menu with options like Unit Summary, Radio Summary, Platform, Faults, Radio, Ethernet Interface, MRMC, PM & Statistics, Diagnostics, Ethernet, Sync, Quick Configuration, and Utilities. The main content area is divided into three sections: Status Parameters, Frequency control (Local), and Configuration Parameters.

Status Parameters	
Radio Location	Radio: Slot 1, Port 1
Type	RFU-50E
XPIC support	No
Radio Interface operational status	Down
Operational TX Level (dBm)	-20
RX Level (dBm)	-72
Modem MSE (dB)	-99.00
Defective Blocks	0
TX Mute Status	On
Adaptive TX power operational status	Down
Temperature	44°C, 111°F

Clear Counter

Frequency control (Local)	
TX Frequency (MHz)	83500.000 (81125.000 ... 85875.000)
RX Frequency (MHz)	73500.000 (71125.000 ... 75875.000)
Frequency Separation (MHz)	10000.000
<input type="checkbox"/> Set also remote unit	

Configuration Parameters	
TX Mute	Mute
TX Level (dBm)	15 (-2 ... 16)
RSL Connector Source	Main
Link Id	1 (1 ... 65535)
Adaptive TX power admin	Disable
RSL degradation alarm	Disable
RSL degradation threshold	-68

Apply

[Table 30](#) lists and describes the parameters displayed in the **Status parameters** section of the Radio Parameters page. The configurable parameters are described in *Configuring the Radio Parameters*.

Table 21 Radio Status Parameters

Parameter	Description
Type	The RF module type.
XPIC Support	Reserved for future use.
Radio Interface operational status	Indicates whether the carrier is operational (Up) or not operational (Down).
Operational TX Level (dBm)	The actual TX signal level (TSL) of the carrier (in dBm).
RX Level (dBm)	The actual measured RX signal level (RSL) of the carrier (in dBm).
Modem MSE (dB)	The MSE (Mean Square Error) of the RX signal, measured in dB. A value of 0 means that the modem is not locked.
Modem XPI (dB)	The XPI (Cross Polarization Interference) level, measured in dB.
Defective Blocks	The number of defective radio blocks that have been counted. Click Clear Counter to reset this counter.
TX Mute Status	Indicates whether radio transmission is muted.
Adaptive TX power operational status	Indicates whether Adaptive TX power is currently operational.
Temperature	The internal temperature of the unit.
TX Frequency	The configured TX radio frequency (MHz). The TX radio frequency is configured in the Frequency control (Local) section of the Radio Parameters page. See <i>Configuring the Radio Parameters</i> .
RX Frequency	The configured RX radio frequency (MHz). The RX radio frequency is configured in the Frequency control (Local) section of the Radio Parameters page. See <i>Configuring the Radio Parameters</i> .
Frequency Separation	The frequency separation, based on the configured TX and RX frequencies.

Configuring the Remote Radio Parameters

You can view and configure the parameters of the carrier or carriers at the remote side of the link in the Remote Radio Parameters page.

To display the remote radio parameters:

1. Select **Radio > Remote Radio Parameters**. The Remote Radio Parameters page opens.



Note

Release 10.6 does not support the ability to configure remote parameters.

Figure 59 Remote Radio Parameters Page

2. Configure the remote radio parameters. For a description of these parameters, see [Table 31 Remote Radio Parameters](#).
3. Click **Apply**.

To reset the remote unit, click **Reset Remote Unit**.

Table 22 Remote Radio Parameters

Parameter	Definition
Radio Location	Read-only. Identifies the carrier.
Remote Radio Location	Read-only. Identifies the location of the remote radio.
Local Remote Channel Operational Status	Read-only. The operational status of the local-remote channel.
Remote Receiver Signal Level	Read-only. The Rx level of the remote radio, in dBm.
Remote Most Severe Alarm	Read-only. The level of the most severe alarm currently active on the remote unit.
Remote Tx Output Level	Set the remote unit's Tx output level (in dBm).

Parameter	Definition
Remote Radio Mute	To mute the TX output of the remote radio, select On . To unmute the TX output of the remote radio, select Off .
Remote IP Address	The IPv4 IP address of the remote unit.
Remote IPv6 Address	The IPv6 IP address of the remote unit.

Configuring and Viewing Radio PMs and Statistics

This section includes:

- [Configuring BER Thresholds and Displaying Current BER](#)
- [Displaying MPMC Status](#)
- [Displaying MPMC PMs](#)
- [Displaying and Clearing Defective Block Counters](#)
- [Displaying Signal Level PMs and Configuring Signal Level PM Thresholds](#)
- [Displaying Modem BER \(Aggregate\) PMs](#)
- [Displaying MSE PMs and Configuring MSE PM Thresholds](#)
-

**Note**

The **Radio > PM & Statistics > Diversity** and **Radio > PM & Statistics > Combined** pages are reserved for future use.

Configuring BER Thresholds and Displaying Current BER

You can configure PM thresholds, BER thresholds, and Excessive BER Administration. This enables you to define the levels at which certain PMs are counted, such as the number of seconds in which the configured threshold RX and TX levels are exceeded. This also enables you to define the levels at which certain alarms are triggered.

- Signal level PM thresholds, such as RX and TX level thresholds, are configured from the Signal Level PM Report page. See [Displaying Signal Level PMs and Configuring Signal Level PM Thresholds](#).
- MSE PM Thresholds are configured from the MSE PM Report page. See [Displaying MSE PMs and Configuring MSE PM Thresholds](#).

You can also display the current BER level.

To configure the BER thresholds and Excessive BER Administration, and display current BER levels

1. Select **Radio > Radio BER Thresholds**. The Radio BER Thresholds page opens. The current BER level is displayed, per radio, in the Radio BER column.

Figure 60 Radio BER Thresholds Page

2. In the **Excessive BER admin** field, select **Enable** to enable excessive BER administration or **Disable** to disable excessive BER administration. Excessive BER administration determines whether or not excessive BER is propagated as a fault and considered a system event. For example, if excessive BER administration is enabled, excessive BER can trigger a protection switchover and can cause a synchronization source to go into a failure status. Excessive BER administration is enabled or disabled for the entire unit rather than for specific radios.
3. In the **Excessive BER Threshold** field, select the level above which an excessive BER alarm is issued for errors detected over the radio link.
4. In the **Signal Degrade BER Threshold** field, select the level above which a Signal Degrade alarm is issued for errors detected over the radio link.
5. Click **Apply**, then **Close**.

Displaying MRMC Status

Related Topics:

- [Configuring the Radio \(MRMC\) Script\(s\)](#)

To display the current modulation and bit rate per radio:

1. Select **Radio > MRMC > MRMC Status**. The MRMC Status page opens.

Figure 61 MRMC Status Page

Logout

Connection

Admin

Filter

Unit Summary

Radio Summary

Platform

Faults

Radio

- Radio Parameters
- Remote Radio Parameters
- Radio BER Thresholds

Ethernet Interface

MRMC

- Symmetrical Scripts
- MRMC Status

PM & Statistics

Diagnostics

Ethernet

Sync

Quick Configuration

Utilities

Microwave radio: MRMC Status

MRMC Status

Radio location

Radio: Slot 1, Port 1

Operational MRMC script ID

5703

Script Name

mdN_A250250N_6_5703

Script Standard

ETSI+FCC

MRMC Script operational mode

Adaptive

MRMC Script maximum profile

10, 512 QAM, 1720.160 Mbps

MRMC Script minimum profile

2, 2 QAM, 190.139 Mbps

Adaptive TX power admin

Disable

MRMC TX Status

TX profile

10

TX QAM

512

TX bit-rate (Mbps)

1720.160

MRMC RX Status

RX profile

10

RX QAM


512

RX bit-rate (Mbps)

1720.160

Apply

Table 23 describes the MRMC status parameters.



Note

To display the same parameters for an individual radio in a separate page, select the radio in the MRMC script status table and click **Edit**.

Table 23 MRMC Status Parameters

Parameter	Definition
Radio Location	Displays the location of the radio.
Operational MRMC Script ID	The current MRMC script.
Script Name	The name of the script.
Script Standard	Indicates whether the script is compatible with ETSI or FCC (ANSI) standards, or both.
MRMC Script operational mode	<p>The ACM mode: Fixed or Adaptive.</p> <ul style="list-style-type: none"> Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels. In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.
MRMC Script profile	Fixed ACM mode only: The profile in which the system will operate.
MRMC Script maximum profile	Adaptive ACM mode only: The maximum profile for the script. For example, if you select a maximum profile of 5, the system will not climb above profile 5, even if channel fading conditions allow it.
MRMC Script minimum profile	<p>Adaptive ACM mode only: The minimum profile for the script. For example, if you select a minimum profile of 3, the system will not go below profile 3 regardless of the channel fading conditions. The minimum profile cannot be greater than the maximum profile, but it can be equal to it.</p> <p>Note: The default minimum profile is 2.</p>
Adaptive Tx Power Admin	Enables or disables Adaptive TX Power. When Adaptive TX Power is enabled, the radio adjusts its TX power dynamically based on the current modulation. When the modulation is at a high level, the TX power is adjusted to the level required with the high modulation. If the modulation goes down to a lower level, the TX power increases to compensate for the lower modulation. The TX level configured in the TX Level (dBm) field of the Radio Parameters page determines the maximum TX level, but the actual TX level as shown in the Operational TX Level (dBm) field of the Radio Parameters page can be expected to be lower when the radio is operating at high modulations requiring less TX power. See <i>Configuring the Radio Parameters</i> .
TX profile	The current TX profile.
TX QAM	The current TX modulation.
TX bit-rate	The current TX bit-rate (Mbps).
RX profile	The current RX profile.
RX QAM	The current RX modulation.
RX bit-rate	The current RX bit-rate (Mbps).

Displaying MPMC PMs

Related Topics:

- [Configuring the Radio \(MPMC\) Script\(s\)](#)

To display Multi-Rate Multi-Constellation PMs, including information on ACM profile fluctuations per interval per radio:

1. Select **Radio > PM & Statistics > MPMC**. The MPMC PM Report page opens.

Figure 62 MPMC PM Report Page

#	Interval	Min profile	Max profile	Min bitrate	Max bitrate	Integrity
	Current (03:44:26)	0	0	47535	47535	X
1	28-Mar-00 03:30	0	0	47535	47535	X
2	28-Mar-00 03:15	0	0	47535	47535	X
3	28-Mar-00 03:00	0	0	47535	47535	X
4	28-Mar-00 02:45	0	0	47535	47535	X
5	28-Mar-00 02:30	0	0	47535	47535	X
6	28-Mar-00 02:15	0	0	47535	47535	X
7	28-Mar-00 02:00	0	0	47535	47535	X
8	28-Mar-00 01:45	0	0	47535	47535	X
9	28-Mar-00 01:30	0	0	47535	47535	X
10	28-Mar-00 01:15	0	0	47535	47535	X

2. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

[Table 24](#) describes the MPMC PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the MPMC PM table and click **View**.

Table 24 MPMC PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Min profile	Displays the minimum ACM profile that was measured during the interval.
Max profile	Displays the maximum ACM profile that was measured during the interval.

Parameter	Definition
Min bitrate	Displays the minimum total radio throughput (Mbps) delivered during the interval.
Max bitrate	Displays the maximum total radio throughput (Mbps) delivered during the interval.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.


Displaying and Clearing Defective Block Counters

The Counters page displays the number of blocks in which errors were detected. The larger the amount, the poorer the radio link quality.

To display the number of blocks in which errors were detected per radio:

1. Select **Radio > PM & Statistics > Counters**. The Counters page opens.

Figure 63 Counters Page



2. To clear the counters, click **Clear Counters**.

Displaying Signal Level PMs and Configuring Signal Level PM Thresholds

To display signal level PMs per radio:

1. Select **Radio > PM & Statistics > Signal Level**. The Signal Level PM report page opens.

Figure 64 Signal Level PM Report Page

Microwave radio: Signal Level PM report (Radio: Slot 1, Port 1, 15 minutes)

Interface: Radio: Slot 1, Port 1 Interval Type: 15 minutes

▼ PM Table

#	Interval ▲	Max TSL (dBm)	Min TSL (dBm)	Max RSL (dBm)	Min RSL (dBm)	TSL exceed threshold seconds	RSL exceed threshold1 seconds	RSL exceed threshold2 seconds	Integrity
	Current (03:46:29)	-20	-20	-71	-72	0	88	88	✓
1	28-Mar-00 03:45	-20	-20	-12	-82	0	238	237	✗
2	28-Mar-00 03:30	-20	-20	-71	-72	0	900	900	✓
3	28-Mar-00 03:15	-20	-20	-71	-72	0	900	900	✓
4	28-Mar-00 03:00	-20	-20	-71	-72	0	900	900	✓
5	28-Mar-00 02:45	-20	-20	-71	-72	0	900	900	✓
6	28-Mar-00 02:30	-20	-20	-71	-72	0	900	900	✓
7	28-Mar-00 02:15	-20	-20	-71	-72	0	900	900	✓
8	28-Mar-00 02:00	-20	-20	-72	-73	0	900	900	✓
9	28-Mar-00 01:45	-20	-20	-72	-73	0	900	900	✓
10	28-Mar-00 01:30	-20	-20	-72	-74	0	900	900	✓
11	28-Mar-00 01:15	-20	-20	-11	-85	0	108	108	✗

View Thresholds Graph

2. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

Table 25 describes the Signal Level PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the RF PM table and click **View**.

Table 25 Signal Level PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Max TSL (dBm)	The maximum TSL (Transmit Signal Level) that was measured during the interval.
Min TSL (dBm)	The minimum TSL (Transmit Signal Level) that was measured during the interval.
Max RSL (dBm)	The maximum RSL (Received Signal Level) that was measured during the interval.
Min RSL (dBm)	The minimum RSL (Received Signal Level) that was measured during the interval.

Parameter	Definition
TSL exceed threshold seconds	The number of seconds the measured TSL exceeded the threshold during the interval. TSL thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER
RSL exceed threshold1 seconds	The number of seconds the measured RSL exceeded RSL threshold 1 during the interval. RSL thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER .
RSL exceed threshold2 seconds	The number of seconds the measured RSL exceeded RSL threshold 2 during the interval. RSL thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

To set the Signal Level PM thresholds, click **Thresholds**. The Signal Level Thresholds Configuration – Edit Page opens. Set the thresholds, described in [Table 36](#), and click **Apply**.

Figure 65 Signal Level Thresholds Configuration - Edit Page

Thresholds Configuration - Edit

Radio location: Radio: Slot 1, Port 1

RX Level Threshold 1 (dBm): -50

RX Level Threshold 2 (dBm): -68

TX Level Threshold (dBm): 25

Apply

Page Refresh Interval (Seconds): None

Last Loaded: 10:32:11

Refresh Close


Table 26 Signal Level Thresholds

Parameter	Definition
RX Level Threshold 1 (dBm)	Specify the threshold for counting exceeded seconds if the RSL is below this level.
RX Level Threshold 2 (dBm)	Specify a second threshold for counting exceeded seconds if the RSL is below this level.
TX Level Threshold (dBm)	Specify the threshold for counting exceeded seconds if the TSL is below this level.

Displaying Modem BER (Aggregate) PMs

To display modem BER (Bit Error Rate) PMs per radio:

1. Select **Radio > PM & Statistics > Aggregate**. The Aggregate PM report page opens.

Figure 66 Aggregate PM Report Page

2. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

Table 27 describes the Modem BER (Aggregate) PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the Modem BER PM table and click **View**.

Table 27 Modem BER (Aggregate) PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
ES	Displays the number of seconds in the measuring interval during which errors occurred.
SES	Displays the number of severe error seconds in the measuring interval.
UAS	Displays the Unavailable Seconds value of the measured interval. The value can be between 0 and 900 seconds (15 minutes).
BBE	Displays the number of background block errors during the measured interval.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

Displaying MSE PMs and Configuring MSE PM Thresholds

To display modem MSE (Minimum Square Error) PMs per radio:

1. Select **Radio > PM & Statistics > MSE**. The MSE PM report page opens.

Figure 67 MSE PM Report Page

#	Interval	Min MSE (dB)	Max MSE (dB)	Exceed threshold seconds	Integrity
	Current (03:59:39)	0	0	0	X
1	28-Mar-00 03:45	0	0	0	X
2	28-Mar-00 03:30	0	0	0	X
3	28-Mar-00 03:15	0	0	0	X
4	28-Mar-00 03:00	0	0	0	X
5	28-Mar-00 02:45	0	0	0	X
6	28-Mar-00 02:30	0	0	0	X
7	28-Mar-00 02:15	0	0	0	X
8	28-Mar-00 02:00	0	0	0	X
9	28-Mar-00 01:45	0	0	0	X
10	28-Mar-00 01:30	0	0	0	X
11	28-Mar-00 01:15	0	0	0	X

2. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

Table 28 describes the Modem MSE PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the Modem MSE PM table and click **View**.

Table 28 Modem MSE PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Min MSE (dB)	Displays the minimum MSE in dB, measured during the interval. A 0 in this field and an X in the Integrity field may also indicate that the modem was unlocked during the entire interval.
Max MSE (dB)	Displays the maximum MSE in dB, measured during the interval. A 0 in this field and an X in the Integrity field may also indicate that the modem was unlocked.

Parameter	Definition
Exceed threshold seconds	Displays the number of seconds the MSE exceeded the MSE PM threshold during the interval. The MSE PM is configured in the Radio Thresholds page. See Configuring BER Thresholds AND Displaying Current BER.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time. An X and a 0 value in the Max MSE field may also indicate that the modem was unlocked.

To set the Modem MSE PM thresholds, click **Thresholds**. The Modem MSE Thresholds Configuration– Edit Page opens. For each radio, specify the modem MSE (Mean Square Error) threshold for calculating MSE Exceed Threshold seconds, and click **Apply**.

Figure 68 Modem MSE Thresholds Configuration – Edit Page

Thresholds Configuration - Edit

Radio location: Radio: Slot 1, Port 1

MSE PM Threshold (dB): -34

Apply

Page Refresh Interval (Seconds): None

Last Loaded: 10:41:46

Refresh Close

Chapter 6: Ethernet Services and Interfaces

This section includes:

- [Configuring Ethernet Service\(s\)](#)
- [Setting the MRU Size and the S-VLAN Ethertype](#)
- [Configuring Ethernet Interfaces](#)
- [Configuring Automatic State Propagation and Link Loss Forwarding.](#)
- [Viewing Ethernet PMs and Statistics](#)

Related topics:

- [Quality of Service \(QoS\)](#)
- [Performing Ethernet Loopback](#)

Configuring Ethernet Service(s)

This section includes:

- [Ethernet Services Overview](#)
- [General Guidelines for Provisioning Ethernet Services](#)
- [The Ethernet Services Page](#)
- [Adding an Ethernet Service](#)
- [Editing a Service](#)
- [Deleting a Service](#)
- [Enabling, Disabling, or Deleting Multiple Services](#)
- [Viewing Service Details](#)
- [Configuring Service Points](#)

Ethernet Services Overview

Users can define up to 64 Ethernet services. Each service constitutes a virtual bridge that defines the connectivity between logical ports in the PTP 850 network element.

This version of PTP 850 supports the following service types:

- Multipoint (MP)
- Point-to-Point (P2P)
- Management (MNG)

**Note**

In release 10.6, only P2P and MNG services are supported. In release 10.9, Multipoint services are also supported.

In addition to user-defined services, PTP 850 contains a pre-defined management service (Service ID 1025). By default, this service is operational.

**Note**

You can use the management service for in-band management. For instructions on configuring in-band management, see [Configuring In-Band Management](#).

A service point is a logical entity attached to a physical or logical interface. Service points define the movement of frames through the service. Each service point includes both ingress and egress attributes. A Point-to-Point or Multipoint service can hold up to 32 service points. A Management service can hold up to 30 service points.

For a more detailed overview of PTP 850's service-oriented Ethernet switching engine, refer to the Technical Description for the PTP 850.

General Guidelines for Provisioning Ethernet Services

When provisioning Ethernet services, it is recommended to follow these guidelines:

- Use the same Service ID for all service fragments along the path of the service.
- Do not re-use the same Service ID within the same region. A region is defined as consisting of all PTP 850 devices having Ethernet connectivity between them.
- Use meaningful EVC IDs.
- Give the same EVC ID (service name) to all service fragments along the path of the service.
- Do not reuse the same EVC ID within the same region.

It is recommended to follow these guidelines for creating service points:

- Always use SNP service points on NNI ports and SAP service points on UNI ports.
- For each logical interface associated with a specific service, there should never be more than a single service point.
- The transport VLAN ID should be unique per service within a single region. That is, no two services should use the same transport VLAN ID.

The Ethernet Services Page

The Ethernet Services page is the starting point for defining Ethernet services on the PTP 850.

To open the Ethernet Services page:

1. Select **Ethernet > Services**. The Ethernet Services page opens.

Figure 69 Ethernet Services Page




Table 29 Ethernet Services Page Parameters

Parameter	Definition
Services ID	A unique ID for the service.
Service Type	<p>The service type:</p> <ul style="list-style-type: none"> • MP – Multipoint • P2P – Point-to-Point • MNG – Management <p>Note: In release 10.6, only P2P and MNG services are supported. In release 10.9, MP services are also supported.</p>
Service sub type	Indicates the type of service (Ethernet).
EVC ID	The Ethernet Virtual Connection (EVC) ID. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
EVC description	The Ethernet Virtual Connection (EVC) description. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
Admin	Indicates whether the service is enabled (Operational) or disabled (Reserved). You can configure services for later use by defining the service as Reserved . In Reserved mode, the service occupies system resources but is unable to transmit and receive data.

Adding an Ethernet Service

To add an Ethernet service:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 93](#)).
2. In the Ethernet Services page, click **Add**. The Ethernet Services – Add page opens.

Figure 70 Ethernet Services - Add page

3. In the **Service ID** field, select a unique ID for the service. You can choose any unused value from 1 to 1024. Once you have added the service, you cannot change the Service ID. Service ID 1025 is reserved for a pre-defined management service.
4. In the **Service Type** field, select the service type:
 - **MP** – Multipoint
 - **MNG** – Management
 - **P2P** – Point-to-Point
5. Optionally, in the **EVC ID** field, enter an Ethernet Virtual Connection (EVC) ID (up to 20 characters). This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
6. Optionally, in the **EVC Description** field, enter a text description of the service (up to 64 characters). This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
7. In the **Admin** field, select one of the following options:
 - **Operational** - The service is functional.
 - **Reserved** - The service is disabled until this parameter is changed to **Operational**. In this mode, the service occupies system resources but is unable to receive and transmit data.
8. In the **MAC table size** field, enter the maximum MAC address table size for the service. The MAC address table is a source MAC address learning table used to forward frames from one service point to another. You can select a value from 16 to 131,072, in multiples of 16. This maximum only applies to dynamic, not static, MAC address table entries.

**Note**

Additional configuration of the MAC address table can be performed via the CLI. See [Defining the MAC Address Forwarding Table for a Service](#).

9. In the **Default CoS** field, enter a default Class of Service (CoS) value (0-7). This value is assigned to frames at the service level if CoS Mode is set to Default-CoS. Otherwise, this value is not used, and frames retain whatever CoS value they were assigned at the service point or logical interface level.
10. In the **CoS Mode** field, select one of the following options. This parameter determines whether or not frames passing through the service have their CoS modified at the service level. The CoS determines the priority queue to which frames are assigned.
 - **Default CoS** – Frames passing through the service are assigned the default CoS defined above. This CoS value overrides whatever CoS may have been assigned at the service point or interface level.
 - **Preserve-SP-COS-Decision** – The CoS of frames passing through the service is not modified by the service's default CoS.
11. Click **Apply**, then **Close** to close the Ethernet Services - Add page.
12. Add service points. You must add service points to the service in order for the service to carry traffic. See [Configuring Service Points](#).

Editing a Service

To edit a service:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 93](#)).
2. Select the service in the Service Configuration Table.
3. In the Ethernet Services page, click **Edit**. The Ethernet Services - Edit page opens.
4. This page is identical to the Ethernet Services - Add page ([Figure 94](#)). You can edit any parameter that can be configured in the Add page, except the **Service ID**.

Deleting a Service

Before deleting a service, you must first delete any service points attached to the service.

To delete a service:

1. Delete all service points attached to the service you wish to delete, as described in [Deleting a Service Point](#).
2. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 93](#)).
3. Select the service in the Ethernet Service Configuration Table.
4. Click **Delete**. The service is deleted.


Enabling, Disabling, or Deleting Multiple Services

To enable, disable, or delete multiple services:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 93](#)).
2. Select the services in the Ethernet Services Configuration table, or select all the services by selecting the check box in the top row.
 - To enable the selected services, in the Multiple Selection Operation section underneath the Ethernet Services Configuration Table, select **Operational** and click **Apply**.

- To disable the selected services, in the Multiple Selection Operation section underneath the Ethernet Services Configuration Table, select **Reserved** and click **Apply**.
- To delete the selected services, select **Delete** underneath the Ethernet Services Configuration Table. Before deleting a service, you must delete any service points attached to the service, as described in [Deleting a Service Point](#).

Figure 71 Multiple Selection Operation Section (Ethernet Services)



When setting multiple services to **Reserve** state, make sure to avoid setting the management service to **Reserve** state

Viewing Service Details

To view the full service parameters:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 93](#)).
2. Select the service in the Ethernet Services Configuration table.
3. In the Ethernet Services page, click **Service Details**. The Ethernet Services – Service Details page opens. The Service Details page contains the same fields as the Add page ([Figure 93](#)). However, in the Service Details page, these fields are read-only.

Configuring Service Points

This section includes:

- [Ethernet Services Points Overview](#)
- [The Ethernet Service Points Page](#)
- [Adding a Service Point](#)
- [Editing a Service Point](#)
- [Deleting a Service Point](#)
- [Attaching VLANs](#)

Ethernet Services Points Overview

Service points are logical interfaces within a service. A service point is a logical entity attached to a physical or logical interface. Service points define the movement of frames through the service. Each service point includes both ingress and egress attributes.

Each service point for a Point-to-Point or Multipoint service can be either a Service Access Point (SAP) or a Service Network Point (SNP). A Point-to-Point service can also use Pipe service points.

- An SAP is equivalent to a UNI in MEF terminology and defines the connection of the user network with its access points. SAPs are used for Point-to-Point and Multipoint traffic services.
- An SNP is equivalent to an NNI or E-NNI in MEF terminology and defines the connection between the network elements in the user network. SNPs are used for Point-to-Point and Multipoint traffic services.
- A Pipe service point is used to create traffic connectivity between two ports in a port-based manner (Smart Pipe). In other words, all the traffic from one port passes to the other port.

Management services utilize Management (MNG) service points.

A Point-to-Point or Multipoint service can hold up to 32 service points. A management service can hold up to 30 service points.

The Ethernet Service Points Page

The Ethernet Service Points page is the starting point for configuring Ethernet service points.

To open the Ethernet Service Points page:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 93](#)).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens.

Figure 72 Ethernet Service Points Page

You can choose to display the following sets of attributes by selecting the appropriate button above the SP Attributes table:

- **General** – See [Ethernet Service Points – General SP Attributes Table](#)
- **Ingress** – See [2. Ethernet Service Points – Ingress Attributes](#)
- **Egress** – See [3. Ethernet Service Points – Egress Attributes](#)

To return to the Ethernet Services page at any time, click **Back to Services table** at the top of the Ethernet Service Points page.

1. Ethernet Service Points – General SP Attributes Table

The General SP Attributes table is shown in [Figure 160 Ethernet Service Points Page](#). [Table 44](#) describes the parameters displayed in the General SP Attributes table.

Table 30 General Service Point Attributes

Parameter	Definition
Service point ID	<p>This ID is unique within the service. For Point-to-Point and Multipoint services, the range of values is 1-32. For Management services, the range of values is 1-30.</p> <p>When adding a service point, you can select a service point ID from the available options in the Service point ID drop-down list in the Ethernet Service Points – Add page. Once you have added the service point, you cannot change the service point ID.</p>
Service point name	A descriptive name for the service point (optional). The Service Point Name can be up to 20 characters.

Parameter	Definition
Service point type	<p>The service point type. Options are:</p> <ul style="list-style-type: none"> • SAP – Service Access Point. • SNP – Service Network Point. • MNG – Management service point. • PIPE – Pipe service point. <p>The following rules apply to the mixing of different types of service points on a single logical interface:</p> <p>You cannot configure both SAPs and SNPs on the same logical interface.</p> <ul style="list-style-type: none"> • You can configure both SAPs or SNPs on the same logical interface as a MNG service point. • If you configure a Pipe service point on an interface, you cannot configure an SAP, SNP, or another Pipe service point on the same interface. You can, however, configure an MNG service point on the same interface. • You cannot configure more than one MNG service point on a single logical interface. • Once you have added the service point, you cannot change this parameter.
Interface location	<p>The physical or logical interface on which the service point is located. Once you have added the service point, you cannot change this parameter.</p>
Attached interface type	<p>The encapsulation type (Ethertype) for frames entering the service point. Once you have added the service point, you cannot change this parameter.</p> <p>The Attached Interface Type determines which frames enter the service via this service point, based on the frame's VLAN tagging. Since more than one service point may be associated with a single interface, frames are assigned to the earliest defined service point in case of conflict.</p> <p>For a list of available Attached Interface Types, the types of frames to which each one applies, and the service point types for which each one is available, see Table 35.</p>
C-Vlan encapsulation	<p>The C-VLAN classified into the service point. Options are 1-4094, Untagged, or N.A. (Not Applicable). Once you have added the service point, you cannot change this parameter.</p> <p>If you selected Bundle-C in the Attached Interface Type field, select Untagged or N.A. You can then add multiple C-VLANs via the Attach VLAN option. See Attaching VLANs.</p>

Parameter	Definition
S-Vlan encapsulation	<p>The S-VLAN classified into the service point. Options are 1-4094, Untagged, or N.A. (Not Applicable). Once you have added the service point, you cannot change this parameter.</p> <p>If you selected Bundle-S in the Attached Interface Type field, select the S-VLAN value to classify into the service point (1-4094), or select Untagged. You can then add multiple C-VLANs via the Attach VLAN option. See Attaching VLANs.</p>

[Table 45](#) describes the available Attached Interface Types.

Table 31 Attached Interface Types

Attached Interface Type	Types of Frames	Available for Service Point Types
dot1q	A single C-VLAN is classified into the service point.	All
s-tag	A single S-VLAN is classified into the service point.	SNP, PIPE, and MNG
Bundle-C	A set of C-VLANs is classified into the service point.	SAP
Bundle-S	A single S-VLAN and a set of C-VLANs are classified into the service point.	SAP
All-to-One	All C-VLANs and untagged frames that enter the interface are classified into the service point.	SAP
Q-in-Q	A single S-VLAN and C-VLAN combination is classified into the service point.	SAP and MNG

2. Ethernet Service Points – Ingress Attributes

Select **Ingress** in the Ethernet Service Points page to display the Ethernet Service Points – Ingress Attributes table.

[Table 46](#) describes the parameters displayed in the Ingress SP Attributes table.

Figure 73 Ethernet Service Points Page – Ingress Attributes

The screenshot shows the 'Microwave radio: Ethernet Service Points (Service ID - 1025)' configuration page. On the left is a navigation menu with options like Unit Summary, Radio Summary, Platform, Faults, Radio, Ethernet, General Configuration, Services, Interfaces, PM & Statistics, QoS, Protocols, Groups, Sync, Quick Configuration, and Utilities. The main area has a 'Back to Services table' link and a 'Select Service Point Attribute' section with radio buttons for General, Ingress (selected), and Egress. Below this is a table titled 'Ethernet Service Points - Ingress Attributes' with columns: Service point ID, Service point name, Service point type, Learning admin, Allow flooding, Allow broadcast, CoS Mode, and Default CoS. The table is currently empty. At the bottom are buttons for Add, Edit, Delete, and Attached VLAN.

Table 32 Service Point Ingress Attributes

Parameter	Definition
Service point ID	This ID is unique within the service. For Point-to-Point and Multipoint services, the range of values is 1-32. For Management services, the range of values is 1-30.
Service point name	A descriptive name for the service point (optional). The Service Point Name can be up to 20 characters.
Service point type	The service point type. Options are: <ul style="list-style-type: none"> SAP – Service Access Point. SNP – Service Network Point. MNG – Management service point. PIPE – Pipe service point.
Learning admin	Determines whether MAC address learning for incoming frames is enabled (Enable) or disabled (Disable). When enabled, the service point learns the source MAC addresses of incoming frames and adds them to a MAC address forwarding table.
Allow flooding	Determines whether incoming frames with unknown MAC addresses are forwarded to other service points via flooding. Select Allow to allow flooding or Disable to disable flooding.
Allow broadcast	Indicates whether frames with a broadcast destination MAC address are allowed to ingress the service via this service point. Select Allow to allow broadcast or Disable to disable broadcast.

Parameter	Definition
CoS Mode	<p>Indicates how the service point handles the CoS of frames that pass through the service point. Options are:</p> <ul style="list-style-type: none"> • sp-def-cos – The service point re-defines the CoS of frames that pass through the service point, according to the Default CoS (below). This decision can be overwritten on the service level. • Interface-Decision – The service point preserves the CoS decision made at the interface level. The decision can still be overwritten at the service level. • PCL – Reserved for future use. • TCAM – Reserved for future use.
Default CoS	The default CoS. If the CoS Mode is sp-def-cos , this is the CoS assigned to frames that pass through the service point. This decision can be overwritten at the service level. Possible values are 0 to 7.
Split horizon group	Reserved for future use.

3. Ethernet Service Points – Egress Attributes

Select **Egress** in the Ethernet Service Points page to display the Ethernet Service Points – Egress Attributes table. [Table 47](#) describes the parameters displayed in the General SP Attributes table.

Figure 74 Ethernet Service Points Page – Egress Attributes

The screenshot shows the 'Microwave radio: Ethernet Service Points (Service ID - 1025)' configuration page. On the left is a navigation menu with options like Unit Summary, Radio Summary, Platform, Faults, Radio, Ethernet, General Configuration, Services, Interfaces, PM & Statistics, QOS, Protocols, Groups, Sync, Quick Configuration, and Utilities. The 'Services' section is expanded, showing a table of Ethernet Service Points. The table has columns for Service point ID, Service point name, Service point type, C-Vlan CoS preservation, C-Vlan preservation, S-Vlan CoS preservation, S-Vlan preservation, Marking admin, and Service Bundle ID. Below the table are buttons for Add, Edit, Delete, and Attached VLAN. The 'Egress' attribute is selected in the 'Select Service Point Attribute' section.

Table 33 Service Point Egress Attributes

Parameter	Definition
Service point ID	This ID is unique within the service. For Point-to-Point and Multipoint services, the range of values is 1-32. For Management services, the range of values is 1-30.
Service point name	A descriptive name for the service point (optional). The Service Point Name can be up to 20 characters.

Parameter	Definition
Service point type	<p>The service point type. Options are:</p> <ul style="list-style-type: none"> • SAP – Service Access Point. • SNP – Service Network Point. • MNG – Management service point. • PIPE – Pipe service point.
C-Vlan CoS preservation	<p>Determines whether the original C-VLAN CoS value is preserved or restored for frames egressing from the service point.</p> <p>If C-VLAN CoS preservation is enabled, the C-VLAN CoS value of frames egressing the service point is the same as the value when the frame entered the service.</p> <p>If C-VLAN CoS preservation is disabled, the C-VLAN CoS value of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking.</p>
C-Vlan preservation	<p>Determines whether the original C-VLAN ID is preserved or restored for frames egressing from the service point.</p> <p>If C-VLAN preservation is enabled, the C-VLAN ID of frames egressing the service point is the same as the C-VLAN ID when the frame entered the service.</p> <p>If C-VLAN preservation is disabled, the C-VLAN ID of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking</p>
S-Vlan CoS preservation	<p>Determines whether the original S-VLAN CoS value is preserved or restored for frames egressing from the service point.</p> <p>If S-VLAN CoS preservation is enabled, the S-VLAN CoS value of frames egressing the service point is the same as the value when the frame entered the service.</p> <p>If S-VLAN CoS preservation is disabled, the C-VLAN CoS value of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking</p>
S-Vlan preservation	<p>Read-only. Indicates whether the original S-VLAN ID is preserved or restored for frames egressing from the service point.</p> <p>If S-VLAN preservation is enabled, the S-VLAN ID of frames egressing the service point is the same as the S-VLAN ID when the frame entered the service.</p> <p>If S-VLAN preservation is disabled, the S-VLAN ID of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking</p>

Parameter	Definition
Marking admin	<p>Determines whether re-marking of the outer VLAN (C-VLAN or S-VLAN) of tagged frames that pass through the service point is enabled.</p> <p>If Marking admin is set to Enable, and CoS preservation for the relevant outer VLAN is set to Disable, the SAP re-marks the C-VLAN or S-VLAN 802.1p UP bits of egress frames according to the calculated CoS and Color, and the user-configurable 802.1Q and 802.1AD marking tables. You can configure these tables by selecting Ethernet > QoS > Marking from the menu on the left side of the Web EMS.</p> <p>If Marking admin and CoS preservation for the relevant outer VLAN are both set to Enable, re-marking is not performed.</p> <p>If Marking admin and CoS preservation for the relevant outer VLAN are both set to Disable, re-marking is applied, but only according to the values defined for Green frames in the 802.1Q and 802.1AD marking tables.</p>
Service Bundle ID	<p>This can be used to assign one of the available service bundles from the H-QoS hierarchy queues to the service point. This enables you to personalize the QoS egress path. Permitted values are 1-63.</p>

Adding a Service Point

To add a service point:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 93](#)).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens ([Figure 96](#)).
4. Select the relevant service point in the Ethernet Services Points – General SP Attributes table.
5. Click **Add**. The Ethernet Service Points – Add page opens.

Figure 75 Ethernet Service Points - Add Page

Ethernet Service Points

Ethernet Service Points - Add (Point to Point Service)

Pre defined options

Option #1 (SAP, dot1q)

Service ID

1

Service point ID

1

Service point name

N.A.

Service point type

SAP

General SP Attributes

Interface location

Ethernet: Slot 1, Port 1

Attached interface type

dot1q

C-Vlan encapsulation

Untagged

S-Vlan encapsulation

N.A.

Ingress Attributes

Learning admin

Disable

Allow flooding

Allow

Allow broadcast

Allow

CoS Mode

Interface-Decision

Default CoS

0

Egress Attributes

C-Vlan CoS preservation

Enable

C-Vlan preservation

Disable

S-Vlan CoS preservation

Enable

Marking admin

Enable

Service Bundle ID

1

Apply

Last Loaded: 12:12:57

Refresh

Close

100%

6. Configure the service point attributes, as described in Table 44, Table 46, and Table 47.

Note

Optionally, you can select from a list of pre-defined service point options in the **Pre defined options** field at the top of the **Ethernet Service Points - Add** page. The system automatically populates the remaining service point parameters according to the system-defined parameters. However, you can manually change these parameter values. The pre-defined options are customized to the type of service to which you are adding the service point.

phn-3963_008v000
Page 6-16

7. Click **Apply**, then **Close**.

Editing a Service Point

To edit a service point:

1. Select **Ethernet > Services**. The Ethernet Services page opens (Figure 93).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens (Figure 96).
4. Select the relevant service point in the Ethernet Services Points – General SP Attributes table.
5. Click **Edit**. The Ethernet Service Points– Edit page opens. The Ethernet Service Points – Edit page is similar to the Ethernet Service Points - Add page (Figure 99). You can edit any parameter that can be configured in the Add Service Point page, except **Service Point ID**, **Service Point Type**, and the **General SP Attributes**.
6. Edit the service point attributes, as described in Table 44, Table 46, and Table 47.
7. Click **Apply**, then **Close**.

Deleting a Service Point

You can only delete a service point with an **Attached Interface Type** of **Bundle-C** or **Bundle-S** if no VLANs are attached to the service point. See *Attaching VLANs*.

To delete a service point:

1. Select **Ethernet > Services**. The Ethernet Services page opens (Figure 93).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens (Figure 96).
4. Select the relevant service point in the Ethernet Services Points – General SP Attributes table.
5. Click **Delete**. The service point is deleted.


Attaching VLANs

When the Attached Interface Type for a service point is set to Bundle-C or Bundle-S, you can add multiple C-VLANs to the service point.

To add multiple C-VLANs:

1. Select **Ethernet > Services**. The Ethernet Services page opens (Figure 93).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens (Figure 96).
4. Select the relevant service point in the Ethernet Services Points – General SP Attributes table.
5. Click **Attached VLAN**. The Attached VLAN List page opens.

Figure 76 Attached VLAN List Page



6. Click **Add**. The Attached VLAN List - Add page opens.

Figure 77 Attached VLAN List - Add Page

7. Configure the VLAN Classification parameters, described in *Table 48*.

8. Click **Apply**, then **Close**.

Table 34 VLAN Classification Parameters

Parameter	Definition
Interface Location	Read-only. The physical or logical interface on which the service point is located.
Service ID	Read-only. The ID of the service to which the service point belongs.
Service Point ID	Read-only. The ID of the service point.
C-Vlan Encapsulation	Select the C-VLAN you want to add to the service point.

Parameter	Definition
S-Vlan Encapsulation	<p>Read-only.</p> <p>If the Attached Interface Type for the service point is Bundle-S, this field displays the S-VLAN encapsulation selected when the service point was created.</p> <p>If the Attached Interface Type for the service point is Bundle-C, this field is inactive.</p>
CoS Overwrite Valid	<p>If you want to assign a specific CoS and Color to frames with the C-VLAN or S-VLAN defined in the C-VLAN Encapsulation field, select true. This CoS and Color values defined below override the CoS and Color decisions made at the interface level. However, if the service point or service are configured to apply their own CoS and Color decisions, those decisions override the decision made here.</p>
CoS Value	<p>If CoS Overwrite Valid is set to true, the CoS value defined in this field is applied to frames with the C-VLAN defined in the C-VLAN Encapsulation field. This CoS overrides the CoS decision made at the interface level. However, if the service point or service are configured to apply their own CoS, that decision overrides the decision made here.</p> <p>If CoS Overwrite Valid is set to false, this parameter has no effect.</p>
Color	<p>If CoS Overwrite Valid is set to true, the Color value defined in this field is applied to frames with the C-VLAN defined in the C-VLAN Encapsulation field. This Color overrides the Color decision made at the interface level. However, if the service point or service are configured to apply their own Color, that decision overrides the decision made here.</p> <p>If CoS Overwrite Valid is set to false, this parameter has no effect.</p>

To edit a VLAN Classification table entry, select the entry in the VLAN Classification table and click **Edit**. You can edit all the fields that can be configured in the Attached VLAN List – Add page, except the **C-VLAN Encapsulation** field.

To delete a VLAN Classification table entry, select the entry in the VLAN Classification table and click **Delete**.

Setting the MRU Size and the S-VLAN Ethertype

To configure the size of the MRU (Maximum Receive Unit) and the S-VLAN Ethertype:

1. Select **Ethernet > General Configuration**. The Ethernet General Configuration page opens.

Figure 78 Ethernet General Configuration Page

Logout ✓ Connection Admin

Microwave radio: Ethernet General Configuration

Filter

Unit Summary
Radio Summary

Platform
Faults
Radio
Ethernet
General Configuration
Services
Interfaces
PM & Statistics
QOS
Protocols
Groups
Sync
Quick Configuration
Utilities

General Parameters

MRU (64 ... 9612)

S VLAN Ether type

C VLAN Ether type

Apply

Instance per Service mapping

Service ID	Instance ID
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0

Page: 1 2 3 4 5 6 7 8 9 Rows per page

Edit

Multiple Selection Operation

Instance ID Apply

2. In the **MRU** field, enter the global size (in bytes) of the Maximum Receive Unit (MRU). Permitted values are 64 to 9612. The default value is 2000. Frames that are larger than the global MRU will be discarded.
3. In the **S VLAN Ether type** field, select the S-VLAN Ethertype. This defines the ethertype recognized by the system as the S-VLAN ethertype. Options are: 0x8100, 0x88A8, 0x9100, and 0x9200. The default value is 0x88A8.



Note

The C-VLAN Ethertype is set at 0x8100 and cannot be modified.

4. Click **Apply**.

Configuring Ethernet Interfaces

Related Topics:

- [Enabling the Interfaces \(Interface Manager\)](#)
- [Performing Ethernet Loopback](#)
- [Configuring Ethernet Service\(s\)](#)
- [Quality of Service \(QoS\)](#)

The PTP 850's switching fabric distinguishes between physical interfaces and logical interfaces. Physical and logical interfaces serve different purposes in the switching fabric. In some cases, a physical interface corresponds to a logical interface on a one-to-one basis. For some features, such as LAG, a group of physical interfaces can be joined into a single logical *interface*.

The basic interface characteristics, such as media type, port speed, duplex, and auto-negotiation, are configured for the physical interface via the Physical Interfaces page. Ethernet services, QoS, and OAM characteristics are configured on the logical interface level.

To configure the physical interface parameters:

1. Select **Ethernet > Interfaces > Physical Interfaces**. The Physical Interfaces page opens.

Figure 79 Physical Interfaces Page

Logout

Connection

Admin

▼ Filter

Unit Summary

Radio Summary

Platform

Faults

Radio

Ethernet

General Configuration

Services

Interfaces

Physical Interfaces

Logical Interfaces

ASP & LLF

PM & Statistics

QOS

Protocols

Groups

Sync

Quick Configuration

Utilities

Microwave radio: Physical Interfaces

▼ Physical Interfaces

Interface location ▲	Description	Operational Status	Admin status	Media type	Auto negotiation	Actual port speed	Actual port duplex
Ethernet: Slot 1, Port 2		Down	Down	SFP	Off	2500	Full Duplex
Ethernet: Slot 1, Port 3		Up	Up	SFP	On	10000	Full Duplex
Ethernet: Slot 1, Port 4		Down	Down	SFP	On	10000	Full Duplex
Ethernet: Slot 1, Port 5		Down	Down	SFP	On	10000	Full Duplex
Ethernet: Slot 1, Port 6		Down	Down	SFP	On	10000	Full Duplex
Ethernet: Slot 1, Port 7		Up	Up	SFP	Off	10000	Full Duplex
Radio: Slot 1, Port 1		Down	Down	Radio	Off	10000	Full Duplex

Edit

If an alarm is currently raised on an interface, an alarm icon appears to the left of the interface location. For example, in *Figure 80*, an alarm is raised on the Radio interface. To display details about the alarm or alarms in tooltip format, hover the mouse over the alarm icon.



Note

In release 10.6, only Ethernet Slot 1, Port 7 and Radio Slot 1, Port 1 are supported. In release 10.9, Ethernet Slot 1, Ports 3 through 7 are supported.

The QSFP port (Port 4) is displayed as follows.

- In a 4x1/10G configuration the QSFP port can provide four Ethernet interfaces: Eth3, Eth4, Eth 5, and Eth6. In this configuration, a QSFP transceiver is attached to the QSFP port, and an MPO-MPO cable is connected between the transceiver and a splitter on the other side of the link. The splitter splits the traffic between four Ethernet cables connecting the splitter to the customer equipment.
7. Select the interface you want to configure and click **Edit**. The Physical Interfaces - Edit page opens.

Figure 80 Physical Interfaces - Edit Page

Physical Interfaces - Edit

Interface location: Ethernet: Slot 1, Port 7

Operational Status: Down

Admin status: Up

Media type: SFP

Actual port speed: 10000

Actual port duplex: Full Duplex

Description:

Media type: SFP

Auto negotiation: Off

Speed: 10000

Duplex: Full Duplex

Apply

Page Refresh Interval (Seconds): None Last Loaded: 15:59:33 Refresh Close

8. Optionally, in the **Description** field, enter a description of the interface.
9. In the **Media type** field, select the physical interface layer 1 media type. Options are:
- **Auto-Type** – NA.
 - **RJ45** – An electrical (RJ-45) Ethernet interface.
 - **SFP** – An optical (SFP) Ethernet interface.
 - **Radio** – A radio interface.
10. In the **Auto negotiation** field, select **On** to enable or **Off** to disable Auto-Negotiation. When the Media-Type is **Radio**, Auto Negotiation is always **Off**.
11. In the **Speed** field, select the maximum speed of the interface. Options are:
- Ethernet RJ-45 interfaces – **100** and **1000**.
 - Ethernet SFP interfaces – Only **1000** is supported.
 - Ethernet SFP+ and QSFP interfaces – Only **1000** and **10000** are supported.
 - Radio interfaces – The parameter is read-only and set by the system to **1000FD**.



Note

In release 10.6 and 10.9, Ethernet Slot 1 Port 7 only supports 10000 Mbps.

To use an SFP+ interface in 10000 Mbps mode, the third-party switch must be running Pause Frame Flow Control, as defined in IEEE 802.3x. It is also recommended to configure shapers on the third-party switch so as to limit the packet flow from the switch to the PTP 850E unit to 2.5 Gbps.

After changing the speed of an SFP+ interface, you must reset the unit in order for the change to take effect.

12. In the **Duplex** field, select the interface's duplex setting (**Full-Duplex** or **Half-Duplex**). Only Full-Duplex is available in this release.

13. Click **Apply**, then **Close**.

[Table 49](#) describes the status parameters that appear in the Physical Interfaces page.

Table 35 Physical Interface Status Parameters

Parameter	Definition
Interface location	The location of the interface.
Operational Status	Indicates whether the interface is currently operational (Up) or non-operational (Down).
Admin Status	Indicates whether the interface is currently enabled (Up) or disabled (Down). You can enable or disable an interface from the Interface Manager page. See <i>Enabling the Interfaces (Interface Manager)</i> .
Actual port speed	Displays the actual speed of the interface for the link as agreed by the two sides of the link after the auto negotiation process.
Actual port duplex	Displays the actual duplex status of the interface for the link as agreed by the two sides of the link after the auto negotiation process.

Configuring Automatic State Propagation and Link Loss Forwarding

Automatic state propagation enables propagation of radio failures back to the Ethernet port. You can also configure Automatic State Propagation to close the Ethernet port based on a radio failure at the remote carrier.

Automatic state propagation is configured as pairs of interfaces. Each interface pair includes one Monitored Interface and one Controlled Interface. You can create multiple pairs using the same monitored interface and multiple controlled interfaces.

The Monitored Interface is a radio interface, or a radio protection or Multi-Carrier ABC group. The Controlled Interface is an Ethernet interface or LAG. An Ethernet interface can only be assigned to one Monitored interface.

Each Controlled Interface is assigned an LLF ID. If **ASP trigger by remote fault** is enabled on the remote side of the link, the ASP state of the Controlled Interface is propagated to the Controlled Interface with the same LLF ID at the remote side of the link. This means if ASP is triggered locally, it is propagated to the remote side of the link, but only to Controlled Interfaces with LLF IDs that match the LLF IDs of the affected Controlled Interfaces on the local side of the link.



Note

LLF requires an activation key (SL-LLF). Without this activation key, only LLF ID 1 is available.

The following events in the Monitored Interface trigger ASP:

- Radio LOF
- Radio Excessive BER
- Remote Radio LOF
- Remote Excessive BER
- Remove LOC

The user can also configure the ASP pair so that Radio LOF, Radio Excessive BER, or loss of the Ethernet connection at the remote side of the link will also trigger ASP.

In addition, ASP is triggered if the Controlled Interface is a LAG, and the physical interfaces that belong to the LAG are set to **Admin = Down** in the Interface Manager.

When a triggering event takes place:

- If the Controlled Interface is an electrical GbE port, the port is closed.
- If the Controlled Interface is an optical GbE port, the port is muted.

The Controlled Interface remains closed or muted until all triggering events are cleared.

In addition, when a local triggering event takes place, the ASP mechanism sends an indication to the remote side of the link. Even when no triggering event has taken place, the ASP mechanism sends periodic update messages indicating that no triggering event has taken place.


A trigger delay time can be configured, so that when a triggering event takes place, the ASP mechanism does not propagate the event until this delay time has elapsed. A trigger delay from 0 to 10,000 ms can be set per LLD ID. The delay time must be configured via CLI. See [Configuring Automatic State Propagation and Link Loss Forwarding \(CLI\)](#).

It is recommended to configure both ends of the link to the same Automatic State Propagation configuration.

To configure an Automatic State Propagation interface pair:


1. Select **Ethernet > Interfaces > Automatic State Propagation**. The Automatic State Propagation page opens.

Figure 81 Automatic State Propagation Page



2. Click **Add**. The Automatic State Propagation - Add page opens.

Figure 82 Automatic State Propagation - Add Page



3. In the **Controlled Ethernet interface** field, select an interface that will be disabled upon failure of the Monitored Radio Interface, defined below.
4. In the **Monitored Radio interface** field, select the Monitored Radio Interface. The Controlled Ethernet Interface, defined above, is disabled upon a failure indication on the Monitored Radio Interface.
5. In the **ASP admin** field, select **Enable** to enable Automatic State Propagation on the interface pair, or **Disable** to disable Automatic State Propagation on the pair.

6. Optionally, in the **ASP trigger by remote fault** field, select **Enable** if you want to configure the system to disable the Controlled Ethernet Interface upon a radio failure at the remote side of the link from the Monitored Radio Interface. ASP events will only be propagated to Controlled Interfaces with LLF IDs that match LLF IDs of affected Controlled Interfaces at the other side of the link.
7. Optionally, in the **ASP CSF mode admin** field, select **Enable** or **Disable** to enable or disable Client Signal Failure (CSF) mode. In CSF mode, the ASP mechanism does not physically shut down the Controlled Interface when ASP is triggered. Instead, the ASP mechanism sends a failure indication message (a CSF message). The CSF message is used to propagate the failure indication to external equipment.
8. In the **ASP LLF ID** field, select an ID for Link Loss Forwarding (LLF). When **ASP trigger by remote fault** is set to **Enable**, ASP events at the other side of the link are propagated to Controlled Interfaces with LLF IDs that match the LLF IDs of affected Controlled Interfaces at the other side of the link. LLF IDs are unique per Monitored Interface. That is, if LLF ID 1 has been used for a Controlled Interface that is grouped with radio interface 1, that ID cannot be used again for another Controlled Interface grouped fixed radio interface 1. However, it *can* be used for Controlled Interface grouped with radio interface 2. You can select an LLF ID between 1 and 30.
9. Repeat this procedure to assign additional Controlled Interfaces to the Monitored Interface, or to set up additional ASP pair with other interfaces. Controlled Interfaces can only be assigned to one ASP pair. Monitored Interfaces can be assigned to multiple ASP pairs.

To edit an Automatic State Propagation interface pair:

1. Select the interface pair in the Automatic state propagation configuration table.
2. Click **Edit**. The Automatic State Propagation – Edit page opens. The Edit page is similar to the Add page ([Figure 170](#)), but the **Controlled Ethernet Interface** and **Monitored Radio Interface** parameters are read-only.

To delete an Automatic State Propagation interface pair:

1. Select the interface pair in the Automatic state propagation configuration table.
2. Click **Delete**. The interface pair is removed from the Automatic state propagation configuration table.

To delete multiple interface pairs:

1. Select the interface pairs in the Automatic state propagation configuration table or select all the interfaces by selecting the check box in the top row.
2. Click **Delete**. The interface pairs are removed from the Automatic state propagation configuration table.

Viewing Ethernet PMs and Statistics

PTP 850 stores and displays statistics in accordance with RMON and RMON2 standards. You can display various peak TX and RX rates (per second) and average TX and RX rates (per second), both in bytes and in packets, for each measured time interval. You can also display the number of seconds in the interval during which TX and RX rates exceeded the configured threshold.

This section includes:

- [RMON Statistics](#)
- [Port TX Statistics](#)
- [Port RX Statistics](#)

RMON Statistics

To view and reset RMON statistics:

1. Select **Ethernet > PM & Statistics > RMON**. The RMON page opens.

Figure 83 RMON Page

	Ethernet: Slot 1, Port 2	Ethernet: Slot 1, Port 3	Ethernet: Slot 1, Port 4	Ethernet: Slot 1, Port 5	Ethernet: Slot 1, Port 6	Ethernet: Slot 1, Port 7
Clear on read	No	No	No	No	No	No
TX byte count	4,964	4,964	4,964	4,964	4,964	456,855,100,386
TX frame count	73	73	73	73	73	520,505,176
TX multicast frame count	73	73	73	73	73	73
TX broadcast frame count	0	0	0	0	0	0
TX control frame count	0	0	0	0	0	0
TX pause frame count	0	0	0	0	0	467
TX fcs error frame count	0	0	0	0	0	0
TX length error frame count	0	0	0	0	0	0
TX oversize frame count	0	0	0	0	0	86,758,933
TX undersize frame count	0	0	0	0	0	0
TX fragment frame count	0	0	0	0	0	0
TX jabber frame count	0	0	0	0	0	0
TX 64 frame count	0	0	0	0	0	467
TX 65-127 frame count	73	73	73	73	73	86,751,280
TX 128-255 frame count	0	0	0	0	0	86,754,349
TX 256-511 frame count	0	0	0	0	0	86,739,481
TX 512-1023 frame count	0	0	0	0	0	86,746,718
TX 1024-1518 frame count	0	0	0	0	0	173,513,326
TX 1519-1522 frame count	0	0	0	0	0	0
RX byte count	0	0	0	0	0	469,000,671,600
RX frame count	0	0	0	0	0	534,348,631
RX multicast frame count	0	0	0	0	0	0
RX broadcast frame count	0	0	0	0	0	0
RX control frame count	0	0	0	0	0	0

- To clear the statistics, click **Clear All** at the bottom of the page.
- To refresh the statistics, click **Refresh** at the bottom of the page.

Each column in the RMON page displays RMON statistics for one of the unit's interfaces. To hide or display columns:

1. Click the arrow next to the table title (**Interface Physical Port RMON Statistics**).
2. Mark the interfaces you want to display and clear the interfaces you do not want to display.

Figure 84 RMON Page – Hiding and Displaying Columns

▼ Interface physical Port RMON statistics	
<input checked="" type="checkbox"/> All columns	Slot 1, Port 2
<input checked="" type="checkbox"/> Ethernet: Slot 1, Port 2	No
<input checked="" type="checkbox"/> Ethernet: Slot 1, Port 3	559,572
<input checked="" type="checkbox"/> Ethernet: Slot 1, Port 4	8,229
<input checked="" type="checkbox"/> Ethernet: Slot 1, Port 5	8,229
<input checked="" type="checkbox"/> Ethernet: Slot 1, Port 6	0
<input checked="" type="checkbox"/> Ethernet: Slot 1, Port 7	0
<input checked="" type="checkbox"/> Radio: Slot 1, Port 1	0
TX undersize frame count	0
TX fragment frame count	0

**Note**

If you click the table title itself, all columns are hidden. To un-hide the columns, click the table title again.

Egress CoS Statistics

You can display packet egress statistics per CoS value. For each CoS value, the following statistics are displayed per Color (Green and Yellow):

- Number of packets transmitted
- Number of packets dropped
- Number of bytes transmitted
- Number of bytes dropped

**Note**

Transmitted bits per second are not supported in the current release.

To display egress CoS statistics:

1. Select **Ethernet > PM & Statistics > Egress CoS Statistics**. The Egress CoS Statistics page opens.

Figure 85 Egress Cos Statistics Page

CoS queue index	Transmitted green packets	Transmitted green bytes	Transmitted green bits per second	Dropped green packets	Dropped green bytes	Transmitted yellow packets	Transmitted yellow bytes	Transmitted yellow bits per second	Dropped yellow packets	Dropped yellow bytes	Clear on read
0	659084814	495837495574	0	0	0	0	0	0	0	0	No
1	0	0	0	0	0	0	0	0	0	0	No
2	0	0	0	0	0	0	0	0	0	0	No
3	0	0	0	0	0	0	0	0	0	0	No
4	0	0	0	0	0	0	0	0	0	0	No
5	0	0	0	0	0	0	0	0	0	0	No
6	0	0	0	0	0	0	0	0	0	0	No
7	0	0	0	0	0	0	0	0	0	0	No

2. In the **Show Service bundle ID** field, select 1.

**Note**

Service Bundles are bundles of queues, grouped together in order to configure common egress characteristics for specific services. In the current release, only Service Bundle 1 is supported.

By default, the egress CoS statistics are cumulative. That is, they are not automatically cleared. You can set each individual CoS number to be cleared whenever the Egress CoS Statistics page is opened by changing the Clear on read value to **Yes**.

1. To change the clear on read value, select the CoS number in the CoS queue index column and click **Edit**. The Egress CoS Statistics – Edit page opens.

Figure 86 Egress CoS Statistics – Edit Page

Egress CoS Statistics - Edit

Interface location: Ethernet: Slot 1, Port 7

Service Bundle ID: 1

CoS queue index: 0

Transmitted green packets: 196809450646

Transmitted green bytes: 294647515389494

Transmitted green bits per second: 0

Dropped green packets: 43659528

Dropped green bytes: 26091560331

Transmitted yellow packets: 0

Transmitted yellow bytes: 0

Transmitted yellow bits per second: 0

Dropped yellow packets: 0

Dropped yellow bytes: 0

Clear on read: No

Apply

Page Refresh Interval (Seconds): None

Last Loaded: 11:47:26

Refresh Close

2. In the **Clear on read** field, select **Yes** to have statistics for the CoS value cleared every time you open the page.

3. Click **Apply**.

Port TX Statistics

The Ethernet Port TX PM report page displays PMs that measure various peak transmission rates (per second) and average transmission rates (per second), both in bytes and in packets, for each measured time interval.

The page also displays the number of seconds in the interval during which transmission rates exceeded the configured threshold.

This section includes:

- [Displaying Ethernet Port TX PMs](#)
- [Enabling or Disabling Gathering of Port TX PM Statistics per Interface](#)
- [Setting the Ethernet Port TX Threshold](#)

Displaying Ethernet Port TX PMs

To display Ethernet Port TX PMs:

1. Select **Ethernet > PM & Statistics > Port TX**. The Ethernet Port TX PM Report page opens.

Figure 87 Ethernet Port TX PM Report Page

#	Interval	Peak TX bytes Layer2	Average TX bytes Layer2	Peak TX bytes Layer1	Average TX bytes Layer1	Peak TX packets	Average TX packets	Peak TX broadcast packets	Average TX broadcast packets	Peak TX multicast packets	Average TX multicast packets	TX bytes Layer1 exceed threshold (sec)	Integrity
	Current (11:18:15)	222120946	207367426	227184486	212092099	253177	236233	0	0	1	0	189	⌕
1	07-May-19 11:15	222349676	204970894	227427156	209641329	254886	233521	0	0	1	0	115	⌕

2. In the **Interface** field, select the interface for which you want to display PMs.
3. In the **Interval Type** field:
 - To display reports for the past 24 hours, in 15 minute intervals, select **15 minutes**.
 - To display reports for the past month, in daily intervals, select **24 hours**.

[Table 50](#) describes the Ethernet TX port PMs.

Table 36 Ethernet TX Port PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Peak... Average... bytes... Packets...	Various peak transmission rates (per second) and average transmission rates (per second), both in bytes and in packets, for each measured time interval.

Parameter	Definition
TX bytes Layer 1 exceed threshold (sec)	The number of seconds the TX bytes exceeded the specified threshold during the interval. For instructions on setting the threshold, see Setting the Ethernet Port TX Threshold .
Invalid data flag	Indicates whether the values received during the measured interval are valid. An x in the column indicates that the values are not valid (for example, because of a power surge or power failure that occurred during the interval).

To clear the PMs, click **Clear All**.

Enabling or Disabling Gathering of Port TX PM Statistics per Interface

To select the interfaces for which to gather and display Port TX PMs:

1. In the Ethernet Port TX PM Report page, click **PM Admin**. The Ethernet PM Port Admin page opens.

Figure 88 Ethernet PM Port Admin Page

Interface location	Port PM admin
Ethernet: Slot 1, Port 2	Disable ▼
Ethernet: Slot 1, Port 3	Disable ▼
Ethernet: Slot 1, Port 4	Disable ▼
Ethernet: Slot 1, Port 5	Disable ▼
Ethernet: Slot 1, Port 6	Disable ▼
Ethernet: Slot 1, Port 7	Enable ▼
Radio: Slot 1, Port 1	Disable ▼

Apply

Page Refresh Interval (Seconds): None ▼ Last Loaded: 11:50:35 Refresh Close

2. Select the interface.
3. Click **Enable Port PM** or **Disable Port PM** to enable or disable the gathering of Port TX PMs on the selected interface.
4. Click **Close**.

Setting the Ethernet Port TX Threshold

The **TX bytes Layer 1 exceed threshold (sec)** column shows, for each interval, the number of seconds the TX bytes exceeded the specified threshold during the interval:

To view and set this threshold:

1. In the Ethernet Port TX PM Report page, click **Threshold**. The Ethernet Port Tx Threshold page opens.

Figure 89 Ethernet Port Tx Threshold Page

Interface location	TX bytes threshold (Byte per second)
Ethernet: Slot 1, Port 2	0
Ethernet: Slot 1, Port 3	0
Ethernet: Slot 1, Port 4	0
Ethernet: Slot 1, Port 5	0
Ethernet: Slot 1, Port 6	0
Ethernet: Slot 1, Port 7	0
Radio: Slot 1, Port 1	0

Apply

Page Refresh Interval (Seconds) None Last Loaded: 11:53:13 Refresh Close

2. Enter a threshold, between 0 and 4294967295.
3. Click **Apply**, then **Close**.

Port RX Statistics

The Ethernet Port RX PM report page displays PMs that measure various peak transmission rates (per second) and average RX rates (per second), both in bytes and in packets, for each measured time interval.

The page also displays the number of seconds in the interval during which RX rates exceeded the configured threshold.

This section includes:

- [Displaying Ethernet Port RX PMs](#)
- [Enabling or Disabling Gathering of Port RX PM Statistics per Interface](#)
- [Setting the Ethernet Port RX Threshold](#)

Displaying Ethernet Port RX PMs

To display Ethernet Port RX PMs:

1. Select **Ethernet > PM & Statistics > Port RX**. The Ethernet Port RX PM Report page opens.

Figure 90: Ethernet Port RX PM Report Page

2. In the **Interface** field, select the interface for which you want to display PMs.
3. In the **Interval Type** field:
 - To display reports for the past 24 hours, in 15 minute intervals, select **15 minutes**.
 - To display reports for the past month, in daily intervals, select **24 hours**.

Table 51 describes the Ethernet RX port PMs.

Table 37 Ethernet RX Port PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Peak... Average... bytes... Packets...	Various peak transmission rates (per second) and average RX rates (per second), both in bytes and in packets, for each measured time interval.
RX bytes Layer 1 exceed threshold (sec)	The number of seconds the RX bytes exceeded the specified threshold during the interval. For instructions on setting the threshold, see Setting the Ethernet Port RX Threshold .
Invalid data flag	Indicates whether the values received during the measured interval are valid. An x in the column indicates that the values are not valid (for example, because of a power surge or power failure that occurred during the interval).

To clear the PMs, click **Clear All**.

Enabling or Disabling Gathering of Port RX PM Statistics per Interface

To select the interfaces for which to gather and display Port RX PMs:

1. In the Ethernet Port RX PM Report page, click **PM Admin**. The Ethernet PM Port Admin page opens.

Figure 91 Ethernet PM Port Admin Page

Ethernet PM Port Admin - Edit

Interface location	Port PM admin
Ethernet: Slot 1, Port 2	Disable ▾
Ethernet: Slot 1, Port 3	Disable ▾
Ethernet: Slot 1, Port 4	Disable ▾
Ethernet: Slot 1, Port 5	Disable ▾
Ethernet: Slot 1, Port 6	Disable ▾
Ethernet: Slot 1, Port 7	Enable ▾
Radio: Slot 1, Port 1	Disable ▾

Apply

Page Refresh Interval (Seconds): None ▾ Last Loaded: 11:54:55 Refresh Close

2. In the field to the right of the interface, select **Enable** or **Disable** to enable or disable the gathering of Port PMs on the interface.
3. Click **Close**.

Setting the Ethernet Port RX Threshold

The **RX bytes Layer 1 exceed threshold (sec)** column shows for each interval, the number of seconds the RX bytes exceeded the specified threshold during the interval:

To view and set this threshold:

1. In the Ethernet Port RX PM Report page, click **Threshold**. The Ethernet Port Rx Threshold page opens.

Figure 92 Ethernet Port Rx Threshold Page

Interface location	RX bytes threshold (Byte per second)
Ethernet: Slot 1, Port 2	0
Ethernet: Slot 1, Port 3	0
Ethernet: Slot 1, Port 4	0
Ethernet: Slot 1, Port 5	0
Ethernet: Slot 1, Port 6	0
Ethernet: Slot 1, Port 7	0
Radio: Slot 1, Port 1	0

Apply

Page Refresh Interval (Seconds): None

Last Loaded: 11:56:55

2. For each interface, you can enter a threshold, in bytes per second, between 0 and 4294967295.
3. Click **Apply**, then **Close**.

Chapter 7: Quality of Service (QoS)

This section includes:

- [QoS Overview](#)
- [Configuring Classification](#)
- [Configuring Policers \(Rate Metering\)](#)
- [Configuring Marking](#)
- [Configuring WRED](#)
- [Configuring Egress Shaping](#)
- [Configuring Scheduling](#)
- [Configuring and Displaying Queue-Level PMs](#)

QoS Overview


Quality of Service (QoS) deals with the way frames are handled within the switching fabric. QoS is required in order to deal with many different network scenarios, such as traffic congestion, packet availability, and delay restrictions.

PTP 850's personalized QoS enables operators to handle a wide and diverse range of scenarios. PTP 850's smart QoS mechanism operates from the frame's ingress into the switching fabric until the moment the frame egresses via the destination port.

QoS capability is very important due to the diverse topologies that exist in today's network scenarios. These can include, for example, streams from two different ports that egress via single port, or a port-to-port connection that holds hundreds of services. In each topology, a customized approach to handling QoS will provide the best results.

Figure 117 shows the basic flow of PTP 850's QoS mechanism. Traffic ingresses (left to right) via the Ethernet or radio interfaces, on the "ingress path." Based on the services model, the system determines how to route the traffic. Traffic is then directed to the most appropriate output queue via the "egress path."

Figure 93 QoS Block Diagram



The ingress path consists of the following QoS building blocks:

- **Ingress Classifier** – A hierarchical mechanism that deals with ingress traffic on three different levels: interface, service point, and service. The classifier determines the exact traffic stream and associates it with the appropriate service. It also calculates an ingress frame CoS and Color. CoS and Color classification can be performed on three levels, according to the user's configuration.
- **Ingress Rate Metering** – A hierarchical mechanism that deals with ingress traffic on three different levels: interface, service point, and service point CoS. The rate metering mechanism enables the system to measure the incoming frame rate on different levels using a TrTCM standard MEF rate meter, and to determine whether to modify the color calculated during the classification stage.



Note

Ingress rate meters can be configured per service point or per service point CoS, but not on both.

The egress path consists of the following QoS building blocks:

- **Queue Manager** – This is the mechanism responsible for managing the transmission queues, utilizing smart WRED per queue and per packet color (Green or Yellow).
- **Scheduling and Shaping** – A hierarchical mechanism that is responsible for scheduling the transmission of frames from the transmission queues, based on priority among queues, Weighted Fair Queuing (WFQ) in bytes per each transmission queue, and eligibility to transmit based on required shaping on several different levels (per queue, per service bundle, and per port).
- **Marker** – This mechanism provides the ability to modify priority bits in frames based on the calculated CoS and Color.

For a more detailed description of QoS in the PTP 850, refer to the Technical Description for the PTP 850 product type you are using.

Configuring Classification

The hierarchical classifier consists of the following levels:

- Logical interface-level classification
- Service point-level classification
- Service level classification

This section explains how to configure classification at the logical interface level.

- For instructions how to configure classification at the service point level, see [2. Ethernet Service Points – Ingress Attributes](#).
- For instructions how to configure classification at the service level, see [Adding an Ethernet Service](#).

This section includes:

- [Classification Overview](#)
- [Configuring Ingress Path Classification on a Logical Interface](#)
- [Modifying the C-VLAN 802.1Q UP and CFI Bit Classification Table](#)
- [Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table](#)
- [Modifying the DSCP Classification Table](#)
- [Modifying the MPLS EXP Bit Classification Table](#)

In addition to the procedures described in this section, you can specify a specific CoS and Color for a specific VLAN ID. This is the highest classification priority on the logical interface level, and overrides any other classification criteria at the logical interface level. Classification by VLAN ID can only be configured via CLI. See [Configuring VLAN Classification and Override \(CLI\)](#).

Classification Overview

PTP 850 supports a hierarchical classification mechanism. The classification mechanism examines incoming frames and determines their CoS and Color. The benefit of hierarchical classification is that it provides the ability to “zoom in” or “zoom out”, enabling classification at higher or lower levels of the hierarchy. The nature of each traffic stream defines which level of the hierarchical classifier to apply, or whether to use several levels of the classification hierarchy in parallel.

Classification takes place on the logical interface level according to the following priorities:

- VLAN ID (CLI-only – see [Configuring VLAN Classification and Override \(CLI\)](#))
- 802.1p bits
- DSCP bits (only considered if MPLS is not present, regardless of trust setting)
- MPLS EXP field
- Default interface CoS

PTP 850 performs the classification on each frame ingressing the system via the logical interface. Classification is performed step by step from the highest priority to the lowest priority classification method. Once a match is found, the classifier determines the CoS and Color decision for the frame for the logical interface-level.

For example, if the frame is an untagged IP Ethernet frame, a match will not be found until the third priority level (DSCP). The CoS and Color values defined for the frame's DSCP value will be applied to the frame.

You can disable some of these classification methods by configuring them as un-trusted. For example, if 802.1p classification is configured as un-trusted for a specific interface, the classification mechanism does not perform classification by UP bits. This is useful, for example, if classification is based on DSCP priority bits.

If no match is found at the logical interface level, the default CoS is applied to incoming frames at this level. In this case, the Color of the frame is assumed to be Green.

Configuring Ingress Path Classification on a Logical Interface

This section explains how to configure the classification criteria per each logical interface. The following sections explain how to modify the classification tables per bit type.

To configure the classification criteria for a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens.

Figure 94 Logical Interfaces Page

Interface location ▲	Trust VLAN UP bits	Trust DSCP	Trust MPLS	Default port CoS	Ingress byte compensation	Egress byte compensation	Interface Mode
Ethernet: Slot 1, Port 2	Trust	Trust	Trust	0	20	0	None
Ethernet: Slot 1, Port 3	Trust	Un-Trust	Un-Trust	0	20	0	None
Ethernet: Slot 1, Port 4	Trust	Un-Trust	Un-Trust	0	20	0	None
Ethernet: Slot 1, Port 5	Trust	Trust	Trust	0	20	0	None
Ethernet: Slot 1, Port 6	Trust	Trust	Trust	0	20	0	None
Ethernet: Slot 1, Port 7	Trust	Un-Trust	Un-Trust	0	20	0	None
Radio: Slot 1, Port 1	Trust	Un-Trust	Un-Trust	0	20	0	None

Buttons: Edit, Policers, WRED, Shaper, Scheduler, Loopback

2. Select the interface you want to configure and click **Edit**. The Logical Interfaces - Edit page opens.

Figure 95 Logical Interfaces - Edit Page

Logical Interfaces

Logical Interfaces - Edit

Interface location

Ethernet: Slot 1, Port 7

Trust VLAN UP bits

Trust

Trust DSCP

Trust

Trust MPLS

Trust

Default port CoS

0

Ingress byte compensation

20

Egress byte compensation

0

Interface Mode

None


Apply

Last Loaded: 10:22:02

Refresh

Close

3. Configure the parameters described in [Table 52](#).
4. Click **Apply**, then **Close**.



Note

The **Ingress byte compensation** and **Egress byte compensation** fields are described in [Configuring the Ingress and Egress Byte Compensation](#).

Table 38 Logical Interface Classification Parameters

Parameter	Definition
Trust VLAN UP bits	<div>Select the interface's trust mode for user priority (UP) bits:</div> <div>Trust – The interface performs QoS and color classification according to UP and CFI/DEI bits according to user-configurable tables for 802.1q UP bits (C-VLAN frames) or 802.1AD UP bits (S-VLAN frames). VLAN UP bit classification has priority over DSCP and MPLS classification, so that if a match is found with the UP bit of the ingressing frame, DSCP values and MPLS bits are not considered.</div> <div>Un-Trust – The interface does not consider 802.1 UP bits during classification.</div>

Parameter	Definition
Trust DSCP	<p>Select the interface's trust mode for DSCP:</p> <p>Trust – The interface performs QoS and color classification according to a user-configurable table for DSCP to CoS and color classification. DSCP classification has priority over MPLS classification, so that if a match is found with the DSCP value of the ingressing frame, MPLS bits are not considered.</p> <p>Un-Trust – The interface does not consider DSCP during classification.</p>
Trust MPLS	<p>Select the interface's trust mode for MPLS bits:</p> <p>Trust – The interface performs QoS and color classification according to a user-configurable table for MPLS EXP to CoS and color classification.</p> <p>Un-Trust – The interface does not consider MPLS bits during classification.</p>
Default port CoS	Select the default CoS value for frames passing through the interface (0 to 7). This value can be overwritten on the service point and service level.
Ingress Byte Compensation	See Configuring the Ingress and Egress Byte Compensation .
Egress Byte Compensation	See Configuring the Ingress and Egress Byte Compensation .
Interface Mode	Reserved for future use.

Modifying the C-VLAN 802.1Q UP and CFI Bit Classification Table

To modify the classification criteria for 802.1Q User Priority (UP) bits:

1. Select **Ethernet > QoS > Classification > 802.1Q**. The 802.1Q Classification page opens.

Figure 96 802.1Q Classification Page

Microwave radio: 802.1Q Classification

▼ 802.1Q Classification

802.1Q UP ▲	802.1Q CFI	802.1Q CoS	802.1Q Color
0	0	0	Green
0	1	0	Yellow
1	0	1	Green
1	1	1	Yellow
2	0	2	Green
2	1	2	Yellow
3	0	3	Green
3	1	3	Yellow
4	0	4	Green
4	1	4	Yellow
5	0	5	Green
5	1	5	Yellow
6	0	6	Green
6	1	6	Yellow
7	0	7	Green
7	1	7	Yellow

Edit

2. Select the row you want to modify and click **Edit**. The 802.1Q Classification – Edit page opens.

Figure 97 802.1Q Classification - Edit Page

802.1Q Classification

802.1Q Classification - Edit

802.1Q UP

802.1Q CFI

802.1Q CoS

802.1Q Color

Apply

Page Refresh Interval (Seconds) Last Loaded: 13:57:09 Refresh Close

3. Modify the parameters you want to change:
 - **802.1Q UP** – Read-only. The User Priority (UP) bit to be mapped.
 - **802.1Q CFI** – Read-only. The CFI bit to be mapped.
 - **802.1Q CoS** – The CoS assigned to frames with the designated UP and CFI.
 - **802.1Q Color** – The Color assigned to frames with the designated UP and CFI.

- Click **Apply**, then **Close**.

Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table

To modify the classification criteria for 802.1AD User Priority (UP) bits:

- Select **Ethernet > QoS > Classification > 802.1AD**. The 802.1AD Classification page opens.

Figure 98 802.1AD Classification Page

802.1AD UP ▲	802.1AD DEI	802.1AD CoS	802.1AD Color
0	0	0	Green
0	1	0	Yellow
1	0	1	Green
1	1	1	Yellow
2	0	2	Green
2	1	2	Yellow
3	0	3	Green
3	1	3	Yellow
4	0	4	Green
4	1	4	Yellow
5	0	5	Green
5	1	5	Yellow
6	0	6	Green
6	1	6	Yellow
7	0	7	Green
7	1	7	Yellow

- Select the row you want to modify and click **Edit**. The 802.1AD Classification - Edit page opens.

Figure 99 802.1Q Classification - Edit Page

802.1AD Classification - Edit

802.1AD UP: 0

802.1AD DEI: 0

802.1AD CoS: 0 ▼

802.1AD Color: Green ▼

Apply

Page Refresh Interval (Seconds): None ▼ Last Loaded: 14:00:20 Refresh Close

3. Modify the parameters you want to change:
 - **802.1AD UP** – Read-only. The User Priority (UP) bit to be mapped.
 - **802.1ADQ DEI** – Read-only. The DEI bit to be mapped.
 - **802.1AD CoS** – The CoS assigned to frames with the designated UP and DEI.
 - **802.1AD Color** – The Color assigned to frames with the designated UP and DEI.
4. Click **Apply**, then **Close**.

Modifying the DSCP Classification Table

You can configure the classification criteria for Differentiated Service Code Point (DSCP) priority values. The DSCP is a 6-bit length field inside the IP datagram header carrying priority information. Classification by DSCP can be used for untagged frames, as well as 802.1Q tagged or provider VLAN tagged frames.

To modify the classification criteria for DSCPs:

1. Select **Ethernet > QoS > Classification > DSCP**. The DSCP Classification page opens.

Figure 100 DSCP Classification Page

DSCP ▲	Binary	Description	CoS	Color
0	000000	BE(CS0)	0	Green
08	001000	CS1	1	Green
10	001010	AF11	1	Green
12	001100	AF12	1	Yellow
14	001110	AF13	1	Yellow
16	010000	CS2	2	Green
18	010010	AF21	2	Green
20	010100	AF22	2	Yellow
22	010110	AF23	2	Yellow
24	011000	CS3	3	Green
26	011010	AF31	3	Green
28	011100	AF32	3	Yellow
30	011110	AF33	3	Yellow
32	100000	CS4	4	Green
34	100010	AF41	4	Green
36	100100	AF42	4	Yellow
38	100110	AF43	4	Yellow

2. Select the row you want to modify and click **Edit**. The DSCP Classification - Edit page opens.

Figure 101 DSCP Classification - Edit Page

DSCP Classification - Edit

DSCP: 14

Binary: 001110

Description: AF13

CoS: 1

Color: Yellow

Apply

Page Refresh Interval (Seconds): None Last Loaded: 14:03:52 Refresh Close

3. Modify the parameters you want to change:
 - **DSCP** – Read-only. The DSCP value to be mapped.
 - **Binary** – Read-only. The binary representation of the DSCP value.
 - **Description** – Read-only. The description of the DSCP value.
 - **CoS** – The CoS assigned to frames with the designated DSCP value.
 - **Color** – The Color assigned to frames with the designated DSCP value.
4. Click **Apply**, then **Close**.


Modifying the MPLS EXP Bit Classification Table

MPLS bits are used to provide QoS capabilities by utilizing the bits set in the MPLS labels. Classification by MPLS bits is supported in both untagged and 802.1Q provider-tagged frames.

To modify the classification criteria for MPLS EXP bits:


1. Select **Ethernet > QoS > Classification > MPLS**. The MPLS Classification page opens.

Figure 102 MPLS Classification Page



2. Select the row you want to modify and click **Edit**. The MPLS Classification - Edit page opens.

Figure 103 MPLS Classification - Edit Page



3. Modify the parameters you want to change:
 - **MPLS EXP** – Read-only. The MPLS (experimental) bit to be mapped.
 - **CoS** – The CoS assigned to frames with the designated MPLS EXP value.
 - **Color** – The Color assigned to frames with the designated MPLS EXP value.
4. Click **Apply**, then **Close**.

Configuring Policers (Rate Metering)

This section includes:

- [Policer \(Rate Metering\) Overview](#)
- [Configuring Policer Profiles](#)
- [Assigning Policers to Interfaces](#)
- [Configuring the Ingress and Egress Byte Compensation](#)

Policer (Rate Metering) Overview

The PTP 850 switching fabric supports hierarchical policing on the logical interface level. You can define up to 250 rate meter (policer) profiles.



Note

Policing on the service point level, and the service point and CoS level, is planned for future release.

PTP 850's policer mechanism is based on a dual leaky bucket mechanism (TrTCM). The policers can change a frame's color and CoS settings based on CIR/EIR + CBS/EBS, which makes the policer mechanism a key tool for implementing bandwidth profiles and enabling operators to meet strict SLA requirements.

The output of the policers is a suggested color for the inspected frame. Based on this color, the queue management mechanism decides whether to drop the frame or to pass it to the queue.

Configuring Policer Profiles

This section includes:


- [Adding a Policer Profile](#)
- [Editing a Policer Profile](#)
- [Deleting a Policer Profile](#)

Adding a Policer Profile

To add a policer profile:


1. Select **Ethernet > QoS > Policer > Policer Profile**. The Policer Profile page opens.

Figure 104 Policer Profile Page



2. Click **Add**. The Policer Profile - Add page opens.

Figure 105 Policer Profile - Add Page



- 3. Configure the profile’s parameters. See [Table 53 Policer Profile Parameters](#) for a description of the policer profile parameters.
- 4. Click **Apply**, then **Close**.

Table 39 Policer Profile Parameters

Parameter	Definition
Profile ID	A unique ID for the policer profile. You can choose from any unused value from 1 to 250. Once you have added the profile, you cannot change the Profile ID.
Description	A description of the policer profile.
Policer type	Read-only. The type of policer. Always set to MEF-TRTCM.
CIR	Enter the Committed Information Rate (CIR) for the policer, in bits per second. Permitted values are 0, or 64,000 through 1,000,000,000 bps. If the value is 0, all incoming CIR traffic is dropped.
CBS	Enter the Committed Burst Rate (CBR) for the policer, in Kbytes. Permitted values are 2 through 128 Kbytes.
EIR	Enter the Excess Information Rate (EIR) for the policer, in bits per second. Permitted values are 0, or 64,000 through 1,000,000,000 bps. If the value is 0, all incoming EIR traffic is dropped.
EBS	Enter the Excess Burst Rate (EBR) for the policer, in Kbytes. Permitted values are 2 through 128 Kbytes.
Color mode	Select how the policer treats packets that ingress with a CFI or DEI field set to 1 (yellow). Options are: Color Aware – All packets that ingress with a CFI/DEI field set to 1 (yellow) are treated as EIR packets, even if credits remain in the CIR bucket. Color Blind – All ingress packets are treated as green regardless of their CFI/DEI value. A color-blind policer discards any former color decisions.
Coupling flag	Select Enable or Disable . When enabled, frames that ingress as yellow may be converted to green when there are no available yellow credits in the EIR bucket. Coupling Flag is only relevant in Color Aware mode.

Editing a Policer Profile

To edit a policer profile, select the profile in the Police Profile table and click **Edit**. The Policer Profile Table Edit page opens.

The Policer Profile Table - Edit page is identical to the Policer Profile Table - Add page ([Figure 132](#)). You can edit any parameter that can be configured in the Policer Profile Table Add page, except the **Profile ID**.

Deleting a Policer Profile

You cannot delete a policer profile that is attached to a logical interface. You must first remove the profile from the logical interface, then delete the profile. See [Assigning Policers to Interfaces](#).

To delete a policer profile, select the profile in the Police Profile table and click **Delete**. The profile is deleted.

To delete multiple policer profiles:

1. Select the profiles in the Policer Profile table or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Assigning Policers to Interfaces

To assign policers to a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 118).
2. Select the interface in the Ethernet Logical Port Configuration table and click **Policies**. The Policies page opens.

Figure 106 Logical Interfaces – Policies Page – Unicast Policer (Default)

For a logical interface, you can assign policers to the following traffic flows:

- Unicast Policer
- Unknown Unicast Policer
- Multicast Policer
- Unknown Multicast Policer
- Broadcast Policer
- Ethertype Policers

Assigning Unicast Policers

To assign a policer for unicast traffic to a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 118).

2. Select the interface in the Ethernet Logical Port Configuration Table and click **Policies**. The Policies page opens. By default, the Policies page opens to the Unicast Policer table ([Figure 133](#)).
3. In the **Policer profile** field, select a profile from the policer profiles defined in the system. The **Policer profile** drop-down list includes the ID and description of all defined profiles.
4. In the **Unicast admin** field, select **Enable** to enable policing on unicast traffic flows from the logical interface, or **Disable** to disable policing on unicast traffic flows from the logical interface.
5. Click **Apply**.

Assigning Multicast Policers

To assign a policer for multicast traffic to a logical interface:

1. Select Ethernet > Interfaces > Logical Interfaces. The Logical Interfaces page opens ([Figure 118](#)).
2. Select the interface in the Ethernet Logical Port Configuration table and click Policies. The Policies page opens. By default, the Policies page opens to the Unicast Policer table ([Figure 133](#)).
3. Select Multicast Policer. The Multicast Policer table appears.

Figure 107 Logical Interfaces – Policies Page – Multicast Policer

Logout ✓ Connection Admin

Filter

Unit Summary
Radio Summary

Platform
Faults
Radio
Ethernet
General Configuration
Services
Interfaces
Physical Interfaces
Logical Interfaces
PM & Statistics
QOS
Protocols
Groups
Sync
Quick Configuration
Utilities

Microwave radio: Logical Interfaces - Policies (Ethernet: Slot 1, Port 7)

<< Back to Logical Interfaces

Select Policer (Ethernet: Slot 1, Port 7)

☐ Unicast Policer
☒ Unknown Unicast Policer
☐ Multicast Policer
☐ Unknown Multicast Policer
☐ Broadcast Policer
☐ Ethertype type 1 Policer
☐ Ethertype type 2 Policer
☐ Ethertype type 3 Policer

Unknown Unicast Policer Table - Add

Interface location: Ethernet: Slot 1, Port 7

Policer profile: None

Unknown unicast admin: Disable

Apply

4. In the Policer profile field, select a profile from the policer profiles defined in the system. The Policer profile drop-down list includes the ID and description of all defined profiles.
5. In the Multicast admin field, select Enable to enable policing on multicast traffic flows from the logical interface, or Disable to disable policing on multicast traffic flows from the logical interface.
6. Click Apply.

Assigning Multicast Policers

To assign a policer for multicast traffic to a logical interface:

- 1 Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 118](#)).
- 2 Select the interface in the Ethernet Logical Port Configuration table and click **Policies**. The Policies page opens. By default, the Policies page opens to the Unicast Policer table ([Figure 133](#)).
- 3 Select **Multicast Policer**. The Multicast Policer table appears.

Logout ✓ Connection Admin

▼ Filter

[Unit Summary](#)
[Radio Summary](#)

▶ Platform
▶ Faults
▶ Radio
▲ Ethernet
 [General Configuration](#)
 [Services](#)
 ▲ Interfaces
 [Physical Interfaces](#)
 [Logical Interfaces](#)
▶ PM & Statistics
▶ QOS
▶ Protocols
▶ Groups
▶ Sync
▶ Quick Configuration
▶ Utilities

Microwave radio: Logical Interfaces - Policies (Ethernet: Slot 1, Port 7)

<< Back to Logical Interfaces

Select Policer (Ethernet: Slot 1, Port 7)

☐ Unicast Policer
☐ Unknown Unicast Policer
☒ Multicast Policer
☐ Unknown Multicast Policer
☐ Broadcast Policer
☐ Ethertype type 1 Policer
☐ Ethertype type 2 Policer
☐ Ethertype type 3 Policer

Multicast Policer Table - Add

Interface location

Policer Profile

Multicast admin

Apply

Figure 108: Logical Interfaces – Policies Page – Multicast Policer

- 4 In the **Policer profile** field, select a profile from the policer profiles defined in the system. The **Policer profile** drop-down list includes the ID and description of all defined profiles.
- 5 In the **Multicast admin** field, select **Enable** to enable policing on multicast traffic flows from the logical interface, or **Disable** to disable policing on multicast traffic flows from the logical interface.
- 6 Click **Apply**.

Assigning Unknown Multicast Policers

Unknown multicast packets are multicast packets with unknown destination MAC addresses. To assign a policer for unknown multicast traffic to a logical interface:

- 1 Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 118](#)).
- 2 Select the interface in the Ethernet Logical Port Configuration table and click **Policies**. The Policies page opens. By default, the Policies page opens to the Unicast Policer table ([Figure 133](#)).
- 3 Select **Unknown Multicast Policer**. The Unknown Multicast Policer table appears.

Figure 109: Logical Interfaces – Policies Page – Unknown Multicast Policer


- 4 In the **Policer profile** field, select a profile from the policer profiles defined in the system. The **Policer profile** drop-down list includes the ID and description of all defined profiles.
- 5 In the **Unknown multicast admin** field, select **Enable** to enable policing on unknown multicast traffic flows from the logical interface, or **Disable** to disable policing on unknown multicast traffic flows from the logical interface.
- 6 Click **Apply**.

Assigning Broadcast Policers

To assign a policer for broadcast traffic to a logical interface:

- 1 Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 118](#)).
- 2 Select the interface in the Ethernet Logical Port Configuration table and click **Policies**. The Policies page opens. By default, the Policies page opens to the Unicast Policer table ([Figure 133](#)).
- 3 Select **Broadcast Policer**. The Broadcast Policer table appears.

Figure 110 Logical Interfaces – Policies Page – Broadcast Policer



4. In the **Policer profile** field, select a profile from the policer profiles defined in the system. The **Policer profile** drop-down list includes the ID and description of all defined profiles.
5. In the **Broadcast admin** field, select **Enable** to enable policing on broadcast traffic flows from the logical interface, or **Disable** to disable policing on broadcast traffic flows from the logical interface.
6. Click **Apply**.

Assigning Ethertype Policers

You can define up to three policers per Ethertype value.

To assign a policer to an Ethertype:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 118).
2. Select the interface in the Ethernet Logical Port Configuration Table and click **Policers**. The Policers page opens. By default, the Policers page opens to the Unicast Policer table (Figure 133).
3. Select **Ethertype type 1 Policer**. The Ethertype type 1 Policer table appears.

Figure 111 Logical Interfaces – Policers Page – Ethertype Policer

4. In the **Ethertype 1 profile** field, select a profile from the policer profiles defined in the system. The **Ethertype 1 profile** drop-down list includes the ID and description of all defined profiles.
5. In the **Ethertype 1 user value** field, enter the Ethertype value to which you want to apply this policer. The field length is 4 nibbles (for example, 0x0806 - ARP).
6. In the **Ethertype 1 admin** field, select **Enable** to enable policing on the logical interface for the specified ethertype, or **Disable** to disable policing on the logical interface for the specified ethertype.
7. Click **Apply**.
8. To assign policers to additional Ethernets, select **Ethertype type 2 Policer** and **Ethertype type 3 Policer** and repeat the steps above.

Configuring the Ingress and Egress Byte Compensation

You can define the ingress and egress byte compensation value per logical interface. The policer attached to the interface uses these values to compensate for Layer 1 non-effective traffic bytes.

To define the ingress byte compensation value for a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 182).
2. Select the interface you want to configure and click **Edit**. The Logical Interfaces - Edit page opens (Figure 183).
3. In the **Ingress byte compensation** field, enter the ingress byte compensation value, in bytes. Permitted values are 0 to 32 bytes. The default value is 20 bytes.
4. In the **Egress byte compensation** field, enter the egress byte compensation value, in bytes. Permitted values are 0 to 32 bytes. The default value is 0 bytes. Only even values are permitted.
5. Click **Apply**, then **Close**.

Configuring Marking

This section includes:

- [Marking Overview](#)
- [Enabling Marking](#)
- [Modifying the 802.1Q Marking Table](#)
- [Modifying the 802.1AD Marking Table](#)

Marking Overview

When enabled, PTP 850's marking mechanism modifies each frame's 802.1p UP bit and CFI/DEI bits according to the classifier decision. The CFI/DEI (color) field is modified according to the classifier and policer decision. The color is first determined by a classifier and may be later overwritten by a policer. Green color is represented by a CFI/DEI value of 0, and Yellow color is represented by a CFI/DEI value of 1. Marking is performed on egress frames that are VLAN-tagged.

The marking is performed according to global mapping tables that describe the 802.1p UP bits and the CFI bits (for C-VLAN tags) or DEI bits (for S-VLAN tags). The marking bit in the service point egress attributes determines whether the frame is marked as green or according to the calculated color.



Note

The calculated color is sent to the queue manager regardless of whether the marking bit is set.

Regular marking is only performed when:

- The outer frame is S-VLAN, and S-VLAN CoS preservation is disabled, or
- The outer frame is C-VLAN, and C-VLAN CoS preservation is disabled.

If marking and CoS preservation for the relevant outer VLAN are both disabled, special marking is applied. Special marking means that marking is performed, but only according to the values defined for Green frames in the 802.1Q and 802.1AD marking tables.

When marking is performed, the C-VLAN or S-VLAN 802.1p UP bits are re-marked according to the calculated CoS and color, and the mapping table for C-VLAN or S-VLAN.

Enabling Marking

Marking is enabled and disabled on the service point level. See [3. Ethernet Service Points – Egress Attributes](#).

Modifying the 802.1Q Marking Table

The 802.1Q Marking table enables you to modify the CoS to UP and CFI bit mapping that is implemented when marking is enabled.

To modify the 802.1Q Marking table:

1. Select **Ethernet > QoS > Marking > 802.1Q**. The 802.1Q Marking page opens. Each row in the 802.1Q Marking page represents a CoS and color combination.

Figure 112 802.1Q Marking Page

The screenshot shows the '802.1Q Marking' page. On the left is a navigation sidebar with a tree structure. The 'Marking' option under 'QoS' is selected. The main area displays a table titled '802.1Q Marking' with the following data:

802.1Q CoS	802.1Q Color	802.1Q UP	802.1Q CFI
0	Green	0	0
0	Yellow	0	1
1	Green	1	0
1	Yellow	1	1
2	Green	2	0
2	Yellow	2	1
3	Green	3	0
3	Yellow	3	1
4	Green	4	0
4	Yellow	4	1
5	Green	5	0
5	Yellow	5	1
6	Green	6	0
6	Yellow	6	1
7	Green	7	0
7	Yellow	7	1

An 'Edit' button is located below the table.

2. Select the row you want to modify and click **Edit**. The 802.1Q Marking - Edit page opens.

Figure 113 802.1Q Marking - Edit Page

The screenshot shows the '802.1Q Marking - Edit' page. It contains the following fields and controls:

- 802.1Q CoS:
- 802.1Q Color:
- 802.1Q UP:
- 802.1Q CFI:
- Apply button
- Page Refresh Interval (Seconds):
- Last Loaded: 14:55:22
- Refresh button
- Close button

3. Enter the new 802.1Q UP and 802.1Q CFI values.
4. Click **Apply**, then **Close**.

Modifying the 802.1AD Marking Table

The 802.1AD Marking table enables you to modify the CoS to UP and DEI bit mapping that is implemented when marking is enabled.

To modify the 802.1AD Marking table:

1. Select **Ethernet > QoS > Marking > 802.1AD**. The 802.1AD Marking page opens. Each row in the 802.1AD Marking page represents a CoS and color combination.

Figure 114 802.1AD Marking Page

802.1AD CoS	802.1AD Color	802.1AD UP	802.1AD DEI
0	Green	0	0
0	Yellow	0	1
1	Green	1	0
1	Yellow	1	1
2	Green	2	0
2	Yellow	2	1
3	Green	3	0
3	Yellow	3	1
4	Green	4	0
4	Yellow	4	1
5	Green	5	0
5	Yellow	5	1
6	Green	6	0
6	Yellow	6	1
7	Green	7	0
7	Yellow	7	1

2. Select the row you want to modify and click **Edit**. The 802.1AD Marking - Edit page opens.

Figure 115 802.1AD Marking - Edit Page

802.1AD Marking - Edit

802.1AD CoS: 6

802.1AD Color: Yellow

802.1AD UP: 6

802.1AD DEI: 1

Apply

Page Refresh Interval (Seconds): None Last Loaded: 14:58:12 Refresh Close

3. Enter the new 802.1AD UP and 802.1AD DEI values.
4. Click **Apply**, then **Close**.

Configuring WRED

This section includes:

- [WRED Overview](#)
- [Configuring WRED Profiles](#)
- [Assigning WRED Profiles to Queues](#)

WRED Overview

Weighted Random Early Detection (WRED) enables differentiation between higher and lower priority traffic based on CoS. You can define up to 30 WRED profiles. Each profile contains a green traffic curve and a yellow traffic curve. This curve describes the probability of randomly dropping frames as a function of queue occupancy.

The system also includes two pre-defined read-only profiles. These profiles are assigned profile IDs 31 and 32.

- Profile number 31 defines a tail-drop curve and is configured with the following values:
 - 100% Yellow traffic drop after 64kbytes occupancy.
 - 100% Green traffic drop after 128kbytes occupancy.
 - Yellow maximum drop is 100%
 - Green maximum drop is 100%
- Profile number 32 defines a profile in which all will be dropped. It is for internal use and should not be applied to traffic.

A WRED profile can be assigned to each queue. The WRED profile assigned to the queue determines whether or not to drop incoming packets according to the occupancy of the queue. As the queue occupancy grows, the probability of dropping each incoming frame increases as well. As a consequence, statistically more TCP flows will be restrained before traffic congestion occurs.

Configuring WRED Profiles

This section includes:

- [Adding a WRED Profile](#)
- [Editing a WRED Profile](#)
- [Deleting a WRED Profile](#)

Adding a WRED Profile

To add a WRED profile:

1. Select **Ethernet > QoS > WRED > WRED Profile**. The WRED Profile page opens.

Figure 116 WRED Profile Page

WRED Profile Configuration Table

WRED Profile ID	Green curve min point	Green curve max point	Green curve max drop ratio	Yellow curve min point	Yellow curve max point	Yellow curve max drop ratio
31	128	128	100	64	64	100
32	0	0	100	0	0	100

Buttons: Add, Edit, Delete, Refresh

- Click **ADD**. The WRED Profile - Add page opens, with default values displayed.

Figure 117 WRED Profile - Add Page

WRED Profile - Add

WRED Profile ID: 1

Green curve min point: 128 (0 ... 8192)

Green curve max point: 128 (0 ... 8192)

Green curve max drop ratio: 100 (1 ... 100)

Yellow curve min point: 64 (0 ... 8192)

Yellow curve max point: 64 (0 ... 8192)

Yellow curve max drop ratio: 100 (1 ... 100)

Apply

Last Loaded: 15:05:12 Refresh Close

- In the **WRED Profile ID** field, select a unique ID to identify the profile. Permitted values are 1-30.
- In the **Green curve min point** field, enter the minimum throughput of green packets for queues with this profile, in Kbytes (0-8192). When this value is reached, the system begins dropping green packets in the queue.
- In the **Green curve max point** field, enter the maximum throughput of green packets for queues with this profile, in Kbytes (0-8192). When this value is reached, all green packets in the queue are dropped.
- In the **Green curve max drop ratio** field, enter the maximum percentage (1-100) of dropped green packets for queues with this profile.
- In the **Yellow curve min point** field, enter the minimum throughput of yellow packets for queues with this profile, in Kbytes (0-8192). When this value is reached, the system begins dropping yellow packets in the queue.

8. In the **Yellow curve max point** field, enter the maximum throughput of yellow packets for queues with this profile, in Kbytes (0-8192). After this value is reached, all yellow packets in the queue are dropped.
9. In the **Yellow curve max drop ratio** field, enter the maximum percentage (1-100) of dropped yellow packets for queues with this profile.
10. Click **Apply**, then **Close**.

Editing a WRED Profile

To edit a WRED profile:

1. Select **Ethernet > QoS > WRED > WRED Profile**. The WRED Profile page opens ().
2. Select the profile you want to edit and click Edit. The WRED Profile – Edit page opens. This page is similar to the WRED Profile – Add page ([Figure 203](#)). You can edit any parameter except the **WRED Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a WRED Profile

You cannot delete a WRED profile that is assigned to a queue. You must first remove the WRED profile from the queue, then delete the WRED profile. See [Assigning WRED Profiles to Queues](#).

To delete a WRED profile, select the profile in the WRED Profile Configuration table ([Figure 202](#)) and click **Delete**. The profile is deleted.

To delete multiple WRED profiles:

1. Select the profiles in the WRED Profile Configuration table or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Assigning WRED Profiles to Queues

To assign a WRED profile to a queue:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 182).
2. Select an interface in the Ethernet Logical Port Configuration table and click **WRED**. The WRED page opens.

Figure 118 Logical Interfaces – WRED Page

Microwave radio: Logical Interfaces - WRED (Ethernet: Slot 1, Port 7)

<< Back to Logical Interfaces

WRED (Ethernet: Slot 1, Port 7)

▼ Egress Queue WRED Configuration Table

Service Bundle ID	CoS queue ID	Profile ID
1	0	31
1	1	31
1	2	31
1	3	31
1	4	31
1	5	31
1	6	31
1	7	31

Edit

3. Select a CoS Queue ID and click **Edit**. The Logical Interfaces – WRED – Edit page opens.

Logical Interfaces - WRED

Egress Queue WRED Configuration Table - Edit

Interface location: Ethernet: Slot 1, Port 7

Service Bundle ID: 1

CoS queue ID: 0

Profile ID: 31 ▼

Apply

Page Refresh Interval (Seconds): None ▼ Last Loaded: 15:10:05 Refresh Close

Figure 119: Logical Interfaces – WRED - Edit Page

4. In the **Profile ID** field, select the WRED profile you want to assign to the selected queue.
5. Click **Apply**, then **Close**.

Configuring Egress Shaping

This section includes:

- [Egress Shaping Overview](#)
- [Configuring Queue Shaper Profiles](#)
- [Assigning a Queue Shaper Profile to a Queue](#)

Egress Shaping Overview

Egress shaping determines the traffic profile for each queue. PTP 850E can perform queue shaping on the queue level, using dual leaky bucket shaping. On the queue level, you can configure up to 31 single leaky bucket shaper profiles. If no profile is attached to the queue, no egress shaping is performed on that queue.

Configuring Queue Shaper Profiles

This section includes:


- [Adding a Queue Shaper Profile](#)
- [Editing a Queue Shaper Profile](#)
- [Deleting a Queue Shaper Profile](#)

Adding a Queue Shaper Profile

To add a queue shaper profile:


1. Select **Ethernet > QoS > Shaper > Queue Profiles**. The Queue Shaper Profile page opens.

Figure 120 Queue Shaper Profile Page



- 2. Click **Add**. The Queue Shaper – Add page opens, with default values displayed.

Figure 121 Queue Shaper Profile – Add Page



- 3. Configure the profile’s parameters. See [Table Queue Shaper Profile Parameters](#) for a description of the queue shaper profile parameters.
- 4. Click **Apply**, then **Close**.



Note
EIR and EBS are only relevant for policers assigned to logical interfaces.

Table 40 Queue Shaper Profile Parameters

Parameter	Definition
Profile ID	A unique ID for the queue shaper profile. You can choose any unused value from 1 to 32. Once you have added the profile, you cannot change the Profile ID.
Description	A description of the queue shaper profile.
CIR	Enter the Committed Information Rate (CIR) for the policer, in Kbits per second. Permitted values are 0-40000000 kbps (40 Gbps). If the value is 0, all incoming CIR traffic is dropped. Granularity is 81 kbps. The default value is 40000000 kbps.
CBS	Enter the Committed Burst Rate (CBR) for the policer, in Kbytes. Permitted values are 1-63 KB. The default value is 16 KB.
EIR	Enter the Excess Information Rate (EIR) for the policer, in Kbits per second. Permitted values are 0-40000000 kbps (40 Gbps). If the value is 0, all incoming EIR traffic is dropped. Granularity is 162 kbps. The default value is 40000000 kbps.
EBS	Enter the Excess Burst Rate (EBR) for the policer, in Kbytes. Permitted values are 1-512 KB. The default value is 16 KB.

Editing a Queue Shaper Profile

To edit a queue shaper profile:

1. Select **Ethernet > QoS > Shaper > Queue Profiles**. The Queue Shaper Profile page opens ([Figure 206](#)).
2. Select the profile you want to edit and click **Edit**. The Queue Shaper Profile – Edit page opens. This page is similar to the Queue Shaper Profile – Add page ([Figure 207](#)). You can edit any parameter except the **Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a Queue Shaper Profile

You cannot delete a queue shaper profile that is assigned to a queue. You must first remove the profile from the queue, then delete the profile. See [Assigning a Queue Shaper Profile to a Queue](#).

To delete a queue shaper profile, select the profile in the Queue Shaper Profiles Configuration table ([Figure 145](#)) and click **Delete**. The profile is deleted.

To delete multiple queue shaper profiles:

1. Select the profiles in the Queue Shaper Profiles Configuration table or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.


Assigning a Queue Shaper Profile to a Queue

To assign a queue shaper profile to a queue:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 118](#)).


- 2. Select an interface in the Ethernet Logical Port Configuration table and click **Shaper**. The Logical Interfaces – Shaper page opens, with the Egress Queue Shaper Configuration table open by default. All queue shaper profiles defined in the system are listed in the table.

Figure 122 Logical Interfaces – Shaper – Egress Queue Shaper



- 3. Click **Add**. The Egress Queue Shaper Configuration – Add page opens.

Figure 123 Logical Interfaces – Egress Queue Shaper Configuration – Add Page



Note

In this release, only one service bundle (Service Bundle ID 1) is supported.

- 4. In the **CoS queue ID** field, select the CoS queue ID of the queue to which you want to assign the shaper. Queues are numbered according to CoS value, from 0 to 7.
- 5. In the **Profile ID** field, select from a list of configured queue shaper profiles. See [Configuring Queue Shaper Profiles](#).
- 6. In the **Shaper Admin** field, select **Enable** to enable egress queue shaping for the selected queue, or **Disable** to disable egress queue shaping for the selected queue.

7. Click **Apply**, then **Close**.

To assign a different queue shaper profile to a queue:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 118](#)).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Shaper**. The Logical Interfaces – Shaper page opens, with the Egress Queue Shaper Configuration table open by default ([Figure 149](#)).
3. Select an interface in the Ethernet Logical Port Configuration table and click **Shaper**. The Logical Interfaces – Shaper page opens, with the Egress Queue Shaper Configuration table open by default ([Figure 149](#)).
4. Select the row you want to edit and click **Edit**. The Egress Queue Shaper Configuration – Edit page opens. This page is similar to the Egress Queue Shaper Configuration – Add page ([Figure 150](#)).
5. To assign a different egress queue shaper profile, select the profile in the **Profile ID** field.
6. To enable or disable egress queue shaping for the selected queue, select **Enable** to enable egress queue shaping for the queue, or **Disable** to disable egress queue shaping for the queue.
7. Click **Apply**, then **Close**.

Configuring Scheduling

This section includes:

- [Scheduling Overview](#)
- [Configuring Priority Profiles](#)
- [Configuring WFQ Profiles](#)
- [Assigning a Priority Profile to an Interface](#)
- [Assigning a WFQ Profile to an Interface](#)

Scheduling Overview

Scheduling determines the priority among the queues. PTP 850 provides a unique hierarchical scheduling model that includes four priorities, with Weighted Fair Queuing (WFQ) within each priority, and shaping per port and per queue.

The scheduler scans the queues and determines which queue is ready to transmit. If more than one queue is ready to transmit, the scheduler determines which queue transmits first based on:

- **Queue Priority** – A queue with higher priority is served before lower-priority queues.
- **Weighted Fair Queuing (WFQ)** – If two or more queues have the same priority and are ready to transmit, the scheduler transmits frames from the queues based on a WFQ algorithm that determines the ratio of frames per queue based on a predefined weight assigned to each queue.

Configuring Priority Profiles

Scheduling priority profiles determine the queue priority. Each profile contains eight CoS-based priorities, corresponding to eight queues in an interface to which the profile is assigned. You can configure up to eight priority profiles. A ninth profile, Profile ID 9, is pre-configured. You can configure Green priorities from 4 (highest) to 1 (lowest). An additional four Yellow priority profiles are defined automatically.

This section includes:


- [Adding a Scheduler Priority Profile](#)
- [Editing a Service Scheduler Priority Profile](#)
- [Deleting a Scheduler Priority Profile](#)

Adding a Scheduler Priority Profile

To add a scheduler priority profile:

1. Select **Ethernet > QoS > Scheduler > Priority Profiles**. The Scheduler Priority Profile page opens.

Figure 124 Scheduler Priority Profile Page



2. Click **Add**. The Scheduler Priority Profile – Add page opens, with default values displayed.

Figure 125 Scheduler Priority Profile – Add Page

Scheduler Priority Profile

Scheduler Priority Profile - Add

Profile ID

1

CoS 0

best effort

Priority

1

CoS 1

data service 4

Priority

2

CoS 2

data service 3

Priority

2

CoS 3

data service 2

Priority

2

CoS 4

data service 1

Priority

2

CoS 5

real time 2

Priority

3

CoS 6

real time 1

Priority

3

CoS 7

management

Priority

4

Apply

Last Loaded: 15:47:51

Refresh

Close


3.

In the **Profile ID** field, select a unique Profile ID between 1 and 8.
4.

For each CoS value, enter the Green priority, from 4 (highest) to 1 (lowest) (1-4). This priority is applied to Green frames with that CoS egressing a queue to which the profile is assigned.
5.

Optionally, you can enter a description of up to 20 characters in the field to the right of each CoS value.
6.

Click **Apply**, then **Close**.



Note

The Yellow priority values are assigned automatically by the system.

Editing a Service Scheduler Priority Profile

To edit a scheduler priority profile:

1.

Select **Ethernet > QoS > Scheduler > Priority Profiles**. The Scheduler Priority Profile page opens (Figure 153).

2. Select the profile you want to edit and click **Edit**. The Scheduler Priority Profile – Edit page opens. This page is similar to the Scheduler Priority Profile – Add page ([Figure 154](#)). You can edit any parameter except the **Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a Scheduler Priority Profile

To delete a scheduler priority profile, select the profile in the Scheduler Priority Profiles page ([Figure 153](#)) and click **Delete**. The profile is deleted.

To delete multiple scheduler priority profiles:

1. Select the profiles in the Scheduler Priority Profiles page or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Configuring WFQ Profiles

WFQ profiles determine the relative weight per queue. Each profile contains eight CoS-based weight values, corresponding to eight queues in an interface to which the profile is assigned. You can configure up to five WFQ profiles. A sixth profile, Profile ID 1, is pre-configured.

This section includes:


- [Adding a WFQ Profile](#)
- [Editing a WFQ Priority Profile](#)
- [Deleting a WFQ Profile](#)

Adding a WFQ Profile

To add a WFQ profile:

1. Select **Ethernet > QoS > Scheduler > WFQ Profiles**. The Scheduler WFQ Profile page opens.

Figure 126 Scheduler WFQ Profile Page



2. Click **Add**. The Scheduler WFQ Profile – Add page opens, with default values displayed.

Figure 127 Scheduler WFQ Profile – Add Page

Scheduler WFQ Profile - Add

Profile ID:

CIR Weight

CoS 0	<input type="text" value="20"/>
CoS 1	<input type="text" value="20"/>
CoS 2	<input type="text" value="20"/>
CoS 3	<input type="text" value="20"/>
CoS 4	<input type="text" value="20"/>
CoS 5	<input type="text" value="20"/>
CoS 6	<input type="text" value="20"/>
CoS 7	<input type="text" value="20"/>

EIR Weight

CoS 0	<input type="text" value="20"/>
CoS 1	<input type="text" value="20"/>
CoS 2	<input type="text" value="20"/>
CoS 3	<input type="text" value="20"/>
CoS 4	<input type="text" value="20"/>
CoS 5	<input type="text" value="20"/>
CoS 6	<input type="text" value="20"/>
CoS 7	<input type="text" value="20"/>

Last Loaded: 15:51:35

3. In the **Profile ID** field, select a unique Profile ID between 2 and 7. Profile ID 1 is used for a pre-defined WFQ profile.
4. For each CoS value, enter the weight for that CoS, from 1 to 20.
5. Click **Apply**, then **Close**.

Editing a WFQ Priority Profile

To edit a scheduler WFQ profile:

1. Select **Ethernet > QoS > Scheduler > WFQ Profiles**. The Scheduler WFQ Profile page opens ([Figure 155](#)).
2. Select the profile you want to edit and click **Edit**. The Scheduler WFQ Profile – Edit page opens. This page is similar to the Scheduler WFQ Profile – Add page ([Figure 145](#)). You can edit any parameter except the **Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a WFQ Profile

To delete a scheduler WFQ profile, select the profile in the Scheduler WFQ Profiles page (Figure 155) and click **Delete**. The profile is deleted.

To delete multiple scheduler WFQ profiles:

1. Select the profiles in the Scheduler WFQ Profiles page or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Assigning a Priority Profile to an Interface

To assign a priority profile to an interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 118).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Scheduler**. The Logical Interfaces – Scheduler page opens, with the Egress Port Scheduling Priority Configuration – Edit page open by default.

Figure 128 Logical Interfaces – Scheduler – Egress Port Scheduling Priority

The screenshot shows the configuration page for a logical interface. The sidebar on the left contains a navigation tree with the following structure:

- Unit Summary
- Radio Summary
- Platform
- Faults
- Radio
- Ethernet
 - General Configuration
 - Services
 - Interfaces
 - Physical Interfaces
 - Logical Interfaces
 - PM & Statistics
 - QOS
 - Classification
 - Policer
 - Marking
 - WRED
 - Shaper
 - Scheduler
 - Protocols
 - Groups
 - Sync
 - Quick Configuration
 - Utilities

The main content area is titled "Microwave radio: Logical Interfaces - Scheduler (Ethernet: Slot 1, Port 7)". It contains a "Back to Logical Interfaces" button and a "Select Scheduler (Ethernet: Slot 1, Port 7)" section with two radio buttons: "Egress Port Scheduling Priority" (selected) and "Egress Port Scheduling WFQ". Below this is the "Egress Port Scheduling Priority Configuration - Edit" section, which includes an "Interface location" field set to "Ethernet: Slot 1, Port 7" and a "Profile ID" dropdown menu set to "9". An "Apply" button is located at the bottom of the configuration section.

3. In the **Profile ID** field, select from a list of configured scheduling priority profiles. See *Configuring Priority Profiles*.
4. Click **Apply**, then **Close**.

Assigning a WFQ Profile to an Interface

To assign a WFQ profile to an interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 182).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Scheduler**. The Logical Interfaces – Scheduler page opens, with the Egress Port Scheduling Priority Configuration – Edit page open by default (Figure 218).
3. Select **Egress Port Scheduling WFQ**. The Egress Port Scheduling WFQ Configuration – Edit page opens.

Figure 129 Logical Interfaces – Scheduler – Egress Port Scheduling WFQ

The screenshot displays the NCM web interface. On the left is a navigation tree with categories like Platform, Faults, Radio, Ethernet, and QoS. The 'Logical Interfaces' link under 'Ethernet' is selected. The main content area is titled 'Microwave radio: Logical Interfaces - Scheduler (Ethernet: Slot 1, Port 7)'. It contains a 'Back to Logical Interfaces' button, a 'Select Scheduler (Ethernet: Slot 1, Port 7)' section with radio buttons for 'Egress Port Scheduling Priority' and 'Egress Port Scheduling WFQ' (which is selected), and an 'Egress Port Scheduling WFQ Configuration - Edit' section. This section includes a text field for 'Interface location' set to 'Ethernet: Slot 1, Port 7' and a dropdown menu for 'Profile ID' with the value '1' selected. An 'Apply' button is at the bottom of the configuration section.

4. In the **Profile ID** field, select from a list of configured scheduling priority profiles. See [Configuring WFQ Profiles](#).
5. Click **Apply**, then **Close**.

Configuring and Displaying Queue-Level PMs

PTP 850 devices support advanced traffic PMs per CoS queue and service bundle. For each logical interface, you can configure thresholds for Green and Yellow traffic per queue. You can then display the following PMs for 15-minute and 24-hour intervals, per queue and color:

- Maximum bytes passed per second
- Minimum bytes passed per second
- Average bytes passed per second
- Maximum bytes dropped per second
- Minimum bytes dropped per second
- Average bytes dropped per second
- Maximum packets passed per second
- Minimum packets passed per second
- Average packets passed per second
- Maximum packets dropped per second
- Minimum packets dropped per second
- Average packets dropped per second
- Seconds bytes per second were over the configured threshold per interval

These PMs are available for any type of logical interface, including groups. To activate collection of these PMs, the user must add a PM collection rule on a logical interface and service bundle and set the relevant thresholds per CoS and Color. When the PM is configured on a group, queue traffic PMs are recorded for the group and not for the individual interfaces that belong to the group.

One collection rule is available per interface.

PMs for queue traffic are saved for 30 days, after which they are removed from the database. It is important to note that they are not persistent, which means they are not saved in the event of unit reset.

To configure queue-level PMs:

- 1 Select **Ethernet > PM & Statistics > Egress CoS PM > Configuration**. The Egress CoS PM Configuration page opens.




Figure 130 Egress CoS PM Configuration Page

- 2 Click **Add**. The Egress CoS PM Configuration – Add page opens.

Egress CoS PM Configuration - Add

Interface Location: Ethernet: Slot 1, Port 1 ▼

Service Bundle ID: 1 ▼

Admin: Disable ▼

Green Bytes Passed Thresholds

CoS 0	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 1	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 2	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 3	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 4	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 5	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 6	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 7	<input type="text" value="0"/>	(0 ... 4294967295)

Yellow Bytes Passed Thresholds

CoS 0	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 1	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 2	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 3	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 4	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 5	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 6	<input type="text" value="0"/>	(0 ... 4294967295)
CoS 7	<input type="text" value="0"/>	(0 ... 4294967295)

Apply

Refresh Close

Figure 131 Egress CoS PM Configuration – Add Page

- 3 In the **Interface Location** field, select the interface for which you want to configure the collection rule.
- 4 In the **Service Bundle** field, select a service bundle (1-6).
- 5 In the **Admin** field, select **Enable** to enable the collection rule.
- 6 Enter the Green and Yellow thresholds for each CoS, in bytes (0-4294967295).
- 7 Click **Apply**.
- 8 Repeat these steps to configure collection rules for additional interfaces.

To display queue-level PMs:

- 1 Select **Ethernet > PM & Statistics > Egress CoS PM > Egress CoS PM**. The Egress CoS PM page opens.




Figure 132 Egress CoS PM Page

The **Integrity** column indicates whether the values received at the time and date of the measured interval are valid. An X in the column indicates that the values are invalid. This can occur for a number of reasons, including but not limited to a disconnected cable, a missing SFP module, muting of a radio interface, and an operational status of **Down**.

Chapter 8: Synchronization

This section includes:

- [Configuring the Sync Source](#)
- [Configuring the Outgoing Clock and SSM Messages](#)

Configuring the Sync Source



Note

To configure a sync source on which the sync source Quality parameter must be set according to ANSI specifications and you must change the ETSI/ANSI mode to ANSI before configuring the sync source. See [Changing the ETSI/ANSI Mode \(CLI\)](#).

Note that the Quality parameter is not supported in release 10.6. It is supported in release 10.9.

Frequency signals can be taken by the system from Ethernet and radio interfaces.

The reference frequency may also be conveyed to external equipment through different interfaces. For instructions how to configure the outgoing clock, see [Configuring the Outgoing Clock and SSM Messages](#).

Frequency is distributed by configuring the following parameters in each node:

- **System Synchronization Sources** – These are the interfaces from which the frequency is taken and distributed to other interfaces. Up to 16 sources can be configured in each node. A revertive timer can be configured. For each interface, you must configure:
 - **Priority (1-16)** – No two synchronization sources can have the same priority.
 - **Quality** – The quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source.

- Each unit determines the current active clock reference source interface:
 - The interface with the highest available quality is selected.
 - From among interfaces with identical quality, the interface with the highest priority is selected.

When configuring the Sync source, the Sync mode must be set to its default setting of automatic. To display the current Sync mode, enter the following CLI command in root view:

```
root> platform sync mode show
```

If the Sync mode is set to pipe, you must set it to automatic by entering the following CLI command in root view:

```
root> platform sync mode set automatic
```

When configuring an Ethernet interface as a Sync source, the Media Type of the interface must be RJ45 or SFP, *not* Auto-Type.

Viewing the Sync Source Status

To view the current sync source and its quality:

- 1 Select **Sync > Sync Source**. The Sync Source page opens.

Figure 133 Sync Source Page




Table 41 Sync Source Parameters


Parameter	Definition
System Reference Quality	The quality of the current synchronization source interface. A value of DNU indicates that no synchronization source interfaces are currently defined.
Current Active Sync Source	The currently active system synchronization source interface.
Sync Clock Unit Status	The status of the unit’s Sync E mechanism.
Sync Interface	Displays the interface that is configured as a synchronization source.
Sync Interface Quality	<p>Displays the quality level assigned to this synchronization source. This enables the system to select the source with the highest quality as the current synchronization source.</p> <p>If the Sync Interface Quality is set to Automatic, the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes "Failure." SSM must be enabled on the remote interface in order for the interface to receive SSM messages. For instructions how to enable SSM, see Configuring the Outgoing Clock and SSM Messages.</p>
Sync Interface Priority	Displays the priority assigned to this synchronization source.
Sync Interface Quality Status	Displays the current actual synchronization quality of the interface.

Adding a Sync Source

To add a synchronization source:

- 1 In the Sync Source page ([Figure 182](#)), click **Add**. The Sync Source – Add page opens.

Figure 134 Sync Source – Add Page



- 2
- In the **Sync Interface** field, select the interface you want to define as a synchronization source. You can select from the following interface types:
- Ethernet interfaces
- Radio interface

Note

In order to select an Ethernet interface, you must first specify the media type for this interface. See [Configuring Ethernet Interfaces](#).

- 3
- In the **Sync Interface Quality** field, select the quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source.
- If the **Sync Interface Quality** is set to **Automatic**, the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes **Failure**. SSM must be enabled on the remote interface in order for the interface to receive SSM messages. For instructions how to enable SSM, see [Configuring the Outgoing Clock and SSM Messages](#).

-
- If the **Sync Interface Quality** is set to a fixed value, then the quality status becomes **Failure** upon interface failure (such as LOS, LOC, LOF).
- 4
- In the **Sync Interface Priority** field, select the priority of this synchronization source relative to other synchronization sources configured in the unit (1-16). You cannot assign the same priority to more than one synchronization source. Once a priority value has been assigned, it no longer appears in the **Sync Interface Priority** dropdown list.
- 5
- Click **Apply**, then **Close**.

Editing a Sync Source

To edit a synchronization source:

- 1
- In the Sync Source page ([Figure 182](#)), click **Edit**. The Sync Source – Edit page opens.

- 2 Edit the parameters, as defined above. You can edit all the parameters except **Sync Interface**, which is read-only.
- 3 Click **Apply**, then **Close**.

Deleting a Sync Source

To delete a synchronization source:

- 1 Select the synchronization source in the Sync Source page ([Figure 182](#)).
- 2 Click **Delete**. The synchronization source is deleted.

Configuring the Outgoing Clock and SSM Messages

In the Outgoing Clock page, you can view and configure the following synchronization settings per interface:

- The interface's clock source (outgoing clock).
- For radio interfaces, the synchronization radio channel (used for interoperability).
- SSM message administration.



Note

SSM message administration is not supported in release 10.6. It is supported in release 10.9.

In order to provide topological resiliency for synchronization transfer, PTP 850E implements the passing of SSM messages over the radio interfaces. SSM timing in PTP 850E complies with ITU-T G.781.

In addition, the SSM mechanism provides reference source resiliency, since a network may have more than one source clock. The following are the principles of operation:

- At all times, each source interface has a “quality status” which is determined as follows:
 - If quality is configured as fixed, then the quality status becomes “failure” upon interface failure (such as LOS, LOC, LOF).
 - If quality is automatic, then the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes “failure”.
- Each unit holds a parameter which indicates the quality of its reference clock. This is the quality of the current synchronization source interface.
- The reference source quality is transmitted through SSM messages to all relevant radio interfaces.
- In order to prevent loops, an SSM with quality “Do Not Use” is sent from the active source interface (both radio and Ethernet)

In order for an interface to transmit SSM messages, SSM must be enabled on the interface. By default, SSM is disabled on all interfaces.

When configuring the outgoing clock and SSM administration, the Sync mode must be set to its default setting of automatic. To display the current Sync mode, enter the following CLI command in root view:

```
root> platform sync mode show
```

If the Sync mode is set to pipe, you must set it to automatic by entering the following CLI command in root view:


```
root> platform sync mode set automatic
```

To configure the outgoing clock on an Ethernet interface, the Media Type of the interface must be RJ45 or SFP, not Auto-Type. To view and configure the Media Type of an Ethernet interface, see [Configuring Ethernet Interfaces](#).

To view and configure the synchronization parameters of the unit's interfaces:


- 1 Select **Sync > Outgoing Clock**. The Outgoing Clock page opens.

Figure 135 Outgoing Clock Page



the interface you want to configure and click **Edit**. The Outgoing Clock – Edit page opens.

Figure 136 Outgoing Clock – Edit Page



- 3
- In the **Outgoing clock source** field, select the interface's synchronization source. Options are:
 - **Local Clock** – The interface uses its internal clock as its synchronization source.
 - **System Clock** – Default value. The interface uses the system clock as its synchronization source.
 - **Source Interface** – Reserved for future use.
 - **Time Loop** – Reserved for future use.
- 4
- In **Sync Radio Channel** field, use the default value of 0.
- 5
- In the **SSM Admin** field, select **On** or **Off** to enable or disable SSM for the interface. By default, SSM is disabled on all interfaces.



Note
In release 10.6, only **Off** is supported for **SSM Admin**.

Chapter 9: Access Management and Security

This section includes:

- [Configuring the General Access Control Parameters](#)
- [Configuring the Password Security Parameters](#)
- [Configuring the Session Timeout](#)
- [Configuring Users](#)
- [Configuring X.509 CSR Certificates](#)
- [Blocking Telnet Access](#)
- [Uploading the Security Log](#)
- [Uploading the Configuration Log](#)

Related topics:

- [Changing Your Password](#)

Configuring the General Access Control Parameters

To avoid unauthorized login to the system, PTP 850 automatically blocks users upon a configurable number of failed login attempts. You can also configure PTP 850 to block users that have not logged into the unit for a defined number of days.

To configure the blocking criteria:

1. Select **Platform > Security > Access Control > General**. The Access Control General Configuration page opens.

Figure 137 Access Control General Configuration Page

The screenshot shows the 'Microwave radio: Access Control General Configuration' page. On the left is a navigation menu with categories like Platform, Security, and Access Control. The 'General' option under 'Access Control' is selected. The main content area contains three configuration fields: 'Failure login attempts to block user' (set to 3), 'Blocking period (Minutes)' (set to 5), and 'Unused account period for blocking (Days)' (set to 0). Each field has a range indicator in parentheses. An 'Apply' button is located below the fields.

Field	Value	Range
Failure login attempts to block user	3	(1 ... 10)
Blocking period (Minutes)	5	(1 ... 60)
Unused account period for blocking (Days)	0	(0 ... 90)

2. In the **Failure login attempts to block user** field, select the number of failed login attempts that will trigger blocking. If a user attempts to login to the system with incorrect credentials this number of times consecutively, the user will temporarily be prevented from logging into the system for the time period defined in the **Blocking period** field. Valid values are 1-10. The default value is 3.
3. In the **Blocking period (Minutes)** field, enter the length of time, in minutes, that a user is prevented from logging into the system after the defined number of failed login attempts. Valid values are 1-60. The default value is 5.
4. In the **Unused account period for blocking (Days)** field, you can configure a number of days after which a user is prevented from logging into the system if the user has not logged in for the configured number of days. Valid values are 0, or 30-90. If you enter 0, this feature is disabled. The default value is 0.
5. Click **Apply**.

Once a user is blocked, you can unblock the user from the User Accounts page. To unblock a user:

1. Select **Platform > Security > Access Control > User Accounts**. The Access Control User Accounts page opens (Figure 195).
2. Select the user and click **Edit**. The Access Control User Accounts - Edit page opens.

Figure 138 Access Control User Accounts - Edit Page

Access Control User Accounts

Access Control User Accounts - Add

Username

Profile

Password

Blocked

Expiration date

Last Loaded: 09:18:33

3. In the **Blocked** field, select **No**.
4. Click **Apply**, then **Close**.

Configuring the Password Security Parameters

To configure enhanced security requirements for user passwords:

1. Select **Platform > Security > Access Control > Password Management**. The Access Control Password Management page opens.

Figure 139 Access Control Password Management Page

The screenshot displays the 'Access Control Password Management' configuration page. On the left, a navigation pane shows the hierarchy: Platform > Security > Access Control > Password Management. The main area contains three settings: 'Enforce password strength' (No), 'Password change for first login' (Yes), and 'Password aging (Days)' (No Aging). Buttons for 'Apply' and 'Refresh' are located below the settings.

2. In the **Enforce password strength** field, select **Yes** or **No**. When **Yes** is selected:
 - Password length must be at least eight characters.
 - Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
 - A password cannot be repeated within five changes in password.
3. In the **Password change for first login** field, select **Yes** or **No**. When **Yes** is selected, the system requires the user to change his or her password the first time the user logs in.
4. In the **Password aging (Days)** field, select the number of days that user passwords will remain valid from the first time the user logs into the system. You can enter 20-90, or **No Aging**. If you select **No Aging**, password aging is disabled and passwords remain valid indefinitely.
5. Click **Apply**.


Configuring the Session Timeout

By default, there is a 10 minute session timeout. If you do not perform any activity on the system for the period of time defined as the session timeout, the user session times out and you will have to log in to the system again.

To modify the session timeout:

1. Select **Platform > Security > Protocols Control**. The Protocols Control page opens.

Figure 140 Protocols Control Page



The screenshot shows a web interface with a top navigation bar containing 'Logout', 'Admin', and 'Connection' status. Below this is a 'Filter' dropdown. The left sidebar has a tree view with 'Main View' at the top, followed by 'Platform' (expanded) with sub-items: 'Management', 'Software', 'Configuration', 'Activation Key', 'Security' (expanded), 'General', 'X.509 Certificate', and 'Access Control'. Below 'Security' is 'Protocols Control' (highlighted), followed by 'Faults', 'Radio', 'Ethernet', 'Sync', 'Quick Configuration', and 'Utilities'. The main content area is titled 'Protocols Control' and contains two fields: 'Session timeout (Minutes)' with a dropdown menu showing '60', and 'Telnet Admin' with a dropdown menu showing 'Enable'. At the bottom of the main area are 'Apply' and 'Refresh' buttons.

2. In the **Session timeout (Minutes)** field, select a session timeout, in minutes, from 1 to 60.



Note

For information about the **Telnet Admin** field, see *Blocking Telnet Access*.

3. Click **Apply**.

Configuring Users

This section includes:

- [User Configuration Overview](#)
- [Configuring User Profiles](#)
- [Configuring Users](#)

Related topics:

- [Changing Your Password](#)

User Configuration Overview

User configuration is based on the Role-Based Access Control (RBAC) model. According to the RBAC model, permissions to perform certain operations are assigned to specific roles. Users are assigned to particular roles, and through those role assignments acquire the permissions to perform particular system functions.

In the PTP 850 GUI, these roles are called user profiles. Up to 50 user profiles can be configured. Each profile contains a set of privilege levels per functionality group, and defines the management protocols (access channels) that can be used to access the system by users to whom the user profile is assigned.

The system parameters are divided into the following functional groups:

- Security
- Management
- Radio
- TDM
- Ethernet
- Synchronization

A user profile defines the permitted access level per functionality group. For each functionality group, the access level is defined separately for read and write operations. The following access levels can be assigned:

- **None** – No access to this functional group.
- **Normal** – The user has access to parameters that require basic knowledge about the functional group.
- **Advanced** – The user has access to parameters that require advanced knowledge about the functional group, as well as parameters that have a significant impact on the system as a whole, such as restoring the configuration to factory default settings.

Configuring User Profiles

User profiles enable you to define system access levels. Each user must be assigned a user profile. Each user profile contains a detailed set of read and write permission levels per functionality group.

The system includes a number of pre-defined user profiles. You can edit these profiles, and add user profiles. Together, the system supports up to 50 user profiles.

To add a user profile:

1. Select **Platform > Security > Access Control > User Profiles**. The Access Control User Profiles page opens.

Figure 141 Access Control User Profiles Page

The screenshot shows the 'Microwave radio: Access Control User Profiles' page. The left sidebar contains a navigation tree with the following structure:

- Unit Summary
- Radio Summary
- Platform
 - Shelf Management
 - Interfaces
 - Management
 - Software
 - Configuration
 - Activation Key
 - Security
 - General
 - X.509 Certificate
 - Access Control
 - General
 - User Profiles** (selected)
 - User Accounts
 - Password Management
 - Change Password
 - RADIUS
 - Protocols Control
 - PM & Statistics
 - Faults
 - Radio
 - Ethernet
 - Sync
 - Quick Configuration
 - Utilities

The main content area displays the 'Users profile configuration table' with the following data:

<input type="checkbox"/>	Profile	Permitted access channels	Usage counter
<input checked="" type="checkbox"/>	tech	Serial+Telnet+SSH+Web+NMS	0
<input type="checkbox"/>	admin	Serial+Telnet+SSH+Web+NMS	1
<input type="checkbox"/>	viewer	Serial+Telnet+SSH+Web+NMS	0
<input type="checkbox"/>	operator	Serial+Telnet+SSH+Web+NMS	0
<input type="checkbox"/>	snmpv1v2	SNMP	1
<input type="checkbox"/>	security-officer	Serial+Telnet+SSH+Web+NMS	0

Below the table are three buttons: **Add**, **Edit**, and **Delete**.

2. Click **Add**. The Access Control User Profiles - Add page opens.

Figure 142 Access Control User Profiles - Add Page

3. In the **Profile** field, enter a name for the profile. The profile name can include up to 49 characters. Once you have created the user profile, you cannot change its name.

**Note**

The **Usage counter** field displays the number of users to whom the user profile is assigned.

4. In the **Permitted access channels** row, select the access channels the user will be permitted to use to access the system.
5. For each functionality group, select one of these options for write level and read level. All users with this profile will be assigned these access levels:
 - **None**
 - **Normal**
 - **Advanced**
6. Click **Apply**, then **Close**.

To view a user profile, click + next to the profile you want to view.

To edit a user profile, select the profile and click **Edit**. You can edit all of the profile parameters except the profile name.

To delete a user profile, select the profile and click **Delete**.

**Note**

You cannot delete a user profile if the profile is assigned to any users.


Configuring Users

You can configure up to 2,000 users. Each user has a user name, password, and user profile. The user profile defines a set of read and write permission levels per functionality group. See [Configuring User Profiles](#).

To add a new user:

- 1. Select **Platform > Security > Access Control > User Accounts**. The Access Control User Accounts page opens.

Figure 143 Access Control User Accounts Page



- 2. Click **Add**. The Access Control User Profiles - Add page opens.

Figure 144 Access Control User Accounts - Add Page

3. In the **User name** field, enter a user name for the user. The user name can be up to 32 characters.
4. In the **Profile** field, select a User Profile. The User Profile defines the user's access levels for functionality groups in the system. See [Configuring User Profiles](#).
5. In the **Password** field, enter a password for the user. If **Enforce Password Strength** is activated (see [Configuring the Password Security Parameters](#)), the password must meet the following criteria:
 - Password length must be at least eight characters.
 - Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
 - The last five passwords you used cannot be reused.
6. In the **Blocked** field, you can block or unblock the user. Selecting **Yes** blocks the user. You can use this option to block a user temporarily, without deleting the user from the system. If you set this option to **Yes** while the user is logged into the system, the user will be automatically logged out of the system within 30 seconds.

**Note**

Users can also be blocked by the system automatically. You can unblock the user by selecting **No** in the **Blocked** field. See [Configuring the General Access Control Parameters](#).

7. Optionally, in the **Expiration date** field, you can configure the user to remain active only until a defined date. After that date, the user automatically becomes inactive. To set an expiration date, click the calendar icon and select a date, or enter a date in the format dd-mm-yyyy.

In addition to the configurable parameters described above, the Access Control User Accounts page displays the following information for each user:

- **Login Status** – Indicates whether the user is currently logged into the system.
- **Last Logout** – The date and time the user most recently logged out of the system.

To edit a user's account details, select the user and click **Edit**. You can edit all of the user account parameters except the **User name** and **password**.

To add a user, click **Add**.

To delete a user, select the user and click **Delete**.

Configuring X.509 CSR Certificates and HTTPS

The web interface protocol for accessing PTP 850 can be configured to HTTP (default) or HTTPS. It cannot be set to both at the same time.

Before setting the protocol to HTTPS, you must:

1. Create and upload a CSR file. See [Generating a Certificate Signing Request \(CSR\) File](#).
2. Download the certificate to the PTP 850 and install the certificate. See [Downloading a Certificate](#).
3. Enable HTTPS. This must be performed via CLI. See [Enabling HTTPS \(CLI\)](#).

When uploading a CSR and downloading a certificate, the PTP 850 functions as an SFTP client. You must install SFTP server software on the PC or laptop you are using to perform the upload or download. For details, see [Installing and Configuring an FTP or SFTP Server](#).

**Note**

For these operations, SFTP must be used.

Generating a Certificate Signing Request (CSR) File

To generate a Certificate Signing Request (CSR) file:

1. Select **Platform > Security > X.509 Certificate > CSR**. The Security Certificate Request page opens.


Figure 145 Security Certificate Request Page

2. In the **Common Name** field, enter the fully-qualified domain name for your web server. You must enter the exact domain name.
3. In the **Organization** field, enter the exact legal name of your organization. Do not abbreviate.
4. In the **Organization Unit** field, enter the division of the organization that handles the certificate.
5. In the **Locality** field, enter the city in which the organization is legally located.
6. In the **State** field, enter the state, province, or region in which the organization is located. Do not abbreviate.
7. In the **Country** field, enter the two-letter ISO abbreviation for your country (e.g., US).
8. In the **Email** field, enter an e-mail address that can be used to contact your organization.
9. In the **File Format** field, select the **PEM** file format. Note that the **DER** file format is planned for future release.

**Note**

In this version, only PEM is supported.

10. Click **Apply** to save your settings.
11. Click **FTP Parameters** to display the FTP Parameters page.

Figure 146 FTP Parameters Page (Security Certificate Request)


12. In the **Username** field, enter the user name you configured in the SFTP server.
13. In the **Password** field, enter the password you configured in the SFTP server. If you did not configure a password for your SFTP user, simply leave this field blank.
14. In the **Path** field, enter the directory path to which you are uploading the CSR. Enter the path relative to the SFTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/"
15. In the **File name** field, enter the name you want to give to the exported CSR.
16. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the SFTP server in the **Server IPV4 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
17. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the SFTP server in the **Server IPV6 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
18. Click **Apply**, then Close, to save the FTP parameters and return to the Security Log Upload page.
19. Click **Generate & Upload**. The file is generated and uploaded.

The **CSR Status** field displays the status of any pending CSR generation and upload. Possible values are:

- **Ready** – The default value, which appears when CSR generation and upload is in progress.
- **File-in-transfer** – The upload operation is in progress.
- **Success** – The file has been successfully uploaded.
- **Failure** – The file was not successfully uploaded.


The **CSR Percentage** field displays the progress of any current CSR upload operation.

Downloading a Certificate

To download a certificate:


1. Select **Platform > Security > X.509 Certificate > Download & Install**. The Security Certification Download and Install page opens.

Figure 147 Security Certification Download and Install Page



2. Click **FTP Parameters** to display the FTP Parameters page

Figure 148 FTP Parameters Page (Security Certification Download & Install)



3. In the **User name for logging** field, enter the user name you configured in the SFTP server.
4. In the **User password to server** field, enter the password you configured in the SFTP server. If you did not configure a password for your SFTP user, simply leave this field blank.
5. In the **Path** field, enter the directory path from which you are uploading the certificate. Enter the path relative to the SFTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".

6. In the **File Name** field, enter the certificate's file name in the SFTP server.
7. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the SFTP server in the **Server IPv4 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
8. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the SFTP server in the **Server IPv6 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
9. Click **Apply** to save your settings.
10. Click **Download**. The certificate is downloaded.
11. Click **Install**. The certificate is installed on the PTP 850.


Blocking Telnet Access

You can block telnet access to the unit. By default, telnet access is not blocked.

To block telnet access:

- 1 Select **Platform > Security > Protocols Control**. The Protocols Control page opens.

Figure 149 Protocols Control Page



- 2 In the **Telnet Admin** field, select **Disable** to block telnet access. By default, telnet access is enabled (**Enable**).
- 3 Click **Apply**.

Uploading the Security Log

The security log is an internal system file which records all changes performed to any security feature, as well as all security related events.

When uploading the security log, the PTP 850 functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the import or export. For details, see [Installing and Configuring an FTP or SFTP Server](#).

To upload the security log:

1. Install and configure an FTP server on the PC or laptop you are using to perform the upload. See [Installing and Configuring an FTP or SFTP Server](#).
2. Select **Platform > Security > General > Security Log Upload**. The Security Log Upload page opens.

Figure 150 Security Log Upload Page

The screenshot displays the 'Security Log Upload' page. On the left, a navigation pane shows a tree structure with 'Platform' expanded, then 'Security', and finally 'General' where 'Security Log Upload' is selected. The main area has a header 'Microwave radio: Security Log Upload'. Below it, the 'Security Log Upload' section contains two status fields: 'File transfer status' with the value 'Ready' and 'File transfer progress' with the value '0'. At the bottom of this section are three buttons: 'Upload', 'FTP Parameters', and 'FTP Port'.

3. Click **FTP Parameters** to display the FTP Parameters page.

Figure 151 FTP Parameters Page (Security Log Upload)

The screenshot shows a web-based configuration window titled "FTP Parameters". It contains the following fields and controls:

- Username:** Text input field containing "anonymous".
- Password:** Password input field with masked characters (dots).
- Server IP address:** Text input field containing "0.0.0.0".
- Server IPv6 address:** Text input field containing "::".
- Path:** Empty text input field.
- File name:** Empty text input field.
- Apply:** A button located below the input fields.
- Page Refresh Interval (Seconds):** A dropdown menu currently set to "None".
- Last Loaded:** A timestamp display showing "15:38:38".
- Refresh:** A button next to the last loaded timestamp.
- Close:** A button at the bottom right of the main form area.
- Zoom:** A zoom level indicator at the bottom right showing "110%".

4. In the **File transfer protocol** field, select the file transfer protocol you want to use (**FTP** or **SFTP**).
5. In the **Username** field, enter the user name you configured in the FTP server.
6. In the **Password** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP user, simply leave this field blank.
7. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP server in the **Server IPV4 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
8. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP server in the **Server IPv6 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
9. In the **Path** field, enter the directory path to which you are uploading the files. Enter the path relative to the FTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/"
10. In the **File name** field, enter the name you want to give to the exported security log.
11. Click **Apply**, then **Close** to save the FTP parameters and return to the Security Log Upload page.
12. Click **Upload**. The upload begins.

The **File transfer operation status** field displays the status of any pending security log upload. Possible values are:

- **Ready** – The default value, which appears when no file transfer is in progress.
- **File-in-transfer** – The upload operation is in progress.
- **Success** – The file has been successfully uploaded.
- **Failure** – The file was not successfully uploaded.
- The **File transfer progress** field displays the progress of any current security log upload operation.

Uploading the Configuration Log


The configuration log lists actions performed by users to configure the system. This file is mostly used for security, to identify suspicious user actions. It can also be used for troubleshooting.

When uploading the configuration log, the PTP 850 functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the upload. For details, see [Installing and Configuring an FTP or SFTP Server](#).


To upload the configuration log:

1. Install and configure an FTP server on the PC or laptop you are using to perform the upload. See [Installing and Configuring an FTP or SFTP Server](#).
2. Select **Platform > Security > General > Configuration Log Upload**. The Configuration Log Upload page opens.

Figure 152 Configuration Log Upload Page



3. Click **FTP Parameters** to display the FTP Parameters page.

Figure 153 Configuration Log Upload Page


The screenshot shows a web-based configuration window titled "FTP Parameters". It contains several input fields: "File transfer protocol" (a dropdown menu set to "FTP"), "Username" (text box with "anonymous"), "Password" (text box with masked characters "••••••"), "Server IPv4 address" (text box with "0.0.0.0"), "Server IPv6 address" (text box with "::"), "Path" (empty text box), and "File name" (empty text box). Below these fields is an "Apply" button. At the bottom of the window, there is a "Page Refresh Interval (Seconds)" dropdown set to "None", a "Last Loaded: 10:07:15" timestamp, and "Refresh" and "Close" buttons.

4. In the **File transfer protocol** field, select the file transfer protocol you want to use (**FTP** or **SFTP**).
5. In the **Username** field, enter the user name you configured in the FTP server.
6. In the **Password** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP user, simply leave this field blank.
7. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP server in the **Server IPV4 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
8. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP server in the **Server IPv6 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
9. In the **Path** field, enter the directory path to which you are uploading the files. Enter the path relative to the FTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".
10. In the **File Name** field, enter the name you want to give to the exported configuration log.

**Note**

The directory path and file name, together, cannot be more than:

If the IP address family is configured to be IPv4: 236 characters

If the IP address family is configured to be IPv6: 220 characters

11. Click **Apply**, and **Close** to save the FTP parameters and return to the Configuration Log Upload page.
12. Click **Upload**. The upload begins.

The **File transfer operation status** field displays the status of any pending configuration log upload. Possible values are:

- **Ready** – The default value, which appears when no file transfer is in progress.
- **File-in-transfer** – The upload operation is in progress.
- **Success** – The file has been successfully uploaded.
- **Failure** – The file was not successfully uploaded.
- The **File transfer progress** field displays the progress of any current configuration log upload operation.

Chapter 10: Alarm Management and Troubleshooting

This section includes:

- [Viewing Current Alarms](#)
- [Viewing Alarm Statistics](#)
- [Viewing and Saving the Event Log](#)
- [Editing Alarm Text and Severity and Disabling Alarms and Events](#)
- [Configuring Voltage Alarm Thresholds and Displaying Voltage PMs](#)
- [Uploading Unit Info](#)
- [Performing Diagnostics](#)



Note

CW mode, used to transmit a single or dual frequency tones for debugging purposes, can be configured using the CLI. See [Working in CW Mode \(Single or Dual Tone\) \(CLI\)](#).


You can configure a 30-second wait time after an alarm is cleared in the system before the alarm is actually reported as being cleared. This prevents traps flooding the NMS in the event that some external condition causes the alarm to be raised and cleared continuously. By default, the timeout for trap generation is disabled. It can be enabled and disabled via CLI. See [Configuring a Timeout for Trap Generation \(CLI\)](#).

Viewing Current Alarms

To display a list of current alarms in the unit:

- 1. Select **Faults > Current Alarms**. The Current Alarms page opens. The Current Alarms page displays current alarms in the unit. Each row in the Current Alarms table describes an alarm and provides basic information about the alarm. For a description of the information provided in the Current Alarms page, see [Table 57](#).

Figure 154 Current Alarms Page



- 2. To view more detailed information about an alarm, click + at the beginning of the row or select the alarm and click **View**.

Figure 155 Current Alarms - View Page




Table 42 Alarm Information


Parameter	Definition
Sequence Number (#)	A unique sequence number assigned to the alarm by the system.
Time	The date and time the alarm was triggered.
Severity	<p>The severity of the alarm. In the Current Alarms table, the severity is indicated by a symbol. You can display a textual description of the severity by holding the cursor over the symbol.</p> <p>Note: You can edit the severity of alarm types in the Alarm Configuration page. See Editing Alarm Text and Severity.</p>
Description	A system-defined description of the alarm.
User Text	<p>Additional text that has been added to the system-defined description of the alarm by users.</p> <p>Note: You can add user text to alarms in the Alarm Configuration page. See Editing Alarm Text and Severity.</p>
Origin	The module that generated the alarm.
Probable Cause	This field only appears in the Current Alarms - View page. One or more possible causes of the alarm, to be used for troubleshooting.
Corrective Actions	This field only appears in the Current Alarms - View page. One or more possible corrective actions to be taken in troubleshooting the alarm.
Alarm ID	A unique ID that identifies the alarm type.

Viewing Alarm Statistics

To display a summary of alarms per module and per interface:

- 1. Select **Faults > Alarm Statistics**. The Alarm Statistics page opens.

Figure 156 Alarm Statistics Page



The Alarm Statistics page displays the number of current alarms per severity level for each module, interface, and virtual interface (such as Multi-Carrier ABC groups) in the unit. Only modules and interfaces for which one or more alarms are currently raised are listed in the Alarm Statistics page.

Viewing and Saving the Event Log

The Event Log displays a list of current and historical events and information about each event.

To display the Event Log:

- 1. Select **Faults > Event Log**. The Event Log opens. For a description of the information provided in the Event Log, see [Table 58 Event Log Information](#).
- 2. To export the Event Log to a CSV file, click **Export to CSV** in the lower right corner of the Event Log page.

Figure 157 Event Log




Table 43 Event Log Information

Parameter	Definition
Time	The date and time the event was triggered.
Sequence Number (#)	A unique sequence number assigned to the event by the system.
Severity	<p>The severity of the event. In the Event Log table, the severity is indicated by a symbol. You can display a textual description of the severity by holding the cursor over the symbol.</p> <p>Note: You can edit the severity of event types in the Alarm Configuration page. See Editing Alarm Text and Severity.</p>
State	Indicates whether the event is currently raised or has been cleared.
Description	A system-defined description of the event.

Parameter	Definition
User Text	<p>Additional text that has been added to the system-defined description of the event by users.</p> <p>Note: You can add user text to events in the Alarm Configuration page. See Editing Alarm Text and Severity.</p>
Origin	The module that generated the event.

Editing Alarm Text and Severity | Disabling Alarms and Event

You can view a list of alarm types, edit the severity level assigned to individual alarm types, and add additional descriptive text to individual alarm types.

This section includes:

- [Displaying Alarm Information](#)
- [Viewing the Probable Cause and Corrective Actions for an Alarm Type](#)
- [Editing an Alarm Type and Disabling Alarms and Events](#)
- [Setting Alarms to their Default Values](#)

Displaying Alarm Information

To view the list of alarms defined in the system:

1. Select **Faults > Alarm Configuration**. The Alarm Configuration page opens. For a description of the information provided in the Alarm Configuration page, see [Table 59 Alarm Configuration Page Parameters](#).

Figure 158 Alarm Configuration Page

#	Alarm ID	Severity	Description	Additional Text	Service Affecting
1	10	Warning	Framer digital loopback		off
2	100	Critical	LAG is not fully functional - LAG Degraded		off
3	101	Critical	LAG operational state is down		off
4	102	Critical	Loopback is active		on
5	103	Warning	Slot X port XX is mirrored to slot Y port YY		on
6	120	Critical	Speed port mismatch		on
7	150	Critical	Auto-state-propagation is triggered		on
8	200	Critical	Protection communication is down		on
9	201	Critical	Protection in Lockout State		off
10	202	Critical	Protection switchover due to local failure		off
11	203	Critical	Mate does not exist		on
12	307	Warning	TDM interface is up		on
13	308	Warning	TDM interface is down		on
14	401	Critical	Loss of Carrier		on
15	407	Warning	Ethernet interface is up		on
16	408	Warning	Ethernet interface is down		on
17	601	Critical	Radio excessive BER		on
18	603	Critical	Radio loss of frame		off
19	604	Warning	Radio signal degrade		on
20	605	Warning	Radio interface is up		on
21	606	Warning	Radio interface is down		on
22	607	Warning	Frequency scanner in process		on
23	604	Critical	Radio failure		off

Table 44 Alarm Configuration Page Parameters

Parameter	Definition
Sequence Number (#)	A unique sequence number assigned to the row by the system.
Alarm ID	A unique ID that identifies the alarm type.

Parameter	Definition
Severity	The severity assigned to the alarm type. You can edit the severity in the Alarm Configuration – Edit page. See Editing an Alarm Type .
Description	A system-defined description of the alarm.
Additional Text	Additional text that has been added to the system-defined description of the alarm by users. You can edit the text in the Alarm Configuration – Edit page. See Editing an Alarm Type .
Service Affecting	Indicates whether the alarm is considered by the system to be service-affecting (on) or not (off).

Viewing the Probable Cause and Corrective Actions for an Alarm Type

Most alarm types include a system-defined probable cause and suggested corrective actions. To view an alarm type's probable cause and corrective actions, click + on the left side of the alarm type's row in the Alarm Configuration page. The Probable Cause and Corrective Actions appear underneath the alarm type's row, as shown below. If there is no +, that means no Probable Cause and Corrective Actions are defined for the alarm type.

Figure 159 Alarm Configuration Page – Expanded

▼ Alarm Configuration					
#	Alarm ID ▲	Severity	Description	Additional Text	Service Affecting
+	1	10	⚠️ Framer digital loopback		off
+	2	100	🔴 LAG is not fully functional - LAG Degraded		off
+	3	101	🔴 LAG operational state is down		off
+	4	102	🟡 Loopback is active		on
+	5	103	🟡 Slot X port XX is mirrored to slot Y port YY		on
+	6	120	🔴 Speed port mismatch		on
Probable Cause The system reset is required after the port speed was changed					
Corrective Actions 1. Change the port speed to the previous value 2. Reset the system					
+	7	150	🔴 Auto-state-propagation is triggered		on
+	8	200	🔴 Protection communication is down		on
+	9	201	🔴 Protection in Lockout State		off
+	10	202	🔴 Protection switchover due to local failure		off
+	11	203	🔴 Mate does not exist		on

Editing an Alarm Type and Disabling Alarms and Events

You can change the severity of an alarm type, and add additional text to the alarm type's description.

You can also choose to disable selected alarms and events. Any alarm or event can be disabled, so that no indication of the alarm is displayed, and no traps are sent for the alarm.


If you disable an alarm that is currently raised, the alarm is treated as if it has been cleared. If an alarm that has been disabled is enabled while it is in a raised state, the alarm is treated as if it has just been raised when it is enabled.

If a timeout for trap generation is configured, and a disabled alarm is enabled while the alarm is raised, the timeout count begins to run when the alarm is enabled. If an alarm is disabled while raised, the timeout count begins to run upon disabling the alarm, and an alarm cleared trap is sent when the timeout expires.

To change the severity of an alarm type and add additional text to the alarm type's description:

1. Select the alarm type in the Alarm Configuration page ([Figure 231](#)).
2. Click **Edit**. The Alarm Configuration - Edit page opens.

Figure 160 Alarm Configuration - Edit Page



Alarm Configuration

Alarm Configuration - Edit

Alarm ID: 120

Description: Speed port mismatch

Severity: Major

Additional Text:

Apply

Last Loaded: 10:31:50 Refresh Close

3. Modify the **Severity** and/or **Additional Text** fields.
4. Click **Apply**, then **Close**.

Setting Alarms to their Default Values

To set all alarms to their default severity levels and text descriptions, click **Set All to Default** in the Alarm Configuration page ([Figure 231](#)).

Configuring Voltage Alarm Thresholds and Displaying Voltage PMs

You can configure undervoltage and overvoltage alarm thresholds and display voltage PMs.

The default thresholds for PTP 850E are:

- Undervoltage Raise Threshold: 32V
- Undervoltage Clear Threshold: 34V
- Overvoltage Raise Threshold: 60V
- Overvoltage Clear Threshold: 58V

These thresholds determine when the following alarms are raised and cleared:

- Alarm #32000: Under voltage
- Alarm #32001: Over voltage

To configure voltage alarm thresholds:

- 1 Select **Faults > Voltage Alarm Configuration**. The Voltage Alarm Configuration page opens.



Note

You can also open the Voltage Alarm Configuration page by selecting **Platform > PM & Statistics > Voltage** and clicking **Thresholds**.

Logout Connection Admin

Filter

Unit Summary

Radio Summary

Platform

Faults

- Current Alarms
- Alarm Statistics
- Event Log
- Alarm Configuration
- Voltage Alarm Configuration

Radio

Ethernet

Sync

Quick Configuration

Utilities

Voltage Alarm Configuration

Voltage Alarm Threshold Configuration

Undervoltage clear threshold (V)	Undervoltage raise threshold (V)	Overvoltage clear threshold (V)	Overvoltage raise threshold (V)
34	32	75	89

Edit

Figure 161 Voltage Alarm Configuration Page

phn-3963_008v000
Page 10-10

- Click **Edit**. The Voltage Alarm Configuration – Edit page opens.

Figure 162 Voltage Alarm Configuration – Edit Page

- Select the thresholds you want in the **Undervoltage clear threshold (V)**, **Undervoltage raise threshold (V)**, **Overvoltage clear threshold (V)**, and **Overvoltage raise threshold (V)** fields. The configurable values for these thresholds are 0-100V.
- Click **Apply**.

To display voltage PMs:

- Select **Platform > PM & Statistics > Voltage**. The Voltage PM Report page opens.

#	Time Interval	Minimum Voltage (V)	Maximum Voltage (V)	Undervoltage Seconds	Overvoltage Seconds	Integrity
	Current (13:39:57)	48	48	0	0	✓
1	16-Jan-19 13:30	48	48	0	0	✓
2	16-Jan-19 13:15	48	48	0	0	✓
3	16-Jan-19 13:00	48	48	0	0	✓
4	16-Jan-19 12:45	48	48	0	0	✓
5	16-Jan-19 12:30	48	48	0	0	✓
6	16-Jan-19 12:15	48	48	0	0	✓
7	16-Jan-19 12:00	48	48	0	0	✓
8	16-Jan-19 11:45	48	48	0	0	✓
9	16-Jan-19 11:30	48	48	0	0	✓
10	16-Jan-19 11:15	48	48	0	0	✓
11	16-Jan-19 11:00	48	48	0	0	✓
12	16-Jan-19 10:45	48	48	0	0	✓
13	16-Jan-19 10:30	48	48	0	0	✓
14	16-Jan-19 10:15	48	48	0	0	✓
15	16-Jan-19 10:00	48	48	0	0	✓

Figure 163 Voltage PM Report Page

- In the **Interface** field, select the power input for which to display PMs.
- In the **Interval Type** field:
 - To display reports for the past 24 hours, in 15 minute intervals, select **15 minutes**.

- To display reports for the past month, in daily intervals, select **24 hours**.

Table 45 Voltage PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Minimum Voltage (V)	The lowest voltage during the measured period.
Maximum Voltage (V)	The highest voltage during the measured period.
Undervoltage Seconds	The number of seconds the unit was in an undervoltage state during the measured period.
Overvoltage Seconds	The number of seconds the unit was in an overvoltage state during the measured period.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred during the interval.

Uploading Unit Info

You can generate a Unit Information file, which includes technical data about the unit. This file can be uploaded and forwarded to customer support, at their request, to help in analyzing issues that may occur.

When uploading a Unit Information file, the PTP 850 functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the upload. For details, see [Installing and Configuring an FTP or SFTP Server](#).




Note

For troubleshooting, it is important that an updated configuration file be included in Unit Info files that are sent to customer support. To ensure that an up-to-date configuration file is included, it is recommended to back up the unit’s configuration before generating the Unit Info file.

- To generate and upload a Unit Information file:
1. Install and configure an FTP server on the PC or laptop you are using to perform the upload. See [Installing and Configuring an FTP or SFTP Server](#).
 2. Select **Platform > Management > Unit Info**. The Unit Info page opens.

Figure 164 Unit Info Page



3. Click **FTP Parameters** to display the FTP Parameters page.

4. In the **File transfer protocol** field, select the file transfer protocol you want to use (**FTP** or **SFTP**).
5. In the **Username in server** field, enter the user name you configured in the FTP server.
6. In the **Password in server** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP user, simply leave this field blank.
7. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP server in the **Server IPv4 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
8. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP server in the **IPv6 Server Address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
9. In the **Path** field, enter the directory path to which you are uploading the file. Enter the path relative to the FTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".
10. In the **File Name** field, enter the name you want to give to the exported Unit Information file.
11. Click **Apply** to save your settings.
12. Click **Create** to create the Unit Information file. The following fields display the status of the file creation process:
 - **Unit Info File creation status** – Displays the file creation status. You must wait until the status is Success to upload the file. Possible values are:
 - **Ready** – The default value, which appears when no file is being created.
 - **Generating File** – The file is being generated.
 - **Success** – The file has been successfully created. You may now upload the file.
 - **Failure** – The file was not successfully created.
 - **Unit Info File creation progress** – Displays the progress of the current Unit Information file creation operation.
13. Click **Export**. The upload begins. The following fields display the status of the upload process:
 - **File File transfer status** – Displays the status of any pending Unit Information file upload. Possible values are:
 - **Ready** – The default value, which appears when no file transfer is in progress.

- **File-in-transfer** – The upload operation is in progress.
- **Success** – The file has been successfully uploaded.
- **Failure** – The file was not successfully uploaded.

If you try to export the file before it has been created, the following error message appears: **Error #3-Invalid set value.**

If this occurs, wait about two minutes then click **Export** again.

- **File transfer progress** – Displays the progress of the current Unit Information file upload operation.

Performing Diagnostics

This section includes:

- [Performing Radio Loopback](#)
- [Performing Ethernet Loopback](#)
- [Configuring Service OAM \(SOAM\) Fault Management \(FM\)](#)

Performing Radio Loopback



Note

To perform radio loopback, the radio must be set to its maximum TX power.

To perform loopback on a radio:

1. Select **Radio > Diagnostics > Loopback**. The Radio Loopbacks page opens.

Figure 165 Radio Loopbacks Page

Logout Connection Admin

Filter

Unit Summary

Radio Summary

Platform

Faults

Radio

- Radio Parameters
- Remote Radio Parameters
- Radio BER Thresholds

Ethernet Interface

MRMC

PM & Statistics

Diagnostics

- Loopback

Ethernet

Sync

Quick Configuration

Utilities

Microwave radio: Radio Loopbacks

Radio Loopbacks Configuration

Radio LocationRadio: Slot 1, Port 1

Loopback timeout (minutes)1(0 ... 1440)

RF LoopbackOff

IF LoopbackOff

Apply

2. In the **Loopback timeout (minutes)** field, enter the timeout, in minutes, for automatic termination of the loopback (0-1440). A value of 0 indicates that there is no timeout.
3. In the **RF loopback** field, select **On**.



Note

IF Loopback is planned for future release.

4. Click **Apply**.

Performing Ethernet Loopback

Ethernet loopbacks can be performed on any logical Ethernet interface except a LAG. When Ethernet loopback is enabled on an interface, the system loops back all packets ingressing the interface. This enables loopbacks to be performed over the link from other points in the network.

To perform Ethernet loopback:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 118).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Loopback**. The Logical Interfaces – Loopback page opens.

Figure 166 Logical Interfaces – Loopback Page

3. In the **Ethernet loopback admin** field, select **Enable** to enable Ethernet loopback on the logical interface, or **Disable** to disable Ethernet loopback on the logical interface.
4. In the **Ethernet loopback duration (sec)** field, enter the loopback duration time (in seconds).
5. In the **Swap MAC address admin** field, select whether to swap DA and SA MAC addresses during the loopback. Swapping addresses prevents Ethernet loops from occurring. It is recommended to enable MAC address swapping if LLDP is enabled.
6. Click **Apply** to initiate the loopback.

Configuring Service OAM (SOAM) Fault Management (FM)

This section includes:

- [SOAM Overview](#)
- [Configuring MDs](#)
- [Configuring MA/MEGs](#)
- [Configuring MEPs](#)

- [Displaying Remote MEPs](#)
- [Displaying Last Invalid CCMS](#)

SOAM Overview

The Y.1731 standards and the MEF-30 specifications define Service OAM (SOAM). SOAM is concerned with detecting, isolating, and reporting connectivity faults spanning networks comprising multiple LANs, including LANs other than IEEE 802.3 media.

Y.1731 Ethernet FM (Fault Management) consists of three protocols that operate together to aid in fault management:

- Continuity check
- Link trace
- Loopback



Note

Link trace is planned for future release.

PTP 850 utilizes these protocols to maintain smooth system operation and non-stop data flow.

The following are the basic building blocks of FM:

- MD (Maintenance Domain) – An MD defines the management space on a network, typically owned and operated by a single entity, for which connectivity faults are managed via SOAM.
- MA/MEG (Maintenance Association/Maintenance Entity Group) – An MA/MEG contains a set of MEPs or MIPs.
- MEP (MEG End Points) – Each MEP is located on a service point of an Ethernet service at the boundary of the MEG. By exchanging CCMs (ContinuityCheck Messages), local and remote MEPs have the ability to detect the network status, discover the MAC address of the remote unit/port where the peer MEP is defined, and identify network failures.
- MIP (MEG Intermediate Points) – Similar to MEPs, but located inside the MEG and can only respond to, not initiate, CCM messages.
- CCM (Continuity Check Message) – MEPs in the network exchange CCMs with their peers at defined intervals. This enables each MEP to detect loss of connectivity or failure in the remote MEP.


Configuring MDs

In the current release, you can define one MD, with an **MD Format** of **None**.

To add an MD:


1. Select **Ethernet > Protocols > SOAM > MD**. The SOAM MD page opens.

Figure 167 SOAM MD Page



2. Click **Add**. The SOAM MD – Add page opens.

Figure 168 SOAM MD Page



- 3. In the **MD Name** field, enter an identifier for the MD (up to 43 alphanumeric characters). The MD Name should be unique over the domain.
- 4. In the **MD Format** field, select **None**.

Note

Support for MDs with the MD format Character String is planned for future release. In this release, the software enables you to configure such MDs, but they have no function.

- 5. In the **MD Level** field, select the maintenance level of the MD (1-7). The maintenance level ensures that the CFM frames for each domain do not interfere with each other. Where domains are nested, the encompassing domain must have a higher level than the domain it encloses. The maintenance level is carried in all CFM frames that relate to that domain. The **MD Level** must be the same on both sides of the link.

**Note**

In the current release, the MD level is not relevant to the SOAM functionality.

- Click **Apply**, then **Close**.

The **MHF (MIP) Creation** field displays the contents of MHF format included in the CCMs sent in this MD (in the current release, this is **MHF none** and **MHF default**).

The **Sender TLV Content** field displays the contents of TLVs included in the CCMs sent in this MD (in the current release, this is only **Send ID Chassis**).

Configuring MA/MEGs

You can configure up to 64 MEP pairs per network element:

- Fast MEGs have a CCM interval of 1 second.
- Slow MEGs have a CCM interval of 10 seconds, 1 minute, or 10 minutes.

You can configure up to 1024 Slow MEPs and up to 256 Fast MEPs per network element. You can configure up to 348 Slow Local MEPs (a local MEP in a Slow MEG) and up to 64 Fast Local MEPs (a local MEP in a Fast MEG) per network element.

To add a MEG:

- Select **Ethernet > Protocols > SOAM > MA/MEG**. The SOAM MA/MEG page opens.

Figure 169 SOAM MA/MEG Page

SOAM MA/MEG

MD (ID, Name) 1, TR-998

▼ SOAM MA/MEG

MD ID ▲	MA/MEG ID	MA/MEG short name	MA/MEG Name Format	MEG Level	CCM Interval	Service ID	MHF (MIP) Creation	Tx Sender ID TLV content	Port Status TLV TX	Interface Status TLV TX	MEP List ▲
1	2	56	Char string	5	1 second	1	MHF explicit	Send Id Defer	False	False	

Add MEG Edit Delete MEG MEP List

- Click **Add MEG**. The SOAM MA/MEG – Add page opens.

Figure 170 SOAM MA/MEG – Add Page

SOAM MA/MEG

SOAM MA/MEG - Add

MD (ID, Name)

1, TR-998

MA/MEG ID

1

(1 ... 4294967295)

MA/MEG short name

MA/MEG Name Format

Char string

MEG Level

0

CCM Interval

1 second

Service ID

1

MHF (MIP) Creation

MHF none

Tx Sender ID TLV content

Send Id Defer

Apply

Last Loaded: 11:06:07

Refresh

Close

3. Configure the fields described in *Table 63*.
4. Click **Apply**, then **Close**.

[Table 62](#) describes the status (read-only) fields in the SOAM MA/MEG Component table.

Table 46 SOAM MA/MEG Configuration Parameters

Parameter	Definition
MD (ID, Name)	Select the MD to which you are assigning the MEP.
MA/MEG short name	Enter a name for the MEG (up to 44 alphanumeric characters).

Parameter	Definition
MEG Level	<p>Select a MEG level (0-7). The MEG level must be the same for MEGs on both sides of the link. Higher levels take priority over lower levels.</p> <p>If MEGs are nested, the OAM flow of each MEG must be clearly identifiable and separable from the OAM flows of the other MEGs. In cases where the OAM flows are not distinguishable by the Ethernet layer encapsulation itself, the MEG level in the OAM frame distinguishes between the OAM flows of nested MEGs.</p> <p>Eight MEG levels are available to accommodate different network deployment scenarios. When customer, provider, and operator data path flows are not distinguishable based on means of the Ethernet layer encapsulations, the eight MEG levels can be shared among them to distinguish between OAM frames belonging to nested MEGs of customers, providers and operators. The default MEG level assignment among customer, provider, and operator roles is:</p> <p>The customer role is assigned MEG levels 6 and 7.</p> <p>The provider role is assigned MEG levels 3 through 5.</p> <p>The operator role is assigned MEG levels: 0 through 2.</p> <p>The default MEG level assignment can be changed via a mutual agreement among customer, provider, and/or operator roles.</p> <p>The number of MEG levels used depends on the number of nested MEGs for which the OAM flows are not distinguishable based on the Ethernet layer encapsulation.</p>
CCM Interval	<p>The interval at which CCM messages are sent within the MEG. Options are:</p> <ul style="list-style-type: none"> 1 second (default) 10 seconds 1 minute 10 minutes <p>It takes a MEP 3.5 times the CCM interval to determine a change in the status of its peer MEP. For example, if the CCM interval is 1 second, a MEP will detect failure of the peer 3.5 seconds after it receives the first CCM failure message. If the CCM interval is 10 minutes, the MEP will detect failure of the peer 35 minutes after it receives the first CCM failure message.</p>
Service ID	<p>Select an Ethernet service to which the MEG belongs. You must define the service and add service points before you configure the MEG.</p>

Parameter	Definition
MHF (MIP) Creation	<p>Determines whether MIPs are created on the MEG. Options are:</p> <ul style="list-style-type: none"> • MHF none – No MIPs are created. • MHF default – MIPs are created automatically on any service point in the MEG's Ethernet service. • MHF explicit – MIPs are created on the service points of the MEG when a lower-level MEP exists on the service point. This option is usually used when the operator's domain is encompassed by another domain. <p>MHF defer – No MIPs are created. Not used in the current release.</p>

Table 47 SOAM MA/MEG Status Parameters

Parameter	Definition
MA/MEG Name Format	Reserved for future use. In the current release, this is Char String only.
Tx Sender ID TLV content	Reserved for future use. Sender ID TLV is not transmitted.
Port Status TLV TX	Reserved for future use. No Port Status TLV is transmitted in the CCM frame.
Interface Status TLV TX	Reserved for future use. No Interface Status TLV is transmitted in the CCM frame.
MEP List	Lists all local and remote MEPs that have been defined for the MEG.

Configuring MEPs

Each MEP is attached to a service point in an Ethernet service. The service and service point must be configured before you configure the MEP. See [Configuring Ethernet Service\(s\)](#).

Each MEP inherits the same VLAN, C-VLAN, or S-VLAN configuration as the service point on which it resides. See [Configuring Service Points \(CLI\)](#).Configuring Service Points

In order to set the VLAN used by CCM/LBM/LTM if the service point is defined ambiguously (for example PIPE, Bundle-C, Bundle-S, or All-to-One), the service point's C-VLAN/S-VLAN parameter should not be set to N.A.

To configure a MEP, you must:


1. Add MEPs to the relevant MA/MEG. In this stage, you add both local and remote MEPs. The only thing you define at this point is the MEP ID. See [1. Adding Local and Remote MEPs](#).
2. Configure the local MEPs. At this point, you determine which MEPs are local MEPs. The system automatically defines the other MEPs you configured in the previous step as remote MEPs. See [2. Configuring the Local MEPs](#).
3. Enable the Local MEPs. See [3. Enabling Local MEPs](#).

Adding Local and Remote MEPs

To add a MEP to the MA/MEG:


1. In the SOAM MA/MEG page, select a MA/MEG and click **MEP List**. The MEP List page opens.

Figure 171 MEP List Page



2. Click **Add**. The Add MEP page opens.

Figure 172 Add MEP Page



3. In the **MEP ID** field, enter a MEP ID (1-8191).

4. Click **Apply**, then **Close**.

Configuring the Local MEPs

Once you have added local and remote MEPs, you must define the MEPs and determine which are the local MEPs:

1. Select **Ethernet > Protocols > SOAM > MEP**. The SOAM MEP page opens. [Table 65](#) lists and describes the parameters displayed in the SOAM MEP page.

Figure 173 SOAM MEP Page

SOAM MEP

MD (ID, Name) 1, TR_998

Filter by MA/MEG All

▼ SOAM MEP

<input type="checkbox"/>	MD ID ▲	MA/MEG ID	MEP ID	Interface Location	SP ID	MEP Direction	MEP Fault Notification State	Connectivity Status	MEP Active	MEP CCM TX Enable	CCM and LTM Priority	MEP Defects	RMEP List ▲
<input checked="" type="checkbox"/>	1	1	10	Ethernet: Slot 1, Port 1	1	Down	Fng Reset	inactive	False	False	7	None	35
<input type="checkbox"/>	1	1	25	Ethernet: Slot 2, Port 4	3	Down	Fng Reset	inactive	False	False	7	None	35

Add Edit Delete RMEP List Last Invalid CCMS Loopback Refresh

Multiple Selection Operation
MEP CCM TX Enable True Apply



Note

To display MEPs belonging to a specific MEG, select the MEG in the **Filter by MA/MEG** field near the top of the SOAM MEP page. To display all MEPs configured for the unit, select **All**.

2. Click **Add**. Page 1 of the Add SOAM MEP wizard opens.

Figure 174 Add SOAM MEP Wizard – Page 1

Add SOAM MEP

MD (ID, Name) 1, MD1

MA/MEG (ID, Name) 1, 58

<< Back

Next >>

Last Loaded: 11:55:14 Close

3. In the **MEG Name** field, select an MA/MEG.
4. Click **Next**. Page 2 of the Add SOAM MEP wizard opens.

Figure 175 Add SOAM MEP Wizard – Page 2

5. In the **Direction** field, select **Up** or **Down**.
6. In the **MEP ID** field, select a MEP ID from the list of MEPs you have added to the selected MEG.
7. In the **Service Point** field, select the service point on which you want to place the MEP.
8. Click **Finish**. The Add SOAM MEP wizard displays the parameters you have selected.

Figure 176 Add SOAM MEP Wizard –Summary Page

9. Verify that you want to submit the displayed parameters and click **Submit**.

Table 48 SOAM MEP Parameters

Parameter	Definition
MD (ID, Name)	AnThe MD ID and name are automatically generated by the system.
MA/MEG (ID, Name)	AnThe MA/MEG ID and name are automatically generated by the system.

Parameter	Definition
MEP ID	The MEP ID.
Interface Location	The interface on which the service point associated with the MEP is located.
SP ID	The service point ID.
MEP Direction	In this release, only Up or Down is supported.
MEP Fault Notification State	<p>The initial Indicates the status of the defect SOAM state machine. Possible values are:</p> <ul style="list-style-type: none"> • Fng Reset – Initial state. • Fng Defect – Transient state when a defect is detected. • Fng Defect Reported – The defect state is steady (stable). • Fng Defect Clearing – Transient state when a defect is in the process of being cleared. • Fng Defect Cleared – The defect has been cleared (Transient state).
MEP ActiveConnectivity Status	<p>Indicates whether a MEP can exchange PDU (CCM, Loopback, LTR) with its remote MEP. A MEP with some defect or an inactive MEP cannot exchange PDUs. Possible values are:</p> <ul style="list-style-type: none"> • inactive – At least one of the MEPreMOTE MEPs is enabled (True).in rMEPFailed status (not discovered). • active – All remote MEPs are discovered correctly and have an rMEPOk status.
MEP Active	Indicates whether the MEP is enabled (True) or disabled (False).
MEP CCM TX Enable	Indicates whether the MEP is sending CCMs (True/False).
CCM and LTM Priority	The p-bit included in CCMs and/or LTM frames sent by this MEP (0 to 7).
MEP Defects	Reserved for future use.Indicates if a defect has been detected by the MEP level.
RMEP List	Once you have configured at least one local MEP, all other MEPs that you have added but not configured as local MEPs are displayed here, and are considered to be remote MEPs.

Enabling Local MEPs

Once you have added a MEP and defined it as a local MEP, you must enable the MEP.

To enable a MEP:

1. In the SOAM MEP page ([Figure 247](#)), select the MEP you want to enable.
2. Click **Edit**. The SOAM MEP - Edit page opens.

Figure 177 SOAM MEP - Edit Page

MD ID	1
MD Name	TR_998
MA/MEG ID	1
MA/MEG Name	56
MEP ID	25
MEG Level	1
Interface Location	Ethernet: Slot 1, Port 1
Service ID	10
Service point ID	1
MEP Direction	Down
MEP Fault Notification State	Eng Defect Reported
MEP MAC Address	00:0A:25:40:1F:93
MEP Alarm On time	250
MEP Alarm Clear time	1000
Connectivity Status	inactive
MEP highest priority fault alarm	Remote CCM
MEP Lowest priority fault alarm	All Def
MEP Operational State	enabled
Last Sent Port status TLV	Ps No Port State TLV
Last Sent Interface status TLV	Down
Last MEP Defects	None
RDI TX indication	False
MEP Defects	Remote CCM
MEP Active	True
MEP CCM TX Enabled	True
CCM and LTM Priority	7

Apply

Page Refresh Interval (Seconds) None Last Loaded: 11:55:18 Refresh Close

3. In the **MEP Active** field, select **True**.
4. In the **MEP CCM TX Enable** field, select **True**.
5. In the **CCM and LTM Priority** field, select the p-bit that will be included in CCMs sent by this MEP (0 to 7). It is recommended to select 7.
6. Click **Apply**, then **Close**.

Displaying Remote MEPs

To display a list of remote MEPs (RMEPs) and their parameters:

1. Select **Ethernet > Protocols > SOAM > MEP**. The SOAM MEP page opens (Figure 247).
2. Select a MEP and click **RMEP List**. The SOAM MEP DB table is displayed.

Figure 178 SOAM MEP DB Table

Microwave radio - MD ID: 1 (TR_998) MA/MEG ID: 1 (56) MEP ID: 10

Filter: [x]

Back to MEP

MD ID: 1

MD Name: TR_998

MA/MEG ID: 1

MA/MEG short name: 56

MEP ID: 10

RMEP ID ▲	RMEP Operational State	RMEP Last rx CCM MAC Address	RMEP Last CCM OK or Fail Timestamp	RMEP Last rx CCM RDI Indication	RMEP Last rx CCM Port status TLV	RMEP Last rx CCM Interface Status TLV	RMEP Last rx CCM chassis ID format	RMEP Last rx CCM Chassis ID
35	RMEP Failed	FF:FF:FF:FF:FF:FF	1 minute, 17.01 seconds	False	Ps No Port State TLV	No Interface Status TLV	None	

View Refresh

Table 64 lists and describes the parameters displayed in the SOAM MEP DB table. To return to the SOAM MEP page, click **Back to MEP**.

Table 49 SOAM MEP DB Table Parameters

Parameter	Definition
RMEP ID	The remote MEP ID.
RMEP Operational State	The operational state of the remote MEP.
RMEP Last rx CCM MAC Address	The MAC Address of the interface on which the remote MEP is located.
RMEP Last CCM OK or Fail Timestamp	The timestamp marked by the remote MEP indicated the most recent CCM OK or failure it recorded. If none, this field indicates the amount of time since SOAM was activated.
RMEP Last rx CCM RDI Indication	Displays the state of the RDI (Remote Defect Indicator) bit in the most recent CCM received by the remote MEP. If none, displays False .
RMEP Last rx CCM Port Status TLV	The Port Status TLV in the most recent CCM received from the remote MEP. Reserved for future use.
RMEP Last rx CCM Interface Status TLV	Displays the operational status of the interface on which the remote MEP has been defined.
RMEP Last rx CCM Chassis ID Format	Displays the MAC addressformat of the remote unit.chassis (always the MAC address).
RMEP Last rx CCM Chassis ID	Reserved for future use.Displays the MAC address of the remote chassis.


Displaying Last Invalid CCMS

To display the entire frame of the last CCM error message and the last CCM cross-connect error message received by a specific local MEP:

1. Select **Ethernet > Protocols > SOAM > MEP**. The SOAM MEP page opens (Figure 302).

- 2. Select a MEP and click **Last Invalid CCMS**. The MEP Last Invalid CCMS page opens.

Figure 179 MEP Last Invalid CCMS Page



The **Last RX error CCM message** field displays the frame of the last CCM that contains an error message received by the MEP.

The **Last RX Xcon fault message** field displays the frame of the last CCM that contains a cross-connect error message received by the MEP.

Note

A cross-connect error occurs when a CCM is received from a remote MEP that has not been defined locally.

Configuring MIPs with MHF Default

If you configure a MEG with the MHF default option, MIPS are created automatically on all service points of the service to which the MEG is attached. These MIPS cannot be displayed in the Web EMS, but can be displayed via CLI. See [Displaying MEP and Remote MEP Attributes \(CLI\)](#).

Creating MIPS is subject to the following limitations:

- Once you have created a MEG that contains MIPS, i.e., a MEG with the MHF default attribute, you cannot create a MEG with the MHF none attribute on the same or higher level on the same Ethernet Service. However, you can create MEGs with the MHF none attribute on the same service on lower levels then the MEG with the MHF default attribute.
- MEPs cannot be attached to a MEG with the MHF default attribute.
- The Ethernet service and service points must already be defined before creating the MEG with the MHF default attribute in order for MIPS to be created on the service points.


To configure MEGs with MIPS:

- 1 Create a MEG with the MHF none attribute on the intended Ethernet service. See [Configuring MA/MEGs](#).
- 2 Select the MEG and click **Edit**. The SOAM MA/MEG – Edit page opens.
- 3 In the **MIP Creation** field, select **MHF Default**.
- 4 Click **Apply**, then **Close**.

Performing Loopback

To perform loopback on a MEP:

1. In the SOAM MEP page ([Figure 247](#)), select the MEP on which you want to perform the loopback.
2. Click **Loopback**. The SOAM MEP – Loopback page opens.

Figure 180 SOAM MEP Loopback Page


SOAM MEP Loopback

MD ID: 1
MD Name: TR-995
MA/MEG ID: 1
MA/MEG Name: T00TR
MEP ID: 25

Session Status

Loopback session state: SOAM Loopback Inactive
Loopback messages transmitted in session: 0
Loopback messages left to transmit in session: 0
Loopback replies received in session: 0

Global Counters

Loopback messages transmitted: 0
Loopback messages received: 0
Valid in-order loopback replies received: 0
Valid out-of-order loopback replies received: 0
Loopback replies transmitted: 0
Bad MSDU Loopback Replies: 0
Loopback messages recieved with bad sender id: 0
Loopback replies recieved with bad sender id: 0


Loopback Destination

Destination: ☐ MEP ID ☒ MAC Address
Loopback Messages Destination MAC Address: 00:00:00:00:00:00
Loopback Messages Destination MEP ID: 0 (1..8191)

Loopback Configuration

Loopback messages to be transmitted: 1
Loopback Messages Interval (seconds): 0
Loopback Messages Frame Size (Octets): 64
Loopback Messages Priority: 0
Drop Enable: False
Loopback Messages Data Pattern Type: All Zeros

Apply Refresh Close

 Pressing 'Apply' will activate loopback session.

3. In the Loopback Destination area, select from the following options:
 - **MEP ID** – If you select **MEP ID**, you must enter the MEP ID of the MEP on the interface to which you want to perform the loopback in the **Loopback Messages Destination MEP ID** field. If you select **MEP ID**, the loopback will only be activated if CCMs have already been received from the MEP. For this reason, it is recommended to initiate loopback via MAC address.

- **MAC Address** (default) – If you select **MAC Address**, you must enter the MAC address of the interface to which you want to send the loopback in the **Loopback Messages Destination MAC Address**. If you are not sure what the interface's MAC address is, you can get it from the Interface Manager by selecting **Platform > Management > Interface Manager**.
4. In the **Loopback messages to be transmitted** field, select the number of loopback messages to transmit (0 – 1024). If you select 0, loopback will not be performed.
 5. In the **Loopback Messages Interval** field, select the interval (in seconds) between each loopback message (0.1 – 60). You can select in increments of 1/10 second. However, the lowest possible interval is 1 second. If you select a smaller interval, the actual interval will still be 1 second.
 6. In the **Loopback Messages Frame Size** field, select the frame size for the loopback messages (64 – 1516). Note that for tagged frames, the frame size will be slightly larger than the selected frame size.
 7. In the **Loopback Messages Priority** field, select a value (0 – 7) for the priority bit for tagged frames.
 8. In the **Drop Enable** field, choose the value of the DEI field for tagged loopback frames (**True** or **False**). The default value is **False**.
 9. In the **Loopback Messages Data Pattern Type** field, select the type of data pattern to be sent in an OAM PDU Data TLV. Options are **All Zeros** and **All Ones**. The default value is **All Zeros**.
 10. Click **Apply** to begin the loopback. The **Loopback session state** field displays the status of the loopback:
 - **SOAM Loopback Complete** – The loopback has been successfully completed.
 - **SOAM Loopback Stopped** – The loopback has been manually stopped.
 - **SOAM Loopback Failed** – The loopback failed.
 - **SOAM Loopback Active** – The loopback is currently active.
 - **SOAM Loopback Inactive** – No loopback has been initiated.

The remote interface will answer and the loopback session will be completed if either of the following is true:

- A remote MEP has been defined on the destination interface.
- A MIP has been defined on the destination interface. See [Configuring MIPs with MHF Default](#).



Note

To manually stop a loopback, you must use the CLI. Enter the following command in root view:

```
root> ethernet soam loopback stop meg-id <meg-id> mep-id <mep-id>
```

Chapter 11: Web EMS Utilities

This section includes:


- [Restarting the HTTP Server](#)
- [Calculating an ifIndex](#)
- [Displaying, Searching, and Saving a list of MIB Entities](#)

Restarting the HTTP Server

To restart the unit's HTTP server:

- 1 Select **Utilities > Restart HTTP**. The Restart HTTP page opens.

Figure 181 Restart HTTP Page



- 2 Click **Restart**. The system prompts you for confirmation.
- 3 Click **OK**. The HTTP server is restarted, and all HTTP sessions are ended. After a few seconds, the Web EMS prompts you to log in again.

Calculating an ifIndex

The ifIndex calculator enables you to:

- Calculate the ifIndex for any object in the system.
- Determine the object represented by any valid ifIndex.

To use the ifIndex calculator:

- 1 Select **Utilities > ifCalculator**. The ifIndex Calculator page opens.

Figure 182 ifIndex Calculator Page

- If you have an ifIndex and you want to determine which hardware item in the unit it represents, enter the number in the **ifIndex number** field and click **Calculate Index to name**. A description of the object appears in the **Result** field.
- To determine the ifIndex of a hardware item in the unit, such as an interface, card, or slot, select the object type in the **Functional Type** field, select the **Slot** and **Port** (if relevant), and click **Calculate Name to Index**. The object's ifIndex appears in the **Result** field.

Displaying, Searching, and Saving a list of MIB Entities

To display a list of entities in the PTP 850 private MIB:

- 1 Select **Utilities > ifCalculator**. The ifIndex Calculator page opens.

Figure 183 MIB Reference Table Page

#	MIB OID	MIB Name	Type	MIB Type	MIB Access	Description
1	1.2.840.10006.300.43.1.1.1.1	dot3adAggTable	Table		not-accessible	The table that contains the aggregator attributes configuration table
2	1.2.840.10006.300.43.1.1.1.1.1	dot3adAggIndex	Column	INTEGER	read-only	The location of the LAG group
3	1.2.840.10006.300.43.1.1.1.1.2	dot3adAggMACAddress	Column	OCTET STRING	read-only	The Individual MAC address assigned to the Aggregator.
4	1.2.840.10006.300.43.1.1.1.1.3	dot3adAggActorSystemPriority	Column	INTEGER	read-only	The Priority value associated with the Actor's System ID.
5	1.2.840.10006.300.43.1.1.1.1.4	dot3adAggActorSystemID	Column	OCTET STRING	read-only	The MAC address value used as a unique identifier for the System that contains this Aggregator.
6	1.2.840.10006.300.43.1.1.1.1.5	dot3adAggAggregateOrIndividual	Column	INTEGER (1..2)	read-only	Indication whether the Aggregator represents an Aggregate or an Individual link.
7	1.2.840.10006.300.43.1.1.1.1.6	dot3adAggActorAdminKey	Column	INTEGER	read-only	The current administrative value of the Key for the Aggregator.
8	1.2.840.10006.300.43.1.1.1.1.7	dot3adAggActorOpenKey	Column	INTEGER	read-only	The current operational value of the Key for the Aggregator.
9	1.2.840.10006.300.43.1.1.1.1.8	dot3adAggPartnerSystemID	Column	OCTET STRING	read-only	The MAC address value consisting of the unique identifier for the current protocol Partner of this Aggregator.
10	1.2.840.10006.300.43.1.1.1.1.9	dot3adAggPartnerSystemPriority	Column	INTEGER	read-only	The priority value associated with the Partner's System ID.
11	1.2.840.10006.300.43.1.1.1.1.10	dot3adAggPartnerOpenKey	Column	INTEGER	read-only	The current operational value of the Key for the Aggregator's current protocol Partner.
12	1.2.840.10006.300.43.1.1.1.1.11	dot3adAggCollectorMaxDelay	Column	INTEGER	read-only	The maximum delay, in tens of microseconds.
13	1.2.840.10006.300.43.1.2.1	dot3adAggPortTable	Table		not-accessible	The table that contains the LACP port attributes config table
14	1.2.840.10006.300.43.1.2.1.1.1	dot3adAggPortIndex	Column	INTEGER	read-only	The location of the port
15	1.2.840.10006.300.43.1.2.1.1.2	dot3adAggPortActorSystemPriority	Column	INTEGER	read-only	The priority value associated with the Actor's System ID.
16	1.2.840.10006.300.43.1.2.1.1.3	dot3adAggPortActorSystemID	Column	OCTET STRING	read-only	The MAC address value that defines the value of the System ID for the System that contains this Aggregation Port.



Note

Some of the entities listed in the Table may not be relevant to the particular unit you are using. This may occur because of activation key restrictions, minor differences between hardware types, or simply because a certain feature is not used in a particular configuration.

- To search for a text string, enter the string in the Search field and press <Enter>. Items that contain the string are displayed in yellow. Searches are not case-sensitive.
- To save the MIB Reference Table as a .csv file, click **Save to File**.

Chapter 12: Getting Started (CLI)

This section includes:

- [General \(CLI\)](#)
- [Establishing a Connection \(CLI\)](#)
- [Logging On \(CLI\)](#)
- [General CLI Commands](#)
- [Changing Your Password \(CLI\)](#)
- [Mate Management Access \(IP Forwarding\) \(CLI\)](#)

General (CLI)

Before connection over the radio hop is established, it is of high importance that you assign to the PTP 850 unit a dedicated IP address, according to an IP plan for the total network. See [Changing the Management IP Address \(CLI\)](#).

By default, a new PTP 850 unit has the following IP settings:

- IP address: 192.168.1.1
- Subnet mask: 255.255.255.0

**Caution**

If the connection over the link is established with identical IP addresses, an IP address conflict will occur and remote connection to the element on the other side of the link may be lost.

Establishing a Connection (CLI)

Connect the PTP 850 unit to a PC by means of a Twisted Pair cable. The cable is connected to the MGT port on the PTP 850 and to the LAN port on the PC. Refer to the Installation Guide for the type of unit you are connecting for cable connection instructions.

**Note**

The PTP 850 IP address, as well as the password, should be changed before the system is set in operation. See [Changing the Management IP Address \(CLI\)](#) and [Changing Your Password \(CLI\)](#).

PC Setup (CLI)

To obtain contact between the PC and the PTP 850 unit, it is necessary to have an IP address on the PC within the same subnet as the PTP 850 unit. The default PTP 850 IP address is 192.168.1.1. Set the PC address to e.g. 192.168.1.10 and subnet mask to 255.255.255.0. Note the initial settings before changing.

**Note**

The PTP 850 IP address, as well as the password, should be changed before operating the system is set in operation. See [Changing the Management IP Address \(CLI\)](#) and [Changing Your Password \(CLI\)](#).

Logging On (CLI)

Use a telnet connection to manage the PTP 850 via CLI. You can use any standard telnet client, such as PuTTY or ZOC Terminal. Alternatively, you can simply use the `telnet <ip address>` command from the CMD window of your PC or laptop.

The default IP address of the unit is 192.168.1.1. Establish a telnet connection to the unit using the default IP address.

When you have connected to the unit, a login prompt appears. For example:

```
login:
```

At the prompt, enter the default login user name: `admin`

A password prompt appears. Enter the default password: `admin`

The root prompt appears. For example:

```
login: admin
Password:
Wind River Linux glibc_cg1 (cg1) 4.1 CE.1.0
Last login: Mon Apr 13 11:27:02 on console
Wind River Linux glibc_cg1 (cg1) 4.1 CE.1.0
PTP 850E
root>
```

General CLI Commands

To display all command levels available from your current level, press <TAB> twice. For example, if you press <TAB> twice at the root level, the following is displayed:

```
root>
auto-state-propagation  ethernet  exit    multi-carrier-abc
platform               quit      radio    radio-groups
switch-back            switch-to  wait
```

Some of these are complete commands, such as `quit` and `exit`. Others constitute the first word or phrase for a series of commands, such as `ethernet` and `radio`.

Similarly, if you enter the word “platform” and press <TAB> twice, the first word or phrase of every command that follows platform is displayed:

```
root> platform
activation-key    configuration  if-manager    management
security          software      status
sync             unit-info    unit-info-file
root> platform
```

To auto-complete a command, press <TAB> once.

Use the up and down arrow keys to navigate through recent commands.

Use the ? key to display a list of useful commands and their definitions.

```
At the prompt, or at any point in entering a command, enter the word help to display a list of
available commands. If you enter help at the prompt, a list of all commands is displayed. If you enter
help after entering part of a command, a list of commands that start with
the portion of the command you have already entered is displayed.
```

To scroll up and down a list, use the up and down arrow keys.

To end the list and return to the most recent prompt, press the letter `q`.

Changing Your Password (CLI)

It is recommended to change your default Admin password as soon as you have logged into the system.

In addition to the Admin password, there is an additional password protected user account, “root user”, which is configured in the system. The root user password and instructions for changing this password are available from Cambium Networks Customer Support. It is strongly recommended to change this password.

To change your password, enter the following command in root view:

```
root> platform security access-control password edit own-password
```

The system will prompt you to enter your existing password. The system will then prompt you to enter the new password.

If Enforce Password Strength is activated, the password must meet the following criteria:

- Password length must be at least eight characters.
- Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
- A password cannot be repeated within five changes in password.

See [Configuring the Password Security Parameters \(CLI\)](#).

Configuring In-Band Management (CLI)

In Release 10.9, in-band management must be enabled via the Web EMS. See [Configuring In-Band Management \(CLI\)](#).

Changing the Management IP Address (CLI)

Related Topics:

- [Defining the IP Protocol Version for Initiating Communications \(CLI\)](#)
- [Configuring the Remote Unit's IP Address \(CLI\)](#)

You can enter the unit's address in IPv4 format and/or in IPv6 format. The unit will receive communications whether they were sent to its IPv4 address or its IPv6 address.

To set the unit's IP address in IPv4 format, enter the following command in root view to configure the IP address, subnet mask, and default gateway:


```
root> platform management ip set ipv4-address <ipv4-address> subnet
<subnet> gateway <gateway> name <name> description <name>
```

Table 50 IP Address (IPv4) CLI Parameters

Parameter	Input Type	Permitted Values	Description
ipv4-address	Dotted decimal format.	Any valid IPv4 address.	The IP address for the unit.
subnet	Dotted decimal format.	Any valid subnet mask.	The subnet mask for the unit.
gateway	Dotted decimal format.	Any valid IPv4 address.	The default gateway for the unit (optional).
name	Text String.		Enter a name (optional).
description	Text String.		Enter a description (optional).

To set the unit's IP address in IPv6 format, enter the following command in root view to configure the IP address, subnet mask, and default gateway:

```
root> platform management ip set ipv6-address <ipv6-address> prefix-
length <prefix-length> gateway <gateway>
```



Note

It is recommended not to configure addresses of type FE:80::/64 (Link Local addresses) because traps are not sent for these addresses.

Table 51 IP Address (IPv6) CLI Parameters

Parameter	Input Type	Permitted Values	Description
ipv6-address	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IP address for the unit.
prefix-length	Number.	1-128	The prefix-length for the unit.
gateway	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The default gateway for the unit (optional).

Examples

The command below sets the following parameters:

- IPv4 Address - 192.168.1.160
- Subnet Mask – 255.255.0.0
- Default Gateway – 192.168.1.100

```
root> platform management ip set ipv4-address 192.168.1.160 subnet
255.255.0.0 gateway 192.168.1.100
```

The command below sets the following parameters:

- IPv6 Address - FE80:0000:0000:0000:0202:B3FF:FE1E:8329
- Prefix length – 64
- Default Gateway - FE80:0000:0000:0000:0202:B3FF:FE1E:8329

```
root> platform management ip set ipv6-address
FE80:0000:0000:0000:0202:B3FF:FE1E:8329 prefix-length 64 gateway
FE80:0000:0000:0000:0202:B3FF:FE1E:8329
```

Configuring the Activation Key (CLI)

This section includes:

- [Activation Key Overview \(CLI\)](#)
- [Viewing the Activation Key Status Parameters \(CLI\)](#)
- [Entering the Activation Key \(CLI\)](#)
- [Activating a Demo Activation Key \(CLI\)](#)
- [Displaying a List of Activation-Key-Enabled Features \(CLI\)](#)

Activation Key Overview (CLI)

PTP 850 offers a pay-as-you-grow concept in which future capacity growth and additional functionality can be enabled with activation keys. For purposes of the activation keys, each PTP 850 chassis is considered a distinct device, regardless of which cards are included in the chassis. Each device contains a single unified activation key cipher.

New PTP 850 units are delivered with a default activation key that enables you to manage and configure the unit. Additional feature and capacity support requires you to enter an activation key. Contact your vendor to obtain your activation key cipher.

Each required feature and capacity should be purchased with an appropriate activation key. It is not permitted to enable features that are not covered by a valid activation key. In the event that the activation-key-enabled capacity and feature set is exceeded, an Activation Key Violation alarm occurs and the Web EMS displays a yellow background and an activation key violation warning. After a 48-hour grace period, all other alarms are hidden until the capacity and features in use are brought within the activation key's capacity and feature set.

In order to clear the alarm, you must configure the system to comply with the activation key that has been loaded in the system. The system automatically checks the configuration to ensure that it complies with the activation-key-enabled features and capacities. If no violation is detected, the alarm is cleared.

When entering sanction state, the system configuration remains unchanged, even after power cycles. However, the alarms remain hidden until an appropriate activation key is entered or the features and capacities are re-configured to be within the parameters of the current activation key.

A demo activation key is available that enables all features for 60 days. When the demo activation key expires, the most recent valid activation key goes into effect. The 60-day period is only counted when the system is powered up. Ten days before the demo activation key expires, an alarm is raised indicating that the demo activation key is about to expire.

Viewing the Activation Key Status Parameters (CLI)

To display information about the currently installed activation key, enter the following command in root view:

```
root> platform activation-key show all
```


Entering the Activation Key (CLI)

To enter the activation key, enter the following command in root view:

```
root> platform activation-key set key string <key string>
```

If the activation key is not legal (e.g., a typing mistake or an invalid serial number), an Activation Key Loading Failure event is sent to the Event Log. When a legal activation key is entered, an Activation Key Loaded Successfully event is sent to the Event Log.

To set the default activation key, enter the following command in root view:

```
root> platform activation-key set key string "Default Activation Key"
```



Note: Make sure to enter the command using the exact syntax above, including the spaces and quotation marks, or an error will be returned.

Activating a Demo Activation Key (CLI)

To activate the demo activation key, enter the following command in root view:

```
root> platform activation-key set demo admin enable
```

To display the current status of the demo activation key, enter the following command in root view:

```
root> platform activation-key show demo status
```

Displaying a List of Activation-Key-Enabled Features (CLI)

To display a list of features that your current activation key supports, and usage information about these features, enter the following command in root view:

```
root> platform activation-key show usage all
```

To display a list of the radio capacities that your current activation key supports and their usage information, enter the following command in root view:

```
root> platform activation-key show usage radio
```

Setting the Time and Date (Optional) (CLI)

Related Topics:

- [Configuring NTP \(CLI\)](#)

PTP 850E uses the Universal Time Coordinated (UTC) standard for time and date configuration. UTC is a more updated and accurate method of date coordination than the earlier date standard, Greenwich Mean Time (GMT). Every PT 850E unit holds the UTC offset and daylight savings time information for the location of the unit. Each management unit presenting the information uses its own UTC offset to present the information with the correct time.



Note
If the unit is powered down, the time and date are saved for 96 hours (four days). If the unit remains powered down for longer, the time and date may need to be reconfigured.

To set the UTC time, enter the following command in root view:

```
root> platform management time-services utc set date-and-time <date-and-time>
```

To set the local time offset relative to UTC, enter the following command in root view:

```
root> platform management time-services utc set offset hours-offset <hours-offset> minutes-offset <minutes-offset>
```

To display the local time configurations, enter the following command in root view:

```
root> platform management time-services show status
```

Table 52 Local Time Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
date-and-time	Number	dd-mm-yyyy,hh:mm:ss where: dd = date mm = month yyyy= year hh = hour mm = minutes ss = seconds	Sets the UTC time.
hours-offset	Number	-12 – 13	The required hours offset (positive or negative) relative to GMT. This is used to offset the clock relative to GMT, according to the global meridian location.
minutes-offset	Number	0 – 59	The required minutes relative to GMT. This is used to offset the clock relative to GMT, according to the global meridian location.

The following command sets the GMT date and time to January 30, 2014, 3:07 pm and 58 seconds:

```
root> platform management time-services utc set date-and-time 30-01-2014,15:07:58
```

The following command sets the GMT offset to 13 hours and 32 minutes:

```
root> platform management time-services utc set offset hours-offset 13 minutes-offset 32
```

Setting the Daylight Savings Time (CLI)

To set the daylight savings time parameters, enter the following command in root view:

```
root> platform management time-services daylight-savings-time set start-date-month <start-date-month> start-date-day <start-date-day> end-date-month <end-date-month> end-date-day <end-date-day> offset <offset>
```

Table 53: Daylight Savings Time CLI Parameters

Parameter	Input Type	Permitted Values	Description
start-date-month	Number	1 – 12	The month when Daylight Savings Time begins.
start-date-day	Number	1 – 31	The date in the month when Daylight Savings Time begins.
end-date-month	Number	1 – 12	The month when Daylight Savings Time ends.
end-date-day	Number	1 – 31	The date in the month when Daylight Savings Time ends.
offset	Number	0 – 23	The required offset, in hours, for Daylight Savings Time. Only positive offset is supported.

The following command configures daylight savings time as starting on May 30 and ending on October 1, with an offset of 20 hours.

```
root> platform management time-services daylight-savings-time set start-date-month 5 start-date-day 30 end-date-month 10 end-date-day 1 offset 20
```

Enabling the Interfaces (CLI)

By default:

- Ethernet traffic interfaces are disabled and must be manually enabled.
- The Ethernet management interface is enabled.
- Radio interfaces are enabled.



Note

In release 10.6, only Ethernet Slot 1, Port 7 is supported, along with the radio and management interfaces. In release 10.9, Ethernet Slot 1, Ports 3 through 7 are supported.

The QSFP port (Port 4), is displayed as follows.

- In a 4x1/10G configuration the QSFP port can provide four Ethernet interfaces: Eth3, Eth4, Eth 5, and Eth6. In this configuration, a QSFP transceiver is attached to the QSFP port, and an MPO-MPO cable is connected between the transceiver and a splitter on the other side of the link. The splitter splits the traffic between four Ethernet cables connecting the splitter to the customer equipment.

To enable or disable an interface, enter the following command in root view:

```
root> platform if-manager set interface-type <interface-type> slot <slot>
port <port> admin <admin>
```

To display the status of all the interfaces in the unit, enter the following command in root view:

```
root> platform if-manager show interfaces
```

Table 54 Interface Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
interface-type	Variable	ethernet radio	ethernet – an Ethernet traffic interface. radio – a radio interface.
slot	Number	Ethernet: 1 Radio in PTP 850E or PTP 850E: 2	The slot on which the interface is located.
port	Number	GbE 1: 1 GbE 2: 2 GbE 3: 3 Radio Carrier 1: 1 Radio Carrier 2 (PTP 850E only): 2	The specific interface you want to enable or disable.
admin	Variable	up down	Enter up to enable the interface or down to disable the interface.

The following command enables Ethernet port 7:

```
root> platform if-manager set interface-type ethernet slot 1 port 7 admin up
```

The following command enables radio interface:

```
root> platform if-manager set interface-type radio slot 1 port 1 admin up
```

The following command disables the radio interface:

```
root> platform if-manager set interface-type radio slot 1 port 1 admin down
```

The following command disables the management interface:

```
root> platform if-manager set interface-type management slot 1 port 1 admin down
```

Configuring the Radio (MRMC) Script(s) (CLI)

Multi-Rate Multi-Constellation (MRMC) radio scripts define how the radio utilizes its available capacity. Each script is a pre-defined collection of configuration settings that specify the radio's transmit and receive levels, link modulation, channel spacing, and bit rate. Scripts apply uniform transmit and receive rates that remain constant regardless of environmental impact on radio operation.



Note

The list of available scripts reflects activation-key-enabled features. Only scripts within your activation-key-enabled capacity will be displayed.

Displaying Available MRMC Scripts (CLI)

To display all scripts that are available for a specific radio carrier in your unit:

Use the following command to enter radio view:

```
root> radio slot 1 port 1
```

Enter the following command in radio view:

```
radio[1/1]>mrmc script show script-type <script-type> acm-support <acm-support>
```

Note: The list of available scripts reflects activation-key-enabled features. Only scripts within your activation-key-enabled capacity will be displayed.

Table 55: MRMC Script CLI Parameters

Parameter	Input Type	Permitted Values	Description
script-type	Variable	Normal asymmetrical	Determines the type of scripts to be displayed: <ul style="list-style-type: none"> normal – Scripts for symmetrical bandwidth. asymmetrical – Scripts for asymmetrical bandwidth. Note: Asymmetrical scripts are not supported in this release.
acm-support	Boolean	Yes no	Determines whether to display scripts that support Adaptive Coding Modulation (ACM). In ACM mode, a range of profiles determines Tx and Rx rates. This allows the radio to modify its transmit and receive levels in response to environmental conditions.

The following command displays available symmetrical (normal) scripts:

```

radio [1/1]>mrmc script show script-type normal acm-support yes
Script      |Script-Name
ID#         |
-----
<5703>      |mdN_A250250N_5_5703
<5704>      |mdN_A500500N_5_5704
<5706>      |mdN_A10001000N_5_5706
<5710>      |mdN_A20002000N_5_5710
-----
radio [1/1]>

```

Assigning an MRMC Script to a Radio Carrier (CLI)

Once you have a list of valid scripts, you can assign a script to the radio carrier. The command syntax differs depending on whether you are assigning a script with ACM support or a script without ACM support.



Note

When you enter a command to change the script, a prompt appears informing you that changing the script will reset the unit and affect traffic. To continue, enter **yes**. Changing the maximum or minimum profile does not reset the radio interface.

To assign a script with ACM enabled, enter the following command in radio view:

```
radio[1/1]> mrmc set acm-support script-id <script-id> modulation
adaptive max-profile <max-profile> min-profile <min-profile>
```

To assign a script without ACM enabled, enter the following command in radio view:

```
radio[1/1]> mrmc set acm-support script-id <script-id> modulation fixed
profile <profile>
```

To display the current MRMC script configuration, enter the following command in radio view:

```
radio[1/1]> mrmc show script-configuration
```

Table 56: MRMC Script Assignment to Radio Carrier CLI Parameters

Parameter	Input Type	Permitted Values	Description
script-id	Number	See <i>Table 14</i> .	The ID of the script you want to assign to the radio carrier.
modulation	Variable	adaptive fixed	Determines whether ACM is enabled (adaptive) or disabled (fixed).
max-profile	Number	See <i>Table 14</i> .	Adaptive ACM mode only: The maximum profile for the script. For example, if you select a maximum profile of 5, the system will not climb above profile 5, even if channel fading conditions allow it.

Parameter	Input Type	Permitted Values	Description
min-profile	Number	See <i>Table 14</i> .	Adaptive ACM mode only: The minimum profile for the script. For example, if you select a minimum profile of 3, the system will not go below profile 3 regardless of the channel fading conditions. The minimum profile cannot be greater than the maximum profile, but it can be equal to it. If you do not include this parameter in the command, the minimum profile is set at the default value of 2.
profile	Number	See <i>Table 14</i> .	Fixed ACM mode only: The profile in which the system will operate

**Note**

For a list and description of available profiles, see *Radio Profiles*. Note that Profiles 0 and 1 require a special activation key (SL-ACMB). These profiles are used with ACMB, which is an enhancement of ACM that provides further flexibility to mitigate fading at BPSK by reducing the channel spacing to one half or one quarter of the original channel bandwidth when fading conditions make this appropriate.

The following command assigns MRMC script ID 5703, with ACM enabled, a minimum profile of 3, and a maximum profile of 9, to the radio carrier:

```
radio[1/1]>mrmc set acm-support script-id 5703 modulation adaptive max-profile 9 min-profile 3
```

The following command assigns MRMC script ID 5704, with ACM disabled and a profile of 5, to the radio carrier:

```
radio[1/1]>mrmc set acm-support script-id 5704 modulation fixed profile 5
```

The following command assigns MRMC script ID 5710, with ACM enabled, minimum profile of 2, and a maximum profile of 8, to the radio carrier:

```
radio[1/1]>mrmc set acm-support script-id 5710 modulation max-profile 8 min-profile 2
```


Configuring the Radio Parameters (CLI)

In order to establish a radio link, you must:

- Enter radio view.
- Verify that the radio is muted (the **Mute Status** should be **On**).
- Configure the radio frequencies.



Note

Even if you are using the default frequencies, it is mandatory to actually configure the frequencies.

- Configure the TX level.
- Set **Mute Admin** to **Off**.
- Verify that the radio is unmuted (the **Mute Status** should be **Off**).

Entering Radio View (CLI)

To view and configure radio parameters, you must first enter the radio's view level in the CLI.

To enter a radio's view level, enter the following command in root view:

```
root> radio slot <slot> port <port>
```

The following prompt appears:

```
radio[1/1]>
```

Muting and Unmuting a Radio (CLI)

To mute or unmute the radio, enter the following command:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[1/1]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.



Note

In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired.

To display the mute status of a radio, enter the following command in radio view:

```
radio[1/1]>rf mute show status
```

The following command mutes the radio:

```
radio[1/1]>rf mute set admin on
```

The following command unmutes the radio:

```
radio[1/1]>rf mute set admin off
```

The following command configures a timed mute. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command includes an option to set the remote RX frequency in parallel:

```
radio[1/1]>rf set tx-frequency <0-4294967295> local-remote  
<enable|disable>
```

Note: CeraOS 10.6 does not support the ability to set the remote RX frequency.

The following command sets the TX frequency of the radio in an PTP 850E unit to 71000000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]> rf set tx-frequency 71000000 local-remote enable
```

The following command sets the TX frequency of the radio in an PTP 850E unit to 71000000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/1]> rf set rx-frequency 71000000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[1/1]>rf set tx-level <-50-50>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[1/1]>rf show max-tx-level
```

The following command sets the TX level of the radio to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

When Adaptive TX power is enabled, this command determines the maximum TX level, as described in [Enabling ACM with Adaptive Transmit Power \(CLI\)](#).

Enabling ACM with Adaptive Transmit Power (CLI)

When Adaptive TX Power is enabled, the radio adjusts its TX power dynamically based on the current modulation. When the modulation is at a high level, the TX power is adjusted to the level required with the high modulation. If the modulation goes down to a lower level, the TX power increases to compensate for the lower modulation. The TX level configured by the `rf set tx-level` command determines the maximum TX level, but the actual TX level as shown in the Operational TX Level (dBm) field can be expected to be lower when the radio is operating at high modulations requiring less TX power.

To enable Adaptive TX Power, enter the following command in radio view:

```
radio[1/1]>rf adaptive-power admin enable
```

To disable Adaptive TX Power for a radio, enter the following command in radio view:

```
radio[1/1]>rf adaptive-power admin disable
```

To display whether Adaptive TX Power is enabled, enter the following command in radio view:

```
radio[1/1]>rf adaptive-power show status
```

The output of this command is:

```
radio [x/x]>rf adaptive-power show status
RF adaptive power admin status: [enable/disable]
RF adaptive power operational status: [up/down]
```

RF adaptive power operational status: Up means the feature is enabled and fully functional for that radio link.

**Note**

Adaptive TX Power only operates when the MRMC script is configured to Adaptive mode. If the script is configured to Fixed mode (or Adaptive mode with the Minimum and Maximum Profile set to the same value), you can set **adaptive-power** to **enable**, but the **adaptive power operational status** will be **down**.

Configuring the RSL Threshold Alarm (CLI)

You can enable an alarm to be triggered in the event that the RSL falls beneath a defined threshold. This alarm is alarm ID 1610, Radio Receive Signal Level is below the configured threshold. By default, the alarm is disabled.

To enable the RSL threshold alarm, enter the following command in radio view:

```
radio[x/x]> rf rsl-degradation set admin enable
```

To disable the RSL threshold alarm, enter the following command in radio view:

```
radio[x/x]> rf rsl-degradation set admin disable
```

To set the threshold of the RSL threshold alarm, enter the following command in radio view:

```
radio[x/x]> rf rsl-degradation set threshold <-99-0>
```

The default threshold is -68 dBm.

To display the current alarm configuration, enter the following command in radio view:

```
radio[x/x]> rf rsl-degradation show status
```

The following commands enable the RSL threshold alarm for radio carrier 1 and set the threshold to -55 dBm.

```
root> radio slot 2 port 1
radio [2/1]>rf rsl-degradation set admin enable
radio [2/1]>rf rsl-degradation set threshold -55
radio [2/1]>rf rsl-degradation show status

RSL degradation alarm admin: enable
RSL degradation threshold: -55
radio [2/1]>
```

The alarm is cleared when the RSL goes above the configured threshold. The alarm is masked if the radio interface is disabled, the radio does not exist, or a communication-failure alarm (Alarm ID #1703) is raised.

Creating Service(s) for Traffic (CLI)

In order to pass traffic through the PTP 850, you must configure Ethernet traffic services. For configuration instructions, see [Configuring Ethernet Services \(CLI\)](#).

Chapter 13: Unit Management (CLI)

This section includes:

- [Defining the IP Protocol Version for Initiating Communications \(CLI\)](#)
- [Configuring the Remote Unit's IP Address \(CLI\)](#)
- [Configuring SNMP \(CLI\)](#)
- [Configuring the Internal Ports for FTP or SFTP \(CLI\)](#)
- [Upgrading the Software \(CLI\)](#)
- [Backing Up and Restoring Configurations \(CLI\)](#)
- [Setting the Unit to the Factory Default Configuration \(CLI\)](#)
- [Performing a Hard \(Cold\) Reset \(CLI\)](#)
- [Configuring Unit Parameters \(CLI\)](#)
- [Configuring NTP \(CLI\)](#)
- [Displaying Unit Inventory \(CLI\)](#)

Related topics:

- [Setting the Time and Date \(Optional\) \(CLI\)](#)
- [Uploading Unit Info \(CLI\)](#)
- [Changing the Management IP Address \(CLI\)](#)

Defining the IP Protocol Version for Initiating Communications (CLI)

You can specify which IP protocol the unit will use when initiating communications, such as downloading software, sending traps, pinging, or exporting configurations. The options are IPv4 or IPv6.

To define which IP protocol the unit will use when initiating communications, enter the following command in root view:

```
root> platform management ip set ip-address-family <ipv4|ipv6>
```

To show the IP protocol version the unit will use when initiating communications, enter the following command in root view:

```
root> platform management ip show ip-address-family
```

Configuring the Remote Unit's IP Address (CLI)

You can configure the remote unit's IP address, subnet mask and default gateway in IPv4 format and/or in IPv6 format. The remote unit will receive communications whether they were sent to its IPv4 address or its IPv6 address.



Note

Release 10.6 does not support the ability to configure the remote IP address.

Configuring the Remote Radio's IP Address in IPv4 format (CLI)

To set the remote radio's IP Address, enter the following command in radio view:

```
radio[x/x]>remote-unit set ip-address <ipv4-address>
```

To display the remote radio's IP Address, enter the following command in radio view:

```
radio[x/x]>remote-unit show ip-address
```

To set the remote radio's subnet mask, enter the following command in radio view:

```
radio[x/x]>remote-unit set subnet-mask IP <subnet-mask>
```

To display the remote radio's subnet mask, enter the following command in radio view:

```
radio[x/x]>remote-unit show subnet-mask
```

To set the remote radio's default gateway, enter the following command in radio view:

```
radio[x/x]>remote-unit set default-gateway IP <ipv4-address>
```

To display the remote radio's default gateway, enter the following command in radio view:

```
radio[x/x]>remote-unit show default-gateway
```

Table 57 Remote Unit IP Address (IPv4) CLI Parameters

Parameter	Input Type	Permitted Values	Description
ipv4-address	Dotted decimal format.	Any valid IPv4 address.	Sets the default gateway or IP address of the remote radio.
subnet-mask	Dotted decimal format.	Any valid subnet mask.	Sets the subnet mask of the remote radio.

The following command sets the default gateway of the remote radio as 192.168.1.20:

```
radio[1/1]>remote-unit set default-gateway IP 192.168.1.20
```

The following commands set the IP address of the remote radio as 192.168.1.1, with a subnet mask of 255.255.255.255.

```
radio[1/1]>remote-unit set ip-address 192.168.1.1
```

```
radio[1/1]>remote-unit set subnet-mask IP 255.255.255.255
```


Configuring the Remote Radio's IP Address in IPv6 format (CLI)

To set the remote radio's IP Address, enter the following command in radio view:

```
radio[x/x]>remote-unit set ip-address-ipv6 <ipv6-address>
```

To display the remote radio's IP Address, enter the following command in radio view:

```
radio[x/x]>remote-unit show ip-address-ipv6
```

To set the remote radio's prefix length , enter the following command in radio view:

```
radio[x/x]>remote-unit set prefix-length <prefix-length >
```

To display the remote radio's prefix-length, enter the following command in radio view:

```
radio[x/x]>remote-unit show prefix-length
```

To set the remote radio's default gateway, enter the following command in radio view:

```
radio[x/x]>remote-unit set default-gateway-ipv6 IPv6 <ipv6-address>
```

To display the remote radio's default gateway, enter the following command in radio view:

```
radio[x/x]>remote-unit show default-gateway-ipv6
```

Table 58 Remote Unit IP Address (IPv6) CLI Parameters

Parameter	Input Type	Permitted Values	Description
ipv6-address	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	Sets the default gateway or IP address of the remote radio.
prefix-length	Number	1-128	Sets the prefix length of the remote radio. It should be different for each RADIUS client.

The following command sets the default gateway of the remote radio as FE80:0000:0000:0000:0202:B3FF:FE1E:8329:

```
radio[1/1]>remote-unit set default-gateway-ipv6 IPv6  
FE80:0000:0000:0000:0202:B3FF:FE1E:8329
```

The following commands set the IP address of the remote radio as FE80:0000:0000:0000:0202:B3FF:FE1E:8329, with a prefix length of 64:

```
radio[1/1]>remote-unit set ip-address-ipv6  
FE80:0000:0000:0000:0202:B3FF:FE1E:8329  
  
radio[1/1]>remote-unit set prefix-length 64
```

Configuring SNMP (CLI)

PTP 850 supports SNMP v1, V2c, and v3. You can set community strings for access to PTP 850 units.

PTP 850 supports the following MIBs:

- RFC-1213 (MIB II).
- RMON MIB.
- Proprietary MIB.

Access to the unit is provided by making use of the community and context fields in SNMPv1 and SNMPv2c/SNMPv3, respectively.

This section includes:

- [Configuring Basic SNMP Settings \(CLI\)](#)
- [Configuring SNMPv3 \(CLI\)](#)
- [Displaying the SNMP Settings \(CLI\)](#)
- [Configuring Trap Managers \(CLI\)](#)

Configuring Basic SNMP Settings (CLI)

To enable SNMP, enter the following command in root view:

```
root> platform security protocols-control snmp admin set <admin>
```

To specify the SNMP version, enter the following command in root view:

```
root> platform security protocols-control snmp version set <version>
```

To specify the SNMP read and write communities, enter the following command in root view:

```
root> platform security protocols-control snmpv1v2 set read-community  
<read-community> write-community <write-community>
```

Table 59 Basic SNMP CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	enable disable	Select enable to enable SNMP monitoring, or disable to disable SNMP monitoring.
version	Variable	v1 v2 v3	Specifies the SNMP version.
read-community	Text String	Any valid SNMP read community.	The community string for the SNMP read community.
write-community	Text String	Any valid SNMP write community.	The community string for the SNMP write community.

The following commands enable SNMP v2 on the unit, and set the read community to “public” and the write community to “private”:

```
root> platform security protocols-control snmp admin set enable
root> platform security protocols-control snmp version set v2
root> platform security protocols-control snmpv1v2 set read-community
public write-community private
```

Configuring SNMPv3 (CLI)

The following commands are relevant for SNMPv3.

To block SNMPv1 and SNMPv2 access so that only SNMPv3 access will be enabled, enter the following command in root view:

```
root> platform security protocols-control snmp v1v2-block set <set-block>
```

To add an SNMPv3 user, enter the following command in root view:

```
root> platform security protocols-control snmp v3-authentication add v3-
user-name <v3-user-name> v3-user-password <v3-user-password> v3-security-
mode <v3-security-mode> v3-encryption-mode <v3-encryption-mode> v3-auth-
algorithm <v3-auth-algorithm> v3-access-mode <v3-access-mode>
```

To remove an SNMP v3 user, enter the following command in root view:

```
root> platform security protocols-control snmp v3-authentication remove
v3-user-name <v3-user-name>
```

To display all SNMP v3 users and their authentication parameters, enter the following command in root view:

```
root> platform security protocols-control snmp v3-authentication show
```

Table 60 SNMPv3 CLI Parameters

Parameter	Input Type	Permitted Values	Description
set-block	Variable	yes no	yes – SNMPv1 and SNMPv2 access is blocked. no – SNMPv1 and SNMPv2 access is not blocked.
v3-user-name	Text String		A SNMPv3 user name.
v3-user-password	Text String	Must be at least eight characters.	An SNMPv3 user password.
v3-security-mode	Variable	authNoPriv authPriv noAuthNoPriv	Defines the security mode to be used for this user.

Parameter	Input Type	Permitted Values	Description
v3-encryption-mode	Variable	None DES AES	Defines the encryption (privacy) protocol to be used for this user.
v3-auth-algorithm	Variable	None SHA MD5	Defines the authentication algorithm to be used for this user.
v3-access-mode	Variable	readWrite readOnly	Defines the access permission level for this user.

The following commands enable SNMP v2 on the unit, and set the read community to “public” and the write community to “private”:

```
root> platform security protocols-control snmp admin set enable
root> platform security protocols-control snmp version set v2
root> platform security protocols-control snmpv1v2 set read-community
public write-community private
```

The following commands enable SNMP v3 on the unit, block SNMP v1 and SNMP v2 access, and define an SNMPv3 user with User Name=Geno, Password=abcdefgh, security mode authPriv, encryption mode DES, authentication algorithm SHA, and read-write access:

```
root> platform security protocols-control snmp admin set enable
root> platform security protocols-control snmp version set v3
root> platform security protocols-control snmp v1v2-block set yes
root> platform security protocols-control snmp v3-authentication add v3-
user-name geno v3-user-password abcdefgh v3-security-mode authPriv v3-
encryption-mode DES v3-auth-algorithm SHA v3-access-mode readwrite
```

Displaying the SNMP Settings (CLI)

To display the general SNMP parameters, enter the following command in root view:

```
root> platform security protocols-control snmp show-all
```

To display all SNMP v3 users and their authentication parameters, enter the following command in root view:

```
root> platform security protocols-control snmp v3-authentication show
```

To display the current MIB version used in the system, enter the following command in root view:

```
root> platform security protocols-control snmp show-mib-version
```

To display details about the current MIB version used in the system, enter the following command in root view:

```
root> platform security protocols-control snmp show-mib-version-table
```

To display the SNMP read and write communities, enter the following command in root view:

```
root> platform security protocols-control snmpv1v2 show
```

Configuring Trap Managers (CLI)

To display the current SNMP trap manager settings, enter the following command in root view:

```
root> platform security protocols-control snmp trap-manager show
```

To modify the settings of an SNMP trap manger, enter the following command in root view:

```
root> platform security protocols-control snmp trap-manager set manager-id <manager-id> manager-admin <manager-admin> manager-ipv4 <manager-ipv4> manager-ipv6<manager-ipv6> manager-port <manager-port> manager-community <manager-community> manager-v3-user <manager-v3-user> manager-description <manager-description>
```

To enable an SNMP trap manger without modifying its parameters, enter the following command in root view:

```
root> platform security protocols-control snmp trap-manager admin manager-id <manager-id> manager-admin <manager-admin>
```

To specify the number of minutes between heartbeat traps, enter the following command in root view:

```
root> platform security protocols-control snmp trap-manager heartbeat manager-id <manager-id> manager-heartbeat <manager-heartbeat>
```

Table 61 Trap Managers CLI Parameters

Parameter	Input Type	Permitted Values	Description
manager-id	Number.	1 – 4	Enter the Manager ID of the trap manager you want to modify.
manager-admin	Variable.	enable disable	Enter enable or disable to enable or disable the trap manager.
manager-ipv4	Dotted decimal format.	Any valid IPv4 address.	If the IP protocol selected in platform management ip set ip-address-family is IPv4, enter the destination IPv4 address. Traps will be sent to this IP address.
manager-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	If the IP protocol selected in platform management ip set ip-address-family is IPv6, enter the destination IPv6 address. Traps will be sent to this IP address.
manager-port	Number.	70 – 65535	Enter the number of the port through which traps will be sent.
manager-community	Text String.	Any valid SNMP read community.	Enter the community string for the SNMP read community.

Parameter	Input Type	Permitted Values	Description
manager-v3-user	Text String.	The name of a V3 user defined in the system.	<p>If the SNMP Trap version selected in platform security protocols-control snmp version set is V3, enter the name of a V3 user defined in the system.</p> <p>Note: Make sure that an identical V3 user is also defined on the manager's side</p>
manager-description	Text String.		Enter a description of the trap manager (optional).
manager-heartbeat	Number.	0 – 1440	<p>Specifies the number of minutes between heartbeat traps. If you enter 0, no heartbeat traps will be sent.</p> <p>Note: To reduce unnecessary traffic, heartbeat traps are only sent if no other trap was sent during the Heartbeat Period.</p>

The following commands enable trap manager 2, and assign it IP address 192.168.1.250, port 164, and community “private”, with a heartbeat of 12 minutes.

```
root> platform security protocols-control snmp trap-manager set manager-
id 2 manager-admin enable manager-ip 192.168.1.250 manager-port 164
manager-community private manager-description text
root> platform security protocols-control snmp trap-manager heartbeat
manager-id 2 manager-heartbeat 12
```

Configuring the Internal Ports for FTP or SFTP (CLI)

By default, the following PTP 850 ports are used for FTP and SFTP when the PTP 850 unit is acting as an FTP or SFTP client (e.g., software downloads, configuration file backup and restore operations):

- FTP – 21
- SFTP – 22

To change the port for either protocol, enter the following command in root view:

```
root> platform management file-transfer port-config protocol <ftp|sftp>
port-number <0-65535>
```

To display the ports that are currently configured for FTP and SFTP, enter the following command in root view:

```
root> platform management file-transfer port-show
```

These ports are configured globally, rather than per specific operation.

The following sequence of commands displays the current (default) FTP and SFTP port settings, changes the FTP port to 125 and the SFTP port to 126, and shows the new FTP and SFTP port settings.

```
root>platform management file-transfer port-show
Port config table:
=====
File transfer   File transfer port
protocol        number
=====
ftp             21
sftp            22

root> platform management file-transfer port-config protocol ftp port-
number 125

root> platform management file-transfer port-config protocol sftp port-
number 126

root>platform management file-transfer port-show
Port config table:
=====
File transfer   File transfer port
protocol        number
=====
ftp             125
sftp            126

root>
```

Upgrading the Software (CLI)

PTP 850 software and firmware releases are provided in a single bundle that includes software and firmware for all components in the system. Software is first downloaded to the system, then installed. After installation, a reset is automatically performed on all components whose software was upgraded.

This section includes:

- [Software Upgrade Overview \(CLI\)](#)
- [Viewing Current Software Versions \(CLI\)](#)
- [Configuring a Software Download \(CLI\)](#)
- [Downloading a Software Package \(CLI\)](#)
- [Installing and Upgrading Software \(CLI\)](#)

Software Upgrade Overview (CLI)

The PTP 850 software installation process includes the following steps:

1. **Download** – The files required for the installation or upgrade are downloaded from a remote server.
2. **Installation** – The downloaded software and firmware files are installed in all modules and components of the PTP 850 that are currently running an older version.
3. **Reset** – The PTP 850 is restarted in order to boot the new software and firmware versions.

Software and firmware releases are provided in a single bundle that includes software and firmware for all components in the system. When you download a software bundle, the system verifies the validity of the bundle. The system also compares the files in the bundle to the files currently installed in the PTP 850 and its components, so that only files that need to be updated are actually downloaded. A message is displayed for each file that is actually downloaded.

**Note**

When downloading an older version, all files in the bundle may be downloaded, including files that are already installed.

Software bundles can be downloaded via HTTP, HTTPS, FTP or SFTP. After the software download is complete, you can initiate the installation.

**Note**

Before performing a software upgrade, it is important to verify that the system date and time are correct. See [Setting the Time and Date \(Optional\) \(CLI\)](#).

When upgrading a node with unit protection, upgrade the standby unit first, then the active unit.

Viewing Current Software Versions (CLI)

To display all current software versions, enter the following command in root view:

```
root> platform software show versions
```


Configuring a Software Download (CLI)

You can download software using HTTP, HTTPS, FTP, or SFTP.

When downloading software via HTTP or HTTPS, the PTP 850 functions as the server, and you can download the software directly to the PTP 850 unit.



Note
HTTP/HTTPS software download is only supported using the Web EMS. For instructions, see [Downloading and Installing Software](#).

When downloading software, the IDU functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the software upgrade. For details, see [Installing and Configuring an FTP or SFTP Server](#).

To set the file transfer protocol you want to use (FTP or SFTP), enter the following command:

```
root> platform software download version protocol <ftp|sftp>
```

If the IP protocol selected in [platform management ip set ip-address-family](#) is IPv4, enter the following command:

```
root> platform software download channel server set server-ip <server-ipv4> directory <directory> username <username> password <password>
```

If the IP protocol selected in [platform management ip set ip-address-family](#) is IPv6, enter the following command:

```
root> platform software download channel server-ipv6 set server-ip <server-ipv6> directory <directory> username <username> password <password>
```

To display the software download channel configuration, enter one of the following commands:

```
root> platform software download channel server show
root> platform software download channel server-ipv6 show
```

Table 62 Software Download CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 address.	The IPv4 address of the PC or laptop you are using as the FTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the FTP server.

Parameter	Input Type	Permitted Values	Description
directory	Text String.		The directory path from which you are downloading the files. Enter the path relative to the FTP user's home directory, not the absolute path. To leave the path blank, enter //. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "//".
server-username	Text String.		The user name you configured in the FTP server.
server-password	Text String.		The password you configured in the FTP server. If you did not configure a password for your FTP user, simply omit this parameter.

The following command configures a download from IP address 192.168.1.242, in the directory “current”, with user name “anonymous” and password “12345.”

```
root> platform software download channel server set server-
ip 192.168.1.242 directory \current username anonymous password 12345
```

Downloading a Software Package (CLI)

To initiate a software download, enter the following command in root view:

```
root> platform software download version protocol ftp
```

The following prompt appears:

```
You are about to perform a software management operation. This may cause
a system reset.
Are you sure? (yes/no)
```

Enter **Yes** at the prompt. When the prompt appears again, enter the following command to check the download status:

```
root> platform software download status show
```

Once the following message appears, proceed with the installation:

```
DOWNLOAD VERSION status: download success, process percentage: 100
```

Installing and Upgrading Software (CLI)

To install or upgrade the software, enter the following command in root view after downloading the software bundle:

```
root> platform software install version
```

If you wish to delay the start of installation, enter instead the following command. The time you enter in HH:MM format is the amount of time to delay until the start of the installation process:

```
root> platform software install version timer-countdown <hh:mm>
```

The following prompt appears:

```
Software version to be installed:  
Are you sure? (yes/no)
```

To display the status of a software installation or upgrade, enter the following command:

```
root> platform software install status show
```

Important Notes:

- DO NOT reboot the unit during software installation process. As soon as the process is successfully completed, the unit will reboot itself.
- Sometimes the installation process can take up to 30 minutes.
- Only in the event that software installation was not successfully finished and more than 30 minutes have passed can the unit be rebooted.

If you configured delayed installation, you can do any of the following:

- Abort the current delayed installation. To do so, enter the following command:

```
root> platform software install abort-timer
```

- Show the time left until the installation process begins. To do so, enter the following command:

```
root> platform software install time-to-install
```

- Show the original timer as configured for a delayed installation. To do so, enter the following command:

```
root> platform software install show-time
```

Backing Up and Restoring Configurations (CLI)

You can import and export PTP 850 configuration files. This enables you to copy the system configuration to multiple PTP 850 units. You can also backup and save configuration files.

Configuration files can only be copied between units of the same type, i.e., PTP 850E to PTP 850E to PTP 850E.

Note that you can also write CLI scripts that will automatically execute a series of commands when the configuration file is restored. For information, refer to [Editing CLI Scripts \(CLI\)](#).

This section includes:

- [Configuration Management Overview \(CLI\)](#)
- [Setting the Configuration Management Parameters \(CLI\)](#)
- [Backing up and Exporting a Configuration File \(CLI\)](#)
- [Importing and Restoring a Configuration File \(CLI\)](#)
- [Editing CLI Scripts \(CLI\)](#)

Configuration Management Overview (CLI)

System configuration files consist of a zip file that contains three components:

- A binary configuration file used by the system to restore the configuration.
- A text file which enables users to examine the system configuration in a readable format. The file includes the value of all system parameters at the time of creation of the backup file.
- An additional text file which enables you to write CLI scripts in order to make desired changes in the backed-up configuration. This file is executed by the system after restoring the configuration.

The system provides three restore points to manage different configuration files. Each restore point contains a single configuration file. Files can be added to the restore points by creating backups of the current system state or by importing them from an external server. For example, you may want to use one restore point to keep a last good configuration, another to import changes from an external server, and the third to store the current configuration.

You can apply a configuration file to the system from any of the restore points.

You must configure from 1 to 3 restore points:

- When you import a configuration file, the file is saved to the selected restore point, and overwrites whichever file was previously held in that restore point.
- When you export a configuration file, the file is exported from the selected restore point.
- When you backup the current configuration, the backup configuration file is saved to the selected restore point, and overwrites whichever file was previously held in that restore point.
- When you restore a configuration, the configuration file in the selected restore point is the file that is restored.

Setting the Configuration Management Parameters (CLI)

When importing and exporting configuration files, the PTP 850 functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the import or export. For details, see [Installing and Configuring an FTP or SFTP Server](#).



Note

Before importing or exporting a configuration file, you must verify that the system date and time are correct. See [Setting the Time and Date \(Optional\) \(CLI\)](#).

To set the FTP or SFTP parameters for configuration file import and export, enter one of the following commands in root view:

- If the IP protocol selected in [platform management ip set ip-address-family](#) is IPv4, enter the following command:

```
root> platform configuration channel server set ip-address <server-ipv4>
directory <directory> filename <filename> username <username> password
<password>
```

- If the IP protocol selected in [platform management ip set ip-address-family](#) is IPv6, enter the following command:

```
root> platform configuration channel server-ipv6 set ip-address <server-
ipv6> directory <directory> filename <filename> username <username>
password <password>
```

To set the file transfer protocol you want to use (FTP or SFTP), enter the following command:

```
root> platform configuration channel set protocol <ftp|sftp>
```

To display the FTP channel parameters for importing and exporting configuration files, enter one of the following commands in root view:

```
root> platform configuration channel server show
root> platform configuration channel server-ipv6 show
```

Table 63 Configuration Management CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 address.	The IPv4 address of the PC or laptop you are using as the FTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the FTP server.

Parameter	Input Type	Permitted Values	Description
directory	Text String.		The location of the file you are downloading or uploading. If the location is the root shared folder, it should be left empty. If the location is a sub-folder under the root shared folder, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/"
filename	Text String.		The name of the file you are importing, or the name you want to give the file you are exporting. Note: You must add the suffix .zip to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix .zip manually.
username	Text String.		The user name you configured in the FTP server.
password	Text String.		The password you configured in the FTP server. If you did not configure a password for your FTP user, simply omit this parameter.

The following command configures the FTP channel for configuration file import and export to IP address 192.168.1.99, in the directory "current", with file name "version_8_backup.zip", user name "anonymous", and password "12345."

```
root> platform configuration channel server set server-ip 192.168.1.99
directory \current filename version_8_backup.zip username anonymous
password 12345
```

Backing up and Exporting a Configuration File (CLI)

To save the current configuration as a backup file to one of the restore points, enter the following command in root view:

```
root> platform configuration configuration-file add <restore-point>
```

To export a configuration from a restore point to the external server location, enter the following command in root view:

```
root> platform configuration configuration-file export <restore-point>
```

Table 64 Configuration Backup and Restore CLI Parameters

Parameter	Input Type	Permitted Values	Description
restore-point	Variable	restore-point-1 restore-point-2 restore-point-3	Identifies the restore point to or from which to perform the backup operation.

The following commands save the current configuration as a configuration at Restore Point 1, and export the file to the external server location:

```
root> platform configuration configuration-file add restore-point-1
root> platform configuration configuration-file export restore-point-1
```

Importing and Restoring a Configuration File (CLI)

You can import a configuration file from an external PC or laptop to one of the restore points. Once you have imported the file, you can restore the configuration. Restoring a saved configuration does not change the unit's FIPS mode.



Note

In order to import a configuration file, you must configure the FTP channel parameters and restore points, as described in [Setting the Configuration Management Parameters](#) and [Backing up and Exporting a Configuration File](#).

To import a configuration file, enter the following command in root view:

```
root> platform configuration configuration-file import <restore-point>
```

To restore a configuration from a restore point to become the active configuration file, enter the following command in root view:

```
root> platform configuration configuration-file restore <restore-point>
```

Table 65 Configuration Import and Restore CLI Parameters

Parameter	Input Type	Permitted Values	Description
restore-point	Variable	restore-point-1 restore-point-2 restore-point-3	Identifies the restore point to or from which to perform the backup operation.

The following commands import a configuration file from an external PC or laptop to Restore Point 2 on the PTP 850, and restore the file to be the system configuration file for the PTP 850:

```
root> platform configuration configuration-file import restore-point-2
root> platform configuration configuration-file restore restore-point-2
```

Editing CLI Scripts (CLI)

The configuration file package includes a text file that enables you to write CLI scripts in a backed-up configuration that are executed after restoring the configuration.

To edit a CLI script:

1. Back up the current configuration to one of the restore points. See [Backing up and Exporting a Configuration File \(CLI\)](#).

2. Export the configuration from the restore point to a PC or laptop. See [Backing up and Exporting a Configuration File \(CLI\)](#).
3. On the PC or laptop, unzip the file *Configuration_files.zip*.
4. Edit the *cli_script.txt* file using clish commands, one per line.
5. Save and close the *cli_script.txt* file, and add it back into the *Configuration_files.zip* file.
6. Import the updated *Configuration_files.zip* file back into the unit. See [Importing and Restoring a Configuration File \(CLI\)](#).
7. Restore the imported configuration file. See [Importing and Restoring a Configuration File \(CLI\)](#). The unit is automatically reset. During initialization, the CLI script is executed, line by line.

**Note**

If any specific command in the CLI script requires reset, the unit is reset when that command is executed. During initialization following the reset, execution of the CLI script continues from the following command.

Setting the Unit to the Factory Default Configuration (CLI)

To restore the unit to its factory default configuration, while retaining the unit's IP address settings and logs, enter the following commands in root view:

```
root> platform management set-to-default
```

The following prompt appears:

```
WARNING: All database and configuration will be lost, unit will be  
restart.  
Are you sure? (yes/no):yes
```

At the prompt, type **yes**.

**Note**

This does not change the unit's IP address or FIPS configuration.

Performing a Hard (Cold) Reset (CLI)

To initiate a hard (cold) reset on the unit, enter the following command in root view:

```
root> platform management chassis reset
```

The following prompt appears:

```
You are about to reset the shelf  
Are you sure? :(yes/no):
```

Enter **yes**. The unit is reset.

Resetting the Remote Unit (CLI)

To initiate a hard (cold) reset on the remote unit, go to radio view and enter the following command:

```
radio [1/1]>remote-unit reset unit
```

The following prompt appears:

```
Are you sure you want to reset the remote unit  
Are you sure? (yes/no):
```

Enter **yes**. The unit is reset.

Configuring Unit Parameters (CLI)

You can view and configure system information:

To configure a name for the unit, enter the following command in root view:

```
root> platform management system-name set name <name>
```

To define a location for the unit, enter the following command in root view:

```
root> platform management system-location set name <name>
```

To define a contact person for questions pertaining to the unit, enter the following command in root view:

```
root> platform management system-contact set name <name>
```

To define the unit's latitude coordinates, enter the following command in root view:

```
root> platform management system-latitude set <latitude>
```

To define the unit's longitude coordinates, enter the following command in root view:

```
root> platform management system-longitude set <longitude>
```

To define the type of measurement unit you want the system to use, enter the following command in root view:

```
root> platform management set unit_measure_format <unit_measure_format>
```

To display the type of measurement unit used by the system, enter the following command in root view:

```
root> platform management show unit_measure_format
```

Table 66 Unit Parameters CLI Parameters

Parameter	Input Type	Permitted Values	Description
name	Text	Up to 64 characters.	Defines the name of the unit.
latitude	Text	Up to 256 characters.	Defines the latitude coordinates of the unit.
longitude	Text	Up to 256 characters.	Defines the longitude coordinates of the unit.
unit_measure _format	Variable	metric imperial	Defines the measurement units of the unit.

The following commands configure a name, location, contact person, latitude coordinates, longitude coordinates, and units of measurements for the PTP 850:

```
root> platform management system-name set name "My-System-Name"
root> platform management system-location set name "My-System-Location"
root> platform management system-contact set name "John Doe"
root> platform management system-latitude set 40
root> platform management system-longitude set 73
root> platform management set unit_measure_format metric
```

Configuring NTP (CLI)

PTP 850 supports Network Time Protocol (NTP). NTP distributes Coordinated Universal Time (UTC) throughout the system, using a jitter buffer to neutralize the effects of variable latency.

To configure NTP, enter the following command in root view:

```
root> platform management ntp set admin <admin> ntp-version <ntp-version>
ntp-server-ip-address-1 <ntp-server-ip-address>
```

To display the current NTP configuration, enter the following command in root view:

```
root> platform management ntp show status
```

Table 67 NTP CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable.	enable disable	Enter enable or disable to enable or disable the NTP server.
ntp-version	Variable.	v3 v4	Enter the NTP version you want to use. NTPv4 provides interoperability with NTP v3 and with SNTP.
ntp-server-ip-address	Dotted decimal format.	Any valid IP address.	Enter the IP address of the NTP server.

The following command enables NTP, using NTP v4, and sets the IP address of the NTP server as 62.90.139.210.

```
root> platform management ntp set admin enable ntp-version ntpv4 ntp-
server-ip-address-1
```

Displaying Unit Inventory (CLI)

To view inventory information, such as the part number and serial number of the unit hardware, enter the following command in root view:

```
root> platform management inventory show-info
```

For example:

```
root> platform management inventory show info

System information:
card-name : PTP 850
Subtype : 350
part number : 22-0001-0|
serial number : F493606212
```

```
company name : Cambium Networks  
product name : AODU DC, All-outdoor, dual radio carriers in one product  
product description : AODU DC, All-outdoor, dual radio carriers in one  
product  
root>
```

Chapter 14: Radio Configuration (CLI)

This section includes:

- [Viewing and Configuring the Remote Radio Parameters \(CLI\)](#)
- [Configuring and Viewing Radio PMs and Statistics \(CLI\)](#)

Related topics:

- [Entering Radio View \(CLI\)](#)
- [Muting and Unmuting a Radio \(CLI\)](#)
- [Configuring the Transmit \(TX\) Level \(CLI\)](#)
- [Configuring the Transmit \(TX\) Frequency \(CLI\)](#)
- [Configuring the Radio \(MRMC\) Script\(s\) \(CLI\)](#)



Note

For convenience, this User Guide generally shows the radio prompt as `radio[1/1]>`.

Viewing and Configuring the Remote Radio Parameters (CLI)

This section includes:

- [Displaying Communication Status with the Remote Radio \(CLI\)](#)
- [Displaying the Remote Radio's Link ID \(CLI\)](#)
- [Muting and Unmuting the Remote Radio \(CLI\)](#)
- [Displaying the Remote Radio's RX Level \(CLI\)](#)
- [Configuring the Remote Radio's TX Level \(CLI\)](#)
- [Configuring Remote ATPC \(CLI\)](#)

Related topics:

- [Configuring the Remote Unit's IP Address \(CLI\)](#)

Displaying Communication Status with the Remote Radio (CLI)

To display the communication status with the remote radio, enter the following command:

```
radio[x/x]>remote-unit communication status show
```

Displaying Remote Radio's Location (CLI)

To display the remote radio's slot ID (location in the chassis), enter the following command in radio view. The slot ID of the remote radio will generally be 1, unless there is no communication with the remote unit. In that case, it will be -1.

```
radio[1/1]>remote-unit show slot-id
```

Muting and Unmuting the Remote Radio (CLI)

To mute or unmute the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit mute set admin <admin>
```

To display the mute status of the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit mute show status
```

Table 68 Remote Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the remote unit.

The following command mutes the remote radio:

```
radio[2/1]>remote-unit mute set admin on
```

The following command unmutes the remote radio:

```
radio[2/1]>remote-unit mute set admin off
```

Displaying the Remote Radio’s RX Level (CLI)

To display the remote radio’s RX level, enter the following command in radio view:

```
radio[x/x]>remote-unit show rx-level
```

Configuring the Remote Radio’s TX Level (CLI)

To set the transmit (TX) level of the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit set tx-level <tx-level>
```

To display the transmit (TX) level of the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit show tx-level
```

Table 69 Remote Radio TX Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	Depends on the frequency and unit type.	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of the remote radio to 10 dBm:

```
radio[2/1]>remote-unit set tx-level 10
```

Displaying the Remote Unit’s Most Severe Alarm (CLI)

To display the most severe alarm currently raised in the unit, enter the following command in radio view:

```
radio[x/x]>remote-unit show most-severe-alarm
```

Configuring and Viewing Radio PMs and Statistics (CLI)

This section includes:

- [Displaying General Modem Status and Defective Block PMs \(CLI\)](#)
- [Displaying Excessive BER \(Aggregate\) PMs \(CLI\)](#)
- [Displaying BER Level and Configuring BER Parameters \(CLI\)](#)
- [Configuring RSL Thresholds \(CLI\)](#)
- [Configuring TSL Thresholds \(CLI\)](#)
- [Displaying RSL and TSL Levels \(CLI\)](#)
- [Configuring the Signal Level Threshold \(CLI\)](#)
- [Configuring the MSE Thresholds and Displaying the MSE PMs \(CLI\)](#)
- [Displaying ACM PMs \(CLI\)](#)

Displaying General Modem Status and Defective Block PMs (CLI)

To display the general status of the modem, enter the following command in radio view:

```
radio[x/x]>modem show status
```

The following is a sample output of the `modem show status` command:

```
MSE[db]: -99.00
Defective Blocks count: 0

Current Tx profile: 0
Current Tx QAM: 4
Current Tx rate(kbps): 43389
Current Rx profile: 0
Current Rx QAM: 4
Current Rx rate(kbps): 43389
```

A value of 0 in the MSE (Db) field means that the modem is not locked.

To clear all radio PMs in the system, enter the following command in root view:

```
root> radio pm clear all
```

To clear defective blocks counters for a radio, enter the following command in radio view:

```
radio[x/x]>modem clear counters
```

Displaying Excessive BER (Aggregate) PMs (CLI)

You can display modem BER (Bit Error Rate) PMs in either 15-minute or daily intervals.

To display modem BER PMs in 15-minute intervals, enter the following command in radio view:

```
radio [x/x]>framer pm-aggregate show interval 15min
```

The following is a partial sample output of the `framer pm-aggregate show interval 15min` command:

```
radio [2/1]>framer pm-aggregate show interval 15min
Modem BER PM table:
=====
```

Interval	Integrity	ES	SES	UAS	BBE
0	1	0	0	333	0
1	1	0	0	900	0
2	1	0	0	900	0
3	1	0	0	900	0
4	1	0	0	900	0
5	1	0	0	900	0
6	1	0	0	900	0
7	1	0	0	900	0
8	1	0	0	900	0

```
radio [2/1]>
```

To display modem BER PMs in daily intervals, enter the following command:

```
radio [x/x]>framer pm-aggregate show interval 24hr
```

The following is a sample output of the `framer pm-aggregate show interval 24hr` command:

```
radio [2/1]>framer pm-aggregate show interval 24hr
Modem BER PM table:
=====
```

Interval	Integrity	ES	SES	UAS	BBE
0	1	0	0	53843	0
4	1	0	0	37061	0
5	1	0	0	4034	0
6	1	0	0	85971	0
8	1	0	0	46171	0
11	1	0	0	24184	0
15	1	0	0	85978	0
17	1	0	0	54979	0

```
radio [2/1]>
```

Table 70 Aggregate PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.

Parameter	Description
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.
ES	Indicates the number of seconds in the measuring interval during which errors occurred.
SES	Indicates the number of severe error seconds in the measuring interval.
UAS	Indicates the Unavailable Seconds value of the measured interval. The value can be between 0 and 900 seconds (15 minutes).
BBE	Indicates the number of background block errors during the measured interval.

Displaying BER Level and Configuring BER Parameters (CLI)

To display the current BER level, enter the following command:

```
radio [x/x]>modem show ber
```

The **excessive-ber** parameter determines whether or not excessive BER is propagated as a fault and considered a system event. For example, if **excessive-ber** is enabled, excessive BER can trigger a protection switchover.

To enable or disable Excessive BER Admin, enter the following command in root view:

```
root> radio excessive-ber set admin <admin>
```

To display the current setting for **excessive-ber**, enter the following command in root view:

```
root> radio excessive-ber show admin
```

To set the level above which an excessive BER alarm is issued for errors detected over the radio link, enter the following command:

```
radio [x/x]>modem excessive-ber set threshold <threshold>
```

To display the excessive BER threshold, enter the following command:

```
radio [x/x]>modem excessive-ber show threshold
```

Table 71 Excessive BER CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	enable disable	Enables or disables propagation of excessive BER as a fault.
threshold	Variable	1e -3 1e -4 1e -5	The level above which an excessive BER alarm is issued for errors detected over the radio link.

The following command enables `excessive-ber`:

```
root> radio excessive-ber set admin enable
```

The following command sets the excessive BER threshold to 1e-5:

```
radio [2/1]>modem excessive-ber set threshold 1e-5
```

Configuring RSL Thresholds (CLI)

You can set two RSL (RX Signal Level) thresholds. The number of seconds during which the RSL exceeds these thresholds are counted as RSL Exceed Threshold Seconds. See [Displaying RSL and TSL Levels \(CLI\)](#).

To set the RSL thresholds, enter the following command:

```
radio [x/x]>rf pm-rsl set threshold1 <threshold1> threshold2 <threshold2>
```

Table 72 RSL Thresholds CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold1	Number	-75 - -15	The first RSL threshold (dBm).
threshold2	Number	-75 - -15	The second RSL threshold (dBm).

The following command sets the RSL thresholds to -30 dBm and -60 dBm, respectively.

```
radio [2/1]>rf pm-rsl set threshold1 -30 threshold2 -60
```

Configuring TSL Thresholds (CLI)

The number of seconds during which the TX Signal Level exceeds the TSL threshold are counted as TSL Exceed Threshold Seconds. See [Displaying RSL and TSL Levels \(CLI\)](#).

To set the TSL threshold, enter the following command:

```
radio [x/x]>rf pm-tsl set threshold -15
```

Table 73 TSL Thresholds CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold	Number	-10 - 34	The TSL threshold (dBm).

The following command sets the TSL threshold to 10 dBm:

```
radio [2/1]>rf pm-tsl set threshold 10
```

Displaying RSL and TSL Levels (CLI)

You can display the RSL (RX Signal Level) and TSL (TX Signal Level) PMs in either 15-minute or daily intervals.

To display RSL and TSL PMs in 15-minute intervals, enter the following command:

```
radio [x/x]>rf pm-rsl-tsl show interval 15min
```

To display RSL and TSL PMs in daily intervals, enter the following command:

```
radio [x/x]>rf pm-rsl-tsl show interval 24hr
```

The following is the output format of the `rf pm-rsl-tsl show` commands:

```
radio [1/1]>rf pm-rsl-tsl show interval 15min

RF PM table:
=====
```

Interval	Integrity	Min RSL (dBm)	Max RSL (dBm)	Min TSL (dBm)	Max TSL (dBm)	TSL exceed threshold seconds	RSL exceed threshold1 seconds	RSL exceed threshold2 seconds
0	0	-72	-71	-20	-20	0	294	294
1	0	-72	-71	-20	-20	0	900	900
2	0	-72	-71	-20	-20	0	900	900
3	0	-72	-71	-20	-20	0	900	900
4	0	-72	-71	-20	-20	0	900	900
5	0	-72	-71	-20	-20	0	900	900
6	0	-72	-71	-20	-20	0	900	900
7	0	-72	-71	-20	-20	0	900	900
8	0	-73	-71	-20	-20	0	900	900
9	0	-73	-72	-20	-20	0	900	900
10	0	-74	-72	-20	-20	0	900	900
11	1	-85	-15	-20	-20	0	381	381
12	0	-72	-71	-20	-20	0	900	900
13	0	-72	-71	-20	-20	0	900	900
14	0	-73	-71	-20	-20	0	900	900
15	1	-84	-14	-20	-20	0	586	586
16	0	-72	-71	-20	-20	0	900	900
17	0	-72	-71	-20	-20	0	900	900
18	0	-72	-71	-20	-20	0	900	900
19	0	-72	-71	-20	-20	0	900	900
20	0	-72	-71	-20	-20	0	900	900
21	0	-72	-71	-20	-20	0	900	900
22	0	-72	-71	-20	-20	0	900	900
23	0	-72	-71	-20	-20	0	900	900
24	0	-72	-71	-20	-20	0	900	900
25	0	-73	-71	-20	-20	0	900	900
26	0	-73	-72	-20	-20	0	900	900
27	1	-84	-11	-20	-20	0	447	447
28	0	-72	-71	-20	-20	0	900	900
29	0	-72	-71	-20	-20	0	900	900
30	0	-72	-71	-20	-20	0	900	900
31	0	-72	-71	-20	-20	0	900	900
32	0	-72	-71	-20	-20	0	900	900
33	0	-72	-71	-20	-20	0	900	900
34	0	-72	-71	-20	-20	0	900	900
35	0	-72	-71	-20	-20	0	900	900
36	0	-72	-71	-20	-20	0	900	900
37	0	-72	-71	-20	-20	0	900	900
38	0	-72	-71	-20	-20	0	900	900
39	0	-72	-71	-20	-20	0	900	900
40	0	-72	-71	-20	-20	0	900	900
41	0	-72	-71	-20	-20	0	900	900
42	0	-72	-71	-20	-20	0	900	900
43	0	-72	-71	-20	-20	0	900	900
44	0	-72	-71	-20	-20	0	900	900
45	0	-72	-71	-20	-20	0	900	900
46	0	-72	-71	-20	-20	0	900	900
47	0	-72	-71	-20	-20	0	900	900
48	0	-72	-71	-20	-20	0	900	900
49	0	-72	-71	-20	-20	0	900	900
50	0	-72	-71	-20	-20	0	900	900
51	0	-72	-71	-20	-20	0	900	900
52	0	-72	-71	-20	-20	0	900	900
53	0	-72	-71	-20	-20	0	900	900
54	0	-72	-71	-20	-20	0	900	900
55	0	-72	-71	-20	-20	0	900	900
56	0	-72	-71	-20	-20	0	900	900
57	0	-72	-71	-20	-20	0	900	900
58	0	-72	-71	-20	-20	0	900	900
59	0	-72	-71	-20	-20	0	900	900
60	0	-72	-71	-20	-20	0	900	900
61	0	-72	-71	-20	-20	0	900	900
62	0	-72	-71	-20	-20	0	900	900
63	0	-72	-71	-20	-20	0	900	900
64	0	-72	-71	-20	-20	0	900	900
65	0	-72	-71	-20	-20	0	900	900
66	0	-72	-71	-20	-20	0	900	900
67	0	-72	-71	-20	-20	0	900	900
68	0	-72	-71	-20	-20	0	900	900
69	0	-72	-71	-20	-20	0	900	900
70	0	-72	-71	-20	-20	0	900	900
71	0	-72	-71	-20	-20	0	900	900
72	0	-72	-71	-20	-20	0	900	900
73	0	-72	-71	-20	-20	0	900	900
74	0	-72	-71	-20	-20	0	900	900
75	0	-72	-71	-20	-20	0	900	900
76	0	-72	-71	-20	-20	0	900	900
77	0	-72	-71	-20	-20	0	900	900
78	0	-72	-71	-20	-20	0	900	900
79	0	-72	-71	-20	-20	0	900	900
80	0	-72	-71	-20	-20	0	900	900
81	0	-72	-71	-20	-20	0	900	900
82	0	-72	-71	-20	-20	0	900	900
83	0	-72	-71	-20	-20	0	900	900
84	0	-72	-71	-20	-20	0	900	900
85	0	-72	-71	-20	-20	0	900	900
86	0	-72	-71	-20	-20	0	900	900
87	0	-72	-71	-20	-20	0	900	900
88	0	-72	-71	-20	-20	0	900	900
89	0	-72	-71	-20	-20	0	900	900
90	0	-72	-71	-20	-20	0	900	900
91	0	-72	-71	-20	-20	0	900	900
92	0	-72	-71	-20	-20	0	900	900
93	0	-72	-71	-20	-20	0	900	900
94	0	-72	-71	-20	-20	0	900	900

```
radio [1/1]>
```

Table 74 RSL and TSL PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.
Min RSL (dBm)	The minimum RSL (Received Signal Level) that was measured during the interval.
Max RSL (dBm)	The maximum RSL (Received Signal Level) that was measured during the interval.
Min TSL (dBm)	The minimum TSL (Transmit Signal Level) that was measured during the interval.
Max TSL (dBm)	The maximum TSL (Transmit Signal Level) that was measured during the interval.
TSL exceed threshold seconds	The number of seconds the measured TSL exceeded the threshold during the interval. See Configuring TSL Thresholds (CLI) .
RSL exceed threshold1 seconds	The number of seconds the measured RSL exceeded RSL threshold 1 during the interval. See Configuring RSL Thresholds (CLI) .
RSL exceed threshold2 seconds	The number of seconds the measured RSL exceeded RSL threshold 2 during the interval. See Configuring RSL Thresholds (CLI) .

Configuring the Signal Level Threshold (CLI)

To set the BER (Bit Error Rate) level above which a Signal Degrad alarm is issued for errors detected over the radio link, enter the following command:

```
radio [x/x]>modem signal-degrade set threshold 1e-7
```

To display the Signal Degrad BER threshold, enter the following command:

```
radio [x/x]>modem signal-degrade show threshold
```

Table 75 Signal Level Threshold CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold	Variable	1e -6	The BER level above which a Signal Degrade alarm is issued for errors detected over the radio link.
		1e -7	
		1e -8	
		1e -9	
		1e -10	

The following command sets the Signal Degrade threshold at 1e-7:

```
radio [2/1]>modem signal-degrade set threshold 1e-7
```

Configuring the MSE Thresholds and Displaying the MSE PMs (CLI)

To configure the MSE (Mean Square Error) threshold, enter the following command:

```
radio [x/x]>modem set mse-exceed threshold <threshold>
```

To display the currently configured MSE threshold, enter the following command:

```
radio [x/x]>modem show threshold-mse-exceed
```

Table 76 MSE CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold	Number	-99 - -1	The MSE threshold.

To display MSE (Mean Square Error) PMs in 15-minute intervals, enter the following command:

```
radio [x/x]>modem pm-mse show interval 15min
```

The following is a partial sample output of the `modem pm-mse show interval 15min` command:


```
radio [2/1]>modem pm-mse show interval 15min
```

```
Modem MSE PM Table:
```

```
=====
```

Interval	Integrity	Min MSE (dB)	Max MSE (dB)	Exceed threshold seconds
0	1	0.00	0.00	708
1	1	0.00	0.00	900
2	1	0.00	0.00	900
3	1	0.00	0.00	900
4	1	0.00	0.00	900
5	1	0.00	0.00	900
6	1	0.00	0.00	900
7	1	0.00	0.00	900
8	1	0.00	0.00	900
9	1	0.00	0.00	900
10	1	0.00	0.00	900

```
radio [2/1]>
```

To display MSE (Mean Square Error) PMs in daily intervals, enter the following command:

```
radio [x/x]>modem pm-mse show interval 24hr
```

The following is sample output of the `modem pm-mse show interval 24hr` command:

```
radio [2/1]>modem pm-mse show interval 24hr
```

```
Modem MSE PM Table:
```

```
=====
```

Interval	Integrity	Min MSE (dB)	Max MSE (dB)	Exceed threshold seconds
0	1	0.00	0.00	63745
4	1	0.00	0.00	37062
5	1	0.00	0.00	3495
6	1	0.00	0.00	85976
8	1	0.00	0.00	46173
11	1	0.00	0.00	24185
15	1	0.00	0.00	85988
17	1	0.00	0.00	54981

```
radio [2/1]>modem
```

Table 77 MSE PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time. A 1 and a 0 value in the Max MSE field may also indicate that the modem was unlocked.
Min MSE (dB)	Indicates the minimum MSE in dB, measured during the interval. A 0 in this field and a 1 in the Integrity field may also indicate that the modem was unlocked during the entire interval.
Max MSE (dB)	Indicates the maximum MSE in dB, measured during the interval. A 0 in this field and a 1 in the Integrity field may also indicate that the modem was unlocked.
Exceed Threshold Seconds	Indicates the number of seconds the MSE exceeded the MSE PM threshold during the interval.

The following command sets the MSE threshold to -30:

```
radio [2/1]>modem set mse-exceed threshold -30
```

Displaying ACM PMs (CLI)

To display ACM PMs in 15-minute intervals, enter the following command:

```
radio [x/x]>mrmc pm-acm show interval 15min
```

The following is a partial sample output of the `modem pm-acm show interval 15min` command:

```
radio [2/1]>mrmc pm-acm show interval 15min
```

MRMC PM Table:

=====

Interval	Integrity	Min profile	Max profile	Min bitrate	Max bitrate
=====					
0	1	0	0	43389	43389
1	1	0	0	43389	43389
2	1	0	0	43389	43389
3	1	0	0	43389	43389
4	1	0	0	43389	43389
5	1	0	0	43389	43389
6	1	0	0	43389	43389
7	1	0	0	43389	43389
8	1	0	0	43389	43389
9	1	0	0	43389	43389
10	1	0	0	43389	43389

radio [2/1]>

To display ACM PMs in daily intervals, enter the following command:

```
radio [x/x]>mrmc pm-acm show interval 24hr
```

The following is sample output of the `modem pm-acm show interval 24hr` command:

```
radio [2/1]>mrmc pm-acm show interval 24hr
```

MRMC PM Table:

=====

Interval	Integrity	Min profile	Max profile	Min bitrate	Max bitrate
=====					
0	1	0	0	43389	43389
4	1	0	0	43389	43389
5	1	0	0	43389	43389
6	1	0	0	43389	43389
8	1	0	0	43389	43389
11	1	0	0	43389	43389
15	1	0	0	43389	43389
17	1	0	0	43389	43389

radio [2/1]>

Table 78 ACM PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

Parameter	Description
Min profile	Indicates the minimum ACM profile that was measured during the interval.
Max profile	Indicates the maximum ACM profile that was measured during the interval.
Min bitrate	Indicates the minimum total radio throughput (Mbps), delivered during the interval.
Max bitrate	Indicates the maximum total radio throughput (Mbps), delivered during the interval.

Chapter 15: Ethernet Services and Interfaces (CLI)

This section includes:

- [Configuring Ethernet Services \(CLI\)](#)
- [Setting the MRU Size and the S-VLAN Ethertype \(CLI\)](#)
- [Configuring Ethernet Interfaces \(CLI\)](#)
- [Configuring Automatic State Propagation and Link Loss Forwarding \(CLI\)](#)
- [Viewing Ethernet PMs and Statistics \(CLI\)](#)

Related topics:

- [Quality of Service \(QoS\) \(CLI\)](#)
- [Performing Ethernet Loopback \(CLI\)](#)

Configuring Ethernet Services (CLI)

This section includes:

- [Ethernet Services Overview \(CLI\)](#)
- [General Guidelines for Provisioning Ethernet Services \(CLI\)](#)
- [Defining Services \(CLI\)](#)
- [Configuring Service Points \(CLI\)](#)
- [Defining the MAC Address Forwarding Table for a Service \(CLI\)](#)

Ethernet Services Overview (CLI)

Users can define up to 64 Ethernet services. Each service constitutes a virtual bridge that defines the connectivity between logical ports in the PTP 850 network element.

This version of PTP 850 supports the following service types:

- Multipoint (MP)
- Point-to-Point (P2P)
- Management (MNG)



Note

In release 10.6, only P2P and MNG services are supported. In release 10.9, Multipoint services are also supported.

In addition to user-defined services, PTP 850 contains a pre-defined management service (Service ID 257). By default, this service is operational.



Note

You can use the management service for in-band management. For instructions on configuring in-band management, see [Mate Management Access \(IP Forwarding\) \(CLI\)](#)

A service point is a logical entity attached to a physical or logical interface. Service points define the movement of frames through the service. Each service point includes both ingress and egress attributes. A Point-to-Point or Multipoint service can hold up to 32 service points. A Management service can hold up to 30 service points.

For a more detailed overview of the PTP 850 service-oriented Ethernet switching engine, refer to the Technical Description for the PTP 850 product type you are using.

General Guidelines for Provisioning Ethernet Services (CLI)

When provisioning Ethernet services, it is recommended to follow these guidelines:

- Use the same Service ID for all service fragments along the path of the service.
- Do not re-use the same Service ID within the same region. A region is defined as consisting of all PTP 850 devices having Ethernet connectivity between them.

- Use meaningful EVC IDs.
- Give the same EVC ID (service name) to all service fragments along the path of the service.
- Do not reuse the same EVC ID within the same region.

It is recommended to follow these guidelines for creating service points:

- Always use SNP service points on NNI ports and SAP service points on UNI ports.
- For each logical interface associated with a specific service, there should never be more than a single service point.
- The transport VLAN ID should be unique per service within a single region. That is, no two services should use the same transport VLAN ID.

Defining Services (CLI)

Use the commands described in the following sections to define a service and its parameters. After defining the service, you must add service points to the service in order for the service to carry traffic.

Adding a Service (CLI)

To add a service, enter the following command in root view:

```
root> ethernet service add type <service type> sid <sid> admin <service
admin mode> evc-id <evc-id> description <evc-description>
```

Table 79 Adding Ethernet Service CLI Parameters

Parameter	Input Type	Permitted Values	Description
service type	Variable	p2p mp	Defines the service type: p2p - Point-to-Point mp - Multipoint
sid	Number	Any unused value from 1-256	A unique ID for the service. Once you have added the service, you cannot change the Service ID. Service ID 257 is reserved for a pre-defined management service.
service admin mode	Variable	Operational reserved	The administrative state of the service: operational - The service is functional. reserved - The service is disabled until this parameter is changed to operational. In this mode, the service occupies system resources but is unable to receive and transmit data.
evc-id	Text String	Up to 20 characters.	Defines an Ethernet Virtual Connection (EVC) ID. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.

Parameter	Input Type	Permitted Values	Description
evc-description	Text String	Up to 64 characters.	A text description of the service. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.

The following command adds a Multipoint service with Service ID 18.

```
root> ethernet service add type mp sid 18 admin operational evc-id Ring_1
description east_west
```

The following command adds a Point-to-Point service with Service ID 10.

```
root> ethernet service add type p2p sid 10 admin operational evc-id
Ring_1 description east_west
```

These services are immediately enabled, although service points must be added to the services in order for the services to carry traffic.

Entering Service View (CLI)

To view service details and set the service's parameters, you must enter the service's view level in the CLI.

To enter a service's view level:

```
root> ethernet service sid <sid>
```

Table 80 Entering Ethernet Service View CLI Parameters

Parameter	Input Type	Permitted Values	Description
sid	Number	Any unused value from 1-256	A unique ID for the service. Once you have added the service, you cannot change the Service ID. Service ID 257 is reserved for a pre-defined management service.

The following command enters service view for the service with Service ID 10:

```
root> ethernet service sid 10
```

The following prompt appears:

```
service[10]>
```

Showing Service Details (CLI)

To display the attributes of a service, go to service view for the service and enter the following command:

```
service[SID]>service info show
```

For example:

```
service[1]>service info show
```



```

service info:
service id: 1
service type: p2p
service admin: operational
Maximal MAC address learning entries: 131072
default cos: 0
cos mode: preserve-sp-cos-decision
EVC id: N.A.
EVC description: N.A.
split horizon group: disable
configured multicast grouping: no

```

```
service[1]>
```

To display the attributes of a service and its service points, go to service view for the service and enter the following command:

```
service[SID]>service detailed-info show
```

For example:

```

service[1]>service detailed-info show
service info:
service id: 1
service type: p2p
service admin: operational
Maximal MAC address learning entries: 131072
default cos: 0
cos mode: preserve-sp-cos-decision
EVC id: PIPE
EVC description: sid1
split horizon group: disable
configured multicast grouping: no
service-points info:
+-----+-----+-----+-----+-----+-----+-----+-----+
|Service ID|Service Type|List of SP's|Attached to Interface|Attached Interface Type|Service Admin|STP Instance|SP name|
+-----+-----+-----+-----+-----+-----+-----+-----+
|1         |p2p         |pipe \1     |sfp                 |1/2 dot1q             |operational  |0           |N.A.   |
|1         |p2p         |pipe \2     |radio               |2/1 dot1q             |operational  |0           |N.A.   |
+-----+-----+-----+-----+-----+-----+-----+-----+
service[1]>

```

To display a list of service points and their attributes, enter the following command in root view:

```
root>ethernet service show info sid <sid>
```

Table 81 Displaying Ethernet Service Details CLI Parameters

Parameter	Input Type	Permitted Values	Description
sid	Number	Any defined Service ID.	None

For example:

```

root>ethernet service show info sid 1
service-points info:
+-----+-----+-----+-----+-----+-----+-----+-----+
|Service ID|Service Type|List of SP's|Attached to Interface|Attached Interface Type|Service Admin|STP Instance|SP name|
+-----+-----+-----+-----+-----+-----+-----+-----+
|1         |p2p         |pipe \1     |sfp                 |1/2 dot1q             |operational  |0           |sp1    |
|1         |p2p         |pipe \2     |radio               |2/1 dot1q             |operational  |0           |sp2    |
+-----+-----+-----+-----+-----+-----+-----+-----+
root>

```

Configuring a Service's Operational State (CLI)

To change the operational state of a service, go to service view for the service and enter the following command:

```
service[SID]>service admin set <service admin mode>
```

To display a service's admin mode, go to service view for the service and enter the following command:

```
service[SID]> service admin show state
```

Table 82 Ethernet Service Operational State CLI Parameters

Parameter	Input Type	Permitted Values	Description
service admin mode	Variable	Operational reserved	The administrative state of the service: operational - The service is functional. reserved - The service is disabled until this parameter is changed to Operational. In this mode, the service occupies system resources but is unable to receive and transmit data.

The following command sets Service 10 to be operational:

```
service[10]>service admin set operational
```

Configuring a Service's CoS Mode and Default CoS (CLI)

The CoS mode determines whether or not frames passing through the service have their CoS modified at the service level. The CoS determines the priority queue to which frames are assigned.

The CoS of frames traveling through a service can be modified on the interface level, the service point level, and the service level. The service level is the highest priority, and overrides CoS decisions made at the interface and service point levels. Thus, by configuring the service to apply a CoS value to frames in the service, you can define a single CoS for all frames traveling through the service.

To set a service's CoS mode, go to service view for the service and enter the following command:

```
service[SID]>service cos-mode set cos-mode <cos-mode>
```

If the CoS mode is set to **default-cos**, you must define the Default CoS. Use the following command to define the Default CoS:

```
service[SID]>service default-cos set cos <cos>
```

Table 83 Ethernet Service CoS Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
cos-mode	Variable	default-cos preserve-sp-cos-decision	default cos - Frames passing through the service are assigned the default CoS defined below. This CoS value overrides whatever CoS may have been assigned at the service point or interface level. preserve-sp-cos-decision - The CoS of frames passing through the service is not modified by the service.
cos	Number	0 – 7	This value is assigned to frames at the service level if cos-mode is set to default-cos. Otherwise, this value is not used, and frames retain whatever CoS value they were assigned at the service point or logical interface level.

The following commands configure Service 10 to assign a CoS value of 7 to frames traversing the service:

```
service[10]>service cos-mode set cos-mode default-cos
service[10]>service default-cos set cos 7
```

The following command configures Service 10 to preserve the CoS decision made at the interface or service point level for frames traveling through the service:

```
service[10]>service cos-mode set cos-mode preserve-sp-cos-decision
```

Configuring a Service's EVC ID and Description (CLI)

To add or change the EVC ID of a service, go to service view for the service and enter the following command:

```
service[SID]>service evcid set <evcid>
```

To display a service's EVC ID, go to service view for the service and enter the following command:

```
service[SID]>service evcid show
```

To add or change the EVC description of a service, go to service view for the service and enter the following command:

```
service[SID]>service description set <evc description>
```

To display a service's EVC description, go to service view for the service and enter the following command:

```
service[SID]>service description show
```

Table 84 Ethernet Service EVC CLI Parameters

Parameter	Input Type	Permitted Values	Description
evcid	Text String	Up to 20 characters.	Defines an Ethernet Virtual Connection (EVC) ID. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
evc description	Text String	Up to 64 characters.	A text description of the service. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.

The following commands add the EVC ID "East_West" and the EVC description "Line_to_Radio" to Service 10:

```
service[10]>service evcid set East_West
service[10]>service description set Line_to_Radio
```

Deleting a Service (CLI)

Before deleting a service, you must first delete any service points attached to the service (refer to [Deleting a Service Point \(CLI\)](#)).

Use the following command to delete a service:

```
root>ethernet service delete sid <sid>
```

Use the following command to delete a range of services:

```
root>ethernet service delete sid <sid> to <sid>
```

Table 85 Deleting Ethernet Service CLI Parameters

Parameter	Input Type	Permitted Values	Description
sid	Number	Any defined Service ID.	The Service ID.

The following command deletes Service 10:

```
root>ethernet service delete sid 10
```

The following command deletes Services 10 through 15:

```
root>ethernet service delete sid 10 to 15
```

Configuring Service Points (CLI)

This section includes:

- [Service Points Overview \(CLI\)](#)
- [Service Point Classification \(CLI\)](#)
- [Adding a Service Point \(CLI\)](#)
- [Configuring Service Point Ingress Attributes \(CLI\)](#)
- [Configuring Service Point Egress Attributes \(CLI\)](#)
- [Displaying Service Point Attributes \(CLI\)](#)
- [Deleting a Service Point \(CLI\)](#)

Service Points Overview (CLI)

Service points are logical interfaces within a service. A service point is a logical entity attached to a physical or logical interface. Service points define the movement of frames through the service. Each service point includes both ingress and egress attributes.

Each service point for a Point-to-Point or Multipoint service can be either a Service Access Point (SAP) or a Service Network Point (SNP). A Point-to-Point service can also use Pipe service points.

- An SAP is equivalent to a UNI in MEF terminology and defines the connection of the user network with its access points. SAPs are used for Point-to-Point and Multipoint traffic services.
- An SNP is equivalent to an NNI or E-NNI in MEF terminology and defines the connection between the network elements in the user network. SNPs are used for Point-to-Point and Multipoint traffic services.
- A Pipe service point is used to create traffic connectivity between two ports in a port-based manner (Smart Pipe). In other words, all the traffic from one port passes to the other port.

Management services utilize Management (MNG) service points.

A Point-to-Point or Multipoint service can hold up to 32 service points. A management service can hold up to 30 service points.

[Table 117](#) summarizes the service point types available per service type.

Table 86 Service Points per Service Type

		Service Point Type			
		MNG	SAP	SNP	Pipe
Service Type	Management	Yes	No	No	No
	Point-to-Point	No	Yes	Yes	Yes
	Multipoint	No	Yes	Yes	No

Table 118 shows which service point types can co-exist on the same interface.

Table 87 Service Point Types per Interface

	MNG	SAP	SNP	Pipe
MNG	Only one MNG SP is allowed per interface.	Yes	Yes	Yes
SAP	Yes	Yes	No	No
SNP	Yes	No	Yes	No
PIPE	Yes	No	No	Only one Pipe SP is allowed per interface.

Service Point Classification (CLI)

This section includes:

- [Overview of Service Point Classification \(CLI\)](#)
- [SAP Classification \(CLI\)](#)
- [SNP Classification \(CLI\)](#)
- [Pipe Service Point Classification \(CLI\)](#)
- [MNG Service Point Classification \(CLI\)](#)

Overview of Service Point Classification (CLI)

Service points connect the service to the network element interfaces. It is crucial that the network element have a means to classify incoming frames to the proper service point. This classification process is implemented by means of a parsing encapsulation rule for the interface associated with the service point. This rule is called the Interface Type, and is based on a key consisting of:

- The Interface ID of the interface through which the frame entered.
- The frame's C-VLAN and/or S-VLAN tags.

The Interface Type provides a definitive mapping of each arriving frame to a specific service point in a specific service. Since more than one service point may be associated with a single interface, frames are assigned to the earliest defined service point in case of conflict.

SAP Classification (CLI)

SAPs can be used with the following Interface Types:

- All to one – All C-VLANs and untagged frames that enter the interface are classified to the same service point.
- Dot1q – A single C-VLAN is classified to the service point.
- QinQ – A single S-VLAN and C-VLAN combination is classified to the service point.
- Bundle C-Tag – A set of multiple C-VLANs is classified to the service point.
- Bundle S-Tag – A single S-VLAN and a set of multiple C-VLANs are classified to the service point.

SNP Classification (CLI)

SNPs can be used with the following Attached Interface Types:

- Dot1q – A single C-VLAN is classified to the service point.
- S-Tag – A single S-VLAN is classified to the service point.

Pipe Service Point Classification (CLI)

Pipe service points can be used with the following Attached Interface Types:

- Dot1q – All C-VLANs and untagged frames that enter the interface are classified to the same service point.
- S-Tag – All S-VLANs and untagged frames that enter the interface are classified to the same service point.

MNG Service Point Classification (CLI)

Management service points can be used with the following Interface Types:

- Dot1q – A single C-VLAN is classified to the service point.
- S-Tag – A single S-VLAN is classified to the service point.
- QinQ – A single S-VLAN and C-VLAN combination is classified to the service point.

[Table 119](#) and [Table 120](#) show which service point – Interface Type combinations can co-exist on the same interface.

Table 88 Legal Service Point – Interface Type Combinations per Interface – SAP and SNP

SP Type		SAP				SNP		
SP Type	Attached Interface Type	802.1q	Bundle-C	Bundle-S	All to One	Q in Q	802.1q	S-Tag
SAP	802.1q	Yes	Yes	No	No	No	No	No
	Bundle-C	Yes	Yes	No	No	No	No	No
	Bundle-S	No	No	Yes	No	Yes	No	No
	All to One	No	No	No	Only 1 All to One SP Allowed	No	No	No
	Q in Q	No	No	Yes	No	Yes	No	No
SNP	802.1q	No	No	No	No	No	Yes	No

	SP Type	SAP				SNP		
	Attached Interface Type	802.1q	Bundle-C	Bundle-S	All to One	Q in Q	802.1q	S-Tag
	S-Tag	No	No	No	No	No	No	Yes
Pipe	802.1q	No	No	No	No	No	No	No
	S-Tag	No	No	No	No	No	No	No
MNG	802.1q	Yes	Yes	No	No	No	Yes	No
	Q in Q	No	No	Yes	No	Yes	No	No
	S-Tag	No	No	No	No	No	No	Yes

Table 89 Legal Service Point – Interface Type Combinations per Interface – Pipe and MNG

	SP Type	Pipe		MNG		
SP Type	Attached Interface Type	802.1q	S-Tag	802.1q	Q in Q	S-Tag
SAP	802.1q	No	No	Yes	No	No
	Bundle-C	No	No	Yes	No	No
	Bundle-S	No	No	No	Yes	No
	All to One	No	No	No	No	No
	Q in Q	No	No	No	Yes	No
SNP	802.1q	No	No	Yes	No	No
	S-Tag	No	No	No	No	Yes
Pipe	802.1q	Only one Pipe SP Allowed	No	Yes	No	No
	S-Tag	No	Only one Pipe SP Allowed	No	No	Yes
MNG	802.1q	Yes	No	Only 1 MNG SP Allowed	No	No
	Q in Q	No	No	No	Only 1 MNG SP Allowed	No
	S-Tag	No	Yes	No	No	Only 1 MNG SP Allowed

Adding a Service Point (CLI)

The command syntax for adding a service point depends on the interface type of the service point. The interface type determines which frames enter the service via this service point.

To add a service point with an All-to-One interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type all-to-one spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> sp-name <sp-
name>
```

To add a service point with a Dot1q interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type dot1q spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> vlan <vlan>
sp-name <sp-name>
```

To add a service point with an S-Tag interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type s-tag spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> vlan <vlan>
sp-name <sp-name>
```

To add a service point with a Bundle-C interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type bundle-c spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> sp-name <sp-
name>
```

To add a service point with a Bundle-S interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type bundle-s spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> [outer-
vlan <outer-vlan>|vlan <vlan>] sp-name <sp-name>
```

Note: In SAP service points, use the parameter `outer-vlan`. In SP service points, use the parameter `vlan`.

To add a service point with a Q-in-Q interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type qinq spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> outer-
vlan <outer-vlan> inner-vlan <inner-vlan> sp-name <sp-name>
```

To add a Pipe service point, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type pipe int-type <int-type> spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> sp-name <sp-
name>
```


Table 90 Add Service Point CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-type	Variable	sap	SAP - Service Access Point
		snp	SNP - Service Network Point
		pipe	PIPE - Pipe service point
		mng	MNG - Management service point
int-type	Variable	all-to-one	<p>Determines which frames enter the service via this service point, based on the frame's VLAN tagging. Since more than one service point may be associated with a single interface, frames are assigned to the earliest defined service point in case of conflict.</p> <p>all-to-one - All C-VLANs and untagged frames that enter the interface are classified to the service point. Only valid for SAP service point types.</p> <p>dot1q - A single C-VLAN is classified to the service point. Valid for all service point types.</p> <p>s-tag - A single S- VLAN is classified to the service point. Valid for SNP and MNG service point types.</p> <p>bundle-c-tag - A set of multiple C-VLANs is classified to the service point. Only valid for SAP service point types.</p> <p>bundle-s-tag - A single S-VLAN and a set of multiple C-VLANs are classified to the service point. Only valid for SAP service point types.</p> <p>qinq - A single S-VLAN and C-VLAN combination is classified to the service point. Valid for SAP and MNG service point types.</p>
		dot1q	
		s-tag	
		bundle-c-tag	
		bundle-s-tag	
		qinq	
sp-id	Number	1-32 for P2P and MP services.	This ID is unique within the service.
		1-30 for MNG services.	
interface	Variable	eth	<p>The Interface type for the service point:</p> <p>eth - An Ethernet interface.</p> <p>radio - A radio interface.</p> <p>When you are defining the service point on a group, such as a LAG, use the group parameter instead of the interface parameter.</p>
		radio	

Parameter	Input Type	Permitted Values	Description
group	Variable	rp1 rp2 rp3 rp4 lag1 lag2 lag3 lag4 mc-abc1 mc-abc2 mc-abc3 mc-abc4	When you are defining the service point on an HSB group (rp1 - rp-4), a LAG (lag1 - lag4), or a Multi-Carrier ABC group (mc-abc1 - mc-abc4), use this parameter instead of the interface parameter to identify the group. The group must be defined before you add the service point. Note: Multi-Carrier ABC and HSB protection are only relevant for PTP 850E units.
slot	Number	Ethernet: 1 Radio: 2	
port	Number	For an Ethernet interface: 1-3 For a radio interface in PTP 850E units: 1-2 For a radio interface in PTP 850E: 1	The port or radio carrier on which the service point is located.
vlan	Number or Variable	1-4094 (except 4092 which is reserved for the default management service), or Untagged	Defines the VLAN classified to the service point. This parameter should not be included for service points with an interface type of bundle-C-tag. For instructions on attaching a bundled VLAN, refer to Attaching a VLAN Bundle to a Service Point (CLI) . This parameter is also not relevant for: Service points with an interface type of qinq and all-to-one. Pipe service points.
outer-vlan	Number	1-4094 (except 4092, which is reserved for the default management service), or Untagged	Defines the S-VLAN classified to the service point. This parameter is only relevant for service points with the interface type bundle-s-tag or qinq.

Parameter	Input Type	Permitted Values	Description
inner-vlan	Number	1-4094 (except 4092, which is reserved for the default management service), or Untagged	Defines the C-VLAN classified to the service point. This parameter is only relevant for service points with the interface type qinq.
sp-name	Text string	Up to 20 characters.	A descriptive name for the service point (optional).

The following command adds an SAP service point with Service Point ID 10 to Service 37, with interface type dot1q. This service point is located on radio carrier 1. VLAN ID 100 is classified to this service point.

```
service[37]>sp add sp-type sap int-type dot1q spid 10 interface radio
slot 2 port 1 vlan 100 sp-name Radio
```

The following command adds an SAP service point with Service Point ID 10 to Service 37, with interface type bundle-s-tag. This service point is located on radio carrier 2 in a PTP 850E unit. S-VLAN 100 is classified to the service point.

```
service[37]>sp add sp-type sap int-type bundle-s-tag spid 10 interface
radio slot 2 port 2 outer-vlan 100 sp-name Radio
```

The following command adds an SAP service point with Service Point ID 10 to Service 37, with interface type qinq. This service point is located on radio carrier 2 in a PTP 850E unit. S-VLAN 100 and C-VLAN 200 are classified to the service point.

```
service[37]>sp add sp-type sap int-type qinq spid 10 interface radio slot
2 port 2 outer-vlan 100 inner-vlan 200 sp-name Radio
```

The following command adds an SAP service point with Service Point ID 10 to Service 37, with interface type all-to-one. This service point is located on radio carrier 1. All traffic entering the system from that port is classified to the service point.

```
service[37]>sp add sp-type sap int-type all-to-one spid 10 interface
radio slot 2 port 1 sp-name "all-to-one"
```

The following command adds an SNP service point with Service Point ID 10 to Service 37, with interface type s-tag. This service point is located on radio carrier 1. S-VLAN 100 is classified to the service point.

```
service[37]>sp add sp-type snp int-type s-tag spid 10 interface radio
slot 2 port 1 vlan 100 sp-name Radio
```

The following command adds an SAP service point with Service Point ID 7 to Service 36, with interface type dot1q. This service point is connected to HSB group 1 (rp1). VLAN ID 100 is classified to the service point.

```
service[36]>sp add sp-type sap int-type dot1q spid 7 group rp1 vlan 100
sp-name test1
```

The following command adds a Pipe service point with Service Point ID 1 to Service 1, with interface type dot1q. This service point is connected to Eth1.

```
service[1]>sp add sp-type pipe int-type dot1q spid 1 interface eth slot 1
port 1 sp-name pipe_dot1q
```

The following commands create a Smart Pipe service between Eth1 and radio carrier 1. This service carries S-VLANs and untagged frames between the two interfaces:

```
root> ethernet service add type p2p sid 10 admin operational evc-id test
description east_west
root>
root> ethernet service sid 10
service[10]>
service[10]>sp add sp-type pipe int-type s-tag spid 1 interface eth slot
1 port 1 sp-name test1
service[10]>
service[10]>sp add sp-type pipe int-type s-tag spid 2 interface radio
slot 2 port 1 sp-name test2
service[10]>
```

Configuring Service Point Ingress Attributes (CLI)

A service point's ingress attributes are attributes that operate upon frames ingressing via the service point. This includes how the service point handles the CoS of ingress frames and how the service point forwards frames to their next destination within the service.

This section includes:

- [Enabling and Disabling Broadcast Frames \(CLI\)](#)
- [CoS Preservation and Modification on a Service Point \(CLI\)](#)
- [Enabling and Disabling Flooding \(CLI\)](#)

Enabling and Disabling Broadcast Frames (CLI)

To determine whether frames with a broadcast destination MAC address are allowed to ingress the service via this service point, go to service view for the service and enter the following command:

```
service[SID]>sp broadcast set spid <sp-id> state <state>
```

Table 91 Enable/Disable Broadcast Frames CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
state	Variable	allow disable	Determines whether frames with a broadcast destination MAC address are allowed to ingress the service via this service point.

The following command allows frames with a broadcast destination MAC address to ingress Service 37 via Service Point 1.

```
service[37]>sp broadcast set spid 1 state allow
```

The following command prevents frames with a broadcast destination MAC address from ingressing Service 37 via Service Point 1.

```
service[37]>sp broadcast set spid 1 state disable
```

CoS Preservation and Modification on a Service Point (CLI)

The CoS of frames traversing a service can be modified on the logical interface, service point, and service level. The service point can override the CoS decision made at the interface level. The service, in turn, can modify the CoS decision made at the service point level.

To determine whether the service point modifies CoS decisions made at the interface level, go to service view for the service and enter the following command:

```
service[SID]> sp cos-mode set spid <sp-id> mode <cos mode>
```

If you set cos-mode to `sp-def-cos`, you must then configure a default CoS. This CoS is applied to frames that ingress the service point, but can be overwritten at the service level.

To configure the default CoS, go to service view for the service and enter the following command:

```
service[SID]>sp sp-def-cos set spid <sp-id> cos <cos>
```

Table 92 Service Point CoS Preservation CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
cos mode	Variable	sp-def-cos interface-decision	sp-def-cos - The service point re-defines the CoS of frames that pass through the service point, according to the Default CoS (below). This decision can be overwritten on the service level. interface-decision - The service point preserves the CoS decision made at the interface level. This decision can still be overwritten at the service level.
cos	Number	0 – 7	If cos-mode is sp-def-cos, this is the CoS assigned to frames that pass through the service point. This decision can be overwritten on the service level.

The following commands configure Service Point 1 in Service 37 to apply a CoS value of 5 to frames that ingress the service point:

```
service[37]>sp cos-mode set spid 1 mode sp-def-cos
service[37]>sp sp-def-cos set spid 1 cos 5
```

The following command configures Service Point 1 in Service 37 to preserve the CoS decision made at the interface level for frames that ingress the service point:

```
service[37]>sp cos-mode set spid 1 mode interface-decision
```

Enabling and Disabling Flooding (CLI)

The ingress service point for a frame can forward the frame within the service by means of flooding or dynamic MAC address learning in the service.

To enable or disable forwarding by means of flooding for a service point, go to service view for the service and enter the following command:

```
service[SID]>sp flooding set spid <sp-id> state <flooding state>
```

Table 93 Service Point Enable/Disable Flooding CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
state	Variable	Allow disable	Determines whether incoming frames with unknown MAC addresses are forwarded to other service points via flooding.

The following command configures Service Point 1 in Service 37 to flood incoming frames with unknown MAC addresses to other service points:

```
service[37]>sp flooding set spid 1 state allow
```

The following command configures Service Point 1 in Service 37 not to flood incoming frames with unknown MAC addresses to other service points:

```
service[37]>sp flooding set spid 1 state disable
```

Configuring Service Point Egress Attributes (CLI)

A service point's egress attributes are attributes that operate upon frames ingressing via the service point. This includes VLAN preservation and marking attributes.

This section includes:

- [Configuring VLAN and CoS Preservation \(CLI\)](#)
- [Configuring Service Bundles \(CLI\)](#)
- [Attaching a VLAN Bundle to a Service Point \(CLI\)](#)

Configuring VLAN and CoS Preservation (CLI)

CoS and VLAN preservation determines whether the CoS and/or VLAN IDs of frames egressing the service via the service point are restored to the values they had when the frame entered the service.

This section includes:

- [Configuring C-VLAN CoS Preservation \(CLI\)](#)
- [Configuring C-VLAN Preservation \(CLI\)](#)
- [Configuring S-VLAN CoS Preservation \(CLI\)](#)

Configuring C-VLAN CoS Preservation (CLI)

To configure CoS preservation for C-VLAN-tagged frames, go to service view for the service and enter the following command:

```
service[SID]>sp cvlan-cos-preservation-mode set spid <sp-id> mode <c-
vlan cos preservation mode>
```

Table 94 C-VLAN CoS Preservation Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
c-vlan cos preservation mode	Variable	enable disable	Select enable or disable to determine whether the original C-VLAN CoS value is preserved or restored for frames egressing the service point. enable - the C-VLAN CoS value of frames egressing the service point is the same as the value when the frame entered the service. disable - the C-VLAN CoS value of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking (see Configuring Marking (CLI)).

The following command enables C-VLAN CoS preservation for Service Point 1 on Service 37:

```
service[37]>sp cvlan-cos-preservation-mode set spid 1 mode enable
```

The following command disables C-VLAN CoS preservation for Service Point 1 on Service 37:

```
service[37]>sp cvlan-cos-preservation-mode set spid 1 mode disable
```

Configuring C-VLAN Preservation (CLI)

To configure VLAN preservation for C-VLAN-tagged frames, go to service view for the service and enter the following command:

```
service[SID]>sp cvlan-preservation-mode set spid <sp-id> mode <c-
vlan preservation mode>
```

Table 95 C-VLAN Preservation CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
c-vlan preservation mode	Variable	enable disable	<p>Determines whether the original C-VLAN ID is preserved or restored for frames egressing from the service point.</p> <p>enable - The C-VLAN ID of frames egressing the service point is the same as the C-VLAN ID when the frame entered the service.</p> <p>disable - The C-VLAN ID of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking (see Configuring Marking (CLI)).</p>

The following command enables C-VLAN preservation for Service Point 1 on Service 37:

```
service[37]>sp cvlan-preservation-mode set spid 1 mode enable
```

The following command disables C-VLAN preservation for Service Point 1 on Service 37:

```
service[37]>sp cvlan-preservation-mode set spid 1 mode disable
```

Configuring S-VLAN CoS Preservation (CLI)

To configure CoS preservation for S-VLAN-tagged frames, go to service view for the service and enter the following command:

```
service[SID]>sp svlan-cos-preservation-mode set spid <sp-id> mode <svlan cos preservation mode>
```


Table 96 S-VLAN CoS Preservation CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
s-vlan cos preservation mode	Variable	enable disable	Select enable or disable to determine whether the original S-VLAN CoS value is preserved or restored for frames egressing the service point. enable - the S-VLAN CoS value of frames egressing the service point is the same as the value when the frame entered the service. disable - the S-VLAN CoS value of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking (see Configuring Marking (CLI)).

The following command enables S-VLAN CoS preservation for Service Point 1 on Service 37:

```
service[37]>sp svlan-cos-preservation-mode set spid 1 mode enable
```

The following command disables S-VLAN CoS preservation for Service Point 1 on Service 37:

```
service[37]>sp svlan-cos-preservation-mode set spid 1 mode disable
```

Configuring Service Bundles (CLI)

You can use service bundles to personalize common sets of egress queue attributes that can be applied to multiple service points. In this version only one service bundle is supported.

To assign a service point to a service bundle, go to service view for the service and enter the following command:

```
service[SID]>sp egress-service-bundle set spid 1 service-bundle-id  
<service-bundle-id>
```

Table 97 Service Bundle CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle assigned to the service point.

The following command assigns Service Bundle 1 to Service Point 1 in Service 37.

```
service[37]>sp egress-service-bundle set spid 1 service-bundle-id 1
```

Attaching a VLAN Bundle to a Service Point (CLI)

For service points with an interface type of bundle-C-tag or bundle-S-tag, you must classify a group of VLANs (VLAN Bundle) to the service point.

To classify a VLAN Bundle to a bundle-c-tag or bundle s-tag service point, go to service view for the service and enter the following command:

```
service[SIP]>sp bundle cvlan attach spid <sp-id> vlan <vlan> to-vlan <to-vlan>
```

To remove a VLAN Bundle from a bundle-c-tag or bundle-s-tag service point, go to service view for the service and enter the following command:

```
service[SIP]>sp bundle cvlan remove spid <sp-id> vlan <vlan> to-vlan <to-vlan>
```

To remove untagged frames from a bundle-c-tag or bundle s-tag service point, go to service view for the service and enter the following command:

```
service[SIP]>sp bundle remove untagged spid <sp-id>
```

To display a service point's attributes, including the VLANs classified to a bundle service point, go to service view for the service to which the service point belongs and enter the following command:

```
service[SID]>sp service-point-info show spid <sp-id>
```

Table 98 VLAN Bundle to Service Point CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
vlan	Number	1-4094 (except 4092, which is reserved for the default management service)	The C-VLAN at the beginning of the range of the VLAN Bundle.
to-vlan	Number	1-4094 (except 4092, which is reserved for the default management service)	The C-VLAN at the end of the range of the VLAN Bundle.

The following command classifies C-VLANs 100 through 200 to Service Point 1 in Service 37:

```
service[37]>sp bundle cvlan attach spid 1 vlan 100 to-vlan 200
```

The following command removes C-VLANs 100 through 200 from Service Point 1 in Service 37:

```
service[37]>sp bundle cvlan remove spid 1 vlan 100 to-vlan 200
```

Displaying Service Point Attributes (CLI)

To display a service point's attributes, go to service view for the service to which the service point belongs and enter the following command:

```
service[SID]>sp service-point-info show spid <sp-id>
```

Table 99 Display Service Point Attributes CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.

The following command displays the attributes of Service Point 1 in Service 37:

```
service[37]>sp service-point-info show spid 1
```

Deleting a Service Point (CLI)

You can only delete a service point if no VLAN bundles are attached to the service point. This is only relevant if the interface type of the service point is bundle-c-tag or bundle-s-tag. For more information, refer to [Attaching a VLAN Bundle to a Service Point \(CLI\)](#).

To delete a service point from a service, go to service view for the service and enter the following command:

```
service[SID]>sp delete spid <sp-id>
```

Table 100 Delete Service Point Attributes CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.

The following command deletes Service Point 10 from Service 37:

```
service[37]>sp delete spid 10
```

Defining the MAC Address Forwarding Table for a Service (CLI)

This section includes:

- [MAC Address Forwarding Table Overview \(CLI\)](#)
- [Setting the Maximum Size of the MAC Address Forwarding Table \(CLI\)](#)
- [Setting the MAC Address Forwarding Table Aging Time \(CLI\)](#)
- [Adding a Static MAC Address to the Forwarding Table \(CLI\)](#)
- [Displaying the MAC Address Forwarding Table \(CLI\)](#)
- [Flushing the MAC Address Forwarding Table \(CLI\)](#)
- [Enabling MAC Address Learning on a Service Point \(CLI\)](#)

MAC Address Forwarding Table Overview (CLI)

PTP 850 performs MAC address learning per service. PTP 850 can learn up to 131,072 MAC addresses.

If necessary due to security issues or resource limitations, you can limit the size of the MAC address forwarding table. The maximum size of the MAC address forwarding table is configurable per service in granularity of 16 entries.

When a frame arrives via a specific service point, the learning mechanism checks the MAC address forwarding table for the service to which the service point belongs to determine whether that MAC address is known to the service. If the MAC address is not found, the learning mechanism adds it to the table.

In parallel with the learning process, the forwarding mechanism searches the service’s MAC forwarding table for the frame’s MAC address. If a match is found, the frame is forwarded to the service point associated with the MAC address. If not, the frame is flooded to all service points in the service.

Setting the Maximum Size of the MAC Address Forwarding Table (CLI)

To limit the size of the MAC address forwarding table for a specific service, go to service view for the service and enter the following command:

```
service[SID]>service mac-limit-value set <mac limit>
```

Table 101 MAC Address Forwarding Table Maximum Size CLI Parameters

Parameter	Input Type	Permitted Values	Description
mac limit	Number	16 to 131,072, in multiples of 16	The maximum MAC address table size for the service. This maximum only applies to dynamic, not static, MAC address table entries.

The following command limits the number of dynamic MAC address forwarding table entries for Service 10 to 128:

```
service[10]>service mac-limit-value set 128
```

Setting the MAC Address Forwarding Table Aging Time (CLI)

You can configure a global aging time for dynamic entries in the MAC address forwarding table. Once this aging time expires for a specific table entry, the entry is erased from the table.

To set the global aging time for the MAC address forwarding table, enter the following command:

```
root> ethernet service learning-ageing-time set time <time>
```

To display the global aging time for the MAC address forwarding table, enter the following command:

```
root> ethernet service learning-ageing-time show
```

Table 102 MAC Address Forwarding Table Aging Time CLI Parameters

Parameter	Input Type	Permitted Values	Description
time	Number	15 - 3825	The global aging time for the MAC address forwarding table, in seconds.

The following command sets the global aging time to 2500 seconds:

```
root> ethernet service learning-ageing-time set time 2500
```

Adding a Static MAC Address to the Forwarding Table (CLI)

You can add static entries to the MAC forwarding table. The global aging timer does not apply to static entries, and they are not counted with respect to the maximum size of the MAC address forwarding table. It is the responsibility of the user not to use all the entries in the table if the user also wants to utilize dynamic MAC address learning.

To add a static MAC address to the MAC address forwarding table, go to service view for the service to which you want to add the MAC address and enter the following command:

```
service[SID]>service mac-learning-table set-static-mac <static mac> spid <sp-id>
```

To delete a static MAC address from the MAC address forwarding table, go to service view for the service from which you want to delete the MAC address and enter the following command:

```
service[SID]>service mac-learning-table del-static-mac <static mac> spid <sp-id>
```

Table 103 Adding Static Address to MAC Address Forwarding Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
static mac	Six groups of two hexadecimal digits		The MAC address.
sp-id	Number	1-32	The Service Point ID of the service point associated with the MAC address.

The following command adds MAC address 00:11:22:33:44:55 to the MAC address forwarding table for Service 10, and associates the MAC address with Service Point ID 1 on Service 10:

```
service[10]>service mac-learning-table set-static-
mac 00:11:22:33:44:55 spid 1
```

The following command deletes MAC address 00:11:22:33:44:55, associated with Service Point 1, from the MAC address forwarding table for Service 10:

```
service[10]>service mac-learning-table del-static-
mac 00:11:22:33:44:55 spid 1
```

Displaying the MAC Address Forwarding Table (CLI)

You can display the MAC address forwarding table for an interface, a service, or for the entire unit.

To display the MAC address forwarding table for a service, go to service view for the service and enter the following command:

```
service[SID]>service mac-learning-table show
```

To display the MAC address forwarding table for an interface, go to interface view for the interface and enter the following command:

```
eth type xxx[x/x]>mac-learning-table show
```

To display the MAC address forwarding table for the entire unit, enter the following command:

```
root> ethernet generalcfg mac-learning-table show
```

Example

To display the MAC address forwarding table for GbE 1, enter the following commands:

```
root> ethernet interfaces eth slot 1 port 1
eth type eth[1/1]>mac-learning-table show
```

Flushing the MAC Address Forwarding Table (CLI)

You can perform a global flush on the MAC address forwarding table. This erases all dynamic entries for all services. Static entries are not erased.



Note

The ability to flush the MAC address forwarding table per-service and per-interface is planned for future release.

To perform a global flush of the MAC address forwarding table, enter the following command:

```
root> ethernet service mac-learning-table set global-flush
```

Enabling MAC Address Learning on a Service Point (CLI)

You can enable or disable MAC address learning for specific service points. By default, MAC learning is enabled.

To enable or disable MAC address learning for a service point, go to service view for the service and enter the following command:

```
service[SID]>sp learning-state set spid <sp-id> learning <learning>
```

Table 104 Enabling MAC Address Learning CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32	The Service Point ID of the service point associated with the MAC address.
learning	Variable	Enable disable	Select enable or disable to enable or disable MAC address learning for frames that ingress via the service point. When enabled, the service point learns the source MAC addresses of incoming frames and adds them to the MAC address forwarding table.

The following command enables MAC address learning for Service Point 1 on Service 37:

```
service[37]>sp learning-state set spid 1 learning enable
```

The following command disables MAC address learning for Service Point 1 on Service 37:

```
service[37]>sp learning-state set spid 1 learning disable
```

Setting the MRU Size and the S-VLAN Ethertype (CLI)

The following parameters are configured globally for the PTP 850 switch:

- S- VLAN Ethertype – Defines the ethertype recognized by the system as the S-VLAN ethertype.
- C-VLAN Ethertype – Defines the ethertype recognized by the system as the C-VLAN ethertype. PTP 850 supports 0x8100 as the C-VLAN ethertype.
- MRU – The maximum segment size defines the maximum receive unit (MRU) capability and the maximum transmit capability (MTU) of the system. You can configure a global MRU for the system.



Note

The MTU is determined by the receiving frame and editing operation on the frame.
This section includes:

- [Configuring the S-VLAN Ethertype \(CLI\)](#)
- [Configuring the C-VLAN Ethertype \(CLI\)](#)
- [Configuring the MRU \(CLI\)](#)

Configuring the S-VLAN Ethertype (CLI)

To configure the S-VLAN Ethertype, enter the following command in root view:

```
root> ethernet generalcfg ethertype set svlan-value <ethertype>
```

To display the system S-VLAN ethertype, enter the following command in root view:

```
root> ethernet generalcfg ethertype show svlan
```

Table 105 Configure S-VLAN Ethertype CLI Parameters

Parameter	Input Type	Permitted Values	Description
ethertype	Hexadecimal	0x8100	Defines the ethertype recognized by the system as the S-VLAN ethertype.
		0x88a8	
		0x9100	
		0x9200	

Example

For example, the following command sets the system S-VLAN ethertype to 0x88a8:

```
root> ethernet generalcfg ethertype set svlan-value 0x88a8
```


Configuring the C-VLAN Ethertype (CLI)

The system C-VLAN Ethertype is set by the system as 0x8100.

To display the system C-VLAN ethertype, enter the following command in root view:

```
root> ethernet generalcfg ethertype show cvlan
```

Configuring the MRU (CLI)

To define the global size (in bytes) of the Maximum Receive Unit (MRU), enter the following command in root view:

```
root> ethernet generalcfg mru set size <size>
```

To display the system MRU, enter the following command in root view:

```
root> ethernet generalcfg mru show
```

Table 106 Configure MRU CLI Parameters

Parameter	Input Type	Permitted Values	Description
size	Number	64 to 9612	Defines the global size (in bytes) of the Maximum Receive Unit (MRU). Frames that are larger than the global MRU will be discarded.

Example

For example, the following command sets the system MRU to 9612:

```
root> ethernet generalcfg mru set size 9612
```

Configuring Ethernet Interfaces (CLI)

Related Topics:

- [Enabling the Interfaces \(CLI\)](#)
- [Performing Ethernet Loopback \(CLI\)](#)
- [Configuring Ethernet Services \(CLI\)](#)
- [Quality of Service \(QoS\) \(CLI\)](#)

P-20's switching fabric distinguishes between physical interfaces and logical interfaces. Physical and logical interfaces serve different purposes in the switching fabric. In some cases, a physical interface corresponds to a logical interface on a one-to-one basis. For some features, such as LAG, a group of physical interfaces can be joined into a single logical interface.

The basic interface characteristics, such as media type, port speed, duplex, and auto-negotiation, are configured on the physical interface level. Ethernet services, QoS, and OAM characteristics are configured on the logical interface level.



Note

You cannot change the configuration of the Management interface. By default, the Management interface has the following configuration:

- Auto negotiation ON
- Full Duplex
- RJ45 - 100Mbps

This section includes:

- [Entering Interface View \(CLI\)](#)
- [Displaying the Operational State of the Interfaces in the Unit \(CLI\)](#)
- [Viewing Interface Attributes \(CLI\)](#)
- [Configuring an Interface’s Media Type \(CLI\)](#)
- [Configuring an Interface’s Speed and Duplex State \(CLI\)](#)
- [Configuring an Interface’s Auto Negotiation State \(CLI\)](#)
- [Configuring an Interface’s IFG \(CLI\)](#)
- [Configuring an Interface’s Preamble \(CLI\)](#)
- [Adding a Description for the Interface \(CLI\)](#)

Entering Interface View (CLI)

To view interface details and set the interface’s parameters, you must enter the interface’s view level in the CLI. Use the following command to enter an Ethernet interface’s view level:

```
root> ethernet interfaces eth slot <slot> port <port>
```

Use the following command to enter the radio interface’s view level:

```
root> ethernet interfaces radio slot <slot> port <port>
```

Use the following command to enter the view level of a group, such as a Multi-Carrier ABC group, an HSB protection group, or a LAG:

```
root> ethernet interfaces group <group>
```

Table 107 Entering Interface View CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	Ethernet: 1-7 Radio: 1	The port number of the interface.



Note

In release 10.6, only Ethernet 7 is supported, along with the radio interface. In release 10.9, Ethernet Slot 1, Ports 4 through 7 are also supported.

The QSFP port (Port 4), is displayed as follows.

- In a 4x1/10G configuration the QSFP port can provide four Ethernet interfaces: Eth3, Eth4, Eth 5, and Eth6. In this configuration, a QSFP transceiver is attached to the QSFP port, and an MPO-MPO cable is connected between the transceiver and a splitter on the other side of the link. The splitter splits the traffic between four Ethernet cables connecting the splitter to the customer equipment.

The following command enters interface view for Ethernet 7:

```
root> ethernet interfaces eth slot 1 port 7
```

The following prompt appears:

```
eth type eth [1/7]>
```

The following command enters interface view for the radio interface:

```
root> ethernet interfaces radio slot 1 port 1
```

The following prompt appears:

```
radio [1/1]>
```



Note

For simplicity, the examples in the following sections show the prompt for an Ethernet interface.

Displaying the Operational State of the Interfaces in the Unit (CLI)

To display a list of all interfaces in the unit and their operational states, enter the following command:

```
root> platform if-manager show interfaces
```

The following is a sample output of this command:

root>platform if-manager show interfaces													
Interface type	slot	port	Type	Description	Admin status	Operational status	Secondary operational-status	Last change	Connector Present	Speed (bps)	MTU	MAC address	Minimum Bandwidth admin
ethernet	1	1	6	Ethernet	down	down	RX LOS/LOC Interface not ready IF admin disabled	01-01-1970,00:00:01	false	10000000000	2000	0:a:25:0:0:c	disable
ethernet	1	2	6	Ethernet	down	down	RX LOS/LOC Interface not ready IF admin disabled	01-01-1970,00:00:01	false	25000000000	2000	0:a:25:0:0:d	disable
ethernet	1	3	6	Ethernet	down	down	RX LOS/LOC Interface not ready IF admin disabled	01-01-1970,00:00:01	false	10000000000	2000	0:a:25:0:0:4	disable
ethernet	1	4	6	Ethernet	down	down	RX LOS/LOC Interface not ready IF admin disabled	01-01-1970,00:00:01	false	10000000000	2000	0:a:25:0:0:5	disable
ethernet	1	5	6	Ethernet	down	down	RX LOS/LOC Interface not ready IF admin disabled	01-01-1970,00:00:01	false	10000000000	2000	0:a:25:0:0:6	disable
ethernet	1	6	6	Ethernet	down	down	RX LOS/LOC Interface not ready IF admin disabled	01-01-1970,00:00:01	false	10000000000	2000	0:a:25:0:0:7	disable
ethernet	1	7	6	Ethernet	up	down	RX LOS/LOC	01-01-1970,00:00:01	false	10000000000	2000	0:a:25:0:0:26	disable
radio	1	1	1	Radionet	up	down	Rx LOF/LOP Rx only	01-01-1970,00:00:01	false	13370000000	2000	0:a:25:0:0:c	disable
management	1	1	6	Management	up	up	Clear	02-04-2000,06:50:03	false	1000000000	1632	0:0:0:0:0:0	disable

Viewing Interface Attributes (CLI)

To display an interface's attributes, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>summary show
```

To display an interface's current operational state (up or down), go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>operational state show
```

The following command shows the attributes of Eth 7:

```
eth type eth [1/7]>summary show
```

The following command shows the operational state of Eth 7:

```
eth type eth [1/7]>operational state show
```

Configuring an Interface's Media Type (CLI)

The Media Type attribute defines the physical interface Layer 1 media type. Permitted values are RJ-45 and SFP.



Note

In release 10.6, only Ethernet Slot 1, Port 7 and Radio Slot 1, Port 1 are supported. Ethernet 7 is an SFP+ interface. In release 10.9, Ethernet Slot 1, Ports 3 through 7 are supported.

To configure an Ethernet interface's Media Type, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>media-type state set <media type>
```

Table 108 Interface Media Type CLI Parameters

Parameter	Input Type	Permitted Values	Description
media type	Variable	rj45 sfp	Select the physical interface layer 1 media type: RJ45 - An electrical (RJ-45) Ethernet interface. SFP - An optical (SFP) Ethernet interface.

Configuring an Interface's Speed and Duplex State (CLI)

To configure an Ethernet interface's maximum speed and duplex state, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>speed-and-duplex state set <speed-and-duplex state>
```

Table 109 Interface Speed and Duplex State CLI Parameters

Parameter	Input Type	Permitted Values	Description
speed-and-duplex state	Variable	'10hd' '10fd' '100hd' '100fd' '1000fd' '10000fd'	This parameter sets the maximum speed and the duplex state of the interface. For RJ-45 interfaces, any of the permitted values except 10000fd can be configured. For SFP interfaces, only '1000fd' is supported. Note: In release 10.6, only Ethernet 7 (SFP+) is supported. In release 10.9, Ethernet Slot 1, Ports 4 through 7 are also supported.

**Note**

To use an SFP+ interface in 10G mode, the third-party switch must be running Pause Frame Flow Control, as defined in IEEE 802.3x. It is also recommended to configure shapers on the third-party switch so as to limit the packet flow from the switch to the PTP 850E unit to 2.5 Gbps.

After changing the speed of an SFP+ interface to or from 10000fd, you must reset the unit in order for the change to take effect.

Configuring an Interface's Auto Negotiation State (CLI)

To configure an Ethernet interface's auto-negotiation state, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>autoneg state set <autoneg state>
```

Table 110 Interface Auto Negotiation State CLI Parameters

Parameter	Input Type	Permitted Values	Description
autoneg state	Variable	On off	Enables or disables auto-negotiation on the physical interface.

The following command enables auto negotiation for GbE 2:

```
eth type eth [1/2]>autoneg state set on
```

Configuring an Interface's IFG (CLI)

The IFG attribute represents the physical port Inter-frame gap. Although you can modify the IFG field length, it is strongly recommended not to modify the default value of 12 bytes without a thorough understanding of how the modification will impact traffic.

To configure an Ethernet interface's IFG, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>ifg set <ifg>
```

Table 111 Interface IFG CLI Parameters

Parameter	Input Type	Permitted Values	Description
ifg	Number	6 - 15	Sets the interface's IFG (in bytes).

The following command sets the ifg for GbE 1 to 12:

```
eth type eth [1/1]>ifg set 12
```

The following displays the currently configured ifg for GbE 1:

```
eth type eth [1/1]>ifg get
```

Configuring an Interface's Preamble (CLI)

Although you can modify an Ethernet interface's preamble, it is strongly recommended not to modify the default value of 8 bytes without a thorough understanding of how the modification will impact traffic.

To configure an Ethernet interface's preamble, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>preamble set <preamble>
```

Table 112 Interface Preamble CLI Parameters

Parameter	Input Type	Permitted Values	Description
preamble	Number	6 - 15	Sets the interface's preamble (in bytes).

The following command sets the preamble for GbE 1 to 8:

```
eth type eth [1/1]>preamble set 8
```

The following command displays the current preamble for GbE 1:

```
eth type eth [1/1]>preamble get
```

Adding a Description for the Interface (CLI)

You can add a text description for an interface. To add a description, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>description set <description>
```

To delete a description, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>description delete
```

To display an interface's description, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>description show
```

Table 113 Interface Description CLI Parameters

Parameter	Input Type	Permitted Values	Description
description	Text String	Up to 40 characters	Adds a text description to the interface.

The following command adds the description “Line” to GbE 1:

```
eth type eth [1/1]>description set Line
```

Configuring Automatic State Propagation and Link Loss Forwarding (CLI)

Automatic state propagation enables propagation of radio failures back to the Ethernet port. You can also configure Automatic State Propagation to close the Ethernet port based on a radio failure at the remote carrier.

Automatic state propagation is configured as pairs of interfaces. Each interface pair includes one Monitored Interface and one Controlled Interface.

Automatic state propagation is configured as pairs of interfaces. Each interface pair includes one Monitored Interface and one Controlled Interface. You can create multiple pairs using the same Monitored Interface and multiple Controlled Interfaces.

The Monitored Interface is a radio interface, a radio protection, or Multi-Carrier ABC group. The Controlled Interface is an Ethernet interface or LAG. An Ethernet interface can only be assigned to one Monitored interface.

Each Controlled Interface is assigned an LLF ID. If **ASP trigger by remote fault** is enabled on the remote side of the link, the ASP state of the Controlled Interface is propagated to the Controlled Interface with the same LLF ID at the remote side of the link. This means if ASP is triggered locally, it is propagated to the remote side of the link, but only to Controlled Interfaces with LLF IDs that match the LLF IDs of the affected Controlled Interfaces on the local side of the link.



Note

LLF requires an activation key. Without this activation key, only LLF ID 1 is available. See [Configuring the Activation Key \(CLI\)](#).

The following events in the Monitored Interface trigger ASP:

- Radio LOF
- Radio Excessive BER
- Remote Radio LOF
- Remote Excessive BER
- Remove LOC

The user can also configure the ASP pair so that Radio LOF, Radio Excessive BER, or loss of the Ethernet connection at the remote side of the link will also trigger ASP.

In addition, ASP is triggered if the Controlled Interface is a LAG, and the physical interfaces that belong to the LAG are set to **Admin = Down** in the Interface Manager.

When a triggering event takes place:

- If the Controlled Interface is an electrical GbE port, the port is closed.
- If the Controlled Interface is an optical GbE port, the port is muted.

The Controlled Interface remains closed or muted until all triggering events are cleared.

In addition, when a local triggering event takes place, the ASP mechanism sends an indication to the remote side of the link. Even when no triggering event has taken place, the ASP mechanism sends periodic update messages indicating that no triggering event has taken place.

A trigger delay time can be configured, so that when a triggering event takes place, the ASP mechanism does not propagate the event until this delay time has elapsed. A trigger delay from 0 to 10,000 ms can be set per LLD ID.

**Note**

It is recommended to configure both ends of the link to the same Automatic State Propagation configuration.

To configure propagation of a radio interface failure to an Ethernet port, use the following command:

```
root> auto-state-propagation add eth-port-to-radio eth-slot 1 eth-port
<eth-port> radio-slot 1 radio-port 1 llf-id <llf-id>
```

To enable automatic state propagation on an Ethernet port, determine whether remote interface failures are also propagated, enable ASP Management Safe (CSF) mode (optional), and set a trigger delay (optional), use the following command:

```
root> auto-state-propagation configure eth-port eth-slot 1 eth-port <eth-
port> asp-admin <asp-admin> remote-fault-trigger-admin <remote-fault-
trigger-admin> csf-mode-admin <csf-mode-admin> trigger-delay <trigger-
delay> llf-id <llf-id>
```

**Note**

In this command, the llf-id command is used optionally to change the LLF ID of the Ethernet port.

To delete automatic state propagation on an Ethernet port, use the following command:

```
root> auto-state-propagation delete eth-port eth-slot 1 eth-port <eth-
port>
```

To display all automatic state propagation configurations on the unit, use the following command:

```
root> auto-state-propagation show-config all
```

To display the automatic state propagation configuration for a specific Ethernet port, use the following command:

```
root> auto-state-propagation show-config eth-port eth-slot <eth-slot>
eth-port <eth-port>
```

Table 114: Automatic State Propagation to an Ethernet Port CLI Parameters

Parameter	Input Type	Permitted Values	Description
eth-port	Number	3-7	The interface to which you want to propagate faults from the selected radio or group.

Parameter	Input Type	Permitted Values	Description
llf-id	Number	1-31	An ID for Link Loss Forwarding (LLF). When remote-fault-trigger-admin is set to enable , ASP events at the other side of the link are propagated to Controlled Interfaces with LLF IDs that match the LLF IDs of affected Controlled Interfaces at the other side of the link. LLF IDs are unique per Monitored Interface. That is, if LLF ID 1 has been used for a Controlled Interface that is grouped with radio interface 1, that ID cannot be used again for another Controlled Interface grouped with radio interface 1. However, it <i>can</i> be used for Controlled Interface grouped with radio interface 2.
asp-admin	Variable	enable disable	Enables or disables automatic state propagation on the Ethernet interface.
remote-fault-trigger-admin	Variable	enable disable	Determines whether faults on the remote radio interface or group are propagated to the local Ethernet interface.
csf-mode-admin	Variable	enable disable	Enables or disables ASP Management Safe (CSF) mode. In ASP Management Safe mode, the ASP mechanism does not physically shut down the Controlled Interface when ASP is triggered. Instead, the ASP mechanism sends a failure indication message. This message is used to propagate the failure indication to external equipment.
trigger-delay	Number	0-10000	Sets a trigger delay time, in milliseconds. When a triggering event takes place, the ASP mechanism does not propagate the event until this delay time has elapsed. By default, the trigger-delay is 0 (no delay time). In XPIC configurations, it is recommended to configure a trigger-delay of 100 ms.

The following commands configure and enable automatic state propagation to propagate faults from radio interface 1 to Ethernet ports 1 and 2, and from radio interface 2 to Ethernet port 3. CSF mode is disabled. Faults on the remote carrier are propagated to the local Ethernet ports as follows:

- A failure on the remote side of the link is propagated to any of local Ethernet ports 3 or 4 that share an LLF ID with an Ethernet interface in an ASP pair with the remote radio.
- The trigger delay for Ethernet port 3 is 100 ms. There is no trigger delay for Ethernet port 4.

```
root> auto-state-propagation add eth-port-to-radio eth-slot 1 eth-port 1
radio-slot 2 radio-port 1 llf-id 1

root> auto-state-propagation add eth-port-to-radio eth-slot 1 eth-port 2
radio-slot 2 radio-port 2 llf-id 2

root> auto-state-propagation configure eth-port eth-slot 1 eth-port 1
asp-admin enable remote-fault-trigger-admin enable csf-mode-admin disable
trigger-delay 100

root> auto-state-propagation configure eth-port eth-slot 1 eth-port 2
asp-admin enable remote-fault-trigger-admin enable csf-mode-admin disable
trigger-delay 5000

root> auto-state-propagation add eth-port-to-radio eth-slot 1 eth-port 3
radio-slot 1 radio-port 2 llf-id 1

root> auto-state-propagation configure eth-port eth-slot 1 eth-port 3
asp-admin enable remote-fault-trigger-admin enable csf-mode-admin disable
```

Viewing Ethernet PMs and Statistics (CLI)

PTP 850 stores and displays statistics in accordance with RMON and RMON2 standards. You can display various peak TX and RX rates (in seconds) and average TX and RX rates (in seconds), both in bytes and in packets, for each measured time interval. You can also display the number of seconds in the interval during which TX and RX rates exceeded the configured threshold.

This section includes:

- [Displaying RMON Statistics \(CLI\)](#)
- PTP 850E stores and displays statistics in accordance with RMON and RMON2 standards.

To display RMON statistics for a physical interface, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rmon statistics show clear-on-read <clear-on-read>
layer-1 <layer-1>
```

Table 113: Interface Statistics (RMON) CLI Parameters

Parameter	Input Type	Permitted Values	Description
clear-on-read	Boolean	yes no	If you enter yes , the statistics are cleared once you display them.
layer-1	Boolean	yes no	yes – Statistics are represented as Layer 1 statistics, including preamble and IFG. no – Statistics are represented as Layer 2 statistics.

The following commands enter interface view for Eth 7, and clear the statistics after displaying them.

```
root> ethernet interfaces eth slot 1 port 7
eth type eth [1/7]>rmon statistics show clear-on-read yes layer-1 yes
```

The following commands enter interface view for radio carrier 1, and display statistics for the interface, without clearing the statistics.

```
root> ethernet interfaces radio slot 1 port 1
eth type radio[1/1]>rmon statistics show clear-on-read no layer-1 no
```

- [Configuring Ethernet Port PMs and PM Thresholds \(CLI\)](#)
- [Displaying Ethernet Port PMs \(CLI\)](#)
- [Clearing Ethernet Port PMs \(CLI\)](#)

Displaying RMON Statistics (CLI)

PTP 850E stores and displays statistics in accordance with RMON and RMON2 standards.

To display RMON statistics for a physical interface, go to interface view for the interface and enter the following command:

To display RMON statistics for a physical interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rmon statistics show clear-on-read <clear-on-read>
layer-1 <layer-1>
```

Table 115 RMON Statistics CLI Parameters

Parameter	Input Type	Permitted Values	Description
clear-on-read	Boolean	yes no	If you enter yes, the statistics are cleared once you display them.
layer-1	Boolean	yes no	yes – Statistics are represented as Layer 1 statistics, including preamble and IFG. no – Statistics are represented as Layer 2 statistics.

The following commands bring you to interface view for Ethernet port 1, and clears the statistics after displaying them.

```
root> ethernet interfaces eth slot 1 port 1
eth type eth [1/1]>rmon statistics show clear-on-read yes layer-1 yes
```

The following commands bring you to interface view for radio interface 2, without clearing the statistics.

```
root> ethernet interfaces radio slot 2 port 1
eth type radio[2/2]>rmon statistics show clear-on-read no layer-1 no
```

Configuring Ethernet Port PMs and PM Thresholds (CLI)

To enable the gathering of PMs for an Ethernet interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm set admin <enable|disable>
```

You can configure thresholds and display the number of seconds these thresholds were exceeded during a specified interval.

To configure interface PM thresholds, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm set thresholds rx-layer1-rate-threshold <0-4294967295>
tx-layer1-rate-threshold <0-4294967295>
```

To display whether or not PM gathering is enabled for an Ethernet interface, as well as the configured thresholds, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show configuration
```

Table 116 Port PM Thresholds CLI Parameters

Parameter	Input Type	Permitted Values	Description
rx-layer1-rate-threshold	Number	0-4294967295	The exceed threshold for port RX PMs, in bytes per second.

Parameter	Input Type	Permitted Values	Description
tx-layer1-rate-threshold	Number	0-4294967295	The exceed threshold for port TX PMs, in bytes per second.

The following commands bring you to interface view for Ethernet port 1, enable PM gathering, and set the thresholds for RX and TX PMs at 850,000,000 bytes per second:

```
root> ethernet interfaces eth slot 1 port 1
eth type eth [1/1]>pm set admin enable
eth type eth [1/1]>pm set thresholds rx-layer1-rate-threshold 850000000
tx-layer1-rate-threshold 850000000
```

Displaying Ethernet Port PMs (CLI)



Note

The port PM results may be several pages long. Remember:
To view the next results page, press the space bar.
To end the list and return to the most recent prompt, press the letter **q**.

To display RX packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-packets interval 15min
```

To display RX packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-packets interval 24hr
```

To display RX broadcast packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bcast-packets interval 15min
```

To display RX broadcast packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bcast-packets interval 24hr
```

To display RX multicast packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-mcast-packets interval 15min
```

To display RX multicast packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-mcast-packets interval 24hr
```

To display Layer 1 RX PMs, in bytes per second, in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bytes-layer1 interval 15min
```

To display Layer 1 RX PMs, in bytes per second, in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bytes-layer1 interval 24hr
```

To display Layer 2 RX PMs, in bytes per second, in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bytes-layer2 interval 15min
```

To display Layer 2 RX PMs, in bytes per second, in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bytes-layer2 interval 24hr
```

To display TX packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-packets interval 15min
```

To display TX packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-packets interval 24hr
```

To display TX broadcast packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bcast-packets interval 15min
```

To display TX broadcast packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bcast-packets interval 24hr
```

To display TX multicast packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-mcast-packets interval 15min
```

To display TX multicast packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-mcast-packets interval 24hr
```

To display Layer 1 TX PMs, in bytes per second, in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bytes-layer1 interval 15min
```

To display Layer 1 TX PMs, in bytes per second, in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bytes-layer1 interval 24hr
```

To display Layer 2 TX PMs, in bytes per second, in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bytes-layer2 interval 15min
```

To display Layer 2 TX PMs, in bytes per second, in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bytes-layer2 interval 24hr
```

Table 117 Ethernet Port PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Invalid data flag	Indicates whether the values received during the measured interval are valid. An x in the column indicates that the values are not valid (for example, because of a power surge or power failure that occurred during the interval).
Peak RX Packets	The peak rate of RX packets per second for the measured time interval.
Average RX Packets	The average rate of RX packets per second for the measured time interval.
Peak RX Broadcast Packets	The peak rate of RX broadcast packets per second for the measured time interval.
Average RX Broadcast Packets	The average rate of RX broadcast packets per second for the measured time interval.
Peak RX Multicast Packets	The peak rate of RX multicast packets per second for the measured time interval.
Average RX Multicast Packets	The average rate of RX multicast packets per second for the measured time interval.
Peak RX Bytes in Layer1	The peak RX rate, in bytes per second, for the measured time interval (including preamble and IFG).
Average RX Bytes in Layer1	The average RX rate, in bytes per second, for the measured time interval (including preamble and IFG).
RX Bytes Layer1 Exceed Threshold (sec)	The number of seconds during the measured time interval that the RX rate exceeded the configured threshold.
Peak RX Bytes in Layer2	The peak RX rate, in bytes per second, for the measured time interval (excluding preamble and IFG).
Average RX Bytes in Layer2	The average RX rate, in bytes per second, for the measured time interval (excluding preamble and IFG).
Peak TX Packets	The peak rate of TX packets per second for the measured time interval.
Average TX Packets	The average rate of TX packets per second for the measured time interval.
Peak TX Broadcast Packets	The peak rate of TX broadcast packets per second for the measured time interval.
Average TX Broadcast Packets	The average rate of TX broadcast packets per second for the measured time interval.
Peak TX Multicast Packets	The peak rate of TX multicast packets per second for the measured time interval.

Parameter	Definition
Average TX Multicast Packets	The average rate of TX multicast packets per second for the measured time interval.
Peak TX Bytes in Layer1	The peak TX rate, in bytes per second, for the measured time interval (including preamble and IFG).
Average TX Bytes in Layer1	The average TX rate, in bytes per second, for the measured time interval (including preamble and IFG).
TX Bytes Layer1 Exceed Threshold (sec)	The number of seconds during the measured time interval that the TX rate exceeded the configured threshold.
Peak TX Bytes in Layer2	The peak TX rate, in bytes per second, for the measured time interval (excluding preamble and IFG).
Average TX Bytes in Layer2	The average TX rate, in bytes per second, for the measured time interval (excluding preamble and IFG).

Clearing Ethernet Port PMs (CLI)

To clear all PMs for an Ethernet interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm clear-all
```

Chapter 16: Quality of Service (QoS) (CLI)

This section includes:

- [Configuring Classification \(CLI\)](#)
- [Configuring Policers \(Rate Metering\) \(CLI\)](#)
- [Configuring Marking \(CLI\)](#)
- [Configuring WRED \(CLI\)](#)
- [Configuring Shapers \(CLI\)](#)
- [Configuring Scheduling \(CLI\)](#)
- [Displaying Egress Statistics \(CLI\)](#)

Configuring Classification (CLI)

This section includes:

- [Classification Overview \(CLI\)](#)
- [Configuring Ingress Path Classification on a Logical Interface \(CLI\)](#)
- [Configuring VLAN Classification and Override \(CLI\)](#)
- [Configuring 802.1p Classification \(CLI\)](#)
- [Configuring DSCP Classification \(CLI\)](#)
- [Configuring MPLS Classification \(CLI\)](#)
- [Configuring a Default CoS \(CLI\)](#)
- [Configuring Ingress Path Classification on a Service Point \(CLI\)](#)
- [Configuring Ingress Path Classification on a Service \(CLI\)](#)

Classification Overview (CLI)

PTP 850 supports a hierarchical classification mechanism. The classification mechanism examines incoming frames and determines their CoS and Color. The benefit of hierarchical classification is that it provides the ability to “zoom in” or “zoom out”, enabling classification at higher or lower levels of the hierarchy. The nature of each traffic stream defines which level of the hierarchical classifier to apply, or whether to use several levels of the classification hierarchy in parallel.

The hierarchical classifier consists of the following levels:

- Logical interface-level classification
- Service point-level classification
- Service level classification

Configuring Ingress Path Classification on a Logical Interface (CLI)

Logical interface-level classification enables you to configure classification on a single interface or on a number of interfaces grouped together, such as a LAG group.

The classifier at the logical interface level supports the following classification methods, listed from highest to lowest priority. A higher level classification method supersedes a lower level classification method:

- VLAN ID
- 802.1p bits.
- DSCP values.
- MPLS EXP field.
- Default CoS

PTP 850 performs the classification on each frame ingressing the system via the logical interface. Classification is performed step by step from the highest priority to the lowest priority classification method. Once a match is found, the classifier determines the CoS and Color decision for the frame for the logical interface-level.

For example, if the frame is an untagged IP Ethernet frame, a match will not be found until the third priority level (DSCP). The CoS and Color values defined for the frame's DSCP value will be applied to the frame.

You can disable some of these classification methods by configuring them as un-trusted. For example, if 802.1p classification is configured as un-trusted for a specific interface, the classification mechanism does not perform classification by UP bits. This is useful, for example, if classification is based on DSCP priority bits.

If no match is found at the logical interface level, the default CoS is applied to incoming frames at this level. In this case, the Color of the frame is assumed to be Green.

Configuring VLAN Classification and Override (CLI)

You can specify a specific CoS and Color for a specific VLAN ID. In the case of double-tagged frames, the match must be with the frame's outer VLAN. Permitted values are CoS 0 to 7 and Color Green or Yellow per VLAN ID. This is the highest classification priority on the logical interface level, and overrides any other classification criteria at the logical interface level.

To configure CoS and Color override based on VLAN ID, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>vlan-cos-override set outer-vlan-id <outer-vlan-id>
inner-vlan-id <inner-vlan-id> use-cos <use-cos> use-color <use-color>
```

To display configured VLAN-based CoS and Color override values, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>vlan-cos-override show outer-vlan-id <outer-vlan-id>
inner-vlan-id <inner-vlan-id>
```

To delete a set of VLAN-based CoS and Color override values, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>vlan-cos-override delete outer-vlan-id <outer-vlan-id>
inner-vlan-id <inner-vlan-id>
```

Table 118 VLAN Classification and Override CLI Parameters

Parameter	Input Type	Permitted Values	Description
outer-vlan-id	Number	1 – 4094 (except 4092, which is reserved for the default management service)	For double-tagged frames, the S-VLAN value mapped to the CoS and Color values defined in the command. For single-tagged frames, the VLAN value mapped to the CoS and Color values defined in the command.

Parameter	Input Type	Permitted Values	Description
inner-vlan-id	Number	1 – 4094 (except 4092, which is reserved for the default management service)	Optional. Include this parameter when you want to map double-tagged frames to specific CoS and Color values. When this parameter is included in the command, both the S-VLAN and the C-VLAN IDs must match the configured <code>outer-vlan-id</code> and <code>inner-vlan-id</code> values, respectively, in order for the defined CoS and Color values to be applied to the frame.
use-cos	Number	0 – 7	The CoS value applied to matching frames.
use-color	Variable	green yellow	The Color applied to matching frames.

The following command configures the classification mechanism on GbE 1 to override the CoS and Color values of frames with S-VLAN ID 10 and C-VLAN ID 30 with a CoS value of 6 and a Color value of Green:

```
eth type eth [1/1]>vlan-cos-override set outer-vlan-id 10 inner-vlan-id 30 use-cos 6 use-color green
```

The following command configures the classification mechanism on GbE 2 to override the CoS and Color values of frames with VLAN ID 20 with a CoS value of 5 and a Color value of Green:

```
eth type eth [1/2]>vlan-cos-override set outer-vlan-id 20 use-cos 5 use-color green
```

The following command displays the CoS and Color override values for frames that ingress on GbE 1, with S-VLAN ID 10 and C-VLAN ID 20:

```
eth type eth [1/1]>vlan-cos-override show outer-vlan-id 10 inner-vlan-id 20
```

The following command displays all CoS and Color override values for frames that ingress on GbE 2:

```
eth type eth [1/2]>vlan-cos-override show all
```

The following command deletes the VLAN to CoS and Color override mapping for frames that ingress on GbE 1, with S-VLAN ID 10 and C-VLAN ID 20:

```
eth type eth [1/1]>vlan-cos-override delete outer-vlan-id 10 inner-vlan-id 20
```

Configuring 802.1p Classification (CLI)

When 802.1p classification is set to Trust mode, the interface performs QoS and Color classification according to user-configurable tables for 802.1q UP bit (C-VLAN frames) or 802.1AD UP bit (S-VLAN frames) to CoS and Color classification.

This section includes:

- [Configuring Trust Mode for 802.1p Classification \(CLI\)](#)
- [Modifying the DSCP Classification Table \(CLI\)](#)

Configuring Trust Mode for 802.1p Classification (CLI)

To define the trust mode for 802.1p classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification set 802.1p <802.1p>
```



Note

If you change the trust mode for DSCP, the trust mode for MPLS is automatically changed to the same setting.

To display the trust mode for 802.1p classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification show 802.1p state
```

Table 119 802.1p Trust Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
802.1p	Variable	trust un-trust	<p>Enter the interface's trust mode for user priority (UP) bits:</p> <p>trust – The interface performs QoS and color classification according to UP and CFI/DEI bits according to user-configurable tables for 802.1q UP bits (C-VLAN frames) or 802.1AD UP bits (S-VLAN frames). VLAN UP bit classification has priority over DSCP and MPLS classification, so that if a match is found with the UP bit of the ingressing frame, DSCP values and MPLS bits are not considered.</p> <p>un-trust – The interface does not consider 802.1 UP bits during classification.</p>

The following command enables 802.1p trust mode for GbE 1:

```
eth type eth [1/1]>classification set 802.1p trust
```

The following command disables 802.1p trust mode for GbE 1:

```
eth type eth [1/1]>classification set 802.1p un-trust
```

Configuring DSCP Classification (CLI)

When DSCP classification is set to Trust mode, the interface performs QoS and Color classification according to a user-configurable DSCP to CoS and Color classification table. 802.1p classification has priority over DSCP Trust Mode, so that if a match is found on the 802.1p level, DSCP is not considered.

This section includes:

- [Configuring Trust Mode for DSCP Classification \(CLI\)](#)
- [Modifying the DSCP Classification Table \(CLI\)](#)

Configuring Trust Mode for DSCP Classification (CLI)

To define the trust mode for DSCP classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification set ip-dscp <ip-dscp>
```

To display the trust mode for DSCP classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification show 802.1p state
```

Table 120 Trust Mode for DSCP CLI Parameters

Parameter	Input Type	Permitted Values	Description
ip-dscp	Variable	trust un-trust	Select the interface's trust mode for DSCP classification: trust – The interface performs QoS and color classification according to a user-configurable table for DSCP to CoS and color classification. DSCP classification has priority over MPLS classification, so that if a match is found with the DSCP value of the ingressing frame, MPLS bits are not considered. un-trust – The interface does not consider DSCP during classification.

The following command enables DSCP trust mode for GbE 1:

```
eth type eth [1/1]>classification set ip-dscp trust
```

The following command disables DSCP trust mode for GbE 1:

```
eth type eth [1/1]>classification set ip-dscp un-trust
```

Modifying the DSCP Classification Table (CLI)

The following table shows the default values for the DSCP classification table.

Table 121 DSCP Classification Table Default Values

DSCP	DSCP (bin)	Description	CoS (Configurable)	Color (Configurable)
0 (default)	000000	BE (CS0)	0	Green
10	001010	AF11	1	Green
12	001100	AF12	1	Yellow
14	001110	AF13	1	Yellow
18	010010	AF21	2	Green
20	010100	AF22	2	Yellow
22	010110	AF23	2	Yellow

DSCP	DSCP (bin)	Description	CoS (Configurable)	Color (Configurable)
26	011010	AF31	3	Green
28	011100	AF32	3	Yellow
30	011110	AF33	3	Yellow
34	100010	AF41	4	Green
36	100100	AF42	4	Yellow
38	100110	AF43	4	Yellow
46	101110	EF	7	Green
8	001000	CS1	1	Green
16	010000	CS2	2	Green
24	011000	CS3	3	Green
32	100000	CS4	4	Green
40	101000	CS5	5	Green
48	110000	CS6	6	Green
56	111000	CS7	7	Green
51	110011	DSCP_51	6	Green
52	110100	DSCP_52	6	Green
54	110110	DSCP_54	6	Green
56	111000	CS7	7	Green

To modify the DSCP classification table, enter the following command:

```
root> ethernet qos dscp-mapping-tbl set dscp <dscp> cos <cos> color
<color>
```

To display the DSCP classification table, enter the following command:

```
root> ethernet qos dscp-mapping-tbl show
```


Table 122 Modify DSCP Classification Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
dscp	Number	Valid DSCP values. Refer to the DSCP column in the table above.	The DSCP value to be mapped.
cos	Number	0 – 7	The CoS assigned to frames with the designated DSCP value.
color	Variable	green yellow	The Color assigned to frames with the designated DSCP value.

Example

The following command maps frames with DSCP value of 10 to CoS 1 and Green color:

```
root> ethernet qos dscp-mapping-tbl set dscp 10 cos 1 color green
```

Configuring MPLS Classification (CLI)

When MPLS classification is set to Trust mode, the interface performs QoS and Color classification according to a user-configurable MPLS EXP bit to CoS and Color classification table. Both 802.1p and DSCP classification have priority over MPLS Trust Mode, so that if a match is found on either the 802.1p or DSCP levels, MPLS bits are not considered.

This section includes:

- [Configuring Trust Mode for MPLS Classification \(CLI\)](#)
- [Modifying the MPLS EXP Bit Classification Table \(CLI\)](#)

Configuring Trust Mode for MPLS Classification (CLI)

To define the trust mode for MPLS classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification set mpls <mpls>
```

**Note**

If you change the trust mode for MPLS, the trust mode for DSCP is automatically changed to the same setting.

To display the trust mode for MPLS classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification show mpls state
```

Table 123 Trust Mode for MPLS CLI Parameters

Parameter	Input Type	Permitted Values	Description
mpls	Variable	Trust un-trust	Select the interface's trust mode for MPLS bits: trust – The interface performs QoS and color classification according to a user-configurable table for MPLS EXP to CoS and color classification. un-trust – The interface does not consider MPLS bits during classification.

The following command enables MPLS trust mode for GbE 1:

```
eth type eth [1/1]>classification set mpls trust
```

The following command disables MPLS trust mode for GbE 1:

```
eth type eth [1/1]>classification set mpls un-trust
```

Modifying the MPLS EXP Bit Classification Table (CLI)

The following table shows the default values for the MPLS EXP bit classification table.

Table 124 MPLS EXP Bit Classification Table Default Values

MPLS EXP bits	CoS (Configurable)	Color (Configurable)
0	0	Yellow
1	1	Green
2	2	Yellow
3	3	Green
4	4	Yellow
5	5	Green
6	6	Green
7	7	Green

To modify the MPLS EXP bit classification table, enter the following command:

```
root> ethernet qos mpls-exp-bits-mapping-tbl set mpls-exp <mpls-exp> cos  
<cos> color <color>
```

To display the MPLS EXP bit classification table, enter the following command:

```
root> ethernet qos mpls-mapping-tbl show
```

Table 125 MPLS EXP Bit Classification Table Modification CLI Parameters

Parameter	Input Type	Permitted Values	Description
mpls-exp	Number	0 – 7	The MPLS EXP bit to be mapped.
cos	Number	0 – 7	The CoS assigned to frames with the designated MPLS EXP bit value.
color	Variable	green yellow	The Color assigned to frames with the designated MPLS EXP bit value.

The following command maps frames with MPLS EXP bit value of 4 to CoS 4 and Yellow color:

```
root> ethernet qos mpls-exp-bits-mapping-tbl set mpls-exp 4 cos 4 color
yellow
```

Configuring 802.1p Classification (CLI)

When 802.1p classification is set to Trust mode, the interface performs QoS and Color classification according to user-configurable tables for 802.1q UP bit (C-VLAN frames) or 802.1AD UP bit (S-VLAN frames) to CoS and Color classification.

This section includes:

- Configuring Trust Mode for 802.1p Classification (CLI)
- Modifying the C-VLAN 802.1 UP and CFI Bit Classification Table (CLI)
- Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table (CLI)

Configuring Trust Mode for 802.1p Classification (CLI)

To define the trust mode for 802.1p classification, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>classification set 802.1p <802.1p>
```

To display the trust mode for 802.1p classification, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>classification show 802.1p state
```

Table 126: 802.1p Trust Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
802.1p	Variable	trust un-trust	<p>Enter the interface's trust mode for user priority (UP) bits:</p> <ul style="list-style-type: none"> • trust – The interface performs QoS and color classification according to UP and CFI/DEI bits according to user-configurable tables for 802.1q UP bits (C-VLAN frames) or 802.1AD UP bits (S-VLAN frames). MPLS and DSCP classification have priority over 802.1p classification, so that if a match is found on the MPLS or DSCP level, 802.1p bits are not considered. • un-trust – The interface does not consider 802.1 UP bits during classification.

The following command enables 802.1p trust mode for Eth 7:

```
eth type eth [1/7]>classification set 802.1p trust
```

The following command disables 802.1p trust mode for GbE 1:

```
eth type eth [1/7]>classification set 802.1p un-trust
```

Modifying the C-VLAN 802.1 UP and CFI Bit Classification Table (CLI)

The following table shows the default values for the C-VLAN 802.1 UP and CFI bit classification table.

Table 127: C-VLAN 802.1 UP and CFI Bit Classification Table Default Values

802.1 UP	CFI	CoS (configurable)	Color (configurable)
0	0	0	Green
0	1	0	Yellow
1	0	1	Green
1	1	1	Yellow
2	0	2	Green
2	1	2	Yellow
3	0	3	Green
3	1	3	Yellow
4	0	4	Green
4	1	4	Yellow
5	0	5	Green
5	1	5	Yellow
6	0	6	Green
6	1	6	Yellow
7	0	7	Green
7	1	7	Yellow

To modify the C-VLAN 802.1 UP and CFI bit classification table, enter the following command:

```
root> ethernet qos 802.1q-up-bits-mapping-tbl set 802.1p <802.1p> cfi
<cfi> cos <cos> color <color>
```

To display the C-VLAN 802.1 UP and CFI bit classification table, enter the following command:

```
root> ethernet qos 802.1q-up-bits-mapping-tbl show
```

Table 128: C-VLAN 802.1 UP and CFI Bit Classification Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
802.1p	Number	0 – 7	The User Priority (UP) bit to be mapped.
cfi	Number	0 – 1	The CFI bit to be mapped.
cos	Number	0 – 7	The CoS assigned to frames with the designated UP and CFI.
color	Variable	Green yellow	The Color assigned to frames with the designated UP and CFI.

The following command maps frames with an 802.1p UP bit value of 1 and a CFI bit value of 0 to CoS 1 and Green color:

```
root> ethernet qos 802.1q-up-bits-mapping-tbl set 802.1p 1 cfi 0 cos 1
color green
```

Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table (CLI)

The following table shows the default values for the S-VLAN 802.1 UP and DEI bit classification table.

Table 129: S-VLAN 802.1 UP and DEI Bit Classification Table Default Values

802.1 UP	DEI	CoS (Configurable)	Color (Configurable)
0	0	0	Green
0	1	0	Yellow
1	0	1	Green
1	1	1	Yellow
2	0	2	Green
2	1	2	Yellow
3	0	3	Green
3	1	3	Yellow
4	0	4	Green
4	1	4	Yellow
5	0	5	Green
5	1	5	Yellow
6	0	6	Green
6	1	6	Yellow
7	0	7	Green
7	1	7	Yellow

To modify the S-VLAN 802.1 UP and DEI bit classification table, enter the following command:

```
root> ethernet qos 802.1ad-up-bits-mapping-tbl set 802.1p <802.1p> dei
<dei> cos <cos> color <color>
```

To display the S-VLAN 802.1 UP and CFI bit classification table, enter the following command:

```
root> ethernet qos 802.1ad-up-bits-mapping-tbl show
```

Table 130: S-VLAN 802.1 UP and DEI Bit Classification Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
802.1p	Number	0 – 7	The User Priority (UP) bit to be mapped.
dei	Number	0 - 1	The DEI bit to be mapped.

Parameter	Input Type	Permitted Values	Description
cos	Number	0 – 7	The CoS assigned to frames with the designated UP and CFI.
color	Variable	green yellow	The Color assigned to frames with the designated UP and CFI.

The following command maps frames with an 802.1ad UP bit value of 7 and a DEI bit value of 0 to CoS 7 and Green color:

```
root> ethernet qos 802.1ad-up-bits-mapping-tbl set 802.1p 7 dei 0 cos 7
color green
```

Configuring a Default CoS (CLI)

You can define a default CoS value for frames passing through the interface. This value can be overwritten on the service point and service level. The Color is assumed to be Green.

To define a default CoS value for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification set default-cos <default-cos>
```

To display the default CoS value for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification show default-cos
```

Table 131 Default CoS CLI Parameters

Parameter	Input Type	Permitted Values	Description
default-cos	Number	0 – 7	Enter the default CoS value for frames passing through the interface. This value can be overwritten on the service point and service level.

The following command sets the default CoS for GbE 1 as 7:

```
eth type eth [1/1]>classification set default-cos 7
```

Configuring Ingress Path Classification on a Service Point (CLI)

For instruction on configuring ingress path classification on a service point, see [CoS Preservation and Modification on a Service Point \(CLI\)](#).

Configuring Ingress Path Classification on a Service (CLI)

For instruction on configuring ingress path classification on a service, see [Configuring a Service's CoS Mode and Default CoS \(CLI\)](#).

Configuring Policers (Rate Metering) (CLI)

This section includes:

- [Overview of Rate Metering \(Policing\) \(CLI\)](#)
- [Configuring Rate Meter \(Policer\) Profiles \(CLI\)](#)
- [Displaying Rate Meter Profiles \(CLI\)](#)
- [Deleting a Rate Meter Profile \(CLI\)](#)
- [Attaching a Rate Meter \(Policer\) to an Interface \(CLI\)](#)
- [Configuring the Line Compensation Value for a Rate Meter \(Policer\) \(CLI\)](#)

Overview of Rate Metering (Policing) (CLI)

The PTP 850 switching fabric supports hierarchical policing on the logical interface level. You can define up to 250 rate meter (policer) profiles.



Note
Policing on the service point level, and the service point and CoS level, is planned for future release.

The PTP 850's policer mechanism is based on a dual leaky bucket mechanism (TrTCM). The policers can change a frame's color and CoS settings based on CIR/EIR + CBS/EBS, which makes the policer mechanism a key tool for implementing bandwidth profiles and enabling operators to meet strict SLA requirements.

The output of the policers is a suggested color for the inspected frame. Based on this color, the queue management mechanism decides whether to drop the frame or to pass it to the queue.

Configuring Rate Meter (Policer) Profiles (CLI)

To add a rate meter (policer) profile, enter the following command:

```
root> ethernet qos rate-meter add profile-id <profile-id> cir <cir> cbs
<cbs> eir <eir> ebs <ebs> color-mode <color-mode> coupling-flag
<coupling-flag> rate-meter-profile-name <rate-meter-profile-name>
```

To edit an existing rate meter (policer) profile, enter the following command:

```
root> ethernet qos rate-meter edit profile-id <profile-id> cir <cir> cbs
<cbs> eir <eir> ebs <ebs> color-mode <color-mode> coupling-flag
<coupling-flag> rate-meter-profile-name <rate-meter-profile-name>
```

Table 132 Rate Meter Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 – 250	A unique ID for the rate meter (policer) profile.
cir	Number	0, or 64,000 - 1,000,000,000	The Committed Information Rate (CIR) defined for the rate meter (policer), in bits per second. If the value is 0, all incoming CIR traffic is dropped.
cbs	Number	0 - 128	The Committed Burst Rate (CBR) for the rate meter (policer), in Kbytes.
eir	Number	0, or 64,000 - 1,000,000,000	The Excess Information Rate (EIR) for the rate meter (policer), in bits per second. If the value is 0, all incoming EIR traffic is dropped.
ebs	Number	0 - 128	The Excess Burst Rate (EBR) for the rate meter (policer), in Kbytes.
color-mode	Variable	color-blind color-aware	Determines how the rate meter (policer) treats frames that ingress with a CFI or DEI field set to 1 (yellow). Options are: color aware – All frames that ingress with a CFI/DEI field set to 1 (yellow) are treated as EIR frames, even if credits remain in the CIR bucket. color blind – All ingress frames are treated as green regardless of their CFI/DEI value. A color-blind policer discards any former color decisions.
coupling-flag	Variable	enable disable	When enabled, frames that ingress as yellow may be converted to green when there are no available yellow credits in the EIR bucket. Only relevant in color-aware mode.
rate-meter-profile-name	Text string	Up to 20 characters.	A description of the rate meter (policer) profile.

The following command creates a rate meter (policer) profile with Profile ID 50, named “64k.”

```
root> ethernet qos rate-meter add profile-id 50 cir 64000 cbs 5 eir 64000
ebs 5 color-mode color-blind coupling-flag disable rate-meter-profile-
name 64k
```

This profile includes the following parameters:

- CIR – 64,000 bps

- CBS – 5 Kbytes
- EIR – 64,000 bps
- EBS – 5 Kbytes
- Color Blind mode
- Coupling Flag disabled

The following command edits the rate meter (policer) profile with Profile ID 50, and changes its name to “256 kBytes.”

```
root> ethernet qos rate-meter edit profile-id 50 cir 128000 cbs 5 eir  
128000 ebs 5 color-mode color-aware coupling-flag enable rate-meter-  
profile-name 256 kBytes
```

This edited profile includes the following parameters:

- CIR – 128,000 bps
- CBS – 5 Kbytes
- EIR – 128,000 bps
- EBS – 5 Kbytes
- Color Aware mode
- Coupling Flag enabled

Displaying Rate Meter Profiles (CLI)

You can display all configured rate meter (policer) profiles or a specific profile.

To display a specific profile, enter the following command:

```
root> ethernet qos rate-meter show profile-id <profile-id>
```

To display all configured profiles, enter the following command:

```
root> ethernet qos rate-meter show profile-id all
```

The following command displays the parameters of Rate Meter Profile 50:

```
root> ethernet qos rate-meter show profile-id 50
```

Deleting a Rate Meter Profile (CLI)

You cannot delete a rate meter (policer) profile that is attached to a logical interface. You must first remove the profile from the logical interface, then delete the profile.

To delete a rate meter (policer) profile, use the following command:

```
root> ethernet qos rate-meter delete profile-id <profile-id>
```

The following command deletes Rate Meter Profile 50:

```
root> ethernet qos rate-meter delete profile-id 50
```

Attaching a Rate Meter (Policer) to an Interface (CLI)

On the logical interface level, you can assign rate meter (policer) profiles as follows:

- Per frame type (unicast, multicast, and broadcast)
- Per frame ethertype

This section includes:

- [Assigning a Rate Meter \(Policer\) for Unicast Traffic \(CLI\)](#)
- [Assigning a Rate Meter \(Policer\) for Multicast Traffic \(CLI\)](#)
- [Assigning a Rate Meter \(Policer\) for Broadcast Traffic \(CLI\)](#)
- [Assigning a Rate Meter \(Policer\) per Ethertype \(CLI\)](#)

Assigning a Rate Meter (Policer) for Unicast Traffic (CLI)

To assign a rate meter (policer) profile for unicast traffic to the interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter unicast add capability admin-state <admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for unicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter unicast edit admin-state <admin-state> profile-id <profile-id>
```

To display the current unicast rate meter (policer) profile for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter unicast show configuration
```

To delete the rate meter (policer) profile for unicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter unicast delete
```

Table 133 Assigning Rate Meter for Unicast Traffic CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Enables or disables rate metering on unicast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the rate meter profiles defined in the system.

The following command assigns Rate Meter Profile 1 to unicast traffic on GbE 1, and enables rate metering on the port:

```
eth type eth [1/1]>rate-meter unicast add capability admin-state enable
profile-id 1
```

The following command changes the rate meter (policer) profile for unicast traffic on GbE 1 to 4:

```
eth type eth [1/1]>rate-meter unicast edit admin-state enable profile-id
4
```

Assigning a Rate Meter (Policer) for Unknown Unicast Traffic (CLI)

Unknown unicast packets are unicast packets with unknown destination MAC addresses. To assign a rate meter (policer) profile for unknown unicast traffic to the interface, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rate-meter unknown-unicast add capability admin-state
<admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for unicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rate-meter unknown-unicast edit admin-state <admin-
state> profile-id <profile-id>
```

To display the current unicast rate meter (policer) profile for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rate-meter unknown-unicast show configuration
```

To delete the rate meter (policer) profile for unicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rate-meter unknown-unicast delete
```

Table 134: Assigning Rate Meter for Unknown Unicast Traffic CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Enables or disables rate metering on unknown unicast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the rate meter profiles defined in the system.

The following command assigns Rate Meter Profile 1 to unknown unicast traffic on Eth 7, and enables rate metering on the port:

```
eth type eth [1/7]>rate-meter unknown-unicast add capability admin-state  
enable profile-id 1
```

The following command changes the rate meter (policer) profile for unknown unicast traffic on Eth 7 to 4:

```
eth type eth [1/7]>rate-meter unknown-unicast edit admin-state enable  
profile-id 4
```

Assigning a Rate Meter (Policer) for Multicast Traffic (CLI)

To assign a rate meter (policer) profile for multicast traffic to the interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter multicast add capability admin-state  
<admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for multicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter multicast edit admin-state <admin-state>  
profile-id <profile-id>
```

To display the current multicast rate meter (policer) profile for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter multicast show configuration
```

To delete the rate meter (policer) profile for multicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter multicast delete
```

Table 135 Assigning Rate Meter for Multicast Traffic CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Enables or disables rate metering on multicast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the rate meter profiles defined in the system.

The following command assigns Rate Meter Profile 1 to multicast traffic on GbE 1, and enables rate metering on the port.

```
eth type eth [1/1]>rate-meter multicast add capability admin-state enable
profile-id 1
```

The following command changes the rate meter (policer) profile for multicast traffic on GbE 1 to 4:

```
eth type eth [1/1]>rate-meter multicast edit admin-state enable profile-
id 4
```

Assigning a Rate Meter (Policer) for Unknown Multicast Traffic (CLI)

Unknown multicast packets are multicast packets with unknown destination MAC addresses. To assign a rate meter (policer) profile for unknown multicast traffic to the interface, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rate-meter unknown-multicast add capability admin-
state <admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for multicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rate-meter unknown-multicast edit admin-state <admin-
state> profile-id <profile-id>
```

To display the current multicast rate meter (policer) profile for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rate-meter unknown-multicast show configuration
```

To delete the rate meter (policer) profile for multicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [1/x]>rate-meter unknown-multicast delete
```

Table 136: Assigning Rate Meter for Multicast Traffic CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Enables or disables rate metering on unknown multicast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the rate meter profiles defined in the system.

The following command assigns Rate Meter Profile 1 to unknown multicast traffic on Eth 7, and enables rate metering on the port.

```
eth type eth [1/7]>rate-meter unknown-multicast add capability admin-  
state enable profile-id 1
```

The following command changes the rate meter (policer) profile for unknown multicast traffic on Eth 7 to 4:

```
eth type eth [1/7]>rate-meter unknown-multicast edit admin-state enable  
profile-id 4
```

Assigning a Rate Meter (Policer) for Broadcast Traffic (CLI)

To assign a rate meter (policer) profile for broadcast traffic to the interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter broadcast add capability admin-state  
<admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for broadcast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter broadcast edit admin-state <admin-state>  
profile-id <profile-id>
```

To display the current broadcast rate meter (policer) settings for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter broadcast show configuration
```

To delete the rate meter (policer) profile for broadcast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter broadcast delete
```

Table 137 Assigning Rate Meter for Broadcast Traffic CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Enables or disables rate metering on broadcast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the rate meter profiles defined in the system.

The following command assigns Profile 1 to broadcast traffic on GbE 1, and enables rate metering on the port.

```
eth type eth [1/1]>rate-meter broadcast add capability admin-state enable
profile-id 1
```

The following command changes the rate meter (policer) profile for broadcast traffic on GbE 1 to 4:

```
eth type eth [1/1]>rate-meter broadcast edit admin-state enable profile-
id 4
```

Assigning a Rate Meter (Policer) per Ethertype (CLI)

You can define up to three policers per Ethertype value.

To assign a rate meter (policer) profile for a specific Ethertype to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter <ethertype#> add capability ethertype-value
<ethertype-value> admin-state <admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for a specific Ethertype, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter <ethertype#> edit ethertype-value
<ethertype-value> admin-state <admin-state> profile-id <profile-id>
```

To display the current Ethertype rate meter (policer) settings for an interface, go to interface view for the interface and enter the following commands:

```
eth type eth [x/x]>rate-meter ethertype1 show configuration
eth type eth [x/x]>rate-meter ethertype2 show configuration
eth type eth [x/x]>rate-meter ethertype3 show configuration
```

To delete the rate meter (policer) profile for an Ethertype, go to interface view for the interface and enter one or more of the following commands:

```
eth type eth [x/x]>rate-meter ethertype1 delete
eth type eth [x/x]>rate-meter ethertype2 delete
eth type eth [x/x]>rate-meter ethertype3 delete
```


Table 138 Assigning Rate Meter per Ethertype CLI Parameters

Parameter	Input Type	Permitted Values	Description
ethertype#	Variable	ethertype1 ethertype2 ethertype3	Identifies which of three possible policer-per-Ethertype combinations you are defining.
ethertype-value	Hexadecimal	1-65535	Identifies the Ethertype to which the profile applies.
admin-state	Variable	enable disable	Enables or disables policing on broadcast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the policer profiles defined in the system. For instructions on defining rate meter (policer) profiles, refer to Configuring Rate Meter (Policer) Profiles (CLI) .

The following commands assign Rate Meter Profiles 1, 2, and 3 to Ethertypes 0x8000, 0x8100, and 0x9100, respectively, on GbE 1, and enable rate metering on the port.

```
eth type eth [1/1]>rate-meter ethertype1 add capability ethertype-value 0x8000 admin-state enable profile-id 1
eth type eth [1/1]>rate-meter ethertype2 add capability ethertype-value 0x8100 admin-state enable profile-id 2
eth type eth [1/1]>rate-meter ethertype3 add capability ethertype-value 0x9100 admin-state enable profile-id 3
```

The following commands change the rate meter (policer) profiles assigned in the examples above to 4, 5, and 6, respectively.

```
eth type eth [1/1]>rate-meter ethertype1 edit ethertype-value 0x8000 admin-state enable profile-id 4
eth type eth [1/1]>rate-meter ethertype2 edit ethertype-value 0x8100 admin-state enable profile-id 5
eth type eth [1/1]>rate-meter ethertype3 edit ethertype-value 0x9100 admin-state enable profile-id 6
```

Configuring the Line Compensation Value for a Rate Meter (Policer) (CLI)

A rate meter can measure CIR and EIR at Layer 1 or Layer 2 rates. Layer 1 capacity is equal to Layer 2 capacity plus 20 additional bytes for each frame due to the preamble and Inter Frame Gap (IFG). In most cases, the preamble and IFG equals 20 bytes, but other values are also possible. Line compensation defines the number of bytes to be added to each frame for purposes of CIR and EIR calculation. When Line Compensation is 20, the rate meter operates as Layer 1. When Line Compensation is 0, the rate meter operates as Layer 2. This parameter is very important to users that want to distinguish between Layer 1 and Layer 2 traffic.

To configure the rate meter (policer) line compensation value for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter-compensation-value set <value>
```

To display the rate meter (policer) line compensation value for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter-compensation-value get
```

Table 139 Assigning Line Compensation Value for Rate Meter CLI Parameters

Parameter	Input Type	Permitted Values	Description
value	Number	0 – 32	Policers attached to the interface use this value to compensate for Layer 1 non-effective traffic bytes.

The following command sets the line compensation value for policers attached to GbE 1 to 20:

```
eth type eth [1/1]>rate-meter-compensation-value set 20
```

Configuring Marking (CLI)

This section includes:

- [Marking Overview \(CLI\)](#)
- [Configuring Marking Mode on a Service Point \(CLI\)](#)
- [Marking Table for C-VLAN UP Bits \(CLI\)](#)
- [Marking Table for S-VLAN UP Bits \(CLI\)](#)

Marking Overview (CLI)

When enabled, PTP 850’s marking mechanism modifies each frame’s 802.1p UP bit and CFI/DEI bits according to the classifier decision. The CFI/DEI (color) field is modified according to the classifier and policer decision. The color is first determined by a classifier and may be later overwritten by a policer. Green color is represented by a CFI/DEI value of 0, and Yellow color is represented by a CFI/DEI value of 1. Marking is performed on egress frames that are VLAN-tagged.

The marking is performed according to global marking tables that describe the 802.1p UP bits and the CFI bits (for C-VLAN tags) or DEI bits (for S VLAN tags). The marking mode attribute in the service point egress attributes determines whether the frame is marked as Green or Yellow according to the calculated color.



Note
The calculated color is sent to the queue manager regardless of whether the marking bit is set.

Regular marking is only performed when:

- The outer frame is S-VLAN, and S-VLAN CoS preservation is disabled
- The outer frame is C-VLAN, and C-VLAN CoS preservation is disabled

If marking and CoS preservation for the relevant outer VLAN are both disabled, special marking is applied. Special marking means that marking is performed, but only according to the values defined for Green frames in the 802.1Q and 802.1AD marking tables.

When marking is performed, the C-VLAN or S-VLAN 802.1p UP bits are re-marked according to the calculated CoS and Color.

Configuring Marking Mode on a Service Point (CLI)

To enable or disable marking mode on a service point, go to service view for the service and enter the following command:

```
service[SID]>sp marking set spid <sp-id> mode <mode>
```

Table 140 Marking Mode on Service Point CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
mode	Variable	enable disable	<p>Determines whether re-marking of the outer VLAN (C-VLAN or S-VLAN) of tagged frames that pass through the service point is enabled.</p> <p>If mode is set to enable, and CoS preservation for the relevant outer VLAN is set to disable, the service point re-marks the C-VLAN or S-VLAN 802.1p UP bits of egress frames according to the calculated CoS and Color, and the user-configurable 802.1Q and 802.1AD marking tables.</p> <p>If mode is set to enable and CoS preservation for the relevant outer VLAN is also set to enable, re-marking is not performed.</p> <p>If mode is set to disable and CoS preservation for the relevant outer VLAN is also set to disable, re-marking is applied, but only according to the values defined for Green frames in the 802.1Q and 802.1AD marking tables.</p> <p>For information about configuring CoS Preservation, refer to <i>CoS Preservation and Modification on a Service Point (CLI)</i>.</p>

Examples

The following command enables marking mode on Service Point 3 on Service 2:

```
service[2]>sp marking set spid 3 mode enable
```

The following command disables marking mode on Service Point 3 on Service 2:

```
service[2]>sp marking set spid 3 mode disable
```

Marking Table for C-VLAN UP Bits (CLI)

When marking is performed, the following table is used by the marker to decide which CoS and Color to use as the egress CoS and Color bits for C-VLAN-tagged frames.

Table 141 Marking Table for C-VLAN UP Bits

CoS	Color	802.1q (Configurable)	CFI Color (Configurable)
0	Green	0	0
0	Yellow	0	1
1	Green	1	0
1	Yellow	1	1
2	Green	2	0
2	Yellow	2	1
3	Green	3	0
3	Yellow	3	1
4	Green	4	0
4	Yellow	4	1
5	Green	5	0
5	Yellow	5	1
6	Green	6	0
6	Yellow	6	1
7	Green	7	0
7	Yellow	7	1

To modify the 802.1q CoS and Color to UP and CFI bit mapping table, enter the following command in root view:

```
root> ethernet qos 802.1q-up-bits-marking-tbl set cos <cos> color <color>
802.1p <802.1p> cfi <cfi>
```

To display the 802.1q CoS and Color to UP and CFI bit mapping table, enter the following command in root view:

```
root> ethernet qos 802.1q-up-bits-marking-tbl show
```

Table 142 802.1q CoS and Color to UP and CFI Bit Mapping Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
cos	Number	0 – 7	The CoS value to be mapped.
color	Variable	green yellow	The Color to be mapped.
802.1p	Number	0 – 7	The UP bit value assigned to matching frames.
cfi	Number	0 – 1	The CFI bit value assigned to matching frames.

Example

The following command maps CoS 0, Green, to 802.1p UP bit 0, and CFI bit 0:

```
root> ethernet qos 802.1q-up-bits-marking-tbl set cos 0 color green
802.1p 0 cfi 0
```

Marking Table for S-VLAN UP Bits (CLI)

When marking is performed, the following table is used by the marker to decide which CoS and Color to use as the egress CoS and Color bits for S-VLAN-tagged frames.

Table 143 802.1ad UP Marking Table (S-VLAN)

CoS	Color	802.1ad UP (Configurable)	DEI Color (Configurable)
0	Green	0	0
0	Yellow	0	1
1	Green	1	0
1	Yellow	1	1
2	Green	2	0
2	Yellow	2	1
3	Green	3	0
3	Yellow	3	1
4	Green	4	0
4	Yellow	4	1
5	Green	5	0
5	Yellow	5	1
6	Green	6	0
6	Yellow	6	1
7	Green	7	0
7	Yellow	7	1

To modify the 802.1ad CoS and Color to UP and DEI bit mapping table, enter the following command in root view:

```
root> ethernet qos 802.1ad-up-bits-marking-tbl set cos <cos> color
<color> 802.1p <802.1p> dei <dei>
```

To display the 802.1q CoS and Color to UP and CFI bit mapping table, enter the following command in root view:

```
root> ethernet qos 802.1ad-up-bits-marking-tbl show
```

Table 144 802.1ad UP Marking Table (S-VLAN) CLI Parameters

Parameter	Input Type	Permitted Values	Description
cos	Number	0 – 7	The CoS value to be mapped.
color	Variable	green yellow	The Color to be mapped.
802.1p	Number	0 – 7	The UP bit value assigned to matching frames.
dei	Number	0 – 1	The DEI bit value assigned to matching frames.

Example

The following command marks CoS 5, Yellow, to 802.1p UP bit 5, and DEI bit 1:

```
root> ethernet qos 802.1ad-up-bits-marking-tbl set cos 5 color yellow  
802.1p 5 dei 1
```

Configuring WRED (CLI)

This section includes:

- [WRED Overview \(CLI\)](#)
- [Configuring WRED Profiles \(CLI\)](#)
- [Assigning a WRED Profile to a Queue \(CLI\)](#)

WRED Overview (CLI)

Weighted Random Early Detection (WRED) enables differentiation between higher and lower priority traffic based on CoS. You can define up to 30 WRED profiles. Each profile contains a green traffic curve and a yellow traffic curve. These curves describe the probability of randomly dropping frames as a function of queue occupancy.

The system also includes two pre-defined read-only profiles. These profiles are assigned WRED profile IDs 31 and 32.

- Profile number 31 defines a tail-drop curve and is configured with the following values:
 - 100% Yellow traffic drop after 64kbytes occupancy.
 - 100% Green traffic drop after 128kbytes occupancy.
 - Yellow maximum drop is 100%
 - Green maximum drop is 100%
- Profile number 32 defines a profile in which all will be dropped. It is for internal use and should not be applied to traffic.

A WRED profile can be assigned to each queue. The WRED profile assigned to the queue determines whether or not to drop incoming frames according to the occupancy of the queue. As the queue occupancy grows, the probability of dropping each incoming frame increases as well. As a consequence, statistically more TCP flows will be restrained before traffic congestion occurs.

Configuring WRED Profiles (CLI)

To configure a WRED profile, enter the following command in root view:

```
root> ethernet qos wred-profile-tbl add profile-id <profile-id> green-  
min-threshold <green-min-threshold> green-max-threshold <green-max-  
threshold> green-max-drop <green-max-drop> yellow-min-threshold <yellow-  
min-threshold> yellow-max-threshold <yellow-max-threshold> yellow-max-  
drop <yellow-max-drop>
```

To edit an existing WRED profile, enter the following command in root view:

```
root> ethernet qos wred-profile-tbl edit profile-id <profile-id> green-  
min-threshold <green-min-threshold> green-max-threshold <green-max-  
threshold> green-max-drop <green-max-drop> yellow-min-threshold <yellow-  
min-threshold> yellow-max-threshold <yellow-max-threshold> yellow-max-  
drop <yellow-max-drop>
```

To display a WRED profile, enter the following command in root view:


```
root> ethernet qos wred-profile-tbl show profile-id <profile-id>
```

To delete a WRED profile, enter the following command in root view:

```
root> ethernet qos wred-profile-tbl delete profile-id <profile id>
```

You cannot delete a WRED profile that is assigned to a queue. You must first remove the WRED profile from the queue by replacing it with a different WRED profile. You can then delete the WRED profile.



Note

Each queue always has a WRED profile assigned to it. By default, WRED Profile 31 is assigned to every queue until a different profile is assigned.

Table 145 WRED Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 - 30	A unique ID to identify the profile.
green-min-threshold	Number	0 - 8192	The minimum throughput of green frames for queues with this profile, in Kbytes. When this value is reached, the system begins dropping green frames in the queue.
green-max-threshold	Number	0 - 8192	The maximum throughput of green frames for queues with this profile, in Kbytes. When this value is reached, all green frames in the queue are dropped.
green-max-drop	Number	1 - 100	The maximum percentage of dropped green frames for queues with this profile.
yellow-min-threshold	Number	0 - 8192	The minimum throughput of yellow frames for queues with this profile, in Kbytes. When this value is reached, the system begins dropping yellow frames in the queue.
yellow-max-threshold	Number	0 - 8192	The maximum throughput of yellow frames for queues with this profile, in Kbytes. After this value is reached, all yellow frames in the queue are dropped.
yellow-max-drop	Number	1 - 100	The maximum percentage of dropped yellow frames for queues with this profile.

Examples

The following command adds a WRED profile.

```
root> ethernet qos wred-profile-tbl add profile-id 2 green-min-threshold
8000 green-max-threshold 8000 green-max-drop 100 yellow-min-threshold
8000 yellow-max-threshold 8000 yellow-max-drop 100
```

The new profile has the following parameters:

- profile-id – 2
- green-min-threshold – 8000 Kbytes
- green-max-threshold – 8000 Kbytes
- green-max-drop – 100%
- yellow-min-threshold – 8000 Kbytes
- yellow-max-threshold – 8000 Kbytes
- yellow-max-drop – 100%

The following command edits the WRED profile created by the previous command:

```
root> ethernet qos wred-profile-tbl edit profile-id 2 green-min-threshold
8000 green-max-threshold 8000 green-max-drop 100 yellow-min-threshold
4000 yellow-max-threshold 4000 yellow-max-drop 100
```

The edited profile has the following parameters:

- green-min-threshold – 8000 Kbytes
- green-max-threshold – 8000 Kbytes
- green-max-drop – 100%
- yellow-min-threshold – 4000 Kbytes
- yellow-max-threshold – 4000 Kbytes
- yellow-max-drop – 100%

Assigning a WRED Profile to a Queue (CLI)

To assign a WRED profile to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> wred set service-bundle-id <service-bundle-id> cos
<cos> profile-id <profile-id>
```

To display the WRED profile assigned to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> wred show profile-id service-bundle-id <service-
bundle-id> cos <cos>
```

Table 146 Assigning WRED Profile to Queue CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	Assigns the WRED profile to a Service Bundle. Service Bundles are bundles of queues, grouped together in order to configure common egress characteristics for specific services.
cos	Number	0 – 7	Assigns the WRED profile to a queue in the designated service bundle.
profile-id	Number	1 – 32	A unique ID that identifies the profile.

Examples

The following command assigns WRED Profile 2 to the CoS 0 queue in Service Bundle 1, on GbE 1:

```
eth type eth [1/1]> wred set service-bundle-id 1 cos 0 profile-id 2
```

The following command displays the WRED profile assigned to the CoS 0 queue in Service Bundle 1, on GbE 1:

```
eth type eth [1/1]> wred show profile-id service-bundle-id 1 cos 0
```

Configuring Shapers (CLI)

This section includes:

- [Overview of Egress Shaping \(CLI\)](#)
- [Configuring Egress Line Compensation for Shaping \(CLI\)](#)

Overview of Egress Shaping (CLI)

Egress shaping determines the traffic profile for each queue. PTP 850 performs egress shaping on the following levels:

- **Queue level** – Single leaky bucket shaping
- **Service Bundle level** – Dual leaky bucket shaping

**Note**

Single leaky bucket shaping on the interface level is planned for future release.

You can configure up to 32 single leaky bucket queue shaper profiles. The CIR value can be set to the following values:

- 16,000 – 32,000,000 bps – granularity of 16,000 bps
- 32,000,000 – 131,008,000 bps – granularity of 64,000 bps

**Note**

You can enter any value within the permitted range. Based on the value you enter, the software automatically rounds off the setting according to the granularity. If you enter a value below the lowest granular value (except 0), the software adjusts the setting to the minimum.

You can attach one of the configured queue shaper profiles to each priority queue. If no profile is attached to the queue, no egress shaping is performed on that queue.

This section includes:

- [Configuring Queue Shaper Profiles \(CLI\)](#)
- [Attaching a Shaper Profile to a Queue \(CLI\)](#)

Configuring Queue Shaper Profiles (CLI)

In release 10.9, you must use the Web EMS to add and edit queue shaper profiles. See *Configuring Queue Shaper Profiles*.

To display the parameters of a queue shaper profile, enter the following command in root view:

```
root> ethernet qos queue-shaper-profile-tbl-broadband show profile-id
<profile-id>
```

To delete a queue shaper profile, enter the following command in root view:

```
root> ethernet qos queue-shaper-profile-tbl-broadband delete profile-id
<profile id>
```

You cannot delete a queue shaper profile if it is attached to a queue. You must first remove the profile from the queue. You can then delete the profile.

Attaching a Shaper Profile to a Queue (CLI)

You can attach one of the configured queue shaper profiles to each priority queue. If no profile is attached to the queue, no egress shaping is performed on that queue. Shapers are attached to queues based on the logical interface and service bundle to which the queue belongs, and the queue's CoS value.

To attach a queue shaper profile to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> queue-shaper add capability service-bundle-id
<service-bundle-id> cos <cos> admin-state <admin-state> profile-id
<profile-id>
```

To change the queue shaper profile attached to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> queue-shaper edit service-bundle-id <service-bundle-
id> cos <cos> admin-state <admin-state> profile-id <profile-id>
```

To display the queue shaper profile attached to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> queue-shaper show configuration service-bundle-id
<service-bundle-id> cos <cos>
```

To remove a queue shaper profile from a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> queue-shaper delete service-bundle-id <service-
bundle-id> cos <cos>
```

Table 147 Attaching Shaper Profile to Queue CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle to which you are attaching the queue shaper profile.
cos	Number	0 – 7	The CoS queue ID of the queue to which you want to assign the shaper. Queues are numbered according to CoS value.

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Select enable to enable egress queue shaping on the queue, or disable to disable egress queue shaping on the queue. If you set shaping to disable , the shaper profile remains attached to the queue, but does not affect traffic.
profile-id	Number	1 – 32	Enter the ID of one of the configured queue shaper profiles.

The following command adds Queue Shaper Profile 5 to queues with CoS 0, on Service Bundle 1, on GbE 1, and enables shaping on these queues.

```
eth type eth [1/1]> queue-shaper add capability service-bundle-id 1 cos 0
admin-state enable profile-id 5
```

The following command changes the Queue Shaper Profile assigned in the previous command to Queue Shaper Profile 2:

```
eth type eth [1/1]> queue-shaper edit service-bundle-id 1 cos 0 admin-
state enable profile-id 2
```

Configuring Egress Line Compensation for Shaping (CLI)

You can configure a line compensation value for all the shapers under a specific logical interface. This value is used to compensate for Layer 1 non-effective traffic bytes on egress.

To set the egress line compensation value, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>shaping-compensation-value set <value>
```

To display the egress line compensation value, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>shaping-compensation-value get
```

Table 148 Egress Line Compensation for Shaping CLI Parameters

Parameter	Input Type	Permitted Values	Description
value	Number	0 – 26 (even numbers only)	Shapers attached to the interface use this value to compensate for Layer 1 non-effective traffic bytes on egress.

The following command sets the egress line compensation value to 0 on GbE 1:

```
eth type eth [1/1]>shaping-compensation-value set 0
```

Configuring Scheduling (CLI)

This section includes:

- [Overview of Egress Scheduling \(CLI\)](#)
- [Configuring Queue Priority \(CLI\)](#)
- [Configuring Interface Priority Profiles \(CLI\)](#)
- [Attaching a Priority Profile to an Interface \(CLI\)](#)
- [Configuring Weighted Fair Queuing \(WFQ\) \(CLI\)](#)

Overview of Egress Scheduling (CLI)

Egress scheduling is responsible for transmission from the priority queues. PTP 850 uses a unique algorithm with a hierarchical scheduling model over the three levels of the egress path that enables compliance with SLA requirements.

The scheduler scans all the queues over all the service bundles, per interface, and determines which queue is ready to transmit. If more than one queue is ready to transmit, the scheduler determines which queue transmits first based on:

- **Queue Priority** – A queue with higher priority is served before lower-priority queues.
- **Weighted Fair Queuing (WFQ)** – If two or more queues have the same priority and are ready to transmit, the scheduler transmits frames from the queues based on a WFQ algorithm that determines the ratio of frames per queue based on a predefined weight assigned to each queue.

Configuring Queue Priority (CLI)

A priority profile defines the exact order for serving the eight priority queues in a single service bundle. When you attach a priority profile to an interface, all the service bundles under the interface inherit the profile.

The priority mechanism distinguishes between two states of the service bundle:

- Green State – Committed state
- Yellow state – Best effort state

Green State refers to any time when the service bundle rate is below the user-defined CIR. Yellow State refers to any time when the service bundle is above the user-defined CIR but below the PIR.

You can define up to four Green priority profiles, from 4 (highest) to 1 (lowest). An additional four Yellow priority profiles are defined automatically and cannot be changed or edited.

The following table provides a sample of an interface priority profile. This profile is also used as the default interface priority profile.

Table 149 Interface Priority Profile Example

Profile ID (1-9)			
CoS	Green Priority (user defined)	Yellow Priority (read only)	Description
0	1	1	Best Effort
1	2	1	Data Service 4
2	2	1	Data Service 3
3	2	1	Data Service 2
4	2	1	Data Service 1
5	3	1	Real Time 2 (Video with large buffer)
6	3	1	Real Time 1 (Video with small buffer)
7	4	4	Management (Sync, PDUs, etc.)

When the service bundle state is Green (committed state), the service bundle priorities are as defined in the Green Priority column. When the service bundle state is Yellow (best effort state), the service bundle priorities are system-defined priorities shown in the Yellow Priority column.



Note

CoS 7 is always marked with the highest priority and cannot be changed or edited, no matter what the service bundle state is, since it is assumed that only high priority traffic will be tunneled via CoS 7.

The system supports up to nine interface priority profiles. Profiles 1 to 8 are defined by the user, while profile 9 is the pre-defined read-only default interface priority profile.

Configuring Interface Priority Profiles (CLI)

To define an interface priority profile, enter the following command in root view:

```
root> ethernet qos port-priority-profile-tbl add profile-id <profile-id>
cos0-priority <cos0-priority> description <description> cos1-priority
<cos1-priority> description <description> cos2-priority <cos2-priority>
description <description> cos3-priority <cos3-priority> description
<description> cos4-priority <cos4-priority> description <description>
cos5-priority <cos5-priority> description <description> cos6-priority
<cos6-priority> description <description> cos7-priority <cos7-priority>
description <description>
```

To edit an existing interface priority profile, enter the following command in root view:


```

root> ethernet qos port-priority-profile-tbl edit profile-id <profile-id>
cos0-priority <cos0-priority> description <description> cos1-priority
<cos1-priority> description <description> cos2-priority <cos2-priority>
description <description> cos3-priority <cos3-priority> description
<description> cos4-priority <cos4-priority> description <description>
cos5-priority <cos5-priority> description <description> cos6-priority
<cos6-priority> description <description> cos7-priority <cos7-priority>
description <description>

```

To display the parameters of an interface priority profile, enter the following command in root view:

```

root> ethernet qos port-priority-profile-tbl show profile-id <profile-id>

```

To delete an interface priority profile, enter the following command in root view:

```

root> ethernet qos port-priority-profile-tbl delete profile-id <profile-id>

```

You can only delete an interface priority profile if the profile is not attached to any interface.

Table 150 Interface Priority Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 – 8	A unique ID to identify the profile.
cos0-priority	Number	1 – 4	The Green priority for the CoS 0 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 0 egressing the service bundle to which the profile is assigned.
description	Text String	Up to 20 characters.	A description of the priority level.
cos1-priority	Number	1 – 4	The Green priority for the CoS 1 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 1 egressing the service bundle to which the profile is assigned.
cos2-priority	Number	1 – 4	The Green priority for the CoS 2 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 2 egressing the service bundle to which the profile is assigned.
cos3-priority	Number	1 – 4	The Green priority for the CoS 3 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 3 egressing the service bundle to which the profile is assigned.
cos4-priority	Number	1 – 4	The Green priority for the CoS 4 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 4 egressing the service bundle to which the profile is assigned.

Parameter	Input Type	Permitted Values	Description
cos5-priority	Number	1 – 4	The Green priority for the CoS 5 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 5 egressing the service bundle to which the profile is assigned.
cos6-priority	Number	1 – 4	The Green priority for the CoS 6 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 6 egressing the service bundle to which the profile is assigned.
cos7-priority	Number	1 – 4	The Green priority for the CoS 7 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 7 egressing the service bundle to which the profile is assigned.

Example

The following command configures a priority profile with Profile ID 1.

```
root> ethernet qos port-priority-profile-tbl add profile-id 1 cos0-
priority 1 description c0_p1 cos1-priority 1 description c1_p1 cos2-
priority 1 description c2_p1 cos3-priority 2 description c3_p2 cos4-
priority 2 description c4_p2 cos5-priority 3 description c5_p3 cos6-
priority 4 description c6_p4 cos7-priority 4 description c7_p4
```

This profile has the parameters listed in the following table.

Table 151 Interface Priority Sample Profile Parameters

CoS	Green Priority (user defined)	Yellow Priority (read only)	Description
0	1	1	c0_p1
1	1	1	c1_p1
2	1	1	c2_p1
3	2	1	c3_p2
4	2	1	c4_p2
5	3	1	c5_p3
6	4	1	c6_p4
7	4	4	c7_p4

The following command edits the profile you created in the previous command so that CoS 6 queues have a Green priority of 3 instead of 4, and a description of “c6_p3”.

```
root> ethernet qos port-priority-profile-tbl edit profile-id 1 cos0-
priority 1 description c0_p1 cos1-priority 1 description c1_p1 cos2-
priority 1 description c2_p1 cos3-priority 2 description c3_p2 cos4-
priority 2 description c4_p2 cos5-priority 3 description c5_p3 cos6-
priority 3 description c6_p3 cos7-priority 4 description c7_p4
```

Attaching a Priority Profile to an Interface (CLI)

To attach a priority profile to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> priority set profile-id <profile-id>
```

To display which priority profile is attached to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> port-priority show profile-id
```

Table 152 Attaching Priority Profile to Interface CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 – 9	Enter the ID of one of the configured logical interface priority profiles.

Examples

The following command attaches Interface Priority Profile 3 to GbE 1:

```
eth type eth [1/1]> priority set profile-id 3
```

The following is a sample output from the `port-priority show profile-id` command:

```
eth type eth [1/1]>port-priority show profile-id
Profile ID: 9
CoS    Priority          Priority          Description
      (when queue is green) (When queue is yellow)
0       1                1                best effort
1       2                1                data service
2       2                1                data service
3       2                1                data service
4       2                1                data service
5       3                1                real time
6       3                1                real time
7       4                4                management
eth type eth [1/1]>
```

Configuring Weighted Fair Queuing (WFQ) (CLI)

This section includes:

- [Overview of WFQ \(CLI\)](#)
- [Configuring a WFQ Profile \(CLI\)](#)
- [Attaching a WFQ Profile to an Interface \(CLI\)](#)

Overview of WFQ (CLI)

The scheduler serves the queues based on their priority, but when two or more queues have data to transmit and their priority is the same, the scheduler uses Weighted Fair Queuing (WFQ) to determine the priorities within each priority. WFQ defines the transmission ratio, in bytes, between the queues. All the service bundles under the interface inherit the WFQ profile attached to the interface.

The system supports up to six WFQ interface profiles. Profile ID 1 is a pre-defined read-only profile, and is used as the default profile. Profiles 2 to 6 are user-defined profiles.

The following table provides an example of a WFQ profile.

Table 153 WFQ Profile Example

Profile ID (1-7)		
CoS	Queue Weight (Green)	Queue Weight (Yellow – not visible to users, and cannot be edited)
0	20	20
1	20	20
2	20	20
3	20	20
4	20	20
5	20	20
6	20	20
7	20	20

You can attach one of the configured interface WFQ profiles to each interface. By default, the interface is assigned Profile ID 1, the pre-defined system profile.

Configuring a WFQ Profile (CLI)

To define a WFQ profile, enter the following command in root view:

```
root> ethernet qos wfq-weight-profile-tbl add profile-id <profile.id>
cos0-weight <cos0-weight> cos1-weight <cos1-weight> cos2-weight <cos2-
weight> cos3-weight <cos3-weight> cos4-weight <cos4-weight> cos5-weight
<cos5-weight> cos6-weight <cos6-weight> cos7-weight <cos7-weight>
```

To edit an existing WFQ profile, enter the following command in root view:

```
root> ethernet qos wfq-weight-profile-tbl edit profile-id <profile.id>
cos0-weight <cos0-weight> cos1-weight <cos1-weight> cos2-weight <cos2-
weight> cos3-weight <cos3-weight> cos4-weight <cos4-weight> cos5-weight
<cos5-weight> cos6-weight <cos6-weight> cos7-weight <cos7-weight>
```

To display the parameters of a WFQ profile, enter the following command in root view:

```
root> ethernet qos wfq-weight-profile-tbl show profile-id <profile-id>
```

To delete a WFQ profile, enter the following command in root view:

```
root> ethernet qos wfq-weight-profile-tbl delete profile-id <profile-id>
```

You can only delete WFQ profile if the profile is not attached to any interface.

Table 154 WFQ Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	2 – 6	A unique ID to identify the profile.
cos0-weight	Number	1 - 20	The relative weight for the CoS 0 queue.
cos1- weight	Number	1 - 20	The relative weight for the CoS 1 queue.
cos2- weight	Number	1 - 20	The relative weight for the CoS 2 queue.
cos3- weight	Number	1 - 20	The relative weight for the CoS 3 queue.
cos4- weight	Number	1 - 20	The relative weight for the CoS 4 queue.
cos5- weight	Number	1 - 20	The relative weight for the CoS 5 queue.
cos6- weight	Number	1 - 20	The relative weight for the CoS 6 queue.
cos7- weight	Number	1 - 20	The relative weight for the CoS 7 queue.

Examples

The following command configures a WFQ profile with Profile ID 2.

```
root> ethernet qos wfq-weight-profile-tbl add profile-id 2 cos0-weight 15
cos1-weight 15 cos2-weight 15 cos3-weight 15 cos4-weight 15 cos5-weight
15 cos6-weight 15 cos7-weight 20
```

This profile has the parameters listed in the following table. Note that the yellow queue weight is constant and cannot be changed. This means that all best effort traffic (yellow) will always have the same weight, regardless of CoS.

Table 155 WFQ Sample Profile Parameters

CoS	Queue Weight (Green)	Queue Weight (Yellow – not visible to users, and cannot be edited)
0	15	20
1	20	20
2	20	20
3	20	20
4	20	20
5	20	20
6	20	20
7	20	20

The following command edits the profile you created in the previous command so that CoS 6 queues have a weight of 20 instead of 15:

```
root> ethernet qos wfq-weight-profile-tbl edit profile-id 2 cos0-weight 15 cos1-weight 15 cos2-weight 15 cos3-weight 15 cos4-weight 15 cos5-weight 15 cos6-weight 20 cos7-weight 20
```

Attaching a WFQ Profile to an Interface (CLI)

To attach a WFQ profile to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> port-wfq set profile-id <profile-id>
```

To display which WFQ profile is attached to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> port-wfq show profile-id
```

Table 156 Attaching WFQ Profile to Interface CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 – 6	Enter the ID of one of the configured WFQ profiles.

Examples

The following command assigns WFQ Profile 3 to GbE 1:

```
eth type eth [1/1]> port-wfq set profile-id 3
```

The following is a sample display for the `port-wfq show profile-id` command:

```
eth type eth [1/1]>port-wfq show profile-id
Profile ID: 1
```

CoS	Queue weight (Green)
0	20
1	20
2	20
3	20
4	20
5	20
6	20
7	20

eth type eth [1/1]>

Displaying Egress Statistics (CLI)

PTP 850 collects egress PMs at the queue level and the service bundle level.

Displaying Queue-Level PMs (CLI)

PTP 850 supports the following counters per queue at the queue level:

- Transmitted Green Packets (64 bits counter)
- Transmitted Green Bytes (64 bits counter)
- Transmitted Green Bits per Second (32 bits counter)
- Dropped Green Packets (64 bits counter)
- Dropped Green Bytes (64 bits counter)
- Transmitted Yellow Packets (64 bits counter)
- Transmitted Yellow Bytes (64 bits counter)
- Transmitted Yellow Bits per Second (32 bits counter)
- Dropped Yellow Packets (64 bits counter)
- Dropped Yellow Bytes (64 bits counter)

To display queue-level PMs, enter interface view for the interface and enter the following command:

```
eth type eth [x/x]> tm-queue show statistics service-bundle-id <service-bundle-id> cos <cos> clear-on-read <clear-on-read> layer-1 <layer-1>
```

To clear queue-level PMs for a specific service bundle, enter interface view for the interface and enter the following command:

```
eth type eth [x/x]> tm-queue clear statistics service-bundle-id <service-bundle-id>
```

Table 157 Egress Queue Level PMs CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle for which you want to display PMs.
cos	Number	0 - 7	The queue for which you want to display PMs.
clear-on-read	Boolean	yes no	If you enter yes, the statistics are cleared once you display them.

Parameter	Input Type	Permitted Values	Description
layer-1	Boolean	yes no	yes – Statistics are represented as Layer 1 statistics, including preamble and IFG. no – Statistics are represented as Layer 2 statistics.

The following command displays PMs for the CoS 0 queue in Service Bundle 1, on GbE 2. The PMs are cleared after they are displayed.

```
eth type eth [1/2]> tm-queue show statistics service-bundle-id 1 cos 0
clear-on-read yes layer-1 yes
```

The following command clears PMs for all queues in Service Bundle 1, on GbE 2.

```
eth type eth [1/2]> tm-queue clear statistics service-bundle-id 1
```

Displaying Service Bundle-Level PMs (CLI)

PTP 850 supports the following counters per service bundle at the service bundle level:

- Transmitted Green Packets (64 bits counter)
- Transmitted Green Bytes (64 bits counter)
- Transmitted Green Bits per Second (32 bits counter)
- Dropped Green Packets (64 bits counter)
- Dropped Green Bytes (64 bits counter)
- Transmitted Yellow Packets (64 bits counter)
- Transmitted Yellow Bytes (64 bits counter)
- Transmitted Yellow Bits per Second (32 bits counter)
- Dropped Yellow Packets (64 bits counter)
- Dropped Yellow Bytes (64 bits counter)

To display service bundle-level PMs, enter interface view for the interface and enter the following command:

```
eth type eth [x/x]> tm-service-bundle show statistics service-bundle-id
<service-bundle-id> clear-on-read <clear-on-read> layer-1 <layer-1>
```

To clear service bundle-level PMs for all service bundles on an interface, enter interface view for the interface and enter the following command:

```
eth type eth [x/x]> tm-service-bundle clear statistics
```

Table 158 Egress Service Bundle Level PMs CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle for which you want to display PMs.
clear-on-read	Boolean	yes no	If you enter yes, the statistics are cleared once you display them.
layer-1	Boolean	yes no	yes – Statistics are represented as Layer 1 statistics, including preamble and IFG. no – Statistics are represented as Layer 2 statistics.

Examples

The following command displays service bundle PMs for Service Bundle 1, on GbE 1. The PMs are cleared after they are displayed.

```
eth type eth [1/1]> tm-service-bundle show statistics service-bundle-id 1
clear-on-read yes layer-1 yes
```

Chapter 17: Synchronization (CLI)

This section includes:

- [Changing the ETSI/ANSI Mode \(CLI\)](#)
- [Configuring the Sync Source \(CLI\)](#)
- [Configuring the Outgoing Clock \(CLI\)](#)
- [Configuring SSM Messages \(CLI\)](#)

Changing the ETSI/ANSI Mode (CLI)

By default, PTP 850 units are set to ETSI mode. No mode change is necessary to configure an MRMC script, even if an FCC (ANSI) script is used. However, to configure a sync source on which the sync source Quality parameter must be set according to ANSI specifications. You must change the ETSI/ANSI mode to ANSI before configuring the sync source.

To change the ETSI/ANSI mode, enter the following command in root view:

```
root> platform management set interfaces-standard <ansi|etsi>
```

The following command changes the ETSI/ANSI mode from the default value of ETSI to ANSI mode:

```
root> platform management set interfaces-standard ansi
```

To display the current ETSI/ANSI mode, enter the following command in root view:

```
root> platform management show interfaces-standard
```

Changing the ETSI/ANSI mode does *not* require unit reset.

Configuring the Sync Source (CLI)

**Note**

To configure a sync source on which the sync source Quality parameter must be set according to ANSI specifications, change the ETSI/ANSI mode to ANSI before configuring the sync source. See [Changing the ETSI/ANSI Mode \(CLI\)](#).

Note that the Quality parameter is not supported in CeraOS 10.6. It is supported in release 10.9.

Frequency signals can be taken by the system from Ethernet and radio interfaces. The reference frequency may also be conveyed to external equipment through different interfaces.

Frequency is distributed by configuring the following parameters in each node:

- **System Synchronization Sources** – These are the interfaces from which the frequency is taken and distributed to other interfaces. Up to 16 sources can be configured in each node. A revertive timer can be configured. For each interface, you must configure:
 - **Priority (1-16)** – No two synchronization sources can have the same priority.
 - **Quality** – The quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source.
- Each unit determines the current active clock reference source interface:
 - The interface with the highest available quality is selected.
 - From among interfaces with identical quality, the interface with the highest priority is selected.

When configuring the Sync source, the Sync mode must be set to its default setting of automatic. To display the current Sync mode, enter the following CLI command in root view:

```
root> platform sync mode show
```

If the Sync mode is set to pipe, you must set it to automatic by entering the following CLI command in root view:

```
root> platform sync mode set automatic
```

When configuring an Ethernet interface as a Sync source, the Media Type of the interface must be rj45 or sfp, *not* auto-type. To view and configure the Media Type of an Ethernet interface, see [Configuring an Interface's Media Type \(CLI\)](#).

This section includes:

- [Configuring an Ethernet Interface as a Synchronization Source \(CLI\)](#)
- [Configuring a Radio Interface as a Synchronization Source \(CLI\)](#)

Configuring an Ethernet Interface as a Synchronization Source (CLI)

**Note**

In order to select an Ethernet interface, you must first specify the media type for this interface. See [Configuring Ethernet Services \(CLI\)](#).

To configure an Ethernet interface as a synchronization source, enter the following command in root view:

```
root> platform sync source add eth-interface slot <slot> port <port>  
priority <priority> quality <quality>
```

To edit the parameters of an existing Ethernet interface synchronization source, enter the following command in root view:

```
root> platform sync source edit eth-interface slot <slot> port <port>  
priority <priority> quality <quality>
```

To remove an Ethernet interface as a synchronization source, enter the following command in root view:

```
root> platform sync source remove eth-interface slot <slot> port <port>
```

Table 159 Sync Source Ethernet CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	1-3	The interface to be configured as a synchronization source.
priority	Number	1 – 16	The priority of this synchronization source relative to other synchronization sources configured in the unit.
quality	Variable	For ETSI systems: <ul style="list-style-type: none"> • automatic • prc • ssu-a • ssu-b • g813.8262 For ANSI (FCC) systems: <ul style="list-style-type: none"> • automatic • prs • stratum-2 • transit-node • stratum-3e • stratum-3 • smc • unknown 	The quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source. If the quality is set to automatic, then the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes "failure." SSM must be enabled on the remote interface in order for the interface to receive SSM messages. If the quality is configured to a fixed value, then the quality status becomes "failure" upon interface failure (such as LOS, LOC, LOF).

The following command configures Ethernet port 2 as a synchronization source with priority = 8, and quality = automatic:

```
root> platform sync source add eth-interface slot 1 port 2 priority 8
quality automatic
```

The following command changes the priority of this synchronization source to 6:

```
root> platform sync source edit eth-interface slot 1 port 2 priority 6
```

The following command removes this synchronization source:

```
root> platform sync source remove eth-interface slot 1 port 2
```

Configuring a Radio Interface as a Synchronization Source (CLI)

To configure a radio interface as a synchronization source, enter the following command in root view:

```
root> platform sync source add radio-interface slot <slot> port <port>
radio-channel <radio-channel> priority <priority> quality <quality>
```

To edit the parameters of an existing radio interface synchronization source, enter the following command in root view:

```
root> platform sync source edit radio-interface slot <slot> port <port>
radio-channel <radio-channel> priority <priority> quality <quality>
```

To remove a radio interface as a synchronization source, enter the following command in root view:

```
root> platform sync source remove radio-interface slot <slot> port <port>
radio-channel <radio-channel>
```

Table 160 Sync Source Radio CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	2	
port	Number	1-2	
radio-channel	Number	0 – 85	Must be set to 0.
priority	Number	1 – 16	The priority of this synchronization source relative to other synchronization sources configured in the unit.
quality	Variable	For ETSI systems: <ul style="list-style-type: none"> • automatic • prc • ssu-a • ssu-b • g813.8262 For ANSI (FCC) systems: <ul style="list-style-type: none"> • automatic • prs • stratum-2 • transit-node • stratum-3e • stratum-3 • smc • unknown 	The quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source. If the quality is set to automatic, then the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes "failure." SSM must be enabled on the remote interface in order for the interface to receive SSM messages.

The following command configures radio interface 1 as a synchronization source with priority = 16, and quality = automatic:

```
root> platform sync source add radio-interface slot 2 port 1 radio-
channel 0 priority 16 quality automatic
```


The following command changes the priority of this synchronization source to 14:

```
root> platform sync source edit radio-interface slot 2 port 1 radio-  
channel 0 priority 14
```

The following command removes this synchronization source:

```
root> platform sync source remove radio-interface slot 2 port 1 radio-  
channel 0
```

Configuring the Outgoing Clock (CLI)

For each interface, you can choose between using the system clock or the interface’s internal clock as its synchronization source. By default, interfaces use the system clock.

When configuring the outgoing clock, the Sync mode must be set to its default setting of automatic. To display the current Sync mode, enter the following command in root view:

```
root> platform sync mode show
```

If the Sync mode is set to pipe, you must set it to automatic by entering the following command in root view:

```
root> platform sync mode set automatic
```

;

To set the interface clock for a radio interface, enter the following command in root view:

```
root> platform sync interface-clock set radio-interface slot <slot> port
<port> radio-channel <radio-channel> source <source>
```

To set the interface clock for an Ethernet interface, enter the following command in root view:

```
root> platform sync interface-clock set eth-interface slot <slot> port
<port> source <source>
```



Note
To configure the interface clock on an Ethernet interface, the Media Type of the interface must be rj45 or sfp, *not* auto-type. To view and configure the Media Type of an Ethernet interface, see [Configuring Ethenet Interfaces \(CLI\)](#).

Table 161 Outgoing Clock CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	ethernet: 1 radio: 2	
port	Number	ethernet: 1-3 radio: 1-2	The port number of the interface.
radio-channel	Number	0 – 84	The radio-channel configured for the synchronization source.
source	Variable	system-clock local-clock	system-clock – The interface uses the system clock as its synchronization source. local-clock – The interface uses its internal clock as its synchronization source.

The following command sets the clock source for radio interface 2 to its internal clock:

```
root> platform sync interface-clock set radio-interface slot 2 port 2  
radio-channel 0 source local-clock
```

The following command sets the clock source for Ethernet port 2 to the system clock:

```
root> platform sync interface-clock set eth-interface slot 1 port 2  
source system-clock
```

Configuring SSM Messages (CLI)

In order to provide topological resiliency for synchronization transfer, PTP 850E implements the passing of SSM messages over the Ethernet and radio interfaces. SSM timing in PTP 850E complies with ITU-T G.781.

In addition, the SSM mechanism provides reference source resiliency, since a network may have more than one source clock.

The following are the principles of operation:

- At all times, each source interface has a “quality status” which is determined as follows:
 - If quality is configured as fixed, then the quality status becomes “failure” upon interface failure (such as LOS, LOC, LOF).
 - If quality is automatic, then the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes “failure.”
- Each unit holds a parameter which indicates the quality of its reference clock. This is the quality of the current synchronization source interface.
- The reference source quality is transmitted through SSM messages to all relevant radio interfaces.
- In order to prevent loops, an SSM with quality “Do Not Use” is sent from the active source interface (both radio and Ethernet).

In order for an interface to transmit SSM messages, SSM must be enabled on the interface. By default, SSM is disabled on all interfaces.

When configuring SSM, the Sync mode must be set to its default setting of automatic. To display the current Sync mode, enter the following command in root view:

```
root> platform sync mode show
```

If the Sync mode is set to pipe, you must set it to automatic by entering the following command in root view:

```
root> platform sync mode set automatic
```

To enable SSM on a radio interface, enter the following command in root view:

```
root> platform sync ssm admin radio-interface slot <slot> port <port>  
admin on
```

To disable SSM on a radio interface, enter the following command in root view:

```
root> platform sync ssm admin radio-interface slot <slot> port <port>  
admin off
```

To enable SSM on an Ethernet interface, enter the following command in root view:

```
root> platform sync ssm admin eth-interface slot <slot> port <port> admin  
on
```

To disable SSM on an Ethernet interface, enter the following command in root view:

```
root> platform sync ssm admin eth-interface slot <slot> port <port> admin  
off
```

The following command enables SSM on radio interface 2:

```
root> platform sync ssm admin radio-interface slot 2 port 2 admin on
```

The following command enables SSM on Ethernet port 1:

```
root> platform sync ssm admin eth-interface slot 1 port 1 admin on
```

Displaying Synchronization Status and Parameters (CLI)

To display the synchronization sources configured in the system, enter the following command in root view:

```
root> platform sync source config show
```

The following is a sample synchronization source display output:

```
number of configured sources = 4
=====|
| Slot | Port | Type | Instance | Priority | Quality |
=====|
| 1 | 7 | Ethernet | 11 | automatic |
-----|
| 1 | 1 | Radio | 6 | automatic |
-----|
```

To display the synchronization source status, enter the following command in root view:

```
root> platform sync source status show
```

The following is a sample synchronization source status display output:

```
root>platform sync source config show
number of configured sources = 1
=====|
| Slot | Port | Type | Instance | Priority | Quality |
=====|
| 1 | 7 | ethernet | | 1 | automatic |
-----|
root>
```

To display the current system reference clock quality, enter the following command in root view:

```
root> platform sync source show-reference-clock-quality
```

To display the current synchronization configuration of the unit's interfaces, enter the following command in root view:

```
root> platform sync interface config show
```

The following is a sample interface synchronization configuration display output:

```

root>platform sync interface config show
number of configured clock-interfaces = 8
=====
| Slot   | Port   | Type       | Trail Radio Ch. | Source-Type | SSM-Admin |
=====
| 1      | 1      | ethernet   |                  | system-clock | Off       |
|-----|
| 1      | 2      | ethernet   |                  | system-clock | Off       |
|-----|
| 1      | 3      | ethernet   |                  | system-clock | Off       |
|-----|
| 1      | 4      | ethernet   |                  | system-clock | Off       |
|-----|
| 1      | 5      | ethernet   |                  | system-clock | Off       |
|-----|
| 1      | 6      | ethernet   |                  | system-clock | Off       |
|-----|
| 1      | 7      | ethernet   |                  | system-clock | On        |
|-----|
| 1      | 1      | radio      |                  | system-clock | Off       |
|-----|
root>

```

To display the current system clock status, enter the following command in root view:

```
root> platform sync clu-state show
```

The following is a sample system clock status display output:

```
CLU is in Free-running mode
```

Chapter 18: Access Management and Security (CLI)

This section includes:

- [Configuring the General Access Control Parameters \(CLI\)](#)
- [Configuring the Password Security Parameters \(CLI\)](#)
- [Configuring Users \(CLI\)](#)
- [Configuring X.509 CSR Certificates and HTTPS \(CLI\)](#)
- [Configuring HTTPS Cipher Hardening \(CLI\)](#)
- [Blocking Telnet Access \(CLI\)](#)
- [Uploading the Security Log \(CLI\)](#)
- [Uploading the Configuration Log \(CLI\)](#)

Related Topics:

- [Logging On \(CLI\)](#)

Configuring the General Access Control Parameters (CLI)

To avoid unauthorized login to the system, the following parameters should be set:

- Inactivity Timeout
- Blocking access due to login failures
- Blocking unused accounts

This section includes:

- [Configuring the Inactivity Timeout Period \(CLI\)](#)
- [Configuring Blocking Upon Login Failure \(CLI\)](#)
- [Configuring Blocking of Unused Accounts \(CLI\)](#)

Configuring the Inactivity Timeout Period (CLI)

A system management session automatically times out after a defined period (in minutes) with no user activity. To configure the session timeout period, enter the following command in root view:

```
root> platform security protocols-control session inactivity-timeout set <inactivity-timeout>
```

To display the currently configured session timeout period, enter the following command in root view:

```
root> platform security protocols-control session inactivity-timeout show
```

Table 162 Inactivity Timeout Period CLI Parameters

Parameter	Input Type	Permitted Values	Description
inactivity-timeout	Number	1 - 60	The session inactivity timeout period (in minutes).

The following command sets the session inactivity timeout period to 30 minutes:

```
root> platform security protocols-control session inactivity-timeout set 30
```

Configuring Blocking Upon Login Failure (CLI)

Upon a configurable number of failed login attempts, the system blocks the user from logging in for a configurable number of minutes.

To configure the number of failed login attempts that will temporarily block the user from logging into the system, enter the following command in root view:

```
root> platform security access-control block-failure-login attempt set <attempt>
```


To define the period (in minutes) for which a user is blocked after the configured number of failed login attempts, enter the following command in root view:

```
root> platform security access-control block-failure-login period set
<period>
```

To display the current failed login attempt blocking parameters, enter the following command in root view:

```
root> platform security access-control block-failure-login show
```

Table 163 Blocking Upon Login Failure CLI Parameters

Parameter	Input Type	Permitted Values	Description
attempt	Number	1 - 10	If a user attempts to login to the system with incorrect credentials this number of times consecutively, the user will temporarily be prevented from logging into the system for the time period defined by the platform security access-control block-failure-login period set command.
period	Number	1 - 60	The duration of time, in minutes, that a user is prevented from logging into the system after the defined number of failed login attempts.

The following commands configure a blocking period of 45 minutes for users that perform 5 consecutive failed login attempts:

```
root> platform security access-control block-failure-login attempt set 5
root> platform security access-control block-failure-login period set 45
```

Configuring Blocking of Unused Accounts (CLI)

You can configure a number of days after which a user is prevented from logging into the system if the user has not logged in for the configured number of days. You can also manually block a specific user.

To configure the blocking of unused accounts period, enter the following command in root view:

```
root> platform security access-control block-unused-account period set
<period>
```

Once the user is blocked, you can use the following command to unblock the user:

```
root> platform security access-control user-account block user-name
<user-name> block no
```

To manually block a specific user, enter the following command in root view:

```
root> platform security access-control user-account block user-name
<user-name> block yes
```

To display the currently configured blocking of unused account period, enter the following command in root view:

```
root> platform security access-control block-unused-account show
```

Table 164 Blocking Unused Accounts CLI Parameters

Parameter	Input Type	Permitted Values	Description
period	Number	0, 30 - 90	The number of days after which a user is prevented from logging into the system if the user has not logged in for the configured number of days. If you enter 0, this feature is disabled.
user-name	Text String	Any valid user name.	The name of the user being blocked or unblocked.

The following command configures the system to block any user that does not log into the system for 50 days:

```
root> platform security access-control block-unused-account period set 50
```

The following commands block, then unblock, a user with the user name John_Smith:

```
root> platform security access-control user-account block user-name  
John_Smith block yes  
root> platform security access-control user-account block user-name  
John_Smith block no
```

Configuring the Password Security Parameters (CLI)

You can configure enhanced security requirements for user passwords.

This section includes:

- [Configuring Password Aging \(CLI\)](#)
- [Configuring Password Strength Enforcement \(CLI\)](#)
- [Forcing Password Change Upon First Login \(CLI\)](#)
- [Displaying the System Password Settings \(CLI\)](#)

Configuring Password Aging (CLI)

Passwords remain valid from the first time the user logs into the system for the number of days (20-90) set by this command. If you set this parameter to 0, password aging is disabled, and passwords remain valid indefinitely.

To configure password aging, enter the following command in root view:

```
root> platform security access-control password aging set <password aging>
```

Table 165 Password Aging CLI Parameters

Parameter	Input Type	Permitted Values	Description
password aging	Number	0, 20 - 90	The number of days that user passwords will remain valid from the first time the user logs into the system.

Example

The following command sets the password aging time to 60 days:

```
root> platform security access-control password aging set 60
```

Configuring Password Strength Enforcement (CLI)

To set password strength enforcement, enter the following command in root view:

```
root> platform security access-control password enforce-strength set <enforce-strength>
```

Table 166 Password Strength Enforcement CLI Parameters

Parameter	Input Type	Permitted Values	Description
password aging	Number	0, 20 - 90	The number of days that user passwords will remain valid from the first time the user logs into the system.
enforce-strength	Boolean	Yes no	When yes is selected: Password length must be at least eight characters. Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted. The last five password you used cannot be reused.

Example

The following command enables password strength enforcement:

```
root> platform security access-control password enforce-strength set yes
```

Forcing Password Change Upon First Login (CLI)

To determine whether the system requires users to change their password the first time they log into the system, enter the following command in root view.

```
root> platform security access-control password first-login set <first-login>
```

To require users to change their password the first time they log in, enter the following command in root view:

```
root> platform security access-control password first-login set yes
```

Table 167 Force Password Change on First Time Login CLI Parameters

Parameter	Input Type	Permitted Values	Description
first-login	Boolean	Yes no	When yes is selected, the system requires users to change their password the first time they log in.

Displaying the System Password Settings (CLI)

Use the following command to display the system password settings:

```
root> platform security access-control password show-all
```

Configuring Users (CLI)

This section includes:

- [User Configuration Overview \(CLI\)](#)
- [Configuring User Profiles \(CLI\)](#)
- [Configuring User Accounts \(CLI\)](#)

Related topics:

- [Logging On \(CLI\)](#)

User Configuration Overview (CLI)

User configuration is based on the Role-Based Access Control (RBAC) model. According to the RBAC model, permissions to perform certain operations are assigned to specific roles. Users are assigned to particular roles, and through those role assignments acquire the permissions to perform particular system functions.

In the PTP 850 GUI, these roles are called user profiles. Up to 50 user profiles can be configured. Each profile contains a set of privilege levels per functionality group, and defines the management protocols (access channels) that can be used to access the system by users to whom the user profile is assigned.

The system parameters are divided into the following functional groups:

- Security
- Management
- Radio
- TDM
- Ethernet
- Synchronization

A user profile defines the permitted access level per functionality group. For each functionality group, the access level is defined separately for read and write operations. The following access levels can be assigned:

- **None** – No access to this functional group.
- **Normal** – The user has access to parameters that require basic knowledge about the functional group.
- **Advanced** – The user has access to parameters that require advanced knowledge about the functional group, as well as parameters that have a significant impact on the system as a whole, such as restoring the configuration to factory default settings.

Configuring User Profiles (CLI)

User profiles enable you to define system access levels. Each user must be assigned a user profile. Each user profile contains a detailed set of read and write permission levels per functionality group.

The system includes a number of pre-defined user profiles. You can edit these profiles, and add user profiles. Together, the system supports up to 50 user profiles.

To create a new user profile with default settings, enter the following command:

```
root> platform security access-control profile add name <profile-name>
```

To edit the settings of a user profile, enter the following command:

```
root> platform security access-control profile edit group name <profile-name> group <group> write-lvl <write-lvl> read-lvl <read-lvl>
```

Table 168 User Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile--name	Text String	Up to 49 characters	The name of the user profile.
group	Variable	security management radio ethernet sync	The functionality group for which you are defining access levels.
write-lvl	Variable	none normal advanced	The read level for the functionality group.
read-lvl	Variable	none normal advanced	The read level for the functionality group.

Example

The following commands create a user profile called “operator” and give users to whom this profile is assigned normal write privileges for all system functionality and advanced read privileges for all functionality except security features.

```
root> platform security access-control profile add name operator
root> platform security access-control profile edit group name operator
group security write-lvl normal read-lvl normal group management write-
lvl normal read-lvl advanced group radio write-lvl normal read-
lvl advanced group ethernet write-lvl normal read-lvl advanced group sync
write-lvl normal read-lvl advanced
```

Limiting Access Protocols for a User Profile (CLI)

The user profile can limit the access channels that users with the user profile can use to access the system. By default, a user profile includes all access channels.

Use the following command to limit the protocols users with this user profile can use to access the system.

```
root> platform security access-control profile edit mng-channel name
<profile-name> channel-type <channel-type> allowed <allowed>
```

Table 169 User Profile Access Protocols CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile--name	Text String	Up to 49 characters	The name of the user profile.
profile-name	Text String	Up to 49 characters	The name of the user profile.
channel-type	Variable	Serial Web NMS Telnet SSH	The access channel type allowed or disallowed by the command for users with this user profile.
allowed	Boolean	yes no	yes – Users with this user profile can access the access channel type defined in the preceding parameter. no - Users with this user profile cannot access the access channel type defined in the preceding parameter.

Example

The following command prevents users with the user profile “operator” from accessing the system via NMS:

```
root> platform security access-control profile edit mng-channel name
operator channel-type NMS allowed no
```

Configuring User Accounts (CLI)

You can configure up to 2,000 users. Each user has a user name, password, and user profile. The user profile defines a set of read and write permission levels per functionality group (see [Configuring User Profiles \(CLI\)](#)).

To create a new user account, enter the following command:

```
root> platform security access-control user-account add user-name <user-
name> profile-name <profile-name> expired-date <expired-date>
```

When you create a new user account, the system will prompt you to enter a default password. If Enforce Password Strength is activated (refer to [Configuring Password Strength Enforcement \(CLI\)](#)), the password must meet the following criteria:

- Password length must be at least eight characters.
- Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
- The last five password you used cannot be reused.

To block or unblock a user account, enter the following command:

```
root> platform security access-control user-account block user-name
<user-name> block <block>
```

To change a user account's expiration date, enter the following command:


```
root> platform security access-control user-account edit expired-date
user-name <user-name> expired-date <expired-date>
```

To change a user account's profile, enter the following command:

```
root> platform security access-control user-account edit profile-name
user-name <user-name> profile-name <profile name>
```

To delete a user account, enter the following command:

```
root> platform security access-control user-account delete user-name
<user-name>
```

To display all user accounts configured on the unit and their settings, including whether the user is currently logged in and the time of the user's last logout, enter the following command:

```
root> platform security access-control user-account show
```

To display the settings of a specific user account, enter the following command:

```
root> platform security access-control user-account show user-name <user-
name>
```

Table 170 User Accounts CLI Parameters

Parameter	Input Type	Permitted Values	Description
user-name	Text String	Up to 32 characters	The name of the user profile.
profile name	Text String	Up to 49 characters	The name of the User Profile you want to assign to the user. The User Profile defines the user's access permissions per functionality group.
expired-date	Date	Use the format: YYYY-MM-DD	Optional. The date on which the user account will expire. On this date, the user automatically becomes inactive.
block	Variable	yes no	yes - blocks the account. no - unblocks the account.

Example

The following command creates a user account named Tom_Jones, with user profile "operator". This user's account expires on February 1, 2014.

```
root> platform security access-control user-account add user-name
Tom_Jones profile-name operator expired-date 2014-02-01
```

Configuring X.509 CSR Certificates and HTTPS (CLI)

The web interface protocol for accessing PTP 850 can be configured to HTTP (default) or HTTPS. It cannot be set to both at the same time.

Before setting the protocol to HTTPS, you must:

- 1 Create and upload a CSR file. See [Generating a Certificate Signing Request \(CSR\) File \(CLI\)](#).
- 2 Download the certificate to the PTP 850 and install the certificate. See [Downloading a Certificate \(CLI\)](#).
- 3 Enable HTTPS. See [Enabling HTTPS \(CLI\)](#).

When uploading a CSR and downloading a certificate, the PTP 850 functions as an SFTP client. You must install SFTP server software on the PC or laptop you are using to perform the upload or download. For details, see [Installing and Configuring an FTP or SFTP Server](#).



Note

For these operations, SFTP must be used.

This section includes:

- [Generating a Certificate Signing Request \(CSR\) File \(CLI\)](#)
- [Downloading a Certificate \(CLI\)](#)
- [Enabling HTTPS \(CLI\)](#)
- [Generating a Certificate Signing Request \(CSR\) File \(CLI\)](#)

Generating a Certificate Signing Request (CSR) File (CLI)

To set the CSR parameters, enter the following command in root view:

```
root> platform security csr-set-parameters common-name <common-name>  
country <country> state <state> locality <locality> organization  
<organization> org-unit <org-unit> email <email> file-format <file-  
format>
```

To display the currently-configured CSR parameters, enter the following command in root view:

```
root> platform security csr-show-parameters
```

If the IP address family is configured to be IPv4, enter the following command in root view to configure the SFTP server parameters for the CSR file upload:

```
root> platform security csr-set-server-parameters server-ipv4 <server-  
ipv4> server-path <server-path> filename <filename> server-username  
<username> server-password <password>
```

If the IP address family is configured to be IPv6, enter the following command in root view to configure the SFTP server parameters for the CSR file upload:

```
root> platform security csr-set-server-parameters server-ipv6 <server-  
ipv6> server-path <server-path> filename <filename> server-username  
<username> server-password <password>
```

To display the currently-configured SFTP parameters for CSR upload, enter the following command in root view:

```
root> platform security csr-show-server-parameters
```

To generate and upload a CSR, enter the following command in root view:

```
root> platform security csr-generate-and-upload
```

To display the status of a pending CSR generation and upload operation, enter the following command in root view:

```
root> platform security csr-generate-and-upload-show-status
```

Table 171 CSR Generation and Upload CLI Parameters

Parameter	Input Type	Permitted Values	Description
common name	String		The fully-qualified domain name for your web server. You must enter the exact domain name.
country	String		The two-letter ISO abbreviation for your country (e.g., US)
state	String		The state, province, or region in which the organization is located. Do not abbreviate.
locality	String		The city in which the organization is legally located.
organization	String		The exact legal name of your organization. Do not abbreviate.
org-unit	String		The division of the organization that handles the certificate.
email	String		An e-mail address that can be used to contact your organization.
file-format	Variable	PEM DER	The file format of the CSR. In this version, only PEM is supported.
server-ipv4	Dotted decimal format.	Any valid IPv4 IP address.	The IPv4 address of the PC or laptop you are using as the SFTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the SFTP server.

Parameter	Input Type	Permitted Values	Description
server-path	Text String		The directory path to which you are uploading the CSR. Enter the path relative to the SFTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".
filename	Text String		The name you want to give the CSR.
username	Text String		The user name for the SFTP session.
password	Text String		The password for the SFTP session. To configure the SFTP settings without a password, simply omit this parameter.

Downloading a Certificate (CLI)

If the IP address family is configured to be IPv4, enter the following command in root view to configure the SFTP server parameters for downloading a certificate:

```
root> platform security certificate-set-download-parameters server-ipv4
<server-ipv4> server-path <server-path> filename <filename> server-
username <username> server-password <password>
```

If the IP address family is configured to be IPv6, enter the following command in root view to configure the SFTP server parameters for downloading a certificate:

```
root> platform security certificate-set-download-parameters server-ipv6 <
server-ipv6> server-path <server-path> filename <filename> server-
username <username> server-password <password>
```

To display the currently-configured SFTP parameters for downloading a certificate, enter the following command in root view:

```
root> platform security certificate-show-download-parameters
```

To download a certificate, enter the following command in root view:

```
root> platform security certificate-download
```

To display the status of a pending certificate download, enter the following command in root view:

```
root> platform security certificate-download-show-status
```

To install a certificate, enter the following command in root view:

```
root> platform security certificate-install
```

Table 172 Certificate Download and Install CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 IP address.	The IPv4 address of the PC or laptop you are using as the SFTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the SFTP server.
server-path	Text String		The directory path from which you are downloading the certificate. Enter the path relative to the SFTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".
filename	Text String		The certificate's file name in the SFTP server.
username	Text String		The user name for the SFTP session.
password	Text String		The password for the SFTP session. To configure the SFTP settings without a password, simply omit this parameter.

Enabling HTTPS (CLI)

By default, HTTP is used by PTP 850 as its web interface protocol.

To change the protocol to HTTPS, enter the following command in root view:

```
root> platform security url-protocol-set url-protocol https
```



Note

Make sure you have installed a valid certificate in the PTP 850 before changing the web interface protocol to HTTPS. Failure to do this may prevent users from accessing the Web EMS.

To change the protocol back to HTTP, enter the following command in root view:

```
root> platform security url-protocol-set url-protocol http
```

To display which protocol is currently enabled, enter the following command in root view:

```
root> platform security url-protocol-show
```

Configuring HTTPS Cipher Hardening (CLI)

You can configure the PTP 850E to operate in HTTPS strong mode. In HTTPS strong mode, SSLv3, TLSv1.0, and TLSv1.1 are disabled completely and only certain ciphers are supported in TLSv1.2.

For a list of supported HTTPS ciphers, including an indication of which ciphers are supported in HTTPS strong mode, refer to *Annex B – Supported Ciphers for Secured Communication Protocols* in the Release Notes for the CeraOS version you are using.

To set HTTPS strong mode, enter the following command:

```
root> platform security https-ciphers-hardening-level-set level strong
```

To set HTTPS normal mode, enter the following command:

```
root> platform security https-ciphers-hardening-level-set level normal
```

Note: The default HTTP cipher mode is normal.

To display the current HTTPS cipher mode, enter the following command:

```
root> platform security https-ciphers-hardening-level-show
```

Blocking Telnet Access (CLI)

You can block telnet access to the unit. By default, telnet access is not blocked.

To block telnet access, enter the following command:

```
root> platform security protocols-control telnet admin set disable
```

To unblock telnet access, enter the following command:

```
root> platform security protocols-control telnet admin set enable
```

To display whether telnet is currently allowed (enable) or blocked (disable), enter the following command:

```
root> platform security protocols-control telnet show
```

**Note**

When you block telnet, any current telnet sessions are immediately disconnected.

Uploading the Security Log (CLI)

The security log is an internal system file which records all changes performed to any security feature, as well as all security related events.

In order to read the security log, you must upload the log to an FTP or SFTP server. PTP 850 works with any standard FTP or SFTP server. For details, see [Installing and Configuring an FTP or SFTP Server](#).

Before uploading the security log, you must install and configure the FTP server on the laptop or PC from which you are performing the download. See [Installing and Configuring an FTP or SFTP Server](#).

To set the FTP parameters for security log upload, enter the following command in root view:

```
root> platform security file-transfer set server-path <server-path> file-
name <file-name> ip-address <ip-address> protocol <protocol> username
<username> password <password>
```

To display the FTP channel parameters for uploading the security log, enter the following command in root view:

```
root> platform security file-transfer show configuration
```

To upload the security log to your FTP server, enter the following command in root view:

```
root> platform security file-transfer operation set upload-security-log
```

To display the progress of a current security log upload operation, enter the following command in root view:

```
root> platform security file-transfer show operation
```

To display the result of the most recent current security log upload operation, enter the following command in root view:

```
root> platform security file-transfer show status
```

Table 173 Security Log CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-path	Text String		The directory path to which you are uploading the security log. Enter the path relative to the FTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".
file-name	Text String		The name you want to give the file you are uploading.
ip-address	Dotted decimal format.	Any valid IP address.	The IP address of the FTP server.

Parameter	Input Type	Permitted Values	Description
protocol	Variable	ftp sftp	
username	Text String		The user name for the FTP or SFTP session.
password	Text String		The password for the FTP or SFTP session. To configure the FTP settings without a password, simply omit this parameter.

Example

The following commands configure an FTP channel for security log upload to IP address 192.168.1.80, in the directory “current”, with file name “security_log_Oct8.zip”, user name “anonymous”, and password “12345”, and initiate the upload:

```
root> platform security file-transfer set server-path \current file-name  
security_log_Oct8.zip ip-address 192.168.1.80 protocol ftp username  
anonymous password 12345  
root> platform security file-transfer operation set upload-security-log
```

Uploading the Configuration Log (CLI)

The configuration log lists actions performed by users to configure the system. This file is mostly used for security, to identify suspicious user actions. It can also be used for troubleshooting.

In order to upload the configuration log, you must install an FTP or SFTP server on the laptop or PC from which you are performing the upload. PTP 850 works with any standard FTP or SFTP server. For details, see [Installing and Configuring an FTP or SFTP Server](#).

To set the FTP or SFTP parameters for configuration log export, enter the following command in root view:

```
root> platform security configuration-log-upload-params set path <path>
file-name <file-name> ip-address <ip-address> protocol <protocol>
username <username> password <password>
```

To display the FTP or SFTP parameters for configuration log export, enter the following command in root view:

```
root> platform security configuration-log-upload-params show
```

To export the configuration log, enter the following command in root view:

```
root> platform security configuration-log upload
```

To display the status of a configuration log export operation, enter the following command in root view

```
root> platform security configuration-log-upload-status show
```

Table 174 Configuration Log CLI Parameters

Parameter	Input Type	Permitted Values	Description
path	Text String		The directory path to which you are exporting the configuration log. Enter the path relative to the FTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".

Parameter	Input Type	Permitted Values	Description
file-name	Text String		<p>The name you want to give the file you are exporting.</p> <p>Note: You must add the suffix .zip to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix .zip manually. For example: UnitInfo.zip</p> <p>If the Unit Information file is exported several times consecutively, the file itself will not be replaced. Instead, the filename will be updated by time stamp. For example: UnitInfo.zip.11-05-14 03-31-04</p>
ip-address	Dotted decimal format.	Any valid IP address.	The IP address of the PC or laptop you are using as the FTP or SFTP server.
protocol	Variable	ftp sftp	The file transfer protocol.
username	Text String		The user name for the FTP or SFTP session.
password	Text String		The password for the FTP or SFTP session. To configure the FTP or SFTP settings without a password, simply omit this parameter.

**Note**

The path and file name, together, cannot be more than:

If the IP address family is configured to be IPv4: 236 characters

If the IP address family is configured to be IPv6: 220 characters

Examples

The following commands configure an FTP channel for configuration log export to IP address 192.168.1.99, in the directory “current”, with file name “cfg_log”, user name “anonymous”, and password “12345.”

```
root> platform security configuration-log-upload-params set path \file-
name cfg_log ip-address 192.168.1.99 protocol ftp username anonymous
password 12345
```

```
root> platform unit-info channel set protocol frp
```

The following command exports the configuration log to the external server location:

```
root> platform security configuration-log upload
```

Chapter 19: Alarm Management and Troubleshooting (CLI)

This section includes:

- [Viewing Current Alarms \(CLI\)](#)
- [Viewing the Event Log \(CLI\)](#)
- [Editing Alarm Text and Severity \(CLI\)](#)
- [Configuring a Timeout for Trap Generation \(CLI\)](#)
- [Configuring Voltage Alarm Thresholds and Displaying Voltage PMs \(CLI\)](#)
- [Uploading Unit Info \(CLI\)](#)
- [Activating the Radio Logger \(CLI\)](#)
- [Performing Diagnostics \(CLI\)](#)
- [Working in CW Mode \(Single or Dual Tone\) \(CLI\)](#)

Viewing Current Alarms (CLI)

To display all alarms currently raised on the unit, enter the following command in root view:

```
root> platform status current-alarm show module unit
```

To display the most severe alarm currently raised in the unit, enter the following command in root view:

```
root> platform status current-alarm show most-severe-alarm module unit
```

Viewing the Event Log (CLI)

The Event Log displays a list of current and historical events and information about each event.

To display the event log, enter the following command in root view:

```
root> platform status event-log show module unit
```

To clear the event log, enter the following command in root view:

```
root> platform status event-log clear module unit
```


Editing Alarm Text and Severity (CLI)

You can view a list of alarm types, edit the severity level assigned to individual alarm types, and add additional descriptive text to individual alarm types.

This section includes:

- [Displaying Alarm Information \(CLI\)](#)
- [Editing an Alarm Type \(CLI\)](#)
- [Setting Alarms to their Default Values \(CLI\)](#)

Displaying Alarm Information (CLI)

To display a list of all alarm types and their severity levels and descriptions, enter the following command in root view:

```
root> platform status alarm-management show alarm-id all
```

Editing an Alarm Type (CLI)

To edit an alarm type’s severity level, enter the following command in root view:

```
root> platform status alarm-management set alarm-id <alarm-id> severity-level <severity-level>
```

To add descriptive information to an alarm type, enter the following command in root view:

```
root> platform status alarm-management set alarm-id <alarm-id> additional-text <additional-text>
```

Table 175 Editing Alarm Text and Severity CLI Parameters

Parameter	Input Type	Permitted Values	Description
alarm-id	Number	All valid alarm type IDs, depending on system configuration	Enter the unique Alarm ID that identifies the alarm type.
severity-level	Variable	indeterminate critical major minor warning	The severity of the alarm, as displayed to users.
additional-text	Text String	255 characters	An additional text description of the alarm type.

Example

The following command changes the severity level of alarm type 401 (Ethernet Loss of Carrier) to minor:

```
root> platform status alarm-management set alarm-id 401 severity-level minor
```

Setting Alarms to their Default Values (CLI)

To restore an alarm type’s severity level and description to their default values, enter the following command in root view:

```
root> platform status alarm-management set alarm-id <alarm-id> restore default
```

To restore the severity levels and descriptions of all alarm types to their default values, enter the following command in root view:

```
root> platform status alarm-management set all default
```

Table 176 Restoring Alarms to Default CLI Parameters

Parameter	Input Type	Permitted Values	Description
alarm-id	Number	All valid alarm type IDs, depending on system configuration	Enter the unique Alarm ID that identifies the alarm type.

Example

The following command restores alarm type 401 (Ethernet Loss of Carrier) to its default severity level:

```
root> platform status alarm-management set alarm-id 401 restore default
```

Configuring a Timeout for Trap Generation (CLI)

You can configure a wait time of up to 120 seconds after an alarm is cleared in the system before the alarm is actually reported as being cleared. This prevents traps flooding the NMS in the event that some external condition causes the alarm to be raised and cleared continuously.

This means that when the alarm is cleared, the alarm continues to be displayed and no clear alarm trap is sent until the timeout period is finished.

The timeout for trap generation can be configured via CLI. By default, the timeout is 10 seconds.

**Note**

If the unit is upgraded from an earlier version to System Release 10.0 or higher, the timeout retains its previous value until it is changed. That means if it was never configured, it retains its previous default value of 0. If the unit is set to its factory default configuration, the timeout is set to 10 seconds.

To configure the timeout (in seconds) for trap generation, enter the following command in root view:

```
root> platform status alarm-management alarm-stabilization-set time <0-120>
```

To disable the timeout for trap generation, enter the following command in root view:

```
root> platform status alarm-management alarm-stabilization-set time 0
```

To display the current trap generation timeout, enter the following command in root view:

```
root> platform status alarm-management alarm-stabilization-show
```

The following command sets a trap generation timeout of 60 seconds:

```
root> platform status alarm-management alarm-stabilization-set time 60
```

Configuring Voltage Alarm Thresholds and Displaying Voltage PMs (CLI)

You can configure undervoltage and overvoltage alarm thresholds.

The default thresholds for PTP 850E are:

- Undervoltage Raise Threshold: 36V
- Undervoltage Clear Threshold: 38V
- Overvoltage Raise Threshold: 60V
- Overvoltage Clear Threshold: 58V

These thresholds determine when the following alarms are raised and cleared:

- Alarm #32000: Under voltage
- Alarm #32001: Over voltage

To display the current thresholds, enter the following command in root view.

```
root> platform management voltage thresholds show
```

To change the threshold for raising an undervoltage alarm, enter the following command in root view:

```
root> platform management undervoltage set raise-threshold <0-100>
```

To change the threshold for clearing an undervoltage alarm, enter the following command in root view:

```
root> platform management undervoltage set clear-threshold <0-100>
```

To change the threshold for raising an overvoltage alarm, enter the following command in root view:

```
root> platform management overvoltage set raise-threshold <0-100>
```

To change the threshold for clearing an overvoltage alarm, enter the following command in root view:

```
root> platform management overvoltage set clear-threshold <0-100>
```

You can display voltage PMs that indicate, per 15-minute and 24-hour periods:

- The number of seconds the unit was in an undervoltage state during the measured period.
- The number of seconds the unit was in an overvoltage state during the measured period.
- The lowest voltage during the measured period.
- The highest voltage during the measured period.

To display voltage PMs, enter the following command in root view:

```
root> platform management voltage pm show pm-interval-type  
<all|15min|24hr>
```

For example:

```
root>platform management voltage pm show pm-interval-type 24hr
```

Voltage PM table:

Interface Location	PM Type	Time Interval	Integrity	Interval time stamp	Minimum Voltage (V)	Maximum Voltage (V)	Undervoltage Seconds	Overvoltage Seconds
PDC #1	24hr	0	1	14-05-2000, 03:00:00	48	48	0	0
PDC #1	24hr	1	1	14-05-2000, 00:00:00	48	48	0	0
PDC #1	24hr	6	1	09-05-2000, 23:00:00	48	48	0	0
PDC #1	24hr	16	1	30-04-2000, 03:15:00	48	48	0	0

```
root>
```

The Integrity column indicates whether the PM is valid:

- 0 indicates a valid entry.
- 1 indicates an invalid entry. This can be caused by a power surge or power failure that occurred during the interval.

Uploading Unit Info (CLI)

You can generate a unit information file, which includes technical data about the unit. This file can be forwarded to customer support, at their request, to help in analyzing issues that may occur.



Note

For troubleshooting, it is important that an updated configuration file be included in Unit Info files that are sent to customer support. To ensure that an up-to-date configuration file is included, it is recommended to back up the unit’s configuration before generating the Unit Info file.

In order to export a unit information file, you must install an FTP or SFTP server on the laptop or PC from which you are performing the upload. PTP 850 works with any standard FTP or SFTP server. For details, see [Installing and Configuring an FTP or SFTP Server](#).

To set the FTP or SFTP parameters for unit information file export, enter one of the following commands in root view. If the IP protocol selected in [platform management ip set ip-address-family](#) is IPv4, enter the destination IPv4 address. If the selected IP protocol is IPv6, enter the destination IPv6 address.

```

root> platform unit-info channel server set ip-address <server-ipv4>
directory <directory> filename <filename> username <username> password
<password>

root> platform unit-info channel server-ipv6 set ip-address <server-ipv6>
directory <directory> filename <filename> username <username> password
<password>
    
```

To set the protocol for unit information file export, enter the following command in root view.

```

root> platform unit-info channel set protocol <protocol>
    
```

To display the FTP or SFTP parameters for unit information file export, enter one of the following commands in root view:

```

root> platform unit-info-file channel show
root> platform unit-info-file channel-ipv6 show
    
```

To create a unit information file based on the current state of the system, enter the following command in root view:

```

root> platform unit-info-file create
    
```

To export the unit information file you just created, enter the following command in root view:

```

root> platform unit-info-file export
    
```

To display the status of a unit information file export operation, enter the following command in root view

```

root> platform unit-info-file status show
    
```

Table 177 Uploading Unit Info CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 address.	The IPv4 address of the PC or laptop you are using as the FTP or SFTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the FTP or SFTP server.
directory	Text String		The directory path to which you are exporting the unit information file. Enter the path relative to the FTP or SFTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/".
filename	Text String		The name you want to give the file you are exporting. Note: You must add the suffix .zip to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix .zip manually.
username	Text String		The user name for the FTP or SFTP session.
password	Text String		The password for the FTP or SFTP session. To configure the FTP or SFTP settings without a password, simply omit this parameter.
protocol	Variable	ftp sftp	The file transfer protocol.

The following commands configure an FTP or SFTP channel for configuration log export to IP address 192.168.1.99, in the directory "current", with file name "cfg_log", user name "anonymous", and password "12345."

```
root> platform security configuration-log-upload-params set path \\ file-  
name cfg_log ip-address 192.168.1.99 protocol ftp username anonymous  
password 12345  
root> platform unit-info channel set protocol ftp
```

The following commands create a unit information file and export the file to the external server location:

```
root> platform unit-info-file create  
root> platform unit-info-file export
```

Example

The following commands configures an FTP channel for unit information file export to IP address 192.168.1.99, in the directory “current”, with file name “version_8_backup.zip”, user name “anonymous”, and password “12345.”

```
root> platform unit-info channel server set ip-address 192.168.1.99  
directory \current filename version_8_backup.zip username anonymous  
password 12345  
root> platform unit-info channel set protocol ftp
```

The following commands create a unit information file and export the file to the external server location:

```
root> platform unit-info-file create  
root> platform unit-info-file export
```


Activating the Radio Logger (CLI)

The Radio Logger, when it is activated, gathers technical data about the radio and its operation. By default, the Radio Logger is inactive. It should only be activated by technical support personnel, or by the customer upon request of Customer Support team. Data gathered by the Radio Logger is added to the Unit Info file, which can be exported from the unit and sent to Customer Support upon their request. See *Uploading Unit Info (CLI)*.

Note: In order to conserve CPU resources, do not activate the Radio Logger unless it is necessary for unit diagnostic purposes, and do not leave it active longer than necessary.

To activate the Radio Logger, enter the following command in root view:

```
root> logger start logger-type radio logger-duration <1-1440> slot1 1
port1 1 slot2 2 port2 2
```

The `logger-duration` parameter is set in minutes. The following command activates the logger for 40 minutes:

```
root> logger start logger-type radio logger-duration 40 slot1 2 port1 1
```

To display whether the Radio Logger is currently active, enter the following command in root view:

```
root> logger get status logger-type radio
```

For example, the following display indicates the Radio Logger has been set on both carriers for 20 minutes, and that the Logger is set to run for an additional 1191 seconds:

```
root> logger get status logger-type radio
Logger status:
Logger duration(in minutes): 20
Logger time left(in seconds): 1191
Active instances list:
Slot 1 Port 1
root>
```

To stop the Radio Logger manually, enter the following command in root view:

```
root> logger stop logger-type radio
```

To delete all data that has been saved by the Radio Logger, enter the following command in root view:

```
root> logger delete logger files<logger-type>.
```



Important Note: Whenever you activate the Radio Logger, any previous Radio Logger results are deleted.

Performing Diagnostics (CLI)

This section includes:

- [Performing Radio Loopback \(CLI\)](#)
- [Performing Ethernet Loopback \(CLI\)](#)

Performing Radio Loopback (CLI)

You can perform loopback on a radio.

To set the timeout for a radio loopback, enter the following command:

```
radio[x/x]> radio loopbacks-timeout set duration <duration>
```

To display the radio loopback timeout, enter the following command:

```
radio[x/x]>radio loopbacks-timeout show
```

To activate an RF loopback, enter the following command:

```
radio[x/x]>rf loopback-rf set admin <admin>
```

Table 178 Radio Loopback CLI Parameters

Parameter	Input Type	Permitted Values	Description
duration	Number	0 – 1440	The timeout, in minutes, for automatic termination of a loopback. A value of 0 indicates that there is no timeout.
admin	Variable	on off	Set on to initiate an RF loopback.

Examples

The following commands initiate an RF loopback on radio carrier 1 with a timeout of two minutes:

```
radio[2/1]> radio loopbacks-timeout set duration 2
radio[2/1]>rf loopback-rf set admin on
```

Performing Ethernet Loopback (CLI)

Ethernet loopbacks can be performed on any logical Ethernet interface except a LAG. When Ethernet loopback is enabled on an interface, the system loops back all packets ingressing the interface. This enables loopbacks to be performed over the link from other points in the network.

To configure loopback on an Ethernet interface, go to interface view for the interface and enter the following command:

```
eth type eth[x/x]> loopback admin <loopback-admin-state>
```

To configure the loopback duration time, go to interface view for the interface and enter the following command:

```
eth type eth[x/x]> loopback set duration <loopback-duration>
```

You can select whether to swap DA and SA MAC addresses during the loopback. Swapping addresses prevents Ethernet loops from occurring. It is recommended to enable MAC address swapping if LLDP is enabled.

To configure MAC address swapping, go to interface view for the interface and enter the following command:

```
eth type eth[x/x]> loopback swap-mac-address admin <MAC_swap-admin-state>
```

To view loopback status, go to interface view for the interface and enter the following command:

```
eth type eth[x/x]> loopback status show
```

Table 179 Ethernet Loopback CLI Parameters

Parameter	Input Type	Permitted Values	Description
loopback-admin-state	Variable	enable disable	Enter enable to enable Ethernet loopback on the interface, or disable to disable Ethernet loopback on the interface.
loopback-duration	Number	1 - 900	The loopback duration time, in seconds.
MAC_swap-admin-state	Variable	enable disable	Enter enable to enable MAC address swapping, or disable to disable MAC address swapping.

Examples

The following command enables Ethernet loopback on Ethernet interface 2.

```
eth type eth [1/2]> loopback admin enable
```

The following command sets the loopback duration time to 900 seconds.

```
eth type eth [1/2]> loopback set duration 900
```

The following command enables MAC address swapping during the loopback.

```
eth type eth [1/2]> loopback swap-mac-address admin enable
```

The following command displays Ethernet port loopback status.

```
eth type eth [1/2]> loopback status show
```

Configuring Service OAM (SOAM) Fault Management (FM) (CLI)

This section includes:

- [SOAM Overview \(CLI\)](#)
- [Configuring MDs \(CLI\)](#)

- [Configuring MA/MEGs \(CLI\)](#)
- [Configuring MEPs \(CLI\)](#)
- [Displaying MEP and Remote MEP Attributes \(CLI\)](#)
- [Displaying Detailed MEP Error Information \(CLI\)](#)
- [Performing Loopback \(CLI\)](#)

SOAM Overview (CLI)

The Y.1731 standard and the MEF-30 specifications define Service OAM (SOAM). SOAM is concerned with detecting, isolating, and reporting connectivity faults spanning networks comprising multiple LANs, including LANs other than IEEE 802.3 media.

Y.1731 Ethernet FM (Fault Management) consists of three protocols that operate together to aid in fault management:

- Continuity check
- Link trace
- Loopback



Note

Link trace is planned for future release.

PTP 850 utilizes these protocols to maintain smooth system operation and non-stop data flow.

The following are the basic building blocks of FM:

- **MD (Maintenance Domain)** – An MD defines the management space on a network, typically owned and operated by a single entity, for which connectivity faults are managed via SOAM.
- **MA/MEG (Maintenance Association/Maintenance Entity Group)** – An MA/MEG contains a set of MEPs or MIPs.
- **MEP (MEG End Points)** – Each MEP is located on a service point of an Ethernet service at the boundary of the MEG. By exchanging CCMs (Continuity Check Messages), local and remote MEPs have the ability to detect the network status, discover the MAC address of the remote unit/port where the peer MEP is defined, and identify network failures.
- **MIP –(MEG Intermediate Points)** – Similar to MEPs, but located inside the MEG and can only respond to, not initiate, CCM messages.
- **CCM (Continuity Check Message)** – MEPs in the network exchange CCMs with their peers at defined intervals. This enables each MEP to detect loss of connectivity or failure in the remote MEP.

Configuring MDs (CLI)

In the current release, you can define one MD, with an **MD Format** of **None**.

To add an MD, enter the following command in root view:

```
root> ethernet soam md create md-id <md-id> md-format none md-name <md-
name> md-level <md-level>
```



Note

Support for MDs with the MD format Character String is planned for future release. In this release, the software enables you to configure such MDs, but they have no functionality.

The following command creates MD 5, named TR-988 with maintenance level 5.

```
root> ethernet soam md create md-id 5 md-format none md-name TR-988 md-
level 5
```

To delete an MD, enter the following command in root view. Before deleting an MD, you must delete any MA/MEG associated with the MD.

```
root> ethernet soam md delete md-id <md-id>
```

To display a list of MDs and their attributes, enter the following command in root view:

```
root> ethernet soam md show
```

Table 180 Maintenance Domain CLI Parameters

Parameter	Input Type	Permitted Values	Description
md-id	Number	1-4294967295	
md-name	String	Up to 43 alphanumeric characters.	An identifier for the MD. The MD Name should be unique over the domain.
md-level	Number	0-7	<p>The maintenance level of the MD. The maintenance level ensures that the CFM frames for each domain do not interfere with each other. Where domains are nested, the encompassing domain must have a higher level than the domain it encloses. The maintenance level is carried in all CFM frames that relate to that domain. The maintenance level must be the same on both sides of the link.</p> <p>Note: In the current release, the maintenance level is not relevant to the SOAM functionality.</p>

Configuring MA/MEGs (CLI)

You can configure up to 1280 MEGs per network element. MEGs are classified as Fast MEGs or Slow MEGs according to the CCM interval (see [Table 226](#)):

- Fast MEGs have a CCM interval of 1 second.
- Slow MEGs have a CCM interval of 10 seconds, 1 minute, or 10 minutes.

You can configure up to 64 MEP pairs per network element.

To add an MA/MEG, enter the following command in root view:

```
root> ethernet soam meg create meg-id <meg-id> meg-fmt charString meg-
name <meg-name> meg-level <meg-level> service-id <0-4095>
```

**Note**

In the current release, charString is the only available MEG name format.

The following command creates MEG ID 1, named FR-10, with MEG level 4, assigned to Ethernet service 20.

```
root> ethernet soam meg create meg-id 1 meg-fmt charString meg-name FR-10
meg-level 4 service-id 20
```

To set the interval at which CCM messages are sent within the MEG, enter the following command in root view:

```
root> ethernet soam meg ccm-interval set meg-id <meg-id> ccm <ccm>
```

The following command sets an interval of one second between CCM messages for MEG 1.

```
root> ethernet soam meg ccm-interval set meg-id 1 ccm interval1s
```

To determine whether MIPs are created on the MEG, enter the following command in root view:

```
root> ethernet soam meg mip set meg-id <meg-id> mhf <1-
4|defMHFnone|defMHFdefault|defMHFexplicit|defMHFdefer>
```

The following command creates MIPs on any service point in the MEG:

```
root> ethernet soam meg mip set meg-id 1 mhf defMHFdefault
```

To delete a MEG, enter the following command in root view:

```
root> ethernet soam meg delete <meg-id> ccm <ccm>
```

**Note**

To can only delete a MEG if no MEPS or MIPs are attached to the MEP.

To display a list of all MEGs configured on the unit, enter the following command in root view:

```
root> ethernet soam meg show
```

To display MEG attributes, including the number of MEPS, local MEPS, and MIPs attached to the MEG, enter the following command in root view:

```
root> ethernet soam meg attributes show meg-id <meg-id>
```

Table 181 SOAM MEG CLI Configuration Parameters

Parameter	Input Type	Permitted Values	Description
meg-id	Number	1-4294967295	Enter an ID for the MEG.
meg-name	String	Up to 44 alphanumeric characters	A name to identify the MEG.

Parameter	Input Type	Permitted Values	Description
meg-level	Number	0-7	<p>The MEG level must be the same for MEGs on both sides of the link. Higher levels take priority over lower levels.</p> <p>If MEGs are nested, the OAM flow of each MEG must be clearly identifiable and separable from the OAM flows of the other MEGs. In cases where the OAM flows are not distinguishable by the Ethernet layer encapsulation itself, the MEG level in the OAM frame distinguishes between the OAM flows of nested MEGs.</p> <p>Eight MEG levels are available to accommodate different network deployment scenarios. When customer, provider, and operator data path flows are not distinguishable based on means of the Ethernet layer encapsulations, the eight MEG levels can be shared among them to distinguish between OAM frames belonging to nested MEGs of customers, providers and operators. The default MEG level assignment among customer, provider, and operator roles is:</p> <p>The customer role is assigned MEG levels 6 and 7</p> <p>The provider role is assigned MEG levels 3 through 5</p> <p>The operator role is assigned MEG levels: 0 through 2</p> <p>The default MEG level assignment can be changed via a mutual agreement among customer, provider, and/or operator roles.</p> <p>The number of MEG levels used depends on the number of nested MEGs for which the OAM flows are not distinguishable based on the Ethernet layer encapsulation.</p>
service-id	Number	0-4095	Assign the MEG to an Ethernet service. You must define the service before you configure the MEG.

Parameter	Input Type	Permitted Values	Description
ccm	Variable	interval1s interval10s interval1min interval10min	interval1s – One second (default) interval10s – 10 seconds interval1min – One minute interval10min – 10 minutes It takes a MEP 3.5 times the CCM interval to determine a change in the status of its peer MEP. For example, if the CCM interval is 1 second, a MEP will detect failure of the peer 3.5 seconds after it receives the first CCM failure message. If the CCM interval is 10 minutes, the MEP will detect failure of the peer 35 minutes after it receives the first CCM failure message.
mhf	Variable	defMHFnone defMHFdefault defMHFexplicit defMHFdefer	Determines whether MIPs are created on the MEG. Options are: defMHFnone – No MIPs are created. defMHFdefault – MIPs are created on any service point in the MEG. defMHFexplicit – MIPs are created on the service points of the MEG when a lower-level MEP exists on the service point. This option is usually used when the operator's domain is encompassed by another domain. defMHFdefer – No MIPs are created.

Configuring MEPs (CLI)

Each MEP is attached to a service point in an Ethernet service. The service and service point must be configured before you configure the MEP. See [Configuring Ethernet Services \(CLI\)](#).

Each MEP inherits the same VLAN, C-VLAN, or S-VLAN configuration as the service point on which it resides. See [Configuring Service Points \(CLI\)](#).

In order to set the VLAN used by CCM/LBM/LTM if the service point is defined ambiguously (for example PIPE, Bundle-C, Bundle-S, or All-to-One), the service point's C-VLAN/S-VLAN parameter should not be set to N.A.

To configure a MEP, you must:

- 1 Add MEPs to the relevant MA/MEG. In this stage, you add both local and remote MEPs. The only thing you define at this point is the MEP ID. See [Adding Local and Remote MEPs \(CLI\)](#).
- 2 Configure the local MEPs. At this point, you determine which MEPs are local MEPs. The system automatically defines the other MEPs you configured in the previous step as remote MEPs. See [Configuring the Local MEPs \(CLI\)](#).
- 3 Enable the Local MEPs. See [Enabling Local MEPs \(CLI\)](#).

Adding Local and Remote MEPs (CLI)

To add a MEP, enter the following command in root view:

```
root> ethernet soam meg mep add meg-id <meg-id> mep-id <mep-id>
```

The following command adds MEP 25 on MEG 2.

```
root> ethernet soam meg mep add meg-id 2 mep-id 25
```

To remove a MEP, enter the following command in root view:

```
root> ethernet soam meg mep remove meg-id <meg-id> mep-id <mep-id>
```

The following command removes MEP 25 from MEG 2.

```
root> ethernet soam meg mep remove meg-id 2 mep-id 25
```

To display a list of all MEPs that belong to a specific MEG, enter the following command in root view:

```
root> ethernet soam meg mep show meg-id <meg-id>
```

Configuring the Local MEPs (CLI)

Once you have added local and remote MEPs, you must configure the MEPs and determine which are the local MEPs.

To make a defined MEP a local MEP, you must assign the MEP to a service point on the Ethernet service on which the MEG resides.

To assign a MEP to a service point, enter the following command in root view:

```
root> ethernet soam mep create meg-id <meg-id> mep-id <mep-id> sp-id <sp-id> mep-dir <mep-dir>
```

The following command assigns MEP 35 on MEG 2 to Service Point 3 on the service on which MEG 2 resides.

```
root> ethernet soam mep create meg-id 2 mep-id 35 sp-id 3 mep-dir down
```

To change a MEP from a local to a remote MEP, enter the following command in root view:

```
root> ethernet soam mep delete meg-id <meg-id> mep-id <mep-id>
```

The following command changes MEP 35 from a local to a remote MEP.

```
root> ethernet soam mep delete meg-id 2 mep-id 35
```

To display a list of local MEPs for a specific MEG, enter the following command in root view:

```
root> ethernet soam meg local-mep show meg-id <meg-id>
```

For example:

```

root> ethernet soam meg local-mep show meg-id 2
MEG:
=====
|MA ID|Format      |Name          |Level|Service|
|----|-----|-----|-----|-----|
|2   |charString|TR-98         |0    |1      |
|----|-----|-----|-----|-----|
MEP:
=====
|MepId  |Interface |Direction|Active  |SP ID |
|-----|-----|-----|-----|-----|
|25     |eth  1/1  |down     |true   |1     |
|-----|-----|-----|-----|-----|
|35     |eth  1/2  |down     |false  |3     |
|-----|-----|-----|-----|-----|
root> _

```

Enabling Local MEPs (CLI)

Once you have added a MEP and defined it as a local MEP, you must enable the MEP by setting the MEP to Active, enabling CCM messages from the MEP, and assigning a CCM-LTM priority to the MEP.

To set a MEP to Active, enter the following command in root view:

```

root> ethernet soam mep active set meg-id <meg-id> mep-id <mep-id> mep-
active <mep-active>

```

The following command sets MEP 35 on MEG 2 to Active.

```

root> ethernet soam mep active set meg-id 2 mep-id 35 mep-active true

```

To enable or disable the sending of CCM messages on a MEP, enter the following command in root view:

```

root> ethernet soam mep ccm-enable set meg-id <meg-id> mep-id <mep-id>
enabled <ccm-enabled>

```

The following command assigns enables CCM messages for MEP 35 on MEG 2.

```

root> ethernet soam mep ccm-enable set meg-id 2 mep-id 35 enabled true

```

To set a MEP's CCM-LTM priority, enter the following command in root view:

```

root> ethernet soam mep ccm-ltm-prio set meg-id <meg-id> mep-id <mep-id>
ccm-ltm-priority <ccm-ltm-priority>

```

The following command sets the CCM-LTM priority of MEP 35 in MEG 2 to 5.

```

root> ethernet soam mep ccm-ltm-prio set meg-id 2 mep-id 35 ccm-ltm-
priority 5

```

Table 182 MEP CLI Configuration Parameters

Parameter	Input Type	Permitted Values	Description
meg-id	Number	1-4294967295	Enter an ID for the MEG.
mep-id	Number	1-8191	A name to identify the MEG.
sp-id	Number	0-32	The Service Point ID of the service point to which you want to assign the MEP.
mep-dir	Variable	up down	The MEP direction.

Parameter	Input Type	Permitted Values	Description
ccm-enabled	Variable	true false	true – CCM messages are enabled on the MEP. false – CCM messages are disabled on the MEP.
ccm-ltm-priority	Number	0-7	The p-bit included in CCMs sent by this MEP.
mep-active	Variable	true false	true – The MEP is Active. false – The MEP is Inactive.

Displaying MEP and Remote MEP Attributes (CLI)

To display the attributes of a specific MEP, enter the following command in root view:

```
root> ethernet soam mep configuration general show meg-id <meg-id> <meg-id> mep-id <mep-id>
```

For example:

```
root> ethernet soam mep configuration general show meg-id 2 mep-id 25
MEG:
=====
|MA ID|Format      |Name          |Level |Service|
|-----|-----|-----|-----|-----|
|2     |charString  |TR-98         |0     |1      |
|-----|-----|-----|-----|-----|

SOAM MEP Table:
=====
Interface  MEP      MEP Active  MEP CCM  CCM and  MEP MAC  MEP Lowest  MEP Alarm  MEP Alarm
Location   Direction  TX Enable  LTM      Priority Address  priority fault on time  Clear Time
|-----|-----|-----|-----|-----|-----|-----|-----|-----|
eth  1/1 |down      |true      |true      |7         |0:a:25:38:9:4b |allDef      |250      |1000
|-----|-----|-----|-----|-----|-----|-----|-----|-----|
root>
```

To display a list of remote MEPs (RMEPs) and their parameters per MEG and local MEP, enter the following command in root view:

```
root> ethernet soam mep rmep list show meg-id <meg-id> <meg-id> mep-id <mep-id>
```

For example:

```

root> ethernet soam mep rmep list show meg-id 2 mepid 25
MD:
=====
|MD ID|MD Name                |MD Format    |MD Level|
=====
|1   |TR-995                    |none        |5      |
=====

MEG:
=====
|MA ID|Format    |Name    |Level|Service|CCM Interval|Number of MEPs|Number of Local MEPs|Number of MIPs|
=====
|2   |charString|TR-98   |0    |1      |intervals  |4           |2           |0           |
=====

SOAM MEP Table:
=====
MEP ID   Interface  MEP      MEP Active  MEP CCM   CCM and
         Location   Direction  TX Enable  LTM Priority
=====
25       |eth  1/1 |down    |true      |true     |7
=====

RMEPs:
=====
| RmepId | State      | MAC                | Rdi |
=====
|45      |rMepFailed|ff:ff:ff:ff:ff:ff|false|
=====
|55      |rMepFailed|ff:ff:ff:ff:ff:ff|false|
=====

```

To display a list of remote MEPs (RMEPs) and their parameters per MEG and local MEP, enter the following command in root view:

```

root> ethernet soam mep rmep show meg-id meg-id < meg-id <meg-id> mep-id
<mep-id> rmep-id <rmep-id>

```

For example:

```

root> ethernet soam mep rmep show meg-id 2 mep-id 35 rmep-id 45
MD:
=====
|MD ID|MD Name                |MD Format    |MD Level|
=====
|1   |TR-995                    |none        |5      |
=====

MEG:
=====
|MA ID|Format    |Name    |Level|Service|CCM Interval|Number of MEPs|Number of Local MEPs|Number of MIPs|
=====
|2   |charString|TR-98   |0    |1      |intervals  |4           |2           |0           |
=====

SOAM MEP Table:
=====
MEP ID   Interface  MEP      MEP Active  MEP CCM   CCM and  MEP MAC  MEP Lowest  MEP Alarm  MEP Alarm  Sequence  CCM
         Location   Direction  TX Enable  LTM Priority  Address  priority  on time    Clear Time Errors  Messages
                                     fault alarm
=====
35       |eth  2/4 |down    |true      |true     |5       |0:a:25:38:9:50|allDef    |250       |1000      |0         |389
=====

RMEP:
=====
|MepId|RmepId|operState |OKorFail Time|MAC                |Rdi |port Status |interface Status |ChassisID format |Chassis ID |Mng Addr Domain |
=====
|35   |45    |rMepFailed|6874         |ff:ff:ff:ff:ff:ff|false|psNoPortStateTLV|isNoInterfaceStatus|None           |           |0               |
=====

root> _

```

Table 183 MEP and Remote MEP Status Parameters (CLI)

Parameter	Description
MD Parameters	
MD ID	The MD ID.
MD Name	The MD name (44 characters).
MD Format	The MD format (None).

Parameter	Description
MD Level	The maintenance level of the MD (0-7).
MEG Parameters	
MA ID	The MA/MEG ID.
Format	charString in the current release.
Name	The MA/MEG name (43 characters).
Level	The MEG Level (0-7).
Service	The Service ID of the Ethernet service to which the MEG belongs.
CCM Interval	The interval at which CCM messages are sent within the MEG.
Number of MEPs	The number of MEPs that belong to the MEG.
Number of Local MEPs	The number of local MEPs that belong to the MEG.
Number of MIPs	The number of MIPs that belong to the MEG.
SOAM MEP Table Parameters	
MEP ID	The MEP ID.
Interface Location	The interface on which the service point associated with the MEP is located.
MEP Direction	Up or Down.
MEP Active	Indicates whether the MEP is enabled (true) or disabled (false).
MEP CCM TX Enable	Indicates whether the MEP is configured to send CCMs (true or false).
CCM and LTM Priority	The p-bit included in CCMs sent by the MEP (0-7).
MEP MAC Address	The MAC address of the service point associated with the MEP.
MEP Lowest priority fault alarm	The lowest defect priority that can trigger alarm generation. Defects with a lower priority will not trigger alarms.
MEP Alarm on time	The amount of time that defects must be present before an alarm is generated, in msec intervals (250-1000).
MEP Alarm Clear Time	The amount of time that defects must be absent before an alarm is cleared, msec intervals (250-1000).
Sequence errors CCM Frames	The number of out-of-sequence CCM messages received.
CCM Messages TX	The number of transmitted CCM messages.
RMEP Parameters	
MepId	The MEP ID of the local MEP paired with the remote MEP.
Rmep Id	The remote MEP ID.

Parameter	Description
operState	The operational state of the remote MEP.
OKorFail Time	The timestamp marked by the remote MEP indicating the most recent CCM OK or failure it recorded. If none, this field indicates the amount of time, in msec intervals, since SOAM was activated.
MAC	The MAC Address of the interface on which the remote MEP is located.
Rdi	Displays the state of the RDI (Remote Defect Indicator) bit in the most recent CCM received by the remote MEP: <ul style="list-style-type: none"> • True – RDI was received in the last CCM. • False – No RDI was received in the last CCM.
Port Status	The Port Status TLV in the most recent CCM received from the remote MEP. Reserved for future use.
Interface Status	The Interface Status TLV in the most recent CCM received from the remote MEP. Indicates the operational status of the interface (Up or Down).
Chassis ID Format	Displays the address format of the remote chassis (in the current release, MAC Address).
Chassis ID	Displays the MAC Address of the remote chassis.
Mng Addr Domain	Displays the BASE MAC address of the remote unit (the unit on which the remote MEP resides),.

Displaying Detailed MEP Error Information (CLI)

To display the entire frame of the last CCM error message and the last CCM cross-connect error message received by a specific local MEP, along with other detailed information, enter the following command in root view:

```
root> ethernet soam mep status general show meg-id <meg-id> mep-id <mep-id> detailed yes
```

For example:

```

root> ethernet soam mep status general show meg-id 2 mep-id 25 detailed yes
MEG:
=====
|MA ID|Format      |Name                                     |Level|Service|
|-----|-----|-----|-----|-----|
|2     |charString    |TR-98                                  |0     |1       |
|-----|-----|-----|-----|-----|

SOAM MEP Table:
=====
MEP Fault      MEP highest      MEP Defects      Sequence      CCM Messages TX
Notification State priority      fault alarm      Errors      CCM Frames
|-----|-----|-----|-----|-----|
fngDefectReported defRemoteCCM    bDefRemoteCCM    0              10469
|-----|-----|-----|-----|-----|

SOAM MEP Table:
=====
Last RX error CCM message      Last RX Xcon fault message
|-----|-----|
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000

SOAM MEP MEF Status Table:
=====
MEP Operational      Connectivity      Last Sent Port status TLV      Last Sent Interface      Last MEP      RDI TX
State                Status              status TLV                    status TLV                Defects          indication
|-----|-----|-----|-----|-----|-----|
enabled              inactive          psNoPortStateTLV              isDown                     None             false
root> _

```

To display the same information without the last RX error CCM and fault messages, enter the following command in root view:

```
root> ethernet soam mep status general show meg-id <meg-id> mep-id <mep-id> detailed no
```

The **Last RX error CCM message** field displays the frame of the last CCM that contains an error received by the MEP.

The **Last RX Xcon fault message** field displays the frame of the last CCM that contains a cross-connect error received by the MEP.



Note

A cross-connect error occurs when a CCM is received from a remote MEP that has not been defined locally.

Performing Loopback (CLI)

To set the interval between loopback message transmissions in a loopback session, enter the following command in root view:

```
root> ethernet soam loopback interval set meg-id <meg-id> mep-id <mep-id>
interval <0-60000>
```

For example, the following command sets the loopback interval for MEP 25 on MEG 1 to 5 seconds:

```
root> ethernet soam loopback interval set meg-id 1 mep-id 25 interval 5000
```

To set the loopback message frame size and data pattern, enter the following command in root view:

```
root> ethernet soam loopback data set meg-id <meg-id> mep-id <mep-id>  
size <size> pattern <pattern>
```

For example, the following command sets the loopback frame size to 128 and the pattern to zero for MEP 25 on MEG 1 to 5 seconds:

```
root> ethernet soam loopback data set meg-id 1 mep-id 25 size 128 pattern
zeroPattern
```

To set the loopback priority bit size and drop-enable parameters, enter the following command in root view:

```
root> ethernet soam loopback prio set meg-id <meg-id> mep-id <mep-id>
prio <priority> drop <drop>
```

For example, the following command sets a priority bit size of 5 and enables frame dropping for MEP 25 on MEG 1 to 5 seconds:

```
root> ethernet soam loopback prio set meg-id 1 mep-id 25 prio 5 drop true
```

To set the loopback destination by MAC address, set the number of loopback messages to transmit and the interval between messages, and initiate the loopback, enter the following command in root view:

```
root> ethernet soam loopback send meg-id <meg-id> mep-id <mep-id> dest-
mac-addr <dest-mac-addr> tx-num <tx-num> tx-interval <interval>
```

For example, the following command initiates a loopback session with the interface having MAC address 00:0A:25:38:09:4B. The session is configured to send 100 loopback messages at six-second intervals.

```
root> ethernet soam loopback send meg-id 1 mep-id 25 dest-mac-addr
00:0A:25:38:09:4B tx-num 100 tx-interval 6000
```

To set the loopback destination by MEP ID, set the number of loopback messages to transmit and the interval between messages, and initiate the loopback, enter the following command in root view:

```
root> ethernet soam loopback send meg-id <meg-id> mep-id <mep-id> dest-
mep-id <dest-mac-addr> tx-num <tx-num> tx-interval <interval>
```

For example, the following command initiates a loopback session with the interface having MAC address 00:0A:25:38:09:4B. The session is configured to send 100 loopback messages at six-second intervals.

```
root> ethernet soam loopback send meg-id 1 mep-id 25 dest-mac-addr
00:0A:25:38:09:4B tx-num 100 tx-interval 6000
```



Note

If you initiate the loopback via MEP ID, the loopback will only be activated if CCMs have already been received from the MEP. For this reason, it is recommended to initiate loopback via MAC address.

To display the loopback attributes of a MEP, enter the following command in root view:

```
root> ethernet soam loopback config show meg-id <meg-id> mep-id <mep-id>
```

For example:

```
root> ethernet soam loopback config show meg-id 1 mep-id 25

SOAM MEP LBM Attributes Table:
=====
Loopback    Loopback    Loopback    Drop    Loopback    Loopback    Loopback    Loopback
messages    Messages    Messages    Enable  Messages    Messages    Messages    Replies
to be       Destination Messages  true     Interval  Frame Size  Data        Age-out
transmitt   MAC Address Priority                                     Time
ed
=====
1           0:0:0:0:0:0 5                                     zeroPatte  5
rn
root> _
```


To stop a loopback that is already in progress, enter the following command in root view:

```
root> ethernet soam loopback stop meg-id <meg-id> mep-id <mep-id>
```

Table 184 Loopback CLI Parameters

Parameter	Input Type	Permitted Values	Description
meg-id	Number	1-4294967295	The MEG ID of the MEG on which the loopback is being configured or run.
mep-id	Number	1-8191	The MEP ID of the MEP on which the loopback is being configured or run.
interval	Number	0-60000	The interval (in ms) between each loopback message. Note that the granularity for this parameter is 100 ms. If you enter a number that is not in multiples of 100, the value will be rounded off to the next higher multiple of 100. Also, the lowest interval is 1000 ms (1 second). If you enter a smaller value, it will be rounded up to 1000 ms.
size	Number	64-1518	The frame size for the loopback messages. Note that for tagged frames, the frame size will be slightly larger than the selected frame size.
pattern	Variable	zeroPattern onesPattern	The type of data pattern to be sent in an OAM PDU Data TLV.
priority	Number	0-7	The priority bit for tagged frames.
drop	Boolean	true false	true – Frame dropping is enabled. false – Frame dropping is disabled.
dest-mac-addr	Six groups of two hexadecimal digits		The MAC address of the interface to which you want to send the loopback. If you are not sure what the interface's MAC address is, you can get it from the Interface Manager by entering the <code>platform if-manager show interfaces</code> command in root view.
dest-mep-id	Number	1-8191	The MEP ID of the interface to which you want to send the loopback.
tx-num	Number	0-1024	The number of loopback messages to transmit. If you enter 0, loopback will not be performed.

```
To display loopback results, enter the following command in root
view:root> ethernet soam loopback status show meg-id <meg-id> mep-id
<mep-id>
```

The following is a sample output for this command on MEG ID 127, MEP ID 1.

```
root> ethernet soam loopback status show meg-id 127 mep-id 1
```

SOAM MEP LBM Attributes Table:
=====

Loopback messages transmitt ed in session	Loopback messages left to transmit in session	Loopback replies received in session	Transacti on ID of 1st loopback message	Loopback session state	Next transacti on ID	Loopback messages transmitt ed	Loopback messages received	Valid in-order loopback replies received	Loopback replies transmitt ed	Valid out-of-or der loopback replies received	Bad MSDU Loopback Replies	Loopback messages recieved with bad sender id	Loopback replies recieved with bad sender id
9	114	9	1	soamLbact ive	10	9	0	9	0	0	0	0	0

```
root>
```

Working in CW Mode (Single or Dual Tone) (CLI)

CW mode enables you to transmit a single or dual frequency tones, for debugging purposes.

To work in CW mode, enter the following command:

```
radio[x/x] modem tx-source set admin enable
```

Once you are in CW mode, you can choose to transmit in a single tone or two tones.

To transmit in a single tone, enter the following command in radio view:

```
radio[x/x] modem tx-source set mode one-tone freq-shift <freq-shift>
```

To transmit two tones, enter the following command in radio view:

```
radio[x/x] modem tx-source set mode two-tone freq-shift <freq-shift>  
freq-shift2 <freq-shift>
```

To exit CW mode, enter the following command:

```
radio[x/x] modem tx-source set admin disable
```

Table 185 CW Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
freq-shift	Number	0-7000	Enter the frequency you want to transmit, in KHz.

The following commands set a single-tone transmit frequency of 5050 KHz on radio interface 1, then exit CW mode and return the interface to normal operation:

```
root> radio slot 2 port 1  
radio[2/1] modem tx-source set admin enable  
radio[2/1] radio[x/x] modem tx-source set mode one-tone freq-shift 5050  
radio[2/1] modem tx-source set admin disable
```

Chapter 20: Maintenance

This section includes:

- [Temperature Ranges](#)
- [Troubleshooting Tips](#)
- [PTP 850E Connector Pin-outs](#)

Temperature Ranges

The following are the permissible unit temperature ranges for PTP 850E.

- **-33°C to 55°** – Temperature range for continuous operating temperature with high reliability.
- **-45°C to 60°C** – Temperature range for exceptional temperatures, tested successfully, with limited margins.

To display the current unit temperature, see [Configuring Unit Parameters](#).

- The permissible IDU humidity range is 5%RH to 100%RH

Troubleshooting Tips

- If during or right after a software upgrade the message *Your session has expired, please login again* appears and you cannot log in, it is recommended to refresh the Web EMS page (F5) after completion of the upgrade. If pressing F5 does not help, clear the browser's cache by pressing Ctrl+Shift+Delete.


PTP 850E Connector Pin-outs

The PTP 850E has an optical SFP cage, an optical SFP/SFP+ cage, and a QSFP cage for traffic and one RJ-45 port for management and PoE.

For power, the PTP 850E has a DC power interface (-48V) (P1). Optionally, when used in all-outdoor configurations, the PTP 850E can also receive PoE power from a Ceragon-approved PoE injector via P2, an RJ-45 port that is also used for management.

Power redundancy can be achieved by using both a DC power input and a passive PoE injector simultaneously. The PTP 850E monitors both power feeds and uses the best power source at any given moment.

Figure 184 PTP 850E Interfaces



- Port 1 – Power Interface (-48V)
- Port 2 (MNG 1/Eth 1):
 - Electric: 10/100/1000Base-T RJ-45
 - Management port (no traffic)
 - PoE
- Port 3 (Eth 2):
 - SFP cage which supports SFP standard
 - 1/2.5GE MultiBand port (user-configurable)
- Port 4 (Eth 3, Eth 4, Eth 5, Eth 6):
 - QSFP cage which supports QSFP standard
 - 4x1G/10G or 1x40GE Eth traffic (user configurable)
 - Option for SFP+ (1x10GE) with adaptor
- Port 5 (Eth 7):
 - SFP cage which supports SFP+ standard
 - 10GE Eth traffic
- Port 6:

- External Connection – Reserved for future use.

**Note**

Only Port 5 is supported for traffic in CeraOS 10.6. 10.9 adds support for Port 4 in 4x10Gbps and 1x1Gbps configurations.

- Antenna Port – Ceragon proprietary flange (flange compliant with UG385/U)
- RSL interface – DVM interface to enable voltage measurement for RSL indication. The RSL measurement is performed using standard DVM testing probes. To access the RSL interface, the user must remove the port's cover and insert the DVM plugs into the sockets, according to the polarization markings.
- Grounding screw

P2 (Eth 1) – MGT/PoE GbE Electrical Interface (RJ-45)

Table 186: PTP 850E MGT Interface - RJ-45/ Pinouts

Pin no.	Description
1	BI_DA+ (Bi-directional pair +A)
2	BI_DA- (Bi-directional pair -A)
3	BI_DB+ (Bi-directional pair +B)
4	BI_DC+ (Bi-directional pair +C)
5	BI_DC- (Bi-directional pair -C)
6	BI_DB- (Bi-directional pair -B)
7	BI_DD+ (Bi-directional pair +D)
8	BI_DD- (Bi-directional pair -D)

P3 (Eth 2) GbE Optical Interface (SFP)

Support for P3 is planned for future release.

P4 (Eth 3, Eth 4, Eth 5, Eth 6) 40 GbE Optical Interface (QSFP)

P4 (QSFP) is a QSFP cage which supports the QSFP standard. With a QSFP to SFP adaptor, it also supports the SFP and SFP+ standards. Port 4 supports 4x1/10Gbps configurations.

P5 (Eth 7) 10G Optical Interface (SFP+)

Eth1 is an SFP cage that supports the SFP+ standard. Eth 7 is supported for 10G Ethernet traffic only.

Protection/XPIC Port

This port is reserved for future use.

RSL Interface

PTP 850E uses a two-pin connection to measure the RSL level using standard voltmeter test leads:




Figure 185: RSL Pins

PTP 850E LEDs

The PTP 850E provides the following LEDs to indicate the status of the unit's interfaces, and the unit as a whole:

- P2 MGT/PoE GbE Electrical Interface (RJ-45) LEDs
- P4/Eth3-7 40G Optical Interface (QSFP) LED
- P5/Eth7 10G Optical Interface (SFP+) LEDs
- Status LED
- Protection LED

P2 MGT/PoE GbE Electrical Interface (RJ-45) LEDs

There are two LEDs next to the MGT interface, a Green LED to the left of the interface and an Orange LED to the right of the interface.

The Orange LED indicates the interface's Admin and cable connection status, and whether there is traffic on the interface:

- **Off** - Admin is Disabled *or* no cable is connected to the interface.
- **Green** - Admin is Enabled and a cable is connected to the interface.
- **Blinking Green** - Admin is Enabled and a cable is connected to the interface, *and* there is traffic on the interface.

The Green LED is not functional in this release.

P4/Eth3-7 40G Optical Interface (QSFP) LEDs

The LED for this port is not operational in Release 10.9.

P5/Eth7 10G Optical Interface (SFP+) LEDs

Eth1 is an SFP cage that supports regular SFP and SFP+.

There is one Green LED to the left of the interface. The LED is for Eth7 and indicates the interface's Admin and cable connection status, and whether there is traffic on the interface:

- **Off** - Admin is Disabled *or* no cable is connected to the interface.
- **Green** - Admin is Enabled and a cable is connected to the interface.
- **Blinking Green** - Admin is Enabled and a cable is connected to the interface, *and* there is traffic on the interface.



Note

The LED does not indicate traffic on the interface (Blinking Green) in 10G mode.

Status LED

The Status LED indicates the status of the main board:

- **Off** – The power is off.
- **Red** – The unit is initializing.

- **Red Blinking** - The power is on, and one or more major or critical alarms are raised.
- **Green** - The power is on, the unit is up, the radio is up, and no major or critical alarms are raised.

Protection LED

Reserved for future use.

PoE Injector Pin-outs and LEDs – Standard PoE




Figure 186: PoE Injector Connectors

PoE Injector Pin-outs and LEDs – Standard PoE

This section applies to the standard PoE Injector units with the following marketing models:

- PoE_Inj_AO_2DC_24V_48V
- PoE_Inj_AO

PoE Port

Table 187: PoE Injector PoE Port - RJ-45 Pinouts

Pin no.	Description
1	BI_DA+ (Bi-directional pair +A)
2	BI_DA- (Bi-directional pair -A)
3	BI_DB+ (Bi-directional pair +B)
4	BI_DC+ (Bi-directional pair +C)
5	BI_DC- (Bi-directional pair -C)
6	BI_DB- (Bi-directional pair -B)
7	BI_DD+ (Bi-directional pair +D)
8	BI_DD- (Bi-directional pair -D)

Data Port

Table 188: PoE Injector RJ-45 Data Port Supporting 10/100/1000Base-T

Pin no.	Description
1	BI_DA+ (Bi-directional pair +A)
2	BI_DA- (Bi-directional pair -A)
3	BI_DB+ (Bi-directional pair +B)
4	BI_DC+ (Bi-directional pair +C)
5	BI_DC- (Bi-directional pair -C)
6	BI_DB- (Bi-directional pair -B)
7	BI_DD+ (Bi-directional pair +D)
8	BI_DD- (Bi-directional pair -D)

DC

One or two DC ports, depending on the PoE Injector model:

Two models of the PoE Injector are available:

- **PoE_Inj_AO_2DC_24V_48V** – Includes two DC power ports with power input ranges of $\pm(18-60)V$ each.
- **PoE_Inj_AO** – Includes one DC power port (DC Power Port #1), with a power input range of $\pm(40-60)V$.

These ports are UL-60950 compliant, with a 2-pin connector.

PoE Injector LEDs – Standard PoE

- PWR1 (Bi-color LED)
 - **Green** – Power available on PWR1 DC input
 - **Off** – No power is available on PWR1 DC input.
- PWR2 (Bi-color LED)
 - **Green** – Power available on PWR2 DC input,
 - **Off** – No power is available on PWR2 DC input.
- PoE (Tri -color LED)
 - **Orange** – No load is detected
 - **Green** – Providing in-line power
 - **Blinking Red** – Invalid/over-load
 - **Off** – no power to the injector unit.

Radio LED

The Radio LED indicates the status of the radio link:

- **Off** – The radio is off.

- **Green** - The power is on, and all carriers are operational (up).
- **Orange** - A signal degrade condition exists in at least one carrier.
- **Red** - A loss of frame (LOF) or excessive BER condition exists in at least one carrier.

PoE Injector Pin-outs and LEDs – Passive PoE

This section applies the passive PoE used with power redundancy. The marketing model of this PoE is:
AC_POE_STD_PWR_INDOOR

PoE Injector Pin-outs and LEDs – Passive PoE

RJ-45 output pinout: 3,4,5,6 (+) and 1,2,7,8 (-)

AC Input Specifications

AC Input Voltage Rating: 100VAC to 240VAC

AC Input Voltage Range: 90VAC to 264VAC

AC Input Current: 2.5A (rms) Max 90 VAC at Full Load
1.2A (rms) Max 240VAC at Full Load

AC Input Frequency: 47Hz to 63Hz

AC Input Inrush Current: 50A Max @115VAC at Full Load
75A Max @230VAC at Full Load

DC Output Specifications

DC Output Voltage: +57-54VDC (+56V Nominal)

Output Power: 90W Maximum

PoE Injector LEDs – Passive PoE

Blue Solid: Power Good/Power Out

Chapter 21: Alarms List

The following table lists all alarms used in the PTP 850 products.

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
10	Alarm	Framer digital loopback	Warning	User enabled framer digital loopback.	Disable framer digital loopback.	
25	Alarm	Unit Temperature is out of system specified limits.	Warning			
28	Event	Unit warm reset.	Indeterminate			
29	Event	Unit reset.	Warning			
30	Alarm	POE input voltage is too low	Warning			
31	Event	Change Remote request was sent	Major			(1)
32	Event	Protection switchover due to remote request	Major			(1)
33	Alarm	Protection-MIMO-misconfigurtion- alarm	Major	Unit redundancy and MIMO 4X4 can not operate simultaneously		
100	Alarm	LAG is not fully functional - LAG Degraded.	Major			
101	Alarm	LAG operational state is down	Critical			
102	Alarm	Loopback is active	Major	Ethernet loopback is active.	Wait till loopback timeout expires or disable loopback.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
103	Alarm	Slot X port XX is mirrored to slot Y port YY	Minor	Mirroring is enabled by user configuration.	Disable mirroring.	
120	Alarm	Port speed mismatch	Major	System reset is required after the port speed was changed		
150	Alarm	Interface is down due to automatic state propagation.	Major	Failure of the radio interface which is monitored for automatic state propagation causes automatic shutdown of the controlled interface.	Check adjacent radio interface for failure conditions that caused automatic state propagation.	
200	Alarm	Protection communication is down	Major	Mate unit is absent/failure. Protection cable is disconnected. Unit failure.	1. Check existence of mate unit. 2. Check protection cable connection between units. 3. Reset mate unit. 4. Replace mate unit.	
201	Alarm	Protection in Lockout State	Major			
202	Event	Protection switchover due to local failure	Major			
203	Alarm	Mate does not exist	Major	Mate does not exist or cable unplugged.		
204	Alarm	HSB insufficient configuration	Critical	External Protection configured both with HSB.	Remove External Protection and HSB configuration.	
307	Event	TDM interface is up	Warning			
308	Event	TDM interface is up	Warning			
401	Alarm	Ethernet Loss of Carrier	Major	Cable disconnected. Defective cable.	1. Check connection of cable 2. Replace cable.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
407	Event	Ethernet interface is up	Warning			
408	Event	Ethernet interface is down	Warning			
601	Alarm	Radio excessive BER	Major	<ol style="list-style-type: none"> 1. Fade in the link. 2. Defective IF cable. 3. Fault in RFU. 4. Fault in RMC (Radio Modem Card). 	<ol style="list-style-type: none"> 1. Check link performance. 2. Check IF cable and replace if required. 3. Replace RFU. 4. Replace RMC (Radio Modem Card). 	
602	Alarm	Link ID mismatch	Major	Link ID is not the same at both sides of link	Configure same Link ID for both sides of link	
603	Alarm	Radio loss of frame	Critical	<ol style="list-style-type: none"> 1. Fade in the link. 2. Defective IF cable. 3. Fault in RFU. 4. Fault in RMC (Radio Modem Card). 5. Different radio scripts at both ends of the link. 	<ol style="list-style-type: none"> 1. Check link performance. 2. Check IF cable and replace if required. 3. Replace RFU. 4. Replace RMC (Radio Modem Card). 5. Make sure same script is loaded at both ends of the link. 	
604	Alarm	Radio signal degrade	Minor	<ol style="list-style-type: none"> 1. Fade in the link. 2. Defective IF cable. 3. Fault in RFU. 4. Fault in RMC (Radio Modem Card). 	<ol style="list-style-type: none"> 1. Check link performance. 2. Check IF cable and replace if required. 3. Replace RFU. 4. Replace RMC (Radio Modem Card). 	
605	Event	Radio interface is up	Warning			

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
606	Event	Radio interface is down	Warning			
801	Alarm	Corrupted inventory file	Warning	The inventory file is corrupted	1. Reset the system. 2. Reinstall the software.	
802	Alarm	Inventory file not found	Warning	The inventory file is missing	1. Reset the system. 2. Reinstall the software.	
803	Alarm	SFP port RX power level is below the rx power level low threshold	Warning	1. Remote SFP port Tx laser power is too low. 2. Fiber length is too long or fiber type doesn't fit the installed SFP.	1. Verify remote SFP Tx laser power is within range. 2. Check fiber type and length fit the installed SFP. If not, replace it with an appropriate one.	
804	Alarm	SFP port RX power level is above the rx power level high threshold	Warning	Remote SFP Tx power is too high.	Add attenuator on Rx side	
805	Alarm	SFP port TX power level is below the tx power level low threshold	Warning	SFP transmit laser power is too low	Check laser Bias current. If it is too low, replace SFP.	
806	Alarm	SFP port TX power level is above the tx power level high threshold	Warning	SFP laser Tx power is too high.	Check laser Bias current and laser temperature values. If either of them is too high, replace SFP.	
901	Alarm	Demo license is active	Warning	Demo license has been activated by the user	Disable the demo license	
902	Event	Demo license is expired	Warning			
903	Event	Demo license is started	Warning			
904	Event	Demo license is stopped	Warning			

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
905	Event	License key loading failure	Major			
906	Event	License key loaded successfully	Warning			
907	Alarm	License violation	Critical	The current configuration does not match the licensed feature set. 48 hours after a "license violation" alarm is raised, sanction mode is activated in which all alarms except the license violation alarm are cleared and no new alarms are raised.	<ol style="list-style-type: none"> 1. Get the list of features' configurations that are violated via the "license information report". 2. Install a new license that allows the use of all required features. 	
908	Alarm	Demo license is about to expire	Major	Demo license allowed period is about to end within 10 days	Disable the demo license and install a new valid one	
910	Alarm	License signature failure	Major	License key validation has failed due to invalid product serial number	Replace the IDU	
911	Event	License violation sanction is enforced	Major			
913	Alarm	License components are missing or corrupted	Major	Essential internal license components are missing or corrupted.	Reinstall software	
1002	Alarm	Radio protection configuration mismatch	Major	The configuration between the radio protection members is not aligned	Apply a copy-to-mate command to copy the configuration from the required radio to the other one	
1006	Event	Radio protection switchover - reason	Warning	Protection decision machine initiated switchover due to local failure or user command	Check the system for local failures	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1007	Alarm	Radio protection no mate	Major	Radio protection function is missing radio module, module defected or disabled	1. Add radio module. 14. Replace a defective existing radio module. 15. Make sure all radio interfaces are enabled.	
1008	Event	Remote switchover request was sent - reason	Warning			
1009	Alarm	Rdadio protection lockout command is on.	Major	The user has issued a lockout command	Clear the lockout command	
1010	Event	Ethernet interface Group protection switchover	Warning	1. LOC event on an Ethernet interface. 16. Protection group member was disabled or pulled out of the shelf.	1. Check the system for local failures. 17. Check external equipment.	
1011	Alarm	Interface protection lockout is on	Major	1. The user has issued a lockout command	1. Clear the lockout command	
1012	Alarm	Interface protection no mate: mate interface is missing or disabled	Major	Interface protection function is missing interface module, module defected or disabled	1. Add interface module. 18. Replace a defective existing interface module. 19. Make sure all interface interfaces are enabled.	
1102	Event	Software installation status:	Warning			
1105	Event	New version installed	Warning	A software version has been installed but system has not been reset.		

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1111	Event	User approved download of software version file	Warning			
1112	Event	Software download status:	Warning			
1113	Event	Missing components:	Warning			
1114	Event	Incomplete file set; missing components	Warning	Software bundle is missing components.	Get a complete software bundle	
1150	Event	Configuration file backup generation started	Warning	User command		
1151	Event	Configuration file backup created	Warning	Backup file creation finished successfully		
1152	Event	Failure in configuration file backup generation	Warning	System failed in attempt to create backup configuration file		
1153	Event	Configuration successfully restored from file backup	Warning	Configuration restore finished successfully		
1154	Event	Failure in configuration restoring from backup file	Warning	System failed in attempt to restore configuration from backup file	1. Configuration file system type mismatch 2. Invalid or corrupted configuration file	
1155	Event	Configuration restore operation cancelled	Warning	Restore operation cancelled because of user command or execution of another configuration management operation	Try again	
1156	Event	User issued command for transfer of configuration file	Warning	User command		
1157	Event	Configuration file transfer successful	Warning	Configuration file transfer successful		

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1158	Event	Configuration file transfer failure	Warning	1. Communications failure. 2. File not found in server	1. Make sure protocol details are properly configured. 2. Make sure file exists.	
1159	Event	Configuration file transfer in progress	Warning	File transfer started		
1163	Event	CLI configuration script activation started	Warning	User command		
1164	Event	CLI Configuration script executed successfully	Warning			
1165	Event	CLI Configuration script failed	Warning	1. Syntax Error. 2. Error returned by system during runtime	Verify script in the relevant line, and run again. Note that script may assume pre-existing configuration.	
1166	Event	Unit info file transfer status:	Warning			
1167	Event	Unit info file creation status:	Warning			
1169	Event	Configuration restore operation started	Warning	Restore operation started because of user command		
1201	Alarm	Modem firmware file not found	Critical	Modem file is missing	1. Download software package. 2. Reset the system.	
1202	Alarm	Modem firmware was not loaded successfully	Critical	1. Modem firmware file is corrupted. 2. System failure.	1. Download software package. 2. Reset the system.	
1203	Event	Modem watch-dog reset event	Warning			
1301	Alarm	Radio MPMC script LUT file is corrupted	Critical	Damaged radio MPMC script LUT file	Download the specific radio MPMC script LUT file	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1302	Alarm	Radio MPMC script LUT file is not found	Critical	Missing radio MPMC script LUT file	Download the specific radio MPMC script LUT file	
1304	Alarm	Radio MPMC script modem file is corrupted	Critical	Damaged radio MPMC script modem file	Download the specific radio MPMC script LUT file	
1305	Alarm	Radio MPMC script modem file is not found	Critical	Missing radio MPMC script modem file	Download the specific radio MPMC script LUT file	
1308	Alarm	Radio MPMC file is corrupted	Critical	Damaged radio MPMC script LUT file	Download the specific radio MPMC script LUT file	
1309	Alarm	Radio MPMC RFU file is not found	Major	Missing radio MPMC RFU file	Download the specific radio MPMC script LUT file	
1312	Alarm	Radio MPMC script loading failed	Major	Damaged hardware module	Replace the radio hardware module	
1401	Alarm	Incompatible RFU TX calibration	Major	RFU calibration tables require SW upgrade	Upgrade IDU SW	
1501	Alarm	Remote communication failure	Critical	Fade in the link	Check the link performance	
1601	Alarm	IF loopback	Warning	User enabled IF loopback	Disable IF loopback	
1602	Alarm	IF synthesizer is unlocked.	Critical	<ol style="list-style-type: none"> 1. Extreme temperature condition. 2. HW failure. 	<ol style="list-style-type: none"> 1. Check installation. 2. Reset the RMC (Radio Modem Card) module. 3. Replace the RMC (Radio Modem Card). 	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1610	Alarm	Radio Receive Signal Level is below the configured threshold	Warning	RSL is very low due to: 1. Weather conditions, obstruction in antenna line of sight, antennae alignment. 2. Configured threshold needs to be adjusted.2.	1. Check for obstruction in link path. 2. Check the antennae alignment and link planning. 3. Recalculate the Path Loss and set the threshold accordingly. 4. Check link settings - Tx Power and Tx Frequency. 5. Hardware problem.	
1651	Alarm	ATPC overridden: Tx level has been equal to the Max Tx level for a longer time than allowed	Warning	Actual transmitted signal level has been at its maximum value for longer than allowed. This is probably caused by a configuration error or link planning error.	Correct the transmission levels. The alarm will be cleared only upon manual clearing.	
1697	Alarm	Radio Unit extreme temperature	Warning	1. Installation conditions 20. Defective RFU	1. Check installation conditions 21. Verify operation as per products specs 22. Replace RFU	
1698	Alarm	Radio unit input voltage is too low	Warning	1. Power supply output too low. 23. Power cable to RFU	1. Check power supply 24. Replace cable.	
1699	Alarm	Radio unit input voltage is too high	Warning	Power supply output too high	1. Check power supply	
1700	Alarm	Radio unit not aligned to IDU	Critical	1. FW alignment interrupted, power disruption, ODU cable malfunction. 25. Damaged ODU.	1. Reinitiate FW download by disable/ enable the corresponding port. 26. Replace RFU	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1701	Alarm	Cable open	Major	Cable is not connected to RMC (Radio Modem Card) or RFU	<ol style="list-style-type: none"> 1. Check IF cable and connectors. 2. Verify that the N-Type connector inner pin is not spliced. 3. Replace RMC (Radio Modem Card). 4. Replace RFU. 	
1702	Alarm	Cable short	Major	Physical short at the IF cable	<ol style="list-style-type: none"> 1. Check IF cable and connectors. 2. Verify that the N-Type connector inner pin is not spliced. 3. Replace RMC (Radio Modem Card). 4. Replace RFU. 	
1703	Alarm	RFU communication failure	Warning	<ol style="list-style-type: none"> 1. Defective IF cable. 2. IF cable not connected properly. 3. Defective RMC (Radio Modem Card). 4. Defective RFU. 5. RFU software download in progress. 	<ol style="list-style-type: none"> 1. Check IF cable and connectors. 2. Verify that N-Type connector inner pin is not spliced. 3. Replace RMC (Radio Modem Card). 4. Replace RFU. <p>For a high power RF Unit:</p> <ol style="list-style-type: none"> 1. Check BMA connector on OCB 2. Check BMA connector on RFU. 	
1704	Alarm	RFU delay calibration failure 1	Warning	Defective RFU	<ol style="list-style-type: none"> 1. Reset the RMC (Radio Modem Card) / RFU. 2. Replace RFU. 	
1705	Alarm	RFU delay calibration failure 2	Warning	Calibration cannot be completed due to notch detection	Enter delay calibration value manually.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1706	Alarm	RFU extreme temperature	Warning	<ol style="list-style-type: none"> 1. Installation conditions. 2. Defective RFU. 	<ol style="list-style-type: none"> 1. Check installation conditions. 2. Verify operation as per product's specs. 3. Replace RFU. 	
1707	Alarm	RFU is incompatible with ABC configuration	Warning	<ol style="list-style-type: none"> 1. The RFU type does not support the type of multi-carrier ABC the user has configured 	Replace the RFU with an RFU type that supports the configured Multi-Carrier ABC type.	
1708	Event	RFU frequency was set automatically	Warning	Defective RFU	<ol style="list-style-type: none"> 1. Check if problem repeats and if errors/alarms reported. 2. Replace RFU. 	
1709	Alarm	RFU hardware failure 1	Critical	Defective RFU.	Replace RFU.	
1710	Alarm	RFU hardware failure 2	Critical	Defective RFU.	Replace RFU.	
1711	Alarm	Low IF signal to RFU	Major	IF cable connection. Defective RFU. Defective RMC (Radio Modem Card).	<ol style="list-style-type: none"> 1. Check IF cable connectors. 2. Verify that N-Type connector inner pin is not spliced. 3. Replace RMC (Radio Modem Card). 4. Replace RFU. 	
1712	Alarm	Low IF signal from RFU	Warning	Low RX IF signal (140 MHz) from RFU.	<ol style="list-style-type: none"> 1. Check IF cable and connectors. 2. Verify that N-Type connector inner pin is not spliced. 3. Replace RMC (Radio Modem Card). 4. Replace RFU. 	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1713	Alarm	RFU PA extreme temperature	Warning	1. Installation conditions. 2. Defective RFU.	1. Check installation conditions. 2. Replace RFU.	
1721	Event	RFU reset	Major			
1722	Alarm	RFU loopback is active	Major	User has activated RFU loopback.	Disable RFU loopback.	
1723	Event	RFU mode changed to Combined	Indeterminate			
1724	Event	RFU mode changed to Diversity	Indeterminate			
1725	Event	RFU mode changed to Main	Indeterminate			
1726	Alarm	RFU power supply failure	Major	At least one of the RFU's power supply voltages is too low.	Replace RFU.	
1727	Alarm	RFU RX level out of range	Warning	RSL is very low, link is down.	1. Check antenna alignment & link planning. 2. Check link settings (TX power, TX frequency). 3. Check antenna connections. 4. Replace local/remote RFU.	
1728	Alarm	RFU RX level path1 out of range	Warning	1. Improper installation. 2. Fading event. 3. Defective RFU.	1. Check that the fault is not due to rain/multi-path fading or lack of LOS. 2. Check link settings (TX power, TX frequency). 3. Check antenna alignment. 4. Check antenna connections. 5. Replace local/remote RFU.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1729	Alarm	RFU RX level path2 out of range	Warning	<ol style="list-style-type: none"> 1. Improper installation. 2. Fading event. 3. Defective RFU. 	<p>Check that the fault is not due to rain/multi-path fading or lack of LOS.</p> <p>Check link settings (TX power, TX frequency).</p> <p>Check antenna alignment.</p> <p>Check antenna connections.</p> <p>Replace local/remote RFU.</p>	
1730	Alarm	Radio unit communication failure	Critical	<ol style="list-style-type: none"> 1. Defective RFU cable 27. RFU cable not connected properly 28. Defective RIC (Radio Interface card.) 29. Defective RFU. 30. RFU initialization in progress. 31. RFU powered off. 	<ol style="list-style-type: none"> 1. Check RFU power supply. 2. Check RFU cable and connectors 3. Replace RIC (Radio Interface card) 4. Replace RFU 	
1731	Alarm	Power supply cable open	Major	Power is enabled but consumption is lower than threshold	<ol style="list-style-type: none"> 1. Check ETH cable and connectors 2. Verify RFU is connected 3. If RFU is connected with an optical cable, disable power interface. 	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1732	Alarm	Power supply cable short	Major	<ol style="list-style-type: none"> Power is enabled but consumption reached the threshold. Physical short at the ETH cable. 	<ol style="list-style-type: none"> Check ETH cable and connectors Replace RIC (Radio Interface Card) Replace RFU If RFU is connected with an optical cable, disable power interface. 	
1733	Alarm	RFU synthesizer unlocked	Major	At least one of the RFU synthesizers is unlocked	<p>Replace RFU.</p> <p>In XPIC mode, replace mate RFU as well.</p>	
1734	Alarm	RFU TX level out of range	Minor	Defective RFU (the RFU cannot transmit the requested TX power)	<p>Replace RFU.</p> <p>Intermediate solution - reduce TX power.</p>	
1735	Alarm	RFU TX Mute	Warning	RFU Transmitter muted by user	Unmute the RFU transmitter	
1736	Alarm	IDU SW does not support this type of RFU	Major	IDC SW does not support the RFU	Upgrade IDC SW	
1737	Event	Card was extracted from slot	Warning	Card was extracted from slot	NA	
1738	Alarm	Card is in Failure state	Major	Card is down as a result of card failure	<ol style="list-style-type: none"> Reset Card. <p>Check if slot was disabled.</p>	
1739	Alarm	FPGA Firmware file not found	Critical	There is no FPGA file found on the Main Board for the card on the slot	NA	
1740	Alarm	Download card firmware has failed	Major	Firmware download was unsuccessful.	<ol style="list-style-type: none"> Reset Card. Download software package. <p>Try to insert another Card.</p>	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1741	Event	Card was inserted to slot	Warning	Card was inserted to slot	NA	
1742	Alarm	Card is in interconnection failure state	Major	Card is down as a result of card interconnection failure	1. Reset Card. Check if the slot was disabled.	
1743	Alarm	Expected Card is missing in slot	Major	1. Card is missing. Expected Card Type configured on empty slot.	1. Insert Expected Card. Clear Expected Card Type.	
1744	Alarm	This Card type is not supported in this slot	Major	The card is not on the Allowed Card Types list for this slot.	1. Reset. Insert Card belongs to Allowed Card Types list.	
1745	Event	Card operational state is Down	Indeterminate	Card state was change to Down state	NA	
1746	Event	Card operational state is Up	Indeterminate	Card state was change to Up state	NA	
1747	Event	Card operational state is Up with Alarms	Indeterminate	Card state was change to Up state but with Alarms indication	NA	
1748	Alarm	Unexpected Card Type in slot	Minor	Expected card type is different than the actual card type	1. Insert Expected Card. Change Expected Card Type.	
1749	Event	Slot was Disabled	Indeterminate	The user Disabled slot	NA	
1750	Event	Slot was Enabled	Indeterminate	The user Enabled slot	NA	
1751	Event	Card on slot was Reset	Indeterminate	The user Reset slot	NA	
1752	Event	FAN Card was extracted from slot	Warning	FAN Card was extracted from slot		
1753	Event	FAN failure	Major			
1754	Event	FAN Card was inserted to slot	Warning	FAN Card was inserted to slot		

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1755	Alarm	FAN Card is missing in slot	Critical	1. FAN Card is missing. Slot enabled when empty.	1. Insert FAN Card. Disable slot.	
1756	Alarm	Extreme Temperature	Major	System Temperature not in allowed range.	NA	
1757	Alarm	FAN Card is in Failure state	Major	FAN Card is in Failure state	Change FAN Card	
1758	Event	Power Supply was extracted from slot	Warning	Power Supply was extracted from slot		
1759	Event	Power Supply was inserted to slot	Warning	Power Supply was inserted to slot.		
1760	Alarm	Power Supply is missing in slot	Major	1. Power Supply is missing. Slot enabled when empty.	1. Insert Power Supply. Disable slot.	
1761	Alarm	Over voltage	Major	System Power Voltage higher than allowed.	NA	
1762	Alarm	Under voltage	Major	System Power Voltage Lower than allowed.	NA	
1763	Alarm	The Main board firmware is not found	Warning			
1764	Alarm	Download Main Board firmware has failed	Major	Firmware download was unsuccessful.	1. Reset board. 2. Download software package. Try to insert another board.	
1765	Event	Main Board was reset	Warning			
1766	Event	RFU installation failure	Warning	1. Unsupported RFU type. 2. IDU-RFU communications problem. RFU failure.	1. Make sure RFU is supported by SW version. 2. Check IDU-RFU cable. Replace RFU.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1767	Event	RFU installation in progress	Warning	User command		
1768	Event	RFU installation successfully completed	Warning	User command		
1769	Event	Unit Perform Power up	Warning			
1770	Event	Unit performing power-up.	Major			
1771	Alarm	RFU cable error.	Major	Errors in signal from IDU to XCVR.	<ol style="list-style-type: none"> 1. Check the IF cable and connectors. 2. Verify that the N-Type/TNC connector inner pin is not spliced. 3. Replace RMC. 4. Replace XCVR. 	
1772	Alarm	Radio XPIC sync loss	Major	Signaling between RMCs (Radio Modem Cards) for XPIC functionality has failed	<ol style="list-style-type: none"> 1. Check that the RMCs are in allowed slots. 2. Populate the RMCs in different allowed location in the chassis. 3. Replace RMC/s. 4. Replace chassis. 	
1773	Alarm	Radio early warning.	Warning	The estimated radio BER (Bit Error Rate) is above 10E-12.	<ol style="list-style-type: none"> 1. Check link performance. 2. Check IF cable, and replace if required. 3. Replace XCVR. 4. Replace RMC. 	
1774	Alarm	RFU software download cannot be initiated.	Critical	The hardware of the XCVR is OK, but is it running with METRO radio application.	Upgrade the XCVR software application via XPAND-IP and then reinitiate software download.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
1775	Alarm	RFU software download is not possible.	Critical	Wrong type of XCVR, the XCVR hardware is METRO.	Replace the XCVR	
1776	Alarm	RMC hardware failure.	Major	RMC hardware failure of the clock distributor.	Replace the RMC.	
1780	Event	MRMC running script is deleted	Warning	New installed software package does not include the running MRMC radio script	Make sure the required software package include the running MRMC radio script. Download and install the correct software package.	
1781	Event	MRMC running script is updated	Warning	New installed software package does has an updated version of the running MRMC radio script	Reset the radio carrier to reacquire the new updated MRMC radio script	
1782	Alarm	2.5Gbps mismatch configuration	Warning	The card can not function outside of an ABC group in 2.5Gbps mode.	Add the card to an ABC group, or change the Slot Section to 1Gbps.	
1783	Alarm	Radio remote fault indication (RFI)	Minor			
1790	Alarm	Hardware failure	Critical	An internal hardware failure has been detected by the system.	Replace the card or unit reporting the hardware failure.	
1800	Alarm	T3 sync interface Loss of Carrier	Major	1. Cable disconnected. Defective cable.	1. Check connection of the cable. Replace the cable.	
2001	Alarm	TDM-LIC has rebooted and is not in service now	Major	1. Recent TDM-LIC card reset; System malfunction.	1. Wait for card to reboot. Reset the TDM-LIC card.	
2002	Alarm	TDM-LIC configuration mismatch	Major	1. Recent warm reset of TDM-LIC; System malfunction.	Power cycle the TDM-LIC.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2003	Alarm	Loss of Signal (LOS) on TDM-LIC's front panel clock port	Major	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2004	Alarm	Communication with TDM-LIC is disrupted in Host-Card direction	Minor	System malfunction	Reset the TDM-LIC.	
2005	Alarm	TDM-LIC hardware failure	Major	System malfunction	Reset the TDM-LIC.	
2006	Alarm	No communication with TDM-LIC	Major	System malfunction	Reset the TDM-LIC.	
2007	Alarm	Jitter-buffer-overflow alarm on TDM service	Major	Something wrong on TDM service synchronization	Check TDM service configuration	
2008	Alarm	Late-frame alarm on TDM service	Warning	Something wrong on TDM service	Check TDM service configuration	
2009	Alarm	Loss-of-frames alarm on TDM service	Major	Failure along the network path of TDM service	Check network or configuration for errors in the network transport side of the service	
2010	Alarm	Malformed-frames alarm on TDM service	Major	1. Payload size does not correspond to the defined value. Mismatch in PT value in RTP header (if used)	Check TDM service configuration	
2011	Alarm	Misconnection alarm on TDM service	Major	Stray packets with wrong RTP configurations are received and dropped.	Check TDM service configuration	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2012	Alarm	Alarm Indication Signal (AIS) on TDM-LIC TDM port	Major	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. Check external equipment.	
2013	Alarm	Loss Of Frame (LOF) on TDM-LIC TDM port	Major	1. Line is not properly connected. External equipment is faulty.		
2014	Alarm	Loss Of Multi-Frame (LOMF) on TDM-LIC TDM port	Major	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. Check external equipment.	
2015	Alarm	Loopback on TDM-LIC TDM port	Warning	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. Check external equipment.	
2016	Alarm	Loss Of Signal (LOS) on TDM-LIC TDM port	Major	1. Line is not properly connected. 2. Cable is faulty. 3. External equipment is faulty. Defective TDM-LIC.	1. Reconnect line. 2. Check line cables. Check external equipment.	
2017	Alarm	Remote Alarm Indication (RAI) on TDM-LIC TDM port	Minor	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. Check external equipment.	
2018	Alarm	E1/DS1 Unexpected signal on TDM-LIC TDM port	Warning	1. Port is disabled. Line is connected to a disabled port.	1. Enable relevant port. Disconnect cable from relevant port.	
2021	Event	SSM received pattern change was discovered	Warning		No action is required.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2022	Alarm	Excessive BER on TDM-LIC STM1/OC3 port	Major	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2023	Alarm	Loss Of Frame (LOF) on TDM-LIC STM1/OC3 port	Major	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2024	Alarm	Loopback on TDM-LIC STM1/OC3 port	Warning	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2025	Alarm	Loss Of Signal (LOS) on TDM-LIC STM1/OC3 port	Critical	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2026	Alarm	SFP is muted on TDM-LIC STM1/OC3 port	Warning			
2027	Alarm	SFP absent in TDM-LIC STM1/OC3 port	Critical	1. SFP is not properly installed. SFP is faulty.	1. Install SFP properly. Replace the card.	
2028	Alarm	SFP failure on TDM-LIC STM1/OC3 port	Critical	1. SFP is not properly installed. SFP is faulty.	1. Install SFP properly. Replace the card.	
2029	Alarm	SFP transmit failure on TDM-LIC STM1/OC3 port	Critical	1. SFP is not properly installed. SFP is faulty.	1. Install SFP properly. Replace the card.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2030	Alarm	Signal Degrade on TDM-LIC STM1/OC3 port	Minor	<ol style="list-style-type: none"> Line is not properly connected. SFP is not properly installed. SFP is faulty. External equipment is faulty	<ol style="list-style-type: none"> Install SFP properly. Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.	
2031	Alarm	J0 Trace Identifier Mismatch on TDM-LIC STM1/OC3 port	Minor	<ol style="list-style-type: none"> J0 misconfiguration. Line is not properly connected. SFP is not properly installed. External equipment is faulty.	<ol style="list-style-type: none"> Make sure expected and received J0 match. Install SFP properly. Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.	
2032	Event	SSM pattern received on TDM-LIC STM1/OC3 port changed	Warning			
2033	Alarm	Alarm Indication Signal (AIS) on TDM-LIC VC12/VT1.5	Minor	<ol style="list-style-type: none"> Line is not properly connected. External equipment is faulty.	<ol style="list-style-type: none"> Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.	
2034	Alarm	Excessive BER on TDM-LIC VC12/VT1.5	Minor	<ol style="list-style-type: none"> Line is not properly connected. External equipment is faulty.	<ol style="list-style-type: none"> Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.	
2035	Alarm	Loopback on TDM-LIC VC12/VT1.5	Warning	<ol style="list-style-type: none"> Line is not properly connected. External equipment is faulty.	<ol style="list-style-type: none"> Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2036	Alarm	Payload Mismatch Path (PLM) received on TDM-LIC VC12/VT1.5	Minor	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2037	Alarm	Remote Defect Indication (RDI) received on TDM-LIC VC12/VT1.5	Minor	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2038	Alarm	Signal Label Mismatch (SLM) received on TDM-LIC VC12/VT1.5	Minor	1. J2 misconfiguration. 2. Line is not properly connected. External equipment is faulty.	1. Make sure expected and receive J2 match. 2. Reconnect line. 3. Check line cables. 4. Check external equipment. Power cycle the TDM-LIC.	
2039	Alarm	Signal Degrade on TDM-LIC VC12/VT1.5	Minor	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2040	Alarm	Unequipped on TDM-LIC VC12/VT1.5	Minor	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2041	Alarm	TDM-LIC card protection configuration mismatch	Major	The configuration between the TDM-LIC card protection members is not aligned	Apply a copy-to-mate command to copy the configuration from the required TDM-LIC to the other one	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2042	Alarm	TDM-LIC card protection group lockout command is on	Minor	The user has issued a lockout command	Clear the lockout command	
2043	Alarm	A member of TDM-LIC card protection group is missing	Minor	TDM-LIC card is not installed in the shelf	Install the missing TDM-LIC card	
2044	Event	TDM-LIC card protection switch over, priority	Warning	1. LOS alarm on a STM1 interface of the TDM-LIC card protection group member; A TDM-LIC card protection group member was disabled or pulled out of the shelf	1. Check line cables. Check external equipment.	
2045	Alarm	Loss Of Pointer (LOP) received on TDM-LIC VC12/VT1.5	Minor	1. Line is not properly connected. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment. Power cycle the TDM-LIC.	
2046	Event	Path protection switch on TDM service	Minor	1. Failure along service primary path. User command.	1. Check errors along primary path Check local service configuration.	
2047	Event	Path protection revertive switch on TDM service	Minor	Primary path has been operational for the duration of the defined WTR time	-	
2100	Alarm	Loss of Signal on Line Interface (LOS) on STM-1/OC-3 port.	Critical	1. Line is not properly connected. 2. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment.	
2101	Alarm	Loss of Frame on Line Interface (LOF) on STM-1/OC-3 port.	Major	1. Line is not properly connected. 2. External equipment is faulty.	1. Reconnect line. 2. Check line cables. 3. Check external equipment.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2102	Alarm	Alarm Indication Signal on Line Interface (MS-AIS/AIS-L) received.	Minor	<ol style="list-style-type: none"> Line is not properly connected. External equipment is faulty. 	<ol style="list-style-type: none"> Reconnect line. Check line cables. Check external equipment. 	
2103	Alarm	Remote Defect Indication on Line Interface (MS-RDI/RDI-L) received.	Minor	External equipment is faulty.	Check external equipment.	
2104	Alarm	Loss of STM-1/OC-3 Frame on Radio Interface.	Major	<ol style="list-style-type: none"> All channels in Multi Carrier ABC group are down. Incorrect configuration on remote side. 	<ol style="list-style-type: none"> Check link performance. Check radio alarms for channel. Check configuration. 	
2105	Alarm	MS-AIS/AIS-L on Radio Interface detected.	Minor	<ol style="list-style-type: none"> Remote STM-1/OC-3 signal is missing (LOS/LOF/MS-AIS/AIS-L on remote STM-1/OC-3 interface). STM-1/OC-3 Channel removed due to reduced radio capacity on remote side. 	Check remote equipment.	
2106	Alarm	MS-RDI/RDI-L on Radio Interface detected.	Minor	External equipment is faulty.	Check remote equipment.	
2107	Alarm	Loopback	Warning	Looping.	Remove looping.	
2108	Alarm	STM-1/OC-3 Channel Removed alarm (due to reduced radio capacity).	Warning	<ol style="list-style-type: none"> Reduced capacity. Fading 	<ol style="list-style-type: none"> Check link performance. Check radio alarms for channel. 	
2109	Alarm	PBRS insertion.	Warning	PRBS insertion on STM-1/OC-3 card.	Remove PRBS insertion.	
2110	Alarm	SFP absent on STM-1/OC-3 port.	Critical	<ol style="list-style-type: none"> SFP is not properly installed. SFP is faulty. 	<ol style="list-style-type: none"> Install SFP properly. Replace the card. 	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2111	Alarm	SFP Transmit Failure on STM-1/OC-3 port.	Critical	SFP is faulty.	1. Replace SFP or insert SFP if it is not inserted correctly. 2. Replace the card.	
2112	Alarm	SFP is muted on STM-1/OC-3 port.	Warning	SFP is muted by configuration.	Remove muting.	
2113	Alarm	STM-1/OC-3 Channel Removed alarm (due to reduced radio capacity).	Warning	1. Reduced capacity. 2. Fading.	1. Check link performance. 2. Check radio alarms for channel.	
2114	Alarm	STM-1/OC-3 Channel Removed alarm (due to reduced radio capacity).	Warning	1. Reduced capacity. 2. Fading.	1. Check link performance. 2. Check radio alarms for channel.	
2115	Alarm	STM-1/OC-3 Channel Removed alarm (due to reduced radio capacity).	Warning	1. Reduced capacity. 2. Fading.	1. Check link performance. 2. Check radio alarms for channel.	
2116	Alarm	STM-1/OC-3 Channel Removed alarm (due to reduced radio capacity).	Warning	1. Reduced capacity. 2. Fading.	1. Check link performance. 2. Check radio alarms for channel.	
2117	Alarm	STM-1/OC-3 Channel Removed alarm (due to reduced radio capacity).	Warning	1. Reduced capacity. 2. Fading.	1. Check link performance. 2. Check radio alarms for channel.	
2118	Alarm	STM-1/OC-3 Channel Removed alarm (due to reduced radio capacity).	Warning	1. Reduced capacity. 2. Fading.	1. Check link performance. 2. Check radio alarms for channel.	
2119	Alarm	STM-1/OC-3 Channel Removed alarm (due to reduced radio capacity).	Warning	1. Reduced capacity. 2. Fading.	1. Check link performance. 2. Check radio alarms for channel.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2200	Alarm	Multi Carrier ABC LOF.	Critical	All channels in Multi Carrier ABC group are down.	<ol style="list-style-type: none"> 1. Check link performance on all radio channels in Multi Carrier ABC group. 2. Check radio alarms for channels in Multi Carrier ABC group. 3. Check configuration of Multi Carrier ABC group. 	
2201	Alarm	Multi Carrier ABC bandwidth is below the threshold	Major	<ol style="list-style-type: none"> 1. One of the radio channels in the Multi Carrier ABC group has a lower capacity than expected 2. Minimum bandwidth threshold configuration is wrong 	<ol style="list-style-type: none"> 1. Check link performance on all radio channels in Multi Carrier ABC group 2. Check radio alarms for channels in Multi Carrier ABC group 3. Check configuration of Multi Carrier ABC group Minimum bandwidth threshold 	
2203	Alarm	LVDS RX Error Slot 2.	Major	Hardware failure between RMC and TCC cards.	<ol style="list-style-type: none"> 1. Replace RMC. 2. Replace TCC. 3. Replace chassis. 	
2204	Alarm	LVDS RX Error Slot 3.	Major	Hardware failure between RMC and TCC cards.	<ol style="list-style-type: none"> 1. Replace RMC. 2. Replace TCC. 3. Replace chassis. 	
2205	Alarm	LVDS RX Error Slot 4.	Major	Hardware failure between RMC and TCC cards.	<ol style="list-style-type: none"> 1. Replace RMC. 2. Replace TCC. 3. Replace chassis. 	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2206	Alarm	LVDS RX Error Slot 5.	Major	Hardware failure between RMC and TCC cards.	1. Replace RMC. 2. Replace TCC. 3. Replace chassis.	
2207	Alarm	LVDS RX Error Slot 6.	Major	Hardware failure between RMC and TCC cards.	1. Replace RMC. 2. Replace TCC. 3. Replace chassis.	
2208	Alarm	LVDS RX Error Slot 7.	Major	Hardware failure between RMC and TCC cards.	1. Replace RMC. 2. Replace TCC. 3. Replace chassis.	
2209	Alarm	LVDS RX Error Slot 8.	Major	Hardware failure between RMC and TCC cards.	1. Replace RMC. 2. Replace TCC. 3. Replace chassis.	
2210	Alarm	LVDS RX Error Slot 9.	Major	Hardware failure between RMC and TCC cards.	1. Replace RMC. 2. Replace TCC. 3. Replace chassis.	
2211	Alarm	LVDS RX Error Slot 10.	Major	Hardware failure between RMC and TCC cards.	1. Replace RMC. 2. Replace TCC. 3. Replace chassis.	
2212	Alarm	LVDS RX Error Slot 12.	Major	Hardware failure between RMC and TCC cards.	1. Replace RMC. 2. Replace TCC. 3. Replace chassis.	
2219	Alarm	Multi Carrier ABC Channel Id Mismatch Ch1.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.	
2220	Alarm	Multi Carrier ABC Channel Id Mismatch Ch2.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2221	Alarm	Multi Carrier ABC Channel Id Mismatch Ch3.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.	
2222	Alarm	Multi Carrier ABC Channel Id Mismatch Ch4.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.	
2223	Alarm	Multi Carrier ABC Channel Id Mismatch Ch5.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.	
2224	Alarm	Multi Carrier ABC Channel Id Mismatch Ch6.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.	
2225	Alarm	Multi Carrier ABC Channel Id Mismatch Ch7.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.	
2226	Alarm	Multi Carrier ABC Channel Id Mismatch Ch8.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.	
2235	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch1.	Warning	Admin state for channel is down.	Enable admin state for channel.	
2236	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch2.	Warning	Admin state for channel is down.	Enable admin state for channel.	
2237	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch3.	Warning	Admin state for channel is down.	Enable admin state for channel.	
2238	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch4.	Warning	Admin state for channel is down.	Enable admin state for channel.	
2239	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch5.	Warning	Admin state for channel is down.	Enable admin state for channel.	
2240	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch6.	Warning	Admin state for channel is down.	Enable admin state for channel.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
2241	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch7.	Warning	Admin state for channel is down.	Enable admin state for channel.	
2242	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch8.	Warning	Admin state for channel is down.	Enable admin state for channel.	
2300	Alarm	Protection configuration mismatch!	Major	The configuration between the protected devices is not aligned.	Apply copy-to-mate command to copy the configuration from the required device to the other one.	All
2301	Event	Copy to mate started	Indeterminate	The copy-to-mate command has just begun!	This is a notification	All
2302	Event	Copy to mate completed	Indeterminate	The copy-to-mate command was completed.	This is a notification	All
3000	Event	Chassis was reset	Warning	User issued a command to reset the chassis.	Wait until the reset cycle is ended and the system is up and running.	
3001	Alarm	Reset chassis to activate front panel Ethernet ports	Warning	Front panel Ethernet ports cannot work when slot 12 is configured in 10Gbps mode.	Reset chassis.	
3002	Alarm	Front panel Ethernet port cannot function in current configured capacity mode	Warning	Front panel Ethernet port cannot work in a mode other than 1Gbps.	Configure the relevant capacity mode to 1 Gbps mode.	
3003	Alarm	Multi Carrier ABC group is not functional in current configured capacity mode	Warning	Multi Carrier ABC group does not support the configured capacity mode.	Configure the relevant capacity mode to 1 Gbps mode.	
3004	Alarm	Multi Carrier ABC group is not functional in current configured capacity mode until chassis is reset	Warning	Multi Carrier ABC group capacity mode is different than the configured capacity mode.	Reset chassis.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
4000	Alarm	Card has one or more HW failures	Critical	One or more HW faults.	Replace card.	
4001	Alarm	Card can not function in 2.5Gbps mode.	Warning	The user set an expected card that does not support 2.5Gbps.	Change the Slot Section to 1Gbps.	
4002	Alarm	Card is not functional until chassis is reset	Warning	Slot is not in 10Gbps mode.	Reset chassis.	
5000	Event	User blocked due to consecutive failure login	Indeterminate	User blocked due to consecutive failure login	The user should wait few minutes until it account will be unblock	
5001	Alarm	ERPI is either in protection state or forced protection state	Minor	Either user "force switch" command or one of the ring links has failed	Either clear force command or recover the link	
5002	Alarm	More than a single RPL is configured in a ring	Warning	User configuration	Reconfigure the RPL	
5003	Event	LLDP topology change	Warning	New neighbor	None	
5004	Event	Security log upload started	Indeterminate	Security log upload started		
5005	Event	Security log upload failed	Indeterminate	Security log upload failed		
5006	Event	Security log upload succeeded	Indeterminate	Security log upload succeeded		
5010	Alarm	System is in sync force mode state	Warning			
5011	Event	The sync-source quality level was changed	Major			
5012	Alarm	System Synchronization Reference in Holdover Mode	Critical			
5013	Event	System Sync reference-to quality has change changed	Major			

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
5014	Alarm	The pipe interface clock-source in signal-interface table is not system-clock	Major			
5015	Alarm	The pipe is missing an edge interface	Major			
5016	Alarm	Pipe interface operational state is down	Major			
5017	Alarm	Pipe is invalid	Major			
5018	Alarm	1588TC is not operational	Major	System Failure	Reboot the unit	
5030	soam-connectivity-failure	A connectivity failure in MA/MEG	Minor	Specific defect dependent: User configuration , connectivity loss.	Reconfigure the RPL.	
5031	soam-def-error-failure	Error CCM received	Major	Invalid CCMs has been received	Check the link in the traffic path	(1)
5032	soam-def-mac-failure	Remote mep MAC status not up	Minor	Remote MEP's associated MAC is reporting an error status	Check remote MEP's MAC status	(1)
5033	soam-def-rdi-failure	Mep Rdi received	Minor	Remote Defect indication has been received from remote MEP	Check the SOAM configurations	(1)
5034	soam-remote-ccm-failure	Remote mep CCMs are not received	Major	The MEP is not receiving CCMs from at least one of the remote MEPs	Check that all remote MEPs are configured or enbaled	(1)

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
5035	soam-def-xcon-failure	Cross Connect CCM received	Major	CCM from another MAID or lower MEG level have been received	Check MA/MEG and MEP configurations	(1)
5036	Event	1588-BC port state changed	Warning			
5037	Event	1588-BC BMCA has been updated.	Warning			
5038	Event	1588-BC outputs are squelched.	Warning			
5039	Event	1588-BC parent dataset has changed.	Warning			
5040	Event	1588-BC UTC offset value changed.	Warning			
5041	Event	1588-BC one of the leap seconds flags have changed.	Warning			
5042	Event	1588-BC message interval change detected.	Warning			
5043	Alarm	1588-BC announce message rate is below expected.	Major	Misconfiguration of the peer system.	Check the configuration of the peer system.	
5044	Alarm	1588-BC sync message rate is below expected.	Major	Misconfiguration of the peer system.	Check the configuration of the peer system.	
5045	Alarm	1588-BC delay request message rate is below expected.	Major	Misconfiguration of the peer system.	Check the configuration of the peer system.	
5046	Alarm	1588-BC performance is degraded due to loss of system clock reference.	Critical	Loss of system clock reference.	Restore the system clock synchronization to a PRC-traceable source.	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
5100	Alarm	Master key mismatch cross over the link	Critical	Master Key was not set correctly.	Verify the Master Key.	(1)
5101	Alarm	No Master Key set, default value used	Warning	Crypto module has been enabled, but no Master Key has been loaded.	Set the Master Key.	(1)
5102	Alarm	Payload Encryption failure	Critical	<ol style="list-style-type: none"> 1. Radio LOF on Tx/Rx direction. 2. The session key does not match across the link. 3. The AES admin setting does not match across the link. 	<ol style="list-style-type: none"> 1. Validate the MSE on both sides of the link. 2. Validate the session key on both sides of the link. 3. Validate the AES admin setting on both sides of the link. 	(1)
5104	Event	Key Exchange Protocol progress, Traffic has been blocked	Indeterminate			(1)
5105	Event	Key Exchange Protocol initiated by remote side	Indeterminate			(1)
5106	Event	Key Zeroization command executed	Indeterminate			(1)
5107	Alarm	FIPS Bypass Self-Test failed	Critical	Disk failure		(1)
5108	Alarm	Power On Self-Test Failed	Critical	System failure	Reboot the unit.	(1)
5109	Alarm	Main board is not FIPS certified	Critical	Main Board used is not FIPS certified	Use a FIPS-certified TCC.	
5110	Alarm	Radio card is not FIPS certified	Major	Radio Card used is not FIPS certified	Use a FIPS-certified RMC.	
5111	Alarm	Radio crypto module fail	Critical	FIPS Radio Encryption Self-Test failed	Use different FIPS supported radio card	

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
5112	Alarm	Radio encryption not supported	Major	No Payload Encryption Activation Key inserted	Insert suitable Activation Key and reboot the unit	
5030	Alarm	A connectivity failure in MA/MEG	Minor	Specific defect dependent: User configuration , connectivity loss.	Reconfigure the RPL.	
30007	Event	Clock source sharing failure	Critical	<ol style="list-style-type: none"> 1. Faulty coaxial cable between master and slave RFUs. 2. Hardware failure in Master RFU. 3. Hardware failure in Slave RFU. 	<ol style="list-style-type: none"> 1. Try re-initiation of MIMO. If still fails: 2. Replace faulty coaxial cable and reset Master RFU. 3. Replace faulty RFU. 	(2)
31000	Alarm	Insufficient conditions for MIMO	Critical	<ol style="list-style-type: none"> 1. Insufficient conditions for MIMO. 2. Hardware failure. 	<ol style="list-style-type: none"> 1. Make sure all cables between master and slave are connected (MIMO 4x4 only). 2. Replace faulty units and check that cables are plugged. 	(2)
31003	Alarm	Unsuitable hardware for MIMO	Critical	<ol style="list-style-type: none"> 1. Unsuitable hardware for MIMO operation requirements. 2. Dual carrier RFUs (MIMO 2x2 and 4x4). 3. RFUs with MIMO bus interface (MIMO 4x4). 4. Clock source sharing capability (MIMO 4x4). 	Make sure both RFUs are compatible for MIMO operation.	(2)

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
31004	Alarm	Unsuitable software configuration for MIMO	Critical	<ol style="list-style-type: none"> Not all MIMO carriers are set to same radio script or script is not compatible for MIMO. Radio TX and RX frequency is not identical on all MIMO carriers. XPIC or Multi radio or ATPC features are enabled. 	<ol style="list-style-type: none"> Load same MIMO compatible radio script to all MIMO carriers. Set same TX and RX frequency on all MIMO carriers. Disable XPIC, Multi radio and ATPC on all MIMO carriers. 	(2)
31005	Alarm	Clock source sharing cable unplugged	Critical	<ol style="list-style-type: none"> Faulty coaxial cable between master and slave RFUs Mate does not exist 	<ol style="list-style-type: none"> Replace faulty coaxial cable and reset Master RFU. Replace faulty RFU. 	(2)
31100	Alarm	Radio script is incompatible to AMCC	Critical	MRMC Script selected does not support AMCC Group type/subtype	Set AFR Script in both Agg1 & Agg2 carriers	
31101	Alarm	Inconsistent MRMC script between members	Critical	All members of a group must be configured to the same MRMC Script	Set the members to the appropriate MRMC script	
31102	Alarm	Inconsistent radio frequency	Critical	Radio TX/RX frequency is not identical on all AMCC carriers	Set same radio TX/RX frequency on all AMCC carriers	
31103	Alarm	Agg 1 failed Bring-up procedure	Critical	Agg1 did not complete Bring-up successfully	Drop both Agg1 & Agg2 into single carrier mode (Pre-Init)	
31104	Alarm	Invalid ACM configuration	Critical	AMCC member have been set to fixed profile	Set AMCC member to adaptive ACM profiles	
5100	Alarm	Master key mismatch cross over the link	Critical	Master Key was not set correctly.	Verify the Master Key.	(1)
5101	Alarm	No Master Key set, default value used	Warning	Crypto module has been enabled, but no Master Key has been loaded.	Set the Master Key.	(1)

Alarm ID	Type	Description	Severity	Probable Cause	Corrective Action	Notes
5102	Alarm	Payload REncryption failure	Critical	1. Radio LOF on Tx/Rx direction. 2. The session key does not match across the link. 3. The AES admin setting does not match across the link.	1. Validate the MSE on both sides of the link. 2. Validate the session key on both sides of the link. 3. Validate the AES admin setting on both sides of the link.	(1)
5103	Event	Key Exchange Protocol successfully finished	Indeterminate			(1)
5104	Event	Key Exchange Protocol initiated	Indeterminate			(1)
5105	Event	Key Exchange Protocol initiated by remote side	Indeterminate			(1)
5106	Event	Key Zeroization command executed	Indeterminate			(1)
5107	Alarm	FIPS Bypass Self-Test failed	Critical	Disk failure		(1)
5108	Alarm	Power On Self-Test Failed	Critical	System failure	Reboot the unit.	(1)
5033	Alarm	Communications	Critical	Radio script is incompatible to AMCC	Set AFR Script in both Agg1 & Agg2 carriers	(1)
5034	Alarm	Communications	Critical	Inconsistent MRMC script between members	Set the members to the appropriate MRMC script	(1)
5035	Alarm	Communications	Critical	Inconsistent radio frequency	Set same radio TX/RX frequency on all AMCC carriers	(1)
5100	Alarm	Communications	Critical	Agg 1 failed Bring-up procedure	Drop both Agg1 & Agg2 into single carrier mode (Pre-Init)	(1)
5101	Alarm	Communications	Critical	Invalid ACM configuration	Set AMCC member to adaptive ACM profiles	(1)

- (1) Supported by PTP 850E
- (2) Supported by PTP 850E only

Glossary

Term	Definition
A	
ABC	Adaptive Bandwidth Control
ABN	Adaptive Bandwidth Notification
AC	Alternating Current
ACAP	Adjacent Channel Alternate Polarization
ACCP	Adjacent Channel Co-Polarization
ACM	Adaptive Coded Modulation
ACR	Adaptive Clock Recovery
AES	Advanced Encryption Standard
AFR	Advanced Frequency Reuse
AGC	Automatic Gain Control
AIS	Alarm Indicating Signal
ALC	Automatic Level Control
AMCC	Advanced Multi-Carrier Configuration
ANSI	American National Standards Institute
ASIC	Application Specified Integrated Circuit
ATPC	Automatic Transmit Power Control
AUX	Auxiliary Unit
B	
BB	Baseband
BBS	Baseband Switching
BER	Bit Error Rate
BLSR	Bidirectional Line Switch Ring
BPDU	Bridge Protocol Data Units
BWA	Broadband Wireless Access
C	

Term	Definition
CBS	Committed Burst Size
CCDP	Co-Channel Dual Polarization
CCITT	Comité Consultatif International de Télégraph et des Télécommunications (ITU)
CET	Carrier-Ethernet Transport
CFM	Connectivity Fault Management
CIR	Committed Information Rate
CLI	Command Line Interface
Clk	Clock
CODEC	Coder/Decoder
CoS	Class of Service
D	
DA	Destination Address
DC	Direct Current
DCB	Diversity Circulator Block
DCC	Data Communication Channel
DXC	Digital Cross Connect
DSCP	Differentiated Services Code Point
E	
EBS	Excess Burst Size
EIR	Excess Information Rate
EMC	Electromagnetic Compatibility
EOW	Engineering Order Wire
EPROM	Erasable Programmable Read Only Memory
ESD	Electrostatic Discharge
ESE	Electrical SFP Electrical
ESP	Electrical SFP SFP+ 10G
ESS	Electrical SFP SFP
ETSI	European Telecommunications Standards Institute
F	
FCC	Federal Communications Commission

Term	Definition
FCS	Frame Check Sequence
FTP	File Transfer Protocol
G	
GbE	Gigabit Ethernet
GFP	Generic Framing Procedure (Procedure for mapping of Ethernet traffic over a transport network)
GND	Ground
GRE	Generic Routing Encapsulation
GTP	GPRS Tunneling Protocol
H	
HBER	High Bit Error Rate
HDLC	High-level Data Link Control
HF	High Frequency (3-30 MHz)
HSB	Hot-Standby
HTTP	Hypertext Transfer Protocol
HTTPS	Secured Hypertext Transfer Protocol
I	
IDC	Indoor Controller
IF	Intermediate Frequency
IFC	IF Combining
ISO	International Organization for Standardization
ITU	International Telecom. Union
ITU-R	International Telecom. Union (former CCIR)
ITU-T	International Telecom. Union (former CCITT)
IVM	Inventory Module
L	
LACP	Link Aggregation Control Protocol
LAG	Link Aggregation Group
LAN	Local Area Network
LBER	Low Bit Error Rate

Term	Definition
LCAS	Link Capacity Adjustment Scheme
LED	Light Emitting Diode
LIU	Line Interface Unit
LLDP	Link Layer Discovery Protocol
LLF	Link Loss Forwarding
LMS	License Management System
LO	Local Oscillator
LOC	Loss of Carrier
LOF	Loss of Frame
LOS	Loss of Signal
LSI	Large Scale Integration
LTE	Long-Term Evolution
M	
MAID	Maintenance Association Identifier
MPLS	Multi Protocol Label Switching
MSP	Multiplex Section Protection
MUX	Multiplexer
N	
NE	Network Element
NMS	Network Management System
NTP	Network Time Protocol
O	
OAM	Operation Administration & Maintenance (Protocols)
OCB	Outdoor Circulator Box
OHC	OverHead Connections
OMT	Orthogonal Mode Transducer
OOF	Out of Frame
OPEX	Operational Expenditure
P	
PBB-TE	Provider Backbone Bridge Traffic Engineering

Term	Definition
PBS	Peak Burst Rate
PC	Personal Computer
PCB	Printed Circuit Board
PDV	Packed Delay Variation
PIR	Peak Information Rate
PLL	Phase Locked Loop
PM	Performance Monitoring
PN	Provider Network
PROM	Programmable Read Only Memory
PSN	Packet Switched Network
PTP	Precision Timing Protocol
PWR	Power
Q	
QoE	Quality of Experience
QoS	Quality of Service
R	
RBAC	Role Based Access Control
RCVR	Receiver
RDI	Reverse Defect Indication
RF	Radio Frequency
RIP	Routing Information Protocol
RMON	Ethernet Statistics
RPS	Radio Protection Switching
RSL	Received Signal Level
RSSI	Received Signal Strength Indicator
RSTP	Rapid Spanning Tree Protocol
S	
SAP	Service Access Point
SDH	Synchronous Digital Hierarchy
SDWRR	Shaped Deficit Weighted Round Robin

Term	Definition
SETS	Synchronous Equipment Timing Source
SFTP	Secure FTP
SLA	Service Level Agreements
SNCP	Simple Network Connection Protection
SNMP	Simple Network Management Protocol
SNP	Service Network Point
SNR	Signal to Noise Ratio
SNTP	Simple Network Time Protocol
SOH	Section OverHead (ETSI)
SONET	Synchronous Optical NETwork
SP	Service Point
SSH	Secured Shell (Protocol)
SSM	Synchronization Status Message
STP	Spanning Tree Protocol
SyncE	Synchronous Ethernet
SVCE	Service Channel Equipment
T	
TC	Traffic Class
TIM	Trace Identifier Mismatch
TOH	Transport OverHead (ANSI)
TOS	Type Of Service
V	
VC	Virtual Container
VCO	Voltage Controlled Oscillator
VCXO	Voltage Controlled crystal Oscillator
VLSI	Very Large Scale of Integration
W	
WAN	Wide Area Network
Web EMS	Web-Based Element Management System
WFQ	Weighted Fair Queue

Term	Definition
WG	Waveguide
WRED	Weighted Random Early Detection
WRR	Weighted Round Robin
X	
XCVR	Transceiver (Transmitter/Receiver)
XMTR	Transmitter
XO	Crystal Oscillator
XPD	Cross Polar Differentiation
XPI	Cross Polarization Isolation
XPIC	Cross Polarization Interference Cancellation