



User Guide

PTP 820 Split-Mount System Release 10.9



Accuracy

While reasonable efforts have been made to assure the accuracy of this document, Cambium Networks assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. Cambium reserves the right to make changes to any products described herein to improve reliability, function, or design, and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Cambium does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others. It is possible that this publication may contain references to, or information about Cambium products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Cambium intends to announce such Cambium products, programming, or services in your country.

Copyrights

This document, Cambium products, and 3rd Party software products described in this document may include or describe copyrighted Cambium and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Cambium, its licensors, and other 3rd Party supplied software certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Cambium, its licensors, or the 3rd Party software supplied material contained in the Cambium products described in this document may not be copied, reproduced, reverse engineered, distributed, merged or modified in any manner without the express written permission of Cambium. Furthermore, the purchase of Cambium products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Cambium or other 3rd Party supplied software, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

Restrictions

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Cambium.

License Agreements

The software described in this document is the property of Cambium and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

High Risk Materials

Cambium and its supplier(s) specifically disclaim any express or implied warranty of fitness for any high risk activities or uses of its products including, but not limited to, the operation of nuclear facilities, aircraft navigation or aircraft communication systems, air traffic control, life support, or weapons systems ("High Risk Use"). Any High Risk is unauthorized, is made at your own risk and you shall be responsible for any and all losses, damage or claims arising out of any High Risk Use.

© 2019 Cambium Networks Limited. All Rights Reserved.

phn-3965_009v000

Contents

About This User Guide	1
Contacting Cambium Networks	2
Purpose	3
Cross references	3
Feedback	3
Problems and warranty	4
Reporting problems.....	4
Repair and service	4
Hardware warranty	4
Security advice	5
Warnings, cautions, and notes	6
Warnings	6
Cautions.....	6
Notes	6
Caring for the environment	7
In EU countries	7
In non-EU countries.....	7
Chapter 1: Introduction.....	1-1
Configuration Tips.....	1-2
System Overview	1-4
PTP 820F	1-4
PTP 820G	1-4
Assured Platform.....	1-5
PTP 820F IDU Hardware Architecture.....	1-6
Front Panel Description	1-7
Ethernet Traffic interfaces.....	1-8
Ethernet Management interfaces	1-8
E1/DS1 Interface	1-9
Radio Interfaces.....	1-9
Power Interface	1-9
Synchronization Interface	1-10
Terminal Interface	1-10
External Alarms	1-10
Storage Memory Card	1-10
PTP 820G IDU Hardware Architecture	1-12
Front Panel Description	1-13
Ethernet Traffic Interfaces	1-14

Ethernet Management Interfaces	1-14
E1/DS1 Interface (Optional)	1-15
Radio Interfaces.....	1-15
Power Interface	1-15
Synchronization Interface	1-15
Terminal Interface	1-15
External Alarms	1-16
RFU Overview	1-17
Radio Frequency Units (RFUs) were designed with sturdiness, power, simplicity, and compatibility in mind. These advanced systems provide high-power transmission for short and long distances and can be assembled and installed quickly and easily.....	1-17
RFU's used with PTP 820F	1-17
RFU's used with PTP 820G	1-17
IDU-RFU Connection and Power Supply for PTP 820F.....	1-18
IDU-RFU Connection and Power Supply for PTP 820G.....	1-19
The Web-Based Element Management System	1-20
Introduction to the Web EMS	1-20
Web EMS Page Layout.....	1-20
The Unit Summary Page	1-24
The Radio Summary Page.....	1-25
Reference Guide to Web EMS Menu Structure	1-27
Chapter 2: Getting Started	2-1
Assigning IP Addresses in the Network.....	2-2
Establishing a Connection	2-3
Connecting to the Unit with a Serial Connection	2-3
Connecting to the Unit with a LAN Connection	2-4
Logging On	2-6
Changing Your Password.....	2-7
Performing Quick Platform Setup	2-8
Configuring In-Band Management.....	2-12
Changing the Management IP Address.....	2-13
Configuring Unit Redundancy for the PTP 820G.....	2-15
Unit Redundancy Overview	2-15
Configuring Unit Redundancy	2-16
Cabling Requirements for Unit Redundancy	2-18
Configuring Ethernet Interface Protection	2-19
Enabling Unit Redundancy	2-20
Changing the Configuration after Enabling Unit Redundancy.....	2-22
Viewing the Configuration of the Standby Unit	2-22
Viewing Link and Protection Status and Activity.....	2-23
Switchover.....	2-23
Performing Lockout.....	2-24
Disabling Unit Redundancy	2-24

Determining ETSI or ANSI (FCC) TDM Mode	2-26
Configuring the Activation Key	2-27
Viewing the Activation Key Status Parameters	2-27
Entering the Activation Key	2-29
Activating a Demo Activation Key	2-29
Displaying a List of Activation-Key-Enabled Features	2-29
Setting the Time and Date (Optional)	2-31
Enabling the Interfaces (Interface Manager)	2-33
Enabling the Second Management Interface	2-35
Configuring Cascading Interfaces (Optional)	2-35
Configuring the Radio Parameters.....	2-40
Enabling Link ID Mismatch Security	2-42
Configuring the Radio (MRMC) Script(s).....	2-43
Enabling ACM with Adaptive Transmit Power	2-54
Operating in FIPS Mode	2-55
Requirements for FIPS Compliance	2-55
Configuring Grouping (Optional)	2-57
Creating Service(s) for Traffic.....	2-58
Chapter 3: Configuration Guide.....	3-1
System Configurations	3-2
Radio Configurations	3-2
TDM Configurations	3-3
Configuring a Link Using the Quick Configuration Wizard	3-5
Configuring a 1+0 Link Using the Quick Configuration Wizard.....	3-5
Configuring a 1+0 (Repeater) Link Using the Quick Configuration Wizard.....	3-10
Configuring a 1+1 HSB Link Using the Quick Configuration Wizard	3-14
Configuring a 1+1 HSB-SD Link Using the Quick Configuration Wizard.....	3-18
Configuring an N+0 Multi-Carrier ABC Link Using the Quick Configuration Wizard.....	3-22
Configuring a 1+0 Link.....	3-31
Configuring Multi-Carrier ABC	3-32
Multi-Carrier ABC Overview	3-32
Configuring a Multi-Carrier ABC Group	3-32
Deleting a Multi-Carrier ABC Group	3-35
Configuring Link Aggregation (LAG) and LACP	3-36
LAG Overview	3-36
Configuring a LAG Group.....	3-37
Enabling and Disabling LAG Group Shutdown in case of Degradation Event.....	3-41
Configuring Enhanced LAG Distribution	3-42
Deleting a LAG Group	3-43
Displaying LACP Parameters and Statistics	3-43
Displaying LACP Aggregation Status Parameters	3-43
Displaying LACP Port Status Parameters	3-44

Displaying LACP Port Statistics	3-47
Displaying LACP Port Debug Staistics	3-48
Configuring XPIC	3-50
Prerequisites for XPIC.....	3-50
Configuring the Carriers	3-50
Creating an XPIC Group.....	3-51
Performing Antenna Alignment for XPIC.....	3-53
Deleting an XPIC Group	3-54
Configuring HSB Radio Protection	3-55
HSB Radio Protection Overview	3-55
Configuring 1+1 HSB without Space Diversity	3-55
Configuring 1+1 HSB with Space Diversity	3-58
Copying Configuration to Mate.....	3-60
Revertive Mode	3-62
Switchovers and Lockout.....	3-63
Deleting an HSB Radio Protection Group without Space Diversity	3-64
Deleting an HSB Radio Protection Group with Space Diversity.....	3-64
Configuring IF Combining	3-65
Chapter 4: Unit Management.....	4-1
Defining the IP Protocol Version for Initiating Communications	4-2
Configuring the Remote Unit’s IP Address.....	4-3
Configuration SNMP	4-6
Configuring Trap Managers	4-9
Configuring the Internal Ports for FTP or SFTP	4-11
Installing and Configuring an FTP or SFTP Server	4-12
Upgrading the Software.....	4-15
Viewing Current Software Versions	4-15
Software Upgrade Overview	4-16
Downloading and Installing Software.....	4-16
Configuring a Timed Installation	4-24
Installing RFU Software	4-25
Backing Up and Restoring Configurations.....	4-26
Configuration Management Overview.....	4-26
Viewing Current Backup Files.....	4-26
Setting the Configuration Management Parameters	4-27
Exporting a Configuration File	4-30
Importing a Configuration File	4-30
Deleting a Configuration File	4-31
Backing Up the Current Configuration	4-31
Restoring a Saved Configuration	4-31
Setting the Unit to the Factory Default Configuration.....	4-33
Performing a Hard (Cold) Reset	4-34

Configuring Unit Parameters	4-35
Configuring NTP	4-37
Displaying Unit Inventory.....	4-39
Chapter 5: Radio Configuration	5-1
Viewing the Radio Status and Settings	5-2
Configuring the IDU-RFU Connection (PTP 820F only)	5-5
Configuring the Remote Radio Parameters	5-8
Configuring ATPC and Override Timer	5-12
Configuring Header De-Duplication	5-15
Configuring Frame Cut-Through	5-17
Viewing Header De-Duplication and Frame Cut-Through Counters	5-19
Configuring AES-256 Payload Encryption	5-22
Configuring and Viewing Radio PMs and Statistics	5-26
Configuring BER Thresholds and Displaying Current BER.....	5-26
Displaying MRMC Status	5-28
Displaying MRMC PMs	5-29
Displaying Defective Block Counters	5-30
Displaying Signal Level PMs and Configuring Signal Level PM Thresholds.....	5-31
Displaying PMs for the Combined IF Combining Signal.....	5-35
Displaying Modem BER (Aggregate) PMs.....	5-36
Displaying MSE PMs and Configuring MSE PM Thresholds.....	5-39
Displaying XPI PMs and Configuring XPI PM Thresholds.....	5-40
Displaying Traffic PMs	5-42
Chapter 6: Ethernet Services and Interfaces.....	6-1
Configuring Ethernet Service(s)	6-2
Ethernet Services Overview	6-2
General Guidelines for Provisioning Ethernet Services.....	6-2
The Ethernet Services Page	6-3
Adding an Ethernet Service	6-4
Editing a Service	6-6
Deleting a Service	6-6
Enabling, Disabling, or Deleting Multiple Services	6-6
Viewing Service Details	6-7
Configuring Service Points.....	6-8
Setting the MRU Size and the S-VLAN Ethertype.....	6-22
Configuring Ethernet Interfaces.....	6-24
Configuring Automatic State Propagation and Link Loss Forwarding.....	6-27
Viewing Ethernet PMs and Statistics	6-30
RMON Statistics.....	6-30
Egress CoS Statistics	6-31
Port TX Statistics.....	6-34
Port RX Statistics	6-37

Chapter 7: Quality of Service (QoS)	7-1
QoS Overview	7-2
Configuring Classification.....	7-4
Classification Overview	7-4
Configuring Ingress Path Classification on a Logical Interface	7-5
Modifying the C-VLAN 802.1Q UP and CFI Bit Classification Table	7-8
Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table.....	7-9
Modifying the DSCP Classification Table	7-10
Modifying the MPLS EXP Bit Classification Table	7-12
Configuring Policers (Rate Metering).....	7-14
Policer (Rate Metering) Overview	7-14
Configuring Policer Profiles	7-14
Assigning Policers to Interfaces.....	7-17
Configuring the Ingress and Egress Byte Compensation	7-20
Configuring Marking	7-21
Marking Overview	7-21
Enabling Marking.....	7-21
Modifying the 802.1Q Marking Table	7-21
Modifying the 802.1AD Marking Table	7-23
Configuring WRED.....	7-24
WRED Overview	7-24
Configuring WRED Profiles	7-24
Assigning WRED Profiles to Queues	7-27
Configuring Egress Shaping.....	7-28
Egress Shaping Overview.....	7-28
Configuring Queue Shaper Profiles	7-28
Configuring Service Bundle Shaper Profiles	7-31
Assigning a Queue Shaper Profile to a Queue.....	7-32
Assigning a Service Bundle Shaper Profile to a Service Bundle	7-35
Configuring Scheduling	7-37
Scheduling Overview	7-37
Configuring Priority Profiles	7-37
Configuring WFQ Profiles	7-41
Assigning a Priority Profile to an Interface	7-43
Assigning a WFQ Profile to an Interface.....	7-43
Chapter 8: Ethernet Protocols	8-1
Configuring G.8032	8-2
G.8032 Overview	8-2
Configuring the Destination MAC Address.....	8-3
Adding ERPIs.....	8-4
Configuring the RPL Owner	8-8
Configuring Timers	8-9

- Viewing the ERPI Configuration and Status Parameters 8-9
- Viewing ERPI State Information 8-10
- Initiating a Manual or Forced Switch and Clearing the Switch or Initiating Reversion 8-12
- Blocking or Unblocking R-APS Messages on a Service Point 8-12
- Viewing ERPI Statistics..... 8-12
- Configuring MSTP 8-14
 - MSTP Overview 8-15
 - Mapping Ethernet Services to MSTP instances (MSTIs) 8-15
 - Configuring the MSTP Bridge Parameters 8-17
 - Configuring the MSTP Port Parameters 8-27
- Configuring LLDP 8-36
 - LLDP Overview 8-36
 - Displaying Peer Status 8-36
 - Configuring the General LLDP Parameters 8-37
 - Configuring the LLDP Port Parameters 8-39
 - Displaying the Unit’s Management Parameters 8-41
 - Displaying Peer Unit’s Management Parameters 8-44
 - Displaying the Local Unit’s Parameters 8-45
 - Displaying LLDP Statistics 8-50
- Chapter 9: TDM Services and Interfaces 9-1**
 - TDM Overview 9-2
 - Configuring the E1/DS1 Interface 9-3
 - Configuring Native TDM Trails 9-7
 - Native TDM Trail Configuration Overview 9-7
 - General Guidelines for Provisioning TDM Services 9-9
 - Viewing TDM Trails..... 9-9
 - Configuring the Revertive Timer 9-10
 - Adding TDM Trails 9-10
 - Editing TDM Trails 9-19
 - Deleting TDM Trails 9-21
 - Limitations on Available Endpoints 9-21
 - Configuring TDM Pseudowire Services 9-22
 - TDM Pseudowire Services Configuration Overview 9-23
 - General Guidelines for Provisioning TDM Pseudowire Services 9-23
 - Viewing TDM Pseudowire Services 9-24
 - Configuring the Revertive Timer 9-26
 - Adding TDM Pseudowire Services 9-26
 - Editing TDM Pseudowire Services 9-36
 - Deleting TDM Pseudowire Services 9-38
 - Limitations on Available Endpoints 9-38
 - Configuring Advanced Pseudowire Parameters 9-39
 - Configuring Pseudowire Card Parameters 9-39

- Configuring OEM for Pseudowire Services 9-41
- Configuring Pseudowire Tunnels and Tunnel Groups 9-47
- Configuring Pseudowire Profiles 9-56
- Configuring Pseudowire TDM Services Manually 9-60
- Displaying TDM PMs 9-66
 - Displaying E1/DS1 PMs 9-66
 - Displaying Native TDM Service PMs 9-68
 - Displaying Pseudowire Service PMs 9-69
- Chapter 10: Synchronization 10-1**
 - Configuring the Sync Source 10-2
 - Viewing the Sync Source Status 10-2
 - Adding a Sync Source 10-3
 - Editing a Sync Source 10-4
 - Deleting a Sync Source 10-5
 - Configuring the Outgoing Clock and SSM Messages 10-6
 - Configuring 1588 Transparent Clock 10-9
 - Configuring 1588 Boundary Clock 10-12
 - Enabling Boundary Clock 10-12
 - Displaying and Setting the Boundary Clock Default Parameters 10-15
 - Displaying the Boundary Clock Advanced Parameters 10-16
 - Displaying the Boundary Clock Port Parameters 10-18
 - Displaying the Boundary Clock Port Statistics 10-19
 - Disabling 1588 PTP 10-20
- Chapter 11: Access Management and Security 11-1**
 - Configuring the General Access Control Parameters 11-2
 - Configuring the Password Security Parameters 11-4
 - Configuring the Session Timeout 11-5
 - Configuring Users 11-6
 - User Configuration Overview 11-6
 - Configuring User Profiles 11-6
 - Configuring Users Accounts 11-9
 - Configuring RADIUS 11-12
 - RADIUS Overview 11-12
 - Activating RADIUS Authentication 11-12
 - Configuring the RADIUS Server Attributes 11-13
 - Viewing RADIUS User Permissions and Connectivity 11-14
 - Configuring a RADIUS Server 11-16
 - Configuring X.509 CSR Certificates and HTTPS 11-35
 - Generating a Certificate Signing Request (CSR) File 11-35
 - Downloading a Certificate 11-37
 - Blocking Telnet Access 11-40
 - Uploading the Security Log 11-41

Uploading the Configuration Log	11-44
Chapter 12: Alarm Management and Troubleshooting	12-1
Viewing Current Alarms	12-2
Viewing Alarm Statistics	12-4
Viewing the Event Log	12-5
Editing Alarm Text and Severity	12-7
Displaying Alarm Information	12-7
Viewing the Probable Cause and Corrective Actions for an Alarm Type	12-8
Editing an Alarm Type	12-8
Setting Alarms to their Default Values	12-9
Configuring External Alarms	12-10
Configuring Input Alarms	12-10
Configuring the Output Alarm	12-12
Uploading Unit Info	12-16
Performing Diagnostics	12-18
Performing Radio Loopback	12-18
Performing Ethernet Loopback	12-20
Performing TDM Diagnostics	12-22
Configuring Service OAM (SOAM) Fault Management (FM)	12-24
Chapter 13: Web EMS Utilities	13-1
Restarting the HTTP Server	13-2
Calculating an ifIndex	13-3
Displaying, Searching, and Saving a list of MIB Entities	13-4
Chapter 14: Getting Started (CLI)	14-1
Establishing a Connection (CLI)	14-2
Logging On (CLI)	14-3
General CLI Commands	14-4
Changing Your Password (CLI)	14-5
Configuring In-Band Management (CLI)	14-6
Changing the Management IP Address (CLI)	14-7
Configuring Unit Redundancy for the PTP 820 Split Mount (CLI)	14-9
Configuring Unit Redundancy (CLI)	14-9
Configuring Ethernet Interface Protection (CLI)	14-10
Enabling Unit Redundancy (CLI)	14-11
Changing the Configuration after Enabling Unit Redundancy (CLI)	14-12
Running Commands in the Standby Unit (CLI)	14-12
Viewing Link and Protection Status and Activity (CLI)	14-13
Switchover (CLI)	14-13
Performing Lockout (CLI)	14-14
Disabling Unit Redundancy (CLI)	14-14
Configuring the Activation Key (CLI)	14-16
Activation Key Overview (CLI)	14-16

Installing an Activation Key (CLI)	14-17
Displaying Activation Key Information (CLI)	14-17
Activating an Activation Key (CLI).....	14-17
Setting the Time and Date (Optional) (CLI)	14-19
Enabling the Interfaces (Interface Manager) (CLI)	14-22
Enabling the Second Management Interface (CLI)	14-23
Configuring Cascading Interfaces (Optional) (CLI)	14-24
Entering Radio View (CLI).....	14-25
Unmuting a Radio (CLI)	14-26
Configuring the Transmit (TX) Level (CLI).....	14-27
Configuring the Transmit (TX) Frequency (CLI)	14-28
Configuring the Radio (MRMC) Script(s) (CLI).....	14-29
Displaying Available MRMC Scripts (CLI)	14-29
Assigning an MRMC Script to a Radio Carrier (CLI)	14-31
Enabling ACM with Adaptive Transmit Power (CLI)	14-33
Configuring the RSL Threshold Alarm (CLI)	14-34
Operating in FIPS Mode (CLI)	14-35
Requirements for FIPS Compliance (CLI)	14-35
Enabling FIPS Mode (CLI).....	14-35
Chapter 15: Configuration Guide (CLI)	15-1
System Configurations (CLI)	15-2
Radio Configurations (CLI)	15-2
TDM Configurations	15-3
Configuring a 1+0 Link (CLI)	15-4
Configuring Multi-Carrier ABC (CLI)	15-5
Multi-Carrier ABC Overview (CLI)	15-5
Configuring a Multi-Carrier ABC Group (CLI)	15-5
Removing Members from a Multi-Carrier ABC Group (CLI)	15-7
Deleting a Multi-Carrier ABC Group (CLI)	15-7
Configuring Link Aggregation (LAG) and LACP (CLI)	15-9
LAG Overview (CLI).....	15-9
Configuring a LAG Group (CLI).....	15-10
Configuring LACP (CLI)	15-12
Enabling and Disabling the LAG Group Shutdown in case of Degradation Event Option (CLI)	15-13
Configuring Enhanced LAG Distribution (CLI)	15-14
Deleting a LAG Group (CLI).....	15-15
Displaying LACP Parameters and Statistics (CLI)	15-15
Configuring XPIC (CLI)	15-20
Prerequisites for XPIC (CLI).....	15-20
Configuring the Carriers (CLI)	15-20
Creating an XPIC Group (CLI)	15-21
Performing Antenna Alignment for XPIC (CLI).....	15-21

Deleting an XPIC Group (CLI)	15-22
Configuring HSB Radio Protection (CLI)	15-23
HSB Radio Protection Overview (CLI)	15-23
Configuring 1+1 HSB without Space Diversity (CLI)	15-23
Configuring 1+1 HSB with Space Diversity (CLI)	15-24
Copying Configuration to Mate (CLI)	15-25
Revertive Mode (CLI)	15-25
Switchovers and Lockout (CLI)	15-26
Deleting an HSB Radio Protection Group (CLI) without Space Diversity	15-27
Deleting an HSB Radio Protection Group with Space Diversity (CLI)	15-27
Chapter 16: Unit Management (CLI)	16-1
Defining the IP Protocol Version for Initiating Communications (CLI)	16-2
Configuring the Remote Unit's IP Address (CLI)	16-3
Configuring the Remote Radio's IP Address in IPv4 format (CLI)	16-3
Configuring the Remote Radio's IP Address in IPv6 format (CLI)	16-4
Configuring SNMP (CLI)	16-6
Configuring SNMP (CLI)	16-6
Defining the SNMP Parameters (CLI)	16-6
Displaying the SNMP Settings (CLI)	16-8
Configuring Trap Managers (CLI)	16-8
Configuring the Internal Ports for FTP or SFTP (CLI)	16-9
Upgrading the Software (CLI)	16-10
Software Upgrade Overview (CLI)	16-10
Displaying Current Software Versions (CLI)	16-11
Configuring a Software Download (CLI)	16-12
Downloading a Software Package (CLI)	16-14
Installing and Upgrading Software (CLI)	16-15
Installing and Upgrading Software in the RFU (CLI)	16-15
Backing Up and Restoring Configurations (CLI)	16-18
Configuration Management Overview (CLI)	16-18
Setting the Configuration Management Parameters (CLI)	16-18
Backing up a Configuration File (CLI)	16-20
Importing and Restoring a Configuration File (CLI)	16-23
Editing CLI Scripts (CLI)	16-25
Setting the Unit to the Factory Default Configuration (CLI)	16-26
Performing a Hard (Cold) Reset (CLI)	16-27
Configuring Unit Parameters (CLI)	16-28
Configuring NTP (CLI)	16-30
Displaying Unit Inventory (CLI)	16-31
Chapter 17: Radio Configuration (CLI)	17-1
Viewing the Radio Status and Settings (CLI)	17-2
Configuring the Remote Radio Parameters (CLI)	17-4

Displaying Communication Status with the Remote Radio (CLI).....	17-4
Displaying the Remote Radio’s Link ID and Location (CLI)	17-4
Muting and Unmuting the Remote Radio (CLI)	17-4
Displaying the Remote Radio’s RX Level (CLI)	17-5
Configuring the Remote Radio’s TX Level (CLI)	17-5
Configuring Remote ATPC (CLI)	17-5
Configuring ATPC and Override Timer (CLI)	17-7
Configuring Header De-Duplication (CLI)	17-10
Displaying Header De-Duplication Information (CLI)	17-11
Configuring Frame Cut-Through (CLI)	17-13
Configuring AES-256 Payload Encryption (CLI)	17-14
Configuring and Viewing Radio PMs and Statistics (CLI).....	17-18
Displaying General Modem Status and Defective Block PMs(CLI)	17-18
Displaying Excessive BER (Aggregate) PMs (CLI)	17-19
Displaying BER Level and Configuring the Excessive BER Thresholds (CLI)	17-21
Configuring RSL Thresholds (CLI)	17-22
Configuring TSL Thresholds (CLI)	17-23
Displaying RSL and TSL Levels (CLI).....	17-23
Configuring the Signal Level Threshold (CLI)	17-24
Configuring the MSE Thresholds and Displaying the MSE PMs (CLI).....	17-25
Displaying ACM PMs (CLI).....	17-27
Configuring the XPI Thresholds and Displaying the XPI PMs (CLI).....	17-28
Chapter 18: Ethernet Services and Interfaces (CLI).....	18-1
Configuring Ethernet Services (CLI).....	18-2
Ethernet Services Overview (CLI)	18-2
General Guidelines for Provisioning Ethernet Services (CLI)	18-2
Defining Services (CLI)	18-3
Configuring Service Points (CLI).....	18-10
Defining the MAC Address Forwarding Table for a Service (CLI).....	18-27
Setting the MRU Size and the S-VLAN Ethertype (CLI).....	18-32
Configuring the S-VLAN Ethertype (CLI)	18-32
Configuring the C-VLAN Ethertype (CLI)	18-33
Configuring the MRU (CLI).....	18-33
Configuring Ethernet Interfaces (CLI)	18-34
Entering Interface View (CLI)	18-34
Displaying the Operational State of the Interfaces in the Unit (CLI)	18-35
Viewing Interface Attributes (CLI)	18-36
Configuring an Interface’s Media Type (CLI)	18-36
Configuring an Interface’s Speed and Duplex State (CLI)	18-36
Configuring an Interface’s Auto Negotiation State (CLI)	18-37
Configuring an Interface’s IFG (CLI)	18-38
Configuring an Interface’s Preamble (CLI).....	18-38

Adding a Description for the Interface (CLI)	18-38
Configuring Automatic State Propagation and Link Loss Forwarding (CLI)	18-40
Configuring Automatic State Propagation to an Ethernet Port (CLI)	18-40
Viewing Ethernet PMs and Statistics (CLI)	18-43
Displaying RMON Statistics (CLI)	18-43
Configuring Ethernet Port PMs and PM Thresholds (CLI)	18-44
Displaying Ethernet Port PMs (CLI)	18-44
Clearing Ethernet Port PMs (CLI)	18-47
Chapter 19: Quality of Service (QoS) (CLI)	19-1
Configuring Classification (CLI)	19-2
Classification Overview (CLI)	19-2
Configuring Ingress Path Classification on a Logical Interface (CLI)	19-2
Configuring VLAN Classification and Override (CLI)	19-3
Configuring 802.1p Classification (CLI)	19-4
Configuring DSCP Classification (CLI)	19-8
Configuring MPLS Classification (CLI)	19-11
Configuring a Default CoS (CLI)	19-12
Configuring Ingress Path Classification on a Service Point (CLI)	19-13
Configuring Ingress Path Classification on a Service (CLI)	19-13
Configuring Policers (Rate Metering) (CLI)	19-14
Overview of Rate Metering (Policing) (CLI)	19-14
Configuring Rate Meter (Policer) Profiles (CLI)	19-14
Displaying Rate Meter Profiles (CLI)	19-16
Deleting a Rate Meter Profile (CLI)	19-16
Attaching a Rate Meter (Policer) to an Interface (CLI)	19-16
Configuring the Line Compensation Value for a Rate Meter (Policer) (CLI)	19-21
Displaying Rate Meter Statistics for an Interface (CLI)	19-22
Configuring Marking (CLI)	19-24
Marking Overview (CLI)	19-24
Configuring Marking Mode on a Service Point (CLI)	19-24
Marking Table for C-VLAN UP Bits (CLI)	19-25
Marking Table for S-VLAN UP Bits (CLI)	19-27
Configuring WRED (CLI)	19-29
WRED Overview (CLI)	19-29
Configuring WRED Profiles (CLI)	19-29
Assigning a WRED Profile to a Queue (CLI)	19-31
Configuring Shapers (CLI)	19-33
Overview of Egress Shaping (CLI)	19-33
Configuring Service Bundle Shapers (CLI)	19-36
Configuring Egress Line Compensation for Shaping (CLI)	19-39
Configuring Scheduling (CLI)	19-40
Overview of Egress Scheduling (CLI)	19-40

Configuring Queue Priority (CLI).....	19-40
Configuring Interface Priority Profiles (CLI).....	19-41
Attaching a Priority Profile to an Interface (CLI)	19-44
Configuring Weighted Fair Queuing (WFQ) (CLI)	19-44
Displaying Egress Statistics (CLI)	19-49
Displaying Queue-Level PMs (CLI)	19-49
Displaying Service Bundle-Level PMs (CLI)	19-50
Chapter 20: Ethernet Protocols (CLI).....	20-1
Configuring G.8032 (CLI)	20-2
Configuring the Destination MAC Address (CLI).....	20-2
Configuring ERPIs (CLI)	20-2
Configuring the RPL Owner (CLI)	20-4
Configuring Timers (CLI)	20-5
Initiating a Manual or Forced Switch and Clearing the Switch or Initiating Reversion (CLI)	20-6
Blocking or Unblocking R-APS Messages on a Service Point (CLI)	20-7
Displaying the ERPI Attributes (CLI).....	20-8
Configuring MSTP (CLI)	20-14
Configuring the MSTP Bridge Parameters (CLI).....	20-14
Configuring the MSTP Port Parameters (CLI)	20-22
Configuring LLDP (CLI).....	20-27
Configuring the General LLDP Parameters (CLI).....	20-28
Displaying the General LLDP Parameters (CLI)	20-29
Configuring LLDP Port Parameters (CLI)	20-30
Displaying the LLDP Local System Parameters (CLI).....	20-31
Displaying the LLDP Remote System Parameters (CLI)	20-34
Displaying LLDP Statistics (CLI)	20-37
Chapter 21: TDM Services and Interfaces (CLI).....	21-1
TDM Overview (CLI)	21-2
Configuring the Unit to Operate in ANSI Mode (CLI)	21-3
Configuring TDM Cards and Interfaces (CLI)	21-4
Configuring the E1/DS1 Interface (CLI).....	21-4
Configuring the E1/DS1 Parameters (CLI)	21-4
Configuring Native TDM Trails (CLI)	21-8
Configuring TDM Pseudowire Services (CLI)	21-9
Configuring Pseudowire Tunnels (CLI).....	21-9
Configuring Pseudowire Profiles (CLI)	21-12
Configuring Ethernet Services for TDM Traffic (CLI).....	21-13
Configuring Pseudowire Path Protection and Dual Homing (CLI)	21-14
Manually Configuring Pseudowire Services (CLI)	21-22
Displaying TDM PMs (CLI)	21-26
Chapter 22: Synchronization (CLI).....	22-1
Configuring the Sync Source (CLI)	22-2

Configuring an Ethernet Interface as a Synchronization Source (CLI)	22-2
Configuring a Radio Interface as a Synchronization Source (CLI)	22-4
Clearing All Sync Sources (CLI)	22-6
Configuring the Outgoing Clock (CLI)	22-7
Configuring SSM Messages (CLI)	22-9
Configuring the Revertive Timer (CLI)	22-10
Displaying Synchronization Status and Parameters (CLI)	22-11
Configuring 1588 Transparent Clock (CLI)	22-13
Configuring 1588 Boundary Clock (CLI)	22-16
Enabling Boundary Clock (CLI)	22-16
Displaying and Setting the Boundary Clock Default Parameters (CLI)	22-19
Displaying the Boundary Clock Advanced Parameters (CLI)	22-21
Displaying the Boundary Clock Port Parameters (CLI)	22-23
Displaying the Boundary Clock Port Statistics (CLI)	22-24
Disabling Boundary Clock (CLI)	22-26
Chapter 23: Access Management and Security (CLI)	23-1
Configuring the General Access Control Parameters (CLI)	23-2
Configuring the Inactivity Timeout Period (CLI)	23-2
Configuring Blocking Upon Login Failure (CLI)	23-2
Configuring Blocking of Unused Accounts (CLI)	23-3
Configuring the Password Security Parameters (CLI)	23-5
Configuring Password Aging (CLI)	23-5
Configuring Password Strength Enforcement (CLI)	23-5
Forcing Password Change Upon First Login (CLI)	23-6
Displaying the System Password Settings (CLI)	23-6
Configuring Users (CLI)	23-7
User Configuration Overview (CLI)	23-7
Configuring User Profiles (CLI)	23-8
Configuring User Accounts (CLI)	23-9
Configuring RADIUS (CLI)	23-11
RADIUS Overview (CLI)	23-11
Activating RADIUS Authentication (CLI)	23-11
Configuring the RADIUS Server Attributes (CLI)	23-11
Viewing RADIUS Access Control and Server Attributes (CLI)	23-12
Viewing RADIUS User Permissions and Connectivity (CLI)	23-12
Configuring X.509 CSR Certificates and HTTPS (CLI)	23-14
Generating a Certificate Signing Request (CSR) File (CLI)	23-14
Downloading a Certificate (CLI)	23-16
Enabling HTTPS (CLI)	23-18
Uploading the Security Log (CLI)	23-19
Uploading the Configuration Log (CLI)	23-22
Chapter 24: Alarm Management and Troubleshooting (CLI)	24-1

Viewing Current Alarms (CLI)	24-2
Viewing the Event Log (CLI)	24-3
Editing Alarm Text and Severity (CLI)	24-4
Displaying Alarm Information (CLI)	24-4
Editing an Alarm Type (CLI)	24-4
Setting Alarms to their Default Values (CLI)	24-5
Configuring a Timeout for Trap Generation (CLI)	24-6
Uploading Unit Info (CLI).....	Error! Bookmark not defined.
Performing Diagnostics (CLI).....	24-11
Performing Radio Loopback (CLI)	24-12
Performing Ethernet Loopback (CLI)	24-13
Performing TDM Diagnostics (CLI).....	24-14
Configuring Service OAM (SOAM) Fault Management (FM) (CLI)	24-15
Working in CW Mode (Single or Dual Tone) (CLI)	24-30
Chapter 25: Fault Finding.....	25-1
Temperature Ranges.....	25-2
Troubleshooting Tips	25-3
Chapter 26: Replacing an IDU or SM card	26-1
Replacing an IDU or SM-Card on an PTP 820F IDU.....	26-1
Replacing an IDU or SM-Card on an PTP 820G IDU	26-3
Chapter 27: Pin-Outs and LEDs – PTP 820G	27-1
Ethernet Pin-Outs and LEDs – PTP 820G.....	27-2
Ethernet Traffic Interface Pin-Outs	27-2
Ethernet Traffic Interface LEDs	27-2
Ethernet Management Interface Pin-Outs.....	27-4
Ethernet Management Interface LEDs	27-4
E1/DS1 Pin-Outs and LEDs – PTP 820G	27-6
E1/DS1 Interface Pin-Outs.....	27-6
E1/DS1 Interface LEDs	27-8
Radio Interface LEDs – PTP 820G	27-9
Synchronization Interface Pin-Outs and LEDs – PTP 820G	27-10
Synchronization Interface Pin-Outs.....	27-10
Synchronization Interface LEDs.....	27-10
Power Interface LEDs – PTP 820G.....	27-12
Terminal Interface Pin-Outs – PTP 820G	27-13
External Alarms – PTP 820G.....	27-14
External Alarm Pin-Outs	27-14
Unit/ACT LED PTP 820G	27-15
Chapter 28: Pin-Outs and LEDs – PTP 820F.....	28-16
Ethernet LEDs and Pin-Outs – PTP 820F	28-17
Ethernet Traffic Interface Pin-Outs	28-17
Ethernet Traffic Interface LEDs	28-17

- Management Interface Pin-Outs 28-19
- Management Interface LEDs 28-19
- E1/DS1 Interface LEDs and Pin-Outs – PTP 820F 28-20
 - E1/DS1 Interface Pin-Outs..... 28-20
 - E1/DS1 Interface LEDs 28-22
- Radio Interface LEDs and Pin-Outs – PTP 820F 28-24
 - Radio RJ-45 Interface Pin-Outs..... 28-24
 - Radio Interface LEDs..... 28-24
- Power Interface LEDs – PTP 820-F 28-26
- Synchronization Interface LEDs and Pin-Outs – PTP 820F 28-27
 - Synchronization Interface Pin-Outs..... 28-27
 - Synchronization Interface LEDs 28-27
- Terminal Interface Pin-Outs – PTP 820F 28-29
- External Alarm Pin-Outs – PTP 820F 28-30
- Unit/ACT LED – PTP 820F 28-31
- Chapter 29: Alarms List..... 29-1**
- Glossary I**

List of Figures

Figure 1 PTP 820F Front Panel and Interface.....	1-7
Figure 2 GbE Combo Interface Numbering.....	1-8
Figure 3 RFU3/ SFP5-6 Interfaces	1-8
Figure 4 Management Interface Pin Connections	1-9
Figure 5 SM Card and Cover	1-11
Figure 6 PTP 820G Front Panel and Interfaces	1-13
Figure 7 Management Interface Pin Connections	1-14
Figure 8 Main Web EMS Page.....	1-21
Figure 9 Displaying a Representation of the Front Panel	1-21
Figure 10 Main Web EMS Page with Representation of the Front Panel- PTP 820F	1-22
Figure 11 Main Web EMS Page with Representation of the Front Panel- PTP 820G	1-22
Figure 12 Related Pages Drop-Down List.....	1-23
Figure 13 Unit Summary Page	1-24
Figure 14 Unit Summary Page – Customizing columns.....	1-25
Figure 15 Radio Summary Page	1-25
Figure 16 Unit & Radio Summary Page – Customizing Columns	1-26
Figure 17 Terminal Interface on Front Panel – PTP 820F	2-3
Figure 18 Terminal Interface on Front Panel – PTP 820G.....	2-3
Figure 19 Management Interface on Front Panel PTP 820F	2-4
Figure 20 Management Interface on Front Panel PTP 820G	2-4
Figure 21 Login Page.....	2-6
Figure 22 Change User Password Page.....	2-7
Figure 23 Quick Configuration – Platform Setup Page	2-9
Figure 24 Quick Configuration – Platform Setup Summary Page	2-11
Figure 25 Local Networking Configuration Page.....	2-13
Figure 26 PTP 820G with Unit Redundancy – Protection and Management Splitter Connection	2-19
Figure 27 Logical Interfaces – Edit Page	2-20
Figure 28 Unit Redundancy Page.....	2-21
Figure 29 Standby Tab of Unit Redundancy Page.....	2-23
Figure 30 Activation Key Configuration Page	2-28
Figure 31 Activation Key Overview Page	2-29
Figure 32 Time Services Page.....	2-31
Figure 33 Interface Manager Page PTP 820F.....	2-33
Figure 34 Interface Manager Page – PTP 820G	2-34
Figure 35 Interface Manager – Edit Page.....	2-34
Figure 36 Multiple Selection Operation Section (Interface Manager Page)	2-35
Figure 37 Cascading Interfaces Page	2-38
Figure 38 Cascading Port Configuration Table – Edit Page	2-38
Figure 39 Radio Parameters Page.....	2-40
Figure 40 Radio Parameters Configuration Page.....	2-41
Figure 41 MRMC Symmetrical Scripts Page (ETSI) – PTP 820F	2-46

Figure 42 MRMC Symmetrical Scripts Page (ETSI) – PTP 820G..... 2-47

Figure 43 MRMC Symmetrical Scripts Page (ANSI) 2-47

Figure 44 MRMC Symmetrical Scripts Page (Configuration) – PTP 820F..... 2-48

Figure 45 MRMC Symmetrical Scripts Page (Configuration) - PTP 820G 2-48

Figure 46 MRMC Symmetrical Scripts Page (Configuration – Adaptive Mode) – PTP 820F 2-49

Figure 47 MRMC Symmetrical Scripts Page (Configuration – Adaptive Mode) PTP 820G..... 2-50

Figure 48 Security General Configuration Page 2-56

Figure 49 1+0 Quick Configuration Wizard (PTP 820G) – Page 1..... 3-6

Figure 50 1+0 Quick Configuration Wizard (PTP 820F) – Page 1 3-6

Figure 51 1+0 Quick Configuration Wizard (PTP 820G) – Page 2..... 3-7

Figure 52 1+0 Quick Configuration Wizard (PTP 820F) – Page 2 3-7

Figure 53 1+0 Quick Configuration Wizard (PTP 820G) – Page 3..... 3-8

Figure 54 1+0 Quick Configuration Wizard (PTP 820F) – Page 3 3-8

Figure 55 1+0 Quick Configuration Wizard (PTP 820G) – Page 4..... 3-9

Figure 56 1+0 Quick Configuration Wizard (PTP 820F) – Page 4 3-9

Figure 57 1+0 Quick Configuration Wizard – Page 5 (Summary Page)..... 3-9

Figure 58 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 1 3-10

Figure 59 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 2 3-10

Figure 60 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 3 3-11

Figure 61 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 4..... 3-12

Figure 62 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 5..... 3-13

Figure 63 1+0 Repeater Quick Configuration Wizard – Page 6 (Summary Page) 3-13

Figure 64 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 1 3-14

Figure 65 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 2 3-15

Figure 66 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 3 3-15

Figure 67 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 4 3-16

Figure 68 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 5 3-17

Figure 69 1+1 HSB Quick Configuration Wizard – Page 6 (Summary Page)..... 3-17

Figure 70 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 1..... 3-18

Figure 71 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 2..... 3-19

Figure 72 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 3..... 3-19

Figure 73 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 4..... 3-20

Figure 74 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 5..... 3-21

Figure 75 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 6 (summary page) 3-21

Figure 76 N + 0 Multi Carrier ABC Quick Configuration Wizard (PTP 820G) – Page 1 3-22

Figure 77 N + 0 Multi Carrier ABC Quick Configuration Wizard (PTP 820F) – Page 1 3-22

Figure 78 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio #2 Selection Page – PTP 820G 3-23

Figure 79 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio #2 Selection Page – PTP 820F 3-24

Figure 80 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio XPIC Configuration Page – PTP 820G..... 3-24

Figure 81 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio XPIC Configuration Page – PTP 820F 3-25

Figure 82 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio Parameters Configuration Page – PTP 820G 3-25

Figure 83 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio Parameters Configuration Page – PTP 820F-26

Figure 84 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio Parameters Configuration Page (XPIC) – PTP 820G 3-26

Figure 85 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio Parameters Configuration Page (XPIC) – PTP 820F 3-26

Figure 86 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio MPMC Script Configuration Page – PTP 820G 3-27

Figure 87 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio MPMC Script Configuration Page – PTP 820F 3-27

Figure 88 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio MPMC Script Configuration Page (XPIC) – PTP 820G 3-28

Figure 89 N + 0 Multi Carrier ABC Quick Configuration Wizard – Management Configuration Page – PTP 820G . 3-28

Figure 90 N + 0 Multi Carrier ABC Quick Configuration Wizard – Management Configuration Page – PTP 820F.. 3-29

Figure 91 N + 0 Multi Carrier ABC Quick Configuration Wizard – Summary Page – PTP 820G..... 3-29

Figure 92 N + 0 Multi Carrier ABC Quick Configuration Wizard – Summary Page – PTP 820F 3-30

Figure 93 Multi-Carrier ABC Group Page (Empty) 3-33

Figure 94 Create ABC Group Wizard – First Page 3-33

Figure 95 Create ABC Group Wizard – Second Page..... 3-34

Figure 96 Create ABC Group Wizard – Finish Page 3-34

Figure 97 Multi Carrier ABC Group - Add/Remove Members Page 3-35

Figure 98 LAG Page (Empty) 3-37

Figure 99 Create LAG Group Page 3-38

Figure 100 Create LAG Group – Finish Page 3-38

Figure 101 LAG Page (Populated) 3-40

Figure 102 Link Aggregation - Edit Page 3-40

Figure 103 LAG Distribution Function (DF) Page 3-42

Figure 104 LACP Aggregation Page 3-44

Figure 105 LACP Port Status Page..... 3-45

Figure 106 LACP Port Status – View Page 3-46

Figure 107 LACP Port Statistics Page..... 3-48

Figure 108 LACP Port Debug Page 3-49

Figure 109 XPIC Configuration Page (Empty)..... 3-51

Figure 110 Create XPIC Group Page..... 3-51

Figure 111 Create XPIC Group Finish Page 3-52

Figure 112 XPIC Page (Populated) 3-52

Figure 113 XPIC Edit Page 3-53

Figure 114 Radio Protection Page (Empty) 3-56

Figure 115 Create Radio Protection Group Page 3-56

Figure 116 Create Radio Protection Group Page – Member 1 3-57

Figure 117 Create Radio Protection Group Finish Page..... 3-57

Figure 118 Multi Carrier ABC Group – Edit Page – Enabling Protection 3-58

Figure 119 Create Radio Protection Group Page (Space Diversity Group Selected) 3-59

Figure 120 Create Radio Protection Group Page – Member 1 (Space Diversity Group Selected) 3-59

Figure 121 Create Radio Protection Group Finish Page (Space Diversity Group Selected) 3-59

Figure 122 Radio Protection Page (Populated)..... 3-61

Figure 123 Radio Protection Groups – Edit Page 3-61

Figure 124 Radio Protection Groups – Edit Page (Copy to Mate)..... 3-62

Figure 125 IF Combining Page 3-65

Figure 126 IF Combining – Edit Page 3-66

Figure 127 Remote Networking Configuration Page 4-3

Figure 128 Remote Networking Configuration – Edit Page 4-4

Figure 129 SNMP Parameters Page 4-6

Figure 130 V3 Users Page 4-7

Figure 131 V3 Users - Add Page..... 4-8

Figure 132 Trap Managers Page 4-9

Figure 133 Trap Managers - Edit Page 4-10

Figure 134 FTP Port Page 4-11

Figure 135 FileZilla Server User Configuration..... 4-13

Figure 136 FileZilla Server Shared Folder Setup 4-14

Figure 137 Versions Page..... 4-15

Figure 138 Download & Install Page – HTTP/ HTTPS Download – No File Selected. 4-17

Figure 139 Download & Install Page – HTTP/HTTPS Download –File Selected 4-18

Figure 140 Download & Install Page..... 4-20

Figure 141 FTP Parameters Page 4-20

Figure 142 Install Parameters Page 4-21

Figure 143 Install Parameters page 4-24

Figure 144 Timer Parameters - Software Installation Page 4-24

Figure 145 Backup Files Page..... 4-27

Figure 146 Configuration Management Page 4-28

Figure 147 FTP Parameters Page (Configuration Management) 4-29

Figure 148 Set to Factory Default Page 4-33

Figure 149 Reset Page..... 4-34

Figure 150 Unit Parameters Page 4-35

Figure 151 NTP Configuration Page 4-37

Figure 152 Inventory Page 4-39

Figure 153 Radio Parameters Page..... 5-2

Figure 154 Radio Parameters Page Per Carrier 5-2

Figure 155 RFU1 Radio Interfaces on PTP 820F 5-5

Figure 156 Radio Unit Page (PTP 820F) 5-6

Figure 157 Remote Radio Parameters Page 5-8

Figure 158 Remote Radio Parameters – Edit Page 5-8

Figure 159: Remote Radio Parameters Page Per Carrier – PTP 820G..... 5-9

Figure 160 ATPC Page 5-12

Figure 161 ATPC – Edit Page 5-13

Figure 162 Radio Ethernet Interface Configuration Page 5-15

Figure 163 Radio Ethernet Interface Configuration – Edit Page 5-16

Figure 164 Radio Ethernet Interface Configuration Page 5-17

Figure 165 Radio Ethernet Interface Configuration – Edit Page 5-18

Figure 166 Radio Ethernet Interface Counters Page 5-19

Figure 167 Radio Ethernet Interface Counters – View Page..... 5-20

Figure 168 Payload Encryption Page 5-23

Figure 169 Payload Encryption – Edit Page 5-23

Figure 170 Payload Encryption – Edit Page with Master Key Displayed..... 5-24

Figure 171 Radio BER Thresholds Page..... 5-27

Figure 172 Radio BER Thresholds – Edit Page..... 5-27

Figure 173 MRMC Status Page..... 5-28

Figure 174 MRMC PM Report Page 5-29

Figure 175 Counters Page 5-31

Figure 176 Signal Level PM Report Page..... 5-32

Figure 177 Signal level Thresholds Configuration – Edit Page 5-33

Figure 178 Combined PM Graph Page..... 5-35

Figure 179 Aggregate PM Report Page..... 5-37

Figure 180 MSE PM Report Page 5-39

Figure 181 Modem MSE Thresholds Configuration – Edit Page 5-40

Figure 182 XPI PM Report Page 5-40

Figure 183 XPI Thresholds Configuration – Edit Page..... 5-42

Figure 184 Capacity PM Report Page..... 5-43

Figure 185: Ethernet Radio Capacity and Throughput Threshold Page..... 5-43

Figure 186 Utilization PM Report Page..... 5-44

Figure 187 Ethernet Radio Utilization Threshold Page 5-45

Figure 188 Frame Error PM Report Page 5-46

Figure 189 Ethernet Services Page 6-3

Figure 190 Ethernet Services - Add page 6-5

Figure 191 Multiple Selection Operation Section (Ethernet Services) 6-7

Figure 192 Ethernet Service Points Page 6-8

Figure 193 Ethernet Service Points Page – Ingress Attributes..... 6-12

Figure 194 Ethernet Service Points Page – Egress Attributes 6-14

Figure 195 Ethernet Service Points - Add Page..... 6-17

Figure 196 Attached VLAN List Page..... 6-19

Figure 197 Attached VLAN List - Add Page 6-20

Figure 198 Ethernet General Configuration Page..... 6-22

Figure 199 Physical Interfaces Page..... 6-24

Figure 200 Physical Interfaces - Edit Page 6-25

Figure 201: Automatic State Propagation Page..... 6-28

Figure 202: Automatic State Propagation - Add Page 6-28

Figure 203 RMON Page..... 6-30

Figure 204 RMON Page – Hiding and Displaying Columns 6-31

Figure 205: Egress CoS Statistics Page 6-32

Figure 206: Egress CoS Statistics – Edit Page 6-32

Figure 207 Ethernet Port TX PM Report Page 6-34

Figure 208 Ethernet PM Port Admin Page 6-36

Figure 209: Ethernet Port Tx Threshold Page 6-36

Figure 210 Ethernet Port RX PM Report Page 6-37

Figure 211 Ethernet PM Port Admin Page 6-39

Figure 212 Ethernet Port Rx Threshold Page 6-39

Figure 213 QoS Block Diagram..... 7-2

Figure 214 Logical Interfaces Page 7-5

Figure 215 Logical Interfaces - Edit Page 7-6

Figure 216 802.1Q Classification Page 7-8

Figure 217 802.1Q Classification - Edit Page..... 7-8

Figure 218 802.1AD Classification Page..... 7-9

Figure 219 802.1Q Classification - Edit Page..... 7-9

Figure 220 DSCP Classification Page 7-10

Figure 221 DSCP Classification - Edit Page..... 7-11

Figure 222 MPLS Classification Page..... 7-12

Figure 223 MPLS Classification - Edit Page 7-13

Figure 224 Policer Profile Page 7-15

Figure 225 Policer Profile - Add Page..... 7-15

Figure 226 Logical Interfaces – Policers Page – Unicast Policer (Default) 7-17

Figure 227 Logical Interfaces – Policers Page – Multicast Policer 7-18

Figure 228 Logical Interfaces – Policers Page – Broadcast Policer 7-19

Figure 229 Logical Interfaces – Policers Page – Ethertype Policer..... 7-19

Figure 230 802.1Q Marking Page..... 7-22

Figure 231 802.1Q Marking - Edit Page 7-22

Figure 232 802.1AD Marking Page 7-23

Figure 233 802.1AD Marking - Edit Page 7-23

Figure 234 WRED Profile Page 7-24

Figure 235 WRED Profile - Add Page..... 7-25

Figure 236 Logical Interfaces – WRED Page..... 7-27

Figure 237 Logical Interfaces – WRED - Edit Page 7-27

Figure 238 Queue Shaper Profile Page 7-29

Figure 239 Queue Shaper Profile – Add Page..... 7-29

Figure 240 Service Bundle Shaper Profile Page 7-31

Figure 241 Service Bundle Shaper Profile – Add Page 7-31

Figure 242 Logical Interfaces – Shaper – Egress Queue Shaper 7-32

Figure 243 Logical Interfaces – Egress Queue Shaper Configuration – Add Page 7-33

Figure 244 Logical Interfaces – Shaper – Egress Service Bundle Shaper 7-35

Figure 245 Logical Interfaces – Egress Service Bundle Shaper Configuration – Add Page 7-36

Figure 246 Scheduler Priority Profile Page 7-38

Figure 247 Scheduler Priority Profile – Add Page 7-39

Figure 248 Scheduler WFQ Profile Page 7-41

Figure 249 Scheduler WFQ Profile – Add Page 7-42

Figure 250 Logical Interfaces – Scheduler – Egress Port Scheduling Priority 7-43

Figure 251 Logical Interfaces – Scheduler – Egress Port Scheduling WFQ 7-43

Figure 252 G.8032 General Attribute Page..... 8-3

Figure 253 G.8032 ERPI Attribute Page 8-4

Figure 254 G.8032 ERPI Attribute Wizard – Page 1 8-4

Figure 255 G.8032 ERPI Attribute Wizard – Page 2 8-5

Figure 256 G.8032 ERPI Attribute Wizard – Page 3 8-6

Figure 257 G.8032 ERPI Attribute Wizard – Page 4 8-6

Figure 258 G.8032 ERPI Attribute Wizard – Submit..... 8-7

Figure 259 G.8032 ERPI Attribute – Edit Page 8-8

Figure 260 G.8032 ERPI Attribute – State Page 8-10

Figure 261 G.8032 ERPI Attribute – Statistics Page 8-12

Figure 262 Instance Per Service Mapping – Edit Page 8-16

Figure 263 MSTP Bridge General Attributes Page 8-17

Figure 264 MSTP Bridge Configuration ID Page..... 8-19

Figure 265 MSTP Bridge Spanning Tree Page 8-20

Figure 266 MSTP Bridge CIST Page 8-23

Figure 267 MSTP Bridge MSTI Page 8-24

Figure 268 MSTP Bridge MSTI – Edit Page 8-25

Figure 269 MSTP Bridge VLAN Page 8-26

Figure 270 MSTP Port Spanning Tree Page..... 8-27

Figure 271 MSTP Port Spanning Tree – Edit Page..... 8-28

Figure 272 MSTP Port CIST Page..... 8-29

Figure 273 MSTP Port CIST – Edit Page..... 8-29

Figure 274 MSTP Port MSTI Page 8-31

Figure 275 MSTP Port MSTI – Edit Page 8-32

Figure 276 MSTP Port BDPU Counters Page 8-35

Figure 277 LLDP Remote System Management Page 8-37

Figure 278 LLDP Configuration Parameters Page 8-37

Figure 279 LLDP Port Configuration Page 8-40

Figure 280 LLDP Port Configuration - Edit Page..... 8-40

Figure 281 LLDP Destination Address Table Page..... 8-42

Figure 282 LLDP Management TLV Configuration Page 8-43

Figure 283 LLDP Remote System Management Page 8-44

Figure 284 LLDP Remote System Table Page 8-45

Figure 285 LLDP Local System Parameters Page 8-46

Figure 286 LLDP Local System Port Page 8-48

Figure287 LLDP Local System Management Page 8-49

Figure 288 LLDP Local System Management – View Page..... 8-49

Figure 289 LLDP Statistic Page 8-50

Figure 290 LLDP Port TX Statistic Page 8-51

Figure 291 LLDP Port RX Statistic Page 8-52

Figure 292 E1/DS1 Interfaces Page..... 9-3

Figure 293 E1/DS1 Interfaces – Edit Page..... 9-4

Figure 294 Native TDM Services Page 9-8

Figure 295 TDM Service Revertive Timer Configuration Page 9-10

Figure 296 Native TDM Service Creation – Interface #1 E1/DS1 9-11

Figure 297 Native TDM Service Creation – Interface #1 Radio..... 9-12

Figure 298 Native TDM Service Creation – Trail Selection Page (Radio-TDM) 9-13

Figure 299 Native TDM Service Creation – Protecting Interface Selection Page..... 9-14

Figure 300 Native TDM Service Creation – Working Trail Selection Page 9-14

Figure 301 Native TDM Service Creation – Selection Summary Page (Radio-TDM) 9-15

Figure 302 Native TDM Service Creation – Interface #1 (Radio/Cascading)..... 9-17

Figure 303 Native TDM Service Creation – Interface #2 (Radio/Cascading)..... 9-17

Figure 304 Native TDM Service Creation – Trail Selection Page (Radio/Cascading)..... 9-18

Figure 305 Native TDM Service Creation – Selection Summary (Radio/Cascading) 9-19

Figure 306 Native TDM Services – Edit Page 9-20

Figure 307 Native TDM Services Edit Page – Multiple Selection Operation 9-21

Figure 308 TDM PseudoWire Services Page 9-23

Figure 309 TDM Service Revertive Timer Configuration Page 9-26

Figure 310: Pseudowire Service Creation – Interface #1 E1/DS1 9-27

Figure 311 Pseudowire Service Creation – Interface #1 Radio/Ethernet/Cascading..... 9-28

Figure 312 Pseudowire Service Creation – EC ID Selection Page (Radio/Ethernet/Cascading - TDM) 9-30

Figure 313 Pseudowire Service Creation – Protecting Interface Selection Page 9-32

Figure 314 Pseudowire Service Creation – Working EC ID Selection Page 9-32

Figure 315 Pseudowire Service Creation – Selection Summary Page (Radio/Ethernet/Cascading - TDM) 9-33

Figure 316 Pseudowire Service Creation – Interface #1 (Radio/Ethernet/Cascading) 9-34

Figure 317 Pseudowire Service Creation – Interface #2 (Radio/Cascading) 9-35

Figure 318 Pseudowire Service Creation – Service Selection Page (Radio/Ethernet/Cascading)..... 9-35

Figure 319 Pseudowire Service Creation – Selection Summary (Radio/Ethernet/Cascading)..... 9-36

Figure 320 TDM PseudoWire Services – Edit Page 9-37

Figure 321 Pseudowire Services Edit Page – Multiple Selection Operation 9-38

Figure 322 PseudoWire Card Configuration Page 9-39

Figure 323 PseudoWire Card Configuration – Edit Page 9-39

Figure 324 Service OAM Maintenance Domain Page 9-41

Figure 325 Service OAM Maintenance Domain – Add Page..... 9-42

Figure 326 Service OAM Maintenance Association Page 9-44

Figure 327 Service OAM Maintenance Association – Add Page 9-46

Figure 328 Pseudowire PSN Tunnels Page..... 9-48

Figure 329 PseudoWire PSN Tunnels– Add Page..... 9-49

Figure 330 PseudoWire PSN Tunnels– Status Page 9-51

Figure 331 Pseudowire Tunnel Groups Page 9-52

Figure 332 PseudoWire Tunnel Groups – Add Page 9-54

Figure 333 PseudoWire Profiles Page 9-56

Figure 334 PseudoWire Profiles – Add Page..... 9-58

Figure 335 PseudoWire Services Page 9-60

Figure 336 PseudoWire Services – Add Page..... 9-63

Figure 337 PseudoWire Services – Information Page 9-64

Figure 338 E1/DS1 PM Page 9-66

Figure 339 E1/DS1 PM Page – Graph Format 9-67

Figure 340 Services PM Page (Native TDM Services)..... 9-68

Figure 341 Native TDM Services Page – Graph Format 9-69

Figure 342 Services PM Page (Pseudowire TDM Services) 9-69

Figure 343 Pseudowire TDM Services Page – Graph Format..... 9-70

1. Select Sync > Sync Source. The Sync Source page opens. Figure 344 Sync Source Page 10-2

Figure 345 Sync Source – Add Page 10-4

Figure 346 Outgoing Clock Page 10-7

Figure 347 Outgoing Clock – Edit Page 10-7

Figure 348 1588-TC Page 10-10

Figure 349 1588-TC – Edit Page 10-10

Figure 350 1588 Boundary Clock – Port Parameters Page 10-13

Figure 351 1588 Boundary Clock – Port Parameters – Edit Page 10-14

Figure 352 1588 Boundary Clock – Clock Default Parameters Page 10-15

Figure 353 1588 Boundary Clock – Clock Advanced Parameters Page..... 10-17

Figure 354 1588 Boundary Clock – Port Statistics Page..... 10-19

Figure 355 Access Control General Configuration Page 11-2

Figure 356 Access Control User Accounts - Edit Page..... 11-3

Figure 357 Access Control Password Management Page 11-4

Figure 358 Protocols Control Page 11-5

Figure 359 Access Control User Profiles Page 11-7

Figure 360 Access Control User Profiles - Add Page 11-8

Figure 361 Access Control User Accounts Page 11-9

Figure 362 Access Control User Accounts - Add Page 11-10

Figure 363 Radius Configuration Page 11-13

Figure 364 Radius Configuration – Edit Page..... 11-14

Figure 365 Radius Users Page 11-14

Figure 366 Radius Users Page – Expanded 11-16

Figure 367 Server Manager – Creating User Groups 11-17

Figure 368 Server Manager – Creating Users 11-18

Figure 369 Server Manager – Creating a RADIUS Client 11-19

Figure 370 Create Network Policy – Specify Name and Connection Type 11-20

Figure 371 Create Network Policy – Select Condition 11-21

Figure 372 Create Network Policy – User Group added to Policy’s Conditions..... 11-22

Figure 373 Create Network Policy – Specifying Access Permission 11-23

Figure 374 Create Network Policy – Configuring Authentication Methods 11-24

Figure 375 Create Network Policy – Insecure Authentication Method Query 11-24

Figure 376 Create Network Policy – Configuring Constraints..... 11-25

Figure 377 Create Network Policy – Configuring Settings 11-26

Figure 378 Create Network Policy – Adding Vendor Specific Attributes 11-27

Figure 379 Create Network Policy – Selecting to Add Attribute Information 11-27

Figure 380 Create Network Policy – Specifying the Vendor 11-28

Figure 381 Create Network Policy – Configuring Vendor-Specific Attribute Information..... 11-29

Figure 382 Create Network Policy – Example of Vendor-Specific Attribute Configuration..... 11-30

Figure 383 Create Network Policy – Stopping/Starting NPS Services..... 11-31

Figure 384 Security Certificate Request Page..... 11-36

Figure 385 FTP Parameters Page (Security Certificate Request) 11-37

Figure 386 Security Certification Download and Install Page..... 11-38

Figure 387 FTP Parameters Page (Security Certificate Download & Install)..... 11-38

Figure 388 Protocols Control Page 11-40

Figure 389 Security Log Upload Page 11-42

Figure 390 FTP Parameters Page (Security Upload Page)..... 11-42

Figure 391 Configuration Log Upload Page 11-45

Figure 392 FTP Parameters Page (Configuration Log Upload)..... 11-45

Figure 393 Current Alarms Page..... 12-2

Figure 394 Current Alarms - View Page 12-2

Figure 395 Alarm Statistics Page..... 12-4

Figure 396 Event Log..... 12-5

Figure 397 Alarm Configuration Page..... 12-7

Figure 398 Alarm Configuration Page – Expanded 12-8

Figure 399 Alarm Configuration - Edit Page..... 12-9

Figure 400 External Alarms Input Page..... 12-11

Figure 401 External Alarms Input – Edit Page..... 12-11

Figure 402 External Alarms Output Page..... 12-14

Figure 403 Unit Info Page 12-16

Figure 404 Radio Loopbacks Page – PTP 820F 12-18

Figure 405 Radio Loopbacks Page – PTP 820G 12-19

Figure 406 Radio Loopbacks – Edit Page 12-19

Figure 407 Logical Interfaces – Loopback Page 12-21

Figure 408 PDH Loopback Page 12-22

Figure 409 PDH Loopback – Edit Page 12-23

Figure 410 SOAM MD Page..... 12-25

Figure 411 SOAM MD Page..... 12-26

Figure 412 SOAM MA/MEG Page 12-27

Figure 413 SOAM MA/MEG – Add Page 12-27

Figure 414 MEP List Page 12-31

Figure 415 Add MEP Page 12-31

Figure 416 SOAM MEP Page 12-32

Figure 417 Add SOAM MEP Wizard – Page 1 12-32

Figure 418 Add SOAM MEP Wizard – Page 2 12-33

Figure 419 Add SOAM MEP Wizard –Summary Page 12-33

Figure 420 SOAM MEP - Edit Page 12-36

Figure 421 SOAM MEP DB Table 12-37

Figure 422 MEP Last Invalid CCMS Page 12-38

Figure 423 SOAM MEP Loopback Page 12-40

Figure 424 Restart HTTP Page 13-2

Figure 425 ifIndex Calculator Page 13-3

Figure 426 MIB Reference Table Page 13-4

Figure 427 1588 Boundary Clock – Current Configuration Sample Display (CLI) 22-19

Figure 428 1588 Boundary Clock – Default Parameters Sample Display (CLI) 22-20

Figure 429 1588 Boundary Clock – Advanced (General) Parameters Sample Display (CLI) 22-21

Figure 430 1588 Boundary Clock – Parent Clock Parameters Sample Display (CLI) 22-22

Figure 431 1588 Boundary Clock – Time Parameters Sample Display (CLI) 22-22

Figure 432 1588 Boundary Clock Port Parameters (CLI) 22-24

Figure 433 1588 Boundary Clock Statistics (CLI) 22-25

Figure 434 Removing the SM-Card Cover of a PTP 820F 26-1

Figure 435 Checking the Sockets for Foreign Matter 26-2

Figure 436 Removing the PTP 820G SM-Card Cover 26-3

Figure 437 Checking the Sockets for Foreign Matter 26-4

Figure 438 Electrical GE Interface LEDs 27-3

Figure 439 Optical GE Interface LED 27-3

Figure 440 Management FE Interface LEDs 27-5

Figure 441 TDM Interface LEDs 27-8

Figure 442 Radio Interface LEDs 27-9

Figure 443 Power Interface LEDs 27-12

Green – Power is on.Figure 444 Unit/ACT LED 27-15

Figure 445 Electrical Ethernet Interface LEDs 28-18

Figure 446 Optical Ethernet Interface LEDs – SFP1 through SFP4 28-18

Figure 447 Management FE Interface LEDs 28-19

Figure 448 E1/DS1 Interface LEDs 28-23

Figure 449 Optical Interface LEDs 28-24

Figure 450 Electrical Interface LEDs 28-25

Figure 451 Power Interface LEDs 28-26

Figure 452 Sync Interface LEDs 28-28

Figure 453 Unit/ACT LED 28-31

List of Tables

Table 1	PTP 820F Interfaces.....	1-7
Table 2	2 x FE Splitter Cable Model Number	1-9
Table 3	PTP 820 Interfaces	1-13
Table 4	2 x FE Splitter Cable Model Number	1-14
Table 5	IDU-RFU Cable connection for PTP 820F.....	1-18
Table 6	Web EMS Menu Hierarchy – Platform Menu.....	1-27
Table 7	Web EMS Menu Hierarchy – Faults Menu	1-30
Table 8	Web EMS Menu Hierarchy – TDM Menu	1-30
Table 9	Web EMS Menu Hierarchy – Radio Menu.....	1-31
Table 10	PTP 820G Web EMS Menu Hierarchy – Ethernet Menu	1-32
Table 11	PTP 820G Web EMS Menu Hierarchy – Cascading Menu	1-35
Table 12	PTP 820G Web EMS Menu Hierarchy – Sync Menu	1-35
Table 13	Web EMS Menu Hierarchy – Quick Configuration Menu.....	1-35
Table 14	Web EMS Menu Hierarchy – Utilities Menu	1-36
Table 15	Y-Cable for Electrical Splitter Mode FE Traffic Interface Protection	2-18
Table 16	Y-Cable for E1/DS1 Protection	2-18
Table 17	Splitter Cable for Protection and Management.....	2-18
Table 18	Activation Key Status Parameters	2-28
Table 19	Activation Key Status Parameters	2-30
Table 20	Time Services Parameters	2-32
Table 21	PTP 820G Radio Profiles for Fixed Interfces and RMC-B.....	2-51
Table 22	PTP 820F Radio Profiles for Microwave RFU’s	2-51
Table 23	PTP 820F Radio Profiles for RFU-E	2-52
Table 24	MRMC Symmetrical Scripts Page Parameters.....	2-52
Table 25	PTP 820F Radio Configurations.....	3-2
Table 26	PTP 820G Radio Configurations	3-2
Table 27	TDM Configurations	3-3
Table 28	LACP Port Status Page.....	3-44
Table 29	LACP Port Status Parameters	3-46
Table 30	LACP Port Statistics Parameters.....	3-48
Table 31	LACP Port Debug Statistics	3-49
Table 32	IF Combining parameters.....	3-66
Table 33	Remote Networking Configuration Parameters.....	4-4
Table 34	SNMP V3 Authentication Parameters.....	4-8
Table 35	Trap Manager Parameters	4-10
Table 36	Versions Page Columns	4-15
Table 37	Download & Install Status Parameters	4-23
Table 38	Backup Files Page Columns	4-27
Table 39	Unit Parameters	4-35
Table 40	NTP Status Parameters	4-37
Table 41	Radio Status Parameters.....	5-3

Table 42 Radio Unit Parameters 5-6

Table 43 Remote Radio Parameters 5-9

Table 44 Radio Ethernet Interface Counters Fields 5-20

Table 45 MRMC Status Parameters 5-29

Table 46 MRMC PMs 5-30

Table 47 Signal Level PMs 5-32

Table 48 Signal Level Thresholds 5-33

Table 49 Combined PMs 5-36

Table 50 Modem BER (Aggregate) PMs 5-37

Table 51 Modem MSE PMs 5-39

Table 52 XPI PMs 5-41

Table 53 Capacity/Throughput PMs 5-44

Table 54 Utilization PMs 5-46

Table 55 Frame Error Rate PMs 5-47

Table 56 Ethernet Services Page Parameters 6-4

Table 57 General Service Point Attributes 6-9

Table 58 Attached Interface Types 6-11

Table 59 Service Point Ingress Attributes 6-12

Table 60 Service Point Egress Attributes 6-14

Table 61 VLAN Classification Parameters 6-20

Table 62 Physical Interface Status Parameters 6-25

Table 63 Ethernet TX Port PMs 6-35

Table 64 Ethernet RX Port PMs 6-37

Table 65 Logical Interface Classification Parameters 7-6

Table 66 Policer Profile Parameters 7-16

Table 67 Attached Interface Types 8-9

Table 68 ERPI Configuration Parameters 8-10

Table 69 ERPI State Parameters 8-11

Table 70 ERPI Statistics 8-13

Table 71 MSTP Bridge Configuration ID Parameters 8-19

Table 72 MSTP Bridge Spanning Tree Status Parameters 8-20

Table 73 MSTP Bridge Spanning Tree Configuration Parameters 8-21

Table 74 MSTP Bridge CIST Status Parameters 8-24

Table 75 MSTP Bridge MSTI Status Parameters 8-25

Table 76 MSTP Port Spanning Tree Status Parameters 8-28

Table 77 MSTP Port CIST Status Parameters 8-30

Table 78 MSTP Port MSTI Status Parameters 8-33

Table 79 MSTP BPDU Counters 8-35

Table 80 LLDP Remote System Management Parameters 8-37

Table 81 LLDP Read-Only Configuration Parameters 8-38

Table 82 LLDP Configurable Configuration Parameters 8-39

Table 83 LLDP Port Configuration Status Parameters 8-41

Table 84 LLDP Management TLV Parameters 8-43

Table 85 LLDP Remote System Management Parameters 8-44

Table 86 LLDP Remote System Table Parameters 8-45

Table 87 LLDP Local System Parameters 8-46

Table 88 LLDP Local System Port Parameters..... 8-48

Table 89 LLDP Local System Management Parameters..... 8-50

Table 90 LLDP Statistics 8-51

Table 91 LLDP Port TX Statistics..... 8-51

Table 92 LLDP Port RX Statistics..... 8-53

Table 93 E1/DS1 Interface Configuration Parameters..... 9-5

Table 94 E1/DS1 Interface Parameters..... 9-6

Table 95 Native TDM Service Parameters 9-9

Table 96 TDM Pseudowire Service Parameters 9-25

Table 97 Pseudowire Card Configuration Parameters..... 9-40

Table 98 Pseudowire Maintenance Domain Parameters 9-42

Table 99 Pseudowire Maintenance Association Parameters 9-44

Table 100 Pseudowire PSN Tunnels Parameters 9-48

Table 101 Pseudowire Tunnel Status Parameters 9-51

Table 102 Pseudowire Tunnel Group Parameters 9-53

Table 103 Pseudowire Profile Parameters..... 9-56

Table 104 Pseudowire TDM Service Parameters..... 9-61

Table 105 Pseudowire TDM Service Status Parameters 9-64

Table 106 E1/DS1 PMs..... 9-66

Table 107 Native TDM Service PMs..... 9-68

Table 108 Pseudowire TDM Service PMs 9-69

Table 109 Sync Source Parameters..... 10-3

Table 110 Boundary Clock Default Parameters 10-16

Table 111 Boundary Clock Advanced Parameters 10-17

Table 112 Boundary Clock Port Parameters. 10-18

Table 113 Boundary Clock Port Statistics 10-19

Table 114 Alarm Information..... 12-3

Table 115 Event Log Information..... 12-5

Table 116 Alarm Configuration Page Parameters..... 12-7

Table 117 External Alarms Interface Pin-Outs..... 12-10

Table 118 SOAM MA/MEG Configuration Parameters 12-29

Table 119 SOAM MA/MEG Status Parameters 12-30

Table 120 SOAM MEP Parameters..... 12-34

Table 121 SOAM MEP DB Table Parameters 12-37

Table 122 IP Address (IPv4) CLI Parameters 14-7

Table 123 IP Address (IPv6) CLI Parameters 14-8

Table 124 Local Time Configuration CLI Parameters 14-19

Table 125 Daylight Savings Time CLI Parameters 14-20

Table 126	Interface Configuration CLI Parameters.....	14-22
Table 127	Cascading Interface CLI Parameters.....	14-24
Table 128	Radio Mute/Unmute CLI Parameters.....	14-26
Table 129	Radio Transmit (TX) Level CLI Parameters	14-27
Table 130	Radio Transmit (TX) Frequency CLI Parameters.....	14-28
Table 131	MRMC Script CLI Parameters	14-29
Table 132	MRMC Script Assignment to Radio Carrier CLI Parameters	14-31
Table 133	Radio Configuration PTP 820F.....	15-2
Table 134	Radio Configurations PTP 820G	15-2
Table 135	TDM Configurations	15-3
Table 136	LACP aggregation status parameters	15-15
Table 137	LACP port status parameters	15-17
Table 138	LACP port statistics.....	15-19
Table 139	XPIC Configuration CLI Parameters	15-21
Table 140	1+1 HSB CLI Parameters.....	15-23
Table 141	HSB Revertive Mode CLI Parameters	15-26
Table 142	Remote Unit IP Address (IPv4) CLI Parameters.....	16-3
Table 143	Remote Unit IP Address (IPv6) CLI Parameters.....	16-4
Table 144	SNMPv3 CLI Parameters.....	16-7
Table 145	Software Download CLI Parameters	16-14
Table 146	RFU Software Upgrade CLI Parameters.....	16-15
Table 147	Configuration Management CLI Parameters.....	16-19
Table 148	Configuration Management CLI Parameters.....	16-22
Table 149	Configuration Import and Restore CLI Parameters.....	16-24
Table 150	Unit Parameters CLI Parameters.....	16-29
Table 151	NTP CLI Parameters.....	16-30
Table 152	Remote Radio Mute/Unmute CLI Parameters	17-5
Table 153	Remote Radio TX Level CLI Parameters	17-5
Table 154	Remote Radio ATPC CLI Parameters	17-5
Table 155	Radio ATPC CLI Parameters.....	17-8
Table 156	Header De-Duplication CLI Parameters	17-11
Table 157	Frame Cut-Through CLI Parameters.....	17-13
Table 158	Aggregate PMs (CLI)	17-21
Table 159	Excessive BER CLI Parameters	17-22
Table 160	Excessive BER Threshold Parameters (CLI).....	17-22
Table 161	RSL Thresholds CLI Parameters	17-23
Table 162	TSL Thresholds CLI Parameters	17-23
Table 163	RSL and TSL PMs (CLI)	17-24
Table 164	Signal Level Threshold CLI Parameters.....	17-25
Table 165	MSE CLI Parameters	17-25
Table 166	MSE PMs (CLI)	17-27
Table 167	ACM PMs (CLI).....	17-28

Table 168 XPI Threshold CLI Parameters	17-29
Table 169 XPI PMs (CLI)	17-30
Table 170 Adding Ethernet Service CLI Parameters	18-3
Table 171 Displaying Ethernet Service Details CLI Parameters	18-5
Table 172 Ethernet Service Operational State CLI Parameters	18-6
Table 173 Ethernet Service CoS Mode CLI Parameters	18-7
Table 174 Ethernet Service Default CoS CLI Parameters	18-8
Table 175 Ethernet Service EVC CLI Parameters	18-8
Table 176 Ethernet Service EVC Description CLI Parameters	18-9
Table 177 Service Points per Service Type	18-10
Table 178 shows which service point types can co-exist on the same interface. Table 178 Service Point Types per Interface	18-10
Table 179 Legal Service Point – Interface Type Combinations per Interface – SAP and SNP	18-12
Table 180 Legal Service Point – Interface Type Combinations per Interface – Pipe and MNG	18-12
Table 181 Add Service Point CLI Parameters	18-14
Table 182 Enable/Disable Broadcast Frames CLI Parameters	18-18
Table 183 Service Point CoS Preservation CLI Parameters	18-19
Table 184 Service Point Default CoS CLI Parameters	18-19
Table 185 Service Point Enable/Disable Flooding CLI Parameters	18-20
Table 186 C-VLAN CoS Preservation Mode CLI Parameters	18-22
Table 187 C-VLAN Preservation CLI Parameters	18-23
Table 188 S-VLAN CoS Preservation CLI Parameters	18-24
Table 189 Service Bundle CLI Parameters	18-25
Table 190 VLAN Bundle to Service Point CLI Parameters	18-25
Table 191 Display Service Point Attributes CLI Parameters	18-26
Table 192 MAC Address Forwarding Table Maximum Size CLI Parameters	18-28
Table 193 MAC Address Forwarding Table Aging Time CLI Parameters	18-28
Table 194 Adding Static Address to MAC Address Forwarding Table CLI Parameters	18-30
Table 195 Enabling MAC Address Learning CLI Parameters	18-31
Table 196 Configure S-VLAN Ethertype CLI Parameters	18-32
Table 197 Configure MRU CLI Parameters	18-33
Table 198 Entering Interface View CLI Parameters	18-35
Table 199 Interface Media Type CLI Parameters	18-36
Table 200 Interface Speed and Duplex State CLI Parameters	18-37
Table 201 Interface Auto Negotiation State CLI Parameters	18-37
Table 202 Interface IFG CLI Parameters	18-38
Table 203 Interface Preamble CLI Parameters	18-38
Table 204 Interface Description CLI Parameters	18-39
Table 205 Automatic State Propagation to an Ethernet Port CLI Parameters	18-41
Table 206 RMON Statistics CLI Parameters	18-43
Table 207 Port PM Thresholds CLI Parameters	18-44
Table 208 Ethernet Port PMs	18-46
Table 209 VLAN Classification and Override CLI Parameters	19-3

Table 210 802.1p Trust Mode CLI Parameters 19-5

Table 211 C-VLAN 802.1 UP and CFI Bit Classification Table Default Values 19-5

Table 212 C-VLAN 802.1 UP and CFI Bit Classification Table CLI Parameters 19-6

Table 213 S-VLAN 802.1 UP and DEI Bit Classification Table Default Values 19-7

Table 214 S-VLAN 802.1 UP and DEI Bit Classification Table CLI Parameters 19-7

Table 215 Trust Mode for DSCP CLI Parameters 19-8

Table 216 DSCP Classification Table Default Values 19-9

Table 217 Modify DSCP Classification Table CLI Parameters 19-10

Table 218 Trust Mode for MPLS CLI Parameters 19-11

Table 219 MPLS EXP Bit Classification Table Default Values 19-11

Table 220 MPLS EXP Bit Classification Table Modification CLI Parameters 19-12

Table 221 Default CoS CLI Parameters 19-13

Table 222 Rate Meter Profile CLI Parameters 19-14

Table 223 Assigning Rate Meter for Unicast Traffic CLI Parameters 19-17

Table 224 Assigning Rate Meter for Multicast Traffic CLI Parameters 19-18

Table 225 Assigning Rate Meter for Broadcast Traffic CLI Parameters 19-19

Table 226 Assigning Rate Meter per Ethertype CLI Parameters 19-20

Table 227 Assigning Line Compensation Value for Rate Meter CLI Parameters 19-21

Table 228 Displaying Rate Meter Statistics CLI Parameters 19-22

Table 229 Marking Mode on Service Point CLI Parameters 19-24

Table 230 Marking Table for C-VLAN UP Bits 19-25

Table 231 802.1q CoS and Color to UP and CFI Bit Mapping Table CLI Parameters 19-26

Table 232 802.1ad UP Marking Table (S-VLAN) 19-27

Table 233 802.1ad UP Marking Table (S-VLAN) CLI Parameters 19-28

Table 234 WRED Profile CLI Parameters 19-30

Table 235 Assigning WRED Profile to Queue CLI Parameters 19-31

Table 236 Queue Shaper Profiles CLI Parameters 19-34

Table 237 Attaching Shaper Profile to Queue CLI Parameters 19-35

Table 238 Service Bundle Shaper Profiles CLI Parameters 19-37

Table 239 Attaching Shaper Profile to Service Bundle CLI Parameters 19-38

Table 240 Egress Line Compensation for Shaping CLI Parameters 19-39

Table 241 Interface Priority Profile Example 19-40

Table 242 Interface Priority Profile CLI Parameters 19-42

Table 243 Interface Priority Sample Profile Parameters 19-43

Table 244 Attaching Priority Profile to Interface CLI Parameters 19-44

Table 245 WFQ Profile Example 19-45

Table 246 WFQ Profile CLI Parameters 19-46

Table 247 WFQ Sample Profile Parameters 19-46

Table 248 Attaching WFQ Profile to Interface CLI Parameters 19-47

Table 249 Egress Queue Level PMs CLI Parameters 19-49

Table 250 Egress Service Bundle Level PMs CLI Parameters 19-55

Table 251 G.8032 Destination MAC Address CLI Parameters 20-2

Table 252 G.8032 ERPI Configuration CLI Parameters..... 20-3

Table 253 G.8032 RPL Owner CLI Parameters 20-4

Table 254 G.8032 Timer Configuration CLI Parameters 20-5

Table 255 G.8032 Switching and Reversion CLI Parameters 20-7

Table 256 G.8032 Switching and Reversion CLI Parameters 20-7

Table 257 G.8032 ERPI Display Command Input Parameters..... 20-9

Table 258 G.8032 ERPI Display Command Output Parameters 20-10

Table 259 G.8032 Service Point Display Command Output Parameters 20-12

Table 260 Defining Number of MSTIs CLI Parameters 20-15

Table 261 BPDU Destination MAC Address CLI Parameters 20-16

Table 262 MSTP Signal Degrade Failure CLI Parameters 20-16

Table 263 MSTP Configuration ID CLI Parameters..... 20-17

Table 264 MSTP Service to MSTI Mapping CLI Parameters 20-18

Table 265 MSTP Bridge Level Spanning Tree CLI Parameters..... 20-19

Table 266 Bridge Level MSTI CLI Parameters..... 20-20

Table 267 CIST Port CLI Parameters..... 20-22

Table 268 MSTI Port CLI Parameters 20-25

Table 269 Port BPDU Counters CLI Parameters..... 20-27

Table 270 General LLDP CLI Parameters..... 20-29

Table 271 LLDP Port CLI Parameters..... 20-30

Table 272 LLDP Local System CLI Parameters..... 20-36

Table 273 TDM Slot Configuration CLI Parameters 21-4

Table 274 E1/DS1 Configuration CLI Parameters 21-5

Table 275 Pseudowire Tunnel CLI Parameters 21-10

Table 276 Pseudowire Profile CLI Parameters..... 21-13

Table 277 Pseudowire OEM MD CLI Parameters..... 21-15

Table 278 Pseudowire OEM MA CLI Parameters..... 21-16

Table 279 Pseudowire OEM CCM Messages CLI Parameters 21-18

Table 280 Assigning MA to TDM Tunnel CLI Parameters..... 21-18

Table 281 Pseudowire Tunnel Group CLI Parameters 21-19

Table 282 Pseudowire Tunnel Group Display CLI Parameters..... 21-21

Table 283 Network Edge Node for Dual Homing CLI Parameters..... 21-22

Table 284 Pseudowire Service CLI Parameters..... 21-23

Table 285 E1/DS1 PMs CLI Parameters..... 21-26

Table 286 Sync Source Ethernet CLI Parameters 22-4

Table 287 Sync Source Radio CLI Parameters 22-5

Table 288 Outgoing Clock CLI Parameters 22-7

Table 289 Synchronization Revertive Timer CLI Parameters 22-10

Table 290 1588 Transparent Clock CLI Parameters 22-14

Table 291 Boundary Clock Configuration CLI Parameters 22-17

Table 292 Boundary Clock Default Settings – CLI Parameters..... 22-20

Table 293 Boundary Clock Default Parameters 22-20

Table 294	Boundary Clock Advanced Parameters (CLI)	22-22
Table 295	Boundary Clock Port Parameters (CLI)	22-24
Table 296	Boundary Clock Configuration CLI Parameters	22-24
Table 297	Boundary Clock Port Statistics (CLI)	22-25
Table 298	Inactivity Timeout Period CLI Parameters	23-2
Table 299	Blocking Upon Login Failure CLI Parameters	23-3
Table 300	Blocking Unused Accounts CLI Parameters	23-4
Table 301	Password Aging CLI Parameters	23-5
Table 302	Password Strength Enforcement CLI Parameters	23-6
Table 303	Force Password Change on First Time Login CLI Parameters	23-6
Table 304	User Profile CLI Parameters	23-8
Table 305	User Profile Access Protocols CLI Parameters	23-9
Table 306	User Accounts CLI Parameters	23-10
Table 307	Activate RADIUS CLI Parameters	23-11
Table 308	RADIUS Server CLI Parameters	23-11
Table 309	CSR Generation and Upload CLI Parameters	23-15
Table 310	Certificate Download and Install CLI Parameters	23-16
Table 311	Security Log CLI Parameters	23-20
Table 312	Configuration Log CLI Parameters	23-22
Table 313	Editing Alarm Text and Severity CLI Parameters	24-4
Table 314	Restoring Alarms to Default CLI Parameters	24-5
Table 315	Uploading Unit Info CLI Parameters	24-9
Table 316	Radio Loopback CLI Parameters	24-12
Table 317	Ethernet Loopback CLI Parameters	24-13
Table 318	E1/DS1 Loopback CLI Parameters	24-14
Table 319	Maintenance Domain CLI Parameters	24-16
Table 320	SOAM MEG CLI Configuration Parameters	24-17
Table 321	MEP CLI Configuration Parameters	24-21
Table 322	MEP and Remote MEP Status Parameters (CLI)	24-23
Table 323	Loopback CLI Parameters	24-28
Table 324	CW Mode CLI Parameters	24-30
Table 325	Fault Finding Checklist	25-1
Table 326	GbE Interface Pin-Out Diagram (GbE1, GbE2, GbE3, GbE4)	27-2
Table 327	Management Interface Pin-Out Diagram (MGMT)	27-4
Table 328	E1/DS1 Interface Pin-Out Diagram (E1/DS1 1-16)	27-6
Table 329	Synchronization Interface Pin-Out Diagram	27-10
Table 330	Sync Interface LEDs	27-11
Table 331	Terminal Interface Pin-Out Diagram	27-13
Table 332	External Alarm Interface Pin-Out Diagram	27-14
Table 333	GbE Interface Pin-Out Diagram (GbE1, GbE2, GbE3, GbE4, 2.5GE5, 2.5GE6)	28-17
Table 334	Management Interface Pin-Out Diagram (MGMT)	28-19
Table 335	E1/DS1 Interface Pin-Out Diagram (E1/DS1 1-16)	28-20

Table 336 Radio Interface Pin-Out Diagram (RFU1, RFU2, RFU3)	28-24
Table 337 Synchronization Interface Pin-Out Diagram	28-27
Table 338 Terminal Interface Pin-Out Diagram	28-29
Table 339 External Alarm Interface Pin-Out Diagram.....	28-30

About This User Guide

This document explains how to configure and operate a PTP 820 Split-Mountsystem. This document applies to system release 10.0

The PTP Split-Mount system is a modular system with a wide variety of configuration options. Not all configurations are described in this manual.

This guide contains the following Chapters:

- Introduction
 - [Chapter 1: Introduction](#)
- Web EMS configuration
 - [Chapter 2: Getting Started](#)
 - [Chapter 3: Configuration Guide](#)
 - [Chapter 4: Unit Management](#)
 - [Chapter 5: Radio Configuration](#)
 - [Chapter 6: Ethernet Services and Interfaces](#)
 - [Chapter 7: Quality of Service \(QoS\)](#)
 - [Chapter 8: Ethernet Protocols](#)
 - [Chapter 9: TDM Services and Interfaces](#)
 - [Chapter 10: Synchronization](#)
 - [Chapter 11: Access Management and Security](#)
 - [Chapter 12: Alarm Management and Troubleshooting](#)
 - [Chapter 13: Web EMS Utilities](#)
- CLI Configuration
 - [Chapter 14: Getting Started \(CLI\)](#)
 - [Chapter 15: Configuration Guide \(CLI\)](#)
 - [Chapter 16: Unit Management \(CLI\)](#)
 - [Chapter 17: Radio Configuration \(CLI\)](#)
 - [Chapter 18: Ethernet Services and Interfaces \(CLI\)](#)
 - [Chapter 19: Quality of Service \(QoS\) \(CLI\)](#)
 - [Chapter 20: Ethernet Protocols \(CLI\)](#)
 - [Chapter 21: TDM Services and Interfaces \(CLI\)](#)
 - [Chapter 22: Synchronization \(CLI\)](#)
 - [Chapter 23: Access Management and Security \(CLI\)](#)
 - [Chapter 24: Alarm Management and Troubleshooting \(CLI\)](#)
- Maintenance
 - [Chapter 25: Fault Finding](#)
 - [Chapter 26: Replacing an IDU or SM card](#)
 - [Chapter 27: Pin-Outs and LEDs](#)
- Appendices

- [Chapter 29: Alarms List](#)

Contacting Cambium Networks

Support website:	http://www.cambiumnetworks.com/support
Main website:	http://www.cambiumnetworks.com
Sales enquiries:	solutions@cambiumnetworks.com
Support enquiries:	support@cambiumnetworks.com
Repair enquiries	rma@cambiumnetworks.com
Telephone number list:	http://www.cambiumnetworks.com/support/contact-support
Address:	Cambium Networks Limited, Global Headquarters 3800 Golf Road, Suite 360 Rolling Meadows, IL 60008 USA

Purpose

Cambium Networks Point-To-Point (PTP) documents are intended to instruct and assist personnel in the operation, installation and maintenance of the Cambium PTP equipment and ancillary devices. It is recommended that all personnel engaged in such activities be properly trained.

Cambium disclaims all liability whatsoever, implied or express, for any risk of damage, loss or reduction in system performance arising directly or indirectly out of the failure of the customer, or anyone acting on the customer's behalf, to abide by the instructions, system parameters, or recommendations made in this document.

Cross references

References to external publications are shown in italics. Other cross references, emphasized in blue text in electronic versions, are active links to the references.

This document is divided into numbered chapters that are divided into sections. Sections are not numbered, but are individually named at the top of each page, and are listed in the table of contents.

Feedback

We appreciate feedback from the users of our documents. This includes feedback on the structure, content, accuracy, or completeness of our documents. Send feedback to support@cambiumnetworks.com.

Problems and warranty

Reporting problems

If any problems are encountered when installing or operating this equipment, follow this procedure to investigate and report:

- 1 Search this document and the software release notes of supported releases.
- 2 Visit the support website.
- 3 Ask for assistance from the Cambium product supplier.
- 4 Gather information from affected units, such as any available diagnostic downloads.
- 5 Escalate the problem by emailing or telephoning support.

Repair and service

If unit failure is suspected, obtain details of the Return Material Authorization (RMA) process from the support website.

Hardware warranty

Cambium's standard hardware warranty is for one (1) year from date of shipment from Cambium Networks or a Cambium distributor. Cambium Networks warrants that hardware will conform to the relevant published specifications and will be free from material defects in material and workmanship under normal use and service. Cambium shall within this time, at its own option, either repair or replace the defective product within thirty (30) days of receipt of the defective product. Repaired or replaced product will be subject to the original warranty period but not less than thirty (30) days.

To register PTP products or activate warranties, visit the support website. For warranty assistance, contact the reseller or distributor.



Caution

Using non-Cambium parts for repair could damage the equipment or void warranty. Contact Cambium for service and repair instructions.

Portions of Cambium equipment may be damaged from exposure to electrostatic discharge. Use precautions to prevent damage.

Security advice

Cambium Networks systems and equipment provide security parameters that can be configured by the operator based on their particular operating environment. Cambium recommends setting and using these parameters following industry recognized security practices. Security aspects to be considered are protecting the confidentiality, integrity, and availability of information and assets. Assets include the ability to communicate, information about the nature of the communications, and information about the parties involved.

In certain instances Cambium makes specific recommendations regarding security practices, however the implementation of these recommendations and final responsibility for the security of the system lies with the operator of the system.

Warnings, cautions, and notes

The following describes how warnings and cautions are used in this document and in all documents of the Cambium Networks document set.

Warnings

Warnings precede instructions that contain potentially hazardous situations. Warnings are used to alert the reader to possible hazards that could cause loss of life or physical injury. A warning has the following format:



Warning

Warning text and consequence for not following the instructions in the warning.

Cautions

Cautions precede instructions and are used when there is a possibility of damage to systems, software, or individual items of equipment within a system. However, this damage presents no danger to personnel. A caution has the following format:



Caution

Caution text and consequence for not following the instructions in the caution.

Notes

A note means that there is a possibility of an undesirable situation or provides additional information to help the reader understand a topic or concept. A note has the following format:



Note

Note text.

Caring for the environment

The following information describes national or regional requirements for the disposal of Cambium Networks supplied equipment and for the approved disposal of surplus packaging.

In EU countries

The following information is provided to enable regulatory compliance with the European Union (EU) directives identified and any amendments made to these directives when using Cambium equipment in EU countries.



Disposal of Cambium equipment

European Union (EU) Directive 2002/96/EC Waste Electrical and Electronic Equipment (WEEE)

Do not dispose of Cambium equipment in landfill sites. For disposal instructions, refer to <http://www.cambiumnetworks.com/support>

Disposal of surplus packaging

Do not dispose of surplus packaging in landfill sites. In the EU, it is the individual recipient's responsibility to ensure that packaging materials are collected and recycled according to the requirements of EU environmental law.

In non-EU countries

In non-EU countries, dispose of Cambium equipment and all surplus packaging in accordance with national and regional regulations.

Chapter 1: Introduction

This section includes:

- [Configuration Tips](#)
- [System Overview](#)
- [PTP 820F IDU Hardware Architecture](#)
- [PTP 820G IDU Hardware Architecture](#)
- [Front Panel Description](#)
- [RFU Overview](#)
- [The Web-Based Element Management System](#)
- [Reference Guide to Web EMS Menu Structure](#)

Configuration Tips

This section describes common issues and how to avoid them.

Ethernet Port Configuration

For RJ-45 ports, it is recommended to enable Auto-Negotiation for both the local port and its peer in order to obtain optimal performance.

For SFP ports, it is recommended to disable Auto-Negotiation.

For instructions, see [Configuring Ethernet interfaces](#).

Admin Status of Second Radio Interface

If the PTP 820F is connected to a single-carrier RFU, or if the second carrier of a MultiCore RFU is not in use, you should set the **Admin status** field of the second Radio interface (Port 2) to **Down** to disable the Radio interface and prevent unnecessary alarms. See [Enabling the Interfaces \(Interface Manager\)](#)

SyncE Interface Configuration

When configuring a Sync source or outgoing clock on an Ethernet interface, the Media Type of the interface must be RJ-45 or SFP, not Auto-Type. See [Synchronization](#).

In-Band Management

In order to use in-band management with an external switch, it must be supported on the external switch.

When configuring in-band management, be sure to tag the management traffic to avoid overflow of the CPU.

For instructions on configuring in-band management on the PTP 820, see [Configuring In-Band Management](#).

Link Aggregation (LAG)

If you are configuring LAG with an external switch, the switch must support LAG. For instructions on configuring LAG, see [Configuring Link Aggregation \(LAG\) and LACP](#).

Software Upgrade

When upgrading software via HTTP, make sure the software package is *not* unzipped. For instructions, see [Upgrading the Software](#).

Configuration Management and Backup Restoration

Configuration files can only be copied to the same PTP 820 hardware type with the same part number as the unit from which they were originally saved. For example, an PTP 820G configuration file can only be restored to an PTP 820G with the same part number as the unit from which it was saved. See [Backing Up and Restoring Configurations](#).

System Overview

This section provides a brief overview of the PTP 820 systems described in this document. A separate Technical Description is available for each product, providing a full description of the individual system and its specifications

PTP 820F

PTP 820F is a split-mount edge node that delivers multi-Gbps radio capacity to the transport network. It provides operators with the simplicity that comes with deploying a very compact, fixed configuration node, helping operators to meet their operational efficiency targets.

PTP 820F contains up to six Ethernet interfaces and up to three RFU interfaces, as detailed in PTP 820F IDU Hardware Architecture

For TDM traffic, PTP 820F includes a 16 x E1/DS1 interface

PTP 820F is based on a passive cooling design that does not require fans, for improved operational efficiency.

An PTP 820F consists of an indoor unit (IDU) and one or two radio frequency units (RFUs). PTP 820F can be used with MultiCore RFU-D and single-carrier RFU-S.

PTP 820G

PTP 820G is a compact, split-mount hauling solution for ring nodes. Its fixed configuration and low power consumption make it simple to install and maintain. Hosting the common capabilities of the PTP 820 platform, it provides a cost-effective, reliable, and flexible hauling solution.

PTP 820G can also include the following optional features:

- Multi-carrier package including two radio channels and radio interfaces.
- 16 x E1/DS1E1/DS1E1/DS1 interfaces, with advanced support for TDM services.
- Dual-feed power option for power redundancy.

PTP 820G is built specifically for tail/edge sites deployments.

The following interfaces are supported:

- 6 x 1 GbE interfaces total
 - 2 x dual mode GbE electrical or cascading interfaces (RJ-45)
 - 2 x GbE electrical interfaces (RJ-45)
 - 2x GbE optical interfaces (SFP)
- Optional: 16 x E1/DS1 interfaces
- Single or dual radio interfaces (TNC)
- Single power-feeds (-48v)
- Sync in/out interface
- Management interfaces
 - Terminal – RS232 (RJ-45)

- 2x FE electrical interfaces (RJ-45)
- External alarms interface

PTP 820G is based on a passive cooling design that does not require fans, for improved operational efficiency.

A PTP 820G consists of an indoor unit (IDU) and one or two radio frequency units (RFUs). PTP 820G can be used with RFU-C, 1500HP/RFU-HP, and RFU-A.

Assured Platform

PTP 820 Assured platform enhances network reliability and security, ensuring that mission-critical networks maintain availability, and protecting the confidentiality and integrity of their users' data.

The PTP 820 Assured platform is compliant with FIPS 140-2, including:

- Compliance with FIPS 140-2 specifications for cryptography module.
- FIPS 140-2 Level 2 physical security.
- AES-256 encryption (FIPS 197) over radio links.

The PTP 820 Assured platform also provides:

- Secured communication and protocols for management interface.
- Centralized user authentication management via RADIUS.
- Advanced identity management and password policy enforcement.
- Security events log.
- Secure product architecture and development.

The PTP 820G supports Assured platform.



Note

Release 10.0 cannot be used in PTP 820 Assured platforms. For PTP 820 Assured, use release 8.3. Support for T3 input and T4 output is planned for future release.

PTP 820F IDU Hardware Architecture

PTP 820F is a compact unit that fits in a single rack unit, with a passive cooling system that eliminates the need for fans. A PTP 820F system consists of an PTP 820F indoor unit (IDU) and up to three radio frequency units (RFUs). The IDU is connected to each RFU via CAT-5e or CAT-6/6a cables or optical fibers. Power can be provided to the RFUs via PoE over the CAT-5e or CAT-6/6a cables, or via an external DC power source when using optical fibers and in all cases for RFU-D-HP. For details, see [IDU-RFU connection](#).

An PTP 820F IDU contains:

- 4 x 1 GbE combo interfaces (GbE 1-4/SFP 1-4)
- 1 x 2.5/1 GbE combo interface (2.5GE6/SFP6)
- Two combo (RJ-45 or SFP) radio interfaces (RFU1 and RFU 2)
- 1 x radio or 2.5/1 GbE combo interface (RFU3/SFP5, RFU3/2.5GE5)

**Note**

In System Release 10.0, only one radio interface (RFU1) can be used per PTP 820F unit. When used with a MultiCore RFU (RFU-D or RFU-D-HP), this interface can support two radio carriers. However, the second carrier must part of a Multi-Carrier ABC group in order to be utilized.

Also, in System Release 10.0, only four Ethernet interfaces (GbE 1-4/SFP 1-4) can be used. GbE 1/SFP 1 and GbE 2/SFP 2 can be configured as normal Ethernet traffic interfaces or as cascading interfaces.

For TDM traffic, an PTP 820F IDU includes a 16 x E1/DS1 interface.

The IDU also includes two FE management interfaces, a DB9 dry contact external alarms interface, and an RJ-45 terminal console interface for connection to a local craft terminal. Optionally, one of the FE management interfaces can be used as an RJ-45 synchronization interface.

PTP 820F receives an external supply of -48V, with a dual-feed option for power redundancy.

Front Panel Description

This section describes the PTP 820F's front panel. The following sections provide detailed descriptions of the PTP 820F's interfaces and LEDs.

Figure 1 PTP 820F Front Panel and Interface




Table 1 PTP 820F Interfaces


Interface	For Further Information
16 x E1s	<i>E1/DS1 Interface</i>
External Alarms (DB9)	<i>External Alarms</i>
Terminal Interface (RJ-45)	<i>Terminal Interface</i>
2 x FE Management Interfaces (RJ-45)	Ethernet Management Interfaces
Sync Interface In/Out (RJ-45)	<i>Synchronization Interface</i>
4 x 1 GbE Combo Interfaces (GbE 1-4/SFP 1-4)	Ethernet Traffic Interfaces
1 x 2.5/1 GbE Combo Interface (2.5GE6/SFP6) ¹	<i>Ethernet Traffic Interfaces</i>
2 x Electrical/Optical RFU Interfaces (RFU1/RFU2)	<i>Radio Interfaces</i>
1 x Optional RFU or 2.5/1 GbE Combo Interface (RFU3/SFP5, RFU3/2.5GE5) ¹	<i>Ethernet Traffic Interfaces</i>
Power Interface -48V	<i>Power Interface</i>

¹ 2.5 GE support is planned for future release.

Ethernet Traffic interfaces

The front panel of the PTP 820F contains 4 x GbE combo interfaces (electrical or optical) for Ethernet traffic. These interfaces are numbered as shown in the following figure.

Figure 2 GbE Combo Interface Numbering




GbE 1/SFP 1 and GbE 2/SFP 2 can be configured as normal Ethernet traffic interfaces or as cascading interfaces. When operating in cascading mode, these interfaces can handle hybrid Ethernet and Native TDM traffic, enabling operators to create links among multiple PTP 820 units in a node for multi-directional applications based on hybrid Ethernet and Native or pseudowire TDM services..

In addition, two pairs of electrical and optical interfaces towards the right of the front panel can be used to provide either two Ethernet interfaces or one Ethernet interface and one radio interface:


- RFU3/SFP5 and RFU3/2.5GE5 – A combo interface that can be used as either an SFP or RJ-45 RFU interface or an SFP or RJ-45 Ethernet interface.
- SFP6/2.5GE6 – A combo interface (SFP or RJ-45) for Ethernet.

Figure 3 RFU3/ SFP5-6 Interfaces



Ethernet Management interfaces

PTP 820F contains two FE management interfaces, which connect to a single RJ-45 physical connector on the front panel. The RJ-45 connector is the upper RJ-45 interface in a pair of interfaces labeled MGMT/SYNC.

Figure 4 Management Interface Pin Connections

If the user only needs to use a single management interface, a standard Cat5 RJ-45 cable (straight or cross) can be connected to the MGMT interface.

To access both management interfaces, a special 2 x FE splitter cable can be ordered from Cambium.

Table 2 2 x FE Splitter Cable Model Number

Model Number	Description
N000082L122A	PTP820 Ethernet split cable for Management

E1/DS1 Interface

PTP 820F includes an MDR69 connector in which 16 E1/DS1 interfaces are available (ports 1 through 16).

Radio Interfaces

PTP 820F includes two combo radio interfaces (electrical or optical, RFU1 and RFU2). A third interface can also be used as a combo radio interface (electrical or optical, RFU3). See [Ethernet Traffic Interfaces](#).

**Note**

Only RFU1 is available for use in System Release 10.0.

For some RFUs, PoE power can be supplied directly from the IDU via an RJ-45 radio interface.

Power Interface

PTP 820F receives an external supply of -48V current via a dual-feed power interface, which can be connected to two separate power sources for power redundancy. The PTP 820F monitors the power supply for under-voltage and includes reverse polarity protection, so that if the positive (+) and negative (-) inputs are mixed up, the system remains shut down.

The allowed power input range for the PTP 820F is -40V to -60V. An under voltage alarm is triggered if the power goes below the allowed range, and an over voltage alarm is triggered if the power goes above the allowed range.

Synchronization Interface

PTP 820F includes an RJ-45 synchronization interface for T3 clock input and T4 clock output. The interface is the lower RJ-45 interface in a pair of interfaces labeled MGMT/SYNC.

Terminal Interface

PTP 820F includes an RJ-45 terminal interface (RS-232). A local craft terminal can be connected to the terminal interface for local CLI management of the unit.

External Alarms

PTP 820F includes a DB9 dry contact external alarms interface. The external alarms interface supports five input alarms and a single output alarm.

The input alarms are configurable according to:

- 1 Intermediate
- 2 Critical
- 3 Major
- 4 Minor
- 5 Warning


The output alarm is configured according to predefined categories.

Storage Memory Card

Each PTP 820F unit includes a Storage Memory card (SM card). The SM card holds the configuration and software for the IDU. The SM card is embedded in the SM card cover. In the event of IDU replacement, re-using the existing SM card cover is necessary to ensure that the unit's software and configuration is maintained.

An SM card is pre-installed inside each PTP 820F unit. It can also be ordered as a separate item (e.g., as a spare unit).

Figure 5 SM Card and Cover



PTP 820G IDU Hardware Architecture

PTP 820G is a compact unit that fits in a single rack unit, with a passive cooling system that eliminates the need for fans. A PTP 820G system consists of a PTP 820G indoor unit (IDU) and one or two radio frequency units (RFUs). A coaxial cable connects the IDU to each RFU, transmits traffic and management data between the IDU and the RFU, and provides -48V DC power to the RFU.

A PTP 820G IDU contains six Ethernet interfaces, one or two radio interfaces depending on the hardware configuration, and optionally a 16 x E1/DS1 interface.

The IDU includes two FE management interfaces, a DB9 dry contact external alarms interface, an RJ-45 synchronization interface, and an RJ-45 terminal console interface for connection to a local craft terminal.

PTP 820G receives an external supply of -48V, with a dual-feed option for power redundancy.

The following hardware assembly options are available for the PTP 820G IDU:

- One or two radio interfaces
- With or without 16 x DS1 interfaces

Front Panel Description

This section describes the PTP 820G front panel. The following sections provide detailed descriptions of the PTP 820G interfaces and LEDs.

Figure 6 PTP 820G Front Panel and Interfaces




Table 3 PTP 820 Interfaces

Interface	For Further Information
16 x E1/DS1s (optional)	E1/DS1 Interface (Optional)
External Alarms (DB9)	External Alarms
TDM Sync Interface In/Out (RJ-45)	Synchronization Interface
2 x FE Management Interfaces (RJ-45)	Ethernet Management Interfaces
Terminal Interface (RJ-45)	Terminal Interface
2 x GbE Dual Mode GbE Electrical or Cascading Interfaces (RJ-45)	Ethernet Traffic Interfaces
2 x GbE Electrical Interfaces (RJ-45)	Ethernet Traffic Interfaces
2 x GbE Optical Interfaces (SFP)	Ethernet Traffic Interfaces
Radio Interfaces (TNC)	Radio Interfaces
Power Interface -48V	Power Interface

Ethernet Traffic Interfaces

The front panel of the PTP 820G contains four electrical and two optical GbE Ethernet traffic interfaces:


- 2 x GbE dual mode electrical or cascading interfaces (RJ-45) – GbE1/CS1, GbE2/CS2
- 2 x GbE electrical interfaces (RJ-45) –GbE3, GbE4
- 2 x GbE optical interfaces (SFP) – SFP5, SFP6

GbE1/CS1 and GbE2/CS2 can be configured as normal GbE traffic interfaces or as cascading interfaces. When operating in cascading mode, these interfaces can handle hybrid Ethernet and Native TDM traffic, enabling operators to create links among multiple PTP 820G units in a node for multi-carrier and multi-directional applications based on hybrid Ethernet and TDM (Native or pseudowire) services.

Ethernet Management Interfaces

PTP 820G contains two FE management interfaces, which connect to a single RJ-45 physical connector on the front panel (MGMT).

Figure 7 Management Interface Pin Connections



If the user only needs to use a single management interface, a standard Cat5 RJ-45 cable (straight or cross) can be connected to the MGMT interface.

To access both management interfaces, a special 2 x FE splitter cable can be ordered from Cambium.

Table 4 2 x FE Splitter Cable Model Number

Model Number	Description
N000082L122A	PTP820 Ethernet split cable for Management

E1/DS1 Interface (Optional)

Optionally, PTP 820G can be ordered with an MDR69 connector in which 16 E1/DS1 interfaces are available (ports 1 through 16).

Radio Interfaces

PTP 820G includes one or two radio interfaces, depending on the hardware assembly option that was selected. Each radio interface uses a TNC connector type. Each radio interface is connected to an RFU via coaxial cable. This connection is used for traffic between the RFU and the IDU. It is also used to provide -48V DC power from the IDU to the RFU, as well as for management and configuration of the RFU.

The radio interfaces are labeled Radio 1 and, if there is a second radio interface, Radio 2.

Power Interface

PTP 820G receives an external supply of -48V current via a power interface. The PTP 820G monitors the power supply for under-voltage and includes reverse polarity protection, so that if the positive (+) and negative (-) inputs are mixed up, the system remains shut down.

The allowed power input range for the PTP 820G is -40V to -60V. An under voltage alarm is triggered if the power goes below the allowed range, and an over voltage alarm is triggered if the power goes above the allowed range.

Synchronization Interface

PTP 820G includes an RJ-45 synchronization interface for T3 clock input and T4 clock output. The interface is labeled SYNC.

**Note**

T3 is only supported when the unit is operating in ETSI mode

Terminal Interface

PTP 820G includes an RJ-45 terminal interface (RS-232). A local craft terminal can be connected to the terminal interface for local CLI management of the unit.

External Alarms

PTP 820G includes a DB9 dry contact external alarms interface. The external alarms interface supports five input alarms and a single output alarm.

The input alarms are configurable according to:

- 1 Intermediate
- 2 Critical
- 3 Major
- 4 Minor
- 5 Warning

The output alarm is configured according to predefined categories.

RFU Overview

Radio Frequency Units (RFUs) were designed with sturdiness, power, simplicity, and compatibility in mind. These advanced systems provide high-power transmission for short and long distances and can be assembled and installed quickly and easily. RFU's used with PTP 820F

The following RFUs can be used with PTP 820F:

- RFU-D – MultiCore that operates in the 6-42 GHz frequency range, supporting channel bandwidth of 14-112 MHz and modulations of BSPK to 4096 QAM.
- RFU-D-HP – High-Power MultiCore RFU that operates in the 4-11 GHz frequency range, supporting channel bandwidth of 14-112 MHz and modulations of BSPK to 4096 QAM.
- RFU-E – Operates in the E-band frequency range, supporting 71-76 GHz and 81-86 GHz frequencies, channel bandwidth of 14, 28, 62.5, 125, and 250 MHz, and modulations of BSPK to 1024 QAM.
- RFU-S – Operates in the 6-42 GHz frequency range, supporting channel bandwidth of 14-112 MHz and modulations of BSPK to 4096 QAM.

RFU's used with PTP 820G

The following RFUs can be used with PTP 820G:

- RFU-C – A state-of-the-art RFU designed for a broad range of interfaces and capacities from 10 Mbps up to 500 Mbps. RFU-C operates in a wide range of spectrum bands, from 6 to 42 GHz. The premium version, RFU-Ce, provides a range of modulations from QPSK to 2048 QAM. RFU-C and RFU-Ce require RFU SW version: 2.17.
- 1500HP/RFU-HP – 1500HP and RFU-HP are high transmit power RFUs designed for long haul applications with multiple carrier traffic. Together with their unique branching design, 1500HP and RFU-HP can chain up to five carriers per single antenna port and 10 carriers for dual port, making them ideal for trunk or multi carrier applications. The 1500HP and RFU-HP can be installed in either indoor or outdoor configurations. RFU-HP requires RFU SW version: 5.14. 1500HP requires RFU SW version 8.13a2.
- RFU-A (including RFU-Ae/Aep) – RFU-A is a high transmit power RFU designed for compact long-haul applications. RFU-A offers a low scale trunk solution with up to four radio carriers and operates in the frequency range of 6, 7, 8, and 11 GHz.² RFU-A requires RFU SW version: 5.14.

² For the exact frequency bands supported by RFU-Aep, contact your Cambium representative.

IDU-RFU Connection and Power Supply for PTP 820F

An RFU-D, RFU-D-HP, RFU-E, and RFU-S can be connected to an PTP 820F via a standard CAT-5e or preferably CAT-6/6a cable, with RJ-45 connectors on the RFU and an RJ-45 connector on the PTP 820F. They can also be connected to the PTP 820F over optical fiber cables via the optical (SFP) RFU connection on the PTP 820F.

For an RFU-D, RFU-E, or RFU-S connecting to an electrical RFU interface, the cable can carry both the data and the DC power required for the RFU. For configuration instructions, see [Configuring the IDU-RFU Connection \(PTP 820F only\)](#).

For an RFU-D, RFU-E, or RFU-S connecting to an optical RFU interface, and for an RFU-D-HP connecting to either an electrical or an optical RFU interface, an external DC power cable is required to supply power to the RFU.

Table 5 IDU-RFU Cable connection for PTP 820F

RFU	Interface	Cable Type	Maximum Length	
			6-11 GHz	13-42 GHz
RFU-D	Optical	Fiber	300m	
	Electrical	CAT-5e (24 AWG)	50m	130m
		CAT-6a (22 AWG)	100m	150m
	DC Power	DC (18 AWG)	100m	
		DC (12 AWG)	101m-300m	
RFU-E/RFU-S	Optical	Fiber	300m	
	Electrical	CAT-5e (24 AWG)	150m	
		CAT-6a (22 AWG)	150m	
	DC Power	DC (18 AWG)	150m	
		DC (14 AWG)	151m-300m	
RFU-D-HP	Optical	Fiber	300m	
	Electrical	CAT-5e (24 AWG)	150m	
		CAT-6a (22 AWG)	150m	
	DC Power	DC (14 AWG)	100m	
		DC (10 AWG)	101m-200m	
DC (8 AWG)		201m-300m		

IDU-RFU Connection and Power Supply for PTP 820G

RFU-C, RFU-HP/1500HP, and RFU-A RFUs are connected to the IDU by a coaxial cable RG-223 (up to 100 m/300 ft), Belden 9914/RG-8 (up to 300 m/1000 ft) or equivalent, with an N-type connector (male) on the RFU and a TNC connector on the PTP 820. These RFUs are powered via this cable.

The Web-Based Element Management System

This section includes:

- [Introduction to the Web EMS](#)
- [Web EMS Page Layout](#)
- [The Unit Summary Page](#)
- [The Radio Summary Page](#)

Introduction to the Web EMS

The Element Management System (Web EMS) is an HTTP web-based element manager that enables the operator to perform configuration operations and obtain statistical and performance information related to the system, including:

- **Configuration Management** – Enables you to view and define configuration data.
- **Fault Monitoring** – Enables you to view active alarms.
- **Performance Monitoring** – Enables you to view and clear performance monitoring values and counters.
- **Diagnostics and Maintenance** – Enables you to define and perform loop back tests and software updates.
- **Security Configuration** – Enables you to configure security features.
- **User Management** – Enables you to define users and user groups.

The Web EMS opens to a page that summarizes the key unit parameters. The next page, when scrolling down the Web EMS main menu, summarizes the key radio parameters. See [The Unit Summary page](#) and [The Radio Summary page](#).

A Web-Based EMS connection to the PTP 820G can be opened using a web browser (Internet Explorer, Mozilla Firefox, or Google Chrome). The Web-Based EMS uses a graphical interface.



Note

The alarms and system configuration details shown in this manual do not necessarily represent actual parameters and values on a fully operating PTP 820G system. Some of the pages and tasks described in this Manual may not be available to all users, based on the actual system configuration, activation key, and other details.


Web EMS Page Layout

Each Web EMS page includes the following sections:

- The left section of the page displays the Web EMS menu tree:
 - Click  to display the sub-options under a menu item.
 - Click  to hide the sub-options under a menu item.

- The main section of the page provides the page's basic functionality.

Figure 8 Main Web EMS Page



Front Panel Representation

Optionally, you can display a representation of the PTP 820G front panel by clicking either the arrow in the center or the arrow at the right of the bottom toolbar.

Figure 9 Displaying a Representation of the Front Panel



Figure 10 Main Web EMS Page with Representation of the Front Panel- PTP 820F





Figure 11 Main Web EMS Page with Representation of the Front Panel- PTP 820G



Related Pages Drop-Down List

Certain pages include a **Related Pages** drop-down list on the upper right of the main section of the page. You can navigate to a page related to the current page by selecting the page from this list.

Figure 12 Related Pages Drop-Down List



The Unit Summary Page

The Unit Summary page is the first page that appears when you log into the Web EMS. It gathers the unit parameters, current alarms, and unit inventory information on a single page for quick viewing.

Figure 13 Unit Summary Page

The screenshot shows the 'Microwave radio: Unit Summary' page. It features a navigation menu on the left with options like 'Unit Summary', 'Radio Summary', 'Platform', 'Faults', 'TDM', 'Radio', 'Ethernet', 'Cascading', 'Sync', 'Quick Configuration', and 'Utilities'. The main content area is divided into three sections:

- Unit Parameters:** A list of key metrics including Description (IP-20GX 1RU, 2 radio, 6 GbE, 16 TDM, dual feed), System up time (1 hour, 6 minutes, 27 seconds), Local date and time (08-02-2000 23:15:37), Running Version (9.7.0.0.0.103), Unit Temperature (30°C, 86°F), Voltage input (Volt) (47), Part number (24-G009-1A), and Serial number (E095900075).
- Current Alarms:** A table listing active alarms with columns for Time, Severity, Description, Origin, and Alarm id.
- ODU Inventory:** A table listing hardware components with columns for Radio Location, Type, Part Number, Serial-Number, and Running Software Version.

Time	Severity	Description	Origin	Alarm id
08-02-2000 22:11:51	▲	Radio loss of frame	Radio: Slot 1, Port 2	603
08-02-2000 22:11:32	▲	1588-BC performance is degraded due to loss of system clock reference	0	5046
08-02-2000 22:10:38	▲	LAG operational state is down	LAG: Group #1	101
08-02-2000 22:10:38	▲	LAG operational state is down	LAG: Group #2	101
08-02-2000 22:11:53	▲	Cable open	Radio: Slot 1, Port 2	1701
08-02-2000 22:11:35	▲	Under voltage	PDC #1	1762
08-02-2000 22:11:34	▲	1588TC is not operational	Radio: Slot 1, Port 2	5018
08-02-2000 22:11:53	▲	RFU communication failure	Radio: Slot 1, Port 2	1703
08-02-2000 22:11:51	▲	RFU TX Mute	Radio: Slot 1, Port 2	1735
08-02-2000 22:10:20	▲	Demo mode is active	Slot 1	901

Radio Location	Type	Part Number	Serial-Number	Running Software Version
Radio: Slot 1, Port 1	Unknown	-	-	-
Radio: Slot 1, Port 2	Unknown	-	-	-

The Unit Summary page includes:

- **Unit Parameters** – Basic unit parameters such as the current software version, unit temperature, and voltage input level. For additional information, see [Configuring Unit Parameters](#).
- **Current Alarms** – All alarms currently raised on the unit. For additional information, see [Viewing Current Alarms](#).
- **IDU Inventory** – The hardware components of the IDU, including the part number and serial number of each component. For additional information, see [Displaying Unit Inventory](#).
- **ODU Inventory** – The RFU used by each radio carrier, including the part number and serial number of each RFU and the software version running on each RFU. For additional information, see [Configuring the Radio Parameters](#).

The Unit Summary page can be customized to include only specific columns and tables. This enables you to hide information you do not need in order to focus on the information that is most relevant.

To hide a specific section of the Unit Summary page, click the section title. To display a section that has been hidden, click the section title again.


To customize which columns appear in a section, click ▼ next to the section title. A list of columns is displayed. Select only the columns you want to display and click ▼ again.



Note

When one or more columns are hidden, the ▼ icon turns white (▽).


Figure 14 Unit Summary Page – Customizing columns



The Radio Summary Page

The Radio Summary page gathers the key link and radio parameters on a single page for quick viewing. To display the Radio Summary page, select **Radio Summary** from the Web EMS main menu.

Figure 15 Radio Summary Page



The Radio Summary page includes:

- **Link Status** – Link status per radio carrier, including whether or not the link is Up, groups to which the link is assigned (such as LAG, XPIC, protection, and/or Multi-Carrier ABC), and the IP address (both IPv4 and IPv6) of the remote carrier. For additional information, see [Configuring the Radio Parameters](#).
- **Radio Information** – The TX and RX frequencies, frequency separation, and channel bandwidth on which the link is operating. For additional information, see [Configuring the Radio Parameters](#).
- **Remote Radio Parameters** – Key information about the status of the remote carrier. For additional information, see [Configuring the Remote Radio Parameters](#).
- **Radio Transmitter** – Mute status, maximum and operational TX level, modulation, and bit rate. For additional information, see [Configuring the Radio Parameters](#).

- **Radio Receiver** – Receiver PMs and statistics, including defective blocks, modem MSE, and RX level, modulation, and bit rate. For additional information, see [Configuring the Radio Parameters](#) and [Entering Radio View \(CLI\)](#)
- **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).

The Radio Summary page can be customized to include only specific columns and tables. This enables you to hide information you do not need in order to focus on the information that is most relevant.

To hide a specific section of the Unit& Radio Summary page, click the section title. To display a section that has been hidden, click the section title again.

To customize which columns appear in a section, click ▼ next to the section title. A list of columns is displayed. Select only the columns you want to display and click ▼ again.



Note

When one or more columns are hidden, the ▼ icon turns white (▼).

Figure 16 Unit & Radio Summary Page – Customizing Columns

▼ Radio Information

<input checked="" type="checkbox"/> All columns		RX Frequency (MHz)
	37086.000	
<input checked="" type="checkbox"/> Radio Location	37086.000	
<input checked="" type="checkbox"/> TX Frequency (MHz)		
<input checked="" type="checkbox"/> RX Frequency (MHz)	on	Local-Remote Channel
<input checked="" type="checkbox"/> Frequency Separation (MHz)		Down
<input checked="" type="checkbox"/> Channel Bandwidth (MHz)		Down
<input checked="" type="checkbox"/> Temperature		
		Maximum TX Level (dBm)

Reference Guide to Web EMS Menu Structure

The following table shows the Web EMS menu hierarchy, with links to the sections in this document that provide instructions for the relevant menu item.

**Note**

Some menu items are only available if the relevant activation key or feature is enabled.

Table 6 Web EMS Menu Hierarchy – Platform Menu

Sub-Menus	For Further Information
Management > Unit Parameters	Configuring Unit Parameters.
Management > NTP Configuration	Configuring NTP
Management > Time Services	Setting the Time and Date (Optional)
Management > Interface Manager	Enabling the Interfaces (Interface Manager)
Management > Inventory	Displaying Unit Inventory
Management > Unit Info	Uploading Unit Info
Management > Reset	Performing a Hard (Cold) Reset
Management > Set to Factory Default	Setting the Unit to the Factory Default Configuration
Management > External Alarms > External Alarms Input	Configuring External Alarms
Management > External Alarms > External Alarms Output	Configuring External Alarms
Management > Networking > Local	Changing the Management IP Address Defining the IP Protocol Version for Initiating Communications
Management > Networking > Remote	Configuring the Remote Unit's IP Address
Management > SNMP > SNMP Parameters	Configuration SNMP
Management > SNMP > Trap Managers	Configuring Trap Managers
Management > SNMP > V3 Users	Configuration SNMP
Software > Timer Parameters	Configuring a Timed Installation
Software > Versions	Viewing Current Software Versions
Software > Download & Install	Downloading and Installing Software
Configuration > Timer Parameters	Reserved for future use.
Configuration > Backup Files	Viewing Current Backup Files
Configuration > Configuration Management	Backing Up and Restoring Configurations
Activation Key > Activation Key Configuration	Configuring the Activation Key.
Activation Key > Activation Key Overview	Displaying a List of Activation-Key-Enabled Features
Security > General > Configuration	Operating in FIPS Mode
Security > General > Security Log Upload	Uploading the Security Log
Security > General > Configuration Log Upload	Uploading the Configuration Log
Security > X.509 Certificate > CSR	Configuring X.509 CSR Certificates and HTTPS

Security > X.509 Certificate > Download & Install	<i>Configuring X.509 CSR Certificates and HTTPS</i>
Security > Access Control > General	<i>Configuring the General Access Control Parameters</i>
Security > Access Control > User Profiles	<i>Configuring User Profiles</i>
Security > Access Control > User Accounts	<i>Configuring Users Accounts</i>
Security > Access Control > Password Management	<i>Configuring the Password Security Parameters</i>
Security > Access Control > Change Password	<i>Changing Your Password</i>
Security > Access Control > Radius > Radius Configuration	<i>Activating RADIUS Authentication</i> <i>Configuring the RADIUS Server Attributes</i>
Security > Access Control > Radius > Radius Users	<i>Viewing RADIUS User Permissions and Connectivity</i>
Security > Protocols Control	<i>Configuring the Session Timeout</i> <i>Blocking Telnet Access</i>

Table 7 Web EMS Menu Hierarchy – Faults Menu

Sub-Menus	For Further Information
Current Alarms	Viewing Current Alarms
Alarm Statistics	Viewing Alarm Statistics
Event Log	Viewing the Event Log
Alarm Configuration	Editing Alarm Text and Severity

Table 8 Web EMS Menu Hierarchy – TDM Menu

Sub-Menus	For Further Information
Native TDM Services	Configuring Native TDM Trails
TDM PseudoWire > Services	Configuring TDM Pseudowire Services
TDM PseudoWire > Advanced > Configuration	Configuring Pseudowire Card Parameters
TDM PseudoWire > Advanced > DS0 Bundles	<i>Reserved for future use.</i>
TDM PseudoWire > Advanced > Service OAM > Maintenance Domain	Configuring Pseudowire Maintenance Domains (MDs)
TDM PseudoWire > Advanced > Service OAM > Maintenance Association	Configuring Pseudowire Maintenance Associations (MAs)
TDM PseudoWire > Advanced > Service OAM > Loopback	<i>Reserved for future use.</i>
TDM PseudoWire > Advanced > Service OAM > Link Trace	<i>Reserved for future use.</i>
TDM PseudoWire > Advanced > PSN Tunnels > PSN Tunnels	Configuring Pseudowire Tunnels and Tunnel Groups
TDM PseudoWire > Advanced > PSN Tunnels > Tunnel Groups	Configuring Pseudowire Tunnels and Tunnel Groups
TDM PseudoWire > Advanced > Profiles	Configuring Pseudowire Profiles
TDM PseudoWire > Advanced > Services	Configuring Pseudowire TDM Services Manually

TDM PseudoWire > Advanced > PM > Service	<i>Displaying Pseudowire Service PMs</i>
TDM > Interfaces > E1/DS1	<i>Configuring the E1/DS1 Parameters (CLI).</i>
TDM > Diagnostics > PDH Loopback	<i>Performing Loopback on E1/DS1s</i>
TDM > PM & Statistics > E1/DS1	<i>Displaying E1/DS1 PMs</i>
TDM > PM & Statistics > Service	<i>Displaying Native TDM Service PMs</i>

Table 9 Web EMS Menu Hierarchy – Radio Menu

Sub-Menus	For Further Information
Radio Parameters	<i>Configuring the Radio Parameters</i> <i>Viewing the Radio Status and Settings</i>
Radio Unit (PTP 820F only)	<i>Configuring the IDU-RFU Connection (PTP 820F only)</i>
Remote Radio Parameters	<i>Configuring the Remote Radio Parameters</i>
Radio BER Thresholds	<i>Configuring BER Thresholds and Displaying current BER</i>
ATPC	<i>Configuring ATPC and Override Timer</i> <i>Configuring ATPC</i>
Payload Encryption (PTP 820G only)	<i>Configuring AES-256 Payload Encryption</i>
Ethernet Interface > Configuration	<i>Configuring Frame Cut-Through</i> <i>Configuring Header De-Duplication</i>
Ethernet Interface > Counters	<i>Viewing Header De-Duplication and Frame Cut-Through Counters</i>
MPMC > Symmetrical Scripts > ETSI	<i>Entering Radio View (CLI)</i> To view and configure radio parameters, you must first enter the radio's view level in the CLI. Use the following command to enter a radio's view level: <pre>root> radio slot <slot> port <port></pre> The following command enters radio view for fixed radio interface 1: <pre>root> radio slot 1 port 1</pre> The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	In	Per	Description
met	pu	mit	
er	t	ted	
	Ty	Val	
	pe	ues	
adm	Va	on	Mutes (on) or unmutes (off) the radio.
in	ria	off	
	bl		
	e		

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 3
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Numeric	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote
disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

Configuring the Radio (MRMC) Script(s)

MRMC >
Symmetrical
Scripts > FCC

Entering Radio View (CLI)

To view and configure radio parameters, you must first enter the radio's view level in the CLI. Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	In	Per	Description
	put	mitted	
	Type	Values	
admin	Variable	on/off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 3
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Numeric	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

Configuring the Radio (MRMC) Script(s)

MRMC > [Displaying MRMC Status](#)
MRMC Status

PM & Statistics > [Displaying Defective Block Counters](#)
> Counters

PM & Statistics > [Displaying Signal Level PMs and Configuring Signal Level PM Thresholds](#)
> Signal Level

PM & Statistics > [Displaying PMs for the Combined IF Combining Signal](#)
> Combined

PM & Statistics > [Displaying Modem BER \(Aggregate\) PMs](#)
> Aggregate

PM & Statistics > [Displaying MSE PMs and Configuring MSE PM Thresholds](#)
> MSE

PM & Statistics > [Displaying XPI PMs and configuring XPI PM Thresholds](#)
> XPI

PM & Statistics > [Displaying MRMC PMs](#)
> MRMC

PM & Statistics > [Displaying Capacity and Throughput PMs](#)
> Traffic >
Capacity/Throughput

PM & Statistics > [Displaying Utilization PMs](#)
> Traffic >
Utilization

PM & Statistics > [Displaying Frame Error Rate PMs](#)
> Traffic >

Frame error rate	
Diagnostics > Loopback	<i>Performing Radio Loopback</i>
Groups > Radio Protection (PTP 820G only)	Configuring HSB Radio Protection
Groups > XPIC	Configuring XPIC
Groups > Multi Carrier ABC	Configuring Multi-Carrier ABC

Table 10 PTP 820G Web EMS Menu Hierarchy – Ethernet Menu

Sub-Menus	For Further Information
General Configuration	<i>Setting the MRU Size and the S-VLAN Ethertype</i> <i>Mapping Ethernet Services to MSTP instances (MSTIs)</i>
Services	Configuring Ethernet Services
Interfaces > Physical Interfaces	<i>Configuring Ethernet Interfaces</i>
Interfaces > Logical Interfaces	<i>Configuring Ingress Path Classification on a Logical Interface</i> <i>Assigning Policers to Interfaces</i> <i>Configuring the Ingress and Egress Byte Compensation</i> <i>Assigning WRED Profiles to Queues</i> <i>Assigning a Queue Shaper Profile to a Queue</i> <i>Assigning a Service Bundle Shaper Profile to a Service Bundle</i> Assigning a Priority Profile to an Interface <i>Assigning a WFQ Profile to an Interface</i> <i>Performing Ethernet Loopback</i>
Interfaces > ASP & LLF	Configuring Automatic State Propagation and Link Loss Forwarding

Sub-Menus	For Further Information
Interfaces > Groups > LAG	Configuring Link Aggregation (LAG) and LACP.
PM & Statistics > RMON	<i>RMON Statistics</i>
PM & Statistics > Egress CoS Statistics	Egress CoS Statistics
PM & Statistics > Port TX	<i>Port TX Statistics</i>
PM & Statistics > Port RX	Port RX Statistics
QoS > Classification > 802.1Q	<i>Modifying the C-VLAN 802.1Q UP and CFI Bit Classification Table</i>
QoS > Classification > 802.1AD	<i>Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table</i>
QoS > Classification > DSCP	<i>Modifying the DSCP Classification Table</i>
QoS > Classification > MPLS	<i>Modifying the MPLS EXP Bit Classification Table</i>
QoS > Policer > Policer Profile	<i>Configuring Policer Profiles</i>
QoS > Marking > 802.1Q	<i>Modifying the 802.1Q Marking Table</i>
QoS > Marking > 802.1AD	<i>Modifying the 802.1AD Marking Table</i>
QoS > WRED > WRED Profile	Configuring WRED
QoS > Shaper > Queue Profiles	<i>Configuring Queue Shaper Profiles</i>
QoS > Shaper > Service Bundle Profiles	<i>Configuring Service Bundle Shaper Profiles</i>
QoS > Scheduler > Priority Profiles	<i>Configuring Priority Profiles</i>
QoS > Scheduler > WFQ Profiles	<i>Configuring WFQ Profiles</i>
Protocols > G.8032 > General Attribute	<i>Configuring the Destination MAC Address</i>
Protocols > G.8032 > ERPI Attribute	<i>Adding ERPIs through Viewing ERPI Statistics</i>
Protocols > MSTP > Bridge > General Attributes	<i>Enabling MSTP and Configuring the MSTP Bridge General Attributes</i>
Protocols > MSTP > Bridge > Configuration ID	<i>Viewing and Configuring the MSTP Bridge Configuration ID</i>
Protocols > MSTP > Bridge > Spanning Tree	<i>Viewing and Configuring the MSTP Bridge Spanning Tree</i>
Protocols > MSTP > Bridge > CIST	<i>Viewing and Configuring the MSTP Bridge CIST Parameters</i>
Protocols > MSTP > Bridge > MSTI	<i>Viewing and Configuring the MSTP Bridge MSTI Parameters</i>

Sub-Menus	For Further Information
Protocols > MSTP > Bridge > VLAN	<i>Viewing the MSTP VLAN Parameters</i>
Protocols > MSTP > Port > Spanning Tree	<i>Viewing and Configuring the MSTP Port Spanning Tree</i>
Protocols > MSTP > Port > CIST	<i>Viewing and Configuring the MSTP Port CIST Parameters</i>
Protocols > MSTP > Port > MSTI	<i>Viewing and Configuring the MSTP Port MSTI Parameters</i>
Protocols > MSTP > Port > BPDU Counters	<i>Viewing and Resetting the BPDU Counters</i>
Protocols > LLDP > Remote Management	<i>Displaying Peer Status</i>
Protocols > LLDP > Advanced > Configuration > Parameters	<i>Configuring the General LLDP Parameters</i>
Protocols > LLDP > Advanced > Configuration > Port Configuration	<i>Configuring the LLDP Port Parameters</i>
Protocols > LLDP > Advanced > Configuration > Destination Address	<i>Displaying the Unit's Management Parameters</i>
Protocols > LLDP > Advanced > Configuration > Management TLV	<i>Displaying the Unit's Management Parameters</i>
Protocols > LLDP > Advanced > Remote System > Management	<i>Displaying Peer Unit's Management Parameters</i>
Protocols > LLDP > Advanced > Remote System > Remote Table	<i>Displaying Peer Unit's Management Parameters</i>
Protocols > LLDP > Advanced > Local System > Parameters	<i>Displaying the Local Unit's Parameters</i>
Protocols > LLDP > Advanced > Local System > Port	<i>Displaying the Local Unit's Parameters</i>
Protocols > LLDP > Advanced > Local System > Management	<i>Displaying the Local Unit's Parameters</i>
Protocols > LLDP > Advanced > Statistic > General	<i>Displaying LLDP Statistics</i>
Protocols > LLDP > Advanced > Statistic > Port TX	<i>Displaying LLDP Statistics</i>
Protocols > LLDP > Advanced > Statistic > Port RX	<i>Displaying LLDP Statistics</i>
Protocols > SOAM > MD	<i>Configuring Service OAM (SOAM) Fault Management (FM)</i>
Protocols > SOAM > MA/MEG	<i>Configuring Service OAM (SOAM) Fault Management (FM)</i>
Protocols > SOAM > MEP	<i>Configuring Service OAM (SOAM) Fault Management (FM)</i>

Sub-Menus	For Further Information
Protocols > LACP > Aggregation	Displaying LACP Aggregation Status Parameters
Protocols > LACP > Port > Status	Displaying LACP Port Status Parameters
Protocols > LACP > Port > Statistics	Displaying LACP Port Statistics
Protocols > LACP > Port > Debug	Displaying LACP Port Debug Statistics

Table 11 PTP 820G Web EMS Menu Hierarchy – Cascading Menu

Sub-Menus	For Further Information
------------------	--------------------------------

Interfaces

Configuring RFU3/SFP5, RFU3/2.5GE5 as an Ethernet or RFU Interface (PTP 820F only)

On PTP 820F, the combo port labelled RFU3/SFP5 (SFP) and RFU3/2.5GE5 (RJ-45) can be configured as either an RFU interface (RFU3) or an Ethernet interface (Eth3). By default, this port is an RFU interface.



Figure: RFU3/SFP5 and RFU3/2.5GE5 Combo Port

To change the port's use from RFU to Ethernet or Ethernet to RFU:

- 1 Set the port's admin state to **Down** in the Interface Manager.
 - If the port is currently configured as an RFU port, it is listed as **Radio: Slot 1, Port 5** in the Interface Manager.
 - If the port is currently configured as an Ethernet port, it is listed as **Ethernet: Slot 1, Port 5** in the Interface Manager.

See [Enabling the Interfaces \(Interface Manager\)](#).
 - 2 In the Radio Unit page, set the Admin status of **Radio Unit: Slot 1, Port 3** to **Down**.
 - 3 If there are any service points attached to the port, remove them.
 - 4 If the port is configured as a Sync source, delete the port as a Sync source.
 - 5 If the port belongs to any interface groups, such as LAG, remove the port from the group.
 - 6 Select **Platform > Interfaces > RFU/Ethernet**. The RFU/Ethernet Interface Configuration page opens.
-




Figure: RFU/Ethernet Interface Configuration Page

7 Select **Radio Unit: Slot 1, Port 3** and click **Edit**. The RFU/Ethernet Interface Configuration – Edit page opens.




Figure: RFU/Ethernet Interface Configuration – Edit Page

8 In the **Interface Type** field, select **RFU** or **Ethernet**.

9 Click **Apply**, then **Close**.

Sub-Menus	For Further Information
	<p>10 If you configured the port as an Ethernet interface, you must set the port's admin state to Up in the Interface Manager. See <i>Enabling the Interfaces (Interface Manager)</i>. If you configured the port as an RFU interface, its admin state is Up automatically.</p> <p>If you configured the port as an Ethernet interface, the port takes the following parameters:</p> <ul style="list-style-type: none"> • Port speed: 1 GE • Media Type: RJ45 • Auto Negotiation: On <p>To change these parameters, go to the Physical Interfaces page. See <i>Configuring Ethernet Interfaces</i>.</p> <p>Note: Both Eth5 and Eth6 can be configured to either 1 GE or 2.5 GE. The other PTP 820F Ethernet ports support 1 GE only.</p> <p>If you configured the port as an RFU interface, make sure to set the Radio Unit parameters as necessary.</p> <p style="text-align: center;">Configuring Cascading Interfaces (Optional)</p>

Table 12 PTP 820G Web EMS Menu Hierarchy – Sync Menu

Sub-Menus	For Further Information
Sync Source	Configuring the Sync Source
Outgoing Clock	<i>Configuring the Outgoing Clock and SSM Messages</i>
1588 > General Configuration	<i>Configuring 1588 Transparent Clock</i> Configuring 1588 Boundary Clock
1588 > Transparent Clock	<i>Configuring 1588 Transparent Clock</i>
1588 > Boundary Clock > Clock Parameters > Default	Configuring 1588 Boundary Clock
1588 > Boundary Clock > Clock Parameters > Advanced	Configuring 1588 Boundary Clock
1588 > Boundary Clock > Port Parameters	Configuring 1588 Boundary Clock

 1588 > Boundary Clock > Port Statistics

[Configuring 1588 Boundary Clock](#)

Table 13 Web EMS Menu Hierarchy – Quick Configuration Menu

Sub-Menus	For Further Information
PIPE > Single Carrier > 1+0	Configuring a 1+0 Link Using the Quick Configuration Wizard
PIPE > Single Carrier > 1+0 (Repeater)	Configuring a 1+0 (Repeater) Link Using the Quick Configuration Wizard
PIPE > Single Carrier > 1+1 (HSB)	Configuring a 1+1 HSB Link Using the Quick Configuration Wizard
PIPE > Multi Carrier ABC > 1+1 (HSB-SD)	Configuring a 1+1 HSB-SD Link Using the Quick Configuration Wizard
PIPE > Multi Carrier ABC > N+0	Configuring an N+0 Multi-Carrier ABC Link Using the Quick Configuration Wizard

Table 14 Web EMS Menu Hierarchy – Utilities Menu

Sub-Menus	For Further Information
Restart HTTP	Restarting the HTTP Server
ifIndex Calculator	Calculating an ifIndex
MIB Reference Guide	Displaying, Searching, and Saving a list of MIB Entities

Chapter 2: Getting Started

This section includes:

- [Assigning IP Addresses in the Network](#)
- [Establishing a Connection](#)
- [Logging On](#)
- [Changing Your Password](#)
- [Performing Quick Platform Setup](#)
- [Configuring In-Band Management](#)
- [Changing the Management IP Address](#)
- [Configuring Unit Redundancy for the PTP 820G](#)
- [Determining ETSI or ANSI \(FCC\) TDM Mode](#)
- [Configuring the Activation Key](#)
- [Setting the Time and Date \(Optional\)](#)
- [Enabling the Interfaces \(Interface Manager\)](#)
- [Configuring RFU3/SFP5,RFU3/2.5GE5 as an Ethernet or RFU Interface\(PTP 820F only\)](#)

On PTP 820F, the combo port labelled RFU3/SFP5 (SFP) and RFU3/2.5GE5 (RJ-45) can be configured as either an RFU interface (RFU3) or an Ethernet interface (Eth3). By default, this port is an RFU interface.



Figure: RFU3/SFP5 and RFU3/2.5GE5 Combo Port

To change the port's use from RFU to Ethernet or Ethernet to RFU:

- 1 Set the port's admin state to **Down** in the Interface Manager.
 - If the port is currently configured as an RFU port, it is listed as **Radio: Slot 1, Port 5** in the Interface Manager.
 - If the port is currently configured as an Ethernet port, it is listed as **Ethernet: Slot 1, Port 5** in the Interface Manager.

See Enabling the Interfaces (Interface Manager).
- 2 In the Radio Unit page, set the Admin status of **Radio Unit: Slot 1, Port 3** to **Down**.
- 3 If there are any service points attached to the port, remove them.
- 4 If the port is configured as a Sync source, delete the port as a Sync source.
- 5 If the port belongs to any interface groups, such as LAG, remove the port from the group.
- 6 Select **Platform > Interfaces > RFU/Ethernet**. The RFU/Ethernet Interface Configuration page opens.




Figure: RFU/Ethernet Interface Configuration Page

7 Select **Radio Unit: Slot 1, Port 3** and click **Edit**. The RFU/Ethernet Interface Configuration – Edit page opens.




Figure: RFU/Ethernet Interface Configuration – Edit Page

- 8 In the **Interface Type** field, select **RFU** or **Ethernet**.
- 9 Click **Apply**, then **Close**.
- 10 If you configured the port as an Ethernet interface, you must set the port’s admin state to **Up** in the Interface Manager. See *Enabling the Interfaces (Interface Manager)*. If you configured the port as an RFU interface, its admin state is **Up** automatically.

If you configured the port as an Ethernet interface, the port takes the following parameters:

- Port speed: 1 GE
- Media Type: RJ45
- Auto Negotiation: On

To change these parameters, go to the Physical Interfaces page. See *Configuring Ethernet Interfaces*.

Note: Both Eth5 and Eth6 can be configured to either 1 GE or 2.5 GE. The other PTP 820F Ethernet ports support 1 GE only.

If you configured the port as an RFU interface, make sure to set the Radio Unit parameters as necessary.

- Configuring Cascading Interfaces (Optional)
- [Configuring the Radio Parameters](#)
- [Entering Radio View \(CLI\)](#)
- [To view](#) and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- [Configuring the Radio \(MRMC\) Script\(s\)](#)
- [Enabling ACM with Adaptive Transmit Power](#)
- [Operating in FIPS Mode](#)
- [Configuring Grouping \(Optional\)](#)
- [Creating Service\(s\) for Traffic](#)

Assigning IP Addresses in the Network

Before connection over the radio hop is established, it is of high importance that you assign each network element a dedicated IP address, according to an IP plan for the total network. See [Changing the Management IP Address](#).

By default all elements have the same IP settings:

- IP address: 192.168.1.1
- Subnet mask: 255.255.255.0

**Caution**

If the connection over the link is established with identical IP addresses, an IP address conflict will occur and remote connection to the element on the other side of the link may be lost.

Establishing a Connection

You can connect to the PTP 820G or PTP 820F unit via a serial or a LAN connection.

Connecting to the Unit with a Serial Connection

- 1 Connect a serial RS-232 cable with an RJ-45 interface from the laptop or PC you are using to configure the unit, to the Terminal Interface on the front panel.

Figure 17 Terminal Interface on Front Panel – PTP 820F





Figure 18 Terminal Interface on Front Panel – PTP 820G



- 2 Configure the following settings for the COM port you are using on your PC or laptop:
 - Bits per Second – 115,200
 - Data Bits – 8
 - Parity – None
 - Stop Bits – 1
 - Flow Control - None

Connecting to the Unit with a LAN Connection

PTP 820G and PTP 820F contain two FE management interfaces, which connect to a single RJ-45 physical connector on the front panel (MGMT). For details on which type of cable to use to utilize either one or both management interfaces, see [Ethernet Management Interfaces](#).

Connect the cable to the Management interface (MGMT) on the PTP 820G or PTP 820F front panel, and to the LAN port on the PC.

Figure 19 Management Interface on Front Panel PTP 820F




Figure 20 Management Interface on Front Panel PTP 820G



To establish a connection with the PTP 820G or PTP 820F unit, it is necessary to configure an IP address on the PC or laptop within the same subnet as the PTP 820G or PTP 820F unit. The default chassis IP address is 192.168.1.1. For example, you can set the PC or laptop address to 192.168.1.10 and the subnet mask to 255.255.255.0. Note the initial settings before changing.



Note

The chassis IP address, as well as password, should be changed before operating the system. See [Changing the Management IP Address](#) and [Changing Your Password](#).

- 3 Select Control Panel > All Control Panel Items > Network and Sharing Center.
- 4 Click Change adapter settings.

- 5 Select Local Area Connection > Properties> Internet Protocol Version 4 (TCP/IP) and set the following parameters:
 - IP address: 192.168.1.10
 - Subnet mask 255.255.255.0
 - No default gateway
- 6 Click **OK** to apply the settings.

Logging On

- 1 Open an Internet browser (Internet Explorer, Mozilla Firefox, or Google Chrome).
- 2 Enter the default IP address "**192.168.1.1**" in the Address Bar. The Login page opens.

Figure 21 Login Page



Microwave radio: Login

User Name

Password

- 3 Enter the following values:
 - User Name: admin
 - Password: admin
- 4 Click Apply.

Changing Your Password

It is recommended to change the default Admin password as soon as you have logged into the system.

In addition to the Admin password, there is an additional password protected user account, “root user”, which is configured in the system. The root user password and instructions for changing this password are available from Cambium Networks Customer Support. It is strongly recommended to change this password.

To change your password:

1. Select **Platform > Security > Access Control > Change Password**. The Change User Password page opens.

Figure 22 Change User Password Page

The screenshot shows a web interface for changing a user password. On the left is a navigation menu with categories like Unit Summary, Radio Summary, Platform, Management, Software, Configuration, Activation Key, Security, and Utilities. The 'Security' section is expanded, and 'Change Password' is selected. The main area is titled 'Microwave radio: Change User Password' and contains a form with the following fields: 'User Name' (with 'admin' entered), 'Old password', 'New Password', and 'Reenter Password'. Below the form are 'Apply' and 'Clear' buttons.

2. In the **Old password** field, enter the current password. For example, upon initial login, enter the default password (**admin**).
3. In the **New password** field, enter a new password. If **Enforce Password Strength** is activated (see [Configuring the Password Security Parameters](#)), the password must meet the following criteria:
 - o Password length must be at least eight characters.
 - o Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
 - o The last five passwords you used cannot be reused
4. Click Apply.

Performing Quick Platform Setup

The Platform Setup page in the Web EMS centralizes the main configurable items from several Web EMS pages in a single location:

- Unit Parameters (Name, Contact Person, Location, Longitude, and Latitude)
- IPv4 Address, Subnet Mask, and Default Gateway
- NTP Enable/Disable
- Demo Activation Key Enable/Disable
- SNMP Parameters

These items enable you to configure the basic platform parameters quickly, in a single Web EMS page. Combined with the quick link configuration wizards, this enables you to configure a new link in the field quickly and efficiently, to the point where the link is up and functioning and any necessary advanced configurations can be performed remotely without the need to physically access the PTP 820 unit.

To use the Platform Setup page:

1. Select **Quick Configuration > Platform Setup**. The Quick Configuration – Platform Setup page opens.

Figure 23 Quick Configuration – Platform Setup Page

The screenshot shows the 'Microwave radio: Quick Configuration - Platform Setup' page. The left sidebar contains a navigation menu with the following items: Unit Summary, Radio Summary, Platform, Faults, TDM, Radio, Ethernet, Cascading, Sync, Quick Configuration (selected), From File, Platform Setup (highlighted), PIPE, and Utilities. The main content area is titled 'Microwave radio: Quick Configuration - Platform Setup' and contains the following sections:

- Unit Parameters:** Name (Microwave radio), Contact person, Location, Longitude, Latitude.
- IPv4 Address:** IPv4 Address (192.168.1.85), IPv4 Subnet Mask (255.255.255.0), IPv4 Default Gateway (0.0.0.0).
- Date & Time:** NTP Admin (Disable). A note states: 'Time and Date value will be taken automatically from client local time.'
- Activation Key:** Demo admin (Disable). A text area contains a long alphanumeric key.
- SNMP Parameters:** Admin (Enable), SNMP Read Community (public), SNMP Write Community (private).

At the bottom of the page are '<< Back' and 'Finish' buttons.

2. The Unit Parameters section is optional. For details on each field, see [Configuring Unit Parameters](#).
3. In the IPv4 Address section, configure the unit's management IP address, subnet mask, and, optionally, a default gateway. If you want to use an IPv6 address, see [Changing the Management IP Address](#).
4. In the Date & Time section, you can enable Network Time Protocol (NTP). NTP distributes Coordinated Universal Time (UTC) throughout the system, using a jitter buffer to neutralize the effects of variable latency.

If you select **Enable**, the **NTP version** and **NTP server IP address** fields are also displayed, enabling you to configure the NTP parameters. For details on these fields, [Configuring NTP](#).

The close-up shows the 'Date & Time' section with the following configuration:

- NTP Admin: Enable
- NTP version: NTPv4
- NTP server IP address: 0.0.0.0

5. In the Activation Key section, you can enable or disable Demo mode in the **Demo admin** field. Demo mode enables all features for 60 days. When demo mode expires, the most recent valid activation key goes into effect. The 60-day period is only counted when the system is powered up. 10 days before demo mode expires, an alarm is raised indicating that demo mode is about to expire.

If you set **Demo admin** to **Disable**, the Activation Key field is displayed. Enter a valid activation key in this field. For a full explanation of activation keys, see [Configuring the Activation Key](#).




Activation Key

Demo admin

Activation Key

- In the **SNMP Parameters** section, you can set whether to enable or disable SNMP monitoring in the **Admin** field, and set the **SNMP Read Community** and **SNMP Write Community**. For a full explanation of SNMP parameters, see [Configuring SNMP \(CLI\)](#).



SNMP Parameters


Admin

SNMP Read Community

SNMP Write Community

6. Click **Finish**. The Selection Summary page opens. To go back and change any of the parameters, click **Back**. To implement the new parameters, click **Submit**.

Figure 24 Quick Configuration – Platform Setup Summary Page



Configuring In-Band Management

You can configure in-band management in order to manage the unit remotely via its radio and/or Ethernet interfaces.

Each PTP 820G or PTP 820F unit includes a pre-defined management service with Service ID 1025. The management service is a multipoint service that connects the two local management ports and the network element host CPU in a single service. In order to enable in-band management, you must add at least one service point to the management service, in the direction of the remote site or sites from which you want to access the unit for management. For instructions on adding service points, see [Configuring Service Points](#).

**Note**

In order to use in-band management, it must be supported on the external switch.

Changing the Management IP Address

Related Topics:

- [Defining the IP Protocol Version for Initiating Communications](#)
- [Configuring the Remote Unit's IP Address](#)

To change the management IP address of the local unit:

- 1 Select **Platform > Management > Networking > Local**. The Local Networking Configuration page opens.

Figure 25 Local Networking Configuration Page

- 2 Optionally, in the **Name** field, enter a name for the unit.
- 3 Optionally, in the **Description** field, enter descriptive information about the unit.
- 4 In the **IPv4 address** field, enter an IP address for the unit. You can enter the address in IPv4 format in this field, and/or in IPv6 format in the **IPv6 Address** field. The unit will receive communications whether they are sent to its IPv4 address or its IPv6 address.
- 5 If you enter an **IPv4** address In the **IPv4 Subnet mask** field, enter the subnet mask.
- 6 Optionally, in the **IPv4 Default gateway** field, enter the default gateway address.
- 7 Optionally, in the **IPv6 Address** field, enter an IPv6 address for the unit. You can enter the address in IPv6 format in this field, and/or in IPv4 format in the **IPv4 IP Address** field. The unit will receive communications whether they are sent to its IPv4 address or its IPv6 address.
- 8 If you entered an IPv6 address, enter the IPv6 prefix length in the **IPv6 Prefix-Length** field.
- 9 Optionally, if you entered an IPv6 address, enter the default gateway in IPv6 format in the **IPv6Default Gateway** field.

10 Click **Apply**.

Configuring Unit Redundancy for the PTP 820G

This section explains how to configure unit redundancy for the PTP 820G, and includes the following topics:

- [Unit Redundancy Overview](#)
- [Configuring Unit Redundancy](#)
- [Cabling Requirements for Unit Redundancy](#)
- [Configuring Ethernet Interface Protection](#)
- [Enabling Unit Redundancy](#)
- [Changing the Configuration after Enabling Unit Redundancy](#)
- [Viewing the Configuration of the Standby Unit](#)
- [Viewing Link and Protection Status and Activity](#)
- [Switchover](#)
- [Performing Lockout](#)
- [Disabling Unit Redundancy](#)

Unit Redundancy Overview



Note

The following protocols cannot be used with unit redundancy:

- G.8032
 - MSTP
 - LLDP
 - Service OAM (SOAM)
-

Unit redundancy utilizes two PTP 820G units, with a single antenna, to provide hardware protection for the PTP 820G IDU and RFU, including protection for Ethernet, radio, and TDM interfaces. One PTP 820G operates in active mode and the other operates in standby mode. If a protection switchover occurs, the roles are switched. The standby unit is managed by the active unit. The standby unit's transmitter is muted, but the standby unit's receiver is kept on in order to monitor the link. However, the received signal is terminated at the switch level.

There are three modes for Ethernet interface protection with PTP 820G unit redundancy:

- **Line Protection Mode** – Traffic is routed to the Ethernet interfaces via two interfaces on an external switch. LACP protocol is used to determine which PTP 820G port is active and which port is standby, and traffic is only forwarded to the active port. Line Protection mode can be used with optical and electrical Ethernet interfaces.

**Note**

- The external switch must support LACP. PTP 820G supports LACP for purposes of line protection only. PTP 820G supports a special LACP implementation for purposes of line protection only. This LACP implementation is configured on the logical interface level, as described in *Configuring Ethernet Interface Protection*. Regular LACP is configured as part of the LAG configuration, and is not supported with unit redundancy. See [Configuring Link Aggregation \(LAG\)](#).

- **Optical Splitter Mode** – An optical splitter cable is used to connect both the active and the standby Ethernet ports. Optical Splitter mode can be used with optical Ethernet interfaces only.
- **Electrical Splitter Mode** – A Y-cable is used to connect to both the active and the standby Ethernet ports. With Electrical Splitter mode, interface protection is only supported for speeds up to 100 Mbps (Fast Ethernet). Electrical Splitter Mode can be used with electrical Ethernet interfaces only.

**Note**

When using the Y-cable with Electrical Splitter mode and Auto Negotiation enabled, there is a traffic disruption of approximately two seconds upon switchover for Ethernet traffic passing through this cable.

PTP 820G unit redundancy can be used with the following radio configurations:

- 2 x 1+0 – PTP 820G unit with a 1+0 configuration protecting another PTP 820G unit with a 1+0 configuration.
- 2 x 2+0 – PTP 820G unit with a 2+0 configuration protecting another PTP 820G unit with a 2+0 configuration.

To configure 2 x 2+0 protection, simply configure the two radios according to your network requirements, then configure unit redundancy according to the instructions in this section.

To configure unit redundancy, you must perform the following steps:

1. Verify that the proper cables for unit redundancy are connected to the units. See [Cabling Requirements for Unit Redundancy](#).
2. Configure Ethernet interface protection. See [Configuring Ethernet Interface Protection](#).
3. Enable unit redundancy. See [Enabling Unit](#).

The Unit ACT LED on each unit indicates whether the unit is Active (Green) or Standby (Orange). See [Unit/ACT LED](#).

Configuring Unit Redundancy

Before configuring unit redundancy, verify that both units have the same hardware part number (see [Displaying Unit Inventory](#)) and the same software version (see [Viewing Current Software Versions](#)). If the units do not have the same software version, upgrade each unit to the most recent software release.

To configure unit redundancy, you must perform the following steps:

- Verify that the PC or laptop being used to configure the devices is directly connected to the management port of the unit that will be the active unit.

- Configure the unit that will be the active unit so that it will have a working radio link by performing all necessary radio configurations, such as configuring the MRMC scripts, setting the frequency, unmuting the radio, and setting up radio groups such as XPIC or Multi-Carrier ABC (Multi-Radio).
- Perform all necessary Ethernet and TDM configurations on the unit that will be the active unit, such as defining Ethernet and TDM services.
- Resolve any alarms in the unit that will be the active unit, so that there are no active alarms raised.
- Configure Ethernet interface protection on the unit that will be the active unit. See [Configuring Ethernet Interface Protection](#). Power up the unit that will be the standby unit.
- Connect the management PC or laptop to the management port of the standby unit.
- Enable unit redundancy on the unit that will be the standby unit. See [Enabling Unit Redundancy](#).
- Connect the PC or laptop again to the management port of the unit that will be the active unit.
- Enable unit redundancy on the unit that will be the active unit. See [Enabling Unit Redundancy](#).
- Verify that the proper cables for unit redundancy are connected to the units. See [Cabling Requirements for Unit Redundancy](#). Note that the first unit you configured should automatically be assigned by the system to be the active unit because it will have no alarms. In contrast, the second unit will have at least one alarm since you have not yet changed its settings from the default settings.
- On the active unit, verify that the connection to the standby unit is up. To do this, go to the Unit Redundancy page and verify that:
 - The **Protection Operation State** is **Up**.
 - The **Protection Link to Mate Status** is **Connected**.
 - Go to the Unit Redundancy page in the active unit, and click **Copy to Mate** to copy the configuration of the active unit to the standby unit. Confirm the action in the confirmation window that appears.
 - Once the standby unit comes back online, perform final checks to verify that unit redundancy has been configured properly:
 - Check the port status on the standby unit.
 - Check the radio link status on the standby unit.
 - Verify that there is no Configuration Mismatch alarm. See [Changing the Configuration after Enabling Unit Redundancy](#).
 - Verify that no other alarms are raised on either unit.

Cabling Requirements for Unit Redundancy

Cabling for Ethernet Interfaces

For Ethernet Splitter Mode, the following Y-cable must be connected to the relevant interfaces on the active and standby units:

Table 15 Y-Cable for Electrical Splitter Mode FE Traffic Interface Protection

Part Number	Description
C000082L153A	PTP 820G Fast Ethernet Protection Y-cable, 1.34m, Cat5E

No special cabling is required for other Ethernet protection modes.

Cabling for E1/DS1 Interfaces

If the E1/DS1 interfaces are being used, a Y-cable is used to connect the active and standby E1/DS1 interfaces. The following table shows the Part Number and Marketing Model of the Y-cable required for E1/DS1 protection.

Table 16 Y-Cable for E1/DS1 Protection

Part Number	Description
C000082L154A	PTP 820G TDM Protection Y cable, 0.6m,120 ohm

Cabling for T3 Synchronization

If T3 synchronization input is being used, a Y cable is used to connect to the active and standby Sync interfaces.


Inter-IDU Protection Connectivity and Management

PTP 820G units in a redundancy configuration must have their CPUs interconnected in order to synchronize their protection status. The same IP address is used for both PTP 820G units, to ensure that management is not lost in the event of switchover. A special cable is required to enable this connectivity.

Table 17 Splitter Cable for Protection and Management

Part Number	Description
C000082L155A	PTP820G Splitter cable for protection and management, 1.34m,CAT5E

The protection and management splitter cable must be connected to the management interfaces of the two PTP 820G units using the RJ-45 plug-ends. The third end of the protection splitter cable (RJ-45 socket) is connected to an external management station.

Figure 26 PTP 820G with Unit Redundancy – Protection and Management Splitter Connection

The local management connection uses PTP 820G management interface 1. The LED on the upper left of the MGMT port is Green when the interface is enabled and the link is operational. See [Ethernet Management Interface LEDs](#).

The inter-unit protection connection uses PTP 820G management interface 2. The LED on the upper right of the MGMT port is Green when the interface is enabled and the link between the IDUs is operational. See [Ethernet Management Interface LEDs](#).

Configuring Ethernet Interface Protection

No special software configuration is required for Optical Splitter and Electrical Splitter modes.

For Line Protection mode, you must perform the following steps:

1. Configure the GbE ports on the external switch in LACP mode. The external switch must support LACP.
2. Connect a GbE port on the external switch to a GbE port on each of the PTP 820G units.
3. Enable LACP on the GbE ports on the PTP 820G that are connected to the external switch:
 - i. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 214](#)).
 - ii. Select the interface and click **Edit**. The Logical Interfaces – Edit page opens.

Figure 27 Logical Interfaces – Edit Page

- iii. In the **Interface Mode** field, select **LACP**.
- iv. Click **Apply**, then **Close**.
- v. Reset the unit. See [Performing a Hard \(Cold\) Reset \(CLI\)](#).


**Note**

Because a unit reset is required when changing the Interface Mode to or from LACP, it is recommended to perform copy-to-mate immediately after changing the Interface Mode to or from LACP, then to reset the active unit only after the standby unit is back up after the copy-to-mate operation.

Enabling Unit Redundancy

To enable unit redundancy:

1. Select **Platform > Management > Unit Redundancy**. The Unit Redundancy page opens.

Figure 28 Unit Redundancy Page


Logout Connection Admin

Filter

Main View

- Platform
 - Management
 - Unit Parameters
 - NTP Configuration
 - Time Services
 - Interface Manager
 - Inventory
 - Unit Info
 - Reset
 - Set to Factory Default
 - Unit Redundancy
 - External Alarms
 - Networking
 - SNMP
 - Software
 - Configuration
 - Activation Key
 - Security
- Faults
- TDM
- Radio
- Ethernet
- Cascading
- Sync
- Quick Configuration
- Utilities

Active, Microwave radio: Unit Redundancy

Active Standby

Unit Redundancy

Protection Operational State

Protection Activity

Protection Link to Mate status

Copy to mate status

Protection Admin

Lockout

Apply Manual Switch Force Switch Copy to Mate

Warning: 'Copy to Mate' involves Mate unit reboot. A temporary loss of management connection may be expected.

- In the **Protection Admin** field, select **Enable**.
- Click **Apply**.

The system configures itself for unit redundancy:

- The system determines which unit is the Active unit based on a number of pre-defined criteria. To see which unit is the active unit, look at the traffic interface LEDs; only the interfaces on the active unit should be indicated by their LEDs as active and functioning.
- When the system returns online, all management must be performed via the Active unit using the IP address you defined for that unit.
- The IP address you defined for the unit which is now the Standby unit is no longer valid, and the management port of the Standby unit becomes non-operational. Note, however, that if switchover takes place before you perform copy-to-mate (Step 5- v), the original IP of the Standby unit, now the Active unit, becomes the working IP for management of both units.
- Management of the Standby unit is performed via the Active unit, via the protection cable. Protection communications are transmitted via Management port 2 in each unit, which is no longer usable or configurable as a management port.



Note

An PTP 820G unit on which (i) unit redundancy is enabled, (ii) there is no radio link, and (iii) no mate unit is connected, will automatically be selected as a standby unit when booting up. As a result, management to the unit will be lost.

In addition, almost every Web EMS page will now include two tabs on top of the main section of the page.

- **Active** – Enables you to configure the Active unit.
- **Standby** – In most cases, this tab is read-only and enables you to display Standby unit parameters. Even when a switchover occurs, the unit displayed in the Web EMS is always the currently Active unit.

Changing the Configuration after Enabling Unit Redundancy

To keep the Standby unit up-to-date, after any change to the configuration of the Active unit click **Copy to Mate** to copy the configuration to the Standby unit.

If you change the configuration of the Active unit but do not perform **Copy to Mate**, a Configuration Mismatch alarm appears in the **Faults > Current Alarms** page.

Note: You can use the following CLI command to display a list of mismatched parameters:

```
root> platform management protection show mismatch details
```

The following items must be configured separately for the Standby unit, and are not copied via copy-to-mate:


- Setting the Unit Name – See [Configuring Unit Parameters](#).
- Disabling/enabling Radio TX mute – See [Configuring the Radio Parameters](#).
- Clearing the Radio and RMON counters – See [Configuring and Viewing Radio PMs and Statistics](#) and [Viewing Ethernet PMs and Statistics](#).
- Configuring the activation key – See [Configuring the Activation Key](#).

When configuring MRMC scripts after enabling unit redundancy, it should be done in the following order. It is important to use this order because if the changes are not performed in the correct order, the connection to the remote units will be lost:

1. Change the MRMC script on the standby unit of the remote pair.
2. Change the MRMC script on the active unit of the remote pair. This will cause the local-remote link to be lost.
3. Change the MRMC script on the active unit of the local pair. When the unit reboots, the local-remote link will be restored.
4. Perform copy-to-mate on the active unit of the local pair.

Viewing the Configuration of the Standby Unit

You can view the settings of the standby unit any time. To view the settings of the standby unit, click the **Standby** tab of the desired page. The following is an example of the **Standby** tab of the Unit Redundancy page after **Protection Admin** has been enabled.

Figure 29 Standby Tab of Unit Redundancy Page

Viewing Link and Protection Status and Activity

You can view link and protection status and activity any time.

To view link and protection status and activity:

Select **Platform > Management > Unit Redundancy**. The Unit Redundancy page opens ([Figure 32](#)).

The following information is displayed:

- **Protection Operational State** – Indicates whether unit redundancy is functional. Radio protection is not functional if the management connection to the mate is down.
- **Protection Activity** – The activity state of the device: Active or Standby.
- **Protection Link to Mate** – Indicates whether the two units (the Active and the Standby) are physically connected.
- **Copy to mate status** – Indicates the status of the last copy-to-mate operation
- **Protection Admin** – Indicates whether unit redundancy is enabled or disabled.
- **Lockout** – Indicates whether lockout is enabled or disabled.

Switchover

The following events trigger switchover for unit redundancy according to their priority, with the highest priority triggers listed first.

1. Loss of active unit
2. Force switch

3. Lockout
4. Radio Loss of Frame (LOF) on active unit
5. Change request from the remote unit. This takes place in the event of radio LOF on both units; a change request is sent to the active unit on the other side of the link.
6. Loss of Carrier (LOC) in any of the Ethernet interfaces or Loss of Signal (LOS) in any of the TDM interfaces
7. Manual switch

LOC takes place if the Admin status of the interface is Enabled and the Operational status is Down. If the interface is closed as a result of ASP, the interface is *not* considered to be in LOC state, and switchover is not triggered.

Following switchover triggered by LOC, there is an automatic timeout of one minute before any further switchover can take place due to LOC.

At any point, you can manually switch to the standby unit, provided that the highest protection fault level in the standby unit is no higher than the highest protection fault level on the active unit.

You can also perform a force switch to the standby unit, even if the protection fault level is higher in the standby unit. Force switch also implements lockout.

To perform a manual switch or force switch:

1. Select **Platform > Management > Unit Redundancy**. The Unit Redundancy page opens.
2. Click **Manual Switch** or **Force Switch**.
3. Confirm the action in the confirmation window that appears.

Performing Lockout

At any point, you can perform lockout, which prevents switchover to the standby unit in all cases other than a force switch.

To perform lockout:

1. Select **Platform > Management > Unit Redundancy**. The Unit Redundancy page opens.
2. In the **Lockout** field, select **on**.
3. Click **Apply**.

To release lockout, select **off** in the **Lockout** field and then click **Apply**.

Disabling Unit Redundancy

You can disable unit redundancy at any time.

To disable protection:

1. Select **Platform > Management > Unit Redundancy**. The Unit Redundancy page opens.
2. Select **Disable** in the **Protection Admin** field.
3. Click **Apply**.

If in-band management is being used, unit redundancy must be disabled in the following order to ensure that management is not lost:

1. Disable unit redundancy in the active unit of the remote pair. The link remains up and no switchover takes place.

2. Change the IP address of the active remote unit.
3. Disable all active traffic interfaces on the active remote unit. This should be performed in a single action by selecting all of the relevant interfaces in the Interface Manager page and selecting **Down > Apply in the Multiple Selection Operation** box. See [Enabling the Interfaces \(Interface Manager\)](#). This causes switchover on the remote pair.
4. Disable unit redundancy in the active unit of the local pair. The link remains up and no switchover takes place.
5. Change the IP address of the active local unit.
6. Disable all active traffic interfaces on the active local unit. This should be performed in a single action by selecting all of the relevant interfaces in the Interface Manager page and selecting **Down > Apply** in the Multiple Selection Operation box. See [Enabling the Interfaces \(Interface Manager\)](#). This causes switchover on the local pair.
7. Disable unit redundancy on both the remote and the local units that were the standby units and have now become the active units.

**Note**

On some occasions, in links with TDM traffic, if you disable unit redundancy then re-enable unit redundancy later, a TDM-LIC configuration mismatch alarm may be raised (Alarm ID 2002). If this happens, you must reset the unit with the alarm, then perform copy-to-mate.

Determining ETSI or ANSI (FCC) TDM Mode

By default, the TDM interfaces in a PTP 820G or PTP 820F unit are set to operate according to the ETSI standard, in E1 mode. For instructions on configuring the system to operate according to the ANSI (FCC) standard (DS1), see [Configuring the Unit to Operate in ANSI Mode \(CLI\)](#)

If you must change the system to ANSI mode, you should do so before performing any other configuration, because changing to ANSI mode resets the system and restores the default configuration.

Configuring the Activation Key

PTP 820G and PTP 820F offers a pay as-you-grow concept in which future capacity growth and additional functionality can be enabled with activation keys. For purposes of the activation keys, each PTP 820G/F unit is considered a distinct device. Each device contains a single unified activation key cipher.

New PTP 820G and PTP 820F units are delivered with a default activation key that enables you to manage and configure the unit. Additional feature and capacity support requires you to enter an activation key cipher in the Activation Key Configuration page. Contact your vendor to obtain your activation key cipher.

**Note**

To obtain an activation key cipher, you may need to provide the unit's serial number. You can display the serial number in the Web EMS Inventory page. See [Displaying Unit Inventory](#).

Each required feature and capacity should be purchased with an appropriate activation key. It is not permitted to enable features that are not covered by a valid activation key. In the event that the activation-key-enabled capacity and feature set is exceeded, an Activation Key Violation alarm occurs and the Web EMS displays a yellow background and an activation key violation warning. After a 48-hour grace period, all other alarms are hidden until the capacity and features in use are brought within the activation key's capacity and feature set.

In order to clear the alarm, you must configure the system to comply with the activation key that has been loaded in the system. The system automatically checks the configuration to ensure that it complies with the activation-key-enabled features and capacities. If no violation is detected, the alarm is cleared.

A demo activation key is available that enables all features for 60 days. When the demo activation key expires, the most recent valid activation key goes into effect. The 60-day period is only counted when the system is powered up. 10 days before the demo activation key expires, an alarm is raised indicating that the demo activation key is about to expire.

Viewing the Activation Key Status Parameters

To display the current activation key status parameters:

- 1 Select **Platform > Activation Key > Activation Key Configuration**. The Activation Key Configuration page opens.

Figure 30 Activation Key Configuration Page




Table 18 Activation Key Status Parameters

Parameter	Definition
Type	Displays the current activation key type.
Validation number	Displays a random, system-generated validation number.
Date code	Displays a date code used for validation of the current activation key cipher.
Violation runtime counter (hours)	In the event of an Activation Key Violation alarm, this field displays the number of hours remaining in the 48-hour activation key violation grace period.
Sanction state	If an Activation Key Violation alarm has occurred, and the 48-hour activation key violation grace period has expired without the system having been brought into conformance with the activation-key-enabled capacity and feature set, Yes appears in this field to indicate that the system is in an Activation Key Violation sanction state. All other alarms are hidden until the capacity and features in use are brought within the activation-key-enabled capacity and feature set.

Entering the Activation Key

To enter a new activation key:

- 1 Select **Platform > Activation Key > Activation Key Configuration**. The Activation Key Configuration page opens (Figure 30).
- 2 Enter the activation key cipher you have received from the vendor in the **Activation Key** field. The activation key cipher is a string that enables all features and capacities that have been purchased for the unit.
- 3 Click **Apply**.

If the activation key cipher is not legal (e.g., a typing mistake or an invalid serial number), an Activation Key Loading Failure event is sent to the Event Log. When a legal activation key cipher is entered, an Activation Key Loaded Successfully event is sent to the Event Log.

Activating a Demo Activation Key

To activate a demo activation key:

- 1 Select **Platform > Activation Key > Activation Key Configuration**. The Activation Key Configuration page opens (Figure 30).
- 2 In the **Demo admin** field, select **Enable**.
- 3 Click **Apply**.

The **Demo timer** field displays the number of hours that remain before the demo activation key expires.

Displaying a List of Activation-Key-Enabled Features

To display the status of activation key coverage for features and capacities in the PTP 820G:

- 1 Select **Platform > Activation Key > Activation Key Overview**. The Activation Key Overview page opens.

Figure 31 Activation Key Overview Page

#	Feature Id	Feature name	Feature description	Activation key-enabled feature usage	Activation key-enabled feature credit	Activation key violation status
1	10	Per Usage	Post paid model for the activation key	Disable	Disable	OK
2	100	Services Mode	Service mode: Smart-Pipe, Edge-CET-Node, Agg-Lvl-1-CET-Node, Agg-Lvl-2-CET-Node	Not used	Edge-CET-Node	OK
3	200	Number of Services	Number of allowed Ethernet services	0	8	OK
4	300	H-QoS	Hierarchical QoS (Quality of Service)	Not used	Allowed	OK
5	500	Network Resiliency	Network resiliency protocols (Smart-TDM Path Protection, G.8032)	Not used	Not allowed	OK
6	600	Ethernet OAM - Fault Management	Enables Connectivity Fault Management (FM) per Y.1731/ 802.1ag and 802.3ah (CET mode only)	Not used	Allowed	OK
7	650	Ethernet OAM - Performance Monitoring	Ethernet OAM (Operation Administration and Maintenance) Performance Monitoring (PM) - Y.1731	Not used	Allowed	OK
8	800	LACP	Link Aggregation Control Protocol (LACP)	Not used	Allowed	OK
9	1100	Sync Unit	ITU-T G.8262 SyncE and ITU-T G.8264 ESMC (Ethernet Synchronization Message Control)	Not used	Not allowed	OK
10	1202	IEEE1588 Transparent Clock	Synchronization over Packet	Not used	Not allowed	OK
11	1300	IEEE1588 Ordinary Clock (quantity)	The allowed number of IEEE1588v2 (PTP - Precision Time Protocol) Ordinary Clocks (OC)	Not used	0	OK
12	1400	IEEE1588 Boundary Clock	IEEE1588v2 (PTP - Precision Time Protocol) Boundary Clocks (BC)	Not used	Not allowed	OK
13	1600	Main card redundancy	Redundancy of the main card	Not used	Not allowed	OK
14	1700	TDM Pseudowire	TDM Pseudowire support	Not used	Allowed	OK
15	1800	Frame cut-through	Frame cut-through capability	Not used	Allowed	OK
16	2100	Secured Management	Secured protocols: SSH, SFTP, HTTPS, RADIUS, SNMPv3	Not used	Not allowed	OK
17	2200	FE traffic ports (quantity)	The allowed number of FE (Fast Ethernet) ports	0	11	OK
18	2300	GbE traffic ports (quantity)	The allowed number of GbE (Gigabit Ethernet) ports	0	13	OK
19	2400	10GbE traffic ports (quantity)	The allowed number of 10GbE (10 Gigabit Ethernet) ports	0	10	OK

The Activation Key Overview page displays the activation-key-enabled features and capacities for the PTP 820G or PTP 820F, and indicates the activation key status of each feature according to the activation key currently implemented in the unit.

**Note**

Some of the features listed in the Activation Key Overview page may not be supported in the currently installed software version.

Table 19 Activation Key Status Parameters

Parameter	Definition
Feature ID	A unique ID that identifies the feature.
Feature name	The name of the feature.
Feature Description	A description of the feature.
Activation key-enabled feature usage	Indicates whether the activation-key-enabled feature is actually being used.
Activation key-enabled feature credit	Indicates whether the feature is allowed under the activation key that is currently installed in the unit.
Activation key violation status	Indicates whether the system configuration violates the currently installed activation key with respect to this feature.

Setting the Time and Date (Optional)

Related Topics:

- [Configuring NTP](#)

PTP 820G/F uses the Universal Time Coordinated (UTC) standard for time and date configuration. UTC is a more updated and accurate method of date coordination than the earlier date standard, Greenwich Mean Time (GMT).

Every PTP 820G/F unit holds the UTC offset and daylight savings time information for the location of the unit. Each management unit presenting the information uses its own UTC offset to present the information with the correct time.



Note

If the unit is powered down, the time and date are saved for 96 hours (four days). If the unit remains powered down for longer, the time and date may need to be reconfigured.

To display and configure the UTC parameters:

- 1 Select **Platform > Management > Time Services**. The Time Services page opens.

Figure 32 Time Services Page

The screenshot shows the 'Time Services' configuration page. The left sidebar contains a navigation tree with 'Time Services' selected. The main content area is titled 'Microwave radio: Time Services' and contains the following configuration options:

- Date & Time Configuration:**
 - UTC date and time: 06-04-2015 18:37:08
 - Local date and time: 06-04-2015 18:37:08
- Offset from GMT:**
 - UTC offset hours: 0
 - UTC offset minutes: 0
- Daylight Saving Start Time:**
 - Month: 1
 - Day: 1
- Daylight Saving End Time:**
 - Month: 1
 - Day: 1
- DST offset (hours):** 0

Buttons for 'Apply' and 'Refresh' are located at the bottom of the configuration area.

- 2 Configure the fields listed in [Table 20](#).
- 3 Click **Apply**.

Table 20 Time Services Parameters

	Parameter	Definition
Date and Time Configuration	UTC date and time	The UTC date and time.
	Local date and time	The calculated local date and time, based on the local clock, Universal Time Coordinated (UTC), and Daylight Savings Time (DST) configurations.
Offset from GMT	UTC offset hours	The required hours offset (positive or negative) relative to GMT. This is used to offset the clock relative to GMT, according to the global meridian location.
	UTC offset minutes	The required minutes offset (positive or negative) relative to GMT. This is used to offset the clock relative to GMT, according to the global meridian location.
Daylight Saving Start Time	Month	The month when Daylight Savings Time begins.
	Day	The date in the month when Daylight Savings Time begins.
Daylight Saving End Time	Month	The month when Daylight Savings Time ends.
	Day	The date in the month when Daylight Savings Time ends.
	DST offset	The required offset, in hours, for Daylight Savings Time. Only positive offset is supported.

Enabling the Interfaces (Interface Manager)

The following are the default settings for fixed interfaces on PTP 820G and PTP 820F unit's:

- Ethernet traffic interfaces, the second management interface, and the Synchronization interface are disabled, and must be manually enabled as described below.
- Radio interfaces, the first management interface, and the TDM interface (optional) are automatically enabled.
- PTP 820F supports both single-carrier and MultiCore RFUs. If the PTP 820F is connected to a single-carrier RFU, the radio interface is displayed in the Web EMS as Radio Slot 1 Port 1. If the PTP 820F is connected to a MultiCore RFU, the radio interfaces are displayed in the Web EMS as Radio Slot 1 Port 1 and Radio Slot 1 Port 2, where Port 1 represents the first radio carrier on the MultiCore RFU, and Port 2 represents the second radio carrier on the MultiCore RFU. The MAC address of the MultiCore RFU is presented in the Port 1 row.



Note

Radio Slot 1 Port 2 always appears, even if the IDU is connected to a single-carrier RFU such as RFU-S. If the PTP 820F is connected to a single-carrier RFU, or if the second carrier of a MultiCore RFU is not in use, you should set the **Admin status** field of Port 2 to **Down** to disable the radio interface and prevent unnecessary alarms.

To enable and disable interfaces:


- 1 Select **Platform > Management > Interface Manager**. The Interface Manager page opens.

Figure 33 Interface Manager Page PTP 820F

Interface location	MAC address	Admin status	Operational Status
Ethernet: Slot 1, Port 1	3C:4C:D0:50:62:C0	Down	Down
Ethernet: Slot 1, Port 2	3C:4C:D0:50:62:BF	Down	Down
Ethernet: Slot 1, Port 3	3C:4C:D0:50:62:BE	Down	Down
Ethernet: Slot 1, Port 4	3C:4C:D0:50:62:BD	Down	Down
Ethernet: Slot 1, Port 6	3C:4C:D0:50:62:BA	Down	Down
Radio: Slot 1, Port 1	3C:4C:D0:50:62:B9	Up	Down
Radio: Slot 1, Port 2	00:00:00:00:00:00	Up	Down
Management: Slot 1, Port 1	00:00:00:00:00:00	Up	Up
Management: Slot 1, Port 2	00:00:00:00:00:00	Down	Down
Sync: Slot 1, Port 1	00:00:00:00:00:00	Down	Down
TDM: Slot 1, Port 1	3C:4C:D0:50:62:CD	Up	Up

Multiple Selection Operation
Admin status: Up Apply


Figure 34 Interface Manager Page – PTP 820G



To enable or disable an individual interface:

- 1 Select the interface in the Interface Manager table.
- 2 Click **Edit**. The Interface Manager – Edit page opens.

Figure 35 Interface Manager – Edit Page



- 3 In the **Admin status** field, select **Up** to enable the interface or **Down** to disable the interface.
- 4 Click **Apply**, then **Close**.

To enable or disable multiple interfaces:

- 1 Select the interfaces in the Interface Manager table or select all the interfaces by selecting the check box in the top row.
- 2 In the Multiple Selection Operation section underneath the Interface Manager Table, select **Admin status - Up** or **Admin status - Down**.

Figure 36 Multiple Selection Operation Section (Interface Manager Page)

Multiple Selection Operation
Admin status

3 Click **Apply**.

**Note**

The **Operational Status** field displays the current, actual operational state of the interface (**Up** or **Down**).

Enabling the Second Management Interface

To enable the second management interface, you must use the CLI. Enter the following command in root view to enable the interface:

```
root> platform management local-mngt admin state set enable port mng2
```

To disable the second management interface, enter the following command in root view:

```
root> platform management local-mngt admin state set disable port mng2
```

To display the status of both management interfaces, enter the following command in root view:

```
root> platform management local-mngt admin state show port all
```

Configuring RFU3/SFP5,RFU3/2.5GE5 as an Ethernet or RFU Interface(PTP 820F only)

On PTP 820F, the combo port labelled RFU3/SFP5 (SFP) and RFU3/2.5GE5 (RJ-45) can be configured as either an RFU interface (RFU3) or an Ethernet interface (Eth3). By default, this port is an RFU interface.



Figure: RFU3/SFP5 and RFU3/2.5GE5 Combo Port

To change the port's use from RFU to Ethernet or Ethernet to RFU:

- 1 Set the port's admin state to **Down** in the Interface Manager.
 - If the port is currently configured as an RFU port, it is listed as **Radio: Slot 1, Port 5** in the Interface Manager.
 - If the port is currently configured as an Ethernet port, it is listed as **Ethernet: Slot 1, Port 5** in the Interface Manager.

See *Enabling the Interfaces (Interface Manager)*.
- 2 In the Radio Unit page, set the Admin status of **Radio Unit: Slot 1, Port 3** to **Down**.
- 3 If there are any service points attached to the port, remove them.
- 4 If the port is configured as a Sync source, delete the port as a Sync source.
- 5 If the port belongs to any interface groups, such as LAG, remove the port from the group.
- 6 Select **Platform > Interfaces > RFU/Ethernet**. The RFU/Ethernet Interface Configuration page opens.




Figure: RFU/Ethernet Interface Configuration Page

7 Select **Radio Unit: Slot 1, Port 3** and click **Edit**. The RFU/Ethernet Interface Configuration – Edit page opens.




Figure: RFU/Ethernet Interface Configuration – Edit Page

- 8 In the **Interface Type** field, select **RFU** or **Ethernet**.
- 9 Click **Apply**, then **Close**.
- 10 If you configured the port as an Ethernet interface, you must set the port’s admin state to **Up** in the Interface Manager. See *Enabling the Interfaces (Interface Manager)*. If you configured the port as an RFU interface, its admin state is **Up** automatically.

If you configured the port as an Ethernet interface, the port takes the following parameters:

- Port speed: 1 GE
- Media Type: RJ45
- Auto Negotiation: On

To change these parameters, go to the Physical Interfaces page. See *Configuring Ethernet Interfaces*.

Note: Both Eth5 and Eth6 can be configured to either 1 GE or 2.5 GE. The other PTP 820F Ethernet ports support 1 GE only.


If you configured the port as an RFU interface, make sure to set the Radio Unit parameters as necessary.

Configuring Cascading Interfaces (Optional)

In PTP 820F, GbE 1/SFP 1 and GbE 2/SFP 2 can be configured as normal GE traffic interfaces or as cascading interfaces. In PTP 820G, GbE1/CS1 and GbE2/CS2 can be configured as normal GE traffic interfaces or as cascading interfaces. When operating in cascading mode, these interfaces can handle hybrid Ethernet and Native TDM traffic, enabling operators to create links among multiple [Product Series] units in a node for multi-directional applications based on hybrid Ethernet and Native or pseudowire TDM services. To configure an interface as a cascading interface:


- 1 Select **Cascading > Interfaces**. The Cascading Interface Configuration page opens.

Figure 37 Cascading Interfaces Page



- 2 Select the interface you want to configure and click Edit. The Cascading Interface Configuration – Edit page opens.

Figure 38 Cascading Port Configuration Table – Edit Page



- 3 In the **Interface Type** field, select **Cascading**.
- 4 Click **Apply**, then **Close**.

**Note**

You cannot change the status of an interface (Cascading or Ethernet) if a service point is configured on the interface.

You cannot change the status of an interface (Cascading or Ethernet) if the interface belongs to a LAG.

Configuring the Radio Parameters

In order to establish a radio link, you must:

- Unmute the radio carrier.
- Configure the radio frequencies.
- Configure the TX level.

You can do these tasks, perform other radio configuration tasks, and display the radio parameters in the Radio Parameters page.

To configure the radio parameters:

- 1 Select Radio > Radio Parameters. The Radio Parameters page opens.

Figure 39 Radio Parameters Page

Radio Location ▲	Type	TX Frequency (MHz)	RX Frequency (MHz)	Operational TX Level (dBm)	RX Level (dBm)	Modem MSE (dB)	Defective Blocks	TX Mute Status
Radio: Slot 1, Port 1	Unknown	37086.000	38346.000	0	-99	-99.00	Clear	0 On
Radio: Slot 1, Port 2	Unknown	37086.000	38346.000	0	-99	-99.00	Clear	0 On

- 2 In the Radio table, select the radio you want to configure and click **Edit**. A separate configuration page opens.

Figure 40 Radio Parameters Configuration Page

Radio Parameters

Radio location: Radio: Slot 1, port 1

Status parameters

Type: RFU-C

Part Number:

Serial-Number:

Running Software Version:

XPIC support: Yes

Radio Interface operational status: Up

Operational TX Level (dBm): 15

RX Level (dBm): -39

Modem MSE (dB): -37.65

Modem XPI (dB): 0

Defective Blocks: 106

TX Mute Status: Off

Temperature: 39°C, 102°F

Frequency control (Local)

TX Frequency (MHz): 12871.000 (12871.000..12977.000)

RX Frequency (MHz): 13233.000 (13140.000..13233.000)

TX to RX frequency separation (MHz): 362.000

Set also remote unit

Configuration parameters

TX Level (dBm): 15 (2..23)

TX mute: Off

RSL Connector Source: Main

Link Id: 1 (1..65535)

Remote Unit link ID: 1 (1..65535)

Apply Refresh Close

- 3 Set the radio frequency in the Frequency control (Local) section:
 - i In the **TX Frequency (MHz)** field, set the transmission radio frequency in MHz.
 - ii In the **RX Frequency (MHz)** field, set the received radio frequency in MHz.
 - iii Click **Apply**. The system automatically calculates and displays the frequency separation in the **TX to RX frequency separation (MHz)** field, based on the configured TX and RX frequencies.
 - iv Optionally, select **Set also remote unit** to apply the frequency settings to the remote unit as well as the local unit.
- 4 Set the other radio parameters in the Configuration parameters section:
 - i In the **TX Level (dBm)** field, enter the desired TX signal level (TSL). The range of values depends on the frequency and RFU type.
 - ii To mute the TX output of the RFU, select **On** in the **TX mute** field. To unmute the TX output of the RFU, select **Off**.

- iii In the **Link ID** field, enter a unique link identifier from 1 to 65535. The Link ID identifies the link, in order to distinguish it from other links. If the Link ID is not the same at both sides of the link, a Link ID Mismatch alarm is raised. If Link ID Mismatch Security is enabled, traffic is also blocked on the link. See [Enabling Link ID Mismatch Security](#).
- iv In the RSL degradation alarm admin field, select Enable if you want the unit to generate an alarm in the event that the RSL falls beneath the threshold defined in the RSL degradation threshold field. The range of values is -99 to 0. By default, the alarm is disabled, with a default degradation threshold of 68 dBm. The RSL degradation alarm is alarm ID 1610, Radio Receive Signal Level is below the configured threshold.

The alarm is cleared when the RSL goes above the configured threshold. The alarm is masked if the radio interface is disabled, the radio does not exist, or a communication-failure alarm (Alarm ID #1703) is raised.



Note

For instructions on the Adaptive TX power admin field, see [Enabling ACM with Adaptive Transmit Power](#).

The **RSL Connector Source** field is reserved for future use.

For a description of the read-only parameters in the Status parameters section, see [Viewing the Radio Status and Settings](#).

Enabling Link ID Mismatch Security

You can configure the unit to block all Ethernet and TDM traffic over the radio link in the event of a Link ID mismatch by enabling Link ID Mismatch Security. When Link ID Mismatch Security is enabled and a Link ID mismatch occurs:

- All Ethernet and TDM traffic over the link is blocked.
- The operational status of the radio is set to Down.
- Automatic State Propagation is triggered.
- You cannot change the Link ID of the remote radio, but the local-remote channel remains open for other remote configurations.
- In-band management is lost. Once the mismatch is cleared, in-band management is automatically restored.
- The relevant interfaces are treated as being Down for purposes of MSTP and G.8032.

Link ID Mismatch Security must be enabled and disabled via CLI.

To enable Link ID Mismatch Security, enter the following command in root view:

```
root> platform security link-id mismatch security set admin enable
```

To disable Link ID Mismatch Security, enter the following command in root view:

```
root> platform security link-id mismatch security set admin disable
```

To display the current Link ID Mismatch Security setting, enter the following command in root view:

```
root> platform security link-id mismatch security show admin
```

By default, Link ID Mismatch Security is disabled.

Entering Radio View (CLI)

To view and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

Configuring the Radio (MRMC) Script(s)

Related Topics:

- [Displaying MRMC Status](#)

Multi-Rate Multi-Constellation (MRMC) radio scripts define how the radio utilizes its available capacity. Each script is a pre-defined collection of configuration settings that specify the radio’s transmit and receive levels, link modulation, channel spacing, and bit rate. Scripts apply uniform transmit and receive rates that remain constant regardless of environmental impact on radio operation.



Note

The list of available scripts reflects activation-key-enabled features. Only scripts within your activation-key-enabled capacity will be displayed.

To display the MRMC scripts and their basic parameters and select a script:

- 1 Select one of the following, depending on the regulatory framework in which you are operating:
 - o To display ETSI scripts, select **Radio > MRMC > Symmetrical Scripts > ETSI**.
 - o To display ANSI (FCC) scripts, select **Radio > MRMC > Symmetrical Scripts > FCC**.

The MRMC Symmetrical Scripts page opens. For a description of the parameters displayed in the MRMC Symmetrical Scripts page, see [Table 26 MRMC Symmetrical Scripts Page Parameters](#).

Figure 41 MRMC Symmetrical Scripts Page (ETSI) – PTP 820F

Script ID	Channel Bandwidth (MHz)	Occupied Bandwidth (MHz)	Script Name	ACM Support	Supported QAM	Bit Rate (Mbps)
4502	56.000	53.000	mdN_A056056X_111_4502	Yes	2 .. 4096	41.423 .. 518.581
<input checked="" type="checkbox"/> 4504	28.000	26.500	mdN_A028028X_128_4504	Yes	2 .. 4096	20.512 .. 262.829
4505	28.000	28.000	mdN_A028028X_107_4505	Yes	2 .. 4096	21.718 .. 278.290
4506	56.000	55.700	mdN_A056056X_107_4506	Yes	2 .. 4096	43.535 .. 544.920
4507	40.000	37.400	mdN_A040040X_107_4507	Yes	2 .. 4096	29.206 .. 369.395
4508	7.000	6.500	mdN_A007007X_110_4508	Yes	2 .. 4096	4.521 .. 57.882
4509	14.000	13.300	mdN_A014014X_108_4509	Yes	2 .. 4096	10.256 .. 131.415
4511	112.000	106.000	mdN_A112112X_123_4511	Yes	2 .. 4096	82.846 .. 1034.937
4525	28.000	23.400	mdN_A025025X_106_4525	Yes	2 .. 4096	18.091 .. 231.596
4700	125.000	119.800	mdN_A125125N_116_4700	Yes	2 .. 512	89.840 .. 914.264
4701	62.500	60.450	mdN_A062062N_131_4701	Yes	2 .. 1024	42.633 .. 500.430
4702	250.000	239.600	mdN_A250250N_129_4702	Yes	2 .. 256	179.679 .. 1636.975
4704	500.000	478.300	mdN_A500500N_129_4704	Yes	2 .. 64	359.358 .. 2426.277
4706	50.000	47.200	mdN_A050050N_108_4706	Yes	2 .. 128	34.642 .. 269.447
4707	100.000	94.400	mdN_A100100N_110_4707	Yes	2 .. 256	69.283 .. 615.520

Figure 42 MRMC Symmetrical Scripts Page (ETSI) – PTP 820G

Microwave radio: MRMC Symmetrical ETSI Scripts (Radio: Slot 1, Port 1)

Radio interface: Radio: Slot 1, Port 1

▼ MRMC Symmetrical ETSI Scripts (Symmetrical ETSI Scripts)

Script ID	Channel Bandwidth (MHz)	Occupied Bandwidth (MHz)	Script Name	ACM Support	Supported QAM	Bit Rate (Mbps)
1003	56.000	53.000	mdN_A5656N_156_1003	Yes	4..2048	82.864 .. 503.904
<input checked="" type="checkbox"/> 1004	28.000	26.500	mdN_A2828N_157_1004	Yes	4..2048	40.978 .. 243.123
1005	28.000	28.000	mdN_A2828N_135_1005	Yes	4..2048	43.389 .. 261.357
1006	56.000	55.700	mdN_A5656N_137_1006	Yes	4..2048	87.122 .. 529.505
1007	40.000	37.400	mdN_A4040N_123_1007	Yes	4..2048	58.224 .. 349.341
1008	7.000	6.500	mdN_A0707N_132_1008	Yes	4..2048	9.547 .. 55.151
1009	14.000	13.300	mdN_A1414N_119_1009	Yes	4..2048	20.386 .. 116.462
1023	3.500	3.267	mdN_A3535N_123_1023	Yes	4..256	4.582 .. 20.344
1203	56.000	53.000	mdN_A5656X_112_1203	Yes	4..2048	81.178 .. 481.815
1204	28.000	26.500	mdN_A2828X_120_1204	Yes	4..2048	39.978 .. 243.091
1205	28.000	28.000	mdN_A2828X_121_1205	Yes	4..2048	42.365 .. 257.391
1206	56.000	55.700	mdN_A5656X_110_1206	Yes	4..2048	85.317 .. 506.204
1207	40.000	37.400	mdN_A4040X_116_1207	Yes	4..2048	56.608 .. 344.163
1209	14.000	13.300	mdN_A1414X_105_1209	Yes	4..2048	19.428 .. 113.541
1214	28.000	26.000	mdN_A2828X_109_1214	Yes	4..2048	38.724 .. 235.611
1217	40.000	33.500	mdN_A4040X_108_1217	Yes	4..2048	51.104 .. 310.488

Configure script

Note: Indicates the current configured script

Figure 43 MRMC Symmetrical Scripts Page (ANSI)

Microwave radio: MRMC Symmetrical FCC Scripts (Radio: Slot 1, port 1)

Select Radio interface: Slot 1 (Radio #1)

MRMC script attribute table (Symmetrical FCC Scripts)

Script ID	Channel bandwidth	Occupied Bandwidth	Script Name	ACM Support	Supported QAM	Bit Rate (Mbps)
1005	30.000	28.000	mdN_A2828N_130_1005	Yes	4..2048	43.389 .. 261.357
1006	60.000	55.700	mdN_A5656N_129_1006	Yes	4..2048	87.122 .. 529.505
<input checked="" type="checkbox"/> 1007	40.000	37.400	mdN_A4040N_119_1007	Yes	4..2048	58.224 .. 349.341
1010	50.000	47.200	mdN_A5050N_111_1010	Yes	4..2048	70.683 .. 445.020
1020	10.000	9.110	mdN_A1010N_100_1020	Yes	4..2048	13.535 .. 78.319
1021	20.000	18.570	mdN_A2020N_100_1021	Yes	4..2048	28.520 .. 165.740
1205	30.000	28.000	mdN_A2828X_111_1205	Yes	4..2048	42.365 .. 257.391
1206	60.000	55.000	mdN_A5656X_101_1206	Yes	4..2048	85.317 .. 506.204
1207	40.000	37.600	mdN_A4040X_109_1207	Yes	4..2048	56.608 .. 344.163
1210	50.000	46.000	mdN_A5050X_104_1210	Yes	4..2048	72.265 .. 428.910
1217	40.000	33.500	mdN_A4040X_102_1217	Yes	4..2048	51.104 .. 310.488
1222	25.000	23.400	mdN_A2525X_103_1222	Yes	4..2048	35.223 .. 214.059

Configure script Refresh

Note: Indicates the current configured script

- 2 In the **Select Radio Interface** field, select the slot for which you want to configure the script.
- 3 Select the script you want to assign to the radio. The currently-assigned script is marked by a check mark (Script ID's 4505 and 1004 in the images above).
- 4 Click **Configure Script**. A separate MRMC Symmetrical Scripts page opens.

Figure 44 MRMC Symmetrical Scripts Page (Configuration) – PTP 820F





Figure 45 MRMC Symmetrical Scripts Page (Configuration) - PTP 820G



- 5 In the **MRMC Script operational mode** field, select the ACM mode: **Fixed** or **Adaptive**.

- Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels.
- In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions. If you select **Adaptive**, two fields are displayed enabling you to select minimum and maximum ACM profiles.

Figure 46 MRMC Symmetrical Scripts Page (Configuration – Adaptive Mode) – PTP 820F

The screenshot shows a configuration window titled "MRMC Symmetrical ETSI Scripts". The window is divided into two main sections: "MRMC script configuration" and "Script configuration parameters".

MRMC script configuration - Script: 4504 Interface: Radio: Slot 1, Port 1

Script ID	4504
Channel Bandwidth (MHz)	28
Occupied Bandwidth (MHz)	26.5
Script Name	mdN_A028028X_128_4504
ACM Support	Yes
Symmetry	Normal
Standard	ETSI

Script configuration parameters - Interface: Slot 1, Port 1

MRMC Script operational mode: **Adaptive** (dropdown menu)

MRMC Script maximum profile: Profile 0, 2 QAM, 20.512 Mbps (dropdown menu)

MRMC Script minimum profile: Profile 0, 2 QAM, 20.512 Mbps (dropdown menu)

Apply

Warning: pressing 'Apply' may reset the radio interface and affect traffic.

Page Refresh Interval (Seconds): None (dropdown menu) Last Loaded: 13:35:14 Refresh Close

Figure 47 MRMC Symmetrical Scripts Page (Configuration – Adaptive Mode) PTP 820G

- 6 Define the script profile or profiles:
 - If you selected **Fixed** ACM mode, select the ACM profile in the **MRMC Script profile** field.
 - If you selected **Adaptive** ACM mode, select the maximum and minimum ACM profiles in the **MRMC Script maximum profile** and the **MRMC Script minimum profile** fields.

See [Table 27 PTP 820F Radio Configurations](#). The number of profiles depends on the type of unit you are configuring. For PT 820G, it also depends on whether you are configuring the MRMC script for a fixed interface. For PTP 820F, it depends on whether you are using a Microwave RFU (RFU-D and RFU-S) or an E-Band RFU (RFU-E).

 - PTP 820G: For fixed interfaces and RMC-B, up to 11 profiles (0-10) are available.
 - PTP 820F: For Microwave RFUs, up to 13 profiles (0-12) are available.
 - PTP 820F: For RFU-E, up to 10 profiles (0-9) are available.

**Note**

Supported profiles differ per script and also may differ based on whether the script is configured for Fixed or Adaptive mode. For details, refer to the Release Notes for the System Version you are using.

- 7 Click **Apply**.

**Note**

Changing the script resets the radio interface and affects traffic. Changing the maximum or minimum profile does not reset the radio interface.

Table 23 PTP 820G Radio Profiles for Fixed Interfces and RMC-B

Profile	Modulation
Profile 0	4 QAM
Profile 1	8 QAM
Profile 2	16 QAM
Profile 3	32 QAM
Profile 4	64 QAM
Profile 5	128 QAM
Profile 6	256 QAM
Profile 7	512 QAM
Profile 8	1024 QAM (Strong FEC)
Profile 9	1024 QAM (Light FEC)
Profile 10	2048 QAM

Table 24 PTP 820F Radio Profiles for Microwave RFU's

Profile	Modulation
Profile 0	BPSK
Profile 1	QPSK
Profile 2	8 PSK
Profile 3	16 QAM
Profile 4	32 QAM
Profile 5	64 QAM
Profile 6	128 QAM
Profile 7	256 QAM
Profile 8	512 QAM
Profile 9	1024 QAM (Strong FEC)
Profile 10	1024 QAM (Light FEC)
Profile 11	2048 QAM
Profile 12	4096 QAM

Table 25 PTP 820F Radio Profiles for RFU-E

Profile	Modulation
Profile 0	BPSK
Profile 1	QPSK
Profile 2	8 PSK
Profile 3	16 QAM
Profile 4	32 QAM
Profile 5	64 QAM
Profile 6	128 QAM
Profile 7	256 QAM
Profile 8	512 QAM
Profile 9	1024 QAM

[Table 26](#) describes the MRMC Symmetrical Scripts page parameters.

Table 26 MRMC Symmetrical Scripts Page Parameters

Profile	Modulation
Script ID	A unique ID assigned to the script in the system.
Channel bandwidth (MHz)	The script's channel bandwidth (channel spacing).
Occupied bandwidth (MHz)	The script's occupied bandwidth.
Script Name	The script's name.
ACM Support	Indicates whether the script supports Adaptive Coding Modulation (ACM). In ACM mode, a range of profiles determines Tx and Rx rates. This allows the radio to modify its transmit and receive levels in response to environmental conditions.
Symmetry	Indicates that the script is symmetrical (Normal). Only symmetrical scripts are supported in the current release.
Standard	Indicates whether the script is compatible with ETSI or FCC (ANSI) standards, or both.

Profile	Modulation
MRMC Script operational mode	<p>The ACM mode: Fixed or Adaptive.</p> <ul style="list-style-type: none"> Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels. <p>In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.</p>
MRMC Script profile	Fixed ACM mode only: The profile in which the system will operate.
MRMC Script maximum profile	Adaptive ACM mode only: The maximum profile for the script. For example, if you select a maximum profile of 5, the system will not climb above profile 5, even if channel fading conditions allow it.
MRMC Script minimum profile	Adaptive ACM mode only: The minimum profile for the script. For example, if you select a minimum profile of 3, the system will not go below profile 3 regardless of the channel fading conditions. The minimum profile cannot be greater than the maximum profile, but it can be equal to it.

Enabling ACM with Adaptive Transmit Power

This feature requires:

- ACM script
- When working with RFU-C, requires RFU software version 2.17 or above

When planning ACM-based radio links, the radio planner attempts to apply the lowest transmit power that will perform satisfactorily at the highest level of modulation. During fade conditions requiring a modulation drop, most radio systems cannot increase transmit power to compensate for the signal degradation, resulting in a deeper reduction in capacity. The PTP 820G is capable of adjusting power on the fly, and optimizing the available capacity at every modulation point.

To enable ACM with adaptive transmit power:

- 1 Select **Radio > Radio Parameters**. The Radio Parameters page opens ([Figure 39](#)).
- 2 Select the carrier in the Radio table and click **Edit**. A separate configuration page opens ([Figure 40](#)).
- 3 In the **Adaptive TX power admin** field, select **Enable**.
- 4 Click **Apply**, then **Close**. When you open the configuration page again, the **Adaptive TX power operational status** field should now indicate **Up** to indicate that the feature is fully functional.

Operating in FIPS Mode

PTP 820G can be configured to be FIPS 140-2-compliant in specific hardware and software configurations, as described in this section.

**Note**

FIPS 140-2 compliance is only available with the PTP 820 Assured platform.³

FIPS validation by NIST can be found from below link:

<http://csrc.nist.gov/groups/STM/cmvp/documents/140-1/140val-all.htm> (Certificate #2752).

Requirements for FIPS Compliance

It is the responsibility of the customer to ensure that these requirements are met.

For PTP 820G node to be FIPS-compliant, the chassis must be FIPS-compliant.

**Note**


To display the part numbers of the hardware components of PTP 820 unit, see [Displaying Unit Inventory](#).

Special labels must be affixed to a FIPS-compliant PTP 820G unit. These labels are tamper-evident and must be applied in such a way that it is not possible to open the chassis. These labels must be replaced whenever components are added to or removed from the unit. Replacement labels can be ordered from Cambium Networks. Tamper-evident labels should be inspected for integrity at least once every six months. For further details, refer to the *PTP 820G Installation Guide*.

Enabling FIPS Mode To set the unit to operate in FIPS mode:

- 1 Select **Platform > Security > General > Configuration**. The Security General Configuration page opens.

³ Release 10.0 cannot be used in PTP 820 Assured platforms. For PTP 820 Assured, use release 8.3.

Figure 48 Security General Configuration Page

- 2 In the **FIPS admin configuration** field, select **Enable**.
- 3 Click **Apply**.

**Note**

Changing the FIPS configuration causes a unit reset..

After enabling FIPS:

- The MD5 option for SNMPv3 is blocked.
- After any system reset, the length of time before users can log back into the system is longer than usual due to FIPS-related self-testing.

Configuring Grouping (Optional)

At this point in the configuration process, you should configure any interface groups that need to be set up according to your network plan. For details on available grouping and other configuration options, as well as configuration instructions, see [System Configurations](#).

Creating Service(s) for Traffic

In order to pass traffic through the PTP 820G, and PTP 820F you must configure Ethernet and/or TDM traffic services. For configuration instructions, see:

- [Configuring Ethernet Service\(s\)](#)
- [Configuring Native TDM Trails](#)
- [Configuring TDM Pseudowire Services](#)

Chapter 3: Configuration Guide

This section includes:

- [System Configurations](#)
- [Configuring a 1+0 Link](#)
- [Configuring Multi-Carrier ABC](#)
- [Configuring Link Aggregation \(LAG\)](#)
- [Configuring XPIC](#)
- [Configuring HSB Radio Protection](#)

System Configurations

This section lists basic system configurations and their prerequisites, with links to configuration instructions.

This section includes:

- Radio Configurations
- TDM Configurations



Note

For an up-to-date description of feature and configuration limitations, refer to the Release Notes for version 10.0

Radio Configurations

A PTP 820G or PTP 820F system can be used in the following radio configurations.



Note

One Multi-Carrier ABC group can be configured per unit.

PTP 820F Radio Configurations

Table 27 PTP 820F Radio Configurations

Configuration	Supported Products	Link to Configuration Instructions
1+0		<ul style="list-style-type: none"> • Configuring a 1+0 Link • Configuring a Link Using the Quick Configuration Wizard
2+0 Single Polarization	Requires Multi-Carrier ABC or LAG	<ul style="list-style-type: none"> • Configuring Multi-Carrier ABC • Configuring Link Aggregation (LAG) and LACP.
2+0 Dual Polarization (XPIC)	Requires Multi-Carrier ABC or LAG	<ul style="list-style-type: none"> • Configuring XPIC • Configuring Multi-Carrier ABC • Configuring XPIC Configuring Link Aggregation (LAG) and LACP.

Table 28 PTP 820G Radio Configurations

Configuration	Supported Products	Link to Configuration Instructions
---------------	--------------------	------------------------------------

1+0		Configuring a 1+0 Link Configuring a Link Using the Quick Configuration Wizard
1+0 IF Combining	Requires 1500HP	Configuring IF Combining
2+0 Single Polarization	Requires Multi-Carrier ABC or LAG	Configuring Multi-Carrier ABC. Configuring Link Aggregation (LAG) and LACP.
2+0 Dual Polarization (XPIC)	Requires Multi-Carrier ABC or LAG	Configuring XPIC. Configuring Multi-Carrier ABC. Configuring Link Aggregation (LAG) and LACP.
1+1 HSB Protection		Configuring HSB Radio Protection Configuring a Link Using the Quick Configuration Wizard
1+1 HSB Protection with BBS Space Diversity	Requires Multi-Carrier ABC	Configuring HSB Radio Protection Configuring Multi-Carrier ABC.

TDM Configurations

PTP 820G/ PTP 820F provide integrated support for transportation of TDM (E1/DS1) services with integrated E1/DS1 interfaces.

Two types of TDM services are supported using the same hardware:

- Native TDM trails.
- TDM Pseudowire services (enabling interoperability with third party packet/PW equipment).

PTP 820G and PTP 820F also offer hybrid Ethernet and TDM services. Hybrid services can utilize either Native TDM or pseudowire.

PTP 820G and PTP 820F offer a variety of path protection options.

[Table 29](#) lists the basic TDM configuration options, with links to configuration instructions.

Table 29 TDM Configurations

Configuration	Special Requirements	Link to Configuration Instructions
Native TDM Services	Requires fixed E1/DS1 interface.	Configuring Native TDM Trails
Native TDM Services with Path Protection	Requires fixed E1/DS1 interface.	Configuring Native TDM Trails
Pseudowire TDM Services	Requires fixed E1/DS1 interface.	Configuring TDM Pseudowire Services
Pseudowire TDM Services with Path Protection	Requires fixed E1/DS1 interface.	Configuring TDM Pseudowire Services

Configuring a Link Using the Quick Configuration Wizard

The Web EMS provides wizards to configure radio links. The wizards guide you through configuration of the basic radio parameters and services necessary to establish a working pipe link. The following link types can be configured with the Quick Configuration wizard:

- **1+0** – Configures a 1+0 radio link consisting of a user-selected Ethernet (or LAG) and radio interface connected. This link passes traffic between the radio and Ethernet interfaces via a point-to-point pipe service. See [Configuring a 1+0 Link Using the Quick Configuration Wizard](#).
- **1+0 Repeater** – Configures a 1+0 radio link that passes traffic between two user-selected radios via a point-to-point pipe service. This type of link is used to configure a node that functions as a repeater, passing traffic between two other nodes. See [Configuring a 1+0 \(Repeater\) Link Using the Quick Configuration Wizard](#).
- **1+1 HSB** – PTP 820G only. Configures a 1+1 HSB radio link consisting of a user-selected Ethernet interface or LAG and two radio interfaces in a 1+1 HSB configuration, one active and one standby. This link passes traffic between the active radio interface and the Ethernet interface via a point-to-point pipe service. See [Configuring a 1+1 HSB Link Using the Quick Configuration Wizard](#). For a detailed explanation of 1+1 HSB and its requirements, see [Configuring HSB Radio Protection](#).
- **1+1 HSB-SD** – PTP 820G only. Configures a 1+1 HSB radio link with Space Diversity, consisting of a user-selected Ethernet interface or LAG and two radio interfaces in a 1+1 HSB configuration, one primary/active and one diversity/standby. This link passes traffic between the radio interfaces and the Ethernet interface via a point-to-point pipe service. See [Configuring a 1+1 HSB-SD Link Using the Quick Configuration Wizard](#). For a detailed explanation of 1+1 HSB-SD and its requirements, see [Configuring HSB Radio Protection](#).
- **N+0 Multi-Carrier ABC** – Configures a 2 + 0 Multi-Carrier ABC group consisting of an Ethernet interface or LAG and the two radio interfaces. See [Configuring an N+0 Multi-Carrier ABC Link Using the Quick Configuration Wizard](#). For a detailed explanation of Multi-Carrier ABC and its requirements, see [Configuring Multi-Carrier ABC](#).

You can also use this wizard to configure XPIC between the radios within the Multi-Carrier ABC group. For a detailed explanation of XPIC and its requirements, see [Configuring XPIC](#).

Because the Quick Configuration wizard creates Pipe links, you cannot add an interface to a link using the Quick Configuration wizard if any service points are attached to the interface prior to configuring the link. See [Deleting a Service Point](#).

Configuring a 1+0 Link Using the Quick Configuration Wizard

To configure a 1+0 link using the Quick Configuration wizard:

- 1 Select **Quick Configuration > PIPE > Single Carrier > 1+0**. Page 1 of the 1+0 Quick Configuration wizard opens.

Figure 49 1+0 Quick Configuration Wizard (PTP 820G) – Page 1





Figure 50 1+0 Quick Configuration Wizard (PTP 820F) – Page 1



- 2 In the **Ethernet Interface** field, select an Ethernet interface or a LAG for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a blue square, as shown in [Figure 49](#) and [Figure 50](#)



Note

To create a LAG, click Create LAG. The Create LAG Group page opens. For instructions on creating LAG groups, see [Configuring Link Aggregation \(LAG\) and LACP](#)

- 3 In the **Radio Interface** field, select a radio interface for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a green circle, as shown in [Figure 49](#) and [Figure 50](#)
- 4 In the **Pipe Type** field, select the Attached Interface type for the service that will connect the radio and Ethernet interfaces. Options are:

- **s-tag** – A single S-VLAN is classified into the service points.
- **dot1q** - A single C-VLAN is classified into the service points.



Note

For a full explanation of Ethernet Services, service types, and attached interface types, see [Configuring Ethernet Service\(s\)](#).

- 5 Click **Next**. Page 2 of the 1+0 Quick Configuration wizard opens.

Figure 51 1+0 Quick Configuration Wizard (PTP 820G) – Page 2





Figure 52 1+0 Quick Configuration Wizard (PTP 820F) – Page 2



- 6 In the **TX Frequency (MHz)** field, set the transmission radio frequency in MHz.
- 7 In the **RX Frequency (MHz)** field, set the received radio frequency in MHz.
- 8 In the **TX Level (dBm)** field, enter the desired TX signal level (TSL). The range of values depends on the frequency and RFU type.
- 9 To mute the TX output of the RFU, select **On** in the **TX mute** field. To unmute the TX output of the RFU, select **Off**.

10 Click **Next**. Page 3 of the 1+0 Quick Configuration wizard opens.

Figure 53 1+0 Quick Configuration Wizard (PTP 820G) – Page 3





Figure 54 1+0 Quick Configuration Wizard (PTP 820F) – Page 3



11 In the **Script ID** field, select the MRM script you want to assign to the radio. For a full explanation of choosing an MRM script, see [Entering Radio View \(CLI\)](#)

To view and configure radio parameters, you must first enter the radio’s view level in the CLI.

Use the following command to enter a radio’s view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

Configuring the Radio (MRMC) Script(s).

12 In the **Operational Mode** field, select the ACM mode: **Fixed** or **Adaptive**.

Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels.

In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.

13 Do one of the following:

- If you selected **Fixed** in the **Operational Mode** field, the next field is **Profile**. Select the ACM profile for the radio in the **Profile** field.

- If you selected Adaptive in the Operational Mode field, the following two fields are displayed:
 - **Maximum profile** – Enter the maximum profile for the script. See [Entering Radio View \(CLI\)](#)
 - **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).
- **Minimum profile** – Enter the minimum profile for the script. See [Entering Radio View \(CLI\)](#)
- **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).

14 Click **Next**. Page 4 of the 1+0 Quick Configuration wizard opens.

Figure 55 1+0 Quick Configuration Wizard (PTP 820G) – Page 4





Figure 56 1+0 Quick Configuration Wizard (PTP 820F) – Page 4

- 15 In the **In Band Management** field, select **Yes** to configure in-band management, or **No** if you do not need in-band management. If you select **Yes**, the **Management VLAN** field appears.
- 16 If you selected **Yes** in the **In Band Management** field, select the management VLAN in the **Management VLAN** field.
- 17 If you want to use the Ethernet interface as well as the radio interface for in-band management, select **In Band includes Ethernet interface**.
- 18 Click **Finish**. Page 5 of the 1+0 Quick Configuration wizard opens. This page displays the parameters you have selected for the link.

Figure 57 1+0 Quick Configuration Wizard – Page 5 (Summary Page)




- 19 To complete configuration of the link, click **Submit**. If you want to go back and change any of the parameters, click **Back**. After you click **Submit**, the unit is reset.

Configuring a 1+0 (Repeater) Link Using the Quick Configuration Wizard

To configure a 1+0 repeater (radio-to-radio) link using the Quick Configuration wizard:


1. Select **Quick Configuration > PIPE > Single Carrier > 1+0 (Repeater)**. Page 1 of the 1+0 Repeater Quick Configuration wizard opens.

Figure 58 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 1



2. In the **Radio #1 Interface** field, select the first radio interface for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a green circle, as shown in Figure 58.
3. Click **Next**. Page 2 of the 1+0 Repeater Quick Configuration wizard opens.

Figure 59 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 2



4. In the **Radio #2 Interface** field, select the second radio interface for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a blue circle, as shown in Figure 59.
5. In the **Pipe Type** field, select the Attached Interface type for the service that will connect the radios. Options are:
 - o **s-tag** – All S-VLANs and untagged frames are classified into the service.


- o **dot1q** - All C-VLANs and untagged frames are classified into the service.

**Note**


For a full explanation of Ethernet Services, service types, and attached interface types, see [Configuring Ethernet Service\(s\)](#).

6. Click **Next**. Page 3 of the 1+0 Repeater Quick Configuration wizard opens.

Figure 60 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 3



7. For each interface, configure the following radio parameters. The red arrow points to the interface you are configuring. For example, in [Figure 60](#), the user is configuring Radio 1
 1. In the **TX Frequency (MHz)** field, set the transmission radio frequency for the first radio in MHz.
 2. In the **RX Frequency (MHz)** field, set the received radio frequency for the first radio in MHz.
 3. In the **TX Level (dBm)** field, enter the desired TX signal level (TSL) for the first radio. The range of values depends on the frequency and RFU type.
 4. To mute the TX output of the RFU, select **On** in the **TX mute** field. To unmute the TX output of the RFU, select **Off**.
8. Click **Next**. Page 4 of the 1+0 Repeater Quick Configuration wizard opens.

Figure 61 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 4

9. For each interface, configure the following MRMC script parameters. The red arrow points to the interface you are configuring. For example, in [Figure 62](#), the user is configuring Radio 2.
10. In the Script ID field, select the MRMC script you want to assign to the first radio. For a full explanation of choosing an MRMC script, see [Entering Radio View \(CLI\)](#)
11. To view and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

12. Configuring the Radio (MRMC) Script(s).

13. In the **Operational Mode** field, select the ACM mode for the first radio: **Fixed** or **Adaptive**.

- Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels.
 - In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.

14. Do one of the following:

- If you selected Fixed in the Operational Mode field, the next field is Profile. Select the ACM profile for the radio in the Profile field.

- If you selected Adaptive in the Operational Mode field, following two fields are displayed:
 - **Maximum profile** – Enter the maximum profile for the script. See [Entering Radio View \(CLI\)](#)
 - [To view](#) and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).
- **Minimum profile** – Enter the minimum profile for the script. See [Entering Radio View \(CLI\)](#)
- **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.


The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).


15. Click **Next**. Page 5 of the 1+0 Repeater Quick Configuration wizard opens.

Figure 62 1+0 Repeater Quick Configuration Wizard (PTP 820G) – Page 5



16. In the **In Band Management** field, select **Yes** to configure in-band management, or **No** if you do not need in-band management. If you select **Yes**, the **Management VLAN** field appears.
17. If you selected **Yes** in the **In Band Management** field, select the management VLAN in the **Management VLAN** field. Management will be available through both radio interfaces.
18. Click **Finish**. Page 6 of the 1+0 Repeater Quick Configuration wizard opens. This page displays the parameters you have selected for the link.

Figure 63 1+0 Repeater Quick Configuration Wizard – Page 6 (Summary Page)



19. To complete configuration of the link, click **Submit**. If you want to go back and change any of the parameters, click **Back**. After you click **Submit**, the unit is reset.

Configuring a 1+1 HSB Link Using the Quick Configuration Wizard




Note

PTP 820G only.

To configure a 1+1 HSB link using the Quick Configuration wizard:

- 1 Select **Quick Configuration > PIPE > Single Carrier > 1+1 (HSB)**. Page 1 of the 1+1 Quick Configuration wizard opens.

Figure 64 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 1



- 2 In the **Ethernet Interface** field, select an Ethernet interface or a LAG for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a blue square, as shown in [Figure 64](#).



Note

To create a LAG, click **Create LAG**. The **Create LAG Group** page opens. For instructions on creating LAG groups, see [Configuring Link Aggregation \(LAG\) and LACP](#).

- 3 In the **Radio #1 Interface** field, select a radio interface for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a green circle, as shown in [Figure 64](#). This interface will be the Active radio in the protection group.
- 4 In the **Pipe Type** field, select the Attached Interface type for the service that will connect the radio and Ethernet interfaces. Options are:
 - **s-tag** – All S-VLANs and untagged frames are classified into the service.
 - **dot1q** - All C-VLANs and untagged frames are classified into the service.




Note

For a full explanation of Ethernet Services, service types, and attached interface types, see [Configuring Ethernet Service\(s\)](#).


- 5 Click **Next**. Page 2 of the 1+1 HSB Quick Configuration wizard opens.

Figure 65 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 2



- 6 In the **Radio #2 Interface** field, select the Standby radio interface for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by an orange circle, as shown in [Figure 65](#). This interface will be the Standby radio in the protection group.
- 7 In the **Revertive Mode** field, select **Yes** or **No** to determine whether or not the HSB radio protection group will operate in revertive mode. When revertive mode is enabled, following a switchover the system initiates a revertive protection switchover back to the original receiver ten minutes after proper link and/or equipment conditions are restored. This ensures that the primary path is used whenever possible.
- 8 Click **Next**. Page 3 of the 1+1 HSB Quick Configuration wizard opens.

Figure 66 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 3



- 9 In the **TX Frequency (MHz)** field, set the transmission radio frequency in MHz.
- 10 In the **RX Frequency (MHz)** field, set the received radio frequency in MHz.


- 11 In the **TX Level (dBm)** field, enter the desired TX signal level (TSL). The range of values depends on the frequency and RFU type.
- 12 To mute the TX output of the RFU, select **On** in the **TX mute** field. To unmute the TX output of the RFU, select **Off**.

**Note**

The frequency settings are applied to both the Active and the Standby radios. However, the TX Level and Mute settings are applied only to the Active radio. You must manually set the TX Level and unmute the Standby radio in order for 1+1 protection to function. See [Configuring the Radio Parameters](#).

- 13 Click **Next**. Page 4 of the 1+1 HSB Quick Configuration wizard opens.

Figure 67 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 4



- 14 In the **Script ID** field, select the MPMC script you want to assign to the radios. For a full explanation of choosing an MPMC script, see [Entering Radio View \(CLI\)](#)

To view and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

Configuring the Radio (MRMC) Script(s).

- 15 In the **Operational Mode** field, select the ACM mode: **Fixed** or **Adaptive**.
 - Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels.
 - In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.
- 16 Do one of the following:
 - If you selected **Fixed** in the **Operational Mode** field, the next field is **Profile**. Select the ACM profile for the radio in the **Profile** field.

- If you selected **Adaptive** in the **Operational Mode** field, following fields are displayed:
 - **Maximum Profile** - Enter the maximum profile for the script. See [Entering Radio View \(CLI\)](#)
 - **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).
- **Minimum Profile** - Enter the minimum profile for the script. See [Entering Radio View \(CLI\)](#)
- **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.


The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s)


17 Click **Next**. Page 5 of the 1+1 HSB Quick Configuration wizard opens.

Figure 68 1+1 HSB Quick Configuration Wizard (PTP 820G) – Page 5



- 18 In the **In Band Management** field, select **Yes** to configure in-band management, or **No** if you do not need in-band management. If you select **Yes**, the **Management VLAN** field appears.
- 19 If you selected **Yes** in the **In Band Management** field, select the management VLAN in the **Management VLAN** field.
- 20 If you want to use the Ethernet interface as well as the radio interface for in-band management, select **In Band includes Ethernet interface**.
- 21 Click **Next**. Page 6 of the 1+1 HSB Quick Configuration wizard opens. This page displays the parameters you have selected for the link.

Figure 69 1+1 HSB Quick Configuration Wizard – Page 6 (Summary Page)



- 22 To complete configuration of the link, click **Submit**. If you want to go back and change any of the parameters, click **Back**. After you click **Submit**, the unit is reset.

Configuring a 1+1 HSB-SD Link Using the Quick Configuration Wizard



Note

1+1 HSB-SD configurations are only available for PTP 820G units.

To configure a 1+1 HSB-SD link using the Quick Configuration wizard:

- 1 Select **Quick Configuration > PIPE > Multi Carrier ABC > 1+1 (HSB-SD)**. Page 1 of the 1+1 Multi Carrier ABC HSB-SD Quick Configuration wizard opens.

Figure 70 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 1

- 2 In the **Ethernet Interface** field, select an Ethernet interface or a LAG for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a blue square, as shown in [Figure 70](#).



Note

To create a LAG, click **Create LAG**. The **Create LAG Group** page opens. For instructions on creating LAG groups, see [Configuring Link Aggregation \(LAG\) and LACP](#).

- 3 In the **Radio #1 Interface** field, select a radio interface for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a green circle, as shown in [Figure 70](#). This interface will be the Active radio in the protection group.
- 4 In the **Pipe Type** field, select the Attached Interface type for the service that will connect the radio and Ethernet interfaces. Options are:
 - **s-tag** – All S-VLANs and untagged frames are classified into the service.
 - **dot1q** - All C-VLANs and untagged frames are classified into the service.




Note

For a full explanation of Ethernet Services, service types, and attached interface types, see [Configuring Ethernet Service\(s\)](#).


- 5 Click **Next**. Page 2 of the 1+1 Multi Carrier ABC HSB-SD Quick Configuration wizard opens.

Figure 71 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 2



- 6 In the **Radio #2 Interface** field, select the Standby radio interface for the link. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by an orange circle, as shown in [Figure 71](#). This interface will be the Standby radio in the protection group.
- 7 In the **Revertive Mode** field, select **Yes** or **No** to determine whether or not the HSB radio protection group will operate in revertive mode. When revertive mode is enabled, following a switchover the system initiates a revertive protection switchover back to the original receiver ten minutes after proper link and/or equipment conditions are restored. This ensures that the primary path is used whenever possible.
- 8 Click **Next**. Page 3 of the 1+1 Multi Carrier ABC HSB-SD Quick Configuration wizard opens.

Figure 72 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 3



- 9 In the **TX Frequency (MHz)** field, set the transmission radio frequency in MHz.
- 10 In the **RX Frequency (MHz)** field, set the received radio frequency in MHz.


- 11 In the **TX Level (dBm)** field, enter the desired TX signal level (TSL). The range of values depends on the frequency and RFU type.
- 12 To mute the TX output of the RFU, select **On** in the **TX Mute** field. To unmute the TX output of the RFU, select **Off**.

**Note**

The frequency settings are applied to both the Active and the Standby radios. However, the TX Level and Mute settings are applied only to the Active radio. You must manually set the TX Level and unmute the Standby radio in order for 1+1 protection to function. See [Configuring the Radio Parameters](#).

- 13 Click **Next**. Page 4 of the 1+1 Multi Carrier ABC HSB-SD Quick Configuration wizard opens.

Figure 73 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 4



- 14 In the **Script ID** field, select the MRMC script you want to assign to the radios. For a full explanation of choosing an MRMC script, see [Entering Radio View \(CLI\)](#)

To view and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

Configuring the Radio (MRMC) Script(s).

- 15 In the **Operational Mode** field, select the ACM mode: **Fixed** or **Adaptive**.
 - Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels.
 - In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.
- 16 Do one of the following:
 - If you selected Fixed in the Operational Mode field, the next field is Profile. Select the ACM profile for the radio in the Profile field.

- If you selected Adaptive in the Operational Mode field, following two fields are displayed:
 - **Maximum Profile** - Enter the maximum profile for the script. See [Entering Radio View \(CLI\)](#)
 - **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).
- **Minimum Profile** - Enter the minimum profile for the script. See [Entering Radio View \(CLI\)](#)
- **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.


The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s)


17 Click **Next**. Page 5 of the 1+1 Multi Carrier ABC HSB-SD Quick Configuration wizard opens.

Figure 74 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 5



- 18 In the **In Band Management** field, select **Yes** to configure in-band management, or **No** if you do not need in-band management. If you select **Yes**, the **Management VLAN** field appears.
- 19 If you selected **Yes** in the **In Band Management** field, select the management VLAN in the **Management VLAN** field.
- 20 If you want to use the Ethernet interface as well as the radio interface for in-band management, select **In Band includes Ethernet interface**.
- 21 Click **Finish**. Page 6 of the 1+1 Multi Carrier ABC HSB-SD Quick Configuration wizard opens. This page displays the parameters you have selected for the link.

Figure 75 1+1 Multi Carrier ABC HSB-SD Quick Configuration Wizard – Page 6 (summary page)



- 22 To complete configuration of the link, click **Submit**. If you want to go back and change any of the parameters, click **Back**. After you click **Submit**, the unit is reset.

Configuring an N+0 Multi-Carrier ABC Link Using the Quick Configuration Wizard



Note

For PTP 820F, Multi-Carrier ABC requires a MultiCore RFU-D and can only be configured between the two radio carriers of the same RFU.

To configure an N+0 Multi-Carrier ABC link using the Quick Configuration wizard:

1. Select **Quick Configuration > PIPE > Multi Carrier ABC > N+0**. Page 1 of the N + 0 Multi Carrier ABC Quick Configuration wizard opens.

Figure 76 N + 0 Multi Carrier ABC Quick Configuration Wizard (PTP 820G) – Page 1





Figure 77 N + 0 Multi Carrier ABC Quick Configuration Wizard (PTP 820F) – Page 1



- In the **Ethernet Interface** field, select an Ethernet interface or a LAG for the group. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a blue square, as shown in [Figure 76](#).



Note

To create a LAG, click Create LAG. The Create LAG Group page opens. For instructions on creating LAG groups, see [Configuring Link Aggregation \(LAG\) and LACP](#).

- In the **Radio #1 Interface** field, select the first radio interface for the group. Alternatively, click the interface in the graphical representation of the unit. The selected interface is surrounded by a blue circle, as shown in [Figure 76](#).



Note

The **Number of Radio Interfaces** field is read-only.

- In the **Pipe Type** field, select the Attached Interface type for the service that will connect the radio and Ethernet interfaces. Options are:
 - s-tag** - All S-VLANs and untagged frames are classified into the service.
 - dot1q** - All C-VLANs and untagged frames are classified into the service.



Note

For a full explanation of Ethernet Services, service types, and attached interface types, see [Configuring Ethernet Service\(s\)](#).

- Click **Next**. The Radio #2 Selection page opens.

Figure 78 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio #2 Selection Page – PTP 820G





Figure 79 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio #2 Selection Page – PTP 820F



6. In the **Radio #2 Interface** field, select the second radio interface for the group. For PTP 820F, the second radio interface must be the second radio carrier of an RFU-D or RFU-D-HP. For PTP 820G, you can click the interface in the graphical representation of the unit. The selected interface is surrounded by a blue circle and the previously selected interface is surrounded by a green circle, as shown in [Figure 78](#).
7. Click **Next**. The Radio XPIC Configuration page opens. If you want to set up an XPIC configuration, select the radio pair. For full instructions on configuring XPIC, including antenna alignment instructions, see [Configuring XPIC](#).

Figure 80 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio XPIC Configuration Page – PTP 820G





Figure 81 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio XPIC Configuration Page – PTP 820F



8. Click **Next**. The Radio Parameters Configuration page opens. You can configure the basic radio parameters for each radio carrier. If you selected XPIC in the Radio XPIC Configuration page, you configure the parameters for the group rather than the individual carriers.

Figure 82 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio Parameters Configuration Page – PTP 820G




Figure 83 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio Parameters Configuration Page – PTP 820F




Figure 84 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio Parameters Configuration Page (XPIC) – PTP 820G





Figure 85 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio Parameters Configuration Page (XPIC) – PTP 820F



9. For each radio carrier or XPIC group, configure the following radio parameters:
 - i In the **TX Frequency (MHz)** field, set the transmission radio frequency in MHz.
 - ii In the **RX Frequency (MHz)** field, set the received radio frequency in MHz.
 - iii In the **TX Level (dBm)** field, enter the desired TX signal level (TSL). The range of values depends on the frequency and RFU type.
 - iv To mute the TX output of the radio carrier, select **On** in the **TX mute** field. To unmute the TX output of the radio carrier, select **Off**.
10. Click **Next**. The Radio MPMC Script Configuration page opens. You can configure the MPMC script parameters for each interface. For an XPIC group, you configure the parameters for the group rather than the individual interfaces.

Figure 86 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio MPMC Script Configuration Page – PTP 820G




Figure 87 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio MPMC Script Configuration Page – PTP 820F





Figure 88 N + 0 Multi Carrier ABC Quick Configuration Wizard – Radio MRMC Script Configuration Page (XPIC) – PTP 820G



11. For each interface or XPIC group, configure the following MRMC script parameters:
12. In the **Script ID** field, select the MRMC script you want to assign to the radio or XPIC group. For a full explanation of choosing an MRMC script, see *Entering Radio View (CLI)*
13. To view and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

14. Configuring the Radio (MRMC) Script(s).
15. In the **Operational Mode** field, select the ACM mode: **Fixed** or **Adaptive**.
 - Fixed ACM mode applies constant TX and RX rates. However, unlike regular scripts, with a Fixed ACM script you can specify a maximum profile to inhibit inefficient transmission levels.
 - In Adaptive ACM mode, TX and RX rates are dynamic. An ACM-enabled radio system automatically chooses which profile to use according to the channel fading conditions.
16. Do one of the following:
 - If you selected Fixed in the Operational Mode field, the next field is Profile. Select the ACM profile for the radio in the Profile field.

- If you selected Adaptive in the Operational Mode field, following two fields are displayed:
 - **Maximum Profile** - Enter the maximum profile for the script. See [Entering Radio View \(CLI\)](#)
 - **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).
- **Minimum Profile** - Enter the minimum profile for the script. See [Entering Radio View \(CLI\)](#)
- **To view** and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters



Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s).

17. Click **Next**. The Management Configuration page opens.

Figure 89 N + 0 Multi Carrier ABC Quick Configuration Wizard – Management Configuration Page – PTP 820G**Figure 90** N + 0 Multi Carrier ABC Quick Configuration Wizard – Management Configuration Page – PTP 820F

18. In the **In Band Management** field, select **Yes** to configure in-band management, or **No** if you do not need in-band management. If you select **Yes**, the **Management VLAN** field appears.
19. If you selected **Yes** in the **In Band Management** field, select the management VLAN in the **Management VLAN** field.
20. If you want to use the Ethernet interface as well as the radio interface for in-band management, select **In Band includes Ethernet interface**.
21. Click **Finish**. The Summary page opens. This page displays the parameters you have selected for the group.

Figure 91 N + 0 Multi Carrier ABC Quick Configuration Wizard – Summary Page – PTP 820G





Figure 92 N + 0 Multi Carrier ABC Quick Configuration Wizard – Summary Page – PTP 820F



22. To complete configuration of the Multi-Carrier ABC group, click **Submit**. If you want to go back and change any of the parameters, click **Back**. After you click **Submit**, the unit is reset.

Configuring a 1+0 Link

To configure a 1+0 link, you must perform the following steps:

1. If you are using an RMC in an expansion slot rather than a fixed radio interface, enable the RMC.
2. Unmute the radio. See [Configuring the Radio Parameters](#).
3. Configure the radio's TX level. See [Configuring the Radio Parameters](#).
4. Configure the radio's frequency. See [Configuring the Radio Parameters](#).
5. Configure the radio's MRMC script. See [Entering Radio View \(CLI\)](#)
6. [To view](#) and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

7. Configuring the Radio (MRMC) Script(s).



Note

You can also use the Quick Configuration wizard to configure a 1+0 Pipe link. See [Configuring a Link Using the Quick Configuration Wizard](#).

Configuring Multi-Carrier ABC

**Note**

For PTP 820F, Multi-Carrier ABC requires a MultiCore RFU-D.

This section includes:

- [Multi-Carrier ABC Overview](#)
- [Configuring a Multi-Carrier ABC Group](#)
- [Deleting a Multi-Carrier ABC Group](#)

Multi-Carrier ABC Overview

Multi-Carrier Adaptive Bandwidth Control (ABC) enables multiple separate radio carriers to be shared by a single Ethernet port. This provides an Ethernet link over the radio with the total sum of the capacity of all the radios in the group, while still behaving as a single Ethernet interface. In Multi-Carrier ABC mode, traffic is dynamically divided among the carriers, at the Layer 1 level, without requiring Ethernet Link Aggregation.

Load balancing is performed regardless of the number of MAC addresses or the number of traffic flows. During fading events which cause ACM modulation changes, each carrier fluctuates independently with hitless switchovers between modulations, increasing capacity over a given bandwidth and maximizing spectrum utilization. The result is 100% utilization of radio resources in which traffic load is balanced based on instantaneous radio capacity per carrier.

**Note**

If the modulation of a radio carrier in the Multi-Carrier ABC group drops to Profile 0, that carrier is removed from the group until modulation returns to Profile 1 or higher.

In this version, one Multi-Carrier ABC group that includes both radio carriers can be configured per unit. The MRMC scripts for both radio carriers must be identical.

Configuring a Multi-Carrier ABC Group


To configure a Multi-Carrier ABC group:

1. Select **Radio > Groups > Multi Carrier ABC**. The Multi Carrier ABC page opens.
-

**Note**


You can also use the Quick Configuration wizard to configure a Multi-Carrier ABC group. See [Configuring a Link Using the Quick Configuration Wizard](#).

Figure 93 Multi-Carrier ABC Group Page (Empty)



2. Click **Create Group**. The first page of the Create ABC Group wizard opens.

Figure 94 Create ABC Group Wizard – First Page



3. Optionally, enter a descriptive name for the group in the Group Name field.
4. Click **Next**. The next page of the Create Group wizard opens.

Figure 95 Create ABC Group Wizard – Second Page

5. In the Member 1 field, select a radio carrier.
6. Click Next. The next page of the Create Group wizard opens.
7. In the Member 2 field, select a radio carrier.
8. Click Next. A summary page opens.

Figure 96 Create ABC Group Wizard – Finish Page

9. Click Submit, A message appears indicating whether or not the operation was successful.
10. Click Close to close the Create Group wizard. You must click Submit before clicking Close, or the selections you made will be discarded and the process cancelled.

Adding and Removing Group Members

You can add and remove radio carriers from the group after creating the group. This is relevant, for example, if you are configuring 1+1 HSB-SD, where you must first create an empty Multi-Carrier ABC group, then later add the 1+1 HSB-SD group to the empty Multi-Carrier ABC group. This is also relevant if you want to delete a Multi-Carrier ABC group, since you must remove the members individually before deleting the group.

To add interfaces:

1. Select the group in the Multi-Carrier ABC table and click **Add/Remove Members**. The Multi Carrier ABC - Add/Remove Members page opens.

Figure 97 Multi Carrier ABC Group - Add/Remove Members Page

2. Select a member from the **Add Member** drop-down list.
3. Click **Apply**.

To remove interfaces:

1. Select a member in the **Remove Member** field.
2. Click **Apply**.
3. Repeat these steps to remove additional members from the group.

Deleting a Multi-Carrier ABC Group



Note

For instructions on deleting a Multi-Carrier ABC/HSB-SD group, see [Deleting an HSB Radio Protection Group with Space Diversity](#).

To delete a Multi-Carrier ABC group:

1. Select **Radio > Groups > Multi Carrier ABC**. The Multi Carrier ABC page opens ([Figure 93](#)).
2. Select the group in the Multi-Carrier ABC table and click **Add/Remove Members**. The Multi Carrier ABC – Add/Remove Members page opens ([Figure 95](#)).
3. Remove each member of the group. See [Adding and Removing Group Members](#).
4. Click **Close** to close the Multi Carrier ABC – Add/Remove Members page.
5. Select the group and click **Delete**.

Configuring Link Aggregation (LAG) and LACP

Link aggregation (LAG) enables you to group several physical Ethernet or radio interfaces into a single logical interface bound to a single MAC address. This logical interface is known as a LAG group. Traffic sent to the interfaces in a LAG group is distributed by means of a load balancing function. PTP 820G uses a distribution function of up to Layer 4 in order to generate the most efficient distribution among the LAG physical ports.

This section explains how to configure LAG and includes the following topics:

- [LAG Overview](#)
- [Configuring a LAG Group](#)
- [Enabling and Disabling LAG Group Shutdown in case of Degradation Event](#)
- [Configuring Enhanced LAG Distribution](#)
- [Deleting a LAG Group](#)
- [Displaying LACP Parameters and Statistics.](#)

LAG Overview

LAG can be used to provide interface redundancy. LAG can also be used to aggregate several interfaces in order to create a wider (aggregate) link. For example, LAG can be used to create a 4 Gbps channel.

You can create up to four LAG groups. The following restrictions exist with respect to LAG groups:

- Only physical interfaces (including radio interfaces), not logical interfaces, can belong to a LAG group.
- Cascading interfaces cannot belong to a LAG group. See [Configuring RFU3/SFP5,RFU3/2.5GE5 as an Ethernet or RFU Interface\(PTP 820F only\)](#)

On PTP 820F, the combo port labelled RFU3/SFP5 (SFP) and RFU3/2.5GE5 (RJ-45) can be configured as either an RFU interface (RFU3) or an Ethernet interface (Eth3). By default, this port is an RFU interface.



Figure: RFU3/SFP5 and RFU3/2.5GE5 Combo Port

To change the port's use from RFU to Ethernet or Ethernet to RFU:

- 1 Set the port's admin state to **Down** in the Interface Manager.
 - If the port is currently configured as an RFU port, it is listed as **Radio: Slot 1, Port 5** in the Interface Manager.
 - If the port is currently configured as an Ethernet port, it is listed as **Ethernet: Slot 1, Port 5** in the Interface Manager.

See Enabling the Interfaces (Interface Manager).
- 2 In the Radio Unit page, set the Admin status of **Radio Unit: Slot 1, Port 3** to **Down**.
- 3 If there are any service points attached to the port, remove them.
- 4 If the port is configured as a Sync source, delete the port as a Sync source.
- 5 If the port belongs to any interface groups, such as LAG, remove the port from the group.
- 6 Select **Platform > Interfaces > RFU/Ethernet**. The RFU/Ethernet Interface Configuration page opens.




Figure: RFU/Ethernet Interface Configuration Page

- 7 Select **Radio Unit: Slot 1, Port 3** and click **Edit**. The RFU/Ethernet Interface Configuration – Edit page opens.




Figure: RFU/Ethernet Interface Configuration – Edit Page

- 8 In the **Interface Type** field, select **RFU** or **Ethernet**.
- 9 Click **Apply**, then **Close**.
- 10 If you configured the port as an Ethernet interface, you must set the port's admin state to **Up** in the Interface Manager. See *Enabling the Interfaces (Interface Manager)*. If you configured the port as an RFU interface, its admin state is **Up** automatically.

If you configured the port as an Ethernet interface, the port takes the following parameters:

- Port speed: 1 GE
- Media Type: RJ45
- Auto Negotiation: On

To change these parameters, go to the Physical Interfaces page. See *Configuring Ethernet Interfaces*.

Note: Both Eth5 and Eth6 can be configured to either 1 GE or 2.5 GE. The other PTP 820F Ethernet ports support 1 GE only.

If you configured the port as an RFU interface, make sure to set the Radio Unit parameters as necessary.

- Configuring Cascading Interfaces (Optional).
- Interfaces can only be added to the LAG group if no services or service points are attached to the interface.
- Any classification rules defined for the interface are overridden by the classification rules defined for the LAG group.
- When removing an interface from a LAG group, the removed interface is assigned the default interface values.

There are no restrictions on the number of interfaces that can be included in a LAG. It is recommended, but not required, that each interface in the LAG have the same parameters (e.g., speed, duplex mode).



Note

To add or remove an Ethernet interface to a LAG group, the interface must be in an administrative state of “down”. This restriction does not apply to radio interfaces. For instructions on setting the administrative state of an interface, see [Enabling the Interfaces \(Interface Manager\)](#).

PTP 820 supports LACP, which expands the capabilities of static LAG and provides interoperability with third-party equipment that uses LACP. LACP improves the communication between LAG members. This improves error detection capabilities in situations such as improper LAG configuration or improper cabling. It also enables the LAG to detect uni-directional failure and remove the link from the LAG, preventing packet loss.

LACP is enabled as part of the LAG configuration process. It should only be used if the LAG is in a link with another LACP-enabled LAG.



Note

LACP is not supported with unit redundancy. For unit redundancy, a special, limited implementation is configured on the logical interface level. See [Configuring Unit Redundancy for PTP 820G](#). LACP can only be used with Ethernet interfaces. LACP cannot be used with Enhanced LAG Distribution or with the LAG Group Shutdown in Case of Degradation Event feature..


Configuring a LAG Group

Creating a LAG Group

To create a LAG group:


1. Select Ethernet > Interfaces > Groups > LAG. The LAG page opens.

Figure 98 LAG Page (Empty)



2. Click **Create Group** underneath the Link Aggregation table. The Create LAG page opens.


Figure 99 Create LAG Group Page



3. In the Group ID field, select a LAG Group ID. Only LAG IDs that are not already assigned to a LAG group appear in the dropdown list.
4. In the **LACP** field, select **Enable** to enable LACP on the LAG or **Disable** to disable LACP on the LAG. The default value is **Disable**.
5. In the LAG Member 1 field, select an interface to assign to the LAG group. Only interfaces not already assigned to a LAG group appear in the dropdown list.
6. Click Next. A new Create LAG Group page opens.
7. In the Member 2 field, select an additional interface to assign to the LAG Group.
8. To add additional interfaces to the LAG group, repeat steps 6 and 7.

9. When you have finished adding interfaces to the LAG group, click Finish. A new LAG page opens displaying all the interfaces you have selected to include in the LAG group.

Figure 100 Create LAG Group – Finish Page




10. Click Submit. If all the interfaces meet the criteria listed above, a message appears that the LAG group has been successfully created. If not, a message appears indicating that the LAG group was not created and giving the reason.

Editing a LAG Group

To edit an existing LAG group:


1. Select the LAG group you want to edit in the Link Aggregation table of the LAG page

Figure 101 LAG Page (Populated)



2. Click **Edit** underneath the Link Aggregation table. The Link Aggregation - Edit page opens.

Figure 102 Link Aggregation - Edit Page



3. Do one or both of the following:
 - o To enable or disable LACP, select **Enable** or **Disable** in the **LACP** field. See [LAG Overview](#) for restrictions.

- To enable or disable LAG Group Shutdown in case of Degradation Event, select **Enable** or **Disable** in the **LAG degrade** field. See *Enabling and Disabling LAG Group Shutdown in case of Degradation Event* for restrictions.
 - To remove an interface from the LAG Group, select the interface in the Remove Member field.
 - To add an interface to the LAG Group, select the interface in the Add Member field.
4. Click **Apply**.
 5. To remove or add additional interfaces, repeat steps 4 and 5.
 6. When you are finished, click **Close** to close the Link Aggregation – Edit page.

**Note**

When removing an interface from a LAG group, the removed interface is assigned the default interface values.

For information about the **LAG degrade** field, see [Enabling and Disabling LAG Group Shutdown in case of Degradation Event](#).

Enabling and Disabling LAG Group Shutdown in case of Degradation Event

**Note**

LAG Group Shutdown in Case of Degradation Event cannot be used with LACP.

A LAG group can be configured to be automatically closed in the event of LAG degradation. This option is used if you want traffic from the switch to be re-routed during such time as the link is providing less than a certain capacity.

By default, the LAG group shutdown in case of degradation event option is disabled. When enabled, the LAG is automatically closed in the event that any one or more ports in the LAG fail. When all ports in the LAG are again operational, the LAG is automatically re-opened.

**Note**

Failure of a port in the LAG also triggers a lag-degraded alarm, Alarm ID 100.

1. To enable or disable the LAG group shutdown in case of degradation event option:
2. Select **Ethernet > Interfaces > Groups > LAG** to open the LAG page.
3. Select the LAG group in the Link Aggregation table.
4. Click **Edit** underneath the Link Aggregation table. The Link Aggregation - Edit page opens ([Figure 102](#)).
5. In the **LAG degrade** field, select **Enable** to enable the LAG group shutdown in case of degradation event option or **Disable** to disable the LAG group shutdown in case of degradation event option.
6. Click **Apply**.

Configuring Enhanced LAG Distribution

You can change the distribution function by selecting from ten pre-defined LAG distribution schemes. The feature includes a display of the TX throughput for each interface in the LAG, to help you identify the best LAG distribution scheme for the specific link.



Note

Enhanced LAG distribution is only available for LAG groups that consist of exactly two interfaces. It cannot be used with LACP.

To configure enhanced LAG distribution:

1. Select **Ethernet > Interfaces > Groups > LAG**. The LAG page opens (Figure 101).
2. Click **LAG DF** underneath the Link Aggregation table. The LAG Distribution Function (DF) page opens.

Figure 103 LAG Distribution Function (DF) Page

3. In the **Distribution Function** field, select a pre-set distribution scheme, from 1 to 10. It is recommended to experiment with the various schemes, monitoring the **TX byte count** fields for each interface to determine the efficiency of each distribution scheme for the link. The default distribution scheme is 1.
4. To clear the TX byte counts, select **Clear on read** for one or both interfaces. The byte counts will be cleared when you close the LAG Distribution Function (DF) page or click **Refresh**.



Note

This counter will also be cleared for the members of the LAG in the Port RMON Statistics page.

5. Click **Apply** to apply the selected distribution scheme.

Deleting a LAG Group

In order to delete a LAG group, you must first make sure that no service points are attached to the LAG group.

To delete a LAG group:

1. Select **Ethernet > Interfaces > Groups > LAG**. The LAG page opens.
2. Select the LAG group you want to delete in the Link Aggregation table.
3. Click **Delete** underneath the Link Aggregation table. The LAG group is deleted.

To delete multiple LAG groups:

1. Select the LAG groups in the Link Aggregation table or select all the LAG groups by selecting the check box in the top row.
2. Click **Delete** underneath the Link Aggregation table.

Displaying LACP Parameters and Statistics

You can display the following LACP parameters and statistics:

- LACP Aggregation (per LAG)
- LACP Port Status
- LACP Port Statistics
- LACP Port Debug Statistics

**Note**

PTP 820 does not support any LACP write parameters.

Displaying LACP Aggregation Status Parameters

To display LACP aggregation status parameters:

1. Select **Ethernet > Protocols > LACP > Aggregation** to open the LACP Aggregation page.

Figure 104 LACP Aggregation Page




Table 30 LACP Port Status Page

Parameter	Definition
LAG Interface Location	Identifies the LAG group.
Administrative Key	The current administrative value of the key for the Aggregator.
Aggregator MAC Address	The individual MAC address assigned to the Aggregator.
Aggregate or Individual	Indicates whether the Aggregator represents an aggregate or an individual link.
Frame Collector Maximum Delay	The maximum delay, in tens of microseconds.
Actor System ID	The MAC address value used as a unique identifier for the system that contains this Aggregator.
Actor System Priority	The priority value associated with the Actor’s System ID.
Actor Operational Key	The current operational value of the Key for the Aggregator.
Partner System ID	The MAC address value consisting of the unique identifier for the current protocol Partner of this Aggregator.
Partner System Priority	The priority value associated with the Partner’s System ID.
Partner Operational Key	The current operational value of the Key for the Aggregator’s current Protocol partner.

Displaying LACP Port Status Parameters

To display LACP port status parameters:

1. Select **Ethernet > Protocols > LACP > Port > Status** to open the LACP Port Status page.

Figure 105 LACP Port Status Page

Port Interface Location	Selected Aggregator ID	Attached Aggregator ID	Aggregate Or Individual	Actor Operational Key	Actor Operational State	Partner Operational Key	Partner Operational State
Ethernet Slot 1, Port 1	LAG Group #1	LAG Group #1	Aggregate	1	Active: Yes Short Timeout: No Aggregatable: Yes Sync: Yes Collecting: Yes Distributing: Yes Defaulted: No Expired: No	1	Active: Yes Short Timeout: No Aggregatable: Yes Sync: Yes Collecting: Yes Distributing: Yes Defaulted: No Expired: No
Ethernet Slot 1, Port 2	LAG Group #1	LAG Group #1	Aggregate	1	Active: Yes Short Timeout: No Aggregatable: Yes Sync: Yes Collecting: Yes Distributing: Yes Defaulted: No Expired: No	1	Active: Yes Short Timeout: No Aggregatable: Yes Sync: Yes Collecting: Yes Distributing: Yes Defaulted: No Expired: No

2. The LACP Port Status page displays the major port status parameters, per port. To display all the available LACP port status parameters, select a port and click View. The LACP Port Status – View page is displayed.

Figure 106 LACP Port Status – View Page

The screenshot shows a web-based configuration window titled "LACP Port Status - View". The window contains several input fields for LACP port parameters. The parameters are organized into sections: Port Interface Location, Selected/Attached Aggregator ID, Aggregate Or Individual, Actor System ID, Actor System Priority, Actor Port, Actor Port Priority, Actor Administrative Key, Actor Administrative State, Actor Operational Key, Actor Operational State, Partner Operational Key, Partner Operational State, Partner Operational System ID, Partner Operational System Priority, Partner Operational Port, Partner Operational Port Priority, Partner Administrative Key, Partner Administrative State, Partner Administrative System ID, Partner Administrative System Priority, Partner Administrative Port, and Partner Administrative Port Priority. At the bottom, there is a "Page Refresh Interval (Seconds)" dropdown set to "None", a "Last Loaded: 12:20:05" timestamp, and "Refresh" and "Close" buttons.

Parameter	Value
Port Interface Location	Ethernet: Slot 1, Port 1
Selected Aggregator ID	LAG: Group #1
Attached Aggregator ID	LAG: Group #1
Aggregate Or Individual	Aggregate
Actor System ID	00:0A:25:40:1F:8C
Actor System Priority	32768
Actor Port	1
Actor Port Priority	32768
Actor Administrative Key	1
Actor Administrative State	
Actor Operational Key	1
Actor Operational State	
Partner Operational Key	0
Partner Operational State	
Partner Operational System ID	00:00:00:00:00:00
Partner Operational System Priority	0
Partner Operational Port	0
Partner Operational Port Priority	0
Partner Administrative Key	0
Partner Administrative State	
Partner Administrative System ID	00:00:00:00:00:00
Partner Administrative System Priority	0
Partner Administrative Port	0
Partner Administrative Port Priority	0

Table 31 LACP Port Status Parameters

Parameter	Definition
Port Interface Location	The location of the port.
Selected Aggregator ID	The identifier value of the Aggregator that this Aggregation port has currently selected.
Attached Aggregator ID	The identifier value of the Aggregator that this Aggregation port is currently attached to.
Aggregate or Individual	Indicates whether the Aggregation Port is able to aggregate or is only able to operate as an individual link.
Actor System ID	The MAC Address value that defines the value of the System ID for the system that contains this Aggregation Port.
Actor System Priority	The priority value associated with the Actor's System ID.

Parameter	Definition
Actor Port	The port number locally assigned to the Aggregation Port.
Actor Port Priority	The priority value assigned to this Aggregation Port.
Actor Administrative Key	The current administrative value of the Key for the Aggregation Port.
Actor Administrative State	The administrative values of the Actor's state as transmitted by the Actor via LACPDUs.
Actor Operational Key	The current operational value of the Key for the Aggregation Port.
Actor Operational State	The current operational values of the Actor's state as transmitted by the Actor via LACPDUs.
Partner Operational Key	The current operational value of the Key for the protocol Partner.
Partner Operational State	The current values of Actor State in the most recently received LACPDUs transmitted by the protocol Partner.
Partner Operational System ID	The MAC Address value representing the current value of the Aggregation Port's protocol Partner's System ID.
Partner Operational System Priority	The operational value of priority associated with the Partner's System ID.
Partner Operational Port	The operational port number assigned to this Aggregation port by the Aggregation port's port Partner.
Partner Operational Port Priority	The Priority value assigned to this Aggregation port by the Partner.
Partner Administrative Key	The current administrative value of the Key for the protocol Partner.
Partner Administrative State	The current administrative value of Actor state for the protocol Partner.
Partner Administrative System ID	The MAC Address value representing the administrative value of the Aggregation Port's Protocol partner's System ID.
Partner Administrative System Priority	The administrative priority value associated with the Partner's System ID.
Partner Administrative Port	The current administrative value of the port number for the protocol partner.
Partner Administrative Port Priority	The current administrative value of the port priority for the protocol partner.

Displaying LACP Port Statistics

To display LACP port statistics:

1. Select **Ethernet > Protocols > LACP > Port > Statistics** to open the LACP Port Statistics page.

Figure 107 LACP Port Statistics Page




Table 32 LACP Port Statistics Parameters

Parameter	Definition
Port Interface Location	The location of the port.
Selected Aggregator ID	The identifier value of the Aggregator that this Aggregation port has currently selected.
LACPDUs TX	The number of LACPDUs that this port has transmitted.
LACPDUs RX	The number of LACPDUs that this port has received.
Unknown RX	The number of unknown protocol frames that this port has received.
Illegal RX	The number of illegal protocol frames that this port has received.

Displaying LACP Port Debug Statistics

To display LACP port debug statistics:

1. Select **Ethernet > Protocols > LACP > Port > Debug** to open the LACP Port Debug page.

Figure 108 LACP Port Debug Page




Table 33 LACP Port Debug Statistics

Parameter	Definition
Port Interface Location	The location of the port.
Selected Aggregator ID	The identifier value of the Aggregator that this Aggregation port has currently selected.
Debug RX State	The state of the receive state machine for the Aggregation port. Possible values are: <ul style="list-style-type: none"> • Current – An LACPDU was received before expiration of the most recent timeout period. • Expired – No LACPDU was received before expiration of the most recent timeout period. • Defaulted – No LACPDU was received during the two most recent timeout periods.
Debug Last RX Time	The value of a TimeSinceSystemReset (F.2.1) when the last LACPDU was received by this Aggregation port.
Debug Mux State	The state of the Mux state machine for the Aggregation port. Possible values are Collecting, Distributing, Attached, and Detached.
Debug Mux Reason	A text string indicating the reason for the most reason change in the state of the Mux machine.

Configuring XPIC

Cross Polarization Interference Canceller (XPIC) is a feature that enables two radio carriers to use the same frequency with a polarity separation between them. Since they will never be completely orthogonal, some signal cancellation is required.

In addition, XPIC includes an automatic recovery mechanism that ensures that if one carrier fails, or a false signal is received, the mate carrier will not be affected. This mechanism also assures that when the failure is cleared, both carriers will be operational.

This section includes:

- [Prerequisites for XPIC](#)
- [Configuring the Carriers](#)
- [Creating an XPIC Group](#)
- [Performing Antenna Alignment for XPIC](#)
- [Deleting an XPIC Group](#)

Related topics:

- [Displaying XPI PMs](#)

Prerequisites for XPIC

- For PTP 820F, XPIC requires a Multicore RFU-D.
- For PTP 820G, Each radio interface must be connected to the same type of RFU.
- For PTP 820G, XPIC requires a hardware model with two radio interfaces.
- Each radio carrier must be assigned the same script. The script must be an XPIC script. The letter X (XPIC) or N (Non-XPIC) in the script name indicates whether or not the script supports XPIC. For example:
 - The script mdN_A2828X_102_1205 supports XPIC.
 - The script mdN_A2828N_123-1005 does not support XPIC.



Note

For a list of XPIC support-enabled scripts, refer to the most recent PTP 820G Release Notes.

Configuring the Carriers

To configure the radio carriers:

1. Configure the carriers on both ends of the link to the desired frequency channel. Both carriers must be configured to the same frequency channel.
2. Assign an XPIC (CCDP operational mode) support-enabled script to the carriers on both ends of the link. Each carrier must be assigned the same script. For details, refer to [Entering Radio View \(CLI\)](#)
3. [To view](#) and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```


4. Configuring the Radio (MRMC) Script(s).
5. In the XPIC page, create an XPIC group that consists of the two RMCs that will be in the XPIC group. See [Creating an XPIC Group](#).

Creating an XPIC Group

To create an XPIC group:


1. Select **Radio > Groups > XPIC**. The XPIC page opens.

Figure 109 XPIC Configuration Page (Empty)




2. Click **Create Group**. The Create XPIC Group page opens.

Figure 110 Create XPIC Group Page



3. In the **Group ID** field, select an ID to identify the XPIC group.
4. In the **Member 1** field, select the first radio in the XPIC group.
5. Click **Next**. A new Create XPIC Group page opens.
6. In the **Member 2** field, select the second radio in the XPIC pair.
7. Click **Next**. A new Create XPIC Group page opens displaying the radios you have selected to include in the XPIC group.

Figure 111 Create XPIC Group Finish Page




8. To create the group with the parameters displayed, click **Submit**. To go back and change any of the parameters, click **Back**. If the XPIC group is successfully created, a confirmation page opens.

After you create an XPIC group, you must enable the group. To enable an XPIC group:

1. Select the XPIC group in the XPIC table.

Figure 112 XPIC Page (Populated)



2. Click **Edit**. The XPIC Groups - Edit page opens.

Figure 113 XPIC Edit Page

3. In the **Admin state** field, select **Enable**.
4. Click **Apply**, then **Close**. The XPIC group is enabled.

Performing Antenna Alignment for XPIC

1. Align the antennas for the first carrier. While you are aligning these antennas, mute the second carrier. See *Configuring the Radio Parameters*.
2. Adjust the antenna alignment until you achieve the maximum RSL for the first-carrier link (the “RSL_{wanted}”). This RSL should be no more than +/-2 dB from the expected level. Record the RSL of the first carrier as the RSL_{wanted}.
3. Measure the RSL of the second carrier and record it as the “RSL_{unwanted}”.
4. Determine the XPI, using either of the following two methods:
 - To calculate the XPI, subtract the RSL_{unwanted} from the RSL_{wanted}.
 - Read the XPI from the Modem XPI field of the Radio Parameters page in the Web EMS. See *Viewing the Radio Status and Settings*.
5. The XPI should be between 25dB and 30dB. If it is not, you should adjust the OMT assembly on the back of the antenna at one side of the link until you achieve the highest XPI, which should be no less than 25dB. Adjust the OMT very slowly in a right-left direction. OMT adjustment requires very fine movements and it may take several minutes to achieve the best possible XPI.



Note

As an extra step, to check the veracity of the initial measurements, you can mute the first carrier and unmute the second carrier on the upper carriers on both sides of the link. Then measure the RSL of the second carrier link (the “RSL_{wanted}”), measure the RSL of the first carrier (the “RSL_{unwanted}”) and determine the XPI. The XPI should match the XPI with the second carriers muted.

6. Unmute all the carriers and check the RSL levels of all the carriers on both sides of the link. The RSL of the horizontal carrier of the local unit should match the RSL of the vertical carrier of the remote unit, within ± 2 dB. The RSL of the vertical carrier of the local unit should match the RSL of the horizontal carrier of the remote unit, within ± 2 dB.
7. Check the XPI levels of both carriers on both sides of the link by checking the **Modem XPI** field of the Radio Parameters page in the Web EMS. See *Viewing the Radio Status and Settings*. All four carriers should have approximately the same XPI value. Do not adjust the XPI at the remote side of the link, as this may cause the XPI at the local side of the link to deteriorate.

**Note**

In some cases, the XPI might not exceed the required 25dB minimum due to adverse atmospheric conditions. If you believe this to be the case, you can leave the configuration at the lower values, but be sure to monitor the XPI to make sure it subsequently exceeds 25dB. A normal XPI level in clear sky conditions is between 25 and 30dB.

Deleting an XPIC Group

In order to delete an XPIC group, you must first disable the group:

1. Select the XPIC group in the XPIC page ([Figure 112](#)).
2. Click **Edit**. The XPIC Groups - Edit page opens ([Figure 113](#)).
3. In the **Admin state** field, select **Disable**.
4. Click **Apply**. The XPIC group is disabled.

Once the XPIC group is disabled, you can delete the group by selecting the group in the XPIC page and clicking **Delete**. You must then assign non-XPIC MRMC scripts to the radio carriers that were included in the XPIC pair.

Configuring HSB Radio Protection

**Note**

This section is only relevant for PTP 820G.

This section explains how to configure HSB radio protection and includes the following topics:

- [HSB Radio Protection Overview](#)
- [Configuring 1+1 HSB without Space Diversity](#)
- [Configuring 1+1 HSB with Space Diversity](#)
- [Copying Configuration to Mate](#)
- [Revertive Mode](#)
- [Switchovers and Lockout](#)
- [Deleting an HSB Radio Protection Group without Space Diversity](#)
- [Deleting an HSB Radio Protection Group with Space Diversity](#)
- [Configuring IF combining](#)

HSB Radio Protection Overview

**Note**

You can also use the Quick Configuration wizard to configure a 1+1 HSB Pipe link. See [Configuring a Link Using the Quick Configuration Wizard](#).

In dual-carrier systems, PTP 820G offers 1+1 HSB radio protection. With Multi-Carrier ABC, you can also configure 1+1 HSB radio protection with BBS Space Diversity.

You can configure the two fix radio interfaces as a protection group, which protects against hardware failure in the RFU. The CPU monitors the radio interfaces and initiates switchover upon indication of a hardware or signal failure.

The radios in a protected pair operate in active and standby mode. If there is a failure in the active radio, the standby radio switches to active mode.


Configuring 1+1 HSB without Space Diversity

To create a 1+1 HSB radio protection group without Space Diversity, Multi-Carrier ABC may not be configured on the unit.

To create a protection group:


1. Select **Radio > Groups > Radio Protection**. The Radio Protection page opens.

Figure 114 Radio Protection Page (Empty)



2. Click **Create Group**. The Create Radio Protection Group page opens.

Figure 115 Create Radio Protection Group Page



- In the **Group Type** field, select **1+1-HSB** and click **Next**. A new Create Radio Protection Group page opens.

Figure 116 Create Radio Protection Group Page – Member 1

- In the **Group ID** field, select an ID to identify the protection group.
- In the **Member 1** field, select the first radio carrier in the protection pair.
- Click **Next**. A new Create Radio Protection Group page opens.
- In the **Member 2** field, select the second radio carrier in the protection pair.
- Click **Next**. A new Create Radio Protection Group page opens displaying the RMCs you have selected to include in the group.

Figure 117 Create Radio Protection Group Finish Page

- To create the group with the parameters displayed, click **Submit**. To go back and change any of the parameters, click **Back**. If the protection group is successfully created, a confirmation page opens.



Note

Radio interface 1 will automatically be the active radio carrier.

- Configure the active radio interface and perform a copy-to-mate command to ensure that the radio carriers in the HSB pair have the same configuration. See [Copying Configuration to Mate](#).

11. When you have finished configuring the 1+1 HSB group, unmute both radio carriers on both sides of the link. See [Configuring the Radio Parameters](#).
12. Optionally, you can enable revertive mode so that following a switchover, the system initiates a revertive protection switchover back to the original receiver once proper link and/or equipment conditions are restored. See [Revertive Mode](#).

Configuring 1+1 HSB with Space Diversity

1. Create a Multi-Carrier ABC group with no members. For instructions, see [Configuring a Multi-Carrier ABC Group](#).
2. Enable protection for the Multi-Carrier ABC group:
 - i. Select **Radio > Groups > Multi Carrier ABC**. The Multi Carrier ABC page opens ([Figure 93](#)).
 - ii. Select the group in the Multi-Carrier ABC table and click **Edit Group**. The Multi Carrier ABC - Edit page opens.

Figure 118 Multi Carrier ABC Group – Edit Page – Enabling Protection

The screenshot shows a web-based configuration interface for a Multi Carrier ABC group. The title bar reads 'Multi Carrier ABC - Edit Group'. The form is organized into sections:

- Group Information:**
 - Group location: Multi Carrier ABC: Group #1
 - Group Name: SD_400
- Status Parameters:**
 - Operational state: Down
 - Remote Operational state: Down
 - Current Aggregated Capacity TX: 0
 - Current Aggregated Capacity RX: 0
- Configuration Parameters:**
 - Admin state: Enable
 - Protection: Enable (dropdown menu)

At the bottom of the form are three buttons: 'Apply', 'Refresh', and 'Close'.

- iii. In the **Protection** field, select **Enable**.
 - iv. Click **Apply**, then **Close**.
3. Create a 1+1 HSB-SD protection group:
 - i. Select **Radio > Groups > Radio Protection**. The Radio Protection page opens ([Figure 114](#)).
 - ii. Click **Create Group**. The Create Radio Protection Group page opens.

Figure 119 Create Radio Protection Group Page (Space Diversity Group Selected)

- iii In the **Group Type** field, select **1+1-HSB-SD** and click **Next**. The next page of the Create Radio Protection Group wizard opens.

Figure 120 Create Radio Protection Group Page – Member 1 (Space Diversity Group Selected)

- iv In the **Group ID** field, select an ID to identify the protection group.
- v In the **Member 1** field, select one of the radio interfaces.
- vi Click **Next**. The next page of the Create Radio Protection Group wizard opens.
- vii In the **Member 2** field, select the other radio interface.
- viii Click **Next**. The Create Radio Protection Group wizard displays the parameters you have selected.

Figure 121 Create Radio Protection Group Finish Page (Space Diversity Group Selected)

- ix To create the group with the parameters displayed, click **Submit**. To go back and change any of the parameters, click **Back**. If the protection group is successfully created, a confirmation page opens.

**Note**

Interface 1 is automatically the active radio carrier.

4. When you have finished configuring the 1+1 HSB group, unmute both radio carriers on both sides of the link. See [Configuring the Radio Parameters](#).
5. Configure the active interface and perform a copy-to-mate command to ensure that the radios have the same configuration. See [Copying Configuration to Mate](#).
6. Optionally, you can enable revertive mode so that following a switchover, the system initiates a revertive protection switchover back to the original receiver ten minutes after proper link and/or equipment conditions are restored. See [Revertive Mode](#).
7. Add the 1+1 HSB-SD group to the Multi-Carrier ABC group:
 - i Select **Radio > Groups > Multi Carrier ABC**. The Multi Carrier ABC page opens ([Figure 93](#)).
 - ii Select the group in the Multi-Carrier ABC table and click **Add/Remove Members**. The Multi Carrier ABC - Add/Remove Members page opens ([Figure 97](#)).
 - iii In the **Add Member** field, select **Radio Protection: Group #1** and click **Apply**.
 - iv Click **Close**.

Copying Configuration to Mate


In a 1+1 HSB configuration, it is necessary for both radio carriers to have the same configuration. PTP 820G includes a mismatch mechanism that detects if there is a mismatch between the radio configurations of the local and mate carriers. This mechanism is activated by the system periodically and independently of other protection mechanisms, at fixed intervals. It is activated asynchronously for both the active and the standby radio. Once the mismatch mechanism detects a configuration mismatch, it raises a Mate Configuration Mismatch alarm. When the configuration of the active and standby radios is changed to be identical, the mechanism clears the Mate Configuration Mismatch alarm.

In order to align the configuration between the active and standby radios, you must verify that at least one of the radios is properly configured, and then perform a copy to mate command. This command copies the entire configuration from a selected radio in the protection pair to the other radio in the pair to achieve full configuration alignment between the radio in the pair. The command also initiates a reset of the radio to which the configuration is copied. As soon as the radio to which the confirmation was copied is up and running, its configuration is aligned to the configuration of the other radio. This operation has no effect on the source radio.

To perform a copy-to-mate command:


1. **Radio > Groups > Radio Protection**. The Radio Protection page opens.

Figure 122 Radio Protection Page (Populated)



2. Select the protection group.
3. Click **Edit**. The Radio Protection Groups - Edit page opens.

Figure 123 Radio Protection Groups – Edit Page



4. In the **Copy to mate source radio location** field, select the radio you want to use as the source.
5. Click **Apply**. The Edit page is refreshed, and a **Copy to Mate** option appears on the bottom of the page.

Figure 124 Radio Protection Groups – Edit Page (Copy to Mate)

The screenshot shows a web-based configuration window titled "Radio Protection". The main content area is titled "Radio Protection Groups - Edit". It contains several configuration fields:

- Group location: Radio Protection: Group #1
- Group Type: 1+1-HSB
- Member 1 location: Radio: Slot 1, port 1 (Active)
- Member 2 location: Radio: Slot 1, port 2 (Standby)
- Lockout status: No
- Revertive mode admin: Disable (dropdown)
- Primary radio location: None (dropdown)
- Radio protection command: Clear (dropdown)
- Copy to mate source radio location: Radio: Slot 1, port 1 (dropdown)

At the bottom of the form, there are four buttons: "Apply", "Copy to Mate", "Refresh", and "Close".

1. Click **Copy to Mate**. The configuration of the selected radio is copied to the other radio in the protected pair.
2. Click **Close** to close the Radio Protection Groups – Edit page.

Revertive Mode

When revertive mode is enabled, following a switchover the system initiates a revertive protection switchover back to the original receiver ten minutes after proper link and/or equipment conditions are restored. This ensures that the primary path is used whenever possible.

For HSB-SD groups, an additional revertive mode option enables you to configure revertive mode for diversity. If a diversity switchover takes place and revertive mode is enabled for diversity, the system initiates a revertive diversity switchover back to the original receiver ten minutes after a proper signal is restored on the primary receiver.

To configure revertive mode:

1. Select **Radio > Groups > Radio Protection**. The Radio Protection page opens ([Figure 122](#)).
2. Select the protection group.
3. Click **Edit**. The Radio Protection Groups - Edit page opens ([Figure 123](#)).
4. In the **Revertive mode admin** field, select **Enable** to enable revertive protection or **Disable** to disable revertive protection.
5. In the **Revertive Rx mode admin** field, select **Enable** to enable revertive diversity or **Disable** to disable revertive diversity.

**Note**

The **Revertive Rx mode admin** field does not appear if the group is a 1+1 HSB group without Space Diversity.

6. Click **Apply**.

Switchovers and Lockout

The following events trigger switchover for 1+1 HSB protection according to their priority, with the highest priority triggers listed first.

- 1 Card missing
- 2 Lockout
- 3 Force switch
- 4 Traffic failures
- 5 Manual switch

To initiate a protection switchover or a lockout:

7. Select **Radio > Groups > Radio Protection**. The Radio Protection page opens ([Figure 122](#)).
8. Select the protection group.
9. Click **Edit**. The Radio Protection Groups - Edit page opens ([Figure 123](#)).
10. In the **Radio protection command** field, select one of the following options:
 - **Clear** – Clears an existing lockout condition.
 - **Manual switch** – Initiates a switchover, provided that the standby carrier is working correctly. Following a manual switch, the protection group operates normally, and a subsequent switchover will occur if any switchover trigger occurs.
 - **Force switch** – Forces a switchover, even if the standby carrier is in an LOF state. Following a force switch, the protection mechanism enters a lockout state. A lockout alarm and a Force Switch event are raised, and no further switchover will take place until another Force Switch is performed, or the user unlocks the lockout mode, or a cold reset is performed.
 - **Lockout** – Places the protection pair in a lockout state. To end the lockout state, select **Clear**.
1. Click **Apply**.

Deleting an HSB Radio Protection Group without Space Diversity

**Note**

Before deleting an HSB radio protection group, both members of the group must be unmuted. See [Configuring the Radio Parameters](#).

To delete a radio protection group:

2. Select **Radio > Groups > Radio Protection**. The Radio Protection page opens ([Figure 122](#)).
3. Select the protection group.
4. Click **Delete**. The protection group is deleted.

Deleting an HSB Radio Protection Group with Space Diversity

**Note**

Before deleting an HSB radio protection group, both members of the group must be unmuted. See [Configuring the Radio Parameters](#).

To delete an HSB-SD radio protection group:

1. Remove the HSB-SD group from the Multi-Carrier ABC group:
 - i Select **Radio > Groups > Multi Carrier ABC**. The Multi Carrier ABC page opens ([Figure 93](#)).
 - ii Select the group in the Multi-Carrier ABC table and click **Add/Remove Members**. The Multi Carrier ABC - Add/Remove Members page opens ([Figure 97](#)).
 - iii Select the HSB-SD group and click **Apply**, then **Close**.
2. Disable protection for the Multi-Carrier ABC group:
 - i Select **Radio > Groups > Multi Carrier ABC**. The Multi Carrier ABC page opens ([Figure 93](#)).
 - ii Select the group in the Multi-Carrier ABC table and click **Edit Group**. The Multi Carrier ABC - Edit page opens ([Figure 118](#)).
 - iii In the **Protection** field, select **Disable**.
 - iv Click **Apply**, then **Close**.
3. Delete the HSB-SD group. See [Deleting an HSB Radio Protection Group](#).
4. Delete the Multi-Carrier ABC group. See [Deleting a Multi-Carrier ABC Group](#).

Configuring IF Combining



Note

This section is only relevant for PTP 820G.

IF Combining is a space diversity configuration in which the RFU receives and processes two signals and combines them into a single, optimized signal. IF Combining requires the use of a 1500HP dual-receiver RFU.



Note

1500HP does not support IF Combining with 56 MHz channels. For 56 MHz channels, BBS can be used for space diversity applications. See [Configuring 1+1 HSB with Space Diversity](#).

To configure IF Combining:

1. **Radio > IF Combining**. The IF Combining page opens.

Figure 125 IF Combining Page

Radio location	Type	IF combiner mode	RSL Connector Source	Diversity RX Level (dBm)	Combined RX Level (dBm)	Delay Calibration Value (nSec)	Automatic delay calibration status
Radio: Slot 1, port 1	1500HP RFU	Combined	Main	43	42	0	No Action




Note

The IF Combining option only appears if the system includes at least one RFU that supports IF Combining.

2. Select the radio you want to configure and click **Edit**. The IF Combining – Edit page opens.

Figure 126 IF Combining – Edit Page



3. Configure the fields listed in the table below.
4. Click **Apply**.

Table 34 IF Combining parameters

Parameter	Definition
Radio location	Read-only. Identifies the radio carrier.
Type	Read-only. The type of RFU.
IF combiner mode	Select which radio signal to use: <ul style="list-style-type: none"> • Main – Only the Main antenna signal is selected. • Diversity – Only the Diversity antenna signal is selected. • Combined – The combined signal from both antennas is selected. To configure IF Combining, select Combined .
RSL Connector Source	Determines the signal source of the RSL connector for purposes of testing RSL output during setup or maintenance. Options are: <ul style="list-style-type: none"> • Main – RSL is taken from the Main radio interface. • Diversity – RSL is taken from the Diversity radio interface. Note: PHY1 and PHY2 are not relevant for this version.
Diversity RX Level (dBm)	Read-only. Displays the RX signal level (RSL) of the Diversity radio interface, in dBm. Note: The RX signal level (RSL) of the Main radio interface is displayed in the RX Level field of the Radio Parameters page.
Combined RX Level (dBm)	Read-only. Displays the signal level (RSL) of the Combined signal, in dBm. Note: The RX signal level (RSL) of the Main radio interface is displayed in the RX Level field of the Radio Parameters page.
Delay Calibration Value (nSec)	For manual delay calibration, in the Delay Calibration Value field, enter the number of nanoseconds to delay between the main and diversity signals.

Parameter	Definition
Automatic delay calibration status	<p data-bbox="589 241 1505 275">Note: Manual delay calibration is only utilized for Combined mode.</p> <p data-bbox="589 296 1505 464">For automatic delay calibration, click Auto Delay Calibration at the bottom of the IF Combining - Edit page. The system automatically calibrates the required delay between the signals from the main and diversity antennas. The Automatic Delay Calibration Status field displays the system status of the Automatic Delay Calibration feature. Possible values status values are:</p> <ul data-bbox="589 478 1505 667" style="list-style-type: none"> • Success – Indicates that the system has successfully calibrated the signal delay • Failure – Indicates that the system cannot automatically calibrate the signal delay. • No-Action – Indicates that the system has not performed an automatic delay calibration. <p data-bbox="589 678 1505 810">Note: Automatic delay calibration can only be performed when the system is error-free and there are no negative weather conditions. In an XPIC link, disable XPIC and mute the mate unit at the remote side of the link before performing automatic delay calibration.</p>

**Note**

You can display detailed PMs for the diversity interface and the combined signal. See [Displaying PMs for the Combined IF Combining Signal](#).

Chapter 4: Unit Management

This section includes:

- [Defining the IP Protocol Version for Initiating Communications](#)
- [Configuring the Remote Unit's IP Address](#)
- [Configuration SNMP](#)
- [Configuring Trap Managers](#)
- [Configuring the Internal Ports for FTP or SFTP](#)
- [Installing and Configuring an FTP or SFTP Server](#)
- [Upgrading the Software](#)
- [Backing Up and Restoring Configurations](#)
- [Setting the Unit to the Factory Default Configuration](#)
- [Performing a Hard \(Cold\) Reset](#)
- [Configuring Unit Parameters](#)
- [Configuring NTP](#)
- [Displaying Unit Inventory](#)

Related topics:

- [Setting the Time and Date \(Optional\)](#)
- [Enabling the Interfaces \(Interface Manager\)](#)
- [Uploading Unit Info](#)
- [Configuring External Alarms](#)
- [Changing the Management IP Address](#)

Defining the IP Protocol Version for Initiating Communications

You can specify which IP protocol the unit will use when initiating communications, such as downloading software, sending traps, pinging, or exporting configurations:

1. Select **Platform > Management > Networking > Local**. The Local Networking Configuration page opens ([Figure 25](#)).
2. From the IP Address Family drop-down list, select **IPv4** or **IPv6**. The default value is **IPv4**.
3. Click **Apply**.

Configuring the Remote Unit's IP Address

To configure the IP address of a remote unit:

1. Select **Platform > Management > Networking > Remote**. The Remote Networking Configuration page opens.

Figure 127 Remote Networking Configuration Page

Radio location	Remote Radio Location	Remote IPv4 Address	Remote Subnet mask	Remote default gateway	Remote IPv6 Address	Remote IPv6 Prefix-Length	Remote IPv6 Default Gateway
Radio: Slot 1, Port 1	Unknown	0.0.0.0	255.255.255.0	0.0.0.0	::	64	::
Radio: Slot 1, Port 2	Unknown	0.0.0.0	255.255.255.0	0.0.0.0	::	64	::

2. Select the radio on the local side of the link in which you want to configure the remote radio.



Note

To access the Web EMS of the remote unit, click the unit's IP address in the Remote IP Address column.

3. Click **Edit**. The Remote Networking Configuration – Edit page opens.

Figure 128 Remote Networking Configuration – Edit Page

4. Configure the IP parameters of the remote radio, as described in [Table 35](#).
5. Click **Apply**, then **Close**.

**Note**

To change the **Remote IP Address** to a different subnet, you must first change the address of the **Remote Default Gateway** to 0.0.0.0 and click **Apply**; then set the **Remote IP Address** as desired, and the **Remote Default Gateway** as desired.

Similarly, to change the **Remote IPv6 Address** to a different subnet, you must first change the address of the **Remote IPv6 Default Gateway** to 0:0:0:0:0:0:0:0 and click **Apply**; then set the **Remote IPv6 Address** as desired, and the **Remote IPv6 Default Gateway** as desired.

Table 35 Remote Networking Configuration Parameters

Parameter	Definition
Radio location	Read-only. Identifies the radio on the local side of the link.
Remote radio location	Read-only. Identifies the radio on the remote side of the link.
Remote IPv4 Address	Enter an IP address for the remote radio. You can enter the address in IPv4 format in this field, and/or in IPv6 format in the Remote IPv6 Address field. The unit will receive communications whether they are sent to its IPv4 address or its IPv6 address.
Remote Subnet mask	If you entered an IPv4 address, Enter the subnet mask of the remote radio.
Remote default gateway	Enter a default gateway for the remote radio (optional).

Parameter	Definition
Remote IPv6 Address	Enter an IPv6 address for the remote radio. You can enter the address in IPv6 format in this field, and/or in IPv4 format in the Remote IP Address field. The unit will receive communications whether they are sent to its IPv4 address or its IPv6 address.
Remote IPv6 Prefix-Length	Enter the IPv6 prefix length for the remote radio if you entered an IPv6 address.
Remote IPv6 Default Gateway	Enter a default IPv6 gateway address for the remote radio (optional).

Configuration SNMP

PTP 820F and PTP 820G supports SNMP v1, v2c, and v3. You can set community strings for access to IDUs.


PTP 820F and PTP 820G supports the following MIBs:

- RFC-1213 (MIB II).
- RMON MIB.
- Proprietary MIB.

To configure SNMP:

1. Select **Platform > Management > SNMP > SNMP Parameters**. The SNMP Parameters page opens.

Figure 129 SNMP Parameters Page



2. In the **Admin** field, select **Enable** to enable SNMP monitoring, or **Disable** to disable SNMP monitoring.



Note

The **Operational Status** field indicates whether SNMP monitoring is currently active (**Up**) or inactive (**Down**).

3. In the **SNMP Read Community** field, enter the community string for the SNMP read community.
4. In the **SNMP Write Community** field, enter the community string for the SNMP write community.
5. In the **SNMP Trap Version** field, select **V1**, **V2**, or **V3** to specify the SNMP version.



Note

The **SNMP MIB Version** field displays the current SNMP MIB version the unit is using.


6. In the **V1V2 Blocked** field, select **Yes** if you want to block SNMPv1 and SNMPv2 access so that only SNMPv3 access will be enabled.
7. Click **Apply**.

If you are using SNMPv3, you must also configure SNMPv3 users. SNMPv3 security parameters are configured per SNMPv3 user.

To add an SNMP user:

1. Select **Platform > Management SNMP > V3 Users**. The V3 Users page opens.

Figure 130 V3 Users Page



2. Click **Add**. The V3 Users - Add page opens.

Figure 131 V3 Users - Add Page

3. Configure the SNMP V3 Authentication parameters, as described below.
4. Click **Apply**, then **Close**.

Table 36 SNMP V3 Authentication Parameters

Parameter	Definition
User Name	Enter the SNMPv3 user name.
Password	Enter a password for SNMPv3 authentication. The password must be at least eight characters.
Authentication Algorithm	Select an authentication algorithm for the user. Options are: <ul style="list-style-type: none"> • None • SHA • MD5
Encryption (Privacy) Mode	Select an encryption (privacy) protocol for the user. Options are: <ul style="list-style-type: none"> • None • DES • AES
Access Mode	Select an access permission level for the user. Options are: <ul style="list-style-type: none"> • Read Write User • Read Only User


Configuring Trap Managers

You can configure trap forwarding parameters by editing the Trap Managers table. Each line in the Trap Managers table displays the setup for a manager defined in the system.

To configure trap managers:

1. Select **Platform > Management SNMP > Trap Managers**. The Trap Managers page opens.

Figure 132 Trap Managers Page



2. Select a trap manager and click Edit. The Trap Managers Edit page opens.

Figure 133 Trap Managers - Edit Page

3. Configure the trap manager parameters, as described in [Table 37 Trap Manager Parameters](#).
4. Click **Apply**, then **Close**.

Table 37 Trap Manager Parameters

Parameter	Definition
IPv4 Address	If the IP address family is configured to be IPv4, enter the destination IPv4 address. Traps will be sent to this IP address. See Defining the IP Protocol Version for Initiating Communications .
IPv6 Address	If the IP address family is configured to be IPv6, enter the destination IPv6 address. Traps will be sent to this IP address. See Defining the IP Protocol Version for Initiating Communications .
Description	Enter a description of the trap manager (optional).
Admin	Select Enable or Disable to enable or disable the selected trap manager.
Community	Enter the community string for the SNMP read community.
Port	Enter the number of the port through which traps will be sent.
Heartbeat Period	Enter the interval, in minutes, between each heartbeat trap.
CLLI	Enter a Common Language Location Identifier (CLLI). The CLLI is free text that will be sent with the trap. You can enter up to 100 characters.
V3 User Name	If the SNMP Trap version selected in Figure 129 SNMP Parameters Page page is V3 , enter the name of a V3 user defined in the system. To view or define a V3 user, use the Figure 130 V3 Users Page page. Note: Make sure that an identical V3 user is also defined on the manager's side.

Configuring the Internal Ports for FTP or SFTP

By default, the following PTP 820 ports are used for FTP and SFTP when the PTP 820 unit is acting as an FTP or SFTP client (e.g., software downloads, configuration file backup and restore operations):


- FTP – 21
- SFTP – 22

You can change either or both of these ports from the following pages:

- Platform > Software > Download & Install
- Platform > Configuration > Configuration Management
- Platform > Security > General > Security Log Upload
- Platform > Security > General > Configuration Log Upload
- Platform > Security > X.509 Certificate > CSR
- Platform > Security > X.509 Certificate > Download & Install

From any of these pages, click **FTP Port**. The FTP Port page opens.

Figure 134 FTP Port Page



File transfer protocol	File transfer port number
FTP	21
SFTP	22

Apply

Last Loaded: 15:35:32 Refresh Close

110%

Edit the **File transfer port number** for FTP and or SFTP and click **Apply**.

Installing and Configuring an FTP or SFTP Server

Several tasks, such as software upgrade and configuration backup, export, and import, require the use of FTP or SFTP. The PTP 820G and PTP 820F can function as an FTP or SFTP client. To use the PTP 820F and PTP 820G as an FTP/SFTP client, you must install FTP/SFTP server software on the PC or laptop you are using.

**Note**


For FTP, it is recommended to use FileZilla_Server software that can be downloaded from the web (freeware).

For SFTP, it is recommended to use SolarWinds SFTP/SFCP server (freeware).

If you are using IPv6 to perform the operation, make sure to use FileZilla version 0.9.38 or higher to ensure IPv6 support. If you are using another type of FTP or SFTP server, make sure the application version supports IPv6.


To install and configure FTP or SFTP server software on the PC or laptop:

1. Create a user and (optional) password on the FTP/SFTP server. For example, in FileZilla Server, perform the following:
 - I. From the Edit menu, select Users.
 - II. In the Users window, click Add.
 - III. In the Add user account window, enter a user name and click OK.
 - IV. In the Users window, select Enable account and, optionally, select Password and enter a password.
 - V. In the Users window, click OK.

Figure 135 FileZilla Server User Configuration

2. Create a shared FTP/SFTP folder on the PC or laptop you are using to perform the software upgrade (for example, `C:\FTPServer`).
3. In the FTP/SFTP server, set up the permissions for the shared FTP/SFTP folder. For example, in FileZilla Server:
 - I. From the **Edit** menu, select **Users**.
 - II. In the Users window, select **Shared folders**.
 - III. Underneath the Shared folders section, click **Add** and browse for your shared FTP folder.
 - IV. Select the folder and click **OK**.
 - V. In the Shared folders section, select your shared FTP folder.
 - VI. In the Files and Directories sections, select all of the permissions.
 - VII. Click **OK** to close the Users window.

Figure 136 FileZilla Server Shared Folder Setup



Upgrading the Software

PTP 820G and PTP 820F software and firmware releases are provided in a single bundle that includes software and firmware for all components and card types supported by the system, including RFURFURFUs. Software is first downloaded to the system, then installed. After installation, a reset is automatically performed on all components whose software was upgraded. RFU software must be installed separately, via the CLI.

This section includes:

- [Viewing Current Software Versions](#)
- [Software Upgrade Overview](#)
- [Downloading and Installing Software](#)
- [Configuring a Timed Installation](#)

Viewing Current Software Versions

To display a list of software packages currently installed and running on the system modules:

- 1 Select **Platform > Software > Versions**. The Versions page opens. For a description of the information provided in the Versions page, see [Table 38 Versions Page Columns](#).

Figure 137 Versions Page

Package Name	Target Device	Running Version	Installed Version	Downloaded version	ResetType
gns	Cleared	9.2.0.0.414	9.2.0.0.414	9.2.0.0.414	Main board cold reset
gns-fpga-fw-elic	LIC-X E4 Elec	N/A	1.8.3	1.8.3	Main board cold reset
gns-fpga-fw-rmc	RMC-A	N/A	2.3	2.3	Main board cold reset
gns-rmc-b	RMC-B	N/A	3.7.51	3.7.51	Main board cold reset
gns-fpga-fw-tcc	TCC-B	4a	N/A	N/A	TCC cold reset
gns-atp	TCC-B	9.2.0.0.414	N/A	N/A	No Reset
gns-management	TCC-B	1.9.2.25	1.9.2.25	1.9.2.25	Main board cold reset
gns-mcfl	TCC-B	9.2.0.0.414	9.2.0.0.414	9.2.0.0.414	Main board cold reset
gns-mrmc-scripts	RMC-A	N/A	7.16	7.16	Main board cold reset
gns-mrmc-b-scripts	RMC-B	N/A	2.56	2.56	Main board cold reset
gns-rfu	Cleared	N/A	3.0.11	3.0.11	Main board cold reset
gns_tcc-config	TCC-B	N/A	N/A	N/A	No Reset
gns_tcc-kernel	TCC-B	2.6.34.8	N/A	N/A	No Reset
gns-modem-fw	RMC-A	N/A	3.40.2	3.40.2	Main board cold reset
gns-pwc	LIC-T16 ACR	N/A	6.23	6.23	Main board cold reset
gns-pwc-stm1	LIC-T155 ACR	N/A	6.24	6.24	Main board cold reset
gns-vm-control	Cleared	N/A	1.0.2.12	1.0.2.12	Main board cold reset
gns-fpga-fw-hrzn	Cleared	N/A	N/A	N/A	No Reset

Table 38 Versions Page Columns

Parameter	Definition
Package Name	The name of the software package.
Target Device	The specific component on which the software runs.
Running Version	The software version currently running on the component.
Installed Version	The software version currently installed for the component. If the installed version is not already the running version, it will become the running version after the next reset takes place.

Parameter	Definition
Downloaded Version	The version, if any, that has been downloaded from the server but not yet installed. Upon installation, this version will become the Installed Version.
Reset Type	The level of reset required by the component in order for the Installed Version to become the Active Version. A cold (hard) reset powers down and powers back up the component. A warm (soft) reset simply reboots the software or firmware in the component.

Software Upgrade Overview

The PTP 820 software installation process includes the following steps:

- **Download** – The files required for the installation or upgrade are downloaded from a remote server.
- **Installation** – The downloaded software and firmware files are installed in all modules and components of the PTP 820 that are currently running an older version.
- **Reset** – The PTP 820G and PTP 820F is restarted in order to boot the new software and firmware versions.

Software and firmware releases are provided in a single bundle that includes software and firmware for all components and card types supported by the system, including RFUs. When you download a software bundle, the system verifies the validity of the bundle. The system also compares the files in the bundle to the files currently installed in the PTP 820G/ F and its components, so that only files that need to be updated are actually downloaded. A message is displayed for each file that is actually downloaded.



Note

When downloading an older version, all files in the bundle may be downloaded, including files that are already installed.

Software bundles can be downloaded via FTP or SFTP. After the software download is complete, you can initiate the installation.

Although [RFU] RFU software is included in the standard installation bundle, the current software version is not automatically updated in the [RFU] RFU when an installation is performed. To upgrade the software in an RFU, you must perform the upgrade manually, per slot. This enables you to manage IDU and [RFU] RFU software versions separately.



Note

Before performing a software upgrade, it is important to verify that the system date and time are correct. See [Setting the Time and Date \(Optional\)](#).

Downloading and Installing Software

You can download software using HTTP, HTTPS, FTP, or SFTP.

When downloading software via HTTP or HTTPS, the PTP 820G or PTP 820F functions as the server, and you can download the software directly to the PTP 820G or PTP 820F unit.



Note

HTTP and HTTPS can only be used to download files for software version 9.5 and later. If there is a requirement to downgradeto a version earlier than software version 9.5 using HTTP or HTTPS, contact Cambium Customer Support for assistance..


When downloading software, the PTP 820G/ F functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the software upgrade. For details, see [Configuring the Internal Ports for FTP or SFTP](#)

Downloading software Via HTTP and HTTPS

To download and install a new software version using HTTP or HTTPS:

1. Before performing a software upgrade, it is important to verify that the system date and time are correct. See [Setting the Time and Date \(Optional\)](#).
2. In the PTP 820G or PTPT 820F’s Web EMS, select **Platform > Software > Download & Install**. The Download & Install page opens.

Figure 138 Download & Install Page – HTTP/ HTTPS Download – No File Selected.



3. Select **HTTP**.
4. Click **Choose File**. A browse window opens.
5. Navigate to the directory in which the software file is located and select the file. The selected file must be a ZIP file.
6. Click **Open**. The file name of the selected file appears in the **File Name** field.

Figure 139 Download & Install Page – HTTP/HTTPS Download –File Selected

1. Click **Download**. The download begins. You can view the status of the download in the **Download Status** field.

**Note**

To discontinue the download process, click **Abort**.

2. Once the download has been completed, verify that the version you want to install has been downloaded. You can check the downloaded version for each component by viewing the *Downloaded Version* column in the Versions page. See [Viewing Current Software Versions](#).

Downloading Software Via FTP or SFTP


Installing and Configuring an FTP or SFTP Server.

To download and install a new software version:

1. Before performing a software upgrade, it is important to verify that the system date and time are correct. See [Setting the Time and Date \(Optional\)](#).
2. Install and configure FTP or SFTP server software on the PC or laptop you are using to perform the software upgrade, as described in [Installing and Configuring an FTP or SFTP Server](#).
3. Unzip the new software package for PTP 820G/ F into your shared FTP or SFTP folder.
4. In the PTP 820's Web EMS, select **Platform > Software > Download & Install**. The Download & Install page opens.


5. Select FTP.

Figure 140 Download & Install Page



6. Click **FTP Parameters** to display the FTP Parameters page.


Figure 141 FTP Parameters Page



7. In the **File Transfer Protocol** field, select the file transfer protocol you want to use (**FTP** or **SFTP**).
8. In the **Username** field, enter the user name you configured in the FTP server.
9. In the **Password** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP/SFTP user, simply leave this field blank.

10. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP/SFTP server in the **Server IPv4 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
11. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP/SFTP server in the **Server IPv6 Address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
12. In the **Path** field, enter the directory path from which you are downloading the files. Enter the path relative to the FTP user's home directory, not the absolute path. If the location is the home directory, it should be left empty. If the location is a sub-folder under the home directory, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "//".
13. Click **Apply** to save your settings, then **Close** to close the FTP Parameters page.

Figure 142 Install Parameters Page



14. Click **Download**. The download begins. You can view the status of the download in the **Download Status** field. See [Table 39 Download & Install Status Parameters](#).
15. Once the download has been completed, verify that the version you want to install has been downloaded. You can check the downloaded version for each component by viewing the *Downloaded Version* column in the Versions page. See [Viewing Current Software Versions](#).



Caution

If upgrading from version 7.9 or earlier:

Before you proceed to install the software, repeat the download process even if **Download Success** is displayed in the **Download status** field, until the unit displays the message **No new software modules found**.

Microwave radio: Download & Install

Download & Install - Status parameters

Download status: No new software modules found

Download progress: 0%

Install status: Ready

Install progress: 0%

Download & Install - Configuration parameters

File transfer protocol: FTP ▾

Username: anonymous

Password: *****

Server IPv4 address: 192.168.1.10

Server IPv6 address: ::

Path: //

Timed installation: No ▾

Apply
Download
Install
Refresh

In case of failure, wait at least 30 minutes and repeat the software download.

16. Click **Install**. The installation begins. You can view the status of the installation in the Download & Install - Status Parameters section of the **Installation Status** field. See [Table 39 Download & Install Status Parameters](#).

Installing Software



Note

For instructions how to configure a timed installation, see *Configuring a Timed Installation*.

To install software:

1. Download the software version you want to install. See [Downloading and Installing Software](#).
2. Select **Platform > Software > Download & Install**. The Download & Install page opens.
3. Click **Install**. The installation begins. You can view the status of the installation in the **Installation Status** field. See [Table 39 Download & Install Status Parameters](#).



Note

RFU software must be installed separately. See [Installing RFU Software](#).

Upon completion of the installation, the system performs an automatic reset.



Note

- DO NOT reboot the unit during the software installation process. As soon as the process is successfully completed, the unit will reboot itself.
- Sometimes the installation process can take up to 30 minutes.
- Only in the event that software installation was not successfully finished and more than 30 minutes have passed can the unit be rebooted.

Table 39 Download & Install Status Parameters

Parameter	Definition
Download Status	<p>The status of any pending software download. Possible values are:</p> <ul style="list-style-type: none"> • Ready – The default value, which appears when no download is in progress. • Verifying download files – The system is verifying the files to be downloaded. • Download in progress – The download files have been verified, and the download is in progress. <p>If an error occurs during the download, an appropriate error message is displayed in this field.</p> <p>When the download is complete, one of the following status indications appears:</p> <ul style="list-style-type: none"> • Download Success • Download Failure • All components already found in the system <p>When the system is reset, the Download Status returns to Ready.</p>
Download Percentage	Displays the progress of the current software download.
Install Status	<p>The status of any pending software installation. Possible values are:</p> <ul style="list-style-type: none"> • Ready – The default value, which appears when no installation is in progress. • Verifying installation files – The system is verifying the files to be installed. • Installation in progress – The installation files have been verified, and the installation is in progress. <p>If an error occurs during the installation, an appropriate error message is displayed in this field.</p> <p>When the installation is complete, one of the following status indications appears:</p> <ul style="list-style-type: none"> • Installation Success • Installation Partial Success • Installation Failure • incomplete-sw-version <p>When the system is reset, the Installation Status returns to Ready.</p>
Install Percentage	Displays the progress of the current software installation.


Configuring a Timed Installation

You can schedule a timed (deferred) software installation to take place at any time within 24 hours after you configure the installation.

To schedule a timed software installation:


1. Download the software version you want to install. See [Downloading and Installing Software](#).
2. Select **Platform > Software > Timer Parameters**. The Timer Parameters – Software Installation page opens.
3. Click **Install Parameters**. The Install Parameters page opens.

Figure 143 Install Parameters page



4. Select **Yes** in the **Timed installation** field.
5. Click **Apply**. The **Software management timer field** appears.

Figure 144 Timer Parameters - Software Installation Page



6. In the **Software management timer** field, enter the amount of time, in hours and minutes, you want to defer the installation. For example, in [Figure 144](#), the timer is set for two hours after the timer was configured (02:00).
7. Click **Apply**, the close to close the Install Parameters Page.

Installing RFU Software

Although RFU software is included in the standard installation bundle, the current software version is not automatically updated in the RFU when an installation is performed. To upgrade the software in an RFU you must perform the upgrade manually, per slot. This enables you to manage IDU and RFU[RFU]software versions separately.

In this version, you must use the Command Line Interface (CLI) to upgrade RFU software. For instructions, refer to [Installing and Upgrading Software in the RFU \(CLI\)](#).

Backing Up and Restoring Configurations

You can import and export PTP 820G and PTP 820-F configuration files. This enables you to copy the system configuration to multiple PTP 820G and PTP 820F units. You can also backup and save configuration files.

This section includes:

- [Configuration Management Overview](#)
- [Viewing Current Backup Files](#)
- [Setting the Configuration Management Parameters](#)
- [Exporting a Configuration File](#)
- [Importing a Configuration File](#)
- [Deleting a Configuration File](#)
- [Backing Up the Current Configuration](#)
- [Restoring a Saved Configuration](#)

Configuration Management Overview

System configuration files consist of a zip file that contains three components:

- A binary configuration file used by the system to restore the configuration.
- A text file which enables users to examine the system configuration in a readable format. The file includes the value of all system parameters at the time of creation of the backup file.
- An additional text file which enables you to write CLI scripts in order to make desired changes in the backed-up configuration. This file is executed by the system after restoring the configuration.

The system provides three restore points to manage different configuration files. Each restore point contains a single configuration file. Files can be added to the restore points by creating backups of the current system state or by importing them from an external server. For example, you may want to use one restore point to keep a last good configuration, another to import changes from an external server, and the third to store the current configuration.

You can apply a configuration file to the system from any of the restore points.

Viewing Current Backup Files

The system provides three restore points to manage different configuration files. Each restore point contains a single configuration file. Files can be added to the restore points by creating backups of the current system state or by importing them from an external server. For example, you may want to use one restore point to keep a last good configuration, another to import changes from an external server, and the third to store the current configuration.

To display the configuration files currently saved at the system restore points:

1. Select **Platform > Configuration > Backup Files**. The Backup Files page opens. For a description of the information provided in the Backup Files page, see [Table 40 Backup Files Page Columns](#).

Figure 145 Backup Files Page




Table 40 Backup Files Page Columns

Parameter	Definition
File number	A number from 1 to 3 that identifies the restore point.
Original system type	The type of unit from which the backup configuration file was created.
Software version	The software version of the unit from which the backup configuration file was created.
Time of creation	The time and date on which the configuration file was created.
Original IP address	The IP address of the unit from which the configuration file was created.
System ID	The System ID, if any, of the unit from which the configuration file was created. This is taken from the Name field in the Unit Parameters page. See Configuring Unit Parameters .
Valid	Reserved for future use.

Setting the Configuration Management Parameters


When importing and exporting configuration files, the PTP 820G/ F functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the import or export. For details, see [Configuring the Internal Ports for FTP or SFTP](#)

Installing and Configuring an FTP or SFTP Server.

Before importing or exporting a configuration file, you must perform the following steps:

1. Verify that the system date and time are correct. See [Setting the Time and Date \(Optional\)](#).
2. Install and configure an FTP server on the PC or laptop you are using to perform the import or export. See [Configuring the Internal Ports for FTP or SFTP](#).
3. In the PTP 820G's Web EMS, select **Platform > Configuration > Configuration Management**. The Configuration Management page opens.

Figure 146 Configuration Management Page



4. Click **FTP Parameters** to display the FTP Parameters page.

Figure 147 FTP Parameters Page (Configuration Management)

The screenshot shows a web-based configuration window titled "FTP Parameters". It includes the following fields and controls:

- Username:** Text input field containing "anonymous".
- Password:** Password input field with masked characters (dots).
- Server IP address:** Text input field containing "0.0.0.0".
- Server IPv6 address:** Text input field containing "::".
- Path:** Empty text input field.
- File name:** Empty text input field.
- Apply:** A button to save the changes.
- Footer:** A bar containing "Page Refresh Interval (Seconds)" with a dropdown menu set to "None", "Last Loaded: 15:38:38", "Refresh" button, and "Close" button.

5. In the **File transfer protocol** field, select the file transfer protocol you want to use (**FTP** or **SFTP**).
6. In the Username field, enter the user name you configured in the FTP server.
7. In the Password field, enter the password you configured in the FTP server. If you did not configure a password for your FTP user, simply leave this field blank.
8. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP server in the **Server IP address** field. See Defining the IP Protocol Version for Initiating Communications.
9. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP server in the **Server IPv6 address** field. See Defining the IP Protocol Version for Initiating Communications.
10. In the **Path** field, enter the location of the file you are downloading or uploading. If the location is the root shared folder, it should be left empty. If the location is a sub-folder under the root shared folder, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "/"..
11. Click **Apply**, then **Close**, to save the FTP parameters and return to the Configuration Management page.
12. In the **File name** field, enter the name of the file you are importing, or the name you want to give the file you are exporting.

**Note**

You must add the suffix **.zip** to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix **.zip** manually.

13. Click **Apply**, then **Close**, to save the FTP parameters and return to the Configuration Management page.
14. In the **File number** field, select from three system restore points:
 - When you import a configuration file, the file is saved to the selected restore point, and overwrites whichever file was previously held in that restore point.
 - When you export a configuration file, the file is exported from the selected restore point.
 - When you back up the current configuration, the backup configuration file is saved to the selected restore point, and overwrites whichever file was previously held in that restore point.

- When you restore a configuration, the configuration file in the selected restore point is the file that is restored.

**Note**

The **Timed installation** field is reserved for future use.

15. Click **Apply** to save your settings.

Exporting a Configuration File

You can export a saved configuration file from one of the system's three restore points to a PC or laptop.

To export a configuration file:

1. Verify that you have followed all the steps in [Setting the Configuration Management Parameters](#).
2. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens ([Figure 146](#)).
3. In the **File Number** field, select the restore point from which you want to export the file.
4. Click **Apply** to save your settings.
5. Click **Export**. The export begins. You can view the status of the export in the **File Transfer status** field in the Export/Import file status section. Possible values are:
 - **Ready** – The default value, which appears when no import or export is in progress.
 - **File-in-Transfer** – The file export is in progress.
 - If an error occurs during the import or export, an appropriate error message is displayed in this field.

When the import or export is complete, one of the following status indications appears:

- **Succeeded**
- **Failure**

The next time the system is reset, the **File Transfer status** field returns to **Ready**.

Importing a Configuration File

You can import a saved configuration file from a PC or laptop to one of the system's three restore points.

To import a configuration file:

1. Verify that you have followed all the steps in [Setting the Configuration Management Parameters](#).
2. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens ([Figure 146](#)).
3. In the **File Number** field, select the restore point to which you want to import the file.
4. Click **Apply** to save your settings.
5. Click **Import**. The import begins. You can view the status of the import in the **File Transfer status** field in the Export/Import file status section. Possible values are:
 - **Ready** – The default value, which appears when no import or export is in progress.

- **File-in-Transfer** – The file import is in progress.
- If an error occurs during the import or export, an appropriate error message is displayed in this field.

When the import or export is complete, one of the following status indications appears:

- **Succeeded**
- **Failure**

The next time the system is reset, the **File Transfer status** field returns to **Ready**.

After importing the configuration file, you can apply the configuration by restoring the file from the restore point to which you saved it. See [Restoring a Saved Configuration](#).

Deleting a Configuration File

You can delete a saved configuration file from any of the system's three restore points:

To delete a configuration file:

1. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens ([Figure 146](#)).
2. In the **File Number** field, select the restore point that holds the configuration file you want to delete.
3. Click **Delete**. The file is deleted.

Backing Up the Current Configuration

You can back up the current configuration file to one of the system's three restore points.

To back up a configuration file:

1. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens ([Figure 146](#)).
2. In the **File Number** field, select the restore point to which you want to back up the file. If another configuration file is already saved to that restore point, it will be overwritten by the file you back up.
3. Click **Backup**. The backup begins. You can view the status of the backup in the **Backup file creation status** field. Possible values in the status field are:
 - **Ready** – The default value, which appears when no backup is in progress.
 - **Generating file** – The system is verifying the files to be backed up.

If an error occurs during the backup, an appropriate error message is displayed in this field.

When the backup is complete, one of the following status indications appears:

- **Succeeded**
- **Failure**

The next time the system is reset, the **Backup file creation status** field returns to **Ready**.

Restoring a Saved Configuration

You can replace the current configuration with any configuration file saved to one of the system's three restore points by restoring the configuration file from the restore point.

To restore a configuration file:

1. Select **Platform > Configuration > Configuration Management**. The Configuration Management page opens ([Figure 146 Configuration Management Page](#)).
2. In the **File Number** field, select the restore point that holds the configuration you want to restore.
3. Click **Restore**. The configuration restoration begins. You can view the status of the restoration in the **Configuration restore status** field.

**Note**


While a configuration restoration is taking place, no user can make any changes to the configuration. All system configuration parameters are read-only during the configuration restoration.

Setting the Unit to the Factory Default Configuration

To restore the factory default settings:

1. Select **Platform > Management > Set to Factory Default**. The Set to Factory Default page opens.

Figure 148 Set to Factory Default Page




2. Click **Set to Factory Default**. The unit is restored to its factory default settings. This does not change the unit's IP address.

Performing a Hard (Cold) Reset

To initiate a hard (cold) reset on the unit:

1. Select **Platform > Management > Reset**. The Reset page opens.
2. Click **Reset**. The unit is reset.

Figure 149 Reset Page



Configuring Unit Parameters

To view and configure system information:

1. Select **Platform > Management > Unit Parameters**. The Unit Parameters page opens.

Table 41 describes the fields in the Unit Parameters page.

Figure 150 Unit Parameters Page




Table 41 Unit Parameters

Parameter	Definition
Name	A name for the unit (optional). This name appears at the top of every Web EMS page.
Description	Descriptive information about the unit. This information is used for debugging, and should include information such as the chassis type.
System up time	The time since the system was last reinitialized.
Contact person	The name of the person to be contacted if and when a problem with the system occurs (optional).
Location	The actual physical location of the node or agent (optional).
Longitude	The unit's longitude coordinates.

Parameter	Definition
Latitude	The unit's latitude coordinates.
WEB Language	Enables you to select the language in which the Web EMS is displayed. In release 10.0, the following languages are available: <ul style="list-style-type: none">• English (default)• Russian
Measurement format	The type of measurement you want the system to use: Metric or Imperial .
Unit Temperature	The current temperature of the unit.
Voltage input (Volt)	The voltage input of the unit.

Configuring NTP

PTP 820G and PTP 820F support Network Time Protocol (NTP). NTP distributes Coordinated Universal Time (UTC) throughout the system, using a jitter buffer to neutralize the effects of variable latency.

To view and configure the NTP Parameters:

1. Select **Platform > Management > NTP Configuration**. The NTP Configuration page opens.

Figure 151 NTP Configuration Page

2. In the **Admin** field, select **Enable**.
3. In the **NTP version** field, select the NTP version you want to use. Options are **NTPv3** and **NTPv4**. NTPv4 provides interoperability with NTPv3 and with SNTP.
4. In the **NTP server IP address** field, enter the IP address of the NTP server.
5. Click **Apply**.

Table 42 describes the status parameters that appear in the NTP Configuration page.

Table 42 NTP Status Parameters

Parameter	Definition
Poll interval	Displays the interval used by the NTP client to maintain synchronization with the current NTP server.


Parameter	Definition
Sync on NTP server IP address	Displays the IP address of the remote NTP server on which the NTP client is currently locked.
Client lock status	Indicates if the NTP client is locked on a remote NTP server. Possible values are: <ul style="list-style-type: none"><li data-bbox="526 436 1149 457">• LOCK – The NTP client is locked on the remote server.<li data-bbox="526 485 1260 548">• LOCAL – The NTP client is locked on the local system clock (free running clock).<li data-bbox="526 569 1084 590">• N/A – The NTP client is not locked on any clock.

Displaying Unit Inventory

To view the unit's part number and serial number:

1. Select **Platform > Management > Inventory**. The Inventory page opens, showing the unit's part number and serial number.

Figure 152 Inventory Page



Chapter 5: Radio Configuration

This section includes:

- [Viewing the Radio Status and Settings](#)
- [Configuring the IDU-RFU Connection \(PTP 820F only\)](#)
- [Configuring the Remote Radio Parameters](#)
- [Configuring ATPC and Override Timer](#)[Configuring ATPC](#)
- [Configuring Header De-Duplication](#)
- [Configuring Frame Cut-Through](#)
- [Viewing Header De-Duplication and Frame Cut-Through Counters](#)
- [Configuring AES-256 Payload Encryption](#)
- [Configuring and Viewing Radio PMs and Statistics](#)

Related topics:

- [RFU Overview](#)
- [Configuring the Radio Parameters](#)
- [Entering Radio View \(CLI\)](#)
- [To view](#) and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- [Configuring the Radio \(MRMC\) Script\(s\)](#)
- [Radio Configurations](#)
- [Configuring Multi-Carrier ABC](#)
- [Configuring XPIC](#)
- [Configuring HSB Radio Protection](#)
- [Performing Radio Loopback](#)

Viewing the Radio Status and Settings

You can configure the radios and display the radio parameters in the Radio Parameters page.



Note

For instructions how to configure the radio parameters, see [Configuring the Radio Parameters](#).

To display the radio parameters:

1. Select **Radio > Radio Parameters**. The Radio Parameters page opens.

Figure 153 Radio Parameters Page

Radio Location	Type	TX Frequency (MHz)	RX Frequency (MHz)	Operational TX Level (dBm)	RX Level (dBm)	Modem MSE (dB)	Defective Blocks	TX Mute Status
Radio: Slot 1, Port 1	Unknown	37086.000	38346.000	0	-99	-99.00	0	On
Radio: Slot 1, Port 2	Unknown	37086.000	38346.000	0	-99	-99.00	0	On



Note

For PTP 820G, the fixed radio interfaces are identified as Slot 1 Port 1 and Slot 1 Port 2.
For PTP 820F, Port 2 represents the second radio carrier in a Multi-Carrier RFU.

2. To display detailed status parameters of a specific radio, select the radio in the Radio table and click **Edit**. A separate configuration page opens.

Figure 154 Radio Parameters Page Per Carrier

The screenshot shows a web-based configuration window titled "Radio Parameters". It is divided into three main sections:

- Status Parameters:** This section contains fields for:
 - Radio Location: Radio: Slot 1, Port 1
 - Type: Unknown
 - Part Number: -
 - Serial-Number: -
 - Running Software Version: -
 - XPIC support: No
 - Radio Interface operational status: Down
 - Operational TX Level (dBm): 0
 - RX Level (dBm): -99
 - Modem MSE (dB): -99.00
 - Defective Blocks: 0 (with a "Clear Counter" button)
 - TX Mute Status: On
 - Adaptive TX power operational status: Down
 - Temperature: N/A
- Frequency control (Local):** This section contains:
 - TX Frequency (MHz): 37086.000 (range: 13.250 ... 2147470.390)
 - RX Frequency (MHz): 38346.000 (range: 13.250 ... 2147470.390)
 - Frequency Separation (MHz): 1260.000
 - Set also remote unit
- Configuration Parameters:** This section contains:
 - TX Level (dBm): 15 (range: -50 ... 50)
 - TX mute: On (dropdown)
 - RSL Connector Source: Main (dropdown)
 - Link Id: 1 (range: 1 ... 65535)
 - Adaptive TX power admin: Disable (dropdown)
 - RSL degradation alarm admin: Disable (dropdown)
 - RSL degradation threshold: -68 (dropdown)

At the bottom of the window, there is an "Apply" button, a "Page Refresh Interval (Seconds)" dropdown set to "None", a "Last Loaded: 11:36:31" timestamp, and "Refresh" and "Close" buttons.

Table 43 lists and describes the parameters in the Radio table of the Radio Parameters page and the **Status parameters** section of the Radio Parameters configuration page.

Table 43 Radio Status Parameters

Parameter	Definition
Radio location	Identifies the radio interface (Slot 1, port 1 or Slot 1, port 2).
Type	The type of RFU connected to the radio interface.
TX Frequency	The configured TX radio frequency. The TX radio frequency is configured in the Frequency control (Local) section of the Radio Parameters page. See Configuring the Radio Parameters .

Parameter	Definition
RX Frequency	The configured RX radio frequency. The RX radio frequency is configured in the Frequency control (Local) section of the Radio Parameters page. See Configuring the Radio Parameters .
Part Number	The part number of the RFU connected to the radio interface.
Serial-Number	The serial number of the RFU connected to the radio interface.
Running Software Version	The software version currently running on the RFU connected to the radio interface.
XPIC support	Indicates whether the RFU supports Cross Polarization Interference Canceller (XPIC). For instructions on configuring XPIC, see Configuring XPIC .
Radio interface operational status	Indicates whether the radio is operational (Up) or not operational (Down).
Operational TX Level (dBm)	The actual TX signal level (TSL) of the RFU (in dBm).
RX Level (dBm)	The actual measured RX signal level (RSL) of the RFU (in dBm).
Modem MSE (dB)	The MSE (Mean Square Error) of the RX signal, measured in dB. A value of -9900 (-99.00 dB) means that the modem is not locked.
Modem XPI (dB)	The current XPI (Cross Polar Interference) level. The value is valid only when the modem is locked on a signal.
Defective Blocks	The number of defective radio blocks that have been counted. Click Clear Counter to reset this counter.
TX Mute Status	Indicates whether radio transmission is muted.
Temperature	The current temperature of the RFU.

Configuring the IDU-RFU Connection (PTP 820F only)

For PTP 820F, you must configure the following IDU-RFU connection parameters:


- **PoE Power** – Certain RFU types can receive PoE power from the IDU when they are connected to the IDU via the PTP 820F RJ-45 RFU interface. See [IDU-RFU Connection and Power Supply](#). By default, the **Power Admin** field in the Radio Unit page is set to **Enable**. If PoE power is being supplied to the RFU, this default setting should be kept. If power is being supplied to the RFU from an external power source, the **Power Admin** field should be set to **Disable** to avoid unnecessary alarms.
- **Media Type** – In System Release 10.0, you can use only one PTP 820F combo radio interface (RFU1), but you can choose between the electrical (RJ-45) RFU1 interface or the optical SFP RFU1 interface. The **Media Type** parameter must match the interface type actually being used on the IDU. The default value is **RJ45**. If you are using an SFP interface, you must set this parameter to **SFP**.



Note

The other radio interfaces on the PTP 820F are reserved for future use.


Figure 155 RFU1 Radio Interfaces on PTP 820F




To view or configure the PTP 820F's IDU-RFU connection parameters:

1. Select **Radio > Radio Unit**. The Radio Unit page opens.

Figure 156 Radio Unit Page (PTP 820F)



2. Select the radio unit you want to configure and click **Edit**. The Radio Unit – Edit page opens.



3. By default, the **Admin Status** is set to **Enable**. To disable the RFU, select **Disable** in the **Admin Status** field.
4. By default, the **Power Admin** field is set to **Enable**. If PoE power is not being used for the RFU connected to this PTP 820F, select **Disable** in the **Power Admin** field.
5. By default, the **Media Type** field is set to **RJ45**. If the RFU is connected to the PTP 820F via the PTP 820F optical (SFP) port, select **SFP** in the **Media Type** field.
6. Click **Apply**.

For a full description of the parameters on the page, see the following table.

Table 44 Radio Unit Parameters

Parameter	Definition
Operational Status	The current status of the IDU-RFU connection.

Power Status	<p>Read-only. Indicates whether the IDU is supplying PoE power to the RFU. Possible values are:</p> <ul style="list-style-type: none">• Supplying – PoE power is being supplied to the RFU via the PTP 820F• Detecting – Usually, this indicates a transient state immediately after connecting the RFU to the IDU. If it lasts for more than about one second, it indicates that there is no power consumption, usually because the RFU is not properly connected to the IDU.• Fault – PoE power to the RFU is disabled due to a hardware failure, usually a short circuit.• Disable – The Power Admin field is set to Disable.
Admin Status	<p>The configured status of the RFU connected to the PTP 820F. By default, the status is Enabled.</p>
Power Admin	<p>Determines whether the IDU supplies PoE power to the RFU. By default, Power Admin is Enabled.</p>
Media Type	<p>The interface type on the PTP 820F connected to the RFU. The default value is RJ45.</p>


Configuring the Remote Radio Parameters

To view and configure the parameters of the carrier or carriers at the remote side of the link:

To display the remote radio parameters:


1. Select **Radio > Remote Radio Parameters**. The Remote Radio Parameters page opens.

Figure 157 Remote Radio Parameters Page




2. Select the radio the remote radio of which you want to configure and click **Edit**. The Remote Radio Parameters – Edit page opens.

Figure 158 Remote Radio Parameters – Edit Page



3. Configure the remote radio parameters. For a description of these parameters, see [Table 45 Remote Radio Parameters](#).
4. Click **Apply**.

Figure 159: Remote Radio Parameters Page Per Carrier – PTP 820G



You can also reset the remote radio or the entire remote unit from the Remote Radio Parameters – Edit page:

- To reset the remote radio, click **Reset remote Slot**.
- To reset the entire remote unit, click **Reset Remote Unit**.

Table 45 Remote Radio Parameters

Parameter	Definition
Radio Location	Identifies the radio interface (Slot 1, port 1 or Slot 1, port 2).
Remote Radio Location	Read-only. Identifies the location of the remote radio.
Local Remote Channel Operational Status	Read-only. The operational status of the active (in a protection configuration) remote channel.
Remote Receiver Signal Level	Read-only. The Rx level of the remote radio, in dBm.

Parameter	Definition
Remote Most Severe Alarm	Read-only. The level of the most severe alarm currently active on the remote unit.
Remote Tx Output Level	The remote unit's Tx output level, if the remote unit has been configured to operate at a fixed Tx level (in dBm).
Remote Radio Mute	To mute the TX output of the remote radio, select On . To unmute the TX output of the remote radio, select Off .
Remote IP Address	The IPv4 IP address of the remote unit.
Remote IPv6 Address	The IPv6 IP address of the remote unit.

Displaying Communication Status with Remote Radio (CLI)

To display the communication status with the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit communication status show
```

Displaying Remote Radio's Link ID and Location (CLI)

To display the remote radio's Link ID, enter the following command in radio view:

```
radio[x/x]>remote-unit show link-id
```

To display the remote radio's slot ID (location in the chassis), enter the following command in radio view:

```
radio[x/x]>remote-unit show slot-id
```

Muting and Unmuting the Remote Radio (CLI)

To mute or unmute the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit mute set admin <admin>
```

To display the mute status of the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit mute show status
```

Table 46: Remote Radio Mute and Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the remote unit.

The following command mutes the remote radio connected to fixed radio interface 2:

```
radio[1/2]>remote-unit mute set admin on
```

The following command unmutes the remote radio connected to fixed radio interface 1:

```
radio[1/1]>remote-unit mute set admin off
```

Displaying the Remote Radio's RX Level (CLI)

To display the remote radio's RX level, enter the following command in radio view:

```
radio[x/x]>remote-unit show rx-level
```

Configuring the Remote Radio's TX Level (CLI)

To set the transmit (TX) level of the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit set tx-level <tx-level>
```

To display the transmit (TX) level of the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit show tx-level
```

Table 47: Remote Radio TX Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	Depends on the frequency and RFU type.	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of the remote radio connected to fixed radio interface 1 to 10 dBm:

```
radio[1/1]>remote-unit set tx-level 10
```

Configuring Remote ATPC (CLI)

To set the RX reference level for ATPC on the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit atpc set ref-level <ref-level>
```

To display the RX reference level for ATPC on the remote radio, enter the following command in radio view:

```
radio[x/x]>remote-unit atpc show ref-level
```

Table 48: Remote Radio ATPC CLI Parameters

Parameter	Input Type	Permitted Values	Description
ref-level	Number	-70 - -30	The RX reference level for the ATPC mechanism.

Configuring ATPC and Override Timer

ATPC is a closed-loop mechanism by which each carrier changes the TX power according to the indication received across the link, in order to achieve a desired RSL on the other side of the link.

With ATPC, if the radio increases its TX power up to the configured TX power, it can lead to a period of sustained transmission at maximum power, resulting in unacceptable interference with other systems.

In order to minimize interference, PTP 820G and PTP 820F provides an ATPC override mechanism. When ATPC override is enabled, a timer begins when ATPC raises the TX power to its maximum. When the timer expires, the radio enters ATPC override state. In ATPC override state, the radio transmits no higher than the pre-determined ATPC override TX level, and an ATPC override alarm is raised. The radio remains in ATPC override state until the ATPC override state is manually cancelled by the user (or until the unit is reset). The radio then returns to normal ATPC operation.

In a configuration with unit redundancy or radio protection, the ATPC override state is propagated to the standby unit or radio in the event of switchover.



Note

When canceling an ATPC override state, you should ensure that the underlying problem has been corrected. Otherwise, ATPC may be overridden again.

To enable and configure ATPC and display the ATPC settings:

1. Select **Radio > ATPC**. The ATPC page opens.

Figure 160 ATPC Page

Radio Location	ATPC Admin	Reference RX Level (dBm)	ATPC Override Admin	ATPC Override State	Override TX Level (dBm)	Override Timeout (seconds)	Remote Radio Location	Remote ATPC Admin	Remote Reference RX Level (dBm)
Radio: Slot 1, Port 1	Disable	-42	Disable	Disabled	15	600	Unknown	Disable	-42
Radio: Slot 1, Port 2	Disable	-42	Disable	Disabled	15	600	Unknown	Disable	-42

2. In the ATPC table, select the radio you want to configure and click **Edit**. The ATPC – Edit page opens.

Figure 161 ATPC – Edit Page

3. In the **ATPC Admin** field, select **Enable** to enable ATPC or **Disable** to disable ATPC.
4. Click **Apply**. If you selected **ATPC -Admin – Enable**, the **Reference RX Level (dBm)** and **ATPC Override Admin** fields are now displayed.
5. In the **Reference RX Level (dBm)** field, enter a number between -70 and -30 as the reference value for the ATPC mechanism. When ATPC is enabled, it adjusts the TX power dynamically to preserve this RSL level. The range of values depends on the frequency, MPMC script, and RFU type
6. In the **ATPC Override Admin** field, select **Enable** to enable ATPC override or **Disable** to disable ATPC override. You can only enable ATPC override if ATPC itself is enabled.

**Note**

Make sure to set an appropriate value in the **Override Timeout** field before enabling ATPC override. Failure to do so can lead to unexpected reduction of the TX power with corresponding loss of capacity if TX override is enabled with the timer set to a lower-than-desired value.

7. Click **Apply**. If you selected **ATPC Override Admin – Enable**, the **ATPC Override State**, **Override TX Level**, and **ATPC Override Admin** fields are now displayed.
8. In the **Override TX Level** field, select the TX power, in dBm, to be used when the unit is in an ATPC override state. The range of values depends on the frequency, MPMC script, and RFU type.
9. In the **Override Timeout** field, select the amount of time, in seconds, the timer counts from the moment the radio reaches its maximum configured TX power until ATPC override goes into effect. You can select from 0 to 1800 seconds.
10. In the **Remote ATPC Admin** field, select **Enable** to enable ATPC or **Disable** to disable ATPC on the remote radio carrier.

11. Click **Apply**. If you selected **Remote ATPC Admin - Enable** the **Remote Reference RX Level (dBm)** field is now displayed.
12. In the **Remote Reference RX Level (dBm)** field, enter a number between -70 and -30 as the reference value for the ATPC mechanism on the remote radio carrier.
13. Click **Apply**.

To cancel an ATPC override state on the local unit, click **Cancel Override**.

Configuring Header De-Duplication

Header De-Duplication enables operators to significantly improve Ethernet throughput over the radio link without affecting user traffic. Header De-Duplication can be configured to operate on various layers of the protocol stack, saving bandwidth by reducing unnecessary header overhead. Header De-duplication is also sometimes known as header compression.



Note

The Header De-Duplication configuration must be identical on both sides of the link.

To configure Header De-Duplication:

1. Select **Radio > Ethernet Interface > Configuration**. The Radio Ethernet Interface Configuration page opens.

Figure 162 Radio Ethernet Interface Configuration Page

Interface location ▲	Header Deduplication mode	Header Deduplication operational state	Cut through mode
Radio: Slot 1, Port 1	Disabled	Disabled	No
Radio: Slot 1, Port 2	Disabled	Disabled	No

2. Select the carrier and click Edit. The Radio Ethernet Interface Configuration – Edit page opens.

Figure 163 Radio Ethernet Interface Configuration – Edit Page

3. In the **Header Deduplication mode** field, select from the following options:
 - **Disabled** – Header De-Duplication is disabled.
 - **Layer2** – Header De-Duplication operates on the Ethernet level.
 - **MPLS** – Header De-Duplication operates on the Ethernet and MPLS levels.
 - **Layer3** – Header De-Duplication operates on the Ethernet and IP levels.
 - **Layer4** – Header De-Duplication operates on all supported layers up to Layer 4.
 - **Tunnel** – Header De-Duplication operates on Layer 2, Layer 3, and on the Tunnel layer for packets carrying GTP or GRE frames.
 - **Tunnel-Layer3** – Header De-Duplication operates on Layer 2, Layer 3, and on the Tunnel and T-3 layers for packets carrying GTP or GRE frames.
 - **Tunnel-Layer4** – Header De-Duplication operates on Layer 2, Layer 3, and on the Tunnel, T-3, and T-4 layers for packets carrying GTP or GRE frames.
4. Click **Apply**, then **Close**.



Note

The **Utilization threshold** field is not applicable.

Configuring Frame Cut-Through

Using the Frame Cut-Through feature, frames assigned to queues with 4th priority pre-empt frames already in transmission over the radio from other queues. After the 4th queue frames have been transmitted, transmission of the pre-empted frames resumes .



Note

The Frame Cut-Through configuration must be identical on both sides of the link.

If Frame Cut-Through is used together with 1588 Transparent Clock, the 1588 packets must be given a CoS that is not assigned to the fourth priority queue.

To configure Frame Cut-Through:

1. Select **Radio > Ethernet Interface > Configuration**. The Radio Ethernet Interface Configuration page opens.

Figure 164 Radio Ethernet Interface Configuration Page

Interface location	Header Deduplication type	Header Deduplication operational state	Cut through mode
Radio: Slot 1, port 1	No Deduplication	Disabled	No
Radio: Slot 1, port 2	No Deduplication	Disabled	No

2. In the Radio Ethernet and Compression table, select the radio you want to configure.
3. Click **Edit**. The Radio Ethernet Interface Configuration – Edit page opens.

Figure 165 Radio Ethernet Interface Configuration – Edit Page

Radio Ethernet Interface Configuration

Radio Ethernet Interface Configuration

Interface location

Header Compression

Header Deduplication type

Header Deduplication operational state

User flow type (0..65535)

Utilization threshold (-1..100)

Cut through mode

4. In the **Cut through mode** field, select **Yes** to enable Frame Cut-Through or **No** to disable Frame Cut-Through.
5. Click **Apply**, then **Close**.

**Note**

The other fields in the Ethernet Interface Configuration – Edit page relate to Header De-Duplication, a feature which is planned for future release. The Radio Ethernet Interface Counters page is also reserved for future use.

Viewing Header De-Duplication and Frame Cut-Through Counters

You can view PMs on the usage of Header De-Duplication.

To view Header De-Duplication counters:

1. Select **Radio > Ethernet Interface > Counters**. The Radio Ethernet Interface Counters page opens.

Figure 166 Radio Ethernet Interface Counters Page

Interface location ▲	Tx bytes before header deduplication	Tx compressed bytes	Tx frames before header deduplication	Tx frames compressed by header deduplication	Tx learning frames	Tx frames not compressed due to excluding rule	Tx frames not compressed due to other reasons	Tx number of active flows	Number of active flows of user selected flow type	Cut through TX frames
Radio: Slot 1, Port 1	0	0	0	0	0	0	0	0	0	0
Radio: Slot 1, Port 2	0	0	0	0	0	0	0	0	0	0

2. Select the carrier and click **View**. The Radio Ethernet Interface Counters- View page opens.

Figure 167 Radio Ethernet Interface Counters – View Page




Table 49 lists and describes the fields in the Radio Ethernet Interface Counters page.

Table 49 Radio Ethernet Interface Counters Fields

Parameter	Definition
Interface Location	Identifies the radio interface.
Header Compression Counters	
TX bytes before header deduplication	Bytes on the TX side before Header De-Duplication.
TX compressed bytes	Bytes on the TX side that were compressed by Header De-Duplication.
TX frames before header deduplication	Frames on the TX side before Header De-Duplication.
TX frames compressed by header deduplication	Frames on the TX side that were compressed by Header De-Duplication.
TX learning frames	The number of frames that have been used to learn unique data flows. Once a particular flow type has been learned, subsequent frames with that flow type are compressed by Header De-Duplication.
TX frames not compressed due to excluding rule	Frames on the TX side that were not compressed due to exclusion rules. Note: The use of exclusion rules for Header De-Duplication is planned for future release.

Parameter	Definition
TX frames not compressed due to other reasons	Frames on the TX side that were not compressed for reasons other than the use of exclusion rules.
TX number of active flows	The number of Header De-Duplication flows that are active on the TX side.
Number of active flows of user selected flow type	Not supported.
Ethernet Port Counters	
Port RX good bytes	The number of good bytes received on the port since the last time the Radio Ethernet Interface counters were cleared.
Port RX good frames	The number of good frames received on the port since the last time the Radio Ethernet Interface counters were cleared.
Port TX total bytes	The number of bytes transmitted since the last time the Radio Ethernet Interface counters were cleared.
Port TX frames	The number of frames transmitted since the last time the Radio Ethernet Interface counters were cleared.
Port TX idle bytes	The number of idle bytes transmitted since the last time the Radio Ethernet Interface counters were cleared.
Cut Through Counters	
TX frames	The number of frames that have been transmitted via Frame Cut-Through since the last time the Radio Ethernet Interface counters were cleared.

Configuring AES-256 Payload Encryption

**Note**

AES-256 is not supported with PTP 820F

This feature requires:

- Requires an activation key. If no valid AES activation key has been applied to the unit, AES will not operate on the unit. See [Configuring the Activation Key](#).
-

**Note**

In order for the AES activation key to become active, you must reset the unit after configuring a valid AES activation key. Until the unit is reset, an alarm will be present if you enable AES. This is not the case for other activation keys.

PTP 820G supports AES-256 payload encryption. AES is enabled and configured separately for each radio carrier.

PTP 820 uses a dual-key encryption mechanism for AES:


- The user provides a master key. The master key can also be generated by the system upon user command. The master key is a 32-byte symmetric encryption key. The same master key must be manually configured on both ends of the encrypted link.
- The session key is a 32-byte symmetric encryption key used to encrypt the actual data. Each link uses two session keys, one for each direction. For each direction, the session key is generated by the transmit side unit and propagated automatically, via a Key Exchange Protocol, to the other side of the link. The Key Exchange Protocol exchanges session keys by encrypting them with the master key, using the AES-256 encryption algorithm. Session keys are regenerated at user-configured intervals.

AES key generation is completely hitless, and has no effect on ACM operation.

To configure payload encryption:


1. Verify that both the local and remote units are running with no alarms. If any alarm is present, take corrective actions to clear the alarms before proceeding.
2. If the link is using in-band management, identify which unit is local and which unit is remote from the management point of view.
3. In a link with radio protection, enable protection lockout, first on the remote and then on the local unit. See [Switchovers and Lockout](#).
4. On the remote unit, Select **Radio > Payload Encryption**. The Payload Encryption page opens.

Figure 168 Payload Encryption Page



5. Select the carrier you want to configure and click **Edit**. The Payload Encryption – Edit page opens.

Figure 169 Payload Encryption – Edit Page



6. Configure the master key by doing one of the following:
 - Enter a master key in the **Master Key** field. You must enter between 8 and 32 ASCII characters.
 - Click **Generate key** to generate a master key automatically.

You must use the same master key on both sides of the link. This means that if you generate a master key automatically on one side of the link, you must copy that key and for use on the other side of the link. Once payload encryption has been enabled on both sides of the link, the Key Exchange Protocol periodically verifies that both ends of the link have the same master key. If a mismatch is detected, an alarm is raised and traffic transmission is stopped for the mismatched carrier at both sides of the link. The link becomes non-valid and traffic stops being forwarded.

When you enter a master key, or when the master key is automatically generated, the key is hidden behind dots. To copy the master key, you must display the key. To display the master key, click **Show Key**. A new **Master key** field appears, displaying the master key. You can copy the key to the clipboard from this field.

Figure 170 Payload Encryption – Edit Page with Master Key Displayed

7. Record and save the master key generated in Step 6.
8. On the local unit, follow Steps **Error! Reference source not found.** through **6** to configure the same master key configured on the remote unit also on the local unit.
9. Enable payload encryption on the remote unit:
 - i In the **Admin Mode** field, select **AES-256** to enable payload encryption.
 - ii In the **Session Key Period** field, configure a time interval in hours and minutes (HH:MM). This is the interval at which the session key is automatically regenerated.



Note

The **Session Key Period** must be the same on both sides of the link.

- iii When you are finished, click **Apply**.
This step will cause the link status to be Down until payload encryption is successfully enabled on the local unit. However, the RSL measured on the link should remain at an acceptable level.
10. 1 Enable payload encryption on the local unit by following the procedure described in Step **Error! Reference source not found.**. Verify that on both the local and remote active units, the link status returns to Up and user traffic is restored. In links using in-band management, verify also that in-band management returns.

11. 2 In a protected link, perform copy-to-mate, first on the remote and then on the local unit. See [Copying Configuration to Mate](#). After the copy-to-mate operation, wait for both standby units to re-boot and verify that there are no alarms.

**Note**

The standby unit may have a *payload encryption failure* alarm for up to about one minute after the unit is up and running.

12. 3 In a protected link, remove the protection lockout, first on the remote and then on the local unit. See [Switchovers and Lockout](#).
13. 4 Verify that there are no alarms on the link.

**Note**

Any time payload encryption fails, the Operational status of the link is Down until payload encryption is successfully restored.

Configuring and Viewing Radio PMs and Statistics

This section includes:

- [Configuring BER Thresholds and Displaying current BER](#)
- [Displaying MRMC Status](#)
- [Displaying MRMC PMs](#)
- [Displaying Defective Block Counters](#)
- [Displaying Signal Level PMs and Configuring Signal Level PM Thresholds](#)
- [Displaying PMs for the Combined IF Combining Signal](#)
- [Displaying Modem BER \(Aggregate\) PMs](#)
- [Displaying MSE PMs and Configuring MSE PM Thresholds](#)
- [Displaying XPI PMs and Configuring XPI PM Thresholds](#)
- [Displaying Signal Level PMs](#)
- [Displaying Traffic PMs](#)

Configuring BER Thresholds and Displaying Current BER

You can configure PM thresholds, BER thresholds, and Excessive BER Administration. This enables you to define the levels at which certain PMs are counted, such as the number of seconds in which the configured threshold RX and TX levels are exceeded. This also enables you to define the levels at which certain alarms are triggered.

- Signal level PM thresholds, such as RX and TX level thresholds, are configured from the Signal Level PM Report page. See [Displaying Signal Level PMs and Configuring Signal Level PM Thresholds](#).
- MSE PM thresholds are configured from the MSE PM Report page. See [Displaying MSE PMs and Configuring MSE PM Thresholds](#).
- XPI PM thresholds are configured from the XPI PM Report page. See [Displaying XPI PMs and Configuring XPI PM Thresholds](#).

You can also display the current BER level.

To configure the BER thresholds and Excessive BER Administration, and display current BER levels:

1. Select **Radio > Radio BER Thresholds**. The Radio BER Thresholds page opens. The current BER level is displayed, per radio, in the **Radio BER** column.

Figure 171 Radio BER Thresholds Page

Microwave radio: Radio BER Thresholds

Radio General Configuration

Excessive BER admin

▼ Threshholds table

Radio Location ▲	Excessive BER Threshold	Signal Degrade BER Threshold	Radio BER
Radio: Slot 1, Port 1	1e-3	1e-6	1e-2
Radio: Slot 1, Port 2	1e-3	1e-6	1e-3

- In the **Excessive BER admin** field, select **Enable** to enable excessive BER administration or **Disable** to disable excessive BER administration. Excessive BER administration determines whether or not excessive BER is propagated as a fault and considered a system event. For example, if excessive BER administration is enabled, excessive BER can trigger a protection switchover and can cause a synchronization source to go into a failure status. Excessive BER administration is enabled or disabled for the entire unit rather than for specific radios.
- In the Thresholds table, select the radio for which you want to configure thresholds.
- Click **Edit**. The Radio BER Thresholds – Edit page opens.

Figure 172 Radio BER Thresholds – Edit Page

5. In the **Excessive BER Threshold** field, select the level above which an excessive BER alarm is issued for errors detected over the radio link.
6. In the **Signal Degrade BER Threshold** field, select the level above which a Signal Degrade alarm is issued for errors detected over the radio link.
7. Click **Apply**, then **Close**.

Displaying MPMC Status

Related Topics:

- [Entering Radio View \(CLI\)](#)
- [To view](#) and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:

```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s)

To display the current modulation and bit rate per radio:

1. Select **Radio > MRMC > MRMC Status**. The MRMC Status page opens.

Figure 173 MRMC Status Page

[Table 50](#) describes the MRMC status parameters.

**Note**

To display the same parameters for an individual radio in a separate page, select the radio in the MRMC script status table and click **Edit**. You can configure Adaptive TX Power from the MRMC Status – Edit page. See [Enabling ACM with Adaptive Transmit Power](#).

Table 50 MRMC Status Parameters

Parameter	Definition
Radio Location	Identifies the carrier (Slot 2, port 1 or Slot 2, port 2).
Configured MRMC Script	The current MRMC script.
TX profile	The current TX profile.
TX QAM	The current TX modulation.
TX bit-rate	The current TX bit-rate.
RX profile	The current RX profile.
RX QAM	The current RX modulation.
RX bit-rate	The current RX bit-rate.

Displaying MRMC PMs

Related Topics:

- [Entering Radio View \(CLI\)](#)
- [To view](#) and configure radio parameters, you must first enter the radio's view level in the CLI.

Use the following command to enter a radio's view level:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for fixed radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for fixed radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

The following command enters radio view for an RMC in expansion slot 3:

```
root> radio slot 3 port 1
```

The following prompt appears:

```
radio[3/1]>
```

Muting and Unmuting the Radio (CLI)

To mute or unmute the radio, enter the following command in radio view:

```
radio[x/x]>rf mute set admin <admin>
```

To configure a timed mute, enter the following command in radio view:

```
radio[x/x]> rf mute set admin on-with-timer timeout-value <1-1440>
```

When the timer expires, the radio is automatically unmuted. A timed mute provides a fail-safe mechanism for maintenance operations that eliminates the possibility of accidentally leaving the radio muted after the maintenance has been completed. By default, the timer is 10 minutes.

Note: In contrast to an ordinary mute, a timed mute is not persistent. This means that if the unit is reset, the radio is not muted when the unit comes back online, even if the timer had not expired. Also, in unit and radio protection configurations, a timed mute is not copied to the mate unit or radio, and no mismatch alarm is raised if a timed mute is configured on only one radio in the protection pair.

To display the mute status of a radio, enter the following command in radio view:

```
radio[x/x]>rf mute show status
```

Table 21: Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes fixed radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command mutes the RMC in expansion slot 2:

```
radio[2/1]>rf mute set admin on
```

The following command configures a timed mute on fixed radio interface 1. This mute will automatically expire in 30 minutes.

```
radio[1/1]> rf mute set admin on-with-timer timeout-value 30
```

The following command unmutes fixed radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the local-remote attribute to disable:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Note: If the carrier belongs to an XPIC group, you must disable the group before changing the TX or RX frequency.

Table 22: Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and RFU type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit. By default, the configured TX frequency value is applied to the RX frequency of the remote unit.

The following command sets the TX frequency of fixed radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of fixed radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, enter the following command in radio view:

```
radio[x/x]>rf show max-tx-level
```

Table: Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	-50-34	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of fixed radio interface 1 to 10 dBm:


```
radio[1/1]>rf set tx-level 10
```

- Configuring the Radio (MRMC) Script(s)

To display Multi-Rate Multi-Constellation PMs, including information on ACM profile fluctuations per interval per radio:

1. Select **Radio > PM & Statistics > MRMC**. The MRMC PM Report page opens.

Figure 174 MRMC PM Report Page



2. In the **Port** field, select the port that holds the radio for which you want to display PMs.
3. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

Table 51 describes the MRMC PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the MRMC PM table and click **View**.

Table 51 MRMC PMs

Parameter	Definition
PM Interval	The length of the interval for which the PMs were measured (15 Minutes or 24 Hours).
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Min profile	Displays the minimum ACM profile that was measured during the interval.
Max profile	Displays the maximum ACM profile that was measured during the interval.
Min bitrate	Displays the minimum total radio throughput (Mbps) delivered during the interval.
Max bitrate	Displays the maximum total radio throughput (Mbps) delivered during the interval.

Parameter	Definition
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

Displaying Defective Block Counters

The Counters page displays the number of blocks in which errors were detected. The larger the amount, the poorer the radio link quality.

To display the number of blocks in which errors were detected per radio:

1. Select **Radio > PM & Statistics > Counters**. The Counters page opens.

Figure 175 Counters Page

Microwave radio: Radio Counters

▼ Radio Counters

Radio Location ▲	Defective Blocks
Radio: Slot 1, Port 1	0
Radio: Slot 1, Port 2	0

View Clear Counter

**Note**


To display the same parameters for an individual radio in a separate page, select the radio in the Radio table and click **View**. To clear the PMs, click **Clear Counters**.

Displaying Signal Level PMs and Configuring Signal Level PM Thresholds

To display signal level PMs per radio:

1. Select **Radio > PM & Statistics > Signal Level**. The Signal Level PM report page opens.

Figure 176 Signal Level PM Report Page



2. In the **Interface** field, select the radio interface for which you want to display PMs.
3. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

Table 52 describes the Signal Level PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the RF PM table and click **View**.

Table 52 Signal Level PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Max TSL (dBm)	The maximum TSL (Transmit Signal Level) that was measured during the interval.
Min TSL (dBm)	The minimum TSL (Transmit Signal Level) that was measured during the interval.
Max RSL (dBm)	The maximum RSL (Received Signal Level) that was measured during the interval.
Min RSL (dBm)	The minimum RSL (Received Signal Level) that was measured during the interval.

Parameter	Definition
TSL exceed threshold seconds	The number of seconds the measured TSL exceeded the threshold during the interval. TSL thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER .
RSL exceed threshold1 seconds	The number of seconds the measured RSL exceeded RSL threshold 1 during the interval. RSL thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER .
RSL exceed threshold2 seconds	The number of seconds the measured RSL exceeded RSL threshold 2 during the interval. RSL thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER .
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

To set the Signal Level PM thresholds, click **Thresholds**. The Signal Level Thresholds Configuration – Edit Page opens. Set the thresholds, described in [Table 53](#), and click **Apply**.

Figure 177 Signal level Thresholds Configuration – Edit Page




Table 53 Signal Level Thresholds

Parameter	Definition
RX Level Threshold 1 (dBm)	Specify the threshold for counting exceeded seconds if the RSL is below this level.
RX Level Threshold 2 (dBm)	Specify a second threshold for counting exceeded seconds if the RSL is below this level.
TX Level Threshold (dBm)	Specify the threshold for counting exceeded seconds if the TSL is below this level.

Displaying PMs for the Combined IF Combining Signal



Note

This section is only relevant for PTP 820G.

Related Topics:

- [Displaying PMs for the Combined IF Combining Signal](#)


IF Combining is a space diversity configuration in which the RFU receives and processes two signals and combines them into a single, optimized signal. You can display RSL (Received Signal Level) PMs for the combined signal, as well as for the Diversity interface.

Note: RSL PMs for the Main interface are displayed in the standard RSL fields of the Signal Level PM report page. See [Displaying Signal Level PMs and Configuring Signal Level PM Thresholds](#).

To display combined RSL PMs per radio:

1. Select **Radio > PM & Statistics > Combined**. The Combined PM graph page opens.

Figure 178 Combined PM Graph Page



2. In the **Interface** field, select the radio interface for which you want to display PMs.
3. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select 15 minutes.
 - To display reports in daily intervals, select 24 hours.

Table 54 describes the Combined PMs.

**Note**

To display the same parameters for a specific interval in a separate page, select the interval in the IF Combiner combined performance PM table and click **View**.

Table 54 Combined PMs


Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Combined Max RSL (dBm)	The maximum combined RSL that was measured during the interval.
Combined Min RSL (dBm)	The minimum combined RSL that was measured during the interval.
Combined RSL exceed threshold1 seconds	The number of seconds the combined RSL exceeded RSL threshold 1 during the interval. RSL thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER .
Combined RSL exceed threshold2 seconds	The number of seconds the combined RSL exceeded RSL threshold 2 during the interval. RSL thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER..
Integrity	Indicates whether the values received at time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

Displaying Modem BER (Aggregate) PMs

To display modem BER (Bit Error Ratio) PMs per radio:

1. Select **Radio > PM & Statistics > Aggregate**. The Aggregate PM report page opens.

Figure 179 Aggregate PM Report Page



2. In the **Port** field, select the port that holds the radio for which you want to display PMs.



Note

The Slot field always displays Slot #1

3. In the **Interval Type** field:
- To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

Table 55 describes the Modem BER (Aggregate) PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the Modem BER PM table and click **View**.

Table 55 Modem BER (Aggregate) PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
ES	Displays the number of seconds in the measuring interval during which errors occurred.
SES	Displays the number of severe error seconds in the measuring interval.


Parameter	Definition
UAS	Displays the Unavailable Seconds value of the measured interval. The value can be between 0 and 900 seconds (15 minutes).
BBE	Displays the number of background block errors during the measured interval.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

Displaying MSE PMs and Configuring MSE PM Thresholds

To display modem MSE (Minimum Square Error) PMs per radio:

1. Select **Radio > PM & Statistics > MSE**. The MSE PM report page opens.

Figure 180 MSE PM Report Page



2. In the **Interface** field, select the interface that holds the radio for which you want to display PMs.
3. In the **Interval Type** field:
 - o To display reports in 15-minute intervals, select **15 minutes**.
 - o To display reports in daily intervals, select **24 hours**.

Table 56 describes the Modem MSE PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the Modem MSE PM table and click **View**.


Table 56 Modem MSE PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Min MSE (dB)	Displays the minimum MSE in dB, measured during the interval.
Max MSE (dB)	Displays the maximum MSE in dB, measured during the interval.

Parameter	Definition
Exceed threshold seconds	Displays the number of seconds the MSE exceeded the MSE PM threshold during the interval. The MSE PM is configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER .
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

To set the Modem MSE PM thresholds, click **Thresholds**. The Modem MSE Thresholds Configuration– Edit Page opens. For each radio, specify the modem MSE (Mean Square Error) threshold for calculating MSE Exceed Threshold seconds, and click **Apply**.

Figure 181 Modem MSE Thresholds Configuration – Edit Page



Displaying XPI PMs and Configuring XPI PM Thresholds

Related topics:

- [Configuring XPIC](#)

To display XPI (Cross Polarization Interface) PMs per radio:

1. Select **Radio > PM & Statistics > XPI**. The XPI PM report page opens.



Note

The XPI page only appears if XPIC is configured on the unit.

Figure 182 XPI PM Report Page

Microwave radio: XPI PM report (Radio: Slot 1, Port 2, 15 minutes)

Interface: Radio: Slot 1, Port 2 | Interval Type: 15 minutes

▼ PM Table

#	Interval ▲	Min XPI (dB)	Max XPI (dB)	XPI below threshold seconds	Integrity
	Current (07:41:27)	55	0	0	✘
1	15-Jan-00 07:30	55	0	0	✘
2	15-Jan-00 07:15	55	0	0	✘
3	15-Jan-00 02:15	55	0	0	✘

View | Thresholds | Graph

2. In the **Interface** field, select the radio interface for which you want to display PMs.
3. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

Table 57 describes the XPI PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the Modem XPI PM table and click **View**.


Table 57 XPI PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Min XPI (dB)	The minimum XPI level that was measured during the interval.
Max XPI (dB)	The maximum XPI level that was measured during the interval.
XPI below threshold seconds	The number of seconds the measured XPI level was below the threshold during the interval. XPI thresholds are configured in the Radio Thresholds page. See Configuring BER Thresholds and Displaying Current BER .

Parameter	Definition
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

To set the XPI PM thresholds, click **Thresholds**. The XPI Thresholds Configuration– Edit Page opens. For each radio, specify the modem XPI threshold for calculating XPI Exceed Threshold seconds, and click **Apply**.

Figure 183 XPI Thresholds Configuration – Edit Page



Displaying Traffic PMs

This section includes:

- [Displaying Capacity and Throughput PMs](#)
- [Displaying Utilization PMs](#)
- [Displaying Frame Error Rate PMs](#)

Displaying Capacity and Throughput PMs

You can display PMs for capacity and throughput for a radio, based on:


- The total Layer 1 bandwidth (payload plus overheads) sent through the radio (Mbps).
- The total effective Layer 2 traffic sent through the radio.

You can also configure thresholds for capacity and throughput PMs. The number of seconds during which these thresholds are exceeded are among the displayed PMs.

To display capacity and throughput PMs per radio:

1. Select **Radio > PM & Statistics > Traffic > Capacity/Throughput**. The Capacity PM report page opens.

Figure 184 Capacity PM Report Page



2. In the **Interface** field, select the interface that holds the radio for which you want to display PMs.
3. In the **Interval Type** field:
 - o To display reports in 15-minute intervals, select **15 minutes**.
 - o To display reports in daily intervals, select **24 hours**.

To set the thresholds for capacity and throughput PMs:

1. Select **Threshold**. The Ethernet Radio Capacity & Throughput Threshold page opens.




Figure 185: Ethernet Radio Capacity and Throughput Threshold Page

2. Enter the capacity and throughput thresholds you want, in Mbps. The range of values is 0 to 4294967295. The default value for is 1000.
3. Click **Apply**, then **Close**.

Table 58 describes the capacity and throughput PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the PM table and click **View**.

Table 58 Capacity/Throughput PMs


Parameter	Definition
Time interval index	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Peak capacity (Mbps)	Displays the highest L1 bandwidth, in Mbps, sent through the selected radio during the measured time interval.
Average capacity (Mbps)	Displays the average L1 bandwidth, in Mbps, during the measured time interval.
Seconds exceeding Threshold	Displays the number of seconds during the measured time interval during which the L1 bandwidth exceeded 0.
Peak throughput (Mbps)	Displays the highest throughput, in Mbps, that occurred for the selected radio during the measured time interval.
Average throughput (Mbps)	Displays the average throughput, in Mbps, for the selected radio during the measured time interval.
Seconds exceeding Threshold	Displays the number of seconds during the measured time interval during which the throughput exceeded 0.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

Displaying Utilization PMs

To display radio capacity utilization PMs per radio:

1. Select **Radio > PM & Statistics > Traffic > Utilization**. The Utilization PM report page opens.

Figure 186 Utilization PM Report Page




2. In the Interface field, select the radio interface that holds the radio for which you want to display PMs.
3. In the Interval Type field:
 - o To display reports in 15-minute intervals, select **15 minutes**.
 - o To display reports in daily intervals, select **24 hours**.

To set the thresholds for utilization PMs:

1. Select **Threshold**. The Utilization Threshold page opens.

Figure 187 Ethernet Radio Utilization Threshold Page



1. Enter the utilization threshold you want, in % (1-100). The default value for is 100.
2. Click **Apply**, then **Close**.

Table 59 describes the capacity and throughput PMs.

**Note**

To display the same parameters for a specific interval in a separate page, select the interval in the PM table and click **View**.

Table 59 Utilization PMs


Parameter	Definition
Time interval index	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Peak capacity (Mbps)	Displays the highest L1 bandwidth, in Mbps, sent through the selected radio during the measured time interval.
Average capacity (Mbps)	Displays the average L1 bandwidth, in Mbps, during the measured time interval.
Seconds exceeding Threshold	Displays the number of seconds during the measured time interval during which the L1 bandwidth exceeded 0.
Peak throughput (Mbps)	Displays the highest throughput, in Mbps, that occurred for the selected radio during the measured time interval.
Average throughput (Mbps)	Displays the average throughput, in Mbps, for the selected radio during the measured time interval.
Seconds exceeding Threshold	Displays the number of seconds during the measured time interval during which the L1 bandwidth exceeded the configured utilization threshold.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

Displaying Frame Error Rate PMs

To display frame error rate PMs per radio or Multi-Carrier ABC group:

1. Select **Radio > PM & Statistics > Traffic > Frame error rate**. The Frame error rate PM report page opens.

Figure 188 Frame Error PM Report Page



2. In the **Interface** field, select the radio interface that holds the radio for which you want to display PMs.
3. In the **Interval Type** field:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

Table 60 describes the capacity and throughput PMs.



Note

To display the same parameters for a specific interval in a separate page, select the interval in the PM table and click **View**.

Table 60 Frame Error Rate PMs

Parameter	Definition
Time interval index	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
FER	Displays the frame error rate (%) during the measured time interval.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

Chapter 6: Ethernet Services and Interfaces

This section includes:

- [Configuring Ethernet Service\(s\)](#)
- [Setting the MRU Size and the S-VLAN Ethertype](#)
- [Configuring Ethernet Interfaces](#)
- [Configuring Automatic State Propagation](#)
- [Viewing Ethernet PMs and Statistics](#)

Related topics:

- [Configuring Link Aggregation \(LAG\) and LACP](#)
- [Quality of Service \(QoS\)](#)
- [Ethernet Protocols](#)
- [Performing Ethernet Loopback](#)
- [Ethernet Traffic Interfaces](#)
- [Ethernet Management Interfaces](#)
- [Ethernet Pin-Outs and LEDs](#)

Configuring Ethernet Service(s)

This section includes:

- [Ethernet Services Overview](#)
- [General Guidelines for Provisioning Ethernet Services](#)
- [The Ethernet Services Page](#)
- [Adding an Ethernet Service](#)
- [Editing a Service](#)
- [Deleting a Service](#)
- [Enabling, Disabling, or Deleting Multiple Services](#)
- [Viewing Service Details](#)
- [Configuring Service Points](#)

Ethernet Services Overview

Users can define up to 64 Ethernet services. Each service constitutes a virtual bridge that defines the connectivity between logical ports in the PTP 820G or PTP 820F network element.

This version of PTP 820G and PTP 820F supports the following service types:

- Multipoint (MP)
- Point-to-Point (P2P)
- Management (MNG)

In addition to user-defined services, PTP 820G and PTP 820F contains a pre-defined management service (Service ID 1025). By default, this service is operational.

**Note**

You can use the management service for in-band management. For instructions on configuring in-band management, see [Configuring In-Band Management](#).

A service point is a logical entity attached to a physical or logical interface. Service points define the movement of frames through the service. Each service point includes both ingress and egress attributes. A Point-to-Point or Multipoint service can hold up to 32 service points. A Management service can hold up to 30 service points.

For a more detailed overview of PTP 820's service-oriented Ethernet switching engine, refer to the Technical Description for the product you are using.

General Guidelines for Provisioning Ethernet Services

When provisioning Ethernet services, it is recommended to follow these guidelines:

- Use the same Service ID for all service fragments along the path of the service.
- Do not re-use the same Service ID within the same region. A region is defined as consisting of all devices having Ethernet connectivity between them.
- Use meaningful EVC IDs.
- Give the same EVC ID (service name) to all service fragments along the path of the service.
- Do not reuse the same EVC ID within the same region.

It is recommended to follow these guidelines for creating service points:

- Always use SNP service points on NNI ports and SAP service points on UNI ports.
- For each logical interface associated with a specific service, there should never be more than a single service point.
- The transport VLAN ID should be unique per service within a single region. That is, no two services should use the same transport VLAN ID.

The Ethernet Services Page

The Ethernet Services page is the starting point for defining Ethernet services on the PTP 820G and PTP 820F.

To open the Ethernet Services page:

1. Select **Ethernet > Services**. The Ethernet Services page opens.

Figure 189 Ethernet Services Page




Table 61 describes the parameters displayed in the Ethernet Services page.

Table 61 Ethernet Services Page Parameters

Parameter	Definition
Services ID	A unique ID for the service.
Service Type	The service type: <ul style="list-style-type: none"> • MP – Multipoint • P2P – Point-to-Point • MNG – Management
Service sub type	Indicates the type of service (Ethernet).
EVC ID	The Ethernet Virtual Connection (EVC) ID. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
EVC description	The Ethernet Virtual Connection (EVC) description. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
Admin	Indicates whether the service is enabled (Operational) or disabled (Reserved). You can configure services for later use by defining the service as Reserved . In Reserved mode, the service occupies system resources but is unable to transmit and receive data.

Adding an Ethernet Service

To add an Ethernet service:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. In the Ethernet Services page, click **Add**. The Ethernet Services – Add page opens.

Figure 190 Ethernet Services - Add page

The screenshot shows a window titled "Ethernet Services" with a sub-header "Ethernet Services Configuration Table - Add". The form contains the following fields and values:

- Service ID:** 2
- Service Type:** P2P
- EVC ID:** N.A.
- EVC description:** N.A.
- Admin:** Operational
- MAC table size:** 131072
- Default CoS:** 0
- CoS Mode:** Preserve-SP-COS-Decision

At the bottom of the form are three buttons: "Apply", "Refresh", and "Close".

3. In the **Service ID** field, select a unique ID for the service. You can choose from any unused value from 1 to 1024. Once you have added the service, you cannot change the Service ID. Service ID 1025 is reserved for a pre-defined management service.
4. In the **Service Type** field, select the service type:
 - **MP** – Multipoint
 - **MNG** – Management
 - **P2P** – Point-to-Point
5. Optionally, in the **EVC ID** field, enter an Ethernet Virtual Connection (EVC) ID (up to 20 characters). This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
6. Optionally, in the **EVC Description** field, enter a text description of the service (up to 64 characters). This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
7. In the **Admin** field, select one of the following options:
 - **Operational** - The service is functional.
 - **Reserved** - The service is disabled until this parameter is changed to **Operational**. In this mode, the service occupies system resources but is unable to receive and transmit data.
8. In the **MAC table size** field, enter the maximum MAC address table size for the service. The MAC address table is a source MAC address learning table used to forward frames from one service point to another. You can select a value from 16 to 131,072, in multiples of 16. This maximum only applies to dynamic, not static, MAC address table entries.

**Note**

Additional configuration of the MAC address table can be performed via the CLI. See [Defining the MAC Address Forwarding Table for a Service](#).

9. In the **Default CoS** field, enter a default Class of Service (CoS) value (0-7). This value is assigned to frames at the service level if CoS Mode is set to Default-CoS. Otherwise, this value is not used, and frames retain whatever CoS value they were assigned at the service point or logical interface level.
10. In the **CoS Mode** field, select one of the following options. This parameter determines whether or not frames passing through the service have their CoS modified at the service level. The CoS determines the priority queue to which frames are assigned.
 - **Default CoS** – Frames passing through the service are assigned the default CoS defined above. This CoS value overrides whatever CoS may have been assigned at the service point or interface level.
 - **Preserve-SP-COS-Decision** – The CoS of frames passing through the service is not modified by the service's default CoS.
11. Click **Apply**, then **Close** to close the Ethernet Services - Add page.
12. Add service points. You must add service points to the service in order for the service to carry traffic. See [Configuring Service Points](#).

Editing a Service

To edit a service:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. Select the service in the Service Configuration Table.
3. In the Ethernet Services page, click **Edit**. The Ethernet Services - Edit page opens.
4. This page is identical to the Ethernet Services - Add page ([Figure 190](#)). You can edit any parameter that can be configured in the Add page, except the **Service ID**.

Deleting a Service

Before deleting a service, you must first delete any service points attached to the service. See [Deleting a Service Point](#).

To delete a service:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. Select the service in the Ethernet Service Configuration Table.
3. Click **Delete**. The service is deleted.

Enabling, Disabling, or Deleting Multiple Services

To enable, disable, or delete multiple services:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. Select the services in the Ethernet Services Configuration table, or select all the services by selecting the check box in the top row.
 - To enable the selected services, in the Multiple Selection Operation section underneath the Ethernet Services Configuration Table, select **Operational** and click **Apply**.
 - To disable the selected services, in the Multiple Selection Operation section underneath the Ethernet Services Configuration Table, select **Reserved** and click **Apply**.
 - To delete the selected services, select **Delete** underneath the Ethernet Services Configuration Table. Before deleting a service, you must delete any service points attached to the service, as described in [Deleting a Service Point](#).

Figure 191 Multiple Selection Operation Section (Ethernet Services)



Note

When setting multiple services to **Reserve** state, make sure to avoid setting the management service to **Reserve** state.

Viewing Service Details

To view the full service parameters:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. Select the service in the Ethernet Services Configuration table.
3. In the Ethernet Services page, click **Service Details**. The Ethernet Services – Service Details page opens. The Service Details page contains the same fields as the Add page ([Figure 189](#)). However, in the Service Details page, these fields are read-only.

Configuring Service Points

This section includes:

- [Ethernet Services Points Overview](#)
- [The Ethernet Service Points Page](#)
- [Adding a Service Point](#)
- [Editing a Service Point](#)
- [Deleting a Service Point](#)
- [Attaching VLANs](#)

Ethernet Services Points Overview

Service points are logical interfaces within a service. A service point is a logical entity attached to a physical or logical interface. Service points define the movement of frames through the service. Each service point includes both ingress and egress attributes.

Each service point for a Point-to-Point or Multipoint service can be either a Service Access Point (SAP) or a Service Network Point (SNP). A Point-to-Point service can also use Pipe service points.

- An SAP is equivalent to a UNI in MEF terminology and defines the connection of the user network with its access points. SAPs are used for Point-to-Point and Multipoint traffic services.
- An SNP is equivalent to an NNI or E-NNI in MEF terminology and defines the connection between the network elements in the user network. SNPs are used for Point-to-Point and Multipoint traffic services.
- A Pipe service point is used to create traffic connectivity between two ports in a port-based manner (Smart Pipe). In other words, all the traffic from one port passes to the other port.

Management services utilize Management (MNG) service points.

A Point-to-Point or Multipoint service can hold up to 32 service points. A management service can hold up to 30 service points.


The Ethernet Service Points Page

The Ethernet Service Points page is the starting point for configuring Ethernet service points.

To open the Ethernet Service Points page:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens.

Figure 192 Ethernet Service Points Page



You can choose to display the following sets of attributes by selecting the appropriate button above the SP Attributes table:

- **General** – See [Ethernet Service Points – General SP Attributes Table](#)
- **Ingress** – See [Ethernet Service Points – Ingress Attributes](#)
- **Egress** – See [Ethernet Service Points – Egress Attributes](#)

To return to the Ethernet Services page at any time, click **Back to Services table** at the top of the Ethernet Service Points page.

a. Ethernet Service Points – General SP Attributes Table

The General SP Attributes table is shown in [Figure 192 Ethernet Service Points Page](#). [Table 62](#) describes the parameters displayed in the General SP Attributes table.

Table 62 General Service Point Attributes

Parameter	Definition
Service point ID	<p>This ID is unique within the service. For Point-to-Point and Multipoint services, the range of values is 1-32. For Management services, the range of values is 1-30.</p> <p>When adding a service point, you can select a service point ID from the available options in the Service point ID drop-down list in the Ethernet Service Points – Add page. Once you have added the service point, you cannot change the service point ID.</p>
Service point name	<p>A descriptive name for the service point (optional). The Service Point Name can be up to 20 characters.</p>

Parameter	Definition
Service point type	<p>The service point type. Options are:</p> <ul style="list-style-type: none"> • SAP – Service Access Point. • SNP – Service Network Point. • MNG – Management service point. • PIPE – Pipe service point. <p>The following rules apply to the mixing of different types of service points on a single logical interface:</p> <p>You cannot configure both SAPs and SNPs on the same logical interface.</p> <ul style="list-style-type: none"> • You can configure both SAPs or SNPs on the same logical interface as a MNG service point. • If you configure a Pipe service point on an interface, you cannot configure an SAP, SNP, or another Pipe service point on the same interface. You can, however, configure an MNG service point on the same interface. • You cannot configure more than one MNG service point on a single logical interface. • Once you have added the service point, you cannot change this parameter.
Interface location	<p>The physical or logical interface on which the service point is located. Once you have added the service point, you cannot change this parameter.</p>
Attached interface type	<p>The encapsulation type (Ethertype) for frames entering the service point. Once you have added the service point, you cannot change this parameter.</p> <p>The Attached Interface Type determines which frames enter the service via this service point, based on the frame's VLAN tagging. Since more than one service point may be associated with a single interface, frames are assigned to the earliest defined service point in case of conflict.</p> <p>For a list of available Attached Interface Types, the types of frames to which each one applies, and the service point types for which each one is available, see Table 63.</p>
C-Vlan encapsulation	<p>The C-VLAN classified into the service point. Options are 1-4094, Untagged, or N.A. (Not Applicable). Once you have added the service point, you cannot change this parameter.</p> <p>If you selected Bundle-C in the Attached Interface Type field, select Untagged or N.A. You can then add multiple C-VLANs via the Attach VLAN option. See Attaching VLANs.</p>

Parameter	Definition
S-Vlan encapsulation	<p>The S-VLAN classified into the service point. Options are 1-4094, Untagged, or N.A. (Not Applicable). Once you have added the service point, you cannot change this parameter.</p> <p>If you selected Bundle-S in the Attached Interface Type field, select the S-VLAN value to classify into the service point (1-4094), or select Untagged. You can then add multiple C-VLANs via the Attach VLAN option. See Attaching VLANs.</p>

Table 63 describes the available Attached Interface Types.

Table 63 Attached Interface Types

Attached Interface Type	Types of Frames	Available for Service Point Types
dot1q	A single C-VLAN is classified into the service point.	All
s-tag	A single S-VLAN is classified into the service point.	SNP, PIPE, and MNG
Bundle-C	A set of C-VLANs is classified into the service point.	SAP
Bundle-S	A single S-VLAN and a set of C-VLANs are classified into the service point.	SAP
All-to-One	All C-VLANs and untagged frames that enter the interface are classified into the service point.	SAP
Q-in-Q	A single S-VLAN and C-VLAN combination is classified into the service point.	SAP and MNG

b. Ethernet Service Points – Ingress Attributes

Select **Ingress** in the Ethernet Service Points page to display the Ethernet Service Points – Ingress Attributes table.

Table 64 describes the parameters displayed in the Ingress SP Attributes table.

Figure 193 Ethernet Service Points Page – Ingress Attributes




Table 64 Service Point Ingress Attributes

Parameter	Definition
Service point ID	This ID is unique within the service. For Point-to-Point and Multipoint services, the range of values is 1-32. For Management services, the range of values is 1-30.
Service point name	A descriptive name for the service point (optional). The Service Point Name can be up to 20 characters.
Service point type	The service point type. Options are: <ul style="list-style-type: none"> • SAP – Service Access Point. • SNP – Service Network Point. • MNG – Management service point. • PIPE – Pipe service point.
Learning admin	Determines whether MAC address learning for incoming frames is enabled (Enable) or disabled (Disable). When enabled, the service point learns the source MAC addresses of incoming frames and adds them to a MAC address forwarding table.
Allow flooding	Determines whether incoming frames with unknown MAC addresses are forwarded to other service points via flooding. Select Allow to allow flooding or Disable to disable flooding.
Allow broadcast	Indicates whether frames with a broadcast destination MAC address are allowed to ingress the service via this service point.. Select Allow to allow broadcast or Disable to disable broadcast.

Parameter	Definition
CoS Mode	<p>Indicates how the service point handles the CoS of frames that pass through the service point. Options are:</p> <ul style="list-style-type: none"> sp-def-cos – The service point re-defines the CoS of frames that pass through the service point, according to the Default CoS (below). This decision can be overwritten on the service level. Interface-Decision – The service point preserves the CoS decision made at the interface level. The decision can still be overwritten at the service level. PCL – Reserved for future use. TCAM – Reserved for future use.
Default CoS	<p>The default CoS. If the CoS Mode is sp-def-cos, this is the CoS assigned to frames that pass through the service point. This decision can be overwritten at the service level. Possible values are 0 to 7.</p>
Split horizon group	<p>Reserved for future use.</p>

c. Ethernet Service Points – Egress Attributes

Select **Egress** in the Ethernet Service Points page to display the Ethernet Service Points – Egress Attributes table.

Microwave radio: Ethernet Service Points (Service ID - 1)

Back to Services table

Select Service Point Attribute

General
 Ingress
 Egress

Ethernet Service Points - Egress Attributes

Service point ID	Service point name	Service point type	C-Vlan CoS preservation	C-Vlan preservation	S-Vlan CoS preservation	S-Vlan preservation	Marking admin	Service bundle ID
<input type="checkbox"/>	1 West_23	SAP	Enable	Disable	Enable	Disable	Enable	1
<input type="checkbox"/>	2 West_24	SNP	Enable	Disable	Enable	Disable	Enable	1
<input checked="" type="checkbox"/>	3 West_2	SAP	Disable	Enable	Enable	Disable	Enable	1

Table 65 describes the parameters displayed in the General SP Attributes table.

Figure 194 Ethernet Service Points Page – Egress Attributes




Table 65 Service Point Egress Attributes

Parameter	Definition
Service point ID	This ID is unique within the service. For Point-to-Point and Multipoint services, the range of values is 1-32. For Management services, the range of values is 1-30.
Service point name	A descriptive name for the service point (optional). The Service Point Name can be up to 20 characters.
Service point type	The service point type. Options are: <ul style="list-style-type: none"> • SAP – Service Access Point. • SNP – Service Network Point. • MNG – Management service point. • PIPE – Pipe service point.
C-Vlan CoS preservation	Determines whether the original C-VLAN CoS value is preserved or restored for frames egressing from the service point. If C-VLAN CoS preservation is enabled, the C-VLAN CoS value of frames egressing the service point is the same as the value when the frame entered the service. If C-VLAN CoS preservation is disabled, the C-VLAN CoS value of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking.

Parameter	Definition
C-Vlan preservation	<p>Determines whether the original C-VLAN ID is preserved or restored for frames egressing from the service point.</p> <p>If C-VLAN preservation is enabled, the C-VLAN ID of frames egressing the service point is the same as the C-VLAN ID when the frame entered the service.</p> <p>If C-VLAN preservation is disabled, the C-VLAN ID of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking</p>
S-Vlan CoS preservation	<p>Determines whether the original S-VLAN CoS value is preserved or restored for frames egressing from the service point.</p> <p>If S-VLAN CoS preservation is enabled, the S-VLAN CoS value of frames egressing the service point is the same as the value when the frame entered the service.</p> <p>If S-VLAN CoS preservation is disabled, the C-VLAN CoS value of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking</p>
S-Vlan preservation	<p>Read-only. Indicates whether the original S-VLAN ID is preserved or restored for frames egressing from the service point.</p> <p>If S-VLAN preservation is enabled, the S-VLAN ID of frames egressing the service point is the same as the S-VLAN ID when the frame entered the service.</p> <p>If S-VLAN preservation is disabled, the S-VLAN ID of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking</p>
Marking admin	<p>Determines whether re-marking of the outer VLAN (C-VLAN or S-VLAN) of tagged frames that pass through the service point is enabled.</p> <p>If Marking admin is set to Enable, and CoS preservation for the relevant outer VLAN is set to Disable, the SAP re-marks the C-VLAN or S-VLAN 802.1p UP bits of egress frames according to the calculated CoS and Color, and the user-configurable 802.1Q and 802.1AD marking tables. You can configure these tables by selecting Ethernet > QoS > Marking from the menu on the left side of the Web EMS.</p> <p>If Marking admin and CoS preservation for the relevant outer VLAN are both set to Enable, re-marking is not performed.</p> <p>If Marking admin and CoS preservation for the relevant outer VLAN are both set to Disable, re-marking is applied, but only according to the values defined for Green frames in the 802.1Q and 802.1AD marking tables.</p>

Parameter	Definition
Service Bundle ID	This can be used to assign one of the available service bundles from the H-QoS hierarchy queues to the service point. This enables you to personalize the QoS egress path. Permitted values are 1-63.

Adding a Service Point

To add a service point:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens ([Figure 192](#)).
4. Select the relevant service point in the Ethernet Services Points – General SP Attributes table.
5. Click **Add**. The Ethernet Service Points – Add page opens.

Figure 195 Ethernet Service Points - Add Page

Ethernet Service Points

Ethernet Service Points - Add (Multi Point Service)

Pre defined options: Option #1 (SAP, dot1q)

Service ID: 1

Service point ID: 4

Service point name: N.A.

Service point type: SAP

General SP Attributes

Interface location: Ethernet: Slot 1, port 1

Attached interface type: dot1q

C-Vlan encapsulation: 1

S-Vlan encapsulation: N.A.

Ingress Attributes

Learning admin: Enable

Allow flooding: Allow

Allow broadcast: Allow

CoS Mode: Interface-Decision

Default CoS: 0

Split horizon group: Group-A

Egress Attributes

C-Vlan CoS preservation: Enable

C-Vlan preservation: Disable

S-Vlan CoS preservation: Enable

Marking admin: Enable

Service bundle ID: 1

Apply Refresh Close

6. Configure the service point attributes, as described above.

**Note**

Optionally, you can select from a list of pre-defined service point options in the **Pre defined options** field at the top of the [Ethernet Service Points - Add](#) page. The system automatically populates the remaining service point parameters according to the system-defined parameters. However, you can manually change these parameter values. The pre-defined options are customized to the type of service to which you are adding the service point.

7. Click **Apply**, then **Close**.

Editing a Service Point

To edit a service point:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens ([Figure 192](#)).
4. Select the relevant service point in the Ethernet Services Points – General SP Attributes table.
5. Click **Edit**. The Ethernet Service Points– Edit page opens. The Ethernet Service Points – Edit page is similar to the Ethernet Service Points - Add page ([Figure 195](#)). You can edit any parameter that can be configured in the Add Service Point page, except **Service Point ID**, **Service Point Type**, and the **General SP Attributes**.
6. Edit the service point attributes, as described in [Table 62](#), [Table 64](#), and [Table 65](#).
7. Click **Apply**, then **Close**.

Deleting a Service Point

You can only delete a service point with an **Attached Interface Type** of **Bundle-C** or **Bundle-S** if no VLANs are attached to the service point. See *Attaching VLANs*.

To delete a service point:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).
2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens ([Figure 192](#)).
4. Select the relevant service point in the Ethernet Services Points – General SP Attributes table.
5. Click **Delete**. The service point is deleted.

Attaching VLANs


When the Attached Interface Type for a service point is set to Bundle-C or Bundle-S, you can add multiple C-VLANs to the service point.

To add multiple C-VLANs:

1. Select **Ethernet > Services**. The Ethernet Services page opens ([Figure 189](#)).


2. Select the relevant service in the Ethernet Services Configuration table.
3. Click **Service Points**. The Ethernet Service Points page opens (Figure 192).
4. Select the relevant service point in the Ethernet Services Points – General SP Attributes table.
5. Click **Attached VLAN**. The Attached VLAN List page opens.

Figure 196 Attached VLAN List Page



6. Click **Add**. The Attached VLAN List - Add page opens.

Figure 197 Attached VLAN List - Add Page



7. Configure the VLAN Classification parameters, described in [Table 66](#).
8. Click **Apply**, then **Close**.

Table 66 VLAN Classification Parameters

Parameter	Definition
Interface Location	Read-only. The physical or logical interface on which the service point is located.
Service ID	Read-only. The ID of the service to which the service point belongs.
Service Point ID	Read-only. The ID of the service point.
C-Vlan Encapsulation	Select the C-VLAN you want to add to the service point.
S-Vlan Encapsulation	Read-only. If the Attached Interface Type for the service point is Bundle-S , this field displays the S-VLAN encapsulation selected when the service point was created. If the Attached Interface Type for the service point is Bundle-C , this field is inactive.

Parameter	Definition
CoS Overwrite Valid	If you want to assign a specific CoS and Color to frames with the C-VLAN or S-VLAN defined in the C-VLAN Encapsulation field, select true . This CoS and Color values defined below override the CoS and Color decisions made at the interface level. However, if the service point or service are configured to apply their own CoS and Color decisions, those decisions override the decision made here.
CoS Value	If CoS Overwrite Valid is set to true , the CoS value defined in this field is applied to frames with the C-VLAN defined in the C-VLAN Encapsulation field. This CoS overrides the CoS decision made at the interface level. However, if the service point or service are configured to apply their own CoS, that decision overrides the decision made here. If CoS Overwrite Valid is set to false, this parameter has no effect.
Color	If CoS Overwrite Valid is set to true , the Color value defined in this field is applied to frames with the C-VLAN defined in the C-VLAN Encapsulation field. This Color overrides the Color decision made at the interface level. However, if the service point or service are configured to apply their own Color, that decision overrides the decision made here. If CoS Overwrite Valid is set to false , this parameter has no effect.

To edit a VLAN Classification table entry, select the entry in the VLAN Classification table and click **Edit**. You can edit all the fields that can be configured in the Attached VLAN List – Add page, except the **C-VLAN Encapsulation** field.

To delete a VLAN Classification table entry, select the entry in the VLAN Classification table and click **Delete**.

Setting the MRU Size and the S-VLAN Ethertype

To configure the size of the MRU (Maximum Receive Unit) and the S-VLAN Ethertype:

1. Select **Ethernet > General Configuration**. The Ethernet General Configuration page opens.

Figure 198 Ethernet General Configuration Page

Microwave radio: Ethernet General Configuration

General Parameters

MRU (64..9612)

S VLAN Ether type

C VLAN Ether type

Instance per Service mapping

Service ID	Instance ID
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0

Page: [1](#) [2](#) [3](#) [4](#) [5](#) [6](#) [7](#) [8](#) [9](#) [10](#) [11](#)

2. In the **MRU** field, enter the global size (in bytes) of the Maximum Receive Unit (MRU). Permitted values are 64 to 9612. The default value is 2000. Frames that are larger than the global MRU will be discarded.
3. In the **S VLAN Ether type** field, select the S-VLAN Ethertype. This defines the ethertype recognized by the system as the S-VLAN ethertype. Options are: 0x8100, 0x88A8, 0x9100, and 0x9200. The default value is 0x88A8.



Note

The C-VLAN Ethertype is set at 0x8100 and cannot be modified.

4. Click **Apply**.

**Note**

You can also map Ethernet services to MSTP instances (MSTIs) in the Ethernet General Configuration page. See [Mapping Ethernet Services to MSTP instances \(MSTIs\)](#).

Configuring Ethernet Interfaces

Related Topics:

- [Enabling the Interfaces \(Interface Manager\)](#)
- [Performing Ethernet Loopback](#)
- [Configuring Ethernet Service\(s\)](#)
- [Quality of Service \(QoS\)](#)

The PTP 820F and PTP 820G's switching fabric distinguishes between physical interfaces and logical interfaces. Physical and logical interfaces serve different purposes in the switching fabric. In some cases, a physical interface corresponds to a logical interface on a one-to-one basis. For some features, such as LAG, a group of physical interfaces can be joined into a single logical interface.

The basic interface characteristics, such as media type, port speed, duplex, and auto-negotiation, are configured for the physical interface via the Physical Interfaces page. Ethernet services, QoS, and OAM characteristics are configured on the logical interface level.

To configure the physical interface parameters:

1. Select **Ethernet > Interfaces > Physical Interfaces**. The Physical Interfaces page opens.

Figure 199 Physical Interfaces Page

Interface location	Description	Operational Status	Admin status	Media type	Auto negotiation	Actual port speed	Actual port duplex
Ethernet: Slot 1, port 1		Down	Down	Auto-Type	On	1000	Full Duplex
Ethernet: Slot 1, port 2		Down	Down	Auto-Type	On	1000	Full Duplex
Ethernet: Slot 1, port 5		Down	Down	Auto-Type	On	1000	Full Duplex
Ethernet: Slot 1, port 6		Down	Down	Auto-Type	On	1000	Full Duplex
Radio: Slot 1, port 1		Down	Up	Radio	Off	1000	Full Duplex
Radio: Slot 1, port 2		Down	Up	Radio	Off	1000	Full Duplex
Radio: Slot 2, port 1		Down	Up	Radio	Off	1000	Full Duplex
TDM: Slot 1, port 1		Down	Up	TDM	Off	100	Full Duplex
TDM: Slot 3, port 1		Down	Up	TDM	Off	1000	Full Duplex

2. Select the interface you want to configure and click **Edit**. The Physical Interfaces - Edit page opens.

Figure 200 Physical Interfaces - Edit Page

Physical Interfaces - Edit

Interface location: Ethernet: Slot 1, port 1

Operational Status: Down

Admin status: Up

Media type: Auto-Type

Actual port speed: 1000

Actual port duplex: Full Duplex

Description: []

Media type: Auto-Type

Auto negotiation: On

Speed: 1000

Duplex: Full Duplex

Apply Refresh Close

3. Optionally, in the **Description** field, enter a description of the interface.
4. In the **Media type** field, select the physical interface layer 1 media type. Options are:
 - o **Auto-Type** – NA.
 - o **RJ45** – An electrical (RJ-45) Ethernet interface.
 - o **SFP** – An optical (SFP) Ethernet interface.
 - o **Radio** – A radio interface.
5. In the **Auto negotiation** field, select **On** to enable or **Off** to disable Auto-Negotiation. When the Media-Type is **Radio**, Auto Negotiation is always **Off**.
6. In the **Speed** field, select the maximum speed of the interface, in Mbps. Options are:
 - o Ethernet RJ-45 interfaces – **100** and **1000**.
 - o Ethernet SFP interfaces – Only **1000** is supported.
 - o Radio interfaces – The parameter is read-only and set by the system to **1000**.
7. In the **Duplex** field, select the interface's duplex setting (**Full-Duplex** or **Half-Duplex**). Only **Full-Duplex** is available in this release.
8. Click **Apply**, then **Close**.

[Table 67](#) describes the status parameters that appear in the Physical Interfaces page.

Table 67 Physical Interface Status Parameters

Parameter	Definition
Interface location	The location of the interface.
Operational Status	Indicates whether the interface is currently operational (Up) or non-operational (Down).
Admin Status	Indicates whether the interface is currently enabled (Up) or disabled (Down). You can enable or disable an interface from the Interface Manager page. See Enabling the Interfaces (Interface Manager) .
Actual port speed	Displays the actual speed of the interface for the link as agreed by the two sides of the link after the auto negotiation process.
Actual port duplex	Displays the actual duplex status of the interface for the link as agreed by the two sides of the link after the auto negotiation process.

Configuring Automatic State Propagation and Link Loss Forwarding

Automatic state propagation enables propagation of radio failures back to the Ethernet port. You can also configure Automatic State Propagation to close the Ethernet port based on a radio failure at the remote carrier.

Automatic state propagation is configured as pairs of interfaces. Each interface pair includes one Monitored Interface and one Controlled Interface. You can create multiple pairs using the same Monitored Interface and multiple Controlled Interfaces.

The Monitored Interface is a radio interface, a radio protection group, or a Multi-Carrier ABC group. The Controlled Interface is an Ethernet interface or LAG. An Ethernet interface can only be assigned to one Monitored interface.

Each Controlled Interface is assigned an LLF ID. If **ASP trigger by remote fault** is enabled on the remote side of the link, the ASP state of the Controlled Interface is propagated to the Controlled Interface with the same LLF ID at the remote side of the link. This means if ASP is triggered locally, it is propagated to the remote side of the link, but only to Controlled Interfaces with LLF IDs that match the LLF IDs of the affected Controlled Interfaces on the local side of the link.

**Note**

It is recommended to configure both ends of the link to the same Automatic State Propagation configuration.

LLF requires an activation key (PTP 820-SL-LLF). Without this activation key, only LLF ID 1 is available. See *Configuring the Activation Key (CLI)*.

The following events in the Monitored Interface trigger ASP:

- Radio LOF
- Radio Excessive BER
- Remote Radio LOF
- Remote Excessive BER
- Remove LOC

The user can also configure the ASP pair so that Radio LOF, Radio Excessive BER, or loss of the Ethernet connection at the remote side of the link will also trigger ASP.

In addition, ASP is triggered if the Controlled Interface is a LAG, and the physical interfaces that belong to the LAG are set to **Admin = Down** in the Interface Manager.

When a triggering event takes place:

- If the Controlled Interface is an electrical GbE port, the port is closed.
- If the Controlled Interface is an optical GbE port, the port is muted.

Each Controlled Interface remains closed or muted until all triggering events are cleared.


In addition, when a local triggering event takes place, the ASP mechanism sends an indication to the remote side of the link. Even when no triggering event has taken place, the ASP mechanism sends periodic update messages indicating that no triggering event has taken place.

A trigger delay time can be configured, so that when a triggering event takes place, the ASP mechanism does not propagate the event until this delay time has elapsed. A trigger delay from 0 to 10,000 ms can be set per LLD ID. The delay time must be configured via CLI. See [Configuring Automatic State Propagation and Link Loss Forwarding](#).

To configure an Automatic State Propagation interface pair:


1. Select **Ethernet > Interfaces > ASP & LLF**. The Automatic State Propagation page opens.

Figure 201: Automatic State Propagation Page



2. Click **Add**. The Automatic State Propagation - Add page opens.

Figure 202: Automatic State Propagation - Add Page



3. In the **Controlled Ethernet interface** field, select the interface that will be disabled upon failure of the Monitored Radio Interface, defined below.

4. In the **Monitored Radio interface** field, select the Monitored Radio Interface. The Controlled Ethernet Interface, defined above, is disabled upon a failure indication on the Monitored Radio Interface. You can select a radio or TDM interface, or a radio protection or Multi-Carrier ABC group, as the Monitored Radio Interface.
5. In the **ASP admin** field, select **Enable** to enable Automatic State Propagation on the interface pair, or **Disable** to disable Automatic State Propagation on the pair.
6. Optionally, in the **ASP trigger by remote fault** field, select **Enable** if you want to configure the system to disable the Controlled Ethernet Interface upon a radio failure at the remote side of the link from the Monitored Radio Interface. ASP events will only be propagated to Controlled Interfaces with LLF IDs that match LLF IDs of affected Controlled Interfaces at the other side of the link.
7. Optionally, in the **Auto state propagation CSF mode admin** field, select **Enable** or **Disable** to enable or disable Client Signal Failure (CSF) mode. In CSF mode, the ASP mechanism does not physically shut down the Controlled Interface when ASP is triggered. Instead, the ASP mechanism sends a failure indication message (a CSF message). The CSF message is used to propagate the failure indication to external equipment.
8. In the **ASP LLF ID** field, select an ID for Link Loss Forwarding (LLF). When **ASP trigger by remote fault** is set to **Enable**, ASP events at the other side of the link are propagated to Controlled Interfaces with LLF IDs that match the LLF IDs of affected Controlled Interfaces at the other side of the link. LLF IDs are unique per Monitored Interface. That is, if LLF ID 1 has been used for a Controlled Interface that is grouped with fixed radio interface 1, that ID cannot be used again for another Controlled Interface grouped with fixed radio interface 1. However, it *can* be used for Controlled Interface grouped with fixed radio interface 2. You can select an LLF ID between 1 and 30.
9. this procedure to assign additional Controlled Interfaces to the Monitored Interface, or to set up additional ASP pair with other interfaces. Controlled Interfaces can only be assigned to one ASP pair. Monitored Interfaces can be assigned to multiple ASP pairs.

To edit an Automatic State Propagation interface pair:

1. Select the interface pair in the Automatic state propagation configuration table.
2. Click **Edit**. The Automatic State Propagation – Edit page opens. The Edit page is similar to the Add page ([Figure 202](#)), but the **Controlled Ethernet Interface** and **Monitored Radio Interface** parameters are read-only.

To delete an Automatic State Propagation interface pair:

1. Select the interface pair in the Automatic state propagation configuration table.
2. Click **Delete**. The interface pair is removed from the Automatic state propagation configuration table.

To delete multiple interface pairs:

1. Select the interface pairs in the Automatic state propagation configuration table or select all the interfaces by selecting the check box in the top row.
2. Click **Delete**. The interface pairs are removed from the Automatic state propagation configuration table.

Viewing Ethernet PMs and Statistics

PTP 820G and PTP 820F stores and displays statistics in accordance with RMON and RMON2 standards. You can display various peak TX and RX rates (in seconds) and average TX and RX rates (in seconds), both in bytes and in packets, for each measured time interval. You can also display the number of seconds in the interval during which TX and RX rates exceeded the configured threshold.

This section includes:


- [RMON Statistics](#)
- **Error! Reference source not found.**
- [Port TX Statistics](#)
- [Port RX Statistics](#)

RMON Statistics

To view and reset RMON statistics:

1. Select **Ethernet > PM & Statistics > RMON**. The RMON page opens.

Figure 203 RMON Page



- To clear the statistics, click **Clear All** at the bottom of the page.
- To refresh the statistics, click **Refresh** at the bottom of the page.

Each column in the RMON page displays RMON statistics for one of the unit’s interfaces. To hide or display columns:

1. In the header row, select the arrow next to any of the columns.
2. Select **Columns**.
3. Mark the interfaces you want to display and clear the interfaces you do not want to display.

Figure 204 RMON Page – Hiding and Displaying Columns

The screenshot shows the 'Microwave radio: RMON' page with the 'Interface physical Port RMON statistics' table. The table has columns for 'Ethernet: Slot 1, port 1', 'Ethernet: Slot 1, port 2', 'Ethernet: Slot 1, port 5', and 'Ethernet: Slot 1, port 6'. A 'Columns' menu is open over the table, showing options to 'Sort Ascending', 'Sort Descending', 'Unlock', and 'Lock' columns. The 'Columns' menu also lists several columns with checkboxes, all of which are checked: 'Ethernet: Slot 1, port 1', 'Ethernet: Slot 1, port 2', 'Ethernet: Slot 1, port 5', 'Ethernet: Slot 1, port 6', 'Radio: Slot 1, port 1', 'Radio: Slot 1, port 2', 'Radio: Slot 2, port 1', and 'Radio Protection: Group #1'. The table data includes statistics like 'TX byte count' (4928), 'TX frame count' (77), and various error counts.

	Ethernet: Slot 1, port 1	Ethernet: Slot 1, port 2	Ethernet: Slot 1, port 5	Ethernet: Slot 1, port 6
Clear on read	0		0	0
TX byte count	4928	4928	4928	4928
TX frame count	77	77	77	77
TX multicast frame count	77			
TX broadcast frame count	0			
TX control frame count	0			
TX pause frame count	0			
TX fcs error frame count	0	0		
TX length error frame count	0	0		
TX oversize frame count	0	0		
TX undersize frame count	0	0		
TX fragment frame count	0	0		
TX jabber frame count	0	0		
TX 64 frame count	77	77		
TX 65-127 frame count	0	0	0	0
TX 128-255 frame count	0	0	0	0
TX 256-511 frame count	0	0	0	0
TX 512-1023 frame count	0	0	0	0
TX 1024-1518 frame count	0	0	0	0
TX 1519-1522 frame count	0	0	0	0

Egress CoS Statistics

You can display packet egress statistics per CoS value. For each CoS value, the following statistics are displayed per Color (Green and Yellow):

- Number of packets transmitted
- Number of packets dropped
- Number of bytes transmitted
- Number of bytes dropped



Note

Transmitted bits per second are not supported in the current release.

To display egress CoS statistics:

1. Select **Ethernet > PM & Statistics > Egress CoS Statistics**. The Egress CoS Statistics page opens.

Figure 205: Egress CoS Statistics Page

CoS queue index	Transmitted green packets	Transmitted green bytes	Transmitted green bits per second	Dropped green packets	Dropped green bytes	Transmitted yellow packets	Transmitted yellow bytes	Transmitted yellow bits per second	Dropped yellow packets	Dropped yellow bytes	Clear on read
0	17301239	13694841578	0	0	0	0	0	0	0	0	No
1	17307193	13690939668	0	0	0	0	0	0	0	0	No
2	17307269	13688590877	0	0	0	0	0	0	0	0	No
3	17304760	13687762286	0	0	0	0	0	0	0	0	No
4	17298291	13685264466	0	0	0	0	0	0	0	0	No
5	17295050	13679871485	0	0	0	0	0	0	0	0	No
6	17304365	13685719752	0	0	0	0	0	0	0	0	No
7	17306134	13690473705	0	0	0	0	0	0	0	0	No

2. In the **Show Service bundle ID** field, select 1.



Note

Service Bundles are bundles of queues, grouped together in order to configure common egress characteristics for specific services. In the current release, only Service Bundle 1 is supported.

By default, the egress CoS statistics are cumulative. That is, they are not automatically cleared. You can set each individual CoS number to be cleared whenever the Egress CoS Statistics page is opened by changing the Clear on read value to **Yes**.

3. To change the clear on read value, select the CoS number in the CoS queue index column and click **Edit**. The Egress CoS Statistics – Edit page opens.

Figure 206: Egress CoS Statistics – Edit Page

Egress CoS Statistics - Edit

Interface location	Ethernet: Slot 1, Port 2
Service bundle ID	1
CoS queue index	3
Transmitted green packets	17304780
Transmitted green bytes	13687762286
Transmitted green bits per second	0
Dropped green packets	0
Dropped green bytes	0
Transmitted yellow packets	0
Transmitted yellow bytes	0
Transmitted yellow bits per second	0
Dropped yellow packets	0
Dropped yellow bytes	0
Clear on read	No ▾

Apply

Page Refresh Interval (Seconds) None ▾ Last Loaded: 12:13:02 Refresh Close

4. In the **Clear on read** field, select **Yes** to have statistics for the CoS value cleared every time you open the page.
5. Click **Apply**.

Port TX Statistics

The Ethernet Port TX PM report page displays PMs that measure various peak transmission rates (in seconds) and average transmission rates (in seconds), both in bytes and in packets, for each measured time interval.

The page also displays the number of seconds in the interval during which transmission rates exceeded the configured threshold.

This section includes:

- [Displaying Ethernet Port TX PMs](#)
- [Enabling or Disabling Gathering of Port TX PM Statistics per Interface](#)
- [Setting the Ethernet Port TX Threshold](#)

Displaying Ethernet Port TX PMs

To display Ethernet Port TX PMs:

1. Select **Ethernet > PM & Statistics > Port TX**. The Ethernet Port TX PM Report page opens.

Figure 207 Ethernet Port TX PM Report Page

#	Interval	Peak TX bytes Layer 2	Average TX bytes Layer 2	Peak TX bytes Layer 1	Average TX bytes Layer 1	Peak TX packets	Average TX packets	Peak TX broadcast packets	Aver
	Current (16:11:59)	11138913	108108694	128885753	125008677	878337	844599	0	
1	25-Sep-14 14:00	115511793	108109659	133568573	125001059	902439	844682	0	
2	25-Sep-14 14:45	118836337	108109642	128154577	125001080	865912	844681	0	
3	25-Sep-14 14:30	116305985	108109182	388639394	125001150	1948834133	844682	0	

2. In the **Interface** field, select the interface for which you want to display PMs.
3. In the **Interval Type** field:
 - o To display reports for the past 24 hours, in 15 minute intervals, select **15 minutes**.
 - o To display reports for the past month, in daily intervals, select **24 hours**.

[Table 68](#) describes the Ethernet TX port PMs.

Table 68 Ethernet TX Port PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Peak... Average... bytes... Packets...	Various peak transmission rates (in seconds) and average transmission rates (in seconds), both in bytes and in packets, for each measured time interval.
TX bytes Layer 1 exceed threshold (sec)	The number of seconds the TX bytes exceeded the specified threshold during the interval. For instructions on setting the threshold, see Setting the Ethernet Port TX Threshold .
Invalid data flag	Indicates whether the values received during the measured interval are valid. An x in the column indicates that the values are not valid (for example, because of a power surge or power failure that occurred during the interval).


To clear the PMs, click **Clear All**.

Enabling or Disabling Gathering of Port TX PM Statistics per Interface

To select the interfaces for which to gather and display Port TX PMs:

1. In the Ethernet Port TX PM Report page, click **PM Admin**. The Ethernet PM Port Admin page opens.

Figure 208 Ethernet PM Port Admin Page



2. Select the interface.
3. Click **Enable Port PM** or **Disable Port PM** to enable or disable the gathering of Port TX PMs on the selected interface.
4. Click **Close**.


Setting the Ethernet Port TX Threshold

The **TX bytes Layer 1 exceed threshold (sec)** column shows, for each interval, the number of seconds the TX bytes exceeded the specified threshold during the interval:

To view and set this threshold:

1. In the Ethernet Port TX PM Report page, click **Threshold**. The Ethernet Port Tx Threshold page opens.

Figure 209: Ethernet Port Tx Threshold Page



2. Enter a threshold, between 0 and 4294967295.
3. Click **Apply**, then **Close**.

6.

Port RX Statistics

The Ethernet Port RX PM report page displays PMs that measure various peak transmission rates (in seconds) and average RX rates (in seconds), both in bytes and in packets, for each measured time interval.

The page also displays the number of seconds in the interval during which RX rates exceeded the configured threshold.

This section includes:


- [Displaying Ethernet Port RX PMs](#)
- [Enabling or Disabling Gathering of Port RX PM Statistics per Interface](#)
- [Setting the Ethernet Port RX Threshold](#)

Displaying Ethernet Port RX PMs

To display Ethernet Port RX PMs:

1. Select **Ethernet > PM & Statistics > Port RX**. The Ethernet Port RX PM Report page opens.

Figure 210 Ethernet Port RX PM Report Page



2. In the **Interface** field, select the interface for which you want to display PMs.
3. In the **Interval Type** field:
 - o To display reports for the past 24 hours, in 15 minute intervals, select **15 minutes**.
 - o To display reports for the past month, in daily intervals, select **24 hours**.

Table 69 describes the Ethernet RX port PMs.

Table 69 Ethernet RX Port PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Peak... Average... bytes... Packets...	Various peak transmission rates (per second) and average RX rates (per second), both in bytes and in packets, for each measured time interval.

Parameter	Definition
RX bytes Layer 1 exceed threshold (sec)	The number of seconds the RX bytes exceeded the specified threshold during the interval. For instructions on setting the threshold, see Setting the Ethernet Port RX Threshold .
Invalid data flag	Indicates whether the values received during the measured interval are valid. An x in the column indicates that the values are not valid (for example, because of a power surge or power failure that occurred during the interval).


To clear the PMs, click **Clear All**.

Enabling or Disabling Gathering of Port RX PM Statistics per Interface

To select the interfaces for which to gather and display Port RX PMs:

1. In the Ethernet Port RX PM Report page, click **PM Admin**. The Ethernet PM Port Admin page opens.

Figure 211 Ethernet PM Port Admin Page



2. Select the interface.
3. Click **Enable Port PM** or **Disable Port PM** to enable or disable the gathering of Port RX PMs on the selected interface.
4. Click **Close**.

Setting the Ethernet Port RX Threshold

The **RX bytes Layer 1 exceed threshold (sec)** column shows for each interval, the number of seconds the RX bytes exceeded the specified threshold during the interval:

To view and set this threshold:

1. In the Ethernet Port RX PM Report page, click **Threshold**. The Ethernet Port Rx Threshold page opens.

Figure 212 Ethernet Port Rx Threshold Page

Ethernet Port Rx Threshold

Interface location

RX bytes threshold (Byte per second) (0..4294967295)

2. Enter a threshold, between 0 and 4294967295.
3. Click **Apply**, then **Close**.

Chapter 7: Quality of Service (QoS)

This section includes:

- [QoS Overview](#)
- [Configuring Classification](#)
- [Configuring Policers \(Rate Metering\)](#)
- [Configuring Marking](#)
- [Configuring WRED](#)
- [Configuring Egress Shaping](#)
- [Configuring Scheduling](#)

**Note**

You can display QoS egress statistics, but only via CLI. For information, see [Displaying Egress Statistics \(CLI\)](#).

QoS Overview


Quality of Service (QoS) deals with the way frames are handled within the switching fabric. QoS is required in order to deal with many different network scenarios, such as traffic congestion, packet availability, and delay restrictions.

PTP 820G and PTP 820F’s personalized QoS enables operators to handle a wide and diverse range of scenarios. PTP 820G and PTP 820F’s smart QoS mechanism operates from the frame’s ingress into the switching fabric until the moment the frame egresses via the destination port.

QoS capability is very important due to the diverse topologies that exist in today’s network scenarios. These can include, for example, streams from two different ports that egress via single port, or a port-to-port connection that holds hundreds of services. In each topology, a customized approach to handling QoS will provide the best results.

Figure 213 shows the basic flow of PTP 820G and PTP 820F’s QoS mechanism. Traffic ingresses (left to right) via the Ethernet or radio interfaces, on the “ingress path.” Based on the services model, the system determines how to route the traffic. Traffic is then directed to the most appropriate output queue via the “egress path.”

Figure 213 QoS Block Diagram



The ingress path consists of the following QoS building blocks:

- **Ingress Classifier** – A hierarchical mechanism that deals with ingress traffic on three different levels: interface, service point, and service. The classifier determines the exact traffic stream and associates it with the appropriate service. It also calculates an ingress frame CoS and Color. CoS and Color classification can be performed on three levels, according to the user’s configuration.
- **Ingress Rate Metering** – A hierarchical mechanism that deals with ingress traffic on three different levels: interface, service point, and service point CoS. The rate metering mechanism enables the system to measure the incoming frame rate on different levels using a TrTCM standard MEF rate meter, and to determine whether to modify the color calculated during the classification stage.

The egress path consists of the following QoS building blocks:

- **Queue Manager** – This is the mechanism responsible for managing the transmission queues, utilizing smart WRED per queue and per packet color (Green or Yellow).

- **Scheduling and Shaping** – A hierarchical mechanism that is responsible for scheduling the transmission of frames from the transmission queues, based on priority among queues, Weighted Fair Queuing (WFQ) in bytes per each transmission queue, and eligibility to transmit based on required shaping on several different levels (per queue, per service bundle, and per port).
- **Marker** – This mechanism provides the ability to modify priority bits in frames based on the calculated CoS and Color.

For a more detailed description of QoS in the PTP 820G or PTP 820F, refer to the Technical Description for the product you are using.

Configuring Classification

The hierarchical classifier consists of the following levels:

- Logical interface-level classification
- Service point-level classification
- Service level classification

This section explains how to configure classification at the logical interface level.

- For instructions how to configure classification at the service point level, see [Ethernet Service Points – Ingress Attributes](#).
- For instructions how to configure classification at the service level, see [Adding an Ethernet Service](#).

This section includes:

- [Classification Overview](#)
- [Configuring Ingress Path Classification on a Logical Interface](#)
- [Modifying the C-VLAN 802.1Q UP and CFI Bit Classification Table](#)
- [Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table](#)
- [Modifying the DSCP Classification Table](#)
- [Modifying the MPLS EXP Bit Classification Table](#)

In addition to the procedures described in this section, you can specify a specific CoS and Color for a specific VLAN ID. This is the highest classification priority on the logical interface level, and overrides any other classification criteria at the logical interface level. Classification by VLAN ID can only be configured via CLI. See [Configuring VLAN Classification and Override \(CLI\)](#).

Classification Overview

PTP 820G and PTP 820F supports a hierarchical classification mechanism. The classification mechanism examines incoming frames and determines their CoS and Color. The benefit of hierarchical classification is that it provides the ability to “zoom in” or “zoom out”, enabling classification at higher or lower levels of the hierarchy. The nature of each traffic stream defines which level of the hierarchical classifier to apply, or whether to use several levels of the classification hierarchy in parallel.

Classification takes place on the logical interface level according to the following priorities:

- VLAN ID (CLI-only – see [Configuring VLAN Classification and Override \(CLI\)](#))
- 802.1p bits
- DSCP bits
- MPLS EXP field
- Default interface CoS

PTP 820G and PTP 820F performs the classification on each frame ingressing the system via the logical interface. Classification is performed step by step from the highest priority to the lowest priority classification method. Once a match is found, the classifier determines the CoS and Color decision for the frame for the logical interface-level.

For example, if the frame is an untagged IP Ethernet frame, a match will not be found until the third priority level (DSCP). The CoS and Color values defined for the frame’s DSCP value will be applied to the frame.

You can disable some of these classification methods by configuring them as un-trusted. For example, if 802.1p classification is configured as un-trusted for a specific interface, the classification mechanism does not perform classification by UP bits. This is useful, for example, if classification is based on DSCP priority bits.

If no match is found at the logical interface level, the default CoS is applied to incoming frames at this level. In this case, the Color of the frame is assumed to be Green.


Configuring Ingress Path Classification on a Logical Interface

This section explains how to configure the classification criteria per each logical interface. The following sections explain how to modify the classification tables per bit type.

To configure the classification criteria for a logical interface:


1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens.

Figure 214 Logical Interfaces Page



2. Select the interface you want to configure and click **Edit**. The Logical Interfaces - Edit page opens.

Figure 215 Logical Interfaces - Edit Page



3. Configure the parameters described in [Table 70](#).
4. Click **Apply**, then **Close**.



Note

The **Edge mode** field is reserved for future use. The **Ingress byte compensation** and **Egress byte compensation** fields are described in [Configuring the Ingress and Egress Byte Compensation](#).

Table 70 Logical Interface Classification Parameters

Parameter	Definition
Trust VLAN UP bits	<p>Select the interface's trust mode for user priority (UP) bits:</p> <p>Trust – The interface performs QoS and color classification according to UP and CFI/DEI bits according to user-configurable tables for 802.1q UP bits (C-VLAN frames) or 802.1AD UP bits (S-VLAN frames). VLAN UP bit classification has priority over DSCP and MPLS classification, so that if a match is found with the UP bit of the ingressing frame, DSCP values and MPLS bits are not considered.</p> <p>Un-Trust – The interface does not consider 802.1 UP bits during classification.</p>


Parameter	Definition
Trust DSCP	Select the interface's trust mode for DSCP: Trust – The interface performs QoS and color classification according to a user-configurable table for DSCP to CoS and color classification. DSCP classification has priority over MPLS classification, so that if a match is found with the DSCP value of the ingressing frame, MPLS bits are not considered. Un-Trust – The interface does not consider DSCP during classification.
Trust MPLS	Select the interface's trust mode for MPLS bits: Trust – The interface performs QoS and color classification according to a user-configurable table for MPLS EXP to CoS and color classification. Un-Trust – The interface does not consider MPLS bits during classification.
Default port CoS	Select the default CoS value for frames passing through the interface (0 to 7). This value can be overwritten on the service point and service level.

Modifying the C-VLAN 802.1Q UP and CFI Bit Classification Table

To modify the classification criteria for 802.1Q User Priority (UP) bits:


1. Select **Ethernet > QoS > Classification > 802.1Q**. The 802.1Q Classification page opens.

Figure 216 802.1Q Classification Page



2. Select the row you want to modify and click **Edit**. The 802.1Q Classification – Edit page opens.

Figure 217 802.1Q Classification - Edit Page




3. Modify the parameters you want to change:
 - o **802.1Q UP** – Read-only. The User Priority (UP) bit to be mapped.
 - o **802.1Q CFI** – Read-only. The CFI bit to be mapped.
 - o **802.1Q CoS** – The CoS assigned to frames with the designated UP and CFI.
 - o **802.1Q Color** – The Color assigned to frames with the designated UP and CFI.
4. Click **Apply**, then **Close**.

Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table

To modify the classification criteria for 802.1AD User Priority (UP) bits:


1. Select **Ethernet > QoS > Classification > 802.1AD**. The 802.1AD Classification page opens.

Figure 218 802.1AD Classification Page



2. Select the row you want to modify and click **Edit**. The 802.1AD Classification - Edit page opens.

Figure 219 802.1Q Classification - Edit Page



3. Modify the parameters you want to change:
 - **802.1AD UP** – Read-only. The User Priority (UP) bit to be mapped.
 - **802.1ADQ DEI** – Read-only. The DEI bit to be mapped.
 - **802.1AD CoS** – The CoS assigned to frames with the designated UP and DEI.
 - **802.1AD Color** – The Color assigned to frames with the designated UP and DEI.
4. Click **Apply**, then **Close**.


Modifying the DSCP Classification Table

You can configure the classification criteria for Differentiated Service Code Point (DSCP) priority values. The DSCP is a 6-bit length field inside the IP datagram header carrying priority information. Classification by DSCP can be used for untagged frames, as well as 802.1Q tagged or provider VLAN tagged frames.

To modify the classification criteria for DSCPs:

1. Select **Ethernet > QoS > Classification > DSCP**. The DSCP Classification page opens.

Figure 220 DSCP Classification Page



2. Select the row you want to modify and click **Edit**. The DSCP Classification - Edit page opens.

Figure 221 DSCP Classification - Edit Page

DSCP Classification Table - Edit

DSCP

Binary

Description

CoS (0..7)

Color ▼

3. Modify the parameters you want to change:
 - **DSCP** – Read-only. The DSCP value to be mapped.
 - **Binary** – Read-only. The binary representation of the DSCP value.
 - **Description** – Read-only. The description of the DSCP value.
 - **CoS** – The CoS assigned to frames with the designated DSCP value.
 - **Color** – The Color assigned to frames with the designated DSCP value.
4. Click **Apply**, then **Close**.


Modifying the MPLS EXP Bit Classification Table

MPLS bits are used to provide QoS capabilities by utilizing the bits set in the MPLS labels. Classification by MPLS bits is supported in both untagged and 802.1Q provider-tagged frames.


To modify the classification criteria for MPLS EXP bits:

1. Select **Ethernet > QoS > Classification > MPLS**. The MPLS Classification page opens.

Figure 222 MPLS Classification Page



2. Select the row you want to modify and click **Edit**. The MPLS Classification - Edit page opens.

Figure 223 MPLS Classification - Edit Page

MPLS Classification

MPLS Classification Table - Edit

MPLS EXP 0

CoS 0 (0..7)

Color Yellow

Apply Refresh Close

3. Modify the parameters you want to change:
 - **MPLS EXP** – Read-only. The MPLS (experimental) bit to be mapped.
 - **CoS** – The CoS assigned to frames with the designated MPLS EXP value.
 - **Color** – The Color assigned to frames with the designated MPLS EXP value.
4. Click **Apply**, then **Close**.

Configuring Policers (Rate Metering)

This section includes:

- [Policer \(Rate Metering\) Overview](#)
- [Configuring Policer Profiles](#)
- [Assigning Policers to Interfaces](#)
- [Configuring the Ingress and Egress Byte Compensation](#)

Policer (Rate Metering) Overview

The PTP 820G and PTP 820F switching fabric supports hierarchical policing on the logical interface level. You can define up to 250 rate meter (policer) profiles.



Note

Policing on the service point level, and the service point and CoS level, is planned for future release.

PTP 820G and PTP 820F 's policer mechanism is based on a dual leaky bucket mechanism (TrTCM). The policers can change a frame's color and CoS settings based on CIR/EIR + CBS/EBS, which makes the policer mechanism a key tool for implementing bandwidth profiles and enabling operators to meet strict SLA requirements.

The output of the policers is a suggested color for the inspected frame. Based on this color, the queue management mechanism decides whether to drop the frame or to pass it to the queue.

Configuring Policer Profiles

This section includes:


- [Adding a Policer Profile](#)
- [Editing a Policer Profile](#)
- [Deleting a Policer Profile](#)

Adding a Policer Profile

To add a policer profile:


1. Select **Ethernet > QoS > Policer > Policer Profile**. The Policer Profile page opens.

Figure 224 Policer Profile Page



2. Click **Add**. The Policer Profile - Add page opens.

Figure 225 Policer Profile - Add Page



3. Configure the profile's parameters. See [Table 71 Policer Profile Parameters](#) for a description of the policer profile parameters.
4. Click **Apply**, then **Close**.

Table 71 Policer Profile Parameters

Parameter	Definition
Profile ID	A unique ID for the policer profile. You can choose from any unused value from 1 to 250. Once you have added the profile, you cannot change the Profile ID.
Description	A description of the policer profile.
Policer type	Read-only. The type of policer. Always set to MEF-TRTCM.
CIR	Enter the Committed Information Rate (CIR) for the policer, in bits per second. Permitted values are 0, or 64,000 through 1,000,000,000 bps. If the value is 0, all incoming CIR traffic is dropped.
CBS	Enter the Committed Burst Rate (CBR) for the policer, in Kbytes. Permitted values are 2 through 128 Kbytes.
EIR	Enter the Excess Information Rate (EIR) for the policer, in bits per second. Permitted values are 0, or 64,000 through 1,000,000,000 bps. If the value is 0, all incoming EIR traffic is dropped.
EBS	Enter the Excess Burst Rate (EBR) for the policer, in Kbytes. Permitted values are 2 through 128 Kbytes.
Color mode	Select how the policer treats packets that ingress with a CFI or DEI field set to 1 (yellow). Options are: Color Aware – All packets that ingress with a CFI/DEI field set to 1 (yellow) are treated as EIR packets, even if credits remain in the CIR bucket. Color Blind – All ingress packets are treated as green regardless of their CFI/DEI value. A color-blind policer discards any former color decisions.
Coupling flag	Select Enable or Disable . When enabled, frames that ingress as yellow may be converted to green when there are no available yellow credits in the EIR bucket. Coupling Flag is only relevant in Color Aware mode.

Editing a Policer Profile

To edit a policer profile, select the profile in the Police Profile table and click **Edit**. The Policer Profile Table Edit page opens.

The Policer Profile Table - Edit page is identical to the Policer Profile Table - Add page ([Figure 225](#)). You can edit any parameter that can be configured in the Policer Profile Table Add page, except the **Profile ID**.

Deleting a Policer Profile

You cannot delete a policer profile that is attached to a logical interface. You must first remove the profile from the logical interface, then delete the profile. See [Assigning Policers to Interfaces](#).

To delete a policer profile, select the profile in the Police Profile table and click **Delete**. The profile is deleted.

To delete multiple policer profiles:


1. Select the profiles in the Policer Profile table or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Assigning Policers to Interfaces

To assign policers to a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select the interface in the Ethernet Logical Port Configuration table and click **Policies**. The Policies page opens.

Figure 226 Logical Interfaces – Policies Page – Unicast Policer (Default)



For a logical interface, you can assign policers to the following traffic flows:

- Unicast Policer
- Multicast Policer
- Broadcast Policer
- Ethertype Policers

Assigning Unicast Policers

To assign a policer for unicast traffic to a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select the interface in the Ethernet Logical Port Configuration Table and click **Policies**. The Policies page opens. By default, the Policies page opens to the Unicast Policer table (Figure 226).


3. In the **Policer profile** field, select a profile from the policer profiles defined in the system. The **Policer profile** drop-down list includes the ID and description of all defined profiles.
4. In the **Unicast admin** field, select **Enable** to enable policing on unicast traffic flows from the logical interface, or **Disable** to disable policing on unicast traffic flows from the logical interface.
5. Click **Apply**.

Assigning Multicast Policers

To assign a policer for multicast traffic to a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 214](#)).
2. Select the interface in the Ethernet Logical Port Configuration table and click **Policers**. The Policers page opens. By default, the Policers page opens to the Unicast Policer table ([Figure 226](#)).
3. Select **Multicast Policer**. The Multicast Policer table appears.

Figure 227 Logical Interfaces – Policers Page – Multicast Policer



4. In the Policer profile field, select a profile from the policer profiles defined in the system. The Policer profile drop-down list includes the ID and description of all defined profiles.
5. In the Multicast admin field, select **Enable** to enable policing on multicast traffic flows from the logical interface, or **Disable** to disable policing on multicast traffic flows from the logical interface.
6. Click **Apply**.


Assigning Broadcast Policers

To assign a policer for broadcast traffic to a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 214](#)).

2. Select the interface in the Ethernet Logical Port Configuration table and click **Policers**. The Policers page opens. By default, the Policers page opens to the Unicast Policer table (Figure 226).
3. Select **Broadcast Policer**. The Broadcast Policer table appears.

Figure 228 Logical Interfaces – Policers Page – Broadcast Policer



4. In the **Policer profile** field, select a profile from the policer profiles defined in the system. The **Policer profile** drop-down list includes the ID and description of all defined profiles.
5. In the **Broadcast admin** field, select **Enable** to enable policing on broadcast traffic flows from the logical interface, or **Disable** to disable policing on broadcast traffic flows from the logical interface.
6. Click **Apply**.


Assigning Ethertype Policers

You can define up to three policers per Ethertype value.

To assign a policer to an Ethertype:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select the interface in the Ethernet Logical Port Configuration Table and click **Policers**. The Policers page opens. By default, the Policers page opens to the Unicast Policer table (Figure 226).
3. Select **Ethertype type 1 Policer**. The Ethertype type 1 Policer table appears.

Figure 229 Logical Interfaces – Policers Page – Ethertype Policer



4. In the **Ethertype 1 profile** field, select a profile from the policer profiles defined in the system. The **Ethertype 1 profile** drop-down list includes the ID and description of all defined profiles.
5. In the **Ethertype 1 user value** field, enter the Ethertype value to which you want to apply this policer. The field length is 4 nibbles (for example, 0x0806 - ARP).
6. In the **Ethertype 1 admin** field, select **Enable** to enable policing on the logical interface for the specified ethertype, or **Disable** to disable policing on the logical interface for the specified ethertype.
7. Click **Apply**.
8. To assign policers to additional Ethertypes, select **Ethertype type 2 Policer** and **Ethertype type 3 Policer** and repeat the steps above.

Configuring the Ingress and Egress Byte Compensation

You can define the ingress and egress byte compensation value per logical interface. The policer attached to the interface uses these values to compensate for Layer 1 non-effective traffic bytes.

To define the ingress byte compensation value for a logical interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select the interface you want to configure and click **Edit**. The Logical Interfaces - Edit page opens (Figure 215).
3. In the **Ingress byte compensation** field, enter the ingress byte compensation value, in bytes. Permitted values are 0 to 32 bytes. The default value is 20 bytes.
4. In the **Egress byte compensation** field, enter the egress byte compensation value, in bytes. Permitted values are 0 to 32 bytes. The default value is 0 bytes. Only even values are permitted.
5. Click **Apply**, then **Close**.

Configuring Marking

This section includes:

- [Marking Overview](#)
- [Enabling Marking](#)
- [Modifying the 802.1Q Marking Table](#)
- [Modifying the 802.1AD Marking Table](#)

Marking Overview

When enabled, PTP 820G and PTP 820F 's marking mechanism modifies each frame's 802.1p UP bit and CFI/DEI bits according to the classifier decision. The CFI/DEI (color) field is modified according to the classifier and policer decision. The color is first determined by a classifier and may be later overwritten by a policer. Green color is represented by a CFI/DEI value of 0, and Yellow color is represented by a CFI/DEI value of 1. Marking is performed on egress frames that are VLAN-tagged.

The marking is performed according to global mapping tables that describe the 802.1p UP bits and the CFI bits (for C-VLAN tags) or DEI bits (for S-VLAN tags). The marking bit in the service point egress attributes determines whether the frame is marked as green or according to the calculated color.



Note

The calculated color is sent to the queue manager regardless of whether the marking bit is set.

Regular marking is only performed when:

- The outer frame is S-VLAN, and S-VLAN CoS preservation is disabled, or
- The outer frame is C-VLAN, and C-VLAN CoS preservation is disabled.

If marking and CoS preservation for the relevant outer VLAN are both disabled, special marking is applied. Special marking means that marking is performed, but only according to the values defined for Green frames in the 802.1Q and 802.1AD marking tables.

When marking is performed, the C-VLAN or S-VLAN 802.1p UP bits are re-marked according to the calculated CoS and color, and the mapping table for C-VLAN or S-VLAN.

Enabling Marking

Marking is enabled and disabled on the service point level. See [Ethernet Service Points – Egress Attributes](#).


Modifying the 802.1Q Marking Table

The 802.1Q Marking table enables you to modify the CoS to UP and CFI bit mapping that is implemented when marking is enabled.

To modify the 802.1Q Marking table:


1. Select **Ethernet > QoS > Marking > 802.1Q**. The 802.1Q Marking page opens. Each row in the 802.1Q Marking page represents a CoS and color combination.

Figure 230 802.1Q Marking Page



2. Select the row you want to modify and click **Edit**. The 802.1Q Marking - Edit page opens.

Figure 231 802.1Q Marking - Edit Page



3. Enter the new 802.1Q UP and 802.1Q CFI values.
4. Click **Apply**, then **Close**.


Modifying the 802.1AD Marking Table

The 802.1AD Marking table enables you to modify the CoS to UP and DEI bit mapping that is implemented when marking is enabled.

To modify the 802.1AD Marking table:


1. Select **Ethernet > QoS > Marking > 802.1AD**. The 802.1AD Marking page opens. Each row in the 802.1AD Marking page represents a CoS and color combination.

Figure 232 802.1AD Marking Page



2. Select the row you want to modify and click **Edit**. The 802.1AD Marking - Edit page opens.

Figure 233 802.1AD Marking - Edit Page



3. Enter the new 802.1AD UP and 802.1AD DEI values.
4. Click **Apply**, then **Close**.

Configuring WRED

This section includes:

- [WRED Overview](#)
- [Configuring WRED Profiles](#)
- [Assigning WRED Profiles to Queues](#)

WRED Overview

Weighted Random Early Detection (WRED) enables differentiation between higher and lower priority traffic based on CoS. You can define up to 30 WRED profiles. Each profile contains a green traffic curve and a yellow traffic curve. This curve describes the probability of randomly dropping frames as a function of queue occupancy.

The system also includes two pre-defined read-only profiles. These profiles are assigned profile IDs 31 and 32:

- Profile number 31 defines a tail-drop curve and is configured with the following values:
 - 100% Yellow traffic drop after 64kbytes occupancy.
 - 100% Green traffic drop after 128kbytes occupancy.
 - Yellow maximum drop is 100%
 - Green maximum drop is 100%
- Profile number 32 defines a profile in which all will be dropped. It is for internal use and should not be applied to traffic.

A WRED profile can be assigned to each queue. The WRED profile assigned to the queue determines whether or not to drop incoming packets according to the occupancy of the queue. As the queue occupancy grows, the probability of dropping each incoming frame increases as well. As a consequence, statistically more TCP flows will be restrained before traffic congestion occurs.

Configuring WRED Profiles

This section includes:


- [Adding a WRED Profile](#)
- [Editing a WRED Profile](#)
- [Deleting a WRED Profile](#)

Adding a WRED Profile

To add a WRED profile:


1. Select **Ethernet > QoS > WRED > WRED Profile**. The WRED Profile page opens.

Figure 234 WRED Profile Page



2. Click **ADD**. The WRED Profile - Add page opens, with default values displayed.

Figure 235 WRED Profile - Add Page



3. In the **WRED Profile ID** field, select a unique ID to identify the profile. Permitted values are 1-30.
4. In the **Green curve min point** field, enter the minimum throughput of green packets for queues with this profile, in Kbytes (0-8192). When this value is reached, the system begins dropping green packets in the queue.
5. In the **Green curve max point** field, enter the maximum throughput of green packets for queues with this profile, in Kbytes (0-8192). When this value is reached, all green packets in the queue are dropped.
6. In the **Green curve max drop ratio** field, enter the maximum percentage (1-100) of dropped green packets for queues with this profile.

7. In the **Yellow curve min point** field, enter the minimum throughput of yellow packets for queues with this profile, in Kbytes (0-8192). When this value is reached, the system begins dropping yellow packets in the queue.
8. In the **Yellow curve max point** field, enter the maximum throughput of yellow packets for queues with this profile, in Kbytes (0-8192). After this value is reached, all yellow packets in the queue are dropped.
9. In the **Yellow curve max drop ratio** field, enter the maximum percentage (1-100) of dropped yellow packets for queues with this profile.
10. Click **Apply**, then **Close**.

Editing a WRED Profile

To edit a WRED profile:

1. Select **Ethernet > QoS > WRED > WRED Profile**. The WRED Profile page opens ().
2. Select the profile you want to edit and click **Edit**. The WRED Profile – Edit page opens. This page is similar to the WRED Profile – Add page ([Figure 235](#)). You can edit any parameter except the **WRED Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a WRED Profile

You cannot delete a WRED profile that is assigned to a queue. You must first remove the WRED profile from the queue, then delete the WRED profile. See [Assigning WRED Profiles to Queues](#).

To delete a WRED profile, select the profile in the WRED Profile Configuration table ([Figure 234](#)) and click **Delete**. The profile is deleted.

To delete multiple WRED profiles:


1. Select the profiles in the WRED Profile Configuration table or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Assigning WRED Profiles to Queues

To assign a WRED profile to a queue:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select an interface in the Ethernet Logical Port Configuration table and click **WRED**. The WRED page opens.

Figure 236 Logical Interfaces – WRED Page



3. In the **Show Service bundle ID** field, select 1.




Note

Service Bundles are bundles of queues, grouped together in order to configure common egress characteristics for specific services. In the current release, only Service Bundle 1 is supported.

4. Select a CoS Queue ID and click **Edit**. The Logical Interfaces – WRED – Edit page opens.

Figure 237 Logical Interfaces – WRED - Edit Page



5. In the **Profile ID** field, select the WRED profile you want to assign to the selected queue.
6. Click **Apply**, then **Close**.

Configuring Egress Shaping

This section includes:

- [Egress Shaping Overview](#)
- [Configuring Queue Shaper Profiles](#)
- [Configuring Service Bundle Shaper Profiles](#)
- [Assigning a Queue Shaper Profile to a Queue](#)
- [Assigning a Service Bundle Shaper Profile to a Service Bundle](#)

Egress Shaping Overview

Egress shaping determines the traffic profile for each queue. PTP 820G and PTP 820F can perform queue shaping on the following levels:

- **Queue Level** – Single leaky bucket shaping. On the queue level, you can configure up to 31 single leaky bucket shaper profiles. If no profile is attached to the queue, no egress shaping is performed on that queue.
- **Service Bundle Level** – Dual leaky bucket shaping. On the service bundle level, users can configure up to 256 dual leaky bucket shaper profiles. If no profile is attached to the service bundle, no egress shaping is performed on that service bundle.
- **Interface Level** – Single leaky bucket shaping.



Note

Egress shaping on the interface level is planned for future release.

Configuring Queue Shaper Profiles

This section includes:


- [Adding a Queue Shaper Profile](#)
- [Editing a Queue Shaper Profile](#)
- [Deleting a Queue Shaper Profile](#)

Adding a Queue Shaper Profile

To add a queue shaper profile:


1. Select **Ethernet > QoS > Shaper > Queue Profiles**. The Queue Shaper Profile page opens.

Figure 238 Queue Shaper Profile Page



2. Click **Add**. The Queue Shaper – Add page opens, with default values displayed.

Figure 239 Queue Shaper Profile – Add Page



3. In the **Profile ID** field, select a unique ID to identify the profile. Permitted values are 1-31.
4. Optionally, in the **Description** field, enter a description of the profile.
5. In the **CIR** field, enter the Committed Information Rate (CIR) assigned to the profile, in bits per second. Permitted values are:
 - o 16,000 - 32,000,000 bps, with granularity of 16,000.
 - o 32,000,000 - 131,008,000 bps, with granularity of 64,000.
6. Click **Apply**, then **Close**.

Editing a Queue Shaper Profile

To edit a queue shaper profile:

1. Select **Ethernet > QoS > Shaper > Queue Profiles**. The Queue Shaper Profile page opens ([Figure 238](#)).
2. Select the profile you want to edit and click **Edit**. The Queue Shaper Profile – Edit page opens. This page is similar to the Queue Shaper Profile – Add page ([Figure 239](#)). You can edit any parameter except the **Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a Queue Shaper Profile

You cannot delete a queue shaper profile that is assigned to a queue. You must first remove the profile from the queue, then delete the profile. See [Assigning a Queue Shaper Profile to a Queue](#).

To delete a queue shaper profile, select the profile in the Queue Shaper Profiles Configuration table ([Figure 238](#)) and click **Delete**. The profile is deleted.

To delete multiple queue shaper profiles:

1. Select the profiles in the Queue Shaper Profiles Configuration table or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Configuring Service Bundle Shaper Profiles

This section includes:


- [Adding a Service Bundle Shaper Profile](#)
- [Editing a Service Bundle Shaper Profile](#)
- [Deleting a Service Bundle Shaper Profile](#)

Adding a Service Bundle Shaper Profile

To add a service bundle shaper profile:


1. Select **Ethernet > QoS > Shaper > Service Bundle Profiles**. The Service Bundle Shaper Profile page opens.

Figure 240 Service Bundle Shaper Profile Page



2. Click **Add**. The Service Bundle Shaper Profile – Add page opens, with default values displayed.

Figure 241 Service Bundle Shaper Profile – Add Page



3. In the **Profile ID** field, select a unique ID to identify the profile. Permitted values are 1-31.

4. Optionally, in the **Description** field, enter a description of the profile.
5. In the **CIR** field, enter the Committed Information Rate (CIR) assigned to the profile, in bits per second. Permitted values are:
 - 0 – 32,000,000 bps, with granularity of 16,000.
 - 32,000,000 – 1,000,000,000 bps, with granularity of 64,000.
6. In the **PIR** field, enter the Peak Information Rate (PIR) assigned to the profile, in bits per second. Permitted values are:
 - 16,000 – 32,000,000 bps, with granularity of 16,000.
 - 32,000,000 – 1,000,000,000 bps, with granularity of 64,000.
7. Click **Apply**, then **Close**.

Editing a Service Bundle Shaper Profile

To edit a service bundle shaper profile:

1. Select **Ethernet > QoS > Shaper > Service Bundle Profiles**. The Service Bundle Shaper Profile page opens (Figure 240).
2. Select the profile you want to edit and click **Edit**. The Service Bundle Shaper Profile – Edit page opens. This page is similar to the Service Bundle Shaper Profile – Add page (Figure 241). You can edit any parameter except the **Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a Service Bundle Shaper Profile

You cannot delete a service bundle shaper profile that is assigned to a service bundle. You must first remove the profile from the service bundle, then delete the profile.

To delete a service bundle shaper profile, select the profile in the Service Bundle Shaper Profiles Configuration table (Figure 240) and click **Delete**. The profile is deleted.

To delete multiple service bundle shaper profiles:


1. Select the profiles in the Service Bundle Shaper Profiles Configuration table or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Assigning a Queue Shaper Profile to a Queue

To assign a queue shaper profile to a queue:


1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Shaper**. The Logical Interfaces – Shaper page opens, with the Egress Queue Shaper Configuration table open by default. All queue shaper profiles defined in the system are listed in the table.

Figure 242 Logical Interfaces – Shaper – Egress Queue Shaper



3. Click **Add**. The Egress Queue Shaper Configuration – Add page opens.

Figure 243 Logical Interfaces – Egress Queue Shaper Configuration – Add Page



Note

In this release, only one service bundle (Service Bundle ID 1) is supported.

4. In the **CoS queue ID** field, select the CoS queue ID of the queue to which you want to assign the shaper. Queues are numbered according to CoS value, from 0 to 7.
5. In the **Profile ID** field, select from a list of configured queue shaper profiles. See [Configuring Queue Shaper Profiles](#).

6. In the **Shaper Admin** field, select **Enable** to enable egress queue shaping for the selected queue, or **Disable** to disable egress queue shaping for the selected queue.
7. Click **Apply**, then **Close**.

To assign a different queue shaper profile to a queue:


1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 214](#)).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Shaper**. The Logical Interfaces – Shaper page opens, with the Egress Queue Shaper Configuration table open by default ([Figure 242](#)).
3. Select an interface in the Ethernet Logical Port Configuration table and click **Shaper**. The Logical Interfaces – Shaper page opens, with the Egress Queue Shaper Configuration table open by default ([Figure 242](#)).
4. Select the row you want to edit and click **Edit**. The Egress Queue Shaper Configuration – Edit page opens. This page is similar to the Egress Queue Shaper Configuration – Add page ([Figure 243](#)).
5. To assign a different egress queue shaper profile, select the profile in the **Profile ID** field.
6. To enable or disable egress queue shaping for the selected queue, select **Enable** to enable egress queue shaping for the queue, or **Disable** to disable egress queue shaping for the queue.
7. Click **Apply**, then **Close**.

Assigning a Service Bundle Shaper Profile to a Service Bundle

To assign a service bundle shaper profile to a service bundle:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Shaper**. The Logical Interfaces – Shaper page opens, with the Egress Queue Shaper Configuration table open by default (Figure 242).
3. Select **Egress Service Bundle Shaper**. The Egress Service Bundle Shaper Configuration table appears. All service bundle shaper profiles defined in the system are listed in the table.

Figure 244 Logical Interfaces – Shaper – Egress Service Bundle Shaper



4. Click **Add**. The Egress Service Bundle Shaper Configuration – Add page opens.

Figure 245 Logical Interfaces – Egress Service Bundle Shaper Configuration – Add Page

**Note**

In this release, only one service bundle (Service Bundle ID 1) is supported.

5. In the **Profile ID** field, select from a list of configured service bundle shaper profiles. See [Configuring Service Bundle Shaper Profiles](#).
6. In the **Shaper Admin** field, select **Enable** to enable egress service bundle shaping, or **Disable** to disable egress service bundle shaping.
7. Click **Apply**, then **Close**.

To assign a different service bundle shaper profile:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 214](#)).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Shaper**. The Logical Interfaces – Shaper page opens, with the Egress Queue Shaper Configuration table open by default ([Figure 242](#)).
3. Select **Egress Service Bundle Shaper**. The Egress Service Bundle Shaper Configuration table appears ([Figure 244](#)). All service bundle shaper profiles defined in the system are listed in the table.
4. Select the row you want to edit and click **Edit**. The Egress Service Bundle Shaper Configuration – Edit page opens. This page is similar to the Egress Service Bundle Shaper Configuration – Add page ([Figure 245](#)).
5. To assign a different egress queue shaper profile, select the profile in the **Profile ID** field.
6. To enable or disable egress service bundle shaping, select **Enable** or **Disable**.
7. Click **Apply**, then **Close**.

Configuring Scheduling

This section includes:

- [Scheduling Overview](#)
- [Configuring Priority Profiles](#)
- [Configuring WFQ Profiles](#)
- [Assigning a Priority Profile to an Interface](#)
- [Assigning a WFQ Profile to an Interface](#)

Scheduling Overview

Scheduling determines the priority among the queues. PTP 820G and PTP 820F provides a unique hierarchical scheduling model that includes four priorities, with Weighted Fair Queuing (WFQ) within each priority, and shaping per port and per queue.

The scheduler scans the queues and determines which queue is ready to transmit. If more than one queue is ready to transmit, the scheduler determines which queue transmits first based on:

- **Queue Priority** – A queue with higher priority is served before lower-priority queues.
- **Weighted Fair Queuing (WFQ)** – If two or more queues have the same priority and are ready to transmit, the scheduler transmits frames from the queues based on a WFQ algorithm that determines the ratio of frames per queue based on a predefined weight assigned to each queue.

Configuring Priority Profiles

Scheduling priority profiles determine the queue priority. Each profile contains eight CoS-based priorities, corresponding to eight queues in an interface to which the profile is assigned. You can configure up to eight priority profiles. A ninth profile, Profile ID 9, is pre-configured. You can configure Green priorities from 4 (highest) to 1 (lowest). An additional four Yellow priority profiles are defined automatically.

This section includes:


- [Adding a Scheduler Priority Profile](#)
- [Editing a Service Scheduler Priority Profile](#)
- [Deleting a Scheduler Priority Profile](#)

Adding a Scheduler Priority Profile

To add a scheduler priority profile:

1. Select **Ethernet > QoS > Scheduler > Priority Profiles**. The Scheduler Priority Profile page opens.

Figure 246 Scheduler Priority Profile Page



2. Click **Add**. The Scheduler Priority Profile – Add page opens, with default values displayed.

Figure 247 Scheduler Priority Profile – Add Page

Port Priority Profiles Configuration Table - Add

Profile ID: 1

CoS 0	best effort	Green CoS 0 priority: 1 (1..4)	Yellow CoS 0 priority: 1
CoS 1	data service 4	Green CoS 1 priority: 2 (1..4)	Yellow CoS 1 priority: 1
CoS 2	data service 3	Green CoS 2 priority: 2 (1..4)	Yellow CoS 2 priority: 1
CoS 3	data service 2	Green CoS 3 priority: 2 (1..4)	Yellow CoS 3 priority: 1
CoS 4	data service 1	Green CoS 4 priority: 2 (1..4)	Yellow CoS 4 priority: 1
CoS 5	real time 2	Green CoS 5 priority: 3 (1..4)	Yellow CoS 5 priority: 1
CoS 6	real time 1	Green CoS 6 priority: 3 (1..4)	Yellow CoS 6 priority: 1
CoS 7	management	Green CoS 7 priority: 4	Yellow CoS 7 priority: 4

Buttons: Apply, Refresh, Close

3. In the **Profile ID** field, select a unique Profile ID between 1 and 8.
4. For each CoS value, enter the Green priority, from 4 (highest) to 1 (lowest) (1-4). This priority is applied to Green frames with that CoS egressing a queue to which the profile is assigned.
5. Optionally, you can enter a description of up to 20 characters in the field to the right of each CoS value.
6. Click **Apply**, then **Close**.

**Note**

The Yellow priority values are assigned automatically by the system.

Editing a Service Scheduler Priority Profile

To edit a scheduler priority profile:

1. Select **Ethernet > QoS > Scheduler > Priority Profiles**. The Scheduler Priority Profile page opens ([Figure 246](#)).
2. Select the profile you want to edit and click **Edit**. The Scheduler Priority Profile – Edit page opens. This page is similar to the Scheduler Priority Profile – Add page ([Figure 247](#)). You can edit any parameter except the **Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a Scheduler Priority Profile

To delete a scheduler priority profile, select the profile in the Scheduler Priority Profiles page ([Figure 246](#)) and click **Delete**. The profile is deleted.

To delete multiple scheduler priority profiles:

1. Select the profiles in the Scheduler Priority Profiles page or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Configuring WFQ Profiles

WFQ profiles determine the relative weight per queue. Each profile contains eight CoS-based weight values, corresponding to eight queues in an interface to which the profile is assigned. You can configure up to five WFQ profiles. A sixth profile, Profile ID 1, is pre-configured.

This section includes:


- [Adding a WFQ Profile](#)
- [Editing a WFQ Priority Profile](#)
- [Deleting a WFQ Profile](#)

Adding a WFQ Profile

To add a WFQ profile:

1. Select **Ethernet > QoS > Scheduler > WFQ Profiles**. The Scheduler WFQ Profile page opens.

Figure 248 Scheduler WFQ Profile Page



2. Click **Add**. The Scheduler WFQ Profile – Add page opens, with default values displayed.

Figure 249 Scheduler WFQ Profile – Add Page

3. In the **Profile ID** field, select a unique Profile ID between 2 and 7. Profile ID 1 is used for a pre-defined WFQ profile.
4. For each CoS value, enter the weight for that CoS, from 1 to 20.
5. Click **Apply**, then **Close**.

Editing a WFQ Priority Profile

To edit a scheduler WFQ profile:

1. Select **Ethernet > QoS > Scheduler > WFQ Profiles**. The Scheduler WFQ Profile page opens ([Figure 248](#)).
2. Select the profile you want to edit and click **Edit**. The Scheduler WFQ Profile – Edit page opens. This page is similar to the Scheduler WFQ Profile – Add page ([Figure 249](#)). You can edit any parameter except the **Profile ID**.
3. Modify the profile.
4. Click **Apply**, then **Close**.

Deleting a WFQ Profile

To delete a scheduler WFQ profile, select the profile in the Scheduler WFQ Profiles page ([Figure 248](#)) and click **Delete**. The profile is deleted.

To delete multiple scheduler WFQ profiles:


1. Select the profiles in the Scheduler WFQ Profiles page or select all the profiles by selecting the check box in the top row.
2. Click **Delete**. The profiles are deleted.

Assigning a Priority Profile to an Interface

To assign a priority profile to an interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Scheduler**. The Logical Interfaces – Scheduler page opens, with the Egress Port Scheduling Priority Configuration – Edit page open by default.

Figure 250 Logical Interfaces – Scheduler – Egress Port Scheduling Priority




3. In the **Profile ID** field, select from a list of configured scheduling priority profiles. See *Configuring Priority Profiles*.
4. Click **Apply**, then **Close**.

Assigning a WFQ Profile to an Interface

To assign a WFQ profile to an interface:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens (Figure 214).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Scheduler**. The Logical Interfaces – Scheduler page opens, with the Egress Port Scheduling Priority Configuration – Edit page open by default (Figure 250).
3. Select **Egress Port Scheduling WFQ**. The Egress Port Scheduling WFQ Configuration – Edit page opens.

Figure 251 Logical Interfaces – Scheduler – Egress Port Scheduling WFQ



4. In the **Profile ID** field, select from a list of configured scheduling priority profiles. See [Configuring WFQ Profiles](#).
5. Click **Apply**, then **Close**.

Chapter 8: Ethernet Protocols

This section includes:

- [Configuring G.8032](#)
- [Configuring MSTP](#)
- [Configuring LLDP](#)

Configuring G.8032

This section includes:

- [G.8032 Overview](#)
- [Configuring the Destination MAC Address](#)
- [Adding ERPIs](#)
- [Configuring the RPL Owner](#)
- [Configuring Timers](#)
- [Viewing the ERPI Configuration and Status Parameters](#)
- [Viewing ERPI State Information](#)
- [Initiating a Manual or Forced Switch and Clearing the Switch or Initiating Reversion](#)
- [Blocking or Unblocking R-APS Messages on a Service Point](#)
- [Viewing ERPI Statistics](#)

G.8032 Overview

ERPS, as defined in the G.8032 ITU standard, is currently the most advanced ring protection protocol, providing convergence times of sub-50ms. ERPS prevents loops in an Ethernet ring by guaranteeing that at any time, traffic can flow on all except one link in the ring. This link is called the Ring Protection Link (RPL). Under normal conditions, the RPL is blocked, i.e., not used for traffic. One designated Ethernet Ring Node, the RPL Owner Node, is responsible for blocking traffic at one end of the RPL. When an Ethernet ring failure occurs, the RPL Owner unblocks its end of the RPL, allowing the RPL to be used for traffic. The other Ethernet Ring Node adjacent to the RPL, the RPL Neighbor Node, may also participate in blocking or unblocking its end of the RPL. A number of ERP instances (ERPIs) can be created on the same ring.


For a more detailed description of G.8032 in the PTP 820G or PTP 820F, refer to the Technical Description for the product you are using..

Configuring the Destination MAC Address

To configure the destination MAC address for G.8032:

- 1 Select **Ethernet > Protocols > G.8032 > General Attribute**. The G.8032 General Attribute page opens.

Figure 252 G.8032 General Attribute Page



- 2 In the **G8032 destination MAC address field**, enter the destination MAC address for PDUs generated by the node.
- 3 Click **Apply**.



Note

The G.8032 Node ID field displays the base MAC address for the node. This field is read-only.

Adding ERPIs

You can configure up to 64 Ethernet Ring Protection instances (ERPIs). Each ERPI is associated with an Ethernet service defined in the system.




Note

Before adding an ERPI to an Ethernet service, the service must be mapped to an MSTP instance. See [Mapping Ethernet Services to MSTP instances \(MSTIs\)](#).

To add an ERPI:

- 1 Select **Ethernet > Protocols > G.8032 > ERPI Attribute**. The G.8032 ERPI Attribute page opens.

Figure 253 G.8032 ERPI Attribute Page



- 2 Click **Add**. The Add G8032 ERPI Attribute wizard opens.

Figure 254 G.8032 ERPI Attribute Wizard – Page 1



- 3 In the **ERPI ID** field, select an available ID. The ERPI ID is a unique ID that identifies the ERPI.

- 4 Optionally, in the **ERPI Name** field, enter a descriptive name for the ERPI.
- 5 In the **Type** field, select the type of ERPI, based on the type of ring:
 - **Ring:** A Ring is an Ethernet ring that is connected on two ports (East and West service points) to an interconnection node.
 - **Sub-ring:** A Sub-Ring is an Ethernet ring which is connected to another ring or network through the use of interconnection nodes (East and West service points). On their own, the Sub-Ring links do not form a closed physical loop. A closed loop may be formed by the sub-ring links and the link between interconnection nodes that is controlled by other ring or network.
 - **Ring with sub-ring:** The ERPI includes both a ring, with East and West service points, and a connection to a sub-ring using a Sub-Ring service point.
- 6 In the **Service ID** field, select the ID of the Ethernet service to which the ERPI belongs.
- 7 Optionally, in the **MEG Level** field, select the Maintenance Entity Group (MEG) level used for R-APS messages sent in the ERPI (0-7).
- 8 Click **Next**. The second page of the Add G.8032 ERPI Attribute wizard opens.

Figure 255 G.8032 ERPI Attribute Wizard – Page 2

The screenshot shows a window titled "Add G8032 ERPI Attribute" with the following fields and values:

- ERPI ID: 1
- ERPI Name: W_65_GSm
- Type: Ring
- Service ID: 1
- MEG Level: 5
- West ERPI port (SP): Service Point #1, Ethernet: Slot 1, port 1

At the bottom of the window, there are three buttons: "<< Back", "Next >>", and "Close".

- 9 In the **West ERPI port (SP)** field, select the first endpoint for the ERPI. This can be any service point that has been configured for the service.
- 10 Click **Next**. The third page of the Add G.8032 ERPI Attribute wizard opens.

Figure 256 G.8032 ERPI Attribute Wizard – Page 3

Add G8032 ERPI Attribute

ERPI ID	1
ERPI Name	W_65_GSm
Type	Ring
Service ID	1
MEG Level	5
West ERPI port (SP)	Service Point #1, Ethernet: Slot 1, port 1
East ERPI port (SP)	Service Point #2, Radio: Slot 1, port 1

<< Back Next >> Close

- 11 In the **East ERPI port (SP)** field, select the second endpoint for the ERPI. This can be any service point that has been configured for the service.
- 12 Click **Next**:
 - If the **Type** is **Ring** or **Sub-ring**, the Submit page opens. Go to [Step 15](#).
 - If the **Type** is **Ring with sub-ring**, the fourth page of the Add G.8032 ERPI Attribute wizard opens.

Figure 257 G.8032 ERPI Attribute Wizard – Page 4

Add G8032 ERPI Attribute


ERPI ID	1
ERPI Name	G_SNam
Type	Ring with sub-ring
Service ID	1
MEG Level	1
West ERPI port (SP)	Service Point #1, Ethernet: Slot 1, port 1
East ERPI port (SP)	Service Point #2, Radio: Slot 1, port 1
Sub Ring port (SP)	Service Point #3, Ethernet: Slot 1, port 4

<< Back Next >> Close

- 13 In the **Sub Ring port (SP)** field, select the service point that connects the Ring with the Sub-Ring. This can be any service point that has been configured for the service.

- 14 Click **Next**. The Submit page opens.

Figure 258 G.8032 ERPI Attribute Wizard – Submit



Add G8032 ERPI Attribute	
ERPI ID	1
ERPI Name	G_SNam
Type	Ring with sub-ring
Service ID	1
MEG Level	1
West ERPI port (SP)	Service Point #1, Ethernet: Slot 1, port 1
East ERPI port (SP)	Service Point #2, Radio: Slot 1, port 1
Sub Ring port (SP)	Service Point #3, Ethernet: Slot 1, port 4

<< Back Next >> Submit Close

- 15 Verify that the parameters of the ERPI are correct and click **Submit**.

Configuring the RPL Owner

The RPL Owner Node is a node in the ERPI that is responsible for blocking traffic at one end of the ERPI. To designate the RPL Owner Node:

- 1 Select **Ethernet > Protocols > G.8032 > ERPI Attribute**. The G.8032 ERPI Attribute page opens (Figure 253).
- 2 Select the ERPI and click **Edit**. The ERPI Attribute – Edit page opens.

Figure 259 G.8032 ERPI Attribute – Edit Page

ERPI configuration

ERPI ID	1
ERPI Name	G_SNam
ERPI Type	Ring with sub-ring
ERPI Service ID	1
Instance ID	10
West ERPI port (SP)	Ethernet: Slot 1, port 1
East ERPI port (SP)	Radio: Slot 1, port 1
Sub Ring port (SP)	Ethernet: Slot 1, port 4
ERPI Protocol Version	2
RPL Owner	West
Revertive	True
Virtual Channel VLAN	0

Timers configuration

ERPI WTR	5	(1..12)
ERPI Guard Time	500	(10..2000)
ERPI Holdoff Time	0	(0..10000)

ERPI status

ERPI State	Protecting	
MEG Level	1	(0..7)
Last Local State	Local SF	
Last Remote State	NR	
Last HP Request	Local SF	
Last Change Timestamp	02-03-2015 08:24:50	

Apply Refresh Close

- 3 In the **RPL Owner** field, select the service point you want to configure as RPL Owner.
- 4 Click **Apply**, then **Close**.

Configuring Timers

You can configure timers per ERPI to control the ERPI's switching and convergence parameters. The following timers are available:

- **Wait to Restore (WTR) Timer** – Defines a minimum time the system waits after signal failure is recovered before reverting to idle state.
- **Guard Time** – Prevents unnecessary state changes and loops.
- **Hold-Off Time** – Determines the time period from failure detection to response.

To configure the ERPI timers:

- 1 Select **Ethernet > Protocols > G.8032 > ERPI Attribute**. The G.8032 ERPI Attribute page opens ([Figure 253](#)).
- 2 Select the ERPI and click **Edit**. The ERPI Attribute – Edit page opens ([Figure 259](#)).
- 3 In the **ERPI WTR** field, enter the Wait to Restore (WTR) timer (in minutes). The WTR timer is a minimum time the system waits after signal failure is recovered before reverting to idle state.
- 4 In the **ERPI Guard Time** field, enter the ERPI guard time (in msec). You must enter a multiple of 10. The guard time is the minimum time the system waits after recovery from a signal failure before accepting new R-APS messages. The purpose of this timer is to prevent unnecessary state changes and loops.
- 5 In the **ERPI Holdoff Time** field, enter the ERPI hold-off time (in msec). You must enter a multiple of 100. The hold-off time determines the time period from failure detection to response.
- 6 Click **Apply**, then **Close**.

Viewing the ERPI Configuration and Status Parameters

The G.8032 ERPI Attribute page ([Figure 253](#)) displays some of the configuration and status parameters for ERPIs configured in the system.

To display a full list of configuration and status parameters for an ERPI:

- 1 Select **Ethernet > Protocols > G.8032 > ERPI Attribute**. The G.8032 ERPI Attribute page opens ([Figure 253](#)).
- 2 Select the ERPI and click **Edit**. The ERPI Attribute – Edit page opens ([Figure 259](#)).
 - [Table 72](#) lists and describes the parameters in the ERPI configuration section of the ERPI Attribute – Edit page.
 - [Table 73](#) lists and describes the parameters in the ERPI status section of the ERPI Attribute – Edit page.

Table 72 Attached Interface Types

Parameter	Definition
ERPI ID	Read-only. A unique ID that identifies the ERPI.
ERPI Name	A descriptive name for the ERPI.
ERPI Type	Read-only. The ERPI type.
ERPI Service ID	Read-only. The ID of the Ethernet service to which the ERPI belongs.
Instance ID	Read-only. The MSTI to which the Ethernet service is mapped. See Mapping Ethernet Services to MSTP instances (MSTIs) .
West ERPI Port (SP)	Read-only. The interface to which the west ERPI service point belongs.

Parameter	Definition
East ERPI Port (SP)	Read-only. The interface to which the east ERPI service point belongs.
Sub Ring Port (SP)	Read-only. The interface to which the service point that connects the Ring with the Sub-Ring belongs.
ERPI Protocol Version	Read-only. The ERPI (G.8032) protocol version currently being used in the unit.
RPL Owner	The RPL Owner Node is a node in the ERPI that is responsible for blocking traffic at one end of the ERPI. See Configuring the RPL Owner .
Revertive	Read-only. Indicates whether the ERPI is currently in revertive mode.
Virtual Channel VLAN	Read-only. The VLAN of the virtual channel. If the value is 0, there is no virtual channel.

Table 73 ERPI Configuration Parameters

Parameter	Definition
ERPI State	Indicates the current ERPI state. Possible values are: <ul style="list-style-type: none"> • Initializing • Idle • Pending • Protecting • FS (Forced Switch) • MS (Manual Switch)
MEG Level	The Maintenance Entity Group (MEG) level used for R-APS messages sent in the ERPI.
Last Local State	Describes the current local state input to the ERPI state machine.
Last Remote State	Indicates the last event received from the other end of the link.
Last HP Request	Indicates the last high-priority event.
Last Change Timestamp	Indicates the time of the last ring state transition.

Viewing ERPI State Information

To view information about an ERPI's state:

- 1 Select **Ethernet > Protocols > G.8032 > ERPI Attribute**. The G.8032 ERPI Attribute page opens ([Figure 253](#)).
- 2 Select the ERPI and click **State**. The ERPI Attribute – State page opens.

Figure 260 G.8032 ERPI Attribute – State Page




Table 74 lists and describes the parameters in the ERPI Attribute – State page.

Table 74 ERPI State Parameters

Parameter	Definition
ERPI Port	Identifies whether the row is for the West endpoint, the East endpoint, or a Sub-Ring connection point.
ERPI Port Active State	Indicates whether or not the service point is active for traffic forwarding.
R-APS Channel Forwarding State	Indicates whether the service point is forwarding R-APS messages.
ERPI Data Forwarding State	Indicates whether the service point is in unblocked (forwarding) state.
RPL Blocking State	Only relevant if the ERPI to which the service point belongs is the RPL owner. Indicates whether the service point is in blocked state.
ERPI Port Defect State	Indicates whether the service point is in Signal Fail (SF) or Signal Defect (SD) state. Note: Support for Signal Defect state is planned for future release.

Initiating a Manual or Forced Switch and Clearing the Switch or Initiating Reversion

You can initiate a manual or forced switch, clear the switch, and initiate reversion, from the G.8032 ERPI Attribute – State page:

- 1 Select **Ethernet > Protocols > G.8032 > ERPI Attribute**. The G.8032 ERPI Attribute page opens (Figure 253).
- 2 Select the ERPI and click **State**. The ERPI Attribute – State page opens (Figure 260).
- 3 Select the service point on which you want to perform the operation.
 - o To initiate a forced switch, click **Force Switch**.
 - o To initiate a manual switch, click **Manual Switch**.
 - o To clear a forced or manual switch, click **Clear**. You can also click **Clear** to trigger convergence prior to the expiration of the relevant timer.

Blocking or Unblocking R-APS Messages on a Service Point

To enable or disable transmission of R-APS messages on a service point:

- 1 Select **Ethernet > Protocols > G.8032 > ERPI Attribute**. The G.8032 ERPI Attribute page opens (Figure 253).
- 2 Select the ERPI and click **State**. The ERPI Attribute – State page opens (Figure 260).
- 3 Select the service point on which you want to perform the operation.
 - o To block R-APS message transmission on the service point, click **R-APS Block**.
 - o To enable R-APS message transmission on the service point, click **R-APS Unblock**.

Viewing ERPI Statistics

To view statistics about an ERPI:

- 1 Select **Ethernet > Protocols > G.8032 > ERPI Attribute**. The G.8032 ERPI Attribute page opens (Figure 253).
- 2 Select the ERPI and click **Statistics**. The ERPI Attribute – Statistics page opens.

Figure 261 G.8032 ERPI Attribute – Statistics Page

ERPI Port	Transmitted total R-APS Frames	PDU	Transmitted SF PDU	Transmitted NR PDU	Transmitted RB PDU	Transmitted FS PDU	Transmitted MS PDU	Transmitted R-APS Events	Received R-APS Frames	Received Invalid R-APS Frames	Received SF PDU	Received NR PDU	Received RB PDU	Received SD PDU	Received FS PDU	Received MS PDU	Received R-APS Events
West	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
East	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Sub-ring	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Table 75 lists and describes the statistics shown in the ERPI Attribute – Statistics page.

Table 75 ERPI Statistics

Parameter	Definition
ERPI Port	Identifies whether the row is for the West endpoint, the East endpoint, or a Sub-Ring connection point.
Transmitted Total R-APS Frames	The number of R-APS frames that have been transmitted via the service point.
Transmitted SF PDU	The number of R-APS Signal Fail (SF) frames that have been transmitted via the service point.
Transmitted NR PDU	The number of R-APS No Request (NR) frames that have been transmitted via the service point.
Transmitted RB PDU	The number of R-APS RPL Blocked (RB) frames that have been transmitted via the service point.
Transmitted FS PDU	The number of R-APS Force Switched (FS) frames that have been transmitted via the service point.
Transmitted MS PDU	The number of R-APS Manual Switched (MS) frames that have been transmitted via the service point.
Transmitted R-APS Events	Reserved for future use.
Received R-APS Frames	The number of R-APS frames that have been received via the service point.
Received Invalid R-APS Frames	The number of R-APS frames with an invalid format that have been received via the service point.
Received SF PDU	The number of R-APS Signal Fail (SF) frames that have been received via the service point.
Received NR PDU	The number of R-APS No Request (NR) frames that have been received via the service point.
Received RB PDU	The number of R-APS RPL Blocked (RB) frames that have been received via the service point.
Received SD PDU	The number of R-APS Signal Degrade (SD) frames that have been received via the service point.
Received FS PDU	The number of R-APS Forced Switch (FS) frames that have been received via the service point.
Received MS PDU	The number of R-APS Manual Switch (MS) frames that have been received via the service point.
Received R-APS Events	Reserved for future use.

Configuring MSTP

This section includes:

- [MSTP Overview](#)
- [Mapping Ethernet Services to MSTP instances \(MSTIs\)](#)
- [Configuring the MSTP Bridge Parameters](#)
- [Configuring the MSTP Port Parameters](#)

MSTP Overview

MSTP, as defined in IEEE 802.1q, provides full connectivity for frames assigned to any given VLAN throughout a bridged LAN consisting of arbitrarily interconnected bridges.

With MSTP, an independent multiple spanning tree instance (MSTI) is configured for each group of services, and only one path is made available (unblocked) per spanning tree instance. This prevents network loops and provides load balancing capability. It also enables operators to differentiate among Ethernet services by mapping them to different, specific MSTIs. The maximum number of MSTIs is configurable, from 2 to 16.

MSTP is an extension of, and is backwards compatible with, Rapid Spanning Tree Protocol (RSTP).

PTP 820G and PTP 820F supports MSTP according to the following IEEE standards:

- 802.1q
- 802.1ad amendment (Q-in-Q)
- 802.1ah (TE instance)

For a more detailed description of MSTP support in the PTP 820G or PTP 820F, refer to the Technical Description for the product you are using.

Mapping Ethernet Services to MSTP instances (MSTIs)


Ethernet services can be mapped to MSTP instances (MSTIs) in the Instances per Service Mapping section of the Ethernet General Configuration page. All mapping of Ethernet services to MSTP instances (MSTIs) should be performed before enabling MSTP.

**Note**

Ethernet service-to-MSTI mapping is also a prerequisite to configuring G.8032. See [Configuring G.8032](#).

To map Ethernet services to MSTP instances (MSTIs):

- 1 Select **Ethernet > General Configuration**. The Ethernet General Configuration page opens ([Figure 198](#)).
- 2 In the Instance per Service Mapping table, select the Service ID of the service you want to map.
- 3 Click **Edit**. The Instance per Service Mapping – Edit page opens.

Figure 262 Instance Per Service Mapping – Edit Page

The screenshot shows a window titled "Ethernet General Configuration" with a sub-header "Instance per Service mapping - Edit". It contains two input fields: "Service ID" with the value "1" and a range "(1..4095)", and "Instance ID" with the value "10" and a range "(0..4095)". Below these fields are three buttons: "Apply", "Refresh", and "Close".

- 4 In the **Instance ID** field, enter a number between 0 and 16, or 4095. A service mapped to MSTI 4095 is never blocked by any protocol.
- 5 Click **Apply**.

By default, all Ethernet services are mapped to MSTI 0, which represents the CIST (Common Instance Spanning Tree).

Configuring the MSTP Bridge Parameters

This section includes:


- [Enabling MSTP and Configuring the MSTP Bridge General Attributes](#)
- [Viewing and Configuring the MSTP Bridge Configuration ID](#)
- [Viewing and Configuring the MSTP Bridge Spanning Tree](#)
- [Viewing and Configuring the MSTP Bridge CIST Parameters](#)
- [Viewing and Configuring the MSTP Bridge MSTI Parameters](#)
- [Viewing the MSTP VLAN Parameters](#)

Enabling MSTP and Configuring the MSTP Bridge General Attributes

To configure the MSTP bridge general attributes:

- 1 Select **Ethernet > Protocols > MSTP > Bridge > General Attributes**. The MSTP Bridge General Attributes page opens.

Figure 263 MSTP Bridge General Attributes Page



- 2 In the **MSTP Enable** field, select **True** to enable MSTP on the unit. To disable MSTP, select **False**.
 - Enabling MSTP starts the protocol and sets all ports in all MSTP instances to Blocking state. Convergence upon enabling the protocol generally takes less than two seconds.
 - Disabling MSTP stops the MSTP protocol from running and sets all ports in all MSTP instances to Forwarding state.
- 3 In the **Number of Instances (excluding CIST)** field, select the number of Multiple Spanning Tree instances (MSTIs). Possible values are 1-16. This number does not include the Common and Internal Spanning Tree (CIST).

**Note**

Changing the Number of Instances causes the MSTP stack to reset.

- 4 In the **MSTP BPDU Destination MAC** field, select the destination MAC address of BPDUs generated in the unit. Options are:
 - **Customer** – The destination MAC address of BPDUs is 0x0180-C200-0000. Provider BPDUs are either tunneled or discarded.
 - **Provider** – The destination MAC address of BPDUs is 0x0180-C200-0008. Customer BPDUs are either tunneled or discarded.
- 5 In the **MSTP SD Handling** field, select how MSTP handles Signal Degrade (SD) failures. Options are:
 - **Ignored** – Signal Degrade (SD) failures are ignored in MSTP.
 - **Same as SF** – SD failures trigger a topology change.

**Note**

SD handling is planned for future release.

- 6 Click **Apply**.


To reset the MSTP stack, click **Reset Protocol**.

Viewing and Configuring the MSTP Bridge Configuration ID

To configure the Configuration Name and Revision Level:

- 1 Select **Ethernet > Protocols > MSTP > Bridge > Configuration ID**. The MSTP Bridge Configuration ID page opens.

Figure 264 MSTP Bridge Configuration ID Page



- 2 Modify the configurable parameters.
- 3 Click **Apply**.

Table 76 lists and describes the parameters in the MSTP Bridge Configuration ID page.

Table 76 MSTP Bridge Configuration ID Parameters


Parameter	Definition
MSTP Configuration ID Format Selector	Read-only. Indicates the format specified in 802.1Q.
MSTP Configuration Name	Enter a valid configuration name. Note: Changing the Configuration Name when MSTP is enabled causes the MSTP stack to reset.
MSTP Configuration Digest	Read-only. Displays the MSTP Configuration Digest.
MSTP Revision Level	Enter a valid MSTP revision level. Note: Changing the Revision Level when MSTP is enabled causes the MSTP stack to reset.

Viewing and Configuring the MSTP Bridge Spanning Tree

To configure the bridge-level spanning tree parameters:

- 1 Select **Ethernet > Protocols > MSTP > Bridge > Spanning Tree**. The MSTP Bridge Spanning Tree page opens.

Figure 265 MSTP Bridge Spanning Tree Page



- 2 Modify the configurable parameters, described in [Table 78](#).
- 3 Click **Apply**.

[Table 77](#) lists and describes the status parameters in the MSTP Bridge Spanning Tree page.

Table 77 MSTP Bridge Spanning Tree Status Parameters

Parameter	Definition
STP Time Since Last TC	The time that has elapsed (in cs) since the last time the bridge entity detected a topology change.
STP Number of Topology Changes	The total number of topology changes that have been detected by this bridge since the management entity was last reset or initialized. Note: Discontinuities in the value of this counter can occur upon reinitialization of the management system.
STP Designated Root	The Bridge ID of the spanning tree root, as determined by MSTP in this node. This value is used as the Root ID in all configuration BPDUs originated by this node.

Parameter	Definition
STP Root Cost	The cost of the path to the root as seen from this bridge.
STP Root Port	The port number of the port that offers the lowest cost path from this bridge to the external root bridge
STP Max Age	<p>The maximum age (in cs) of MSTP information learned from the network on any port before the information is discarded.</p> <p>Note: This field displays the value actually being used by the bridge, in contrast to the STP Bridge Max Age parameter described below, which is user-configurable and which represents the value that this and all other bridges use if and when this bridge becomes the root.</p>
STP Forward Delay	<p>The speed at which ports change their spanning state when moving towards the Forwarding state. This value determines how long the port stays in Listening state and Learning state. This value is also used when a topology change has been detected and is underway for purposes of aging all dynamic entries in the filtering database.</p> <p>Note: This field displays the value actually being used by the bridge, in contrast to the STP Bridge Forward Delay parameter described below, which is user-configurable and which represents the value that this and all other bridges use if and when this bridge becomes the root.</p>
STP Version	The STP version the bridge is currently running (MSTP).

Table 78 MSTP Bridge Spanning Tree Configuration Parameters

Parameter	Definition
STP Priority	Select a value as the writeable portion of the Bridge ID. This value constitutes the first two octets of the Bridge ID. Possible values are 0-61440, in steps of 4096
STP Hold Time	Select a value (in cs) as the interval length during which no more than two configuration bridge PDUs will be transmitted by this node. Possible values are 10-100.
STP Bridge Max Age	Select a value (in cs) that all bridges will use, when this bridge is the root, as the maximum age of MSTP information learned from the network on any port before the information is discarded. Options are 600-4000 cs.
STP Bridge Forward Delay	Select a value (in cs) that all bridges will use, when this bridge is the root, as the speed at which ports change their spanning state when moving towards the Forwarding state. This value determines how long the port stays in Listening state and Learning state. This value is also used when a topology change has been detected and is underway for purposes of aging all dynamic entries in the filtering database. Options are 400-3000 cs.

Parameter	Definition
STP Bridge Hello Time	Select the value (in cs) that all bridges will use, when this bridge is the root, as the Hello Time. The Hello Time determines how often the switch broadcasts its hello message to other switches, and is the same for all MSTIs. Options are 100-1000 cs.

Viewing and Configuring the MSTP Bridge CIST Parameters

To configure the maximum hops parameter for the Common and Internal Spanning Tree (CIST) and view CIST status information:

- 1 Select **Ethernet > Protocols > MSTP > Bridge > CIST**. The MSTP Bridge CIST page opens.

Figure 266 MSTP Bridge CIST Page

Logout Admin Connection

Filter

Main View

- Platform
- Faults
- TDM
- Radio
- Ethernet
 - General Configuration
 - Services
 - Interfaces
 - PM & Statistics
 - QOS
 - Protocols
 - G.8032
 - MSTP
 - Bridge
 - General Attributes
 - Configuration ID
 - Spanning Tree
 - CIST**
 - MSTI
 - VLAN
 - Port
 - LLDP
 - SOAM
- Cascading
- Sync

Microwave radio: MSTP Bridge CIST

MSTP Bridge CIST - Status parameters

CIST Bridge Identifier

CIST Topology Change in progress

CIST Regional Root ID

CIST Path Cost

MSTP Bridge CIST - Configuration parameters

CIST Max Hops

- In the **CIST Max Hops** field, select the value that all bridges will use, when this bridge is the root, as the maximum number of hops allowed for a BPDU within a region before it is discarded. Options are 6-40.
- Click **Apply**.

[Table 79](#) lists and describes the status parameters in the MSTP Bridge CIST page.

Table 79 MSTP Bridge CIST Status Parameters


Parameter	Definition
CIST Bridge Identifier	The Bridge ID of the CIST.
CIST Topology Change in Progress	Indicates whether a topology change is currently in progress for any port that is part of the CIST.
CIST Regional Root ID	The Bridge ID of the current CIST regional root.
CIST Path Cost	The CIST path cost from the transmitting bridge to the CIST regional root. If the transmitting bridge is the CIST regional root, the value of this parameter may be 0.

Viewing and Configuring the MSTP Bridge MSTI Parameters

To view the parameters of each MSTI in the system, and to configure the MSTI bridge priority for each MSTI:


- 1 Select **Ethernet > Protocols > MSTP > Bridge > MSTI**. The MSTP Bridge MSTI page opens.

Figure 267 MSTP Bridge MSTI Page



- 2 To view all the bridge parameters of an MSTI and/or configure its bridge priority, select the MSTI and click **Edit**.

Figure 268 MSTP Bridge MSTI – Edit Page



- 3 To view all the bridge parameters of an MSTI and/or configure its bridge priority, select the MSTI and click **Edit**.
- 4 In the **MSTI Bridge Priority** field, enter the MSTI writeable portion of the Bridge ID. Possible values are 0-61440, in steps of 4096.
- 5 Click **Apply**, then **Close**.

Table 80 lists and describes the status parameters in the MSTP Bridge MSTI page.

Table 80 MSTP Bridge MSTI Status Parameters

Parameter	Definition
MSTI Instance ID	The MSTI ID.
MSTI Bridge Identifier	The Bridge ID for the MSTI.
MSTI Designated Root	The Bridge ID of the root bridge for the MSTI.
MSTI Root Cost	The path cost from the transmitting bridge to the root bridge for the MSTI.
MSTI Root Port	The root port for the MSTI.
MSTI Number of Topology Changes	The number of topology changes that the bridge has detected in the MSTI since the last time the management entity was reset or initialized.
MSTI Topology Change in Progress	Indicates whether a topology change is currently in progress on any port in the MSTI.

Parameter	Definition
MSTI Time Since Last TC	The number of centi-seconds that have elapsed since the last time the bridge identified a topology change for a port in the MSTI.

Viewing the MSTP VLAN Parameters

Each Ethernet service is mapped to an MSTI. By default, all services (VLAN ID) are assigned to MSTI 0 (CIST). See [Mapping Ethernet Services to MSTP instances \(MSTIs\)](#).



Note

A service mapped to MSTI 4095 is never blocked by any protocol.

To view the VLAN ID to MSTI mapping table:

- 1 Select **Ethernet > Protocols > MSTP > Bridge > VLAN**. The MSTP Bridge VLAN page opens.

Figure 269 MSTP Bridge VLAN Page

Microwave radio: MSTP Bridge VLAN

Show VLAN MSTI ID: ▼

MSTP Vlan (services) association to instances

VLAN ID	VLAN MSTI ID
1	10
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0
13	0
14	0
15	0
16	0
17	0
18	0
19	0
20	0
21	0
22	0

Configuring the MSTP Port Parameters

This section includes:

- [Viewing and Configuring the MSTP Port Spanning Tree](#)
- [Viewing and Configuring the MSTP Port CIST Parameters](#)
- [Viewing and Configuring the MSTP Port MSTI Parameters](#)
- [Viewing and Resetting the BPDU Counters](#)

Viewing and Configuring the MSTP Port Spanning Tree

To view the port-level spanning tree parameters and configure the STP port priority:

- 1 Select **Ethernet > Protocols > MSTP > Port > Spanning Tree**. The MSTP Port Spanning Tree page opens.

Figure 270 MSTP Port Spanning Tree Page

Microwave radio: MSTP Port Spanning Tree


MSTP 802.1 inherited attributes per port

STP Interface Location	STP Port Priority	STP Port State	STP Port Designated Cost	STP Port Designated Bridge
Ethernet: Slot 1, port 1	128	Blocking	20000	80:00:00:0A:25:40:1F:8C
Ethernet: Slot 1, port 2	128	Blocking	20000	80:00:00:0A:25:40:1F:8C
Ethernet: Slot 1, port 3	128	Blocking	200000	80:00:00:0A:25:40:1F:8C
Ethernet: Slot 1, port 4	128	Blocking	200000	80:00:00:0A:25:40:1F:8C
Ethernet: Slot 1, port 5	128	Blocking	20000	80:00:00:0A:25:40:1F:8C
Ethernet: Slot 1, port 6	128	Blocking	20000	80:00:00:0A:25:40:1F:8C
TDM: Slot 1, port 1	128	Blocking	20000	80:00:00:0A:25:40:1F:8C
Radio Protection: Group #1	128	Blocking	20000	80:00:00:0A:25:40:1F:8C

Edit Refresh

- 2 Select an interface and click **Edit**. The MSTP Port Spanning Tree – Edit page opens.

Figure 271 MSTP Port Spanning Tree – Edit Page



- 3 In the **STP Port Priority** field, select the CIST port priority of the interface. You can select values from 0-240, in multiples of 16.
- 4 Click **Apply**, then **Close**.

[Table 81](#) lists and describes the status parameters in the MSTP Port Spanning Tree page.

Table 81 MSTP Port Spanning Tree Status Parameters

Parameter	Definition
STP Interface Location	The slot number and port number of the port.
STP Port State	The port's current state, as defined by application of STP. The port's state controls the action the port takes upon receipt of a frame. Possible values are: <ul style="list-style-type: none"> • Forwarding – The port sends and receives traffic normally. • Blocking – The port does not send or receive traffic, but does receive BPDUs. • Learning – The port receives traffic but does not forward the traffic. The port learns the source MAC addresses of incoming frames. • Listening – The port monitors BPDUs, but does not forward traffic and does not learn the source MAC addresses of incoming frames. • Disabled – The port is disabled (not by MSTP).
STP Port Designated Cost	The CIST Path Cost of the segment connected to this port. This value is compared to the root path cost in received BPDUs.
STP Port Designated Bridge	The CIST Bridge ID of the bridge that this port considers to be the designated bridge for this port's segment.

Viewing and Configuring the MSTP Port CIST Parameters

To view and configure CIST port parameters:

- 1 Select **Ethernet > Protocols > MSTP > Port > CIST**. The MSTP Port CIST page opens.

Figure 272 MSTP Port CIST Page

Microwave radio: MSTP Port CIST

MSTP CIST attributes per port

CIST Port Interface Location	CIST Port Admin Path Cost	CIST Port Designated Root	CIST Port Edge Admin	CIST Port Edge Oper State	CIST Port Role	CIST Port CIST Regional Root ID	CIST Port CIST Path Cost	CIST Port Hello Time	CIST Port Protocol Migration	CIST Port MAC enabled	CIST Port MAC Oper State	CIST Port uptime
Ethernet: Slot 1, port 1	20000	80:00:00:0A:25:40:1F:8C	False	False	Disabled	80:00:00:0A:25:40:1F:8C	20000	2	False	Automatic	True	0 second
Ethernet: Slot 1, port 2	20000	80:00:00:0A:25:40:1F:8C	False	False	Disabled	80:00:00:0A:25:40:1F:8C	20000	2	False	Automatic	True	0 second
Ethernet: Slot 1, port 3	20000	80:00:00:0A:25:40:1F:8C	False	False	Disabled	80:00:00:0A:25:40:1F:8C	20000	2	False	Automatic	True	0 second
Ethernet: Slot 1, port 4	20000	80:00:00:0A:25:40:1F:8C	False	False	Disabled	80:00:00:0A:25:40:1F:8C	20000	2	False	Automatic	True	0 second
Ethernet: Slot 1, port 5	20000	80:00:00:0A:25:40:1F:8C	False	False	Disabled	80:00:00:0A:25:40:1F:8C	20000	2	False	Automatic	True	0 second
Ethernet: Slot 1, port 6	20000	80:00:00:0A:25:40:1F:8C	False	False	Disabled	80:00:00:0A:25:40:1F:8C	20000	2	False	Automatic	True	0 second
TDM: Slot 1, port 1	20000	80:00:00:0A:25:40:1F:8C	False	False	Disabled	80:00:00:0A:25:40:1F:8C	20000	2	False	Automatic	True	0 second
Radio Protection: Group #1	20000	80:00:00:0A:25:40:1F:8C	False	False	Disabled	80:00:00:0A:25:40:1F:8C	20000	2	False	Automatic	True	0 second

- 2 Select an interface and click **Edit**. The MSTP Port CIST – Edit page opens.

Figure 273 MSTP Port CIST – Edit Page

MSTP Port CIST

MSTP Port CIST - Status parameters

CIST Port Interface Location: Ethernet: Slot 1, port 1

CIST Port Designated Root: 80:00:00:0A:25:38:09:48

CIST Port Edge Oper State: False

CIST Port Role: Disabled

CIST Port CIST Regional Root ID: 80:00:00:0A:25:38:09:48

CIST Port CIST Path Cost: 20000

CIST Port Hello Time: 2

CIST Port Protocol Migration: False

CIST Port MAC Oper State: True

CIST Port uptime: 0 second

MSTP Port CIST - Configuration parameters

CIST Port Admin Path Cost: 20000 (1..200000000)

CIST Port Edge Admin: False

CIST Port MAC enabled: Automatic

Apply Refresh Close

- 3 In the **CIST Port Admin Path Cost** field, enter an assigned value for the contribution of this port to the path cost of paths towards the spanning tree root.

**Note**

Changing the value of this parameter is considered to be a topology change by the MSTP mechanism.

- 4 In the **CIST Port Edge Admin** field, select the port's administrative edge port parameter, for the CIST.
- 5 In the **CIST MAC enabled** field, select the port's MAC Enabled parameter. A value of **True** indicates that administratively, the MAC is set as if it were connected to a point-to-point LAN. Options are:
 - **Force True** – The MAC is treated as if it is connected to a point-to-point LAN, regardless of any indications to the contrary that are generated by the MAC entity.
 - **Force False** – The MAC is treated as if it is connected to a non-point-to-point LAN, regardless of any indications to the contrary that are generated by the MAC entity.
 - **Automatic** – The MAC Enabled parameter is set to True if the MAC is connected to a point-to-point or full-duplex LAN. The MAC Enabled parameter is set to False if the MAC is connected to a non-point-to-point and half-duplex LAN.
- 6 Click **Apply**, then **Close**.

[Table 82](#) lists and describes the status parameters in the MSTP Port Spanning Tree page.

Table 82 MSTP Port CIST Status Parameters

Parameter	Definition
CIST Port Interface Location	The slot number and port number of the port.
CIST Port Designated Root	The CIST Regional Root ID component of the port's Port Priority vector for the CIST
CIST Port Edge Oper State	<p>Indicates whether or not the port is operating as an Edge port. Possible values are:</p> <ul style="list-style-type: none"> • True – The port is operating as an Edge port, which means it does not process the BPDUs that it receives. • False – The port is operating as a non-Edge port, which means it processes the BPDUs that it receives. <p>If CIST Port Edge Admin is set to True, the system automatically determines its operational Edge port state.</p>

Parameter	Definition
CIST Port Role	<p>The port's current role in the CIST.</p> <p>Transient port roles may be:</p> <ul style="list-style-type: none"> • Blocking – The port does not send or receive traffic, but does receive BPDUs. • Learning – The port receives traffic but does not forward the traffic. The port learns the source MAC addresses of incoming frames. • Listening – The port monitors BPDUs, but does not forward traffic and does not learn the source MAC addresses of incoming frames. • Final port roles may be: • Disabled – The port is in Operational - Down state and is not included in the MSTP calculation. • Designated – The port is in Operational - Up state and has been designated to forward traffic. • Root – The port is forwarding traffic towards the root bridge. • Alternate – The port is not forwarding traffic (blocked) but can become a Designated port after MSTP calculation.
CIST Port CIST Regional Route ID	The Bridge ID of the current CIST Regional Root.
CIST Port CIST Path Cost	The CIST path cost from the transmitting bridge to the CIST regional root. If the transmitting bridge is the CIST regional root, the value of this parameter will be 0.
CIST Port Hello Time	The port's Hello Time timer parameter value, for the CIST (in cs).
CIST Port Protocol Migration	<p>The current value of the mcheck variable for the port.</p> <p>Note: Migration support is planned for future release.</p>
CIST Port MAC Oper State	The current state of the port's MAC operational parameter. True indicates the MAC is operational.
CIST Port Uptime	The number of seconds that have elapsed since the port was last reset or initialized.

Viewing and Configuring the MSTP Port MSTI Parameters

To view and configure MSTI port parameters:

- 1 Select **Ethernet > Protocols > MSTP > Port > MSTI**. The MSTP Port MSTI page opens.

Figure 274 MSTP Port MSTI Page

Microwave radio: MSTP Port MSTI

Show MSTI Port MSTI ID: All

MSTP attributes per port per instance

MSTI Port MSTI ID	MSTI Port Interface Location	MSTI Port State	MSTI Port Priority	MSTI Port Path Cost	MSTI Port Designated Root	MSTI Port Designated Cost	MSTI Port Designated Bridge	MSTI Port Role	MSTI Port Uptime
1	Ethernet: Slot 1, port 1	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
1	Ethernet: Slot 1, port 2	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
1	Ethernet: Slot 1, port 3	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	200000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
1	Ethernet: Slot 1, port 4	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	200000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
1	Ethernet: Slot 1, port 5	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
1	Ethernet: Slot 1, port 6	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
1	TDM: Slot 1, port 1	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
1	Radio Protection: Group #1	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
2	Ethernet: Slot 1, port 1	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
2	Ethernet: Slot 1, port 2	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
2	Ethernet: Slot 1, port 3	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	200000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
2	Ethernet: Slot 1, port 4	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	200000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
2	Ethernet: Slot 1, port 5	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
2	Ethernet: Slot 1, port 6	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
2	TDM: Slot 1, port 1	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
2	Radio Protection: Group #1	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
3	Ethernet: Slot 1, port 1	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
3	Ethernet: Slot 1, port 2	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	20000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
3	Ethernet: Slot 1, port 3	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	200000	80:00:00:0A:25:40:1F:8C	Disabled	0 second
3	Ethernet: Slot 1, port 4	Blocking	128	20000	80:00:00:0A:25:40:1F:8C	200000	80:00:00:0A:25:40:1F:8C	Disabled	0 second

- To view the parameters for a specific MSTI-port combination in a separate window and modify several of the parameters, select the row location with the MSTI-port combination you want to view and/or modify and click **Edit**. The MSTP Port MSTI – Edit page opens.

Figure 275 MSTP Port MSTI – Edit Page

MSTP Port MSTI

MSTP Port MSTI - Status parameters

MSTI Port MSTI ID: 1

MSTI Port Interface Location: Ethernet: Slot 1, port 1

MSTI Port State: Blocking

MSTI Port Designated Root: 80:00:00:0A:25:38:09:48

MSTI Port Designated Cost: 20000

MSTI Port Designated Bridge: 80:00:00:0A:25:38:09:48

MSTI Port Role: Disabled

MSTI Port Uptime: 0 second

MSTP Port MSTI - Configuration parameters

MSTI Port Priority: 128

MSTI Port Path Cost: 20000 (1..200000000)

Apply Refresh Close

- In the **MSTI Port Priority** field, select the port's Priority parameter value for the MSTI, i.e., the priority field for the Port ID for the MSTI. You can select values from 0-240, in multiples of 16.

**Note**

Changing the value of this parameter is considered to be a topology change by the MSTP mechanism.

- 4 In the **MSTI Port Path Cost** field, select the port's Path Cost parameter value for the MSTI.

**Note**

Changing the value of this parameter may cause re-initialization of the MSTI for which the parameter is changed. No other MSTI is affected.

- 5 Click **Apply**, then **Close**.

[Table 83](#) lists and describes the status parameters in the MSTP MSTI Tree page.

Table 83 MSTP Port MSTI Status Parameters

Parameter	Definition
MSTI Port MSTI ID	The MSTI ID.
MSTI Port Interface Location	The slot number and port number of the port.
MSTI Port State	The port's current state for the MSTI. Possible values are: <ul style="list-style-type: none"> • Forwarding – The port sends and receives traffic normally. • Blocking – The port does not send or receive traffic, but does receive BPDUs. • Learning – The port receives traffic but does not forward the traffic. The port learns the source MAC addresses of incoming frames. • Listening – The port monitors BPDUs, but does not forward traffic and does not learn the source MAC addresses of incoming frames. • Disabled – The port is disabled (not by MSTP).
MSTI Port Designated Root	The Regional Root ID component of the port's Port Priority vector for the MSTI.
MSTI Port Designated Cost	The Internal Root Path Cost component of the port's MSTI port priority vector, for the MSTI.
MSTI Port Designated Bridge	The Designated Bridge ID component of the port's MSTI port priority vector.


Parameter	Definition
MSTI Port Role	<p>The port's current role in the MSTI.</p> <p>Transient port roles may be:</p> <ul style="list-style-type: none"> • Blocking – The port does not send or receive traffic, but does receive BPDUs. • Learning – The port receives traffic but does not forward the traffic. The port learns the source MAC addresses of incoming frames. • Listening – The port monitors BPDUs, but does not forward traffic and does not learn the source MAC addresses of incoming frames. • Final port roles may be: • Disabled – The port is in Operational - Down state and is not included in the MSTP calculation. • Designated – The port is in Operational - Up state and has been designated to forward traffic. • Root – The port is forwarding traffic towards the root bridge. • Alternate – The port is not forwarding traffic (blocked) but can become a Designated port after MSTP calculation. • Master – The port is forwarding traffic towards the CIST root bridge.
MSTI Port Uptime	<p>The port's uptime parameter value for the MSTI. This is the number of seconds that have elapsed since the port was last reset or initialized.</p>

Viewing and Resetting the BPDU Counters

To view and reset the BPDU counters:

- 1 Select **Ethernet > Protocols > MSTP > Port > BPDU Counters**. The MSTP Port BPDU Counters page opens.

Figure 276 MSTP Port BDPU Counters Page



- To reset the counters, click **Reset Counters**.
- To display the counters for a specific interface in a separate page, select the interface and click **View**.

Table 84 describes the available MSTP BDPU counters.

Table 84 MSTP BDPU Counters

Parameter	Definition
Interface Location	The location of the port.
Received TCN	The number of Topology Change Notifications (TCNs) received since the last counter reset.
Received Configuration BDPU	The number of configuration BPDUs received since the last counter reset.
Received RST BDPU	The number of Rapid Spanning Tree (RST) BPDUs received since the last counter reset.
Received MST BDPU	The number of Multiple Spanning Tree (MST) BPDUs received since the last counter reset.
Transmitted TCN BDPU	The number of Topology Change Notifications (TCNs) transmitted since the last counter reset.
Transmitted Configuration BDPU	The number of configuration BPDUs transmitted since the last counter reset.
Transmitted RST BDPU	The number of Rapid Spanning Tree (RST) BPDUs transmitted since the last counter reset.
Transmitted MST BDPU	The number of Multiple Spanning Tree (MST) BPDUs transmitted since the last counter reset.

Configuring LLDP

This section includes:

- [LLDP Overview](#)
- [Displaying Peer Status](#)
- [Configuring the General LLDP Parameters](#)
- [Configuring the LLDP Port Parameters](#)
- [Displaying the Unit's Management Parameters](#)
- [Displaying Peer Unit's Management Parameters](#)
- [Displaying the Local Unit's Parameters](#)
- [Displaying LLDP Statistics](#)

LLDP Overview

Link Layer Discovery Protocol (LLDP) is a vendor-neutral layer 2 protocol that can be used by a network element attached to a specific LAN segment to advertise its identity and capabilities and to receive identity and capacity information from physically adjacent layer 2 peers. LLDP is a part of the IEEE 802.1AB – 2005 standard that enables automatic network connectivity discovery by means of a port identity information exchange between each port and its peer. Each port periodically sends and also expects to receive frames called Link Layer Discovery Protocol Data Units (LLDPDU). LLDPDUs contain information in TLV format about port identity, such as MAC address and IP address.

LLDP is used to send notifications to the NMS, based on data of the local unit and data gathered from peer systems. These notifications enable the NMS to build an accurate network topology.

Displaying Peer Status

To display a summary of the important LLDP management information regarding the unit's nearest neighbor (peer):

1. Select **Ethernet > Protocols > LLDP > Remote Management**. The LLDP Remote Management page opens.

Figure 277 LLDP Remote System Management Page




Table 85 describes the LLDP remote system management parameters. These parameters are read-only.

Table 85 LLDP Remote System Management Parameters

Parameter	Definition
Local Interface Location	The location of the local interface.
Management Address	The octet string used to identify the management address component associated with the remote system.
Address Sub Type	The type of management address identifier encoding used in the associated LLDP Agent Remote Management Address.
Time Mark	The time the entry was created.

Configuring the General LLDP Parameters

This section explains how to define the general LLDP parameters for the unit. For instructions on defining port-specific parameters, see [Configuring the LLDP Port Parameters](#).




Note

The management IP address advertised by the local element depends on the IP protocol (IPv4 or IPv6) configured for the unit. See [Defining the IP Protocol Version for Initiating Communications](#).

To display and configure the general LLDP parameters for the unit:

1. Select **Ethernet > Protocols > LLDP > Advanced > Configuration > Parameters**. The LLDP Configuration Parameters page opens.

Figure 278 LLDP Configuration Parameters Page



2. Modify the configurable parameters, described in *Table 87*.
3. Click **Apply**.

[Table 86](#) lists and describes the status parameters in the LLDP Configuration Parameters page.

Table 86 LLDP Read-Only Configuration Parameters

Parameter	Definition
Max TX Credit	Displays the maximum number of consecutive LLDPDUs that can be transmitted at any one time. In this release, the Max TX Credit is set at 5.
Fast TX Interval (Seconds)	Displays, in seconds, the interval at which LLDP frames are transmitted during fast transmission periods, such as when the unit detects a new peer. In this release, the Fast TX Interval is set at 1.
Fast TX	The initial value used to initialize the variable which determines the number of transmissions that are made during fast transmission periods. In this release, the Fast TX No. is set at 4.
Reinit Delay (Seconds)	Defines the minimum time, in seconds, the system waits after the LLDP Admin status becomes Disabled until it will process a request to reinitialize LLDP. For instructions on disabling or enabling LLDP on a port, see Configuring the LLDP Port Parameters . In this release, the Reinit Delay is set at 2.

Table 87 LLDP Configurable Configuration Parameters


Parameter	Definition
TX Interval (Seconds)	Defines the interval, in seconds, at which LLDP frames are transmitted. You can select a value from 5 to 32768. The default value is 30.
Notification Interval (Seconds)	Defines the interval, in seconds, between transmissions of LLDP notifications during normal transmission periods. You can select a value from 5 to 3600. The default value is 10.
Hold Multiplier	Defines the time-to-live (TTL) multiplier. The TTL determines the length of time LLDP frames are retained by the receiving device. The TTL is determined by multiplying the TX Interval by the Hold Multiplier. You can select a value from 2 to 10. The default value is 4.

Configuring the LLDP Port Parameters

To enable LLDP per port and determine how LLDP operates and which TLVs are sent for each port:


1. Select **Ethernet > Protocols > LLDP > Advanced > Configuration > Port Configuration**. The LLDP Port Configuration page opens.

Figure 279 LLDP Port Configuration Page



2. Select an interface and click **Edit**. The LLDP Port Configuration - Edit page opens.

Figure 280 LLDP Port Configuration - Edit Page



3. In the **Admin** field, select from the following options to define how the LLDP protocol operates for this port:
 - **TX Only** – LLDP agent transmits LLDP frames on this port but does not update information about its peer.
 - **RX Only** – LLDP agent receives but does not transmit LLDP frames on this port.
 - **TX and RX** – LLDP agent transmits and receives LLDP frames on this port (default value).
 - **Disabled** – LLDP agent does not transmit or receive LLDP frames on this port.
4. In the **Notification Enable** field, select from the following options to define, on a per agent basis, whether or not notifications from the agent to the NMS are enabled:
 - **True** – The agent sends a Topology Change trap to the NMS whenever the system information received from the peer changes.

- **False** – Notifications to the NMS are disabled (default value).

5. Click **Apply**, then **Close**.

Table 88 lists and describes the status parameters in the LLDP Port Configuration page.

Table 88 LLDP Port Configuration Status Parameters


Parameter	Definition
Interface Location	Identifies the port.
Destination Address	The destination address of the LLDP agent associated with this port.
TLV TX	Indicates which of the unit's capabilities is transmitted by the LLDP agent for the port: <ul style="list-style-type: none"> • PortDesc – The LLDP agent transmits Port Description TLVs. • SysName – The LLDP agent transmits System Name TLVs. • SysDesc – The LLDP agent transmits System Description TLVs. • SysCap – The LLDP agent transmits System Capabilities TLVs.

Displaying the Unit's Management Parameters

To display the unit's destination LLDP MAC address:

1. Select **Ethernet > Protocols > LLDP > Advanced > Configuration > Destination Address**. The LLDP Destination Address Table page opens.

Figure 281 LLDP Destination Address Table Page



To display the MAC address associated with the unit for purposes of LLDP transmissions:

1. Select **Ethernet > Protocols > LLDP > Advanced > Configuration > Management TLV**. The LLDP Management TLV Configuration page opens.

Figure 282 LLDP Management TLV Configuration Page




Table 89 lists and describes the status parameters in the LLDP Management TLV Configuration page.

Table 89 LLDP Management TLV Parameters

Parameter	Definition
Interface Location	Identifies the port.
Destination Address	Defines the MAC address associated with the port for purposes of LLDP transmissions.
Management Address	The unit's IP address.
Address Subtype	Defines the type of the management address identifier encoding used for the Management Address.
Tx Enable	Indicates whether the unit's Management Address is transmitted with LLDPDUs. In this release, the Management Address is always sent.

Displaying Peer Unit's Management Parameters

To display LLDP management information about the unit's nearest neighbor (peer):

1. Select **Ethernet > Protocols > LLDP > Advanced > Remote System > Management**. The LLDP Remote System Management page opens.

Figure 283 LLDP Remote System Management Page




Table 90 describes the LLDP remote system management parameters. These parameters are read-only.

Table 90 LLDP Remote System Management Parameters

Parameter	Definition
Local Interface Location	The location of the local interface.
Management Address	The octet string used to identify the management address component associated with the remote system.
Address Sub Type	The type of management address identifier encoding used in the associated LLDP Agent Remote Management Address.
Destination Address	The peer LLDP agent's destination MAC Address.
Remote ID	An arbitrary local integer value used by this agent to identify a particular connection instance, unique only for the indicated remote system.
Time Mark	The time the entry was created.

To display unit parameter information received via LLDP from the unit's nearest neighbor (peer):

1. Select **Ethernet > Protocols > LLDP > Advanced > Remote System > Remote Table**. The LLDP Remote System Table page opens.

Figure 284 LLDP Remote System Table Page




Table 91 describes the parameters in the LLDP Remote System Table page. These parameters are read-only.

Table 91 LLDP Remote System Table Parameters

Parameter	Definition
Local Interface Location	The location of the local interface.
Remote ID	An arbitrary local integer value used by this agent to identify a particular connection instance, unique only for the indicated peer.
Remote Chassis ID	An octet string used to identify the peer's chassis.
Chassis ID Subtype	The type of encoding used to identify the peer's chassis.
Remote Port	An octet string used to identify the port component associated with the remote system.
Port Sub type	The type of port identifier encoding used in the peer's Port ID.
Time Mark	The time the entry was created.

Displaying the Local Unit's Parameters

To display the unit parameters, as transmitted by the LLDP agents:

1. Select **Ethernet > Protocols > LLDP > Advanced > Local System > Parameters**. The LLDP Local System Parameters page opens.

Figure 285 LLDP Local System Parameters Page




Table 92 describes the parameters in the LLDP Local System Parameters page. These parameters are read-only.

Table 92 LLDP Local System Parameters

Parameter	Definition
System Name	The system name included in TLVs transmitted by the LLDP agent, as defined in the Name field of the Unit Parameters page. See Configuring Unit Parameters .
System Description	The system description included in TLVs transmitted by the LLDP agent, as defined in the Description field of the Unit Parameters page. See Configuring Unit Parameters .
Chassis ID	The MAC Address of the local unit's chassis.
Chassis ID SubType	The type of encoding used to identify the local unit's chassis. In this release, this parameter is always set to MAC Address.

Parameter	Definition
Capabilities Supported	<p>A bitmap value used to identify which system capabilities are supported on the local system, as included in TLVs transmitted by the LLDP agent.</p> <p>The bitmap is defined by the following parameters:</p> <ul style="list-style-type: none"> 0 – other 1 – repeater 2 – bridge 3 – wlanAccessPoint 4 – router 5 – telephone 6 – docsisCableDevice 7 – stationOnly 8 – cVLANComponent 9 – sVLANComponent 10 – twoPortMACRelay
Capabilities Enabled	<p>A bitmap value used to identify which system capabilities are enabled on the local system, as included in TLVs transmitted by the LLDP agent.</p> <p>The bitmap is defined by the following parameters:</p> <ul style="list-style-type: none"> 0 – other 1 – repeater 2 – bridge 3 – wlanAccessPoint 4 – router 5 – telephone 6 – docsisCableDevice 7 – stationOnly 8 – cVLANComponent 9 – sVLANComponent 10 – twoPortMACRelay

To display the unit’s port parameters, as transmitted by the LLDP agents:

1. Select **Ethernet > Protocols > LLDP > Advanced > Local System > Port**. The LLDP Local System Port page opens.

Figure 286 LLDP Local System Port Page




Table 93 describes the parameters in the LLDP Local System Port page. These parameters are read-only.


Table 93 LLDP Local System Port Parameters

Parameter	Definition
Interface Location	Identifies the port.
Port ID	The port's MAC address.
Port Sub Type	The type of encoding used to identify the port in LLDP transmissions. In this release, this parameter is always set to MAC Address.
Port Description	A description of the port.

To display the unit’s management parameters, as transmitted by the LLDP agents:

1. Select **Ethernet > Protocols > LLDP > Advanced > Local System > Management**. The LLDP Local System Management page opens.

Figure287 LLDP Local System Management Page



2. To display all the parameters, select a row and click **View**.

Figure 288 LLDP Local System Management – View Page




Table 94 describes the parameters in the LLDP Local System Management page. These parameters are read-only.

Table 94 LLDP Local System Management Parameters

Parameter	Definition
Management Address	The local unit's IP address.
Address Sub Type	The format of the local unit's IP Address.
Address Length	Reserved for future use.
Address Interface ID	Reserved for future use.
Address Interface Sub Type	Reserved for future use.
Address OID	Reserved for future use.

Displaying LLDP Statistics

To display statistics about changes reported via LLDP by the remote unit:

1. Select **Ethernet > Protocols > LLDP > Advanced > Statistic > General**. The LLDP Statistic page opens.

Figure 289 LLDP Statistic Page




Table 95 describes the statistics in the LLDP Statistic page.

Table 95 LLDP Statistics

Parameter	Definition
Last Change Time	The time of the most recent change in the remote unit, as reported via LLDP.
Inserts	The number of times the information from the remote system has changed.
Deletes	The number of times the information from the remote system has been deleted.
Drops	Reserved for future use.
Ageouts	The number of times the information from the remote system has been deleted from the local unit's database because the information's TTL has expired. The RX Ageouts counter in the Port RX page is similar to this counter, but is for specific ports rather than the entire unit.

To display statistics about LLDP transmissions and transmission errors:

1. Select **Ethernet > Protocols > LLDP > Advanced > Statistic > Port TX**. The LLDP Port TX Statistic page opens.

Figure 290 LLDP Port TX Statistic Page




Table 96 describes the statistics in the LLDP Port TX Statistic page.

Table 96 LLDP Port TX Statistics

Parameter	Definition
Interface Location	The index value used to identify the port in LLDP transmissions.
Destination Address	The LLDP MAC address associated with this entry.
Total Frames	The number of LLDP frames transmitted by the LLDP agent on this port to the destination MAC address.
Errored Length Frames	<p>The number of LLDPDU Length Errors recorded for this port and destination MAC address.</p> <p>If the set of TLVs that is selected in the LLDP local system MIB by network management would result in an LLDPDU that violates LLDPDU length restrictions, then the No. of Length Error statistic is incremented by 1, and an LLDPDU is sent containing the mandatory TLVs plus as many of the optional TLVs in the set as will fit in the remaining LLDPDU length.</p>

To display statistics about LLDP frames received by the unit:

1. Select **Ethernet > Protocols > LLDP > Advanced > Statistic > Port RX**. The LLDP Port TX Statistic page opens.

Figure 291 LLDP Port RX Statistic Page




Table 97 describes the statistics in the LLDP Port TX Statistic page.

Table 97 LLDP Port RX Statistics

Parameter	Definition
Interface Location	The index value used to identify the port in LLDP transmissions.
Destination Address	The LLDP MAC address associated with this entry.
Total Discarded	The number of LLDP frames received by the LLDP agent on this port, and then discarded for any reason. This counter can provide an indication that LLDP header formatting problems may exist with the local LLDP agent in the sending system or that LLDPDU validation problems may exist with the local LLDP agent in the receiving system.
Invalid Frames	The number of invalid LLDP frames received by the LLDP agent on this port while the agent is enabled.
Valid Frames	The number of valid LLDP frames received by the LLDP agent on this port.
Discarded TLVs	The number of LLDP TLVs discarded for any reason by the LLDP agent on this port.
Unrecognized TLVs	The number of LLDP TLVs received on the given port that are not recognized by LLDP agent.
Ageouts	<p>The number of age-outs that occurred on the port. An age-out is the number of times the complete set of information advertised by the remote system has been deleted from the unit's database because the information timeliness interval has expired.</p> <p>This counter is similar to the LLDP No. of Ageouts counter in the LLDP Statistic page, except that it is per port rather than for the entire unit.</p> <p>This counter is set to zero during agent initialization. This counter is incremented only once when the complete set of information is invalidated (aged out) from all related tables on a particular port. Partial ageing is not allowed.</p>

Chapter 9: TDM Services and Interfaces

This section includes:

- [TDM Overview](#)
- [Configuring the E1/DS1 Interface](#)
- [Configuring Native TDM Trails](#)
- [Configuring TDM Pseudowire Services](#)
- [Configuring Advanced Pseudowire Parameters](#)
- [Displaying TDM PMs](#)

Related topics:

- [Performing TDM Diagnostics](#)

TDM Overview

PTP 820G and PTP 820F provides integrated support for transportation of TDM services with an integrated E1/DS1 interface (optional).

Two types of TDM services are supported using the same hardware:

- Native TDM trails
- TDM Pseudowire services (enabling interoperability with third party packet/PW equipment)

PTP 820G and PTP 820F also offers hybrid Ethernet and TDM services. Hybrid services can utilize either Native TDM or pseudowire.

Hybrid Ethernet and TDM services can also be transported via cascading interfaces. This enables the creation of links among multiple units in a node for multi-carrier and multi-directional applications.

The PTP 820G and PTP 820F Web EMS provides convenient workflows for both native TDM trails and pseudowire services. These workflows guide you through the configuration process, step by step.

Configuring the E1/DS1 Interface



Note

By default, the TDM interfaces in a PTP 820G unit are set to operate according to the ETSI standard, in E1 mode. For instructions on configuring the system to operate according to the ANSI (FCC) standard (DS1), see [TDM Overview \(CLI\)](#).

You can configure the E1/DS1 interface in the E1/DS1 Interfaces page.

To configure the E1/DS1 interface:

- 1 Select **TDM > Interfaces > E1/DS1**. The E1/DS1 Interfaces page opens.

Figure 292 E1/DS1 Interfaces Page

Port number	Admin	Operational state	Timing mode	Absolute clock reference	Recovery clock source reference port	Line alarms	Loopback state	TDM signal line type	Line Coding	Signal Channelization	Idle code	Cable Length
1	Disable	Down	Loop	None	1	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
2	Disable	Down	Loop	None	2	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
3	Disable	Down	Loop	None	3	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
4	Disable	Down	Loop	None	4	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
5	Disable	Down	Loop	None	5	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
6	Disable	Down	Loop	None	6	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
7	Disable	Down	Loop	None	7	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
8	Disable	Down	Loop	None	8	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
9	Disable	Down	Loop	None	9	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
10	Disable	Down	Loop	None	10	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
11	Disable	Down	Loop	None	11	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
12	Disable	Down	Loop	None	12	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
13	Disable	Down	Loop	None	13	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
14	Disable	Down	Loop	None	14	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
15	Disable	Down	Loop	None	15	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft
16	Disable	Down	Loop	None	16	1	None	Unframed	HDB3-B8ZS	Disable	0	Fixed or 0-133ft

- 2 Select an interface and click **Edit**. The E1/DS1 Interfaces – Edit page opens.

Figure 293 E1/DS1 Interfaces – Edit Page

The screenshot shows a configuration window titled "E1/DS1 Interfaces". It is divided into two sections: "E1/DS1 Interfaces - Status parameters" and "E1/DS1 Interfaces - Configuration parameters".

Status parameters:

- Shelf slot ID: Slot 1: E1/DS1 1-16
- Port number: 1
- Operational state: Down
- Line alarms: 1
- Loopback state: None

Configuration parameters:

- Admin: Disable
- Timing mode: Loop
- Absolute clock reference: None
- Recovery clock source reference port: 1
- TDM signal line type: Unframed
- Line Coding: HDB3-B8ZS
- Signal Channelization: Disable
- Idle code: 0
- Cable Length: Fixed or 0-133ft

At the bottom of the configuration section are three buttons: "Apply", "Refresh", and "Close".

- 3 Configure the parameters described in *Table 98*.
- 4 Click **Apply**, then **Close**.

**Note**

[Table 99](#) lists and describes the non-configurable E1/DS1 Interface status parameters.

Table 98 E1/DS1 Interface Configuration Parameters

Parameter	Definition
Admin	Select Enable to enable the port or Disable to disable the port.
Timing Mode	Select the clock reference for the outgoing TDM signal from the port. Options are: <ul style="list-style-type: none"> • Loop – The output signal uses the clock of the incoming E1/DS1 lines. If you select Loop, you must select the clock source reference in the Recovery Clock Source Reference Port field. By default, each port will take itself as a reference. • Absolute – All ports are synchronized to a single common clock, which you select in the Absolute Clock Reference field. • Clock Recovery – Adaptive Clock Recovery. Clock information is recovered on the egress path. Extra information may be located in an RTP header that can be used to correct frequency offsets. <p>If you select Clock Recovery, you must select the clock source reference in the Recovery Clock Source Reference Port field.</p>
Absolute Clock Reference	If Timing Mode is set to Absolute , select the clock source reference for the port. Options are: <ul style="list-style-type: none"> • Front Panel - An external clock reference from a dedicated front panel clock interface. This can be: <ul style="list-style-type: none"> ○ An E1/DS1 line, or ○ A Digital 2.048MHz/1.544MHz input • System Reference Clock <p>If Timing Mode is set to Loop or Clock Recovery, select None.</p>
Recovery Clock Source Reference Port	If Timing Mode is set to Loop or Clock Recovery , select the clock source reference for the port. Options are 1-16. By default, each port will take itself as a reference. Select a different port only if more than 16 clock domains are being used. If Timing Mode is set to Absolute , this field must be set to 0.
TDM Signal Line Type	Select the line type of this port. Options are: <ul style="list-style-type: none"> • Unframed • E1 (reserved for future use) • E1-CRC (reserved for future use) • E1-MF (reserved for future use) • E1-MF-CRC (reserved for future use) • DS1-D4 (reserved for future use) • DS1-ESF (reserved for future use)

Parameter	Definition
Line Coding	Select the line coding for this port. Options are: <ul style="list-style-type: none"> • hdb3-b8zs – hdb3 coding for E1, b8zs coding for DS1. • AMI – Only relevant for DS1 ports.
Signal Channelization	Select Disable . Note: Channelization is only relevant for CESoP mode, which is planned for future release.
Idle Code	Enter the value to be transmitted on this port for unused time slots (0-255).
Cable Length	Reserved for future use.

Table 99 E1/DS1 Interface Parameters

Parameter	Definition
Shelf Slot ID	Slot 1.
Port Number	The physical port number of the port on the TDM card.
Operational State	Indicates whether the port is currently operational (Up) or non-operational (Down).
Line Alarms	The number of line-level PDH alarms currently present on the port.
Loopback State	The actual status of loopback on this port, as reported by the TDM card.

Configuring Native TDM Trails

This section includes:

- [Native TDM Trail Configuration Overview](#)
- [General Guidelines for Provisioning TDM Services](#)
- [Viewing TDM Trails](#)
- [Configuring the Revertive Timer](#)
- [Adding TDM Trails](#)
- [Editing TDM Trails](#)
- [Deleting TDM Trails](#)
- [Limitations on Available Endpoints](#)

Native TDM Trail Configuration Overview



Note


By default, the TDM interfaces in a PTP 820G or PTP 820F unit are set to operate according to the ETSI standard, in E1 mode. For instructions on configuring the system to operate according to the ANSI (FCC) standard (DS1), see [TDM Overview \(CLI\)](#).

The Web EMS provides a simple interface that guides you, step-by-step, through the trail configuration process.

To open the Native TDM Services page:

- 1 Select **TDM > Native TDM Services**. The Native TDM Services page opens.

Figure 294 Native TDM Services Page



The Native TDM Services page displays all TDM trails configured on the unit and provides a simple and efficient workflow for adding TDM trails. The following interfaces can be used as trail endpoints:

- TDM interfaces
- Radio interfaces
- Cascading interfaces

TDM endpoints can be E1/DS1s.



Note

In order use a LIC-T155 as an endpoint for a TDM trail, you must set the **Slot Admin State** field in the Chassis Configuration page to **Enable** and the **Admin Status** field in the **Interface Manager** page to **Up**. Otherwise, the LIC-T155 will not appear in the dropdown list. See *Enabling the Expansion Slots* and *Enabling the Interfaces (Interface Manager)*.

Radio endpoints can be selected from the radio interfaces, a Radio Protection Group, or a Multi-Carrier ABC Group. Cascading interfaces can be configured on ports GbE1/CS1 and GbE2/CS2. When operating in cascading mode, these interfaces can handle hybrid Ethernet and Native TDM traffic, enabling operators to create links among multiple PTP 820 units in a node for multi-directional applications based on hybrid Ethernet and Native or pseudowire TDM services. For instructions, see [Configuring RFU3/SFP5, RFU3/2.5GE5](#) as an Ethernet or RFU Interface (PTP 820F only)

On PTP 820F, the combo port labelled RFU3/SFP5 (SFP) and RFU3/2.5GE5 (RJ-45) can be configured as either an RFU interface (RFU3) or an Ethernet interface (Eth3). By default, this port is an RFU interface.



Figure: RFU3/SFP5 and RFU3/2.5GE5 Combo Port

To change the port's use from RFU to Ethernet or Ethernet to RFU:

- 1 Set the port's admin state to **Down** in the Interface Manager.
 - If the port is currently configured as an RFU port, it is listed as **Radio: Slot 1, Port 5** in the Interface Manager.
 - If the port is currently configured as an Ethernet port, it is listed as **Ethernet: Slot 1, Port 5** in the Interface Manager.

See Enabling the Interfaces (Interface Manager).
- 2 In the Radio Unit page, set the Admin status of **Radio Unit: Slot 1, Port 3** to **Down**.
- 3 If there are any service points attached to the port, remove them.
- 4 If the port is configured as a Sync source, delete the port as a Sync source.
- 5 If the port belongs to any interface groups, such as LAG, remove the port from the group.
- 6 Select **Platform > Interfaces > RFU/Ethernet**. The RFU/Ethernet Interface Configuration page opens.




Figure: RFU/Ethernet Interface Configuration Page

7 Select **Radio Unit: Slot 1, Port 3** and click **Edit**. The RFU/Ethernet Interface Configuration – Edit page opens.




Figure: RFU/Ethernet Interface Configuration – Edit Page

- 8 In the **Interface Type** field, select **RFU** or **Ethernet**.
- 9 Click **Apply**, then **Close**.
- 10 If you configured the port as an Ethernet interface, you must set the port’s admin state to **Up** in the Interface Manager. See *Enabling the Interfaces (Interface Manager)*. If you configured the port as an RFU interface, its admin state is **Up** automatically.

If you configured the port as an Ethernet interface, the port takes the following parameters:

- Port speed: 1 GE
- Media Type: RJ45
- Auto Negotiation: On

To change these parameters, go to the Physical Interfaces page. See *Configuring Ethernet Interfaces*.

Note: Both Eth5 and Eth6 can be configured to either 1 GE or 2.5 GE. The other PTP 820F Ethernet ports support 1 GE only.

If you configured the port as an RFU interface, make sure to set the Radio Unit parameters as necessary.

Configuring Cascading Interfaces (Optional).

**Note**

In order use a radio interface, a radio protection group, a Multi-Carrier ABC group, or a cascading interface as an endpoint for a TDM trail, you must configure either a management or a pipe service point on that interface or group. Otherwise, the interface or group will not appear in the dropdown list. See [Configuring Ethernet Service\(s\)](#).

General Guidelines for Provisioning TDM Services

When provisioning TDM trails, it is recommended to follow these guidelines:

- Each trail within the same local region should use a unique Trail ID. The Trail ID should also be unique along the path of each trail.
- For protected trails, the Trail ID of the protecting trail must be different from the Trail ID of the working trail.
- At one of the two endpoint devices, the **Local** parameter should be set to **1** while, at the far-end endpoint device, the **Local** parameter should be set to **2**.

Viewing TDM Trails

The Native TDM Services page ([Figure 294](#)) displays the TDM trails configured on the unit and their basic parameters.

[Table 100](#) lists and describes the parameters in the Native TDM Services page.

Table 100 Native TDM Service Parameters

Parameter	Definition
Trail ID	A unique ID for the trail.
Trail Description	A text description of the trail.
Interface #1: Slot/Group	Slot 1 or the group number of the first endpoint in the trail.
Interface #1: Port	The port number of the first endpoint in the trail.
Interface #1: VC	The VC classified to the first endpoint of the trail (1-256). This field is only relevant for radio and cascading endpoints.
Interface #2: Slot/Group	Slot 1 or the group number of the second endpoint in the trail.
Interface #2: Port	The port number of the second endpoint in the trail.
Interface #2: VC	The VC classified to the second endpoint of the trail (1-256). This field is only relevant for radio and cascading endpoints.
Protecting Interface: Slot/Group	For protected trails, displays Slot 1 or the group number of the protecting trail endpoint.
Protecting Interface: Port	For protected trails, the port number of the protecting trail endpoint.
Protecting Interface: VC	For protected trails, the VC classified to the protecting trail endpoint (1-256). This field is only relevant for radio and cascading endpoints.
Trail Status: Admin	The administrative status of the trail.
Trail Status: Operational	The operational status of the trail.

Configuring the Revertive Timer

1:1 TDM path protection can be configured to operate in revertive mode. In revertive mode, the system monitors the availability of the protected path at all times. After switchover to the protecting path, once the protected path is operational and available without any alarms, the system waits for the duration of the user-configured Wait to Restore (WTR) time and then, if the protected path remains operational and available, initiates a revertive protection switch. A single WTR time is configured for all the TDM trails in the system. However, trails with 1:1 path protection can be configured individually as revertive or non-revertive.



Note


TDM trails with 1:1 path protection that were configured using software versions prior to T7.9 are non-revertive.

The Revertive timer must be configured before creating a protecting TDM trail so that the configured WTR time will be in effect for this trail.

To set the WTR time for trails with revertive 1:1 path protection:

- 1 Underneath the Native TDM Services table, click **Timer Configuration**. The TDM Service Revertive Timer Configuration page opens.

Figure 295 TDM Service Revertive Timer Configuration Page



- 2 Enter the number, in seconds, for the WTR time. The default value is 10 seconds.
- 3 Click **Apply**, then **Close**.

Adding TDM Trails

To initiate the workflow for adding a TDM trail:

- 1 Select **TDM > Native TDM Services**. The Native TDM Services page opens ([Figure 294](#)).
- 2 Click **Create Service**. The Add Native TDM Service workflow begins. The workflow and options provided by the TDM Services Creation page depends on the selection you make in the **Slot/Group/Port** field. For detailed instructions per trail type, see:
 - o [Adding a Trail between a TDM Port or Protection Group and a Radio Port, a Radio Group, or a Cascading Interface](#)
 - o [Adding a Trail between Radio Ports, Radio Groups, or Cascading Interfaces](#)

You cannot add a TDM trail if any of the following conditions exist:

- There are no available TDM endpoints (E1/DS1s or VC12s).

- There are no available services:
 - There are no available Service IDs in the range reserved for TDM trails (801-928), or
 - The maximum number of trails (256) has already been configured on the PTP 820G or PTP 820F unit.

Adding a Trail between a TDM Port or Protection Group and a Radio Port, a Radio Group, or a Cascading Interface

- 1 In the Interface #1 screen of the TDM Services Creation page, configure the parameters of the trail's first endpoint.
- 2 In the **Slot/Group/Port** field, select a TDM interface, a radio interface or group, or a cascading interface.

Configuring a TDM Card or Group as an Endpoint

- i Select the E1/DS1 interface.

Figure 296 Native TDM Service Creation – Interface #1 E1/DS1



Note

Some interfaces may not appear in the **Slot/Group/Port** field. Refer to [Limitations on Available Endpoints](#) for the possible reasons an interface will not appear. If there are no available interfaces, a message appears that no endpoint can be selected.

- ii In the **E1/DS1** field, select an E1/DS1. This configures the first endpoint for the trail.

**Note**

Only E1/DS1s or VC12s that are not already assigned to a TDM trail appear in the selection box. Also, an E1/DS1 or VC12 will not appear in the selection box if the TDM card or group has already been assigned a service point with a classification and a slot and port or group number that match the classification that would automatically be assigned to the E1/DS1 or VC12 via the TDM Service Creation page.

- iii In the **Timing** field, select the synchronization mode for the endpoint. Options are:
- **Loop Timing** – The interface takes the timing from incoming signals.
 - **Recovered** – Clock information is recovered on the egress path. Extra information may be located in an RTP header that can be used to correct frequency offsets.
 - **System Reference** – The interface is synchronized to the system reference clock.
 - **Front Panel** – The interface is synchronized to an external clock reference from a dedicated front panel clock interface.

Configuring a Radio Card or Group or a Cascading Interface as an Endpoint

**Note**

In order to add a radio, radio group, or cascading interface as a trail endpoint, an MNG service point must be added to the interface or group in the pre-defined management service (Service ID 1025) or in a Pipe service. See [Configuring Service Points](#).

- iv In the Interface #1 screen of the TDM Services Creation page, configure the parameters of the trail's first endpoint.

Figure 297 Native TDM Service Creation – Interface #1 Radio

**Note**

Some interfaces may not appear in the **Slot/Group/Port** field. Refer to [Limitations on Available Endpoints](#) for the possible reasons an interface will not appear. If there are no available interfaces, a message appears that no endpoint can be selected.

- v In the **VC** field, select the VC you want to classify to the endpoint (1-512).
- 3 Click **Next**. The Interface #2 page opens. In the Interface #2 page, configure the parameters of the trail's second endpoint:

If the first endpoint is a TDM interface, select a radio interface, a Radio Protection group, a Multi-Carrier ABC group, or a cascading interface in the Interface #2 page.

If the first endpoint is a radio interface, a Radio Protection group, a Multi-Carrier ABC group, or a cascading interface, select a TDM interface in the Interface #2 page.

- 4 Follow the instructions in Step 2 to configure the second endpoint.
- 5 Click **Next**. The Trail Selection page opens.

Figure 298 Native TDM Service Creation – Trail Selection Page (Radio-TDM)

- 6 In the **Trail ID** field, select a Trail ID (1-512) to identify the trail. Only unused Trail ID values appear in the selection box. The default value is the lowest unused Trail ID.
- 7 Optionally, in the **Trail Description** field, enter text to describe the trail.
- 8 In the **Trail Protection** field, select one of the following:
 - o **Unprotected** - The trail will not have trail protection.
 - o **1:1 Protection (non-revertive)** – The trail will have 1:1 trail protection in which two separate network paths are defined for the trail. Each trail has the same TDM interface endpoints, but traffic flows to the destination via different radio or cascading interfaces. Bandwidth is utilized only on the active path, freeing up resources on the standby path.
When you click **Next**, you will be asked to configure an additional radio interface, Radio Protection group, Multi-Carrier ABC group, or cascading interface as the protecting interface.
 - o **1:1 Protection (revertive)** – The trail will have 1:1 trail protection, as described above, in revertive mode. See [Configuring Service Points](#).

- **1+1 Protection** – Used for networks in which the PTP 820G network elements are set up as a chain connected to third party networks at two different sites, where one end-point is located on a PTP 820G unit and the other end-point is located on third-party equipment supporting SNCP. The trail will have 1+1 trail protection in which two separate network paths are defined for the trail. Each trail has the same TDM interface endpoints, but traffic flows to the destination via different radio or cascading interfaces. Unlike 1:1 path protection, traffic flows through both paths simultaneously, thereby supporting SNCP in third party equipment at the other end of the link.
When you click **Next**, you will be asked to configure an additional radio interface, Radio Protection group, Multi-Carrier ABC group, or cascading interface as the protecting interface.
- **1+1 Dual Homing Network Edge** – Used for PTP 820G units located at the network edge in a 1+1 Protection configuration. Since the node itself is part of the protected or protecting path, the node itself is essentially unprotected and you do not need to configure a separate protecting path.
When you click **Next**, you will be asked to configure a Working Path ID.

**Note**


In a 1+1 Protection configuration, the third-party equipment usually detects problems in the link via E1/DS1 AIS signals. If the third party equipment does not support the ability to read E1/DS1 AIS signals, it must be configured to perform switchover upon receiving an UNEQUIPPED indication in the signal label bits in the overhead.

- 9 In the **Local** field, select 1 or 2. If you select 1, the **Local** field in the network element at the other side of the link must be configured as 2, and vice versa.
 - If you selected **Unprotected** in the **Trail Protection** field, click **Finish**. The Selection Summary page opens (Figure 301).
 - If you selected **1:1 Protection (revertive or non-revertive)** or **1+1 Protection** in the **Trail Protection** field, click **Next**. The Protecting Interface Selection page opens.

Figure 299 Native TDM Service Creation – Protecting Interface Selection Page

- If you selected **1+1 Dual Homing Network Edge** in the **Trail Protection** field, click **Next**. The Working Trail Selection page opens. Skip steps 10 and 11 and proceed to Step 12.

Figure 300 Native TDM Service Creation – Working Trail Selection Page



- 10 In the **Slot/Group/Port** field, select a radio interface, Radio Protection group, Multi-Carrier ABC group, or cascading interface to serve as the interface for the protecting trail.

**Note**

Some interfaces may not appear in the **Slot/Group/Port** field. Refer to [Limitations on Available Endpoints](#) for the possible reasons an interface will not appear. If there are no available interfaces, a message appears that no endpoint can be selected.

- 11 In the **VC** field, select the VC you want to classify to the endpoint of the protecting trail (1-512).
- 12 In the **Protecting Trail ID** or **Working Trail ID** field, select a Trail ID (1-512) to identify the protecting or working trail. Only unused Trail ID values appear in the selection box. The default value is the lowest unused Trail ID. All nodes in the protected configuration, both on the protected and the protecting path, must have the same **Protecting Trail ID** or **Working Trail ID**.
- 13 Click **Finish**. The Selection Summary page opens, displaying the parameters you have configured.

Figure 301 Native TDM Service Creation – Selection Summary Page (Radio-TDM)

Interface #1:
Slot 1 (Cascading: Slot 1, port 2), VC #1

Interface #2:
Slot 1 (E1/DS1 1-16), E1/DS1 #2
Timing: Recovered

Trail Selection:
Trail ID: 2
Trail Description: TJ-DH

Protecting interface Selection:
Slot 1 (Cascading: Slot 1, port 2), VC #2

Protecting Trail Selection:
Protecting Trail ID: 3

Press 'Submit' to configure the selected parameters.

<< Back Next >> Submit Close

- 14 To create the trail with the displayed parameters, click **Submit**. If you want to return to an earlier page and change the trail parameters, click **Back**.



Note

An invalid configuration error may occur in the event that another user utilized a resource that you selected, such as an interface or a Trail ID, between the time you selected the resource and the time you pressed **Submit**. If this occurs, you must go back and, if necessary, select alternative resources for the trail.

Adding a Trail between Radio Ports, Radio Groups, or Cascading Interfaces

Note: In order to add a radio, radio group, or cascading interface as a trail endpoint, an MNG service point must be added to the interface or group in the pre-defined management service (Service ID 1025) or in a Pipe service. See [Configuring Service Points](#).

- 1 In the Interface #1 screen of the TDM Services Creation page, configure the parameters of the trail's first endpoint.

Figure 302 Native TDM Service Creation – Interface #1 (Radio/Cascading)

Interface #1

Slot/Group/Port Radio Protection: Group 1 ▼

VC 1 ▼

<< Back Next >> Finish Close

- 2 In the **Slot/Group/Port** field, select a radio interface, Radio Protection group, Multi-Carrier ABC group, or cascading interface.

**Note**

Some interfaces may not appear in the **Slot/Group/Port** field. Refer to [Limitations on Available Endpoints](#) for the possible reasons an interface will not appear. If there are no available interfaces, a message appears that no endpoint can be selected.

- 3 In the **VC** field, select the VC you want to classify to the endpoint (1-512).
- 4 Click **Next**. The Interface #2 page opens. In the Interface #2, configure the parameters of the trail's second endpoint.

Figure 303 Native TDM Service Creation – Interface #2 (Radio/Cascading)


Interface #2

Slot/Group/Port Slot 1 (Cascading: Slot 1, port 2) ▼

VC 3 ▼


<< Back Next >> Finish Close

- 5 Follow the instructions in Steps 2-3 to configure the second endpoint.
- 6 Click **Next**. The Trail Selection page opens.

Figure 304 Native TDM Service Creation – Trail Selection Page (Radio/Cascading)

The screenshot shows a software window titled "Trail Selection". Inside the window, there is a section labeled "Trail Selection". Below this label, there is a "Trail ID" field with a dropdown menu showing the number "3". Below the "Trail ID" field is a "Trail Description" text input field. At the bottom of the window, there are four buttons: "<< Back", "Next >>", "Finish", and "Close".

- 7 In the **Trail ID** field, select a Trail ID (1-512) to identify the trail. Only unused Trail ID values appear in the selection box. The default value is the lowest unused Trail ID.
- 8 Optionally, in the **Trail Description** field, enter text to describe the trail.
- 9 Click **Finish**. The Selection Summary page opens, displaying the parameters you have configured.

Figure 305 Native TDM Service Creation – Selection Summary (Radio/Cascading)

Interface #1:
Radio Protection: Group 1, VC #1

Interface #2:
Slot 1 (Cascading: Slot 1, port 2), VC #4

Trail Selection:
Trail ID: 4
Trail Description:

Press 'Submit' to configure the selected parameters.

<< Back Next >> Submit Close

- 10 To create the trail with the displayed parameters, click **Submit**. If you want to return to an earlier page and change the trail parameters, click **Back**.

**Note**

An invalid configuration error may occur in the event that another user utilized a resource that you selected, such as an interface or a Trail ID, between the time you selected the resource and the time you pressed **Submit**. If this occurs, you must go back and, if necessary, select alternative resources for the trail.

Editing TDM Trails

To edit an existing trail:

- 1 Select the trail in the Native TDM Services page ([Figure 294](#)).
- 2 Click **Edit**. The Native TDM Services – Edit page opens.

Figure 306 Native TDM Services – Edit Page

Native TDM Services - Edit

Trail ID: 2

Trail Description: TJ-DH

Trail Protection: 1:1 Protection (revertive)

Revertive Countdown: 0

Local: 1

Remote: 2

Interface #1

Location: Slot 1, Cascading #2, VC #1

Interface #2

Location: Slot 1, E1/DS1 #2

Timing: Recovered

Protecting Interface

Location: Slot #1, Cascading #2, VC #2

Protecting Trail ID: 3

Active: Working

Operational status: Down

Admin status: Up

Switch Command: No Action

Apply Refresh Close

You can edit the following parameters:

- **Trail Description** - Optional. A text description of the trail.
- **Admin Status** - Select **Up** to enable the trail or **Down** to disable the trail. For protected trails, you can select **Working Down** or **Protecting Down** to disable only the working or only the protecting trail.
- **Switch Command** - Used for protected trails to initiate a manual switchover. Select from the following options:
 - **No Action** - No manual switchover is initiated.
 - **Manual Switch** - Initiates a manual switchover.

To implement the changes, click **Apply**, then **Close**.

To change the Admin Status of multiple trails:

- 1 Select the trails in the Native TDM Services table or select all the trails by selecting the check box in the top row.
- 2 In the Multiple Selection Operation section underneath the Native TDM Services table, select **Service Admin Status - Up** or **Service Admin Status - Down** and click **Apply**.

Figure 307 Native TDM Services Edit Page – Multiple Selection Operation



Deleting TDM Trails

To delete a trail, select the trail in the TDM Services table and click **Delete**. The Admin status of the trail must be **Down** in order to delete the trail.

To delete multiple trails:

- 1 Select the trails in the TDM Services table or select all the trails by selecting the check box in the top row.
- 2 Click **Delete** underneath the TDM Services table.

Limitations on Available Endpoints

A group or interface will not appear in the Slot/Group/Port field if any of the following conditions exist:

- For the E1/DS1 interface, the E1/DS1s have all already been assigned to other trails.
- For a radio interface or group, all VCs have already been assigned to other trails.
- For a TDM interface, there is no available TDM trail ID.
- For a TDM interface, there are no available TDM resources.
- After opening the TDM Services Creation page, but before selecting an interface or group, the last available Service ID or Trail ID was configured by another user, or the maximum amount of trails (256) was reached for the unit.

The following additional condition applies if you are in the Interface #2 screen:

For E1/DS1, an E1/DS1 has already been selected as the first interface.

Configuring TDM Pseudowire Services

This section includes:

- [TDM Pseudowire Services Configuration Overview](#)
- [General Guidelines for Provisioning TDM Pseudowire Services](#)
- [Viewing TDM Pseudowire Services](#)
- [Configuring the Revertive Timer](#)
- [Adding TDM Pseudowire Services](#)
- [Editing TDM Pseudowire Services](#)
- [Deleting TDM Pseudowire Services](#)
- [Limitations on Available Endpoints](#)

TDM Pseudowire Services Configuration Overview



Note

By default, the TDM interfaces in a PTP 820G or PTP 820F unit are set to operate according to the ETSI standard, in E1 mode. For instructions on configuring the system to operate according to the ANSI (FCC) standard (DS1), see [TDM Overview \(CLI\)](#).

The PTP 820G Web EMS provides a simple and easy-to-use GUI that enables users to provision end-to-end TDM pseudowire services.

To open the TDM PseudoWire Services page:

- 1 Select **TDM > TDM PseudoWire > Services**. The TDM PseudoWire Services page opens.

Figure 308 TDM PseudoWire Services Page

EC ID	Description	Interface #1	Interface #2	Protecting Interface	PseudoWire Service Status
1		Radio Slot 1 Port 1	Ethernet Slot 1 Port 5	N/A	Up

The TDM PseudoWire Services page displays all pseudowire services configured on the unit and provides a simple and efficient workflow for adding pseudowire services. The following interfaces can be used as service endpoints:

- TDM interfaces
- Radio interfaces
- Cascading interfaces
- Ethernet interfaces

TDM endpoints can be E1/DS1s.

Radio endpoints can be selected from the radio interfaces, a Radio Protection Group, or a Multi-Carrier ABC Group.

Cascading interfaces can be configured on ports GbE1/CS1 and GbE2/CS2. When operating in cascading mode, these interfaces can handle hybrid Ethernet and Native TDM traffic, enabling operators to create links among multiple PTP 820units in a node for multi-directional applications based on hybrid Ethernet and Native or pseudowire TDM services. For instructions, see [Configuring RFU3/SFP5,RFU3/2.5GE5 as an Ethernet or RFU Interface\(PTP 820F only\)](#)

On PTP 820F, the combo port labelled RFU3/SFP5 (SFP) and RFU3/2.5GE5 (RJ-45) can be configured as either an RFU interface (RFU3) or an Ethernet interface (Eth3). By default, this port is an RFU interface.



Figure: RFU3/SFP5 and RFU3/2.5GE5 Combo Port

To change the port's use from RFU to Ethernet or Ethernet to RFU:

- 1 Set the port's admin state to **Down** in the Interface Manager.
 - If the port is currently configured as an RFU port, it is listed as **Radio: Slot 1, Port 5** in the Interface Manager.
 - If the port is currently configured as an Ethernet port, it is listed as **Ethernet: Slot 1, Port 5** in the Interface Manager.

See Enabling the Interfaces (Interface Manager).
- 2 In the Radio Unit page, set the Admin status of **Radio Unit: Slot 1, Port 3** to **Down**.
- 3 If there are any service points attached to the port, remove them.
- 4 If the port is configured as a Sync source, delete the port as a Sync source.
- 5 If the port belongs to any interface groups, such as LAG, remove the port from the group.
- 6 Select **Platform > Interfaces > RFU/Ethernet**. The RFU/Ethernet Interface Configuration page opens.




Figure: RFU/Ethernet Interface Configuration Page

7 Select **Radio Unit: Slot 1, Port 3** and click **Edit**. The RFU/Ethernet Interface Configuration – Edit page opens.




Figure: RFU/Ethernet Interface Configuration – Edit Page

- 8 In the **Interface Type** field, select **RFU** or **Ethernet**.
- 9 Click **Apply**, then **Close**.
- 10 If you configured the port as an Ethernet interface, you must set the port’s admin state to **Up** in the Interface Manager. See *Enabling the Interfaces (Interface Manager)*. If you configured the port as an RFU interface, its admin state is **Up** automatically.

If you configured the port as an Ethernet interface, the port takes the following parameters:

- Port speed: 1 GE
- Media Type: RJ45
- Auto Negotiation: On

To change these parameters, go to the Physical Interfaces page. See *Configuring Ethernet Interfaces*.

Note: Both Eth5 and Eth6 can be configured to either 1 GE or 2.5 GE. The other PTP 820F Ethernet ports support 1 GE only.

If you configured the port as an RFU interface, make sure to set the Radio Unit parameters as necessary.

Configuring Cascading Interfaces (Optional).

Ethernet interfaces can be any of the unit's Ethernet interfaces. LAGs can also be used.

General Guidelines for Provisioning TDM Pseudowire Services

When provisioning TDM pseudowire services, it is recommended to follow these guidelines:

- Each service within the same local region should use a unique EC ID. The EC ID should also be unique along the path of each service.
- For protected services, the EC ID of the protecting service must be different from the EC ID of the working service.
- At one of the two endpoint devices, the **Local MEP** parameter should be set to **1** while, at the far-end endpoint device, the **Local MEP** parameter should be set to **2**.

Viewing TDM Pseudowire Services

The TDM PseudoWire Services page ([Figure 294](#)) displays the pseudowire services configured on the unit and their basic parameters.



Note

To filter the list of pseudowire services according to slot or group, select the slot or group in the **Show services for** field. Only services with an endpoint in the selected slot or group appear.

[Table 100](#) lists and describes the parameters in the TDM PseudoWire Services page.

Table 101 TDM Pseudowire Service Parameters

Parameter	Definition
EC ID	A unique ID for the service.
Description	A text description of the service.
Interface #1: Slot/Group	Slot 1 or the group number of the first endpoint in the service.
Interface #1: Port	The port number of the first endpoint in the service.
Interface #1: VC/VLAN	<ul style="list-style-type: none"> For Ethernet, radio, and cascading interfaces – The VLAN classified to the first endpoint of the service (1-4094). For E1/DS1 interfaces – Not relevant (N/A).
Interface #2: Slot/Group	Slot 1 or the group number of the second endpoint in the service.
Interface #2: Slot/Group	The slot or group number of the second endpoint in the service.
Interface #2: Port	The port number of the second endpoint in the service.
Interface #2: VC/VLAN	<ul style="list-style-type: none"> For Ethernet, radio, and cascading interfaces – The VLAN classified to the second endpoint of the service (1-4094). For E1/DS1 interfaces – Not relevant (N/A).
Protecting Interface: Slot/Group	For protected services, Slot 1 or the group number of the protecting service endpoint.
Protecting Interface: Port	For protected services, the port number of the protecting service endpoint.
Protecting Interface: VC/VLAN	For protected services: <ul style="list-style-type: none"> For Ethernet, radio, and cascading interfaces – The VLAN classified to the protecting endpoint (1-4094). For E1/DS1 interfaces – Not relevant (N/A).
PseudoWire Service Status: Admin	The administrative status of the service.
PseudoWire Service Status: Operational	The operational status of the service.

Configuring the Revertive Timer

1:1 pseudowire path protection can be configured to operate in revertive mode. In revertive mode, the system monitors the availability of the protected path at all times. After switchover to the protecting path, once the protected path is operational and available without any alarms, the system waits for the duration of the user-configured Wait to Restore (WTR) time and then, if the protected path remains operational and available, initiates a revertive protection switch. A single WTR time is configured for all the pseudowire services in the system. However, services with 1:1 path protection can be configured individually as revertive or non-revertive.




Note

Pseudowire services with 1:1 path protection that were configured using software versions prior to T7.9 are non-revertive.

To set the WTR time for services with revertive 1:1 path protection:

- 1 Underneath the TDM PseudoWire Services table, click **Timer Configuration**. The TDM Service Revertive Timer Configuration page opens.

Figure 309 TDM Service Revertive Timer Configuration Page



- 2 Enter the number, in seconds, for the WTR time. The default value is 10 seconds.
- 3 Click **Apply**, then **Close**.

Adding TDM Pseudowire Services

To initiate the workflow for adding a pseudowire service:

- 1 Select **TDM > TDM PseudoWire > Services**. The TDM PseudoWire Services page opens ([Figure 308](#)).
- 2 Click **Create Service**. The Add Pseudowire TDM Service workflow begins. The workflow and options provided by the TDM PseudoWire Services Creation page depends on the selection you make in the **Slot/Group/Port** field. For detailed instructions per service type, see:
 - o [Adding a Service between a TDM Port or Protection Group and a Radio Port, a Radio Group, or an Ethernet or Cascading Interface](#)
 - o [Adding a Service between Radio Ports, Radio Groups, or Ethernet or Cascading Interfaces](#)

You cannot add a pseudowire service if any of the following conditions exist:

- There are no available pseudowire services.
 - o There are no available Service IDs in the range reserved for TDM services (801-928), or

- o The maximum number of services (256) has already been configured on the PTP 820G or PTP 820F unit.

Adding a Service between a TDM Port or Protection Group and a Radio Port, a Radio Group, or an Ethernet or Cascading Interface

- 1 In the Interface #1 screen of the TDM PseudoWire Services Creation page, configure the parameters of the service's first endpoint.
- 2 In the **Slot/Group/Port** field, select a TDM interface, a radio interface or group, an Ethernet interface, or a cascading interface.

Configuring a TDM Card or Group as an Endpoint

- i Select the E1/DS1 interface.

Figure 310: Pseudowire Service Creation – Interface #1 E1/DS1

The screenshot shows a configuration window titled "Interface #1". It contains the following fields and options:

- Slot/Group/Port:** A dropdown menu showing "Slot 1 (E1/DS1 1-16)".
- E1/DS1:** A dropdown menu showing "3".
- Profile:** A dropdown menu showing "1, Payload size:16, Jitter buffer depth: 9, RTP header use: Disable".
- Timing:** A dropdown menu showing "Recovered".

At the bottom of the window, there are four buttons: "<< Back", "Next >>", "Finish", and "Close".



Note

Some interfaces may not appear in the **Slot/Group/Port** field. Refer to [Limitations on Available Endpoints](#) for the possible reasons an interface will not appear. If there are no available interfaces, a message appears that no endpoint can be selected.

- ii In the **E1/DS1** field, select an E1/DS1 or VC12. This configures the first endpoint for the service.



Note

Only E1/DS1s that are not already assigned to a pseudowire service appear in the selection box. Also, an E1/DS1 will not appear in the selection box if the TDM interface has already been assigned a service point with a classification and a slot and port or group number that match the classification that would automatically be assigned to the E1/DS1 via the TDM PseudoWire Service Creation page.

- iii In the **Profile** field, select a pseudowire profile for the endpoint. You can select a predefined profile (Profile 1 or Profile 2), or you can configure additional profiles and select one of these profiles. See [Configuring Pseudowire Profiles](#).
- iv In the **Timing** field, select the synchronization mode for the endpoint. Options are:
 - o **Loop Timing** – The interface takes the timing from incoming signals.
 - o **Recovered** – Clock information is recovered on the egress path. Extra information may be located in an RTP header that can be used to correct frequency offsets.
 - o **System Reference** – The interface is synchronized to the system reference clock.
 - o **Front Panel** – The interface is synchronized to an external clock reference from a dedicated front panel clock interface.

Configuring a Radio Port or Group or an Ethernet or Cascading Interface as an Endpoint

- i In the Interface #1 screen of the TDM PseudoWire Services Creation page, configure the parameters of the service's first endpoint.

Figure 311 Pseudowire Service Creation – Interface #1 Radio/Ethernet/Cascading



Note

Some interfaces may not appear in the **Slot/Group/Port** field. Refer to [Limitations on Available Endpoints](#) for the possible reasons an interface will not appear. If there are no available interfaces, a message appears that no endpoint can be selected.

- ii In the **VLAN Type** field, select the VLAN Type for the first endpoint. The VLAN Type determines which frames enter the service via this endpoint, based on the frame's VLAN tagging. Options are:
 - o **S-TAG** – A single S- VLAN is classified to the service point.
 - o **C-TAG** - A single C- VLAN is classified to the service point.
- iii In the **S-VLAN** or **C-VLAN** field, select the VLAN you want to classify to the endpoint (1-4090).

- 3 Click **Next**. The Interface #2 page opens. In the Interface #2 page, configure the parameters of the service's second endpoint:
 - If the first endpoint is a TDM interface, select a radio interface, a Radio Protection group, a Multi-Carrier ABC group, or an Ethernet or cascading interface in the Interface #2 page.
 - If the first endpoint is a radio interface, a Radio Protection group, a Multi-Carrier ABC group, or an Ethernet or cascading interface, select a TDM interface in the Interface #2 page.
- 4 Follow the instructions in [Step 2](#) to configure the second endpoint.
- 5 Click **Next**. The EC ID Selection page opens.

Figure 312 Pseudowire Service Creation – EC ID Selection Page (Radio/Ethernet/Cascading - TDM)

- 6 In the **EC ID** field, select an EC ID (1-512) to identify the service. Only unused EC ID values appear in the selection box. The default value is the lowest unused EC ID.
- 7 In the **P-bit** field, select a p-bit value (0-7). This value will be assigned to frames passing through the service.
- 8 Optionally, in the **Description** field, enter text to describe the service.

**Note**

The **Service Type** and **Tunnel Type** fields are read-only. In this version, only SAToP/Ethernet pseudowire services are supported.

- 9 In the **Protection** field, select one of the following:
 - **Unprotected** - The service will not have path protection.
 - **1:1 Protection (non-revertive)** – The service will have 1:1 path protection in which two separate network paths are defined for the service. Each service has the same TDM interface endpoints, but traffic flows to the destination via different radio, Ethernet, or cascading interfaces. Bandwidth is utilized only on the active path, freeing up resources on the standby path.
When you click **Next**, you will be asked to configure an additional radio interface or group, or Ethernet or cascading interface, as the protecting interface.
 - **1:1 Protection (revertive)** – The service will have 1:1 path protection, as described above, in revertive mode. See [Configuring the Revertive Timer](#).

- **1+1 Protection** – Used for networks in which the PTP 820G or PTP 820F network elements are set up as a chain connected to third party networks at two different sites, where one end-point is located on a PTP 820G or PTP 820F unit and the other end-point is located on third-party equipment supporting SNCP. The service will have 1+1 path protection in which two separate network paths are defined for the service. Each path has the same TDM interface endpoints, but traffic flows to the destination via different radio, Ethernet, or cascading interfaces. Unlike 1:1 path protection, traffic flows through both paths simultaneously, thereby supporting SNCP in third party equipment at the other end of the link. When you click **Next**, you will be asked to configure an additional radio interface or group, or Ethernet or cascading interface as the protecting interface.
- **1+1 Dual Homing Network Edge** – Used for PTP 820G or PTP 820F units located at the network edge in a 1+1 Protection configuration. Since the node itself is part of the protected or protecting path, the node itself is essentially unprotected and you do not need to configure a separate protecting path. When you click **Next**, you will be asked to configure a Working Path ID.

**Note**

In a 1+1 Protection configuration, the third-party equipment usually detects problems in the link via E1/DS1 AIS signals. If the third party equipment does not support the ability to read E1/DS1 AIS signals, it must be configured to perform switchover upon receiving an UNEQUIPPED indication in the signal label bits in the overhead.

- 10 In the **Local MEP** field, select 1 or 2. If you select 1, the **Local MEP** field in the network element at the other side of the link must be configured as 2, and vice versa.
 - If you selected **Unprotected** in the **Protection** field, click **Finish**. The Selection Summary page opens ([Figure 315](#)).
 - If you selected **1:1 Protection (revertive or non-revertive)** or **1+1 Protection** in the **Protection** field, click **Next**. The Protecting Interface Selection page opens.

Figure 313 Pseudowire Service Creation – Protecting Interface Selection Page

- If you selected **1+1 Dual Homing Network Edge** in the **Protection** field, click **Next**. The Working EC ID Selection page opens. Skip steps 11 through 13 and proceed to Step 14.

Figure 314 Pseudowire Service Creation – Working EC ID Selection Page

- 11 In the **Slot/Group/Port** field, In the **Slot/Group/Port** field, select a radio interface, Radio Protection group, Multi-Carrier ABC group, or cascading interface to serve as the interface for the protecting path.

**Note**

Some interfaces may not appear in the **Slot/Group/Port** field. Refer to [Limitations on Available Endpoints](#) for the possible reasons an interface will not appear. If there are no available interfaces, a message appears that no endpoint can be selected.

- 12 In the **VLAN Type** field, select the VLAN Type for the protecting path endpoint. The VLAN Type determines which frames enter the service via this endpoint, based on the frame's VLAN tagging. Options are:
 - **S-TAG** – A single S- VLAN is classified to the service point.
 - **C-TAG** – A single C- VLAN is classified to the service point.
- 13 In the **S-VLAN** or **C-VLAN** field, select the VLAN you want to classify to the endpoint (1-4090).

- 14 In the **Protecting EC ID** or **Working EC ID** field, select an EC ID (1-512) to identify the protecting or working path. Only unused EC ID values appear in the selection box. The default value is the lowest unused EC ID. All nodes in the protected configuration, both on the protected and the protecting path, must have the same **Protecting EC ID** or **Working EC ID**.
- 15 Click **Finish**. The Selection Summary page opens, displaying the parameters you have configured.

Figure 315 Pseudowire Service Creation – Selection Summary Page (Radio/Ethernet/Cascading - TDM)

The screenshot shows a window titled "Selection Summary Page" with the following content:

Interface #1:
Slot 1 (E1/DS1 1-16), E1/DS1 #3
Profile: 1
Timing: Recovered

Interface #2:
Slot 1 (Cascading: Slot 1, port 2), VC #1

PseudoWire Service Configuration:
EC ID: 4
P-bit: 5
Description:

Protecting interface Selection:
Slot 1 (Ethernet: Slot 1, port 1), VC #1

Protecting EC ID Configuration:
Protecting EC ID: 5

Press 'Submit' to configure the selected parameters.

At the bottom, there are four buttons: << Back, Next >>, Submit, and Close.

- 16 To create the service with the displayed parameters, click **Submit**. If you want to return to an earlier page and change the service parameters, click **Back**.



Note

An invalid configuration error may occur in the event that another user utilized a resource that you selected, such as an interface or a EC ID, between the time you selected the resource and the time you pressed **Submit**. If this occurs, you must go back and, if necessary, select alternative resources for the service.

Adding a Service between Radio Ports, Radio Groups, or Ethernet or Cascading Interfaces

- 1 In the Interface #1 screen of the TDM PseudoWire Services Creation page, configure the parameters of the service's first endpoint.

Figure 316 Pseudowire Service Creation – Interface #1 (Radio/Ethernet/Cascading)

- 2 In the **Slot/Group/Port** field, select a radio interface, Radio Protection group, Multi-Carrier ABC group, or cascading interface.



Note

Some interfaces may not appear in the **Slot/Group/Port** field. Refer to [Limitations on Available Endpoints](#) for the possible reasons an interface will not appear. If there are no available interfaces, a message appears that no endpoint can be selected.

- 3 In the **VLAN Type** field, select the VLAN Type for the first endpoint. The VLAN Type determines which frames enter the service via this endpoint, based on the frame's VLAN tagging. Options are:
 - **S-TAG** – A single S- VLAN is classified to the service point.
 - **C-TAG** – A single C- VLAN is classified to the service point.
- 4 In the **S-VLAN** or **C-VLAN** field, select the VLAN you want to classify to the endpoint (1-4090).
- 5 Click **Next**. The Interface #2 page opens. In the Interface #2, configure the parameters of the service's second endpoint.

Figure 317 Pseudowire Service Creation – Interface #2 (Radio/Cascading)

Interface #2

Slot/Group/Port Radio Protection: Group 1

C-VLAN 1

<< Back Next >> Finish Close

6 Follow the instructions in Steps 2-4 to configure the second endpoint.

7 Click **Next**. The EC ID page opens.

Figure 318 Pseudowire Service Creation – Service Selection Page (Radio/Ethernet/Cascading)

PseudoWire Service Configuration

EC ID 3

P-bit 5

Description TN-356

<< Back Next >> Finish Close

8 Select an **EC ID** (1-512) to identify the service. Only unused EC ID values appear in the **EC ID** selection box. The default value is the lowest unused EC ID.

9 In the **P-bit** field, select a p-bit value (0-7). This value will be assigned to frames passing through the service.

10 Optionally, in the **Description** field, enter text to describe the service.

11 Click **Finish**. The Selection Summary page opens, displaying the parameters you have configured.

Figure 319 Pseudowire Service Creation – Selection Summary (Radio/Ethernet/Cascading)

Interface #1:
Slot 1 (Cascading: Slot 1, port 2), VC #2

Interface #2:
Radio Protection: Group 1, VC #1

PseudoWire Service Configuration:
EC ID: 6
P-bit: 5
Description:

Press 'Submit' to configure the selected parameters.

<< Back Next >> Submit Close

- 12 To create the service with the displayed parameters, click **Submit**. If you want to return to an earlier page and change the service parameters, click **Back**.

**Note**

An invalid configuration error may occur in the event that another user utilized a resource that you selected, such as an interface or a EC ID, between the time you selected the resource and the time you pressed **Submit**. If this occurs, you must go back and, if necessary, select alternative resources for the service.

Editing TDM Pseudowire Services

To edit an existing service:

- 1 Select the service in the TDM PseudoWire Services page ([Figure 308](#)).
- 2 Click **Edit**. The TDM PseudoWire Services – Edit page opens.

Figure 320 TDM PseudoWire Services – Edit Page

You can edit the following parameters:

- **Description** - Optional. A text description of the service.
- **Admin Status** - Select **Up** to enable the service or **Down** to disable the service. For protected service, you can select **Working Down** or **Protecting Down** to disable only the working or only the protecting path.
- **Switch Command** - Used for protected services to initiate a manual switchover. Select from the following options:
 - **No Action** - No manual switchover is initiated.
 - **Manual Switch** - Initiates a manual switchover.

To implement the changes, click **Apply**, then **Close**.

To change the Admin Status of multiple services:

- 1 Select the services in the TDM PseudoWire Services table or select all the services by selecting the check box in the top row.
- 2 In the Multiple Selection Operation section underneath the TDM PseudoWire Services table, select **Service Admin Status - Up** or **Service Admin Status - Down** and click **Apply**.

Figure 321 Pseudowire Services Edit Page – Multiple Selection Operation

Multiple Selection Operation

Service Admin Status

Deleting TDM Pseudowire Services

To delete a service, select the service in the TDM PseudoWire Services table and click **Delete**. The Admin status of the service must be **Down** in order to delete the service.

To delete multiple services:

- 1 Select the services in the TDM PseudoWire Services table or select all the services by selecting the check box in the top row.
- 2 Click **Delete** underneath the TDM PseudoWire Services table.

Limitations on Available Endpoints

A slot, group, or interface will not appear in the **Slot/Group/Port** field if any of the following conditions exist:

- An SAP service point has been configured on the interface.
- For the E1/DS1 interface, the E1/DS1s have all already been assigned to other services.
- For a radio interface or group, all VCs have already been assigned to other services.
- For a TDM interface, there is no available TDM service ID.
- For TDM interface, there are no available TDM resources.
- After opening the TDM Services Creation page, but before selecting a slot or group, the last available Service ID was configured by another user, or the maximum amount of services (256) was reached for the unit.

The following additional condition applies if you are in the Interface #2 screen:

- For E1/DS1, an E1/DS1 has already been selected as the first interface.

Configuring Advanced Pseudowire Parameters

To configure pseudowire services, it is recommended to use the TDM Pseudowire Services page, which provides a step-by-step workflow based on pre-configured pseudowire settings. See [Configuring TDM Pseudowire Services](#).

To manually configure the pseudowire parameters and services, follow the instructions in this section to configure the parameters located in the **TDM > TDM PseudoWire > Advanced** section of the Web EMS.

This section includes:

- [Configuring Pseudowire Card Parameters](#)
- [Configuring OEM for Pseudowire Services](#)
- [Configuring Pseudowire Tunnels and Tunnel Groups](#)
- [Configuring Pseudowire Profiles](#)
- [Configuring Pseudowire TDM Services Manually](#)



Note


The DS0 Bundles page is reserved for future use.

Configuring Pseudowire Card Parameters

To configure the pseudowire parameters of the E1/DS1 interface:


- 1 Select **TDM > TDM PseudoWire > Advanced > Configuration**. The PseudoWire Card Configuration page opens.

Figure 322 PseudoWire Card Configuration Page



- 2 Select the E1/DS1 interface and click **Edit**. The PseudoWire Card Configuration – Edit page opens.

Figure 323 PseudoWire Card Configuration – Edit Page



3 Configure the parameters, as described in [Table 102](#).

Table 102 Pseudowire Card Configuration Parameters

Parameter	Definition
Shelf Slot ID	Read-only. Slot 1.
Ethernet Traffic MAC Address	Displays the E1/DS1 connector's MAC address, which is unique per unit. This means if the E1/DS1 connector is replaced, the MAC address remains the same, and no configuration changes are required.
Signal to System Sync Distribution Reference	Select the clock source that the TDM interface exports to the general PTP 820G or PTP 820F synchronization mechanism. Options are: <ul style="list-style-type: none"> • None – No clock source is exported from the TDM interface to the general PTP 820G synchronization mechanism. • Front Panel – Reserved for future use. • Clock Recovery – Reserved for future use. • clock-1588 – Reserved for future use. • rx-pdh – Reserved for future use. • rx-sdh – Reserved for future use.
TDM Port for System Clock Recovery Reference	Reserved for future use.
Card Clock Recovery Mode	Reserved for future use.

Parameter	Definition
Differential Clock Reference Source	Reserved for future use.
Differential Clock Reference Frequency	Reserved for future use.
Card IP Address	Reserved for future use.
Card Subnet Mask	Reserved for future use.

Configuring OEM for Pseudowire Services

In order to configure a TDM service with path protection, you must first assign a Maintenance Domain (MD) to the E1/DS1 interface. You must then configure Maintenance Associations (MAs), which are assigned to the tunnels that constitute the tunnel group in the protected service.

You can configure up to eight MDs per card.



Note

Pseudowire Loopback and Link Trace are planned for future release.

Configuring Pseudowire Maintenance Domains (MDs)

To view all the MDs configured for a TDM card:

- 1 Select **TDM > TDM PseudoWire > Advanced > Service OAM > Maintenance Domain**. The Service OAM Maintenance Domain page opens. [Table 103](#) describes the MD parameters.

Figure 324 Service OAM Maintenance Domain Page




Table 103 Pseudowire Maintenance Domain Parameters

Parameter	Definition
Maintenance Domain ID	A unique ID that identifies the MD.
Maintenance Domain Name	A name for the MD, for information purposes.
Level	The maintenance level of the MD. The maintenance level ensures that the CFM frames for each domain do not interfere with each other. Where domains are nested, the encompassing domain must have a higher level than the domain it encloses. The maintenance level is carried in all CFM frames that relate to that domain.

To add an MD:

- 1 In the **Select a slot** field, select the TDM card to which you want to add the MD.
- 2 Click **Add**. The Service OAM Maintenance Domain – Add page opens.

Figure 325 Service OAM Maintenance Domain – Add Page

- 3 In the **Maintenance Domain ID** field, select a unique ID from 1 to 8 to identify the MD.
- 4 Optionally, in the **Maintenance Domain Name** field, enter a name for the MD, for information purposes.
- 5 In the **Level** field, select a maintenance level for the MD, from 0 to 7. The maintenance level ensures that the CFM frames for each domain do not interfere with each other. Where domains are nested, the encompassing domain must have a higher level than the domain it encloses. The maintenance level is carried in all CFM frames that relate to that domain.
- 6 Click **Apply**, then **Close**.

To edit an MD:

- 1 In the **Select a slot** field, select the TDM card to which the MD you want to edit belongs.
- 2 Click **Edit**. The Service OAM Maintenance Domain – Edit page opens. You can edit any of the MD parameters you can configure when you add an MD except the **Maintenance Domain ID** field.
- 3 Edit the MD parameters, as described above.
- 4 Click **Apply**, then **Close**.

To delete an MD:

- 1 In the **Select a slot** field, select the TDM card to which the MD you want to delete belongs.
- 2 Click **Delete**. The MD is deleted.



Note

You cannot delete an MD for which MAs have been configured. See [Configuring Pseudowire Maintenance Associations \(MAs\)](#).

Configuring Pseudowire Maintenance Associations (MAs)

Maintenance Associations (MAs) define Maintenance End Points (MEPs), and perform continuity checks by sending Continuity Check Messages (CCMs) between the MEPs. This is the mechanism by which PTP 820G or PTP 820F monitors the status of both paths in a protected TDM service and determines when a switchover is necessary.

For PTP 820F and PTP 820G, You can configure up to 32 MAs per unit.

Each of the two TDM tunnels that make up a path-protected TDM service must be assigned its own MA. Each MA must have a unique local MEP ID and a unique remote MEP ID. Each MA must also include a defined VLAN, which corresponds to the VLAN that will be assigned to the TDM tunnel associated with the MA.

To view all the MAs configured for a TDM card:

- 1 Select **TDM > TDM PseudoWire > Advanced > Service OAM > Maintenance Association**. The Service OAM Maintenance Association page opens. [Table 104](#) describes the MA parameters.

Figure 326 Service OAM Maintenance Association Page




Table 104 Pseudowire Maintenance Association Parameters

Parameter	Definition
Maintenance Association ID	A unique ID that identifies the MA.
Maintenance Association Name	A name for the MA, for information purposes.
Maintenance Domain ID	The MD to which the MA belongs.
Local MEP ID	A unique ID for the local MEP.
Remote MEP ID	A unique ID for the remote MEP.
VLAN Type	The outer VLAN type assigned to the tunnel to which the MA will be attached. This should be the same as the VLAN Type for the service being monitored.
VLAN ID	The VLAN assigned to the tunnel to which the MA will be attached.
CCM Interval	The interval (in ms) at which the MA sends CCM messages.
CCM Admin	Displays whether or not CCM messages are enabled for the MA. CCM must be enabled in order for the MA to serve its purpose as the monitoring mechanism for TDM path protection.

Parameter	Definition
LTM Priority	The link trace message priority assigned to the MA (0 - 7).
Detected Defects	<p>A bitmask that indicates several possible problems with the link:</p> <ul style="list-style-type: none">• 0: no-alarm• 1: RDI• 2: MAC-status• 4: remote CCM• 8: error CCM• 16: Cross-connection CCM• 32: AIS <p>The number that appears indicates the sum of the defects. For example, the number 7 indicates that RDI, MAC-status, and remote CCM defects have been detected in the link.</p>
Remote MEP MAC Address	The MAC address of the remote MEP.

To add an MD:

- 1 In the **Select a slot** field, select the TDM card to which you want to add the MA.
- 2 Click **Add**. The Service OAM Maintenance Association – Add page opens.

Figure 327 Service OAM Maintenance Association – Add Page

- 3 In the **Maintenance Association ID** field, select a unique ID to identify the MA.
- 4 Optionally, in the **Maintenance Association Name** field, enter a name for the MA, for information purposes.
- 5 In the **Maintenance Domain ID** field, select an MD to which the MA belongs.
- 6 In the **Local MEP ID** field, select a unique ID for the local MEP.
- 7 In the **Remote MEP ID** field, select a unique ID for the remote MEP.
- 8 In the **VLAN Type** field, select the outer VLAN type assigned to the tunnel to which the MA will be attached. Options are:
 - **None**
 - **C-type**
 - **S-type**
 This should be the same as the VLAN Type for the service being monitored.
- 9 In the **VLAN ID** field, select the VLAN assigned to the tunnel to which the MA will be attached. This should be the same as the VLAN of the service being monitored.
- 10 In the **CCM Interval** field, select the interval (in ms) at which the MA sends CCM messages. Options are:
 - **3.3 ms**
 - **10 ms**
 - **100 ms**
 - **1 second**
 - **10 seconds**
 - **1 minutes**

- **10 minutes**
- 11 In the **CCM Admin** field, select **Enable** to enable the MA to send CCM messages. CCM must be enabled in order for the MA to serve its purpose as the monitoring mechanism for TDM path protection.
- 12 In the **LTM Priority** field, select a link trace message priority for the MA (0 - 7).
- 13 Click **Apply**, then **Close**.

To edit an MA:

- 1 In the **Select a slot** field, select the TDM card to which the MA you want to edit belongs.
- 2 Click **Edit**. The Service OAM Maintenance Association – Edit page opens. You can edit any of the MA parameters that you can configure when adding an MA except the **Maintenance Association ID** field.
- 3 Edit the MA parameters, as described above.
- 4 Click **Apply**, then **Close**.

To delete an MA:

- 1 In the **Select a slot** field, select the TDM card to which the MA you want to delete belongs.
- 2 Click **Delete**. The MA is deleted.



Note

You cannot delete an MA that is assigned to a tunnel. See [Configuring Pseudowire Tunnels and Tunnel Groups](#).

Configuring Pseudowire Tunnels and Tunnel Groups

Each TDM service must include an encapsulation tunnel to determine how traffic over the service passes through the network. In this version, encapsulation must use the MEF-8 protocol.

For PTP 820G and PTP 820F, You can configure up to 32 tunnels per unit.



Note

UDP/IP and MPLS support are planned for future release.

To configure TDM services with path protection, you must configure two tunnels for each protected service and combine these tunnels into a tunnel group. For more information, see [Configuring a Tunnel Group](#).

Configuring a Tunnel

This section includes:

- [Viewing Tunnels](#)
- [Adding a Tunnel](#)
- [Editing a Tunnel](#)

- [Viewing a Tunnel’s Operational Status and Attributes](#)
- [Deleting a Tunnel](#)

Viewing Tunnels

To view all the tunnels configured for the unit:

- 1 Select **TDM > TDM PseudoWire > Advanced > PSN Tunnels > PSN Tunnels**. The PseudoWire PSN Tunnels page opens. [Table 105](#) describes the tunnel parameters.

Figure 328 Pseudowire PSN Tunnels Page




Table 105 Pseudowire PSN Tunnels Parameters

Parameter	Definition
Tunnel ID	A unique ID that identifies the tunnel.
Tunnel Admin	Displays the administrative state of the tunnel (Enabled or Disabled).
Tunnel Type	Displays the tunnel's encapsulation type. In this release, only Ethernet Layer 2 MEF-8 encapsulation (Eth) is available.
Destination MAC Address	The MAC address of the interface or card at the other site of the link. This is only relevant for Ethernet (MEF-8) tunnels.
VLAN Type	Displays the outer VLAN type used by the tunnel. Options are: <ul style="list-style-type: none"> • None • C-type • S-type
VLAN ID	Displays the VLAN ID assigned to frames passing through the tunnel.
Tunnel P-bits	Displays the p-bit value assigned to frames passing through the tunnel.

Parameter	Definition
Maintenance Association ID	Displays the Maintenance Association (MA) ID assigned to the tunnel. This is only relevant for tunnels that are used in TDM services with path protection. For more information, see Configuring a Tunnel Group .

Adding a Tunnel

To add a tunnel:

- 1 Click **Add**. The PseudoWire PSN Tunnels – Add page opens.

Figure 329 PseudoWire PSN Tunnels– Add Page

- 2 In the **Tunnel ID** field, enter a unique ID, from 1 to 16, to identify the tunnel.
- 3 In the **Tunnel Admin** field, select **Enable** to enable the tunnel, or **Disable** if you want to add the tunnel but enable it at a later time.
- 4 In the **Tunnel Type** field, select the tunnel's encapsulation type. In this release, only Ethernet Layer 2 MEF-8 encapsulation (**Eth**) is available.
- 5 In the **Destination MAC Address** field, for Ethernet (MEF-8) tunnels, enter the MAC address of the card at the other site of the link.
- 6 In the **VLAN Type** field, select the outer VLAN type used by the tunnel. Options are:
 - **None**
 - **C-type**
 - **S-type**
- 7 In the **VLAN ID** field, enter a VLAN ID (1-4090). This value will be assigned to frames passing through the tunnel.

- 8 In the **PSN Tunnel P-bits** field, enter a p-bit value. This value will be assigned to frames passing through the tunnel.
- 9 In the **Maintenance Association ID** field, you must select a Maintenance Association (MA) if you plan to use the tunnel for path-protected services. This MA is assigned to the tunnel, defines Maintenance End Points (MEPs), and performs continuity checks by sending Continuity Check Messages (CCMs) between the MEPs. This is the mechanism by which PTP 820G or PTP 820F monitors the status of both paths in a protected TDM service and determines when a switchover is necessary.

You must define the MA separately in order to assign it to a tunnel. For instructions, see [Configuring OEM for Pseudowire Services](#). For more information about defining TDM path protection generally, see [Configuring a Tunnel Group](#).
- 10 Click **Apply**, then **Close**.

Editing a Tunnel


To edit a tunnel:

- 1 Select the tunnel you want to edit.
- 2 Click **Edit**. The PseudoWire PSN Tunnels – Edit page opens. You can edit any of the tunnel parameters you can configure when you add a tunnel except the **Tunnel ID** field.
- 3 Edit the tunnel parameters, as described above.
- 4 Click **Apply**, then **Close**.

Viewing a Tunnel's Operational Status and Attributes

To view a tunnel's operational status and attributes:

- 1 Select the tunnel you want to view.
- 2 Click **Tunnel Status**. The PseudoWire PSN Tunnels – Status page opens. [Table 106](#) describes the tunnel status parameters.

Figure 330 PseudoWire PSN Tunnels– Status Page**Table 106** Pseudowire Tunnel Status Parameters

Parameter	Definition
Slot ID	Slot 1.
Tunnel ID	A unique ID that identifies the tunnel. Once you have added the tunnel, you cannot change the Tunnel ID.
Tunnel operational state	Displays the current operational state of the tunnel (Up or Down).
Tunnel source IP address	Reserved for future use.
Tunnel source MAC address	The source MAC address for the tunnel.
Remote MAC address	The MAC address of the interface or card at the other site of the link. This is only relevant for Ethernet (MEF-8) tunnels.

Deleting a Tunnel

To delete a tunnel:

- 1 Select the tunnel you want to delete.
- 2 Click **Delete**. The tunnel is deleted.



Note

You cannot delete a tunnel that is assigned to a tunnel group or a pseudowire TDM service.

Configuring a Tunnel Group

This section includes:

- [TDM Pseudowire Path Protection Overview](#)
- [Viewing Tunnel Groups](#)
- [Configuring the Revertive Timer](#)
- [Adding a Tunnel Group](#)
- [Editing a Tunnel Group](#)
- [Deleting a Tunnel Group](#)

TDM Pseudowire Path Protection Overview

TDM pseudowire path protection enables you to define two separate network paths for a single TDM pseudowire service. Each path has the same destination address, but traffic flows to the destination via different paths.

TDM pseudowire path protection requires the use of SOAM (CFM) at both end-points. The TDM interface sends two data streams to the COY. Only the data stream for the active path contains actual traffic. Both data streams contain continuity messages (CCMs). This enables the TDM interface to monitor the status of both paths without doubling the amount of data being sent over the network. The TDM interface determines when a switchover is necessary based on the monitored network status.

In order to achieve path protection, different provisioning should be made for the Ethernet service corresponding to each of the two data streams. In order to do this, it is recommended to map the corresponding Ethernet services to MSTP instance number 63, which is meant for Traffic Engineering (ports are always forwarding) and to map the two different transport VLANs over two different paths.

TDM path protection uses CFM to monitor the network paths. Because SOAM (CFM) is configured on the TDM interface level, the TDM interface can determine the status of the entire network path, up to and including the interface itself.

To configure a TDM service with path protection, you must perform the following steps:

- Configure a Maintenance Domain – see [Configuring Pseudowire Maintenance Domains \(MDs\)](#)
- Configure Maintenance Associations (MAs) – see [Configuring Pseudowire Maintenance Associations \(MAs\)](#)
- Configure PSN Tunnels and Assign to them MAs – see [Configuring a Tunnel](#)
- Configure a TDM Tunnel Group – see below

TDM pseudowire path protection is implemented by combining two TDM tunnels into a single tunnel group. One of the tunnels in the group is designated as the primary tunnel. The other tunnel is designated as the secondary tunnel. CCM messages are sent from the TDM interface to the CPU via both tunnels. However, only the primary tunnel sends actual traffic. The CPU monitors both paths using the CCM messages, and determines when to perform a switchover from the primary tunnel to the secondary tunnel.

Viewing Tunnel Groups

To view all the tunnel groups configured for the unit:

- 1 Select **TDM > TDM PseudoWire > Advanced > PSN Tunnels > Tunnel Groups**. The PseudoWire Tunnel Groups page opens.

Figure 331 Pseudowire Tunnel Groups Page




Table 107 Pseudowire Tunnel Group Parameters

Parameter	Definition
Tunnel group ID	A unique ID that identifies the tunnel group.
Admin	Displays the administrative state of the tunnel group (Enabled or Disabled).
Primary Tunnel ID	The primary tunnel.
Secondary Tunnel ID	The secondary tunnel.
Revertive mode admin	Indicates whether revertive mode is enabled or disabled for the tunnel group. See Configuring the Revertive Timer .
Operational state	Displays the current operational state of the tunnel group (Up or Down).
Active Tunnel	Displays the ID of the tunnel that is currently in active mode.
Number of switches	Displays the number of protection switches that have taken place since the last system reset or creation of the group.
Revertive countdown	In the event that a switchover to the protecting path has taken place and revertive timer is enabled for the tunnel group, this column indicates the time remaining, in seconds, before reversion to the primary path will take place. See Configuring the Revertive Timer .

Configuring the Revertive Timer

Path protection can be configured to operate in revertive mode. In revertive mode, the system monitors the availability of the protected path at all times. After switchover to the protecting path, once the active path is operational and available without any alarms, the system waits for the duration of the user-configured Wait to Restore (WTR) time and then, if the active path remains operational and available, initiates a revertive protection switch. A single WTR time is configured for all the TDM pseudowire services in the system. However, services with path protection can be configured individually as revertive or non-revertive. You can configure this when you configure the tunnel group, as explained below.



Note

TDM pseudowire services with 1:1 path protection that were configured using software versions prior to T7.9 are non-revertive.

To set the WTR time for TDM pseudowire services with revertive path protection:

- 1 In the Revertive Timer Configuration area at the top of the Pseudowire Tunnel Groups page (Figure 331), enter the number, in seconds, for the WTR time. The default value is 10 seconds.
- 2 Click **Apply**.

Adding a Tunnel Group

To add a tunnel group:

- 1 In the **Select a slot** field, select the TDM card to which you want to add the tunnel group.
- 2 Click **Add**. The PseudoWire Tunnel Groups – Add page opens.

Figure 332 PseudoWire Tunnel Groups – Add Page

- 3 In the **Tunnel Group ID** field, select a unique ID to identify the tunnel group.
- 4 In the **Admin** field, select **Enable** to enable the tunnel group, or **Disable** if you want to add the tunnel group but enable it at a later time.
- 5 In the **Primary Tunnel ID** field, enter the ID of the tunnel you want to assign as the primary tunnel.

- 6 In the **Secondary Tunnel ID** field, enter the ID of the tunnel you want to assign as the secondary tunnel.
- 7 In the **Revertive mode admin** field, select **Enable** or **Disable** to determine whether services using the tunnel group will use revertive mode. See [Configuring the Revertive Timer](#).
- 8 Click **Apply**, then **Close**.

In the event that a switchover to the protecting path has taken place and revertive timer is enabled for the tunnel group, the **Revertive Countdown** field column displays the time remaining, in seconds, before reversion to the primary path will take place. See [Configuring the Revertive Timer](#).

Editing a Tunnel Group

To edit a tunnel group:

- 1 Select the tunnel you want to edit.
- 2 Click **Edit**. The PseudoWire Tunnel Groups – Edit page opens. You can edit any of the tunnel group parameters you can configure when you add a tunnel except the **Tunnel group ID** field.
- 3 Edit the tunnel group parameters, as described above.
- 4 Click **Apply**, then **Close**.



Note

To edit the other parameters of a tunnel group, you must first set **Admin** to **Disable** and click **Apply**.

Deleting a Tunnel Group

To delete a tunnel group:

- 1 Select the tunnel you want to delete.
- 2 Click **Delete**. The tunnel group is deleted.



Note

You cannot delete a tunnel group that is assigned to a pseudowire TDM service.

Configuring Pseudowire Profiles

Each TDM service must include a TDM profile. The profile determines the behavior of the service, including the buffer, payload suppression, and other parameters. A profile can be used by multiple services.

You can configure up to 64 TDM profiles.

This section includes:

- [Viewing a Pseudowire Profile](#)
- [Adding a Pseudowire Profile](#)
- [Editing a Pseudowire Profile](#)
- [Deleting a Pseudowire Profile](#)

Viewing a Pseudowire Profile

To view all the pseudowire profiles configured for the unit:

- 1 Select **TDM > TDM PseudoWire > Advanced > Profiles**. The PseudoWire Profiles page opens.

Figure 333 PseudoWire Profiles Page




Table 108 describes the pseudowire profile parameters.

Table 108 Pseudowire Profile Parameters

Parameter	Definition
Profile ID	Enter unique ID, from 1 to 64, that identifies the profile. Once you add the profile, you cannot edit this field.
Payload Size	Enter the number of times E1/DS1 should be sampled for each Ethernet packet.
Jitter Buffer Depth	Enter the desired jitter buffer depth (from 1 to 32, in milliseconds). This is used to enable the network to accommodate PSN-specific packet delay variation. The jitter buffer can be increased if the network experiences a higher-than-normal level of jitter.

Parameter	Definition
Payload Suppression Admin	Select Enable or Disable to enable or disable payload suppression. When enabled, the payload is suppressed upon incoming TDM failure.
Payload Type	Enter a value between 96 and 127. This value is used to distinguish between signaling and data types. The default value is 96.
Timeslot Fill Pattern	Enter the byte pattern transmitted on DS0 channels when packets overflow or underflow the jitter buffer (from 0 to 255).
CAS Alarm Bit Pattern	Enter the CAS alarm pattern transmitted on the E1/DS1 interface when packets overflow or underflow the jitter buffer (from 0 to 15).
RTP Header Use	Reserved for future use.
RTP Timestamp Mode	Reserved for future use.
RTP Timestamp Factor	Reserved for future use.
LOPS Detection Admin	Select Enable or Disable to enable or disable loss of packet synchronization (LOPS) detection. The default value is Enable .
Consecutive Sequential Packets Threshold	Enter the number of consecutive packets with sequential sequence numbers required in order for the system to exit a loss of packet synchronization state (LOPS), from 1 to 10. The default value is 2.
Consecutive Missing Packets Threshold	Enter the number of consecutive missing packets required in order for the system to enter a loss of packet synchronization state (LOPS), from 1 to 15. The default value is 2.
Packet Loss Window	Enter the time period (in milliseconds) the system uses to compute the average packet loss rate in order to detect excessive packet loss (1-65535). The default value is 3000.
Excessive Packet Loss Threshold	Enter the alarm threshold (in percentage) for excessive packet loss (1-100). The default value is 50.
Alarm Raise Threshold	Enter the amount of time (in milliseconds) the system waits after a fault condition exists before raising an alarm (1-65535). The default value is 2500.
Alarm Clear Threshold	Enter the time (in milliseconds) the system waits before clearing an alarm once the alarm condition has ended (1-65535). The default value is 10000.
SES Threshold	Enter the percentage of missing packets detected within a one second window that will cause SES to be counted.

Adding a Pseudowire Profile

To add a pseudowire profile:

- 1 In the PseudoWire Profiles page (Figure 333), click **Add**. The PseudoWire Profiles – Add page opens.

Figure 334 PseudoWire Profiles – Add Page

Parameter	Value	Unit
Profile ID	3	
Payload size	16	
Jitter buffer depth	9	
Payload suppression admin	Disable	
Payload type	96	
Timeslot fill pattern	255	
CAS alarm bit pattern	15	
RTP header use	Disable	
RTP timestamp mode	Absolute	
RTP timestamp factor	1	(1..65535)
LOPS detection admin	Enable	
Consecutive sequential packets threshold	2	
Consecutive missing packets threshold	2	
Packet loss window	3000	(1..65535)
Excessive packet loss threshold	50	
Alarm raise threshold	2500	(1..65535)
Alarm clear threshold	10	(1..65535)
SES threshold	30	

Buttons: Apply, Refresh, Close

- 2 Configure the pseudowire profile parameters, described in *Table 108*.
- 3 Click **Apply**, then **Close**.

Editing a Pseudowire Profile

To edit a pseudowire profile:

- 1 In the PseudoWire Profiles page (Figure 333), select the profile you want to edit and click **Edit**. The PseudoWire Profiles – Edit page opens.
- 2 Edit the pseudowire profile parameters, described in *Table 108*. You can edit any of the parameters you can configure when you add a profile except the **Profile ID** field.
- 3 Click **Apply**, then **Close**.

Deleting a Pseudowire Profile

To delete a pseudowire profile:

- 1 In the PseudoWire Profiles page (Figure 333), select the profile you want to delete.

- 2 Click **Delete**. The profile is deleted.
-

**Note**

You cannot delete a tunnel group that is assigned to a pseudowire TDM service.

Configuring Pseudowire TDM Services Manually

For PTP 820F and PTP 820G, you can configure up to 16 TDM pseudowire services per unit.



Note

Once a profile, tunnel, or bundle has been assigned to a service, you cannot modify that profile, tunnel, or bundle until you first disable the service.

This section includes:

- [Viewing Pseudowire TDM Services](#)
- [Adding a Pseudowire TDM Service](#)
- [Editing a Pseudowire TDM Service](#)
- [Viewing the Status of a Pseudowire TDM Service](#)
- [Deleting a Pseudowire TDM Service](#)

Viewing Pseudowire TDM Services

To view all the pseudowire TDM services configured for a TDM card:

- 1 Select **TDM > TDM PseudoWire > Advanced > Services**. The PseudoWire Services page opens. [Table 109](#) describes the pseudowire TDM service parameters.

Figure 335 PseudoWire Services Page

Microwave radio: PseudoWire Services

Select a slot: Slot 1: E1/DS1 1-16

Service ID	Admin state	Service type	Tunnel type	TDM interface	TDM port / Bundle ID	PW profile ID	Tunnel ID or Tunnel Group ID	Clock recovery master	Source Tunnel Identifier	Destination Tunnel Identifier	Path protection mode
1	Enable	SAToP	Eth	TDM: Slot 1, port 1	1	1	1	Yes	1	1	No
2	Disable	SAToP	Eth	TDM: Slot 1, port 2	2	1	1	Yes	2	2	yes
3	Enable	SAToP	Eth	TDM: Slot 1, port 3	3	1	2	Yes	4	4	yes

Buttons: Add, Edit, Delete, Service Status, Refresh

Table 109 Pseudowire TDM Service Parameters

Parameter	Definition
Service ID	A unique ID that identifies the service. Once you have added the service, you cannot change the Service ID. Options are 1-16.
Admin State	Select one of the following options: <ul style="list-style-type: none"> • Enable – The service is functional. • Disable – The service is disabled until this parameter is changed to Enabled. In this mode, the service occupies system resources but is unable to receive and transmit data.
Service Type	Select the pseudotype protocol you want to use for the service: <ul style="list-style-type: none"> • E1 SAToP – Service uses SAToP protocol • CESoPSN – Service uses CESoP protocol without CAS signaling • CAS-CESoPSN – Service uses CESoP protocol with CAS signaling. Only SAToP is supported in this release.
Tunnel Type	Select the encapsulation type to use with the service. Options are: <ul style="list-style-type: none"> • UDP/IP – UDP/IP • Eth – MEF-8 Only Eth is supported in this release.
TDM Interface	Select the TDM port to use with the service.
TDM Port/ Bundle ID	Reserved for future use.
PW Profile ID	Select the TDM profile to use with the service. The TDM profile determines the behavior of the TDM service, including the buffer, payload suppression, and other parameters. A profile can be used by multiple TDM services. You can define up to 64 TDM profiles for the unit in the PseudoWire Profiles page. See Configuring Pseudowire Profiles .
Tunnel ID or Tunnel Group ID	Select the TDM tunnel or tunnel group to use with the service. The tunnel determines how traffic over the service passes through the network. In this version, encapsulation must use the MEF-8 protocol. Up to 16 tunnels can be configured. TDM tunnels are configured in the PseudoWire Tunnels page. Tunnel groups are configured in the Tunnel Groups page. See Configuring Pseudowire Tunnels and Tunnel Groups .
Clock Recovery Master	Select Enable to use this service as a reference for clock recovery. Otherwise, select Disable .
Source Tunnel Identifier	Enter the source ECID for the Ethernet tunnel. Note: The ECID must be unique for each service.
Destination Tunnel Identifier	Enter the destination ECID for the Ethernet tunnel.

Parameter	Definition
Path Protection Mode	If you are creating a service with path protection, select Yes . If you are creating a service without path protection, select No . If you select Yes , the Tunnel ID must be the ID of a Tunnel Group. For instructions on creating a tunnel group, see Configuring a Tunnel Group .

Adding a Pseudowire TDM Service

To add a pseudowire TDM service:

- 1 Click **Add**. The PseudoWire Services – Add page opens.

Figure 336 PseudoWire Services – Add Page

PseudoWire Services - Add

PW service configuration table - Add

Shelf slot ID Slot 1: E1/DS1 1-16

Service ID 4

Admin state Disable

Service type SAToP

Tunnel type Eth

TDM interface TDM: Slot 1, port 1

PW profile ID 1

Tunnel ID or Tunnel Group ID 1

Clock recovery master No

Source Tunnel Identifier 0 (0..1048575)

Destination Tunnel Identifier 0 (0..1048575)

Path protection mode No

Apply Refresh Close

- 2 Configure the pseudowire service parameters, described in [Table 109](#).
- 3 Click **Apply**, then **Close**.

Editing a Pseudowire TDM Service

To edit a pseudowire service:

- 1 Select the service you want to edit.
- 2 Click **Edit**. The PseudoWire Services – Edit page opens. You can edit any of the service parameters you can configure when you add a service except the **Service ID** field.
- 3 Edit the service parameters, as described above.
- 4 Click **Apply**, then **Close**.

Viewing the Status of a Pseudowire TDM Service

To view the operational status of a service and the service's statistics:

- 1 Select the service you want to view.
- 2 Click **Service Status**. The PseudoWire Services – Information page opens.

Figure 337 PseudoWire Services – Information Page




Table 110 describes the pseudowire TDM service status parameters. To clear the statistics, click **Clear Statistics** at the bottom of the page.

Table 110 Pseudowire TDM Service Status Parameters

Parameter	Definition
Shelf Slot ID	Slot 1.
Service ID	A unique ID that identifies the service. Once you have added the service, you cannot change the Service ID.
Operational Status	Displays the current operational state of the service (Up or Down). If no traffic is currently passing through the service, the Operational Status displays Down . This does not necessarily mean there is anything wrong with the unit or the configuration of the service.
Tx Packets	The number of transmitted packets.
Rx Packets	The number of received packets.
LOPS Transitions	The number of transitions from normal state to Loss of Packet Synchronization (LOPS) state.
Jitter Buffer Overruns	The number of jitter buffer overruns.
Jitter Buffer Deviations	The maximum jitter buffer deviation.
Minimum Jitter Buffer Count	The minimum jitter buffer usage registered for the previous second.

Parameter	Definition
Maximum Jitter Buffer Count	The maximum jitter buffer usage registered for the previous second.

Deleting a Pseudowire TDM Service

To delete a pseudowire TDM service:

- 1 Select the service you want to delete.
- 2 Select the service.
- 3 Click **Edit**, and set the **Admin State** of the service to **Disable**.
- 4 Click **Apply**, then **Close**.
- 5 Select the service.
- 6 Click **Delete**. The service is deleted.

Displaying TDM PMs

This section includes:


- [Displaying E1/DS1 PMs](#)
- [Displaying Native TDM Service PMs](#)
- [Displaying Pseudowire Service PMs](#)

Displaying E1/DS1 PMs

To display PMs for all E1/DS1s in the system:

- 1 Select **TDM > PM & Statistics > E1/DS1**. The E1/DS1 PM page opens.

Figure 338 E1/DS1 PM Page



- 2 In the **Interface** field, select the port for which you want to display PMs.
- 3 In the **Interval Type** field, select:
 - To display reports in 15-minute intervals, select **15 minutes**.
 - To display reports in daily intervals, select **24 hours**.

[Table 111](#) describes the E1/DS1 PMs.


Table 111 E1/DS1 PMs

Parameter	Definition
ES	Indicates the number of seconds during which errors occurred.
SES	Indicates the number of seconds during which severe errors occurred.
UAS	Indicates the Unavailable Seconds value of the current interval. The value can be between 0 and 900 seconds (15 minutes).

Parameter	Definition
Integrity	Indicates whether the values received at time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

To display the PMs in a graph format, click **Graph**.

Figure 339 E1/DS1 PM Page – Graph Format




Displaying Native TDM Service PMs

To display PMs for all Native TDM services defined in the system:

- 1 Select **TDM > PM & Statistics > Service**. The Services PM page opens.

Figure 340 Services PM Page (Native TDM Services)



- 2 In the **Service** field, select a service.
- 3 In the **Interval Type** field, select:
 - o To display reports in 15-minute intervals, select **15 minutes**.
 - o To display reports in daily intervals, select **24 hours**.


Table 112 describes the Native TDM Service PMs.

Table 112 Native TDM Service PMs

Parameter	Definition
ES	Indicates the number of seconds during which errors occurred.
SES	Indicates the number of seconds during which severe errors occurred.
UAS	Indicates the Unavailable Seconds value of the current interval. The value can be between 0 and 900 seconds (15 minutes).
FC	Indicates the number of LOPS (Loss of Packets) events during the current interval.
Integrity	Indicates whether the values received at time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

To display the PMs in a graph format, click **Graph**.

Figure 341 Native TDM Services Page – Graph Format




Displaying Pseudowire Service PMs

To display PMs for all pseudowire TDM services defined in the system:

- 1 Select **TDM > TDM PseudoWire > Advanced > PM > Service**. The Services PM page opens.

Figure 342 Services PM Page (Pseudowire TDM Services)



- 2 In the **Service** field, select a service.
- 3 In the **Interval Type** field, select:
 - o To display reports in 15-minute intervals, select **15 minutes**.
 - o To display reports in daily intervals, select **24 hours**.

Table 113 describes the Pseudowire TDM Service PMs.


Table 113 Pseudowire TDM Service PMs

Parameter	Definition
ES	Indicates the number of seconds during which errors occurred.
SES	Indicates the number of seconds during which severe errors occurred.

Parameter	Definition
UAS	Indicates the Unavailable Seconds value of the current interval. The value can be between 0 and 900 seconds (15 minutes).
FC	Indicates the number of LOPS (Loss of Packets) events during the current interval.
FER	Indicates the number of LOPS (Loss of Packets) events during the current interval.
Missing packets	Indicates the number of packets that never reached the service endpoint during the current interval.
Packets reorder	Indicates the number of packets that arrived out of order but could be recovered during the current interval.
Misordered and Dropped Packets	Indicates the number of packets that arrived out of order and could not be recovered during the current interval.
Malformed Packets	Indicates the number of packets that were detected as having an unexpected size or a bad header stack during the current interval.
Integrity	Indicates whether the values received at time and date of the measured interval are reliable. An x in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.

To display the PMs in a graph format, click **Graph**.

Figure 343 Pseudowire TDM Services Page – Graph Format



Chapter 10: Synchronization

This section includes:

- [Configuring the Sync](#)
- [Configuring the Outgoing Clock and SSM Message](#)
- [Configuring 1588 Transparent Clock](#)
- [Configuring the 1588 Boundary Clock](#)

**Note**

By default, the unit is set to operate according to the ETSI standard. For instructions on configuring the system to operate according to the ANSI (FCC) standard (DS1), see [TDM Overview \(CLI\)](#).

Configuring the Sync Source

Frequency signals can be taken by the system from Ethernet and radio interfaces.

The reference frequency may also be conveyed to external equipment through different interfaces. For instructions how to configure the outgoing clock, see [Configuring the Outgoing Clock and SSM Messages](#).

Frequency is distributed by configuring the following parameters in each node:

- System Synchronization Sources – These are the interfaces from which the frequency is taken and distributed to other interfaces. Up to 16 sources can be configured in each node. A revertive timer can be configured. For each interface, you must configure:
 - **Priority (1-16)** – No two synchronization sources can have the same priority.
 - **Quality** – The quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source.
- Each unit determines the current active clock reference source interface:
 - The interface with the highest available quality is selected.
 - From among interfaces with identical quality, the interface with the highest priority is selected.



Note

You can configure a revertive timer for the PTP 820G or PTP 820F unit. When the revertive timer is configured, the unit will not switch to another synchronization source unless that source has been stable for at least the number of seconds defined in the revertive timer. This helps to prevent a situation in which numerous switchovers occur when a synchronization source reports a higher quality for a brief time interval, followed by a degradation of the source's quality. By default, the revertive timer is set to 0, which means that it is disabled. Configuration of the revertive timer must be performed via CLI. See [Configuring the Revertive Timer \(CLI\)](#).

When configuring the Sync source, the Sync mode must be set to its default setting of automatic. To display the current Sync mode, enter the following CLI command in root view:

```
root> platform sync mode show
```

If the Sync mode is set to pipe, you must set it to automatic by entering the following CLI command in root view:

```
root> platform sync mode set automatic
```

When configuring an Ethernet interface as a Sync source, the Media Type of the interface must be RJ45 or SFP, *not* Auto-Type. To view and configure the Media Type of an Ethernet interface, see [Configuring Ethernet Interfaces](#).

Viewing the Sync Source Status

To view the current sync source and its quality:

1. Select **Sync > Sync Source**. The Sync Source page opens. **Figure 344** Sync Source Page




Table 114 lists and defines the sync source status parameters.


Table 114 Sync Source Parameters

Parameter	Definition
System Reference Quality	The quality of the current synchronization source interface. A value of DNU indicates that no synchronization source interfaces are currently defined.
Current Active Sync Source	The currently active system synchronization source interface.
Sync clock unit status	The status of the unit’s Sync E mechanism.
Sync Interface	Displays the interface that is configured as a synchronization source.
Sync Interface Quality	Displays the quality level assigned to this synchronization source. This enables the system to select the source with the highest quality as the current synchronization source. If the Sync Interface Quality is set to Automatic , the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes "Failure." SSM must be enabled on the remote interface in order for the interface to receive SSM messages. For instructions how to enable SSM, see Configuring the Outgoing Clock and SSM Messages .
Sync Interface Priority	Displays the priority assigned to this synchronization source.
Sync Interface Quality Status	Displays the current actual synchronization quality of the interface.

Adding a Sync Source

To add a synchronization source:

- 1 In the Sync Source page ([Figure 344](#)), click **Add**. The Sync Source – Add page opens.

Figure 345 Sync Source – Add Page

- 2 In the **Sync Interface** field, select the interface you want to define as a synchronization source. You can select from the following interface types:
 - **Ethernet interfaces** – You can use Ethernet interfaces, including Cascading interfaces.
 - **Radio interfaces** – You can use any radio interface.

**Note**

In order to select an Ethernet interface, you must first specify the media type for this interface. See [Configuring Ethernet Interfaces](#).

- 3 In the **Sync Interface Quality** field, select the quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source.
 - If the **Sync Interface Quality** is set to **Automatic**, the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes **Failure**. SSM must be enabled on the remote interface in order for the interface to receive SSM messages. For instructions how to enable SSM, see [Configuring the Outgoing Clock and SSM Messages](#).
 - If the **Sync Interface Quality** is set to a fixed value, then the quality status becomes **Failure** upon interface failure (such as LOS, LOC, LOF).
- 4 In the **Sync Interface Priority** field, select the priority of this synchronization source relative to other synchronization sources configured in the unit (1-16). You cannot assign the same priority to more than one synchronization source. Once a priority value has been assigned, it no longer appears in the **Sync Interface Priority** dropdown list.
- 5 Click **Apply**, then **Close**.

Editing a Sync Source

To edit a synchronization source:

- 1 In the Sync Source page ([Figure 344](#)), click **Edit**. The Sync Source – Edit page opens.
- 2 Edit the parameters, as defined above. You can edit all the parameters except **Sync Interface**, which is read-only.
- 3 Click **Apply**, then **Close**.

Deleting a Sync Source

To delete a synchronization source:

- 1 Select the synchronization source in the Sync Source page ([Figure 344](#)).
- 2 Click **Delete**. The synchronization source is deleted.

Configuring the Outgoing Clock and SSM Messages

In the Outgoing Clock page, you can view and configure the following synchronization settings per interface:

- The interface's clock source (outgoing clock).
- For radio interfaces, the synchronization radio channel (used for interoperability).
- SSM message administration.

In order to provide topological resiliency for synchronization transfer, PTP 820G and PTP 820F implements the passing of SSM messages over the radio interfaces. SSM timing in PTP 820G and PTP 820F complies with ITU-T G.781.

In addition, the SSM mechanism provides reference source resiliency, since a network may have more than one source clock. The following are the principles of operation:

- At all times, each source interface has a “quality status” which is determined as follows:
 - If quality is configured as fixed, then the quality status becomes “failure” upon interface failure (such as LOS, LOC, LOF).
 - If quality is automatic, then the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes “failure.”
- Each unit holds a parameter which indicates the quality of its reference clock. This is the quality of the current synchronization source interface.
- The reference source quality is transmitted through SSM messages to all relevant radio interfaces.
- In order to prevent loops, an SSM with quality “Do Not Use” is sent from the active source interface (both radio and Ethernet)

In order for an interface to transmit SSM messages, SSM must be enabled on the interface. By default, SSM is disabled on all interfaces.

When configuring the outgoing clock and SSM administration, the Sync mode must be set to its default setting of automatic. To display the current Sync mode, enter the following CLI command in root view:


```
root> platform sync mode show
```

If the Sync mode is set to pipe, you must set it to automatic by entering the following CLI command in root view:

```
root> platform sync mode set automatic
```

To configure the outgoing clock on an Ethernet interface, the Media Type of the interface must be RJ45 or SFP, *not* Auto-Type. To view and configure the Media Type of an Ethernet interface, see *Configuring Ethernet Interfaces*. To view and configure the synchronization parameters of the unit's interfaces:


- 1 Select **Sync > Outgoing Clock**. The Outgoing Clock page opens.

Figure 346 Outgoing Clock Page

- 2 Select the interface you want to configure and click **Edit**. The Outgoing Clock – Edit page opens.

**Note**

You cannot edit the clock source of E1/DS1 interfaces.

Figure 347 Outgoing Clock – Edit Page

- 3 In the **Outgoing clock source** field, select the interface's synchronization source. Options are:
 - o **Local Clock** – The interface uses its internal clock as its synchronization source.
 - o **System Clock** – Default value. The interface uses the system clock as its synchronization source.
 - o **Source Interface** – Reserved for future use.
 - o **Time Loop** – Reserved for future use.
- 4 The **Sync Radio Channel** field is only relevant for radio interfaces. Select a synchronization channel to use for interoperability:
 - o For interoperability with other PTP 820G or PTP 820F units, use the default value of 0.
 - o For non-radio interfaces, use the default value of 0.

- 5 In the **SSM Admin** field, select **On** or **Off** to enable or disable SSM for the interface. By default, SSM is disabled on all interfaces. On radio interfaces, SSM messages with the quality DNU (Do not Use) are sent when SSM Admin is set to **Off**.

Configuring 1588 Transparent Clock

**Note**

This section is only relevant for PTP 820G

PTP 820G uses 1588v2-compliant Transparent Clock to counter the effects of delay variation. Transparent Clock measures and adjusts for delay variation, enabling the PTP 820G to guarantee ultra-low PDV.

A Transparent Clock node resides between a master and a slave node, and updates the timestamps of PTP packets passing from the master to the slave to compensate for delay, enabling the terminating clock in the slave node to remove the delay accrued in the Transparent Clock node. The Transparent Clock node is itself neither a master nor a slave node, but rather, serves as a bridge between master and slave nodes.

Note that in release 10.0:

- 1588 TC is not supported when Master-Slave communication is using the IPv6 transport layer.
 - 1588 TC cannot be used on 1+1 HSB links.
 - 1588 TC is not supported with Frame Cut-Through.
-


**Note**

Make sure to enable Transparent Clock on the remote side of the link before enabling it on the local side.

To configure Transparent Clock:


1. Add the port receiving synchronization from the customer side as a Sync source. See [Adding a Sync Source](#).
2. Add a radio interface as a Sync source, with lower priority than the port receiving synchronization from the customer side. See [Adding a Sync Source](#).
3. On the remote side of the radio link, add the radio interface facing the local device as a Sync source, with Sync Interface Priority 1. See [Adding a Sync Source](#)
4. On the remote side of the radio link, if there is an Ethernet port conveying synchronization, add this port as a Sync source, with lower priority than the radio interface. See [Adding a Sync Source](#)
5. Verify that the Sync Interface Quality Status of the first Sync source is not Failure. See [Viewing the Sync Source Status](#).
6. Select **Sync > 1588-TC**. The 1588-TC page opens.

Figure 348 1588-TC Page



7. In the **TC admin** field, select **Enable**.
8. Click **Apply**.
9. Select a radio and click **Edit**. The 1588-TC – Edit page opens.

Figure 349 1588-TC – Edit Page



10. In the **Port direction** field, select **Upstream** or **Downstream**. This field must be set to different values on the two sides of the link. If you set the local side to **Upstream**, you must set the remote side to **Downstream**, and vice versa.

**Note**

This parameter must be set to **Upstream** on one side of the 1588 link and **Downstream** on the other.

11. Click **Apply**, then **Close**.
12. 1588 packets should be mapped to CoS 7. By default, 1588 packets are *not* mapped to any CoS. To map 1588 packets to CoS 7, you must *disable* CoS preservation for 1588 packets. This must be performed via CLI, using the following command:

```
root> ethernet generalcfg ptp-tc cos-preserve set admin disable
```

13. To map 1588 packets to CoS 7, enter the following command:

```
root> ethernet generalcfg ptp-tc cos-preserve cos value 7
```

After you enter these commands, 1588 packets will automatically be mapped to CoS 7.

**Note**

If necessary, you can use the `ethernet generalcfg ptp-tc cos-preserve cos value` command to map a different CoS value (0-7) to 1588 packets, but it is recommended to map 1588 packets to CoS 7.

Configuring 1588 Boundary Clock

**Note**

This section is only relevant for PTP 820G. 1588 Boundary Clock for PTP 820F is planned for future release.

IEEE-1588v2 Boundary Clock enables the PTP 820 to regenerate phase synchronization via standard Ethernet. Boundary Clock complies with ITU-T Telecom Profile G.8275.1. This enables PTP 820, with Boundary Clock, to meet the rigorous synchronization requirements of LTE-Advanced (LTE-A) networks.

The Boundary Clock in PTP 820 supports up to four 1588 slave clock devices.

The Boundary Clock terminates the PTP flow it receives on the slave port, recovers the time and phase, and regenerates the PTP flow on the master ports.

The Boundary Clock node selects the best synchronization source available in the domain and regenerates PTP towards the slave clocks. This reduces the processing load from grandmaster clocks and increases the scalability of the synchronization network, while rigorously maintaining timing accuracy.

The PTP 820 Boundary Clock mechanism requires the use of untagged Ethernet multicast PTP packets.

**Note**

Boundary Clock and Transparent Clock can be used together in the same PTP 820 node.

Note that in System Release 10.0:

- 1588 BC cannot be configured on interface groups, such as LAG and Multi-Carrier ABC.
- 1588 BC can only be used in a chain or star topology. It cannot be used in a ring topology.
- 1588 BC is not supported when Master-Slave communication is using the IPv6 transport layer.
- 1588 BC is not supported with RMC-A
- 1588 BC cannot be used on 1+1 links.
- 1588 BC is not supported with Frame Cut-Through

Enabling Boundary Clock

**Note**

Before configuring Boundary Clock, you must configure Transparent Clock. See *Configuring 1588 Transparent Clock*.

To enable Boundary Clock:

1. Select **Sync > 1588 > General Configuration**. The 1588 – General Configuration page opens.
2. In the **1588 PTP** field, select **Enable**.
3. Click **Apply**.

4. Select **Sync > 1588 > Boundary Clock > Port Parameters**. The 1588 Boundary Clock – Port Parameters page opens. You can configure up to four interfaces per unit to be part of the Boundary Clock node. These interfaces can be radio and Ethernet interfaces, but not TDM interfaces or groups (e.g., LAG or Multi-Carrier ABC groups).

Figure 350 1588 Boundary Clock – Port Parameters Page

Microwave radio: 1588 Boundary Clock - Port Parameters

▼ 1588 Boundary Clock - Port Parameters

Interface location ▲	Admin	Master Only	Local Priority	Destination Mac Address	Port State
Ethernet: Slot 1, Port 3	Enable	Yes	128	01:1B:19:00:00:00	Master
Ethernet: Slot 1, Port 4	Disable	Yes	128	01:1B:19:00:00:00	Initializing
Ethernet: Slot 1, Port 5	Disable	Yes	128	01:1B:19:00:00:00	Initializing
Ethernet: Slot 1, Port 6	Disable	Yes	128	01:1B:19:00:00:00	Initializing

Edit

5. Select an interface and click **Edit**. The 1588 Boundary Clock – Port Parameters – Edit page opens.

Figure 351 1588 Boundary Clock – Port Parameters – Edit Page

1588 Boundary Clock - Port Parameters - Edit

Interface location: Ethernet: Slot 1, Port 3

Admin: Enable

Master Only: Yes

Local Priority: 128

Destination Mac Address: 01:1B:19:00:00:00

Clock Identity: 00:0A:25:FF:FE:40:1F:93

Port Number: 1

Port State: Master

Log Min DelayReq Interval: -4 (16 pps)

Log Announce Interval: -3 (8 pps)

Announce Receipt Timeout: 8

Log Sync Interval: -4 (16 pps)

Delay Mechanism: 1

Version Number: 2

Apply

Last Loaded: 12:24:43 Refresh Close

110%

6. In the **Admin** field, select **Enable**.
7. In the **Master Only** field, select from the following options:
 - **Yes** – The port can only be used as the master port, which means the port acts as a PTP synchronization source for other nodes.
 - **No** – The port can be used as either a master port or the slave port. The slave port receives PTP synchronization input from an external grandmaster clock. The Best Master Clock Algorithm (BMCA) determines the port's role, based on its determination of which is the best available grandmaster clock. Only one slave port can exist in a single PTP 820 node at any one time.
8. Optionally, in the **Local Priority** field, select a value between 1-255. The default value is 128. The Local Priority value is taken into account when two identical announce messages are received by at least two different ports. In such a case, the Boundary Clock mechanism selects the slave port based on the best (lowest) Local Priority.
9. In the **Destination Mac Address** field, select a MAC address for multicast re-transmission of PTP packets. Options are:

- 01-1B-19-00-00-00 – General group address. An 802.1Q VLAN Bridge would forward the frame unchanged.
 - 01-80-C2-00-00-0E – Individual LAN Scope group address. An 802.1Q VLAN Bridge would drop the frame.
10. Click **Apply**.
 11. Repeat these steps to add up to four interfaces to the unit's Boundary Clock node.
 12. To map PTP packets into the Boundary Clock node, a service point must be created on each interface in the Boundary Clock node. This service point must be defined to gather untagged packets. See *Adding a Service Point*.
 13. Add a port receiving synchronization from the customer side as a Sync source, with Sync Interface Priority 1. See *Adding a Sync Source*.
 14. Add a radio interface as a Sync source, with lower priority than the port receiving synchronization from the customer side. See *Adding a Sync Source*.
 15. On the remote side of the radio link, add the radio interface facing the local device as a Sync source, with Sync Interface Priority 1. See *Adding a Sync Source*.
 16. On the remote side of the radio link, if there is an Ethernet port conveying synchronization, add this port as a Sync source, with lower priority than the radio interface. See *Adding a Sync Source*.
 17. Verify that the Sync Interface Quality Status of the first Sync source is not Failure. See *Viewing the Sync Source Status*.

Displaying and Setting the Boundary Clock Default Parameters

To display and set the Boundary Clock default parameters:

1. Select **Sync > 1588 > Boundary Clock > Clock Parameters > Default**. The 1588 Boundary Clock – Clock Default Parameters page opens.

Figure 352 1588 Boundary Clock – Clock Default Parameters Page

Test Unit: 1588 Boundary Clock - Clock Default Parameters	
Clock Default Parameters	
Two Step	Yes
Clock Identity	00:0A:25:FF:FE:38:09:4B
Number Of Ports	4
Clock Class	187
Clock Accuracy	Worse than 10 seconds
Offset Scaled Log Variance	52592
Slave Only	No
Priority 1	128
Priority 2	128
Domain Number	24
Local Priority	128
Max Step removed	255
Apply	

2. In the **Priority 2** field, you can select a value between 0 and 255. The default value is 128. The Priority 2 value is one of the factors used by the BMCA to determine the grandmaster. The PTP 820's Boundary Clock node advertises this value when it is not locked on an external grandmaster.
3. In the **Domain Number** field, you can select a value between 24 and 43. The default value is 24.
4. In the **Local Priority** field, you can select a value between 1 and 255. The default value is 128. The Local Priority value is taken into account when two identical announce messages are received by at least two different ports. In such a case, the Boundary Clock mechanism selects the slave port based on the best (lowest) Local Priority.
5. In the **Max Step removed** field, you can select the maximum number of PTP clocks traversed from the grandmaster to the slave clock in the local PTP 820 Boundary Clock node. The value range is 1-255. The default value is 255. If the defined number is exceeded, packets from this grandmaster candidate are discarded and the grandmaster will not be eligible for use by the Boundary Clock node.
6. To implement your changes, click **Apply**.

The following *Table* lists and describes the read-only Boundary Clock default parameters.

Table 115 Boundary Clock Default Parameters


Parameter	Definition
Two Step	Indicates whether the Boundary Clock node is operating in two-step mode. In PTP 820, this is always set to Yes .
Clock Identity	Identifies the system clock.
Number of Ports	Displays the number of ports on the unit on which Boundary Clock is enabled. The maximum is 4 per PTP 820 unit.
Clock Class	One of the elements of the clock quality, as defined in IEEE-1588.
Clock Accuracy	One of the elements of the clock quality, as defined in IEEE-1588.
Offset Scaled Log Variance	One of the elements of the clock quality, as defined in IEEE-1588.
Slave Only	Indicates whether the Boundary Clock node is operating in slave mode only. In PTP 820, this is always set to No .
Priority 1	Always displays 128.

Displaying the Boundary Clock Advanced Parameters

To display and set the Boundary Clock advanced parameters:

1. Select **Sync > 1588 > Boundary Clock > Clock Parameters > Advanced**. The 1588 Boundary Clock – Clock Advanced Parameters page opens.

Figure 353 1588 Boundary Clock – Clock Advanced Parameters Page



All of the advanced Boundary Clock parameters are read-only. The following Table lists and describes the Boundary Clock advanced parameters.

Table 116 Boundary Clock Advanced Parameters

Parameter	Definition
Steps Removed	The number of PTP clocks traversed from the grandmaster to the slave clock in the local PTP 820 Boundary Clock node. You can define a maximum number of steps in the Clock Default Parameters page. See <i>Displaying and Setting the Boundary Clock Default Parameters</i> .
Offset from Master (Nanoseconds)	The time difference between the master clock and the local slave clock (in ns).
Mean Path Delay (Nanoseconds)	The mean propagation time for the link between the master and the local slave (in ns).
Master Clock Identity	The clock identity of the current master clock.
Master Port Number	The clock identity of the current master port.
Grandmaster Identity	The clock identity of the current grandmaster.
Grandmaster Clock Class	The clock class of the current grandmaster. The clock class is one of the elements of the clock quality, as defined in IEEE-1588.

Parameter	Definition
Grandmaster Clock Accuracy	The clock accuracy of the current grandmaster. The clock accuracy is one of the elements of the clock quality, as defined in IEEE-1588.
Grandmaster Offset Scaled Log Variance	The offset scaled log variance of the current grandmaster. The offset scaled log variance is one of the elements of the clock quality, as defined in IEEE-1588.
Grandmaster Priority 1	The Priority 1 value of the current grandmaster.
Grandmaster Priority 2	The Priority 2 value of the current grandmaster.
Current UTC Offset (Seconds)	The current UTC offset value (in seconds).
Current UTC Offset Valid	Indicates whether the current UTC offset value is valid.
Leap 59	Indicates that the last minute of the current UTC day contains 59 seconds.
Leap 61	Indicates that the last minute of the current UTC day contains 61 seconds.
Time Traceable	Traceability to the primary time reference.
Frequency Traceable	Traceability to the primary frequency reference.
PTP Timescale	Indicates whether the clock time scale of the grandmaster clock is PTP.
Time Source	The source of the time used by the grandmaster clock.

Displaying the Boundary Clock Port Parameters

To display the Boundary Clock port parameters:

1. Select **Sync > 1588 > Boundary Clock > Port Parameters**. The 1588 Boundary Clock – Port Parameters page opens.
2. Select the port you want to configure and click **Edit**. The 1588 Boundary Clock – Port Parameters – Edit page opens.

For an explanation of the configurable fields, see *Enabling Boundary Clock*. The Following Table describes the Boundary Clock Port Parameters,

Table 117 Boundary Clock Port Parameters.

Parameter	Definition
Clock Identity	The PTP 820 unit's clock identity. The same value is used for every port that belongs to the Boundary Clock node.
Port Number	In this version, displays 1 for every port.


Port State	Indicates whether the port is currently acting as Master (distributing PTP to other nodes) or Slave (receiving PTP from a grandmaster).
Log Min Delay Req Interval	The minimum allowed interval between Delay Request messages.
Log Announce Interval	The interval between Announce messages.
Announce Receipt Timeout	The maximum allowed number of intervals without receiving any Announce messages.
Log Sync Interval	Interval between sync messages.
Delay Mechanism	Always displays 1.
Version Number	Always displays 2.

Displaying the Boundary Clock Port Statistics

To display the Boundary Clock port statistics:

1. Select **Sync > 1588 > Boundary Clock > Port Statistics**. The 1588 Boundary Clock – Port Statistics page opens.

Figure 354 1588 Boundary Clock – Port Statistics Page



- To display the statistics for a specific port in a separate page, click View.
- To clear the statistics for a specific port, select the port’s row and click Clear.
- To clear the statistics for all Boundary Clock ports, click Clear All.

The Following Table lists and describes the Boundary Clock port statistics.

Table 118 Boundary Clock Port Statistics

Parameter	Definition
Announce Transmitted	The number of Announce messages that have been transmitted from the port.

Parameter	Definition
Sync Transmitted	The number of Sync messages that have been transmitted from the port.
Follow-Up Transmitted	The number of Follow-Up messages that have been transmitted from the port.
Delay Response Transmitted	The number of Delay Response messages that have been transmitted from the port.
Delay Request Transmitted	The number of Delay Request messages that have been transmitted from the port.
Announce Received	The number of Announce messages that have been received by the port.
Sync Received	The number of Sync messages that have been received by the port.
Follow-Up Received	The number of Follow-Up messages that have been received by the port.
Delay Response Received	The number of Delay Response messages that have been received by the port.
Delay Request Received	The number of Delay Request messages that have been received by the port.
Dropped Messages	The number of dropped messages.
Lost Messages	The number of lost messages.

Disabling 1588 PTP

To disable 1588 PTP synchronization:

1. Select **Sync > 1588 > Boundary Clock > Port Parameters**. The 1588 Boundary Clock – Port Parameters page opens.
2. Select an interface and click **Edit**. The 1588 Boundary Clock – Port Parameters – Edit page opens.
3. In the **Admin** field, select **Disable**.



Note

It is important to disable Boundary Clock on the interfaces before disabling 1588 PTP.

4. Select **Sync > 1588 > General Configuration**. The 1588 – General Configuration page opens.
5. In the **1588 PTP** field, select **Disable**.
6. Click **Apply**.

**Note**

Disabling 1588 PTP disables both Transparent Clock and Boundary Clock, and can drastically affect time synchronization performance in the entire network.

Chapter 11: Access Management and Security

This section includes:

- [Configuring the General Access Control Parameters](#)
- [Configuring the Password Security Parameters](#)
- [Configuring the Session Timeout](#)
- [Configuring Users](#)
- [Configuring RADIUS](#)
- [Configuring X.509 CSR Certificates](#)
- [Blocking Telnet Access](#)
- [Uploading the Security Log](#)
- [Uploading the Configuration Log](#)

Related topics:

- [Changing Your Password](#)
- [Operating in FIPS Mode](#)


Configuring the General Access Control Parameters

To avoid unauthorized login to the system, PTP 820 automatically blocks users upon a configurable number of failed login attempts. You can also configure PTP 820G and PTP 820F to block users that have not logged into the unit for a defined number of days.

To configure the blocking criteria:

1. Select **Platform > Security > Access Control > General**. The Access Control General Configuration page opens.

Figure 355 Access Control General Configuration Page



2. In the **Failure login attempts to block user** field, select the number of failed login attempts that will trigger blocking. If a user attempts to login to the system with incorrect credentials this number of times consecutively, the user will temporarily be prevented from logging into the system for the time period defined in the **Blocking period** field. Valid values are 1-10. The default value is 3.
3. In the **Blocking period (Minutes)** field, enter the length of time, in minutes, that a user is prevented from logging into the system after the defined number of failed login attempts. Valid values are 1-60. The default value is 5.
4. In the **Unused account period for blocking (Days)** field, you can configure a number of days after which a user is prevented from logging into the system if the user has not logged in for the configured number of days. Valid values are 0, or 30-90. If you enter 0, this feature is disabled. The default value is 0.
5. Click **Apply**.

Once a user is blocked, you can unblock the user from the User Accounts page. To unblock a user:

1. Select **Platform > Security > Access Control > User Accounts**. The Access Control User Accounts page opens (Figure 361).
2. Select the user and click **Edit**. The Access Control User Accounts - Edit page opens.

Figure 356 Access Control User Accounts - Edit Page

Access Control User Accounts - Edit

User name

Login status

last logout

Profile

Blocked

Expiration date


3. In the **Blocked** field, select **No**.
4. Click **Apply**, then **Close**.

Configuring the Password Security Parameters

To configure enhanced security requirements for user passwords:

1. Select **Platform > Security > Access Control > Password Management**. The Access Control Password Management page opens.

Figure 357 Access Control Password Management Page



2. In the **Enforce password strength** field, select **Yes** or **No**. When **Yes** is selected:
 - Password length must be at least eight characters.
 - Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
 - A password cannot be repeated within five changes in password.
3. In the **Password change for first login** field, select **Yes** or **No**. When **Yes** is selected, the system requires the user to change his or her password the first time the user logs in.
4. In the **Password aging (Days)** field, select the number of days that user passwords will remain valid from the first time the user logs into the system. You can enter 20-90, or **No Aging**. If you select **No Aging**, password aging is disabled and passwords remain valid indefinitely.
5. Click **Apply**.


Configuring the Session Timeout

By default, there is a 10 minute session timeout. If you do not perform any activity on the system for the period of time defined as the session timeout, the user session times out and you will have to log in to the system again.

To modify the session timeout:

1. Select **Platform > Security > Protocols Control**. The Protocols Control page opens.

Figure 358 Protocols Control Page



2. In the **Session timeout (Minutes)** field, select a session timeout, in minutes, from 1 to 60.
3. Click **Apply**.

Configuring Users

This section includes:

- [User Configuration Overview](#)
- [Configuring User Profiles](#)
- [Configuring Users Accounts](#)

Related topics:

- [Changing Your Password](#)

User Configuration Overview

User configuration is based on the Role-Based Access Control (RBAC) model. According to the RBAC model, permissions to perform certain operations are assigned to specific roles. Users are assigned to particular roles, and through those role assignments acquire the permissions to perform particular system functions.

In the PTP 820G and PTP 820F GUI, these roles are called user profiles. Up to 50 user profiles can be configured. Each profile contains a set of privilege levels per functionality group, and defines the management protocols (access channels) that can be used to access the system by users to whom the user profile is assigned.

The system parameters are divided into the following functional groups:

- Security
- Management
- Radio
- TDM
- Ethernet
- Synchronization

A user profile defines the permitted access level per functionality group. For each functionality group, the access level is defined separately for read and write operations. The following access levels can be assigned:

- **None** – No access to this functional group.
- **Normal** – The user has access to parameters that require basic knowledge about the functional group.
- **Advanced** – The user has access to parameters that require advanced knowledge about the functional group, as well as parameters that have a significant impact on the system as a whole, such as restoring the configuration to factory default settings.

Configuring User Profiles


User profiles enable you to define system access levels. Each user must be assigned a user profile. Each user profile contains a detailed set of read and write permission levels per functionality group.

The system includes a number of pre-defined user profiles. You can edit these profiles, and add user profiles. All together, the system supports up to 50 user profiles.

To add a user profile:

1. Select **Platform > Security > Access Control > User Profiles**. The Access Control User Profiles page opens.

Figure 359 Access Control User Profiles Page



2. Click **Add**. The Access Control User Profiles - Add page opens.

Figure 360 Access Control User Profiles - Add Page

3. In the **Profile** field, enter a name for the profile. The profile name can include up to 49 characters. Once you have created the user profile, you cannot change its name.

**Note**

The **Usage counter** field displays the number of users to whom the user profile is assigned.

4. In the **Permitted access channels** row, select the access channels the user will be permitted to use to access the system.
5. For each functionality group, select one of these options for write level and read level. All users with this profile will be assigned these access levels:
 - **None**
 - **Normal**
 - **Advanced**
6. Click **Apply**, then **Close**.

To view a user profile, click + next to the profile you want to view.

To edit a user profile, select the profile and click **Edit**. You can edit all of the profile parameters except the profile name.

To delete a user profile, select the profile and click **Delete**.



Note

You cannot delete a user profile if the profile is assigned to any users.


Configuring Users Accounts

You can configure up to 2,000 users. Each user has a user name, password, and user profile. The user profile defines a set of read and write permission levels per functionality group. See [Configuring User Profiles](#).

To add a new user:

1. Select **Platform > Security > Access Control > User Accounts**. The Access Control User Accounts page opens.

Figure 361 Access Control User Accounts Page



2. Click **Add**. The Access Control User Profiles - Add page opens.

Figure 362 Access Control User Accounts - Add Page

3. In the **User name** field, enter a user name for the user. The user name can be up to 32 characters.
4. In the **Profile** field, select a User Profile. The User Profile defines the user's access levels for functionality groups in the system. See [Configuring User Profiles](#).
5. In the **Password** field, enter a password for the user. If **Enforce Password Strength** is activated (see [Configuring the Password Security Parameters](#)), the password must meet the following criteria:
 - Password length must be at least eight characters.
 - Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
 - A password cannot be repeated within five changes in password.
6. In the **Blocked** field, you can block or unblock the user. Selecting **Yes** blocks the user. You can use this option to block a user temporarily, without deleting the user from the system. If you set this option to **Yes** while the user is logged into the system, the user will be automatically logged out of the system within 30 seconds.

**Note**

Users can also be blocked by the system automatically. You can unblock the user by selecting **No** in the **Blocked** field. See [Configuring the General Access Control Parameters](#).

7. Optionally, in the **Expiration date** field, you can configure the user to remain active only until a defined date. After that date, the user automatically becomes inactive. To set an expiration date, click the calendar icon and select a date, or enter a date in the format dd-mm-yyyy.

In addition to the configurable parameters described above, the Access Control User Accounts page displays the following information for each user:

- **Login Status** – Indicates whether the user is currently logged into the system.
- **Last Logout** – The date and time the user most recently logged out of the system.

To edit a user's account details, select the user and click **Edit**. You can edit all of the user account parameters except the **User name** and **password**.

To add a user, click **Add**.

To delete a user, select the user and click **Delete**.

Configuring RADIUS

This section includes:

- [RADIUS Overview](#)
- [Activating RADIUS Authentication](#)
- [Configuring the RADIUS Server Attributes](#)
- [Viewing RADIUS User Permissions and Connectivity](#)

RADIUS Overview

The RADIUS protocol provides centralized user management services. PTP 820G and PTP 820F supports RADIUS server and provides a RADIUS client for authentication and authorization. When RADIUS is enabled, a user attempting to log into the system from any access channel (CLI, WEB, NMS) is not authenticated locally. Instead, the user's credentials are sent to a centralized standard RADIUS server which indicates to the PTP 820G or PTP 820F whether the user is known, and which privilege is to be given to the user.

The following RADIUS servers are supported:

- FreeRADIUS
- RADIUS on Windows Server (IAS)
 - Windows Server 2008

You can define up to two Radius servers. If you define two, one serves as the primary server and the other as the secondary server.

Activating RADIUS Authentication

To activate RADIUS authentication:

1. Select **Platform > Security > Access Control > Radius > Radius Configuration**. The Radius Configuration page opens.

Figure 363 Radius Configuration Page

The screenshot shows the Radius Configuration page. The navigation tree on the left includes: Platform, Management, Software, Configuration, Activation Key, Security (General, X.509 Certificate, Access Control, Radius Configuration, Radius Users, Protocols Control), Faults, Radio, Ethernet, and Sync. The main content area shows 'Radius enabled' with a dropdown menu set to 'Enable' and an 'Apply' button. Below this is a table titled 'Radius Configuration Table' with the following data:

Server Id	Connectivity Status	IPV4 address	Port	Retries	Timeout	Secret
1	False	0.0.0.0	1812	3	5	*****
2	False	0.0.0.0	1812	3	5	*****

Below the table are 'Edit' and 'Refresh' buttons.

2. In the **Radius Admin** field, select **Enable**.
3. Click **Apply**
4. .

Configuring the RADIUS Server Attributes

To configure the RADIUS server attributes:

1. Select **Platform > Security > Access Control > Radius > Radius Configuration**. The Radius Configuration page opens (Figure 363).
2. In the Radius Configuration table, select the line that corresponds to the RADIUS server you want to configure:
 - Select **Server ID 1** to configure the Primary Radius server.
 - Select **Server ID 2** to configure the Secondary Radius server.
3. Click **Edit**. The Radius Configuration – Edit page opens.

Figure 364 Radius Configuration – Edit Page

4. In the **IPV4 address** field, enter the IP address of the RADIUS server.
5. In the **Port** field, enter the port ID of the RADIUS protocol in the RADIUS server.
6. In the **Retries** field, enter the number of times the unit will try to communicate with the RADIUS server before declaring the server to be unreachable.
7. In the **Timeout** field, enter the length of time (in seconds) the device will wait during each communication with the Radius server before retrying if no response is received.
8. In the **Secret** field, enter a text string that will serve as the password between the RADIUS server and the RADIUS client. The string must be between 22 and 128 characters long.
9. Click **Apply**, then **Close**.

In addition to the configurable parameters described above, the Radius Configuration page displays the following information for each RADIUS server:

- **Server Id** – The server ID of the Radius server:
 - **1** – The primary Radius server.
 - **2** – The secondary Radius server.
- **Connectivity Status** – The connectivity status of the Radius server in the last attempted connection:
 - **True** – The last connection attempt succeeded.
 - **False** – The last connection attempt failed.


Viewing RADIUS User Permissions and Connectivity

You can view RADIUS user connectivity and permissions information for all Radius users currently connected.

To view RADIUS users:

1. Select **Platform > Security > Access Control > Radius > Radius Users**. The Radius Users page opens.

Figure 365 Radius Users Page



- The **User ID** column displays the user’s name.
- The **Access Channels** column displays the access channels the user is allowed to use to access the unit.
- The **User Instances** column displays the number of open sessions the user currently has.

To view the user’s authorized access levels, click + next to the user name. The page refreshes and displays the additional access level information.

Figure 366 Radius Users Page – Expanded

Radius table		
User ID	Access Channels	User Instances
<input type="checkbox"/> u1	Serial+Telnet+SSH+Web+NMS+SNMP+SNMPv3	4
Ethernet access levels		
Write - Advanced; Read - Advanced		
Management access levels		
Write - Advanced; Read - Advanced		
Radio access levels		
Write - Advanced; Read - Advanced		
Security access levels		
Write - Advanced; Read - Advanced		
Sync access levels		
Write - Advanced; Read - Advanced		
TDM access levels		
Write - Advanced; Read - Advanced		

View Refresh

For each of the six functional groups (**Ethernet, Management, Radio, Security, Sync, TDM**), the page displays the Read access level (**None, Regular, or Advanced**), and the Write access level (**None, Regular, or Advanced**).

Configuring a RADIUS Server

If you want to use the PTP 820 RADIUS feature, you must first install a RADIUS server and configure it to work with the PTP 820 device.

The following subsections describe how to configure a Win2008 RADIUS server and a Linux FreeRADIUS server to work with a PTP 820. For the sake of simplicity, the subsections describe how to create three users: a Advanced user with Advanced read/write permissions, a Normal user with regular read/write permissions, and a Viewer user with no read/write permissions.

Configuring a Win 2008 RADIUS Server


The following sub-sections describe how to configure a Win 2008 RADIUS Server to work with PTP 820 device.

Step 1 – Creating Groups and Users

To create groups and users:

- 1 Create three user groups, as follows:
 - i In the Server Manager, navigate to **Configuration > Local Users and Groups**.
 - ii Right click **Groups** and create the following three user groups:
 - o Radius_Advanced
 - o Radius_Normal
 - o Radius_Viewer


Figure 367 Server Manager – Creating User Groups



2 Create three users:

- o u1
- o u2
- o u3

Figure 368 Server Manager – Creating Users




- 3 Attach each user to a group, as follows:
 - o Attach u1 to Radius_Advanced
 - o Attach u2 to Radius_Normal
 - o Attach u3 to Radius_Viewer

Step 2 – Creating a RADIUS Client

Define the PTP 820 device as a RADIUS client, as follows:

- 1 In the Server Manager, navigate to **Roles > Network Policy and Access Services > NPS (Local) > RADIUS Clients and Servers > RADIUS Clients**.
- 2 Right-click **RADIUS Clients**, and select **New RADIUS Client**. The New RADIUS Client window appears.

Figure 369 Server Manager – Creating a RADIUS Client



- 3 In the New RADIUS Client window:
 - i Select the **Enable this RADIUS client** check box.
 - ii Enter a descriptive **Friendly name** for the device, such as **PTP 820X**.
 - iii Enter the device **IP Address**.
 - iv Select **RADIUS Standard** as the **Vendor name**.
 - v In the **Shared Secret** section, select **Manual**, and enter a **Shared secret**, then enter it again in **Confirm shared secret**. Note down the secret because you will need to enter the same value in the **Secret** field of the Radius Configuration – Edit page (Figure 364).


Step 3 – Creating a Network Policy

Create a network policy for each of the three groups you created: Radius_Advanced, Radius_Normal, Radius_Viewer. That is, follow the instructions in this section, for each of the three groups.

To create a network policy:


- 1 In the Server Manager, navigate to **Roles > Network Policy and Access Service > NPS (Local) > Policies > Network Policies**.
- 2 Right-click **Network Policies**, and select **New**. The New Network Policy wizard appears.
- 3 In the specify Network Policy Name and Connection Type, give the policy a descriptive name, indicating whether it is a policy for the Advanced, the Normal or the Viewer group.

Figure 370 Create Network Policy – Specify Name and Connection Type




- 4 Click **Next**.
- 5 In the Specify Conditions window, click **Add**.
- 6 In the Select Condition window that appears, select the **User Groups** condition and click **Add**.


Figure 371 Create Network Policy – Select Condition



- 7 In the User Groups window that appears, click **Add Groups**.
- 8 In the Select Group window that appears, click **Advanced**.
- 9 In the Select Group window that appears, click **Find Now** to list all groups, and then select the appropriate group from the list: Radius_Advanced, Radius_Normal, or Radius_Viewer.
- 10 Click **OK**.


Figure 372 Create Network Policy – User Group added to Policy’s Conditions

- 11 Click **OK** to save settings.
- 12 Click **Next**.
- 13 In the Specify Access Permission window that appears, select the **Access Granted** option.

Figure 373 Create Network Policy – Specifying Access Permission


- 14 Click **Next**.
- 15 In the Configure Authentication Methods window that appears, make sure only the **Unencrypted Authentication (PAP, SPAP)** option is selected.

Figure 374 Create Network Policy – Configuring Authentication Methods




16 In the query window that appears, click **No**.

Figure 375 Create Network Policy – Insecure Authentication Method Query




17 In the Configure Constraints window that appears, click **Next**.

Figure 376 Create Network Policy – Configuring Constraints




- 18 In the Configure Settings window that appears:
 - i Remove all **Standard** RADIUS attributes. Make sure the Attributes table is empty.

Figure 377 Create Network Policy – Configuring Settings


- ii Select the **Vendor Specific** checkbox and click **Add** under the Attributes table.
- 19 In the Add Vendor Specific Attribute window that appears:
- i Select **Custom** in the **Vendor** drop down field.
 - ii Click **Add**.

Figure 378 Create Network Policy – Adding Vendor Specific Attributes



20 In the Attribute Information window that appears, click **Add**.

Figure 379 Create Network Policy – Selecting to Add Attribute Information



21 In the Vendor-Specific Attribute Information window that appears:

- i Select **Enter Vendor Code**.
- ii Enter **2281** in the **Enter Vendor Code** field.
- iii Select the option **Yes. It conforms**.
- iv Click **Configure Attribute**.

Figure 380 Create Network Policy – Specifying the Vendor

The screenshot shows a dialog box titled "Vendor-Specific Attribute Information". It contains the following elements:

- Attribute name: Vendor Specific
- Specify network access server vendor.
 - Select from list: RADIUS Standard
 - Enter Vendor Code: 2281
- Specify whether the attribute conforms to the RADIUS RFC specification for vendor specific attributes.
 - Yes. It conforms
 - No. It does not conform
- Buttons: "Configure Attribute...", "OK", and "Cancel".

22 In the Configure VSA (RFC Compliant) window that appears, configure 13 attributes as follows:

- i For **Vendor-assigned attribute number** from 21 till 32, select **Decimal** in the **Attribute format** field. These twelve attributes define the Read access level (None, Regular, or Advanced), and the Write access level (None, Regular, or Advanced) for each of the six functional groups (Ethernet, Management, Radio, Security, Sync, TDM). Therefore, in the **Attribute value** field enter the value corresponding to the access level you wish to permit to members of the group whose policy you are configuring, where:

2 = Advanced

1 = Regular


0 = None

Thus for example, enter **2** for all twelve attributes if you are configuring a policy for the Radius_Advanced group. This gives Advanced read permissions and Advanced write permissions, for all six functional groups, to the members of the Radius_Advanced group.

23 Click **OK**.

The following figure shows the Attributes table for the Radius_Advanced group, where access to the device is allowed from all channels.

Figure 382 Create Network Policy – Example of Vendor-Specific Attribute Configuration




24 Close all opened windows and click **Next**.

25 In the Completing New Network Policy window, click **Finish**.

26 Reset the Network Policy Server (NPS) by stopping and starting the NPS service as follows:

- i Right click the **NPS (Local)** node, and select **Stop NPS Service**.
- ii Right click the **NPS (Local)** node, and select **Start NPS Service**.

Figure 383 Create Network Policy – Stopping/Starting NPS Services

Configuring a Linux FreeRADIUS Server

The following sub-sections describe how to configure a Linux FreeRADIUS server to work with PTP 820 device.

To so do, you will need to modify the following three files:

- `/etc/raddb/users`
- `/etc/raddb/clients.conf`
- `/usr/share/freeradius/dictionary.cambium`

Step 1 – Creating Users

This step describes how to create the following three users:

- u1 – with advanced read/write privileges, password 1111
- u2 – with normal read/write privileges, password 2222
- u3 – with no read/write privileges, password 3333

To create these RADIUS users:

- 1 Add the users in the `/etc/raddb/users` file, using any editor you like, according to the following example:

```
# user1 - advanced privileges
u1    auth-type := local, Cleartext-Password := "1111"
      security-ro = advanced,
      security-wo = advanced,
```

```
mng-ro = advanced,  
mng-wo = advanced,  
radio-ro = advanced,  
radio-wo = advanced,  
tdm-ro = advanced,  
tdm-wo = advanced,  
eth-ro = advanced,  
eth-wo = advanced,  
sync-ro = advanced,  
sync-wo = advanced,  
access_channel = u1accesschannel,  
fall-through = yes  
  
# user2 - regular privileges  
u2    auth-type := local, Cleartext-Password := "2222"  
      security-ro = regular,  
      security-wo = regular,  
      mng-ro = regular,  
      mng-wo = regular,  
      radio-ro = regular,  
      radio-wo = regular,  
      tdm-ro = regular,  
      tdm-wo = regular,  
      eth-ro = regular,  
      eth-wo = regular,  
      sync-ro = regular,  
      sync-wo = regular,  
      access_channel = u2accesschannel,  
      fall-through = yes  
  
# user3 - no privilege (viewer)  
u3    auth-type := local, Cleartext-Password := "3333"  
      security-ro = none,  
      security-wo = none,  
      mng-ro = none,  
      mng-wo = none,
```

```

radio-ro = none,
radio-wo = none,
tdm-ro = none,
tdm-wo = none,
eth-ro = none,
eth-wo = none,
sync-ro = none,
sync-wo = none,
access_channel = u3accesschannel,
fall-through = yes

```

- 2 Save the changes in the `/etc/raddb/users` file.

Step 2 – Defining the Permitted Access Channels

The `access_channel` of each user we configured in the `/etc/raddb/users` file, defines the channels through which that user is allowed to access the unit.

This is done by summing the values corresponding to the allowed channels, where the values are:

###	none	0
###	serial	1
###	telnet	2
###	ssh	4
###	web	8
###	nms	16
###	snmp	32
###	snmpV3	64

For example:

- The value `127` denotes permission to access the device from all channels:
Serial + Telnet + SSH + Web + NMS + SNMP +SNMPv3
- The value `24` indicates permission to access the device only from the Web + NMS channels.

To define each user's access channels:

- 1 In the `usr/share/freeradius/dictionary.cambium` file, configure the values of the access channels according to the following example:

```

### access_channel for u1 user:serial+telnet+ssh+web+nms+snmp+snmpV4
VALUE ACCESS_CHANNEL u1accesschannel 127

```

- 2 Save the changes to the `usr/share/freeradius/dictionary.cambium` file.

Step 3 – Specifying the RADIUS client

This step describes how to define a device as a RADIUS client. The RADIUS server accepts attempts to connect to a device only if that is device is defined as a RADIUS client.

To define a device as a RADIUS client:

- 1 In the `/etc/raddb/clients.conf` file, add the device according to the following example.

The example shows how to add PTP 820G device with IP address 192.168.1.118:

```
# IP20-G
client 192.168.1.118 {
    secret          = default_not_applicable
    shortname       = cambium-PTP 820G
}
```

Keep in mind:

- The `secret` must be between 22 and 128 characters long. Note down the secret because you will need to enter the same value in the **Secret** field of the Radius Configuration – Edit page (Figure 364).
 - The `shortname` is not mandatory, but should be added, and should be different for each RADIUS client.
- 2 Save the changes to the `/etc/raddb/clients.conf` file.

Step 4 – Restarting the RADIUS client

After configuring all of the above, restart the RADIUS process.

To restart the RADIUS process:

- 1 Stop the process by entering:

```
killall -9 radiusd
```

- 2 Start the process running in the background by entering:

```
radius -x &
```



Note

To check the logs each time a user connects to the server, enter:

```
radius -x &
```

Configuring X.509 CSR Certificates and HTTPS

The web interface protocol for accessing PTP 820G or PTP 820F can be configured to HTTP (default) or HTTPS. It cannot be set to both at the same time.

Before setting the protocol to HTTPS, you must:

1. Create and upload a CSR file. See [Generating a Certificate Signing Request \(CSR\) File](#).
2. Download the certificate to the PTP 820G or PTP 820F and install the certificate. See [Downloading a Certificate](#).
3. Enable HTTPS. This must be performed via CLI. See [Enabling HTTPS \(CLI\)](#).

When uploading a CSR and downloading a certificate, the PTP 820G or PTP 820F functions as an SFTP client. You must install SFTP server software on the PC or laptop you are using to perform the upload or download. For details, see [Configuring the Internal Ports for FTP or SFTP](#).

**Note**

For these operations, SFTP must be used.

Generating a Certificate Signing Request (CSR) File

To generate a Certificate Signing Request (CSR) file:

1. Select **Platform > Security > X.509 Certificate > CSR**. The Security Certificate Request page opens.

Figure 384 Security Certificate Request Page

2. In the **Common Name** field, enter the fully-qualified domain name for your web server. You must enter the exact domain name.
3. In the **Organization** field, enter the exact legal name of your organization. Do not abbreviate.
4. In the **Organization Unit** field, enter the division of the organization that handles the certificate.
5. In the **Locality** field, enter the city in which the organization is legally located.
6. In the **State** field, enter the state, province, or region in which the organization is located. Do not abbreviate.
7. In the **Country** field, enter the two-letter ISO abbreviation for your country (e.g., US).
8. In the **Email** field, enter an e-mail address that can be used to contact your organization.
9. In the **File Format** field, select the **PEM** file format. Note that the **DER** file format is planned for future release.

**Note**

In this version, only PEM is supported.

10. Click **Apply** to save your settings.
11. Click **FTP Parameters** to display the FTP Parameters page.

Figure 385 FTP Parameters Page (Security Certificate Request)

FTP Parameters

File transfer protocol

Username

Password

Path

File name

Server IPv4 address

Server IPv6 address

Note: Server must be configured as SFTP.

Page Refresh Interval (Seconds) Last Loaded: 19:07:33

12. In the **Username** field, enter the user name you configured in the SFTP server.
13. In the **Password** field, enter the password you configured in the SFTP server. If you did not configure a password for your SFTP user, simply leave this field blank.
14. In the **Path** field, enter the directory path to which you are uploading the CSR. Enter the path relative to the SFTP user's home directory, not the absolute path. To leave the path blank, enter //.
15. In the **File Name** field, enter the name you want to give to the exported CSR.
16. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the SFTP server in the **Server IP address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
17. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the SFTP server in the **Server IPv6 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
18. Click **Apply**, then **Close** to save the FTP parameters and return to the Security Log Upload page.
19. Click **Generate & Upload**. The file is generated and uploaded.

The **CSR Status** field displays the status of any pending CSR generation and upload. Possible values are:

- **Ready** – The default value, which appears when CSR generation and upload is in progress.
- **File-in-transfer** – The upload operation is in progress.
- **Success** – The file has been successfully uploaded.
- **Failure** – The file was not successfully uploaded.


The **CSR Percentage** field displays the progress of any current CSR upload operation.

Downloading a Certificate

To download a certificate:


1. Select **Platform > Security > X.509 Certificate > Download & Install**. The Security Certification Download and Install page opens.

Figure 386 Security Certification Download and Install Page



2. Click **FTP Parameters** to display FTP Parameters page.

Figure 387 FTP Parameters Page (Security Certificate Download & Install)



3. In the **Username** field, enter the user name you configured in the SFTP server.
4. In the **Password** field, enter the password you configured in the SFTP server. If you did not configure a password for your SFTP user, simply leave this field blank.

5. In the **Path** field, enter the directory path from which you are uploading the certificate. Enter the path relative to the SFTP user's home directory, not the absolute path. To leave the path blank, enter //.
6. In the **File Name** field, enter the certificate's file name in the SFTP server.
7. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the SFTP server in the **Server IPv4 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
8. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the SFTP server in the **Server IPv6 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
9. Click **Apply**, then **Close** to save the FTP parameters and return to the Security Log Upload page.
10. Click **Download**. The certificate is downloaded.
11. Click **Install**. The certificate is installed on the PTP 820G or PTP 820F.


Blocking Telnet Access

You can block telnet access to the unit. By default, telnet access is not blocked.

To block telnet access:

- 1 Select **Platform > Security > Protocols Control**. The Protocols Control page opens.

Figure 388 Protocols Control Page



- 2 In the **Telnet Admin** field, select **Disable** to block telnet access. By default, telnet access is enabled (**Enable**).
- 3 Click **Apply**.

Uploading the Security Log


The security log is an internal system file which records all changes performed to any security feature, as well as all security related events.

When uploading the security log, the PTP 820G or PTP 820F functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the import or export. For details, see [Configuring the Internal Ports for FTP or SFTP](#).

To upload the security log:


1. Install and configure an FTP server on the PC or laptop you are using to perform the upload. See [Configuring the Internal Ports for FTP or SFTP](#).
2. Select **Platform > Security > General > Security Log Upload**. The Security Log Upload page opens.

Figure 389 Security Log Upload Page



3. Click **FTP Parameters** to display FTP Parameters page.

Figure 390 FTP Parameters Page (Security Upload Page)



4. In the **Username** field, enter the user name you configured in the FTP server.
5. In the **Password** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP user, simply leave this field blank.

6. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP server in the **Server IP address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
7. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP server in the **Server IPv6 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
8. In the **Path** field, enter the directory path to which you are uploading the files. Enter the path relative to the FTP user's home directory, not the absolute path. To leave the path blank, enter `//`.
9. In the **File name** field, enter the name you want to give to the exported security log.
10. Click **Apply**, then **Close** to save the FTP parameters and return to the Security Log Upload page.
11. Click **Upload**. The upload begins.

The **File transfer operation status** field displays the status of any pending security log upload. Possible values are:

- **Ready** – The default value, which appears when no file transfer is in progress.
- **File-in-transfer** – The upload operation is in progress.
- **Success** – The file has been successfully uploaded.
- **Failure** – The file was not successfully uploaded.

The **Process percentage** field displays the progress of any current security log upload operation.

Uploading the Configuration Log


The configuration log lists actions performed by users to configure the system. This file is mostly used for security, to identify suspicious user actions. It can also be used for troubleshooting.

When uploading the configuration log, the PTP 820G or PTP 820F functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the upload. For details, see [Configuring the Internal Ports for FTP or SFTP](#).

To upload the configuration log:


1. Install and configure an FTP server on the PC or laptop you are using to perform the upload. See [Configuring the Internal Ports for FTP or SFTP](#).
2. Select **Platform > Security > General > Configuration Log Upload**. The Security Log Upload page opens.

Figure 391 Configuration Log Upload Page



3. Click **FTP Parameters** to display FTP Parameters page.

Figure 392 FTP Parameters Page (Configuration Log Upload)



4. In the **Username** field, enter the user name you configured in the FTP server.

5. In the **Password** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP user, simply leave this field blank.
6. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP server in the **Server IP address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
7. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP server in the **Server IPv6 address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
8. In the **Path** field, enter the directory path to which you are uploading the files. Enter the path relative to the FTP user's home directory, not the absolute path. To leave the path blank, enter `//`.
9. In the **File name** field, enter the name you want to give to the exported configuration log.

**Note**

The directory path and file name, together, cannot be more than:

If the IP address family is configured to be IPv4: 236 characters

If the IP address family is configured to be IPv6: 220 characters

10. Click **Apply**, then **Close** to save the FTP parameters and return to the Configuration Log Upload page.
11. Click **Upload**. The upload begins.

The **File transfer operation status** field displays the status of any pending configuration log upload. Possible values are:

- **Ready** – The default value, which appears when no file transfer is in progress.
- **File-in-transfer** – The upload operation is in progress.
- **Success** – The file has been successfully uploaded.
- **Failure** – The file was not successfully uploaded.

The **Process percentage** field displays the progress of any current configuration log upload operation.

Chapter 12: Alarm Management and Troubleshooting

This section includes:

- [Viewing Current Alarms](#)
- [Viewing Alarm Statistics](#)
- [Viewing the Event Log](#)
- [Editing Alarm Text and Severity](#)
- [Uploading Unit Info](#)
- [Performing Diagnostics](#)

**Note**

CW mode, used to transmit a single or dual frequency tones for debugging purposes, can be configured using the CLI. See [Working in CW Mode \(Single or Dual Tone\) \(CLI\)](#).

Related topics:

- [Configuring Trap Managers](#)
- [Alarms List](#)

**Note**

You can configure a wait time of up to 120 seconds after an alarm is cleared in the system before the alarm is actually reported as being cleared. This prevents traps flooding the NMS in the event that some external condition causes the alarm to be raised and cleared continuously. The timeout for trap generationConfigured via CLI. By default, the timeout is 10 seconds. It can be enabled and disabled via CLI. See [Configuring a Timeout for Trap Generation \(CLI\)](#)..

Viewing Current Alarms

To display a list of current alarms in the unit:

1. Select **Faults > Current Alarms**. The Current Alarms page opens. The Current Alarms page displays current alarms in the unit. Each row in the Current Alarms table describes an alarm and provides basic information about the alarm. For a description of the information provided in the Current Alarms page, see [Table 119](#).

Figure 393 Current Alarms Page

#	Time	Severity	Description	User Text	Origin	Alarm id
1	22-03-2015 19:11:52	▲	Multi Carrier ABC LOF		Multi Carrier ABC: Group #1	2200
2	22-03-2015 19:11:52	▲	Radio loss of frame		Radio: Slot 2, port 1	603
3	22-03-2015 19:08:44	▲	Remote communication failure		Radio: Slot 2, port 1	1501
4	22-03-2015 17:13:41	▲	Radio loss of frame		Radio: Slot 2, port 2	603
5	22-03-2015 16:39:18	▲	LAG operational state is down		LAG: Group #1	101
6	22-03-2015 16:39:17	▲	Ethernet Loss of Carrier		Ethernet: Slot 1, port 2	401
7	22-03-2015 19:11:52	▲	RFU RX level out of range		Radio: Slot 2, port 1	1727
8	22-03-2015 17:13:41	▲	RFU RX level out of range		Radio: Slot 2, port 2	1727
9	19-03-2015 18:41:21	▲	protection-mate-not-present-alarm		Unit	0
10	19-03-2015 18:36:46	▲	RFU TX Mute		Radio: Slot 2, port 2	1735

2. To view more detailed information about an alarm, click + at the beginning of the row or select the alarm and click **View**.

Figure 394 Current Alarms - View Page

Active, Current Alarms - View

Sequence Number: 380465

Time: 22-03-2015 19:11:52

Severity: critical

Description: Multi Carrier ABC LOF

User Text:

Origin: Multi Carrier ABC: Group #1

Probable Cause: All channels in Multi Carrier ABC group are down

Corrective Actions:

- 1) Check link performance on all radio channel in Multi Carrier ABC group
- 2) Check radio alarms for channels in Multi Carrier ABC group
- 3) Check configuration of Multi Carrier ABC group

Alarm id: 2200

Buttons: Refresh, Close

Table 119 Alarm Information


Parameter	Definition
Sequence Number (#)	A unique sequence number assigned to the alarm by the system.
Time	The date and time the alarm was triggered.
Severity	<p>The severity of the alarm. In the Current Alarms table, the severity is indicated by a symbol. You can display a textual description of the severity by holding the cursor over the symbol.</p> <p>Note: You can edit the severity of alarm types in the Alarm Configuration page. See Editing Alarm Text and Severity.</p>
Description	A system-defined description of the alarm.
User Text	<p>Additional text that has been added to the system-defined description of the alarm by users.</p> <p>Note: You can add user text to alarms in the Alarm Configuration page. See Editing Alarm Text and Severity.</p>
Origin	The module that generated the alarm.
Probable Cause	This field only appears in the Current Alarms - View page. One or more possible causes of the alarm, to be used for troubleshooting.
Corrective Actions	This field only appears in the Current Alarms - View page. One or more possible corrective actions to be taken in troubleshooting the alarm.
Alarm ID	A unique ID that identifies the alarm type.

Viewing Alarm Statistics

To display a summary of alarms per module and per interface:

1. Select **Faults > Alarm Statistics**. The Alarm Statistics page opens.

Figure 395 Alarm Statistics Page



The Alarm Statistics page displays the number of current alarms per severity level for each module, interface, and virtual interface (such as Multi-Carrier ABC groups) in the unit. Only modules and interfaces for which one or more alarms are currently raised are listed in the Alarm Statistics page.

Viewing the Event Log

The Event Log displays a list of current and historical events and information about each event.

To display the Event Log:

1. Select **Faults > Event Log**. The Event Log opens. For a description of the information provided in the Event Log, see [Table 120 Event Log Information](#).

Figure 396 Event Log




Table 120 Event Log Information

Parameter	Definition
Time	The date and time the event was triggered.
Sequence Number (#)	A unique sequence number assigned to the event by the system.
Severity	The severity of the event. In the Event Log table, the severity is indicated by a symbol. You can display a textual description of the severity by holding the cursor over the symbol. Note: You can edit the severity of event types in the Alarm Configuration page. See Editing Alarm Text and Severity .
State	Indicates whether the event is currently raised or has been cleared.
Description	A system-defined description of the event.

Parameter	Definition
User Text	Additional text that has been added to the system-defined description of the event by users. Note: You can add user text to events in the Alarm Configuration page. See Editing Alarm Text and Severity .
Origin	The module that generated the event.

Editing Alarm Text and Severity

You can view a list of alarm types, edit the severity level assigned to individual alarm types, and add additional descriptive text to individual alarm types.

This section includes:

- [Displaying Alarm Information](#)
- [Viewing the Probable Cause and Corrective Actions for an Alarm Type](#)
- [Editing an Alarm Type](#)
- [Setting Alarms to their Default Values](#)

Displaying Alarm Information

To view the list of alarms defined in the system:

1. Select **Faults > Alarm Configuration**. The Alarm Configuration page opens. For a description of the information provided in the Alarm Configuration page, see [Table 121 Alarm Configuration Page Parameters](#).

Figure 397 Alarm Configuration Page

#	Alarm ID	Severity	Description	Additional Text	Service Affecting
1	10	Warning	Framer digital loopback		off
2	25	Warning	Unit Temperature is out of system specified limits		off
3	26	Warning	Unit input voltage is too low		off
4	27	Warning	Unit input voltage is too high		off
5	28	Warning	Unit warm Reset		off
6	29	Warning	Unit Reset		off
7	31	Warning	Protection switchover due to remote request		on
8	32	Warning	Change Remote request was sent		on
9	33	Warning	Unit Redundancy and MIMO 4x4 can not operate simultaneously		on
10	100	Warning	LAG is not fully functional - LAG Degraded		off
11	101	Warning	LAG operational state is down		off
12	102	Warning	Loopback is active		on
13	103	Warning	Slot X port XX is mirrored to slot Y port YY		on
14	150	Warning	Interface is down due to auto state propagation		on
15	200	Warning	Protection communication is down		on
16	201	Warning	Protection in Lockout State		off
17	202	Warning	Protection switchover due to local failure		off
18	307	Warning	TDM interface is up		on
19	308	Warning	TDM interface is down		on
20	401	Warning	Ethernet Loss of Carrier		on
21	407	Warning	Ethernet interface is up		on

Table 121 Alarm Configuration Page Parameters

Parameter	Definition
Sequence Number (#)	A unique sequence number assigned to the row by the system.
Alarm ID	A unique ID that identifies the alarm type.
Severity	The severity assigned to the alarm type. You can edit the severity in the Alarm Configuration – Edit page. See Editing an Alarm Type .

Parameter	Definition
Description	A system-defined description of the alarm.
Additional Text	Additional text that has been added to the system-defined description of the alarm by users. You can edit the text in the Alarm Configuration – Edit page. See Editing an Alarm Type .
Service Affecting	Indicates whether the alarm is considered by the system to be service-affecting (on) or not (off).

Viewing the Probable Cause and Corrective Actions for an Alarm Type

Most alarm types include a system-defined probable cause and suggested corrective actions. To view an alarm type's probable cause and corrective actions, click + on the left side of the alarm type's row in the Alarm Configuration page. The Probable Cause and Corrective Actions appear underneath the alarm type's row, as shown below. If there is no +, that means no Probable Cause and Corrective Actions are defined for the alarm type.


Figure 398 Alarm Configuration Page – Expanded

#	Alarm ID	Severity	Description	Additional Text	Service Affecting
1	10	🔔	Framer digital loopback		off
Probable Cause User enabled framer digital loopback					
Corrective Actions Disable framer digital loopback					
2	25	🔔	Unit Temperature is out of system specified limits		off

Editing an Alarm Type

To change the severity of an alarm type and add additional text to the alarm type's description:

1. Select the alarm type in the Alarm Configuration page ([Figure 397](#)).
2. Click **Edit**. The Alarm Configuration - Edit page opens.

Figure 399 Alarm Configuration - Edit Page

The screenshot shows a window titled "Alarm Configuration" with a sub-header "Alarm Configuration - Edit". The form contains the following fields and controls:

- Alarm ID:** A text input field containing the value "601".
- Description:** A text input field containing the value "Radio excessive BER".
- Severity:** A dropdown menu currently set to "major".
- Additional Text:** An empty text input field.
- Buttons:** Three buttons labeled "Apply", "Refresh", and "Close" are located at the bottom of the form.

3. Modify the **Severity** and/or **Additional Text** fields.
4. Click **Apply**, then **Close**.

Setting Alarms to their Default Values

To set all alarms to their default severity levels and text descriptions, click **Set All to Default** in the Alarm Configuration page (Figure 397).

Configuring External Alarms

PTP 820G and PTP 820F includes a DB9 dry contact external alarms interface. This interface is located on the front panel. See [External Alarms](#).

[Table 122](#) shows the pin-outs for the external alarms interface.

Table 122 External Alarms Interface Pin-Outs


	Pin Number	Description
	1	External Input Alarm #1
	2	External Input Alarm #2
	3	External Input Alarm #3
	4	External Input Alarm #4
	5	External Input Alarm #5
	6	Relay #1, normally closed pin
	7	Relay #1, common pin
	8	Relay #1, normally open pin
	9	GND

Configuring Input Alarms

To enable and configure the input alarms:


- 1 Select Platform > Management > External Alarms > Input. The External Alarms Input page opens.

Figure 400 External Alarms Input Page



- 2 Select the alarm input you want to configure.
- 3 Click **Edit**. The External Alarms Input – Edit page opens.

Figure 401 External Alarms Input – Edit Page



- 4 In the **Admin** field, select **Enable** to enable the alarm input or **Disable** to disable the alarm input.

- 5 In the **Severity** field, select the alarm severity:
 - **Indeterminate**
 - **Critical**
 - **Major**
 - **Minor**
 - **Warning**
- 6 In the **Description** field, enter text to describe the alarm input. When the alarm is raised, this appears as the alarm description text.
- 7 Click **Apply**, then **Close**.

The **ID** field identifies the external alarm input. See [Table 122 External Alarms Interface Pin-Outs](#).

The **State** field indicates whether the alarm is currently raised (**on**) or cleared (**off**).

Configuring Voltage Alarm Thresholds and Masking Undervoltage Alarms

Some hardware models include dual power interfaces for power redundancy. If you are only using one feed in a dual-feed configuration, it is recommended to mask the unused feed in order to prevent an unnecessary undervoltage alarm.

You can also configure undervoltage and overvoltage alarm thresholds. The default thresholds for PTP 820F, PTP 820G are:

- Undervoltage Raise Threshold: 40V
- Undervoltage Clear Threshold: 42V
- Overvoltage Raise Threshold: 60V
- Overvoltage Clear Threshold: 58V

These thresholds determine when the following alarms are raised and cleared:

- Alarm #32000: Under voltage
- Alarm #32001: Over voltage

To mask undervoltage alarms and configure voltage alarm thresholds:

- 1 Select **Faults > Voltage Alarm Configuration**. The Voltage Alarm Configuration page opens.




Figure 402: Voltage Alarm Configuration Page

- 2 To mask the undervoltage alarm, select **Enable** in the appropriate row in the Alarm Parameters section of the Alarm Configuration page, then click **Apply**:
 - **Mask undervoltage alarm on 1st DC power feed** – Select **Enable** to mask the undervoltage alarm for the power feed on the left.
 - **Mask undervoltage alarm on 2nd DC power feed** – Select **Enable** to mask the undervoltage alarm for the power feed on the right.
- 3 To change the undervoltage and overvoltage alarm thresholds, click **Edit**. The Voltage Alarm Configuration – Edit page opens.




Figure 403: Voltage Alarm Configuration – Edit Page

- 4 Select the thresholds you want in the **Undervoltage clear threshold (V)**, **Undervoltage raise threshold (V)**, **Overvoltage clear threshold (V)**, and **Overvoltage raise threshold (V)** fields. The configurable values for these thresholds are 0-100V.
- 5 Click **Apply**.

In addition to adding the ability to configure these alarm thresholds, Release 10.9 adds PMs that indicate, per 15-minute and 24-hour periods:

- The number of seconds the unit was in an undervoltage state during the measured period.
- The number of seconds the unit was in an overvoltage state during the measured period.
- The lowest voltage during the measured period.
- The highest voltage during the measured period.


These PMs are displayed via CLI. For instructions, see *Configuring Voltage Alarm Thresholds and Displaying Voltage Threshold PMs (CLI)*.

Configuring the Output Alarm

To enable and configure the output alarm:

- 1 Select **Platform > Management > External Alarms > Output**. The External Alarms Output page opens.

Figure External Alarms Output Page



- 2 In the **Admin** field, select **enable** to enable the output alarm or **disable** to disable the output alarm.
- 3 In the **Group** field, select from a list of alarm groups, or select **all groups**. When an alarm belonging to the selected group is raised, the alarm output is triggered. The available alarm groups are:
 - Communications
 - Quality of Service
 - Processing
 - Equipment

- Environmental
- All groups

**Note**

In the current release, no alarms belong to the Quality of Service and Environmental groups. For a list of alarms and their assigned groups, see [Alarms List](#).

- 4 Click **Apply**, then **Close**.

Uploading Unit Info

You can generate a Unit Information file, which includes technical data about the unit. This file can be uploaded and forwarded to customer support, at their request, to help in analyzing issues that may occur.

When uploading a Unit Information file, the PTP 820G functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the upload. For details, see [Configuring the Internal Ports for FTP or SFTP](#).



Note

For troubleshooting, it is important that an updated configuration file be included in User Info files that are sent to customer support. To ensure that an up-to-date configuration file is included, it is recommended to back up the unit's configuration before generating the Unit Info file.

To generate and upload a Unit Information file:

1. Install and configure an FTP server on the PC or laptop you are using to perform the upload. See [Configuring the Internal Ports for FTP or SFTP](#).
2. Select **Platform > Management > Unit Info**. The Unit Info page opens.

Figure 404 Unit Info Page

The screenshot shows the 'Unit Info' page in a web interface. The left sidebar contains a navigation tree with the following items: Main View, Platform, Management (Unit Parameters, NTP Configuration, Time Services, Interface Manager, Inventory, Unit Info, Reset, Set to Factory Default, Unit Redundancy), Networking, SNMP, Software, Configuration, Activation Key, Security, Faults, Radio, Ethernet, and Sync. The 'Unit Info' page contains the following fields and controls:

- Unit info file creation status: ready
- Unit info file creation progress: 0
- Unit info file transfer status: Ready
- Unit info file transfer progress: 0
- File transfer protocol: FTP (dropdown menu)
- Username in server: anonymous
- Password in server: (empty text field)
- Server IP: 0.0.0.0
- Location of files in server: (empty text field)
- File name in server: (empty text field)
- IPv6 Server Address: :: (empty text field)
- Buttons: Apply, Create, Export, Refresh

3. In the **File transfer protocol** field, select the file transfer protocol you want to use (**FTP** or **SFTP**).
4. In the **Username in server** field, enter the user name you configured in the FTP server.

5. In the **Password in server** field, enter the password you configured in the FTP server. If you did not configure a password for your FTP user, simply leave this field blank.
6. If the IP address family is configured to be IPv4, enter the IPv4 address of the PC or laptop you are using as the FTP server in the **Server IP** field. See [Defining the IP Protocol Version for Initiating Communications](#).
7. If the IP address family is configured to be IPv6, enter the IPv6 address of the PC or laptop you are using as the FTP server in the **IPv6 Server Address** field. See [Defining the IP Protocol Version for Initiating Communications](#).
8. In the **Location of files in server** field, enter the directory path to which you are uploading the file. Enter the path relative to the FTP user's home directory, not the absolute path. To leave the path blank, enter `//`.
9. In the **File Name in server** field, enter the name you want to give to the exported Unit Information file.
10. Click **Apply** to save your settings.
11. Click **Create** to create the Unit Information file. The following fields display the status of the file creation process:
 - **Unit Info File Creation Status** – Displays the file creation status. You must wait until the status is Success to upload the file. Possible values are:
 - **Ready** – The default value, which appears when no file is being created.
 - **Generating File** – The file is being generated.
 - **Success** – The file has been successfully created. You may now upload the file.
 - **Failure** – The file was not successfully created.
 - **Unit Info File Creation Progress** – Displays the progress of the current Unit Information file creation operation.
12. Click **Export**. The upload begins. The following fields display the status of the upload process:
 - **Unit Info File Transfer Status** – Displays the status of any pending Unit Information file upload. Possible values are:
 - **Ready** – The default value, which appears when no file transfer is in progress.
 - **File-in-transfer** – The upload operation is in progress.
 - **Success** – The file has been successfully uploaded.
 - **Failure** – The file was not successfully uploaded.

If you try to export the file before it has been created, the following error message appears: **Error #3-Invalid set value.**

If this occurs, wait about two minutes then click **Export** again.

- **Unit Info File Creation Progress** – Displays the progress of the current Unit Information file upload operation.

Performing Diagnostics

This section includes:

- [Performing Radio Loopback](#)
- [Performing Ethernet Loopback](#)
- [Performing TDM Diagnostics](#)
- [Configuring Service OAM \(SOAM\) Fault Management \(FM\)](#)

Performing Radio Loopback

To perform loopback on a radio:

1. Select **Radio > Diagnostics > Loopback**. The Radio Loopbacks page opens.

Figure 405 Radio Loopbacks Page – PTP 820F





Figure 406 Radio Loopbacks Page – PTP 820G




2. Select the slot on which you want to perform loopback and click **Edit**. The Radio Loopbacks – Edit page opens.



Note

You cannot perform loopback directly on a Multi-Carrier ABC group. To perform traffic-level diagnostics on a Multi-Carrier ABC group, the loopback must be activated for all members of the group. Radio-level diagnostics can still be performed on individual members of the group.

Figure 407 Radio Loopbacks – Edit Page



3. In the **Loopback timeout (minutes)** field, enter the timeout, in minutes, for automatic termination of the loopback (0-1440). A value of 0 indicates that there is no timeout.


4. In the **RF loopback** field, select **On**.
5. Click **Apply**.

Performing Ethernet Loopback

Ethernet loopbacks can be performed on any logical Ethernet interface except a LAG. When Ethernet loopback is enabled on an interface, the system loops back all packets ingressing the interface. This enables loopbacks to be performed over the link from other points in the network.

To perform Ethernet loopback:

1. Select **Ethernet > Interfaces > Logical Interfaces**. The Logical Interfaces page opens ([Figure 214](#)).
2. Select an interface in the Ethernet Logical Port Configuration table and click **Loopback**. The Logical Interfaces – Loopback page opens.

Figure 408 Logical Interfaces – Loopback Page

3. In the **Ethernet loopback admin** field, select **Enable** to enable Ethernet loopback on the logical interface, or **Disable** to disable Ethernet loopback on the logical interface.
4. In the **Ethernet loopback duration (sec)** field, enter the loopback duration time (in seconds).
5. In the **Swap MAC address admin** field, select whether to swap DA and SA MAC addresses during the loopback. Swapping addresses prevents Ethernet loops from occurring. It is recommended to enable MAC address swapping if LLDP is enabled.
6. Click **Apply** to initiate the loopback.

Performing TDM Diagnostics

This section includes:

- [Performing Loopback on E1/DS1s](#)

Performing Loopback on E1/DS1s

To perform PDH loopback on a TDM line:

- 1 Select **TDM > Diagnostics > PDH Loopback**. The PDH Loopback page opens.

Figure 409 PDH Loopback Page

Microwave radio: PDH Loopback

Slot

TDM loopback timeout (0..1440)

TDM port loopback status table

Port number	Loopback type	Counter
1	None	0
2	None	0
3	None	0
4	None	0
5	None	0
6	None	0
7	None	0
8	None	0
9	None	0
10	None	0
11	None	0
12	None	0
13	None	0
14	None	0
15	None	0
16	None	0

- 2 In the **Select a slot** field at the top of the PDH Loopback page, select the slot with the TDM card on which you want to run the loopback.
- 3 In the **TDM Loopback Timeout** field, specify the number of minutes before timing out a loopback operation.
- 4 Click **Apply** to save the settings.
- 5 For each interface, select the interface and click **Edit**. The PDH Loopback – Edit page opens.

Figure 410 PDH Loopback – Edit Page

PDH Loopback

PDH Loopback - Status parameters

Slot ID Slot 1: E1/DS1 1-16

Port number 1

Port number TDM: Slot 1, port 1

Counter 0

PDH Loopback - Configuration parameters

Loopback type Towards line

Apply Refresh Close

- 6 In the **Loopback type** field, select the type of loopback to run on the selected interface:
 - None
 - Towards Line
 - Towards System
- 7 Click **Apply**, then **Close**.

Configuring Service OAM (SOAM) Fault Management (FM)

This section includes:

- [SOAM Overview](#)
- [Configuring MDs](#)
- [Configuring MA/MEGs](#)
- [Configuring MEPs](#)
- [Displaying Remote MEPs](#)
- [Displaying Last Invalid CCMS](#)
- [Configuring MIPs with MHF Default](#)
- [Performing Loopback](#)

SOAM Overview

The Y.1731 standard and the MEF-30 specifications define Service OAM (SOAM). SOAM is concerned with detecting, isolating, and reporting connectivity faults spanning networks comprising multiple LANs, including LANs other than IEEE 802.3 media.

Y.1731 Ethernet FM (Fault Management) consists of three protocols that operate together to aid in fault management:

- Continuity check
- Link trace
- Loopback

**Note**

Link trace are planned for future release.

PTP 820G and PTP 820F utilizes these protocols to maintain smooth system operation and non-stop data flow.

**Note**

Support for IEEE 802.1ag is planned for future release.

The following are the basic building blocks of FM:

- MD (Maintenance Domain) – An MD defines the management space on a network, typically owned and operated by a single entity, for which connectivity faults are managed via SOAM.
- MA/MEG (Maintenance Association/Maintenance Entity Group) – An MA/MEG contains a set of MEPs or MIPs.

- MEP (MEG End Points) – Each MEP is located on a service point of an Ethernet service at the boundary of the MEG. By exchanging CCMs (Continuity Check Messages), local and remote MEPs have the ability to detect the network status, discover the MAC address of the remote unit/port where the peer MEP is defined, and identify network failures.
- MIP –(MEG Intermediate Points) – Similar to MEPs, but located inside the MEG and can only respond to, not initiate, CCM messages.
- CCM (Continuity Check Message) – MEPs in the network exchange CCMs with their peers at defined intervals. This enables each MEP to detect loss of connectivity or failure in the remote MEP.


Configuring MDs

In the current release, you can define one MD, with an **MD Format of None**.

To add an MD:

1. Select **Ethernet > Protocols > SOAM > MD**. The SOAM MD page opens.

Figure 411 SOAM MD Page



2. Click **Add**. The SOAM MD – Add page opens.

Figure 412 SOAM MD Page

3. In the **MD Name** field, enter an identifier for the MD (up to 43 alphanumeric characters). The MD Name should be unique over the domain.
4. In the **MD Format** field, select **None**.

**Note**

Support for MDs with the MD format Character String is planned for future release. In this release, the software enables you to configure such MDs, but they have no functionality.

5. In the **MD Level** field, select the maintenance level of the MD (1-7). The maintenance level ensures that the CFM frames for each domain do not interfere with each other. Where domains are nested, the encompassing domain must have a higher level than the domain it encloses. The maintenance level is carried in all CFM frames that relate to that domain. The **MD Level** must be the same on both sides of the link.
6. Click **Apply**, then **Close**.

The **MHF (MIP) Creation** field displays the type of MHF format included in the CCMs sent in this MD (in the current release, this is **MHF Default**).

The **Sender TLV Content** field displays the contents of TLVs included in the CCMs sent in this MD (in the current release, this is **Send ID Chassis**).

Configuring MA/MEGs

You can configure up to 1280 MEGs per network element. MEGs are classified as Fast MEGs or Slow MEGs according to the CCM interval (see [Table 123](#)):


- Fast MEGs have a CCM interval of 1 second.
- Slow MEGs have a CCM interval of 10 seconds, 1 minute, or 10 minutes.

You can configure up to 64 MEP pairs per network element.

To add a MEG:


1. Select **Ethernet > Protocols > SOAM > MA/MEG**. The SOAM MA/MEG page opens.

Figure 413 SOAM MA/MEG Page



2. Click **Add MEG**. The SOAM MA/MEG – Add page opens.

Figure 414 SOAM MA/MEG – Add Page



3. Configure the fields described in [Table 123](#).
4. Click **Apply**, then **Close**.

To edit a MEG, select the MEG and click **Edit**. The SOAM MA/MEG – Edit page opens. Only the **CCM Interval** and **MIP Creation** fields can be edited.

[Table 124](#) describes the status (read-only) fields in the SOAM MA/MEG Component table.

Table 123 SOAM MA/MEG Configuration Parameters

Parameter	Definition
MD (ID, Name)	Select the MD to which you are assigning the MEP.
MA/MEG short name	Enter a name for the MEG (up to 44 alphanumeric characters).
MEG Level	<p>Select a MEG level (0-7). The MEG level must be the same for MEGs on both sides of the link. Higher levels take priority over lower levels.</p> <p>If MEGs are nested, the OAM flow of each MEG must be clearly identifiable and separable from the OAM flows of the other MEGs. In cases where the OAM flows are not distinguishable by the Ethernet layer encapsulation itself, the MEG level in the OAM frame distinguishes between the OAM flows of nested MEGs.</p> <p>Eight MEG levels are available to accommodate different network deployment scenarios. When customer, provider, and operator data path flows are not distinguishable based on means of the Ethernet layer encapsulations, the eight MEG levels can be shared among them to distinguish between OAM frames belonging to nested MEGs of customers, providers and operators. The default MEG level assignment among customer, provider, and operator roles is:</p> <ul style="list-style-type: none"> • The customer role is assigned MEG levels 6 and 7. • The provider role is assigned MEG levels 3 through 5. • The operator role is assigned MEG levels: 0 through 2. <p>The default MEG level assignment can be changed via a mutual agreement among customer, provider, and/or operator roles.</p> <p>The number of MEG levels used depends on the number of nested MEGs for which the OAM flows are not distinguishable based on the Ethernet layer encapsulation.</p>
CCM Interval	<p>The interval at which CCM messages are sent within the MEG. Options are:</p> <ul style="list-style-type: none"> • 1 second (default) • 10 seconds • 1 minute • 10 minutes <p>It takes a MEP 3.5 times the CCM interval to determine a change in the status of its peer MEP. For example, if the CCM interval is 1 second, a MEP will detect failure of the peer 3.5 seconds after it receives the first CCM failure message. If the CCM interval is 10 minutes, the MEP will detect failure of the peer 35 minutes after it receives the first CCM failure message.</p>
Service ID	Select an Ethernet service to which the MEG belongs. You must define the service and add service points before you configure the MEG.

Parameter	Definition
MIP Creation	<p>Determines whether MIPs are created on the MEG. Options are:</p> <ul style="list-style-type: none"> • MHF none – No MIPs are created. • MHF default – MIPs are created automatically on any service point in the MEG’s Ethernet service. • MHF explicit – MIPs are created on the service points of the MEG when a lower-level MEP exists on the service point. This option is usually used when the operator’s domain is encompassed by another domain. • MHF defer – No MIPs are created. Not used in the current release.

Table 124 SOAM MA/MEG Status Parameters

Parameter	Definition
MA/MEG ID	Automatically generated by the system.
MA/MEG Name Format	Reserved for future use. In the current release, this is Char String only.
Tx Sender ID TLV content	Sender ID TLV is transmitted.
Port Status TLV TX	Reserved for future use. No Port Status TLV is transmitted in the CCM frame.
Interface Status TLV TX	An Interface Status TLV is transmitted in the CCM frame, indicating the operational status of the interface on which the transmitting MEP is configured (Up or Down)..
MEP List	Lists all local and remote MEPs that have been defined for the MEG.

Configuring MEPs

Each MEP is attached to a service point in an Ethernet service. The service and service point must be configured before you configure the MEP. See [Configuring Ethernet Service\(s\)](#).

Each MEP inherits the same VLAN, C-VLAN, or S-VLAN configuration as the service point on which it resides. See [Configuring Service Points](#).

In order to set the VLAN used by CCM/LBM/LTM if the service point is defined ambiguously (for example PIPE, Bundle-C, Bundle-S, or All-to-One), the service point’s C-VLAN/S-VLAN parameter should *not* be set to N.A.

To configure a MEP, you must:


1. Add MEPs to the relevant MA/MEG. In this stage, you add both local and remote MEPs. The only thing you define at this point is the MEP ID. See [Adding Local and Remote MEPs](#).
2. Configure the local MEPs. At this point, you determine which MEPs are local MEPs. The system automatically defines the other MEPs you configured in the previous step as remote MEPs. See [Configuring the Local MEPs](#).
3. Enable the Local MEPs. See [Enabling Local MEPs](#).

d. Adding Local and Remote MEPs

To add a MEP to the MA/MEG:


1. In the SOAM MA/MEG page, select a MA/MEG and click **MEP List**. The MEP List page opens.

Figure 415 MEP List Page



2. Click **Add**. The Add MEP page opens.

Figure 416 Add MEP Page



3. In the **MEP ID** field, enter a MEP ID (1-8191).


4. Click **Apply**, then **Close**.

e. Configuring the Local MEPs

Once you have added local and remote MEPs, you must define the MEPs and determine which are the local MEPs:

1. Select **Ethernet > Protocols > SOAM > MEP**. The SOAM MEP page opens. [Table 125](#) lists and describes the parameters displayed in the SOAM MEP page.

Figure 417 SOAM MEP Page




Note

To display MEPs belonging to a specific MEG, select the MEG in the **Filter by MA/MEG** field near the top of the SOAM MEP page. To display all MEPs configured for the unit, select **All**.

2. Click **Add**. Page 1 of the Add SOAM MEP wizard opens.

Figure 418 Add SOAM MEP Wizard – Page 1



3. In the **MEG Name** field, select an MA/MEG.
4. Click **Next**. Page 2 of the Add SOAM MEP wizard opens.

Figure 419 Add SOAM MEP Wizard – Page 2

5. In the **Direction** field, select **Down**.

**Note**

In the current release, the Up direction is not supported.

6. In the **MEP ID** field, select from a list of MEPs you have added to the selected MEG.
7. In the **Service Point** field, select the service point on which you want to place the MEP.
8. Click **Finish**. The Add Soam MEP wizard displays the parameters you have selected.

Figure 420 Add SOAM MEP Wizard –Summary Page

9. Verify that you want to submit the displayed parameters and click **Submit**.

Table 125 SOAM MEP Parameters

Parameter	Definition
MD (ID, Name)	The MD ID and name are automatically generated by the system.
MA/MEG (ID, Name)	The MA/MEG ID and name are automatically generated by the system.
MEP ID	The MEP ID.
Interface Location	The interface on which the service point associated with the MEP is located.
SP ID	The service point ID.
MEP Direction	Up or Down.
MEP Fault Notification State	Indicates the status of the defect SOAM state machine. Possible values are: <ul style="list-style-type: none"> • Fng Reset – Initial state. • Fng Defect – Transient state when a defect is detected. • Fng Defect Reported – The defect state is steady (stable). • Fng Defect Clearing – Transient state when a defect is in the process of being cleared. • Fng Defect Cleared – The defect has been cleared (transient state).
Connectivity Status	Indicates whether a MEP can exchange PDU (CCM, Loopback, LTR) with its remote MEP. A MEP with some defect or an inactive MEP cannot exchange PDUs. <p>Possible values are:</p> <ul style="list-style-type: none"> • inactive – At least one of the remote MEPs is in rMEPFailed status (not discovered). • active – All remote MEPs are discovered correctly and have an rMEPOk status.
MEP Active	Indicates whether the MEP is enabled (True) or disabled (False).
MEP CCM TX Enable	Indicates whether the MEP is sending CCMs (True/False).
CCM and LTM Priority	The p-bit included in CCMs and/or LTM frames sent by this MEP (0 to 7).
MEP Defects	Indicates if a defect has been detected by the MEP level.
RMEP List	Once you have configured at least one local MEP, all other MEPs that you have added but not configured as local MEPs are displayed here and are considered to be remote MEPs.

f. Enabling Local MEPs

Once you have added a MEP and defined it as a local MEP, you must enable the MEP.

To enable a MEP:

1. In the SOAM MEP page ([Figure 417](#)), select the MEP you want to enable.

2. Click **Edit**. The SOAM MEP - Edit page opens.

Figure 421 SOAM MEP - Edit Page

SOAM MEP - Edit

MD ID	1
MD Name	TR_998
MA/MEG ID	1
MA/MEG Name	56
MEP ID	25
MEG Level	1
<hr/>	
Interface Location	Ethernet: Slot 1, Port 1
Service ID	10
Service point ID	1
MEP Direction	Down
<hr/>	
MEP Fault Notification State	Fng Defect Reported
MEP MAC Address	00:0A:25:40:1F:93
MEP Alarm On time	250
MEP Alarm Clear time	1000
Connectivity Status	inactive
MEP highest priority fault alarm	Remote CCM
MEP Lowest priority fault alarm	All Def
MEP Operational State	enabled
Last Sent Port status TLV	Ps No Port State TLV
Last Sent Interface status TLV	Down
Last MEP Defects	None
RDI TX indication	False
MEP Defects	Remote CCM
<hr/>	
MEP Active	True
MEP CCM TX Enabled	True
CCM and LTM Priority	7

Apply

Page Refresh Interval (Seconds) None Last Loaded: 11:55:18 Refresh Close

3. In the **MEP Active** field, select **True**.
4. In the **MEP CCM TX Enable** field, select **True**.
5. In the **CCM and LTM Priority** field, select the p-bit that will be include in CCMs sent by this MEP (0 to 7). It is recommended to select 7.
6. Click **Apply**, then **Close**.

Displaying Remote MEPs

To display a list of remote MEPs (RMEPs) and their parameters:

1. Select **Ethernet > Protocols > SOAM > MEP**. The SOAM MEP page opens (Figure 417).
2. Select a MEP and click **RMEP List**. The SOAM MEP DB table is displayed.

Figure 422 SOAM MEP DB Table




Table 126 lists and describes the parameters displayed in the SOAM MEP DB table. To return to the SOAM MEP page, click **Back to MEP**.

Table 126 SOAM MEP DB Table Parameters

Parameter	Definition
RMEP ID	The remote MEP ID.
RMEP Operational State	The operational state of the remote MEP.
RMEP Last rx CCM MAC Address	The MAC Address of the interface on which the remote MEP is located.
RMEP Last CCM OK or Fail Timestamp	The timestamp marked by the remote MEP indicated the most recent CCM OK or failure it recorded. If none, this field indicates the amount of time since SOAM was activated.
RMEP Last rx CCM RDI Indication	Displays the state of the RDI (Remote Defect Indicator)bit in the most recent CCM received by the remote MEP: <ul style="list-style-type: none"> • True – RDI was received in the last CCM. • False – No RDI was received in the last CCM.
RMEP Last rx CCM Port Status TLV	The Port Status TLV in the most recent CCM received from the remote MEP. Reserved for future use.
RMEP Last rx CCM Interface Status TLV	Displays the operational status of the interface on which the remote MEP has been defined.


Parameter	Definition
RMEP Last rx CCM Chassis ID Format	Displays the format of the remote chassis (always the MAC address).
RMEP Last rx CCM Chassis ID	Displays the MAC address of the remote chassis.

Displaying Last Invalid CCMS

To display the entire frame of the last CCM error message and the last CCM cross-connect error message received by a specific local MEP:

1. Select **Ethernet > Protocols > SOAM > MEP**. The SOAM MEP page opens (Figure 417).
2. Select a MEP and click **Last Invalid CCMS**. The MEP Last Invalid CCMS page opens.

Figure 423 MEP Last Invalid CCMS Page



The **Last RX error CCM message** field displays the frame of the last CCM error message received by the MEP.

The **Last RX Xcon fault message** field displays the frame of the last CCM cross-connect error message received by the MEP.



Note

A cross-connect error occurs when a CCM is received from a remote MEP that has not been defined locally.

Configuring MIPs with MHF Default

If you configure a MEG with the MHF default option, MIPS are created automatically on all service points of the service to which the MEG is attached. These MIPS cannot be displayed in the Web EMS, but can be displayed via CLI. See [Displaying MEP and Remote MEP Attributes \(CLI\)](#).

Creating MIPS is subject to the following limitations:

- Once you have created a MEG that contains MIPS, i.e., a MEG with the MHF default attribute, you cannot create a MEG with the MHF none attribute on the same or higher level on the same Ethernet Service. However, you can create MEGs with the MHF none attribute on the same service on lower levels than the MEG with the MHF default attribute.
- MEPs cannot be attached to a MEG with the MHF default attribute.
- The Ethernet service and service points must already be defined before creating the MEG with the MHF default attribute in order for MIPS to be created on the service points.


To configure MEGs with MIPS:

- 1 Create a MEG with the MHF none attribute on the intended Ethernet service. See [Configuring MA/MEGs](#).
- 2 Select the MEG and click **Edit**. The SOAM MA/MEG – Edit page opens.
- 3 In the **MIP Creation** field, select **MHF Default**.
- 4 Click **Apply**, then **Close**.

Performing Loopback

To perform loopback on a MEP:

- 1 In the SOAM MEP page ([Figure 417](#)), select the MEP on which you want to perform the loopback.
- 2 Click **Loopback**. The SOAM MEP – Loopback page opens.

Figure 424 SOAM MEP Loopback Page


SOAM MEP Loopback

MD ID: 1
MD Name: TR-995
MA/MEG ID: 1
MA/MEG Name: T00TR
MEP ID: 25

Session Status

Loopback session state: SOAM Loopback Inactive
Loopback messages transmitted in session: 0
Loopback messages left to transmit in session: 0
Loopback replies received in session: 0

Global Counters

Loopback messages transmitted: 0
Loopback messages received: 0
Valid in-order loopback replies received: 0
Valid out-of-order loopback replies received: 0
Loopback replies transmitted: 0
Bad MSDU Loopback Replies: 0
Loopback messages received with bad sender id: 0
Loopback replies received with bad sender id: 0

Loopback Destination

Destination: MEP ID MAC Address
Loopback Messages Destination MAC Address: 00:00:00:00:00:00
Loopback Messages Destination MEP ID: 0 (1..8191)

Loopback Configuration

Loopback messages to be transmitted: 1
Loopback Messages Interval (seconds): 0
Loopback Messages Frame Size (Octets): 64
Loopback Messages Priority: 0
Drop Enable: False
Loopback Messages Data Pattern Type: All Zeros

Apply Refresh Close

 Pressing 'Apply' will activate loopback session.

100%

- 3 In the Loopback Destination area, select from the following options:
 - o **MEP ID** – If you select **MEP ID**, you must enter the MEP ID of the MEP on the interface to which you want to perform the loopback in the **Loopback Messages Destination MEP ID** field. If you select **MEP ID**, the loopback will only be activated if CCMs have already been received from the MEP. For this reason, it is recommended to initiate loopback via MAC address.

- **MAC Address** (default) – If you select **MAC Address**, you must enter the MAC address of the interface to which you want to send the loopback in the **Loopback Messages Destination MAC Address**. If you are not sure what the interface's MAC address is, you can get it from the Interface Manager by selecting **Platform > Management > Interface Manager**.
- 4 In the **Loopback messages to be transmitted** field, select the number of loopback messages to transmit (0 – 1024). If you select 0, loopback will not be performed.
 - 5 In the **Loopback Messages Interval** field, select the interval (in seconds) between each loopback message (0.1 – 60). You can select in increments of 1/10 second. However, the lowest possible interval is 1 second. If you select a smaller interval, the actual interval will still be 1 second.
 - 6 In the **Loopback Messages Frame Size** field, select the frame size for the loopback messages (64 – 1516). Note that for tagged frames, the frame size will be slightly larger than the selected frame size.
 - 7 In the **Loopback Messages Priority** field, select a value (0 – 7) for the priority bit for tagged frames.
 - 8 In the **Drop Enable** field, choose the value of the DEI field for tagged loopback frames (**True** or **False**). The default value is **False**.
 - 9 In the **Loopback Messages Data Pattern Type** field, select the type of data pattern to be sent in an OAM PDU Data TLV. Options are **All Zeros** and **All Ones**. The default value is **All Zeros**.
 - 10 Click **Apply** to begin the loopback. The **Loopback session state** field displays the status of the loopback:
 - **SOAM Loopback Complete** – The loopback has been successfully completed.
 - **SOAM Loopback Stopped** – The loopback has been manually stopped.
 - **SOAM Loopback Failed** – The loopback failed.
 - **SOAM Loopback Active** – The loopback is currently active.
 - **SOAM Loopback Inactive** – No loopback has been initiated.

The remote interface will answer and the loopback session will be completed if either of the following is true:

- A remote MEP has been defined on the destination interface.
- A MIP has been defined on the destination interface. See [Configuring MIPs with MHF Default](#).



Note

To manually stop a loopback, you must use the CLI. Enter the following command in root view:
root> ethernet soam loopback stop meg-id <meg-id> mep-id <mep-id>.

Chapter 13: Web EMS Utilities

This section includes:

- [Restarting the HTTP Server](#)
- [Calculating an ifIndex](#)
- [Displaying, Searching, and Saving a list of MIB Entities](#)

Restarting the HTTP Server

To restart the unit's HTTP server:

- 1 Select **Utilities > Restart HTTP**. The Restart HTTP page opens.

Figure 425 Restart HTTP Page



- 2 Click **Restart**. The system prompts you for confirmation.
- 3 Click **OK**. The HTTP server is restarted, and all HTTP sessions are ended. After a few seconds, the Web EMS prompts you to log in again.

Calculating an ifIndex

The ifIndex calculator enables you to:

- Calculate the ifIndex for any object in the system.
- Determine the object represented by any valid ifIndex.

To use the ifIndex calculator:

- 1 Select **Utilities > ifCalculator**. The ifIndex Calculator page opens.

Figure 426 ifIndex Calculator Page

- If you have an ifIndex and you want to determine which hardware item in the unit it represents, enter the number in the **ifIndex number** field and click **Calculate Index to name**. A description of the object appears in the **Result** field.
- To determine the ifIndex of a hardware item in the unit, such as an interface, card, or slot, select the object type in the **Functional Type** field, select the **Slot** and **Port** (if relevant), and click **Calculate Name to Index**. The object's ifIndex appears in the **Result** field.

Displaying, Searching, and Saving a list of MIB Entities

To display a list of entities in the PTP 820 private MIB:

- 1 Select **Utilities > MIB Reference Guide**. The MIB Reference Table page opens.

Figure 427 MIB Reference Table Page

#	MIB OID	MIB Name	Type	MIB Type	MIB Access	Description
1	1.3.6.1.2.1.1.1	sysDescr	Scalar	OCTET STRING	read-only	A short description of the system
2	1.3.6.1.2.1.1.2	sysObjectID	Scalar	OCTET STRING	read-only	System object ID
3	1.3.6.1.2.1.1.3	sysUpTime	Scalar	INTEGER	read-only	The time (in hundredths of a second) since the system was last re-initialized
4	1.3.6.1.2.1.1.4	sysContact	Scalar	OCTET STRING	read-write	The required contact person for the system
5	1.3.6.1.2.1.1.5	sysName	Scalar	OCTET STRING	read-write	The name of the system
6	1.3.6.1.2.1.1.6	sysLocation	Scalar	OCTET STRING	read-write	The location of the system
7	1.3.6.1.2.1.2.2	ifTable	Table		not-accessible	This table contains a list of configuration information about the user managed interfaces
8	1.3.6.1.2.1.2.2.1.1	ifIndex	Column	INTEGER	read-only	Interface location
9	1.3.6.1.2.1.2.2.1.2	ifDescr	Column	OCTET STRING	read-only	A textual string containing information about the interface
10	1.3.6.1.2.1.2.2.1.3	ifType	Column	INTEGER (1..-1)	read-only	The type of the interface
11	1.3.6.1.2.1.2.2.1.4	ifMtu	Column	INTEGER (1..10000)	read-only	Maximum Transmission Unit. "The size of the largest datagram which can be sent/receive on the interface, specified in octets"
12	1.3.6.1.2.1.2.2.1.5	ifSpeed	Column	INTEGER	read-only	An estimate of the interface's bandwidth in bits per second
13	1.3.6.1.2.1.2.2.1.6	ifPhysAddress	Column	OCTET STRING	read-only	The MAC (Media Access Control) address of the interface
14	1.3.6.1.2.1.2.2.1.7	ifAdminStatus	Column	INTEGER (1..2)	read-write	The desired state of the interface
15	1.3.6.1.2.1.2.2.1.8	ifOperStatus	Column	INTEGER (1..7)	read-only	The current operational state of the interface
16	1.3.6.1.2.1.2.2.1.9	ifLastChange	Column	INTEGER (1..-1)	read-only	The value of system up time at the time the interface has entered its current operational-state
17	1.3.6.1.2.1.2.2.1.10	ifInOctets	Column	Counter32	read-only	The total number of octets received on the interface

The MIB Reference Table is customized to the type of PTP 820 product you are using. There are two separate versions of the MIB Reference Table:

- PTP 820G/F
- PTP 820C/S



Note

-

Even though the MIB Reference Table is customized to these three product groups, some of the entities listed in the Table may not be relevant to the particular unit you are using. This may occur because of activation key restrictions, minor differences between product types, or simply because a certain feature is not used in a particular configuration.

Chapter 14: Getting Started (CLI)

This section includes:

- [Establishing a Connection \(CLI\)](#)
- [Logging On \(CLI\)](#)
- [General CLI Commands](#)
- [Changing Your Password \(CLI\)](#)
- [Configuring In-Band Management \(CLI\)](#)
- [Changing the Management IP Address \(CLI\)](#)
- [Configuring Unit Redundancy for the PTP 820 Split Mount \(CLI\)](#)
- [Configuring the Activation Key \(CLI\)](#)
- [Setting the Time and Date \(Optional\) \(CLI\)](#)
- [Enabling the Interfaces \(Interface Manager\) \(CLI\)](#)
- [Configuring Cascading Interfaces \(Optional\) \(CLI\)](#)
- [Entering Radio View \(CLI\)](#)
- [Unmuting a Radio \(CLI\)](#)
- [Configuring the Transmit \(TX\) Level \(CLI\)](#)
- [Configuring the Transmit \(TX\) Frequency \(CLI\)](#)
- [Configuring the Radio \(MRMC\) Script\(s\) \(CLI\)](#)
- [Enabling ACM with Adaptive Transmit Power \(CLI\)](#)
- [Configuring the RSL Threshold Alarm \(CLI\)](#)
- [Operating in FIPS Mode \(CLI\)](#)

Establishing a Connection (CLI)

For instructions on establishing a physical management connection to the unit from your PC or laptop, see [Establishing a Connection](#).

Logging On (CLI)

Use a telnet connection to manage the PTP 820G or PTP 820F via CLI. You can use any standard telnet client, such as PuTTY or ZOC Terminal. Alternatively, you can simply use the `telnet <ip address>` command from the CMD window of your PC or laptop.

The default IP address of the unit is 192.168.1.1. Establish a telnet connection to the unit using the default IP address.

When you have connected to the unit, a login prompt appears. For example:

```
Linux 2.6.34.8-grsec-WR4.1.0.0_cg1-CE.0.5 (localhost) (13:44 on Saturday, 21 March 2015)
```

Login:

At the prompt, enter the default login user name: `admin`

A password prompt appears. Enter the default password: `admin`

General CLI Commands

To display all command levels available from your current level, press <TAB> twice. For example, if you press <TAB> twice at the root level, the following is displayed:

```
root>
auto-state-propagation  ethernet  exit  multi-carrier-abc
platform                pwe3     quit   radio   radio-groups
stm1oc3_rst            switch-back  switch-to  wait
```

Some of these are complete commands, such as `quit` and `exit`. Others constitute the first word or phrase for a series of commands, such as `ethernet` and `radio`.

Similarly, if you enter the word `platform` and press <TAB> twice, the first word or phrase of every command that follows `platform` is displayed:

```
root> platform
activation-key          configuration  if-manager    management
security               shelf-manager  software      status
sync                   tdm-latency-optimization  tdm-offset    tdm-range
unit-info              unit-info-file          wtr-timer
root> platform
```

To auto-complete a command, press <TAB> once.

Use the up and down arrow keys to navigate through recent commands.

Use the ? key to display a list of useful commands and their definitions.

At the prompt, or at any point in entering a command, enter the word `help` to display a list of available commands. If you enter `help` at the prompt, a list of all commands is displayed. If you enter `help` after entering part of a command, a list of commands that start with the portion of the command you have already entered is displayed.

To scroll up and down a list, use the up and down arrow keys.

To end the list and return to the most recent prompt, press the letter `q`.

To ping another network device, enter one of the following commands in root view:

```
root> ping ipv4-address <x.x.x.x> count <number of echo packets> packet-size
<packet-size>
root> ping ipv6-address <ipv6> count <number of echo packets> packet-size
<packet-size>
```

The optional `count` parameter determines how many packets are sent. This parameter can be an integer from 1 to 1000. The default value is 4.

The optional `packet-size` parameter determines the size of each packet, in bytes. This parameter can be an integer from 64 to 1480. The default value is 64.

The `ping` command is available from all views (e.g., root, interface views, group views).

Changing Your Password (CLI)

It is recommended to change your default Admin password as soon as you have logged into the system.

In addition to the Admin password, there is an additional password protected user account, “root user”, which is configured in the system. The root user password and instructions for changing this password are available from CambiumCambium Customer Support. It is strongly recommended to change this password.

To change your password, enter the following command in root view:

```
root> platform security access-control password edit own-password
```

The system will prompt you to enter your existing password. The system will then prompt you to enter the new password.

If Enforce Password Strength is activated, the password must meet the following criteria:

- Password length must be at least eight characters.
- Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
- A password cannot be repeated within five changes in password.

See [Configuring the Password Security Parameters \(CLI\)](#).

Configuring In-Band Management (CLI)

You can configure in-band management in order to manage the unit remotely via its radio and/or Ethernet interfaces.

Each PTP 820 unit includes a pre-defined management service with Service ID 257. The management service is a multipoint service that connects the two local management ports and the network element host CPU into a single service. In order to enable in-band management, you must add at least one service point to the management service, in the direction of the remote site or sites from which you want to access the unit for management. For instructions on adding service points, see [Configuring Service Points \(CLI\)](#).

**Note**

In order to use in-band management, it must be supported on the external switch.

Changing the Management IP Address (CLI)

Related Topics:

- [Defining the IP Protocol Version for Initiating Communications \(CLI\)](#)
- [Configuring the Remote Unit's IP Address \(CLI\)](#)

You can enter the unit's address in IPv4 format and/or in IPv6 format. The unit will receive communications whether they were sent to its IPv4 address or its IPv6 address.

To set the unit's IP address in IPv4 format, enter the following command in root view to configure the IP address, subnet mask, and default gateway:

```
root> platform management ip set ipv4-address <ipv4-address> subnet
<subnet> gateway <gateway> name <name> description <name>
```

Table 127 IP Address (IPv4) CLI Parameters

Parameter	Input Type	Permitted Values	Description
ipv4-address	Dotted decimal format.	Any valid IPv4 address.	The IP address for the unit.
subnet	Dotted decimal format.	Any valid subnet mask.	The subnet mask for the unit.
gateway	Dotted decimal format.	Any valid IPv4 address.	The default gateway for the unit (optional).
name	Text String.		Enter a name (optional).
description	Text String.		Enter a description (optional).

To set the unit's IP address in IPv6 format, set in root view the IP address, prefix length, and default gateway of the PTP 820G or PTP 820F unit, as follows:

```
root> platform management ip set ipv6-address <ipv6-address> prefix-
length <prefix-length> gateway <gateway>
```



Note

It is recommended not to configure addresses of type FE:80::/64 (Link Local addresses) because traps are not sent for these addresses.

Table 128 IP Address (IPv6) CLI Parameters

Parameter	Input Type	Permitted Values	Description
ipv6-address	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IP address for the unit.
prefix-length	Number.	1-128	The prefix-length for the unit.
gateway	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The default gateway for the unit (optional).

Examples

The following command sets the following parameters:

- IPv4 Address - 192.168.1.160
- Subnet Mask – 255.255.0.0
- Default Gateway – 192.168.1.100

```
root> platform management ip set ipv4-address 192.168.1.160 subnet
255.255.0.0 gateway 192.168.1.100
```

The following command sets the following parameters:

- IPv6 Address - FE80:0000:0000:0000:0202:B3FF:FE1E:8329
- Prefix length – 64
- Default Gateway - FE80:0000:0000:0000:0202:B3FF:FE1E:8329

```
root> platform management ip set ipv6-address
FE80:0000:0000:0000:0202:B3FF:FE1E:8329 prefix-length 64 gateway
FE80:0000:0000:0000:0202:B3FF:FE1E:8329
```

Configuring Unit Redundancy for the PTP 820 Split Mount (CLI)

This section explains how to configure unit redundancy and includes the following topics:

- [Configuring Unit Redundancy \(CLI\)](#)
- [Configuring Ethernet Interface Protection \(CLI\)](#)
- [Enabling Unit Redundancy \(CLI\)](#)
- [Changing the Configuration after Enabling Unit Redundancy \(CLI\)](#)
- [Running Commands in the Standby Unit \(CLI\)](#)
- [Viewing Link and Protection Status and Activity \(CLI\)](#)
- [Switchover \(CLI\)](#)
- [Performing Lockout \(CLI\)](#)
- [Disabling Unit Redundancy \(CLI\)](#)

For an overview of unit redundancy and a description of the relevant cabling requirements, see:

- [Unit Redundancy Overview](#)
- [Cabling Requirements for Unit Redundancy](#)

To configure unit redundancy, you must perform the following steps:

1. Verify that the proper cables for unit redundancy are connected to the units. See [Cabling Requirements for Unit Redundancy](#).
2. Configure Ethernet interface protection. See [Configuring Ethernet Interface Protection \(CLI\)](#).
3. Enable unit redundancy. See [Enabling Unit Redundancy \(CLI\)](#).

Configuring Unit Redundancy (CLI)

- Before configuring unit redundancy, verify that both units have the same hardware part number see, [Displaying Unit Inventory \(CLI\)](#). and the same software version (see [Displaying Current Software Versions \(CLI\)](#)). If the units do not have the same software version, upgrade each unit to the most recent software release (see [Upgrading the Software \(CLI\)](#)).

To configure unit redundancy, you must perform the following steps:

1. Verify that the PC or laptop being used to configure the devices is directly connected to the management port of the unit that will be the active unit.
2. Configure the unit that will be the active unit so that it will have a working radio link by performing all necessary radio configurations, such as configuring the MRMC scripts, setting the frequency, unmuting the radio, and setting up radio groups such as XPIC or Multi-Carrier ABC (Multi-Radio).
3. Perform all necessary Ethernet and TDM configurations on the unit that will be the active unit , such as defining Ethernet and TDM services.

4. Resolve any alarms in the unit that will be the active unit, so that there are no active alarms raised.
5. Configure Ethernet interface protection on the unit that will be the active unit. See *Configuring Ethernet Interface Protection (CLI)*.
6. Power up the unit that will be the standby unit.
7. Connect the management PC or laptop to the management port of the unit that will be the standby unit.
8. Enable unit redundancy on the unit that will be the standby unit. See *Enabling Unit Redundancy (CLI)*.
9. Connect the PC or laptop again to the management port of the unit that will be the active unit.
10. Enable unit redundancy on the unit that will be the active unit. See *Enabling Unit Redundancy (CLI)*.
11. Verify that the proper cables for unit redundancy are connected to the units. See *Cabling Requirements for Unit Redundancy*. Note that the first unit you configured should automatically be assigned by the system to be the active unit because it will have no alarms. In contrast, the second unit will have at least one alarm since you have not yet changed its settings from the default settings.
12. On the active unit, verify that the connection operation state is Up and the protection link to mate status is Connected. See *Viewing Link and Protection Status and Activity (CLI)*.
13. Enter the following command in root view to copy the configuration of the active unit to the standby unit:

```
root> platform management protection copy-to-mate
```



Note

While the system is performing the copy-to-mate operation, a temporary loss of management connection will occur.

14. Once the standby unit comes back online, perform final checks to verify that unit redundancy has been configured properly:
 - Check the port status on the standby unit.
 - Check the radio link status on the standby unit.
 - Verify that there is no Configuration Mismatch alarm. See *Changing the Configuration after Enabling Unit Redundancy (CLI)*.
 - Verify that no other alarms are raised on either unit.

Configuring Ethernet Interface Protection (CLI)

No special software configuration is required for Optical Splitter and Electrical Splitter modes.

For Line Protection mode, you must perform the following steps:

1. Configure the GbE interfaces on the external switch in LACP mode. The external switch must support LACP.
2. Connect a GbE port on the external switch to a GbE interface on each of the PTP 820G units.
3. Enable LACP on the GbE interfaces on the PTP 820G that are connected to the external switch:
 - a. Go to interface view for the GbE interface.
 - b. In interface view, enter the following command:

```
eth type eth [1/x]>interface-mode-set interface-mode LACP
```

- c. Reset the unit. See [Performing a Hard \(Cold\) Reset \(CLI\)](#).

**Note**

Because a unit reset is required when changing the Interface Mode to or from LACP, it is recommended to perform copy-to-mate immediately after changing the Interface Mode to or from LACP, then to reset the active unit only after the standby unit is back up after the copy-to-mate operation.

To disable LACP mode, enter the following command in Ethernet interface view:

```
eth type eth [1/x]>interface-mode-set interface-mode NONE
```

To display an interface's current LACP setting, enter the following command in Ethernet interface view:

```
eth type eth [1/x]>interface-mode-show
```

Enabling Unit Redundancy (CLI)

To enable unit redundancy:

1. To enable protection, enter the following command in root view:

```
root> platform management protection set admin enable
```

The system configures itself for unit redundancy:

- o The system determines which unit is the Active unit based on a number of pre-defined criteria.
- o When the system returns online, all management must be performed via the Active unit using the IP address you defined for that unit.
- o The IP address you defined for the unit which is now the Standby unit is no longer valid, and the management port of the Standby unit becomes non-operational. Note, however, that if switchover takes place before you perform copy-to-mate, the original IP of the Standby unit, now the Active unit, becomes the working IP for management of both units.
- o Management of the Standby unit is performed via the Active unit, via the protection cable. Protection communications are transmitted via Management port 2 in each unit, which is no longer usable or configurable as a management port.

**Note**

An PTP 820G unit on which (i) unit redundancy is enabled, (ii) there is no radio link, and (iii) no mate unit is connected, will automatically be selected as a standby unit when booting up. As a result, management to the unit will be lost.

Changing the Configuration after Enabling Unit Redundancy (CLI)

To keep the standby unit up-to-date, after any change to the configuration of the active unit you must enter a copy-to-mate command to copy the configuration to the standby unit.

If you change the configuration of the Active unit but do not perform a copy-to-mate command, a Configuration Mismatch alarm is raised.

To display a list of mismatched parameters, enter the following command in root view:

```
root> platform management protection show mismatch details
```

The following items must be configured separately for the Standby unit, and are not copied via copy-to-mate:

- Setting the Unit Name – See [Configuring Unit Parameters \(CLI\)](#).
- Disabling/enabling Radio TX mute – See [Unmuting a Radio \(CLI\)](#).
- Clearing the Radio and RMON counters – See [Configuring and Viewing Radio PMs and Statistics \(CLI\)](#) and [Viewing Ethernet PMs and Statistics \(CLI\)](#).
- Configuring the activation key – See [Configuring the Activation Key \(CLI\)](#).

For instructions on performing configuration directly on the standby unit, see [Running Commands in the Standby Unit \(CLI\)](#).

When configuring MRMC scripts after enabling unit redundancy, it should be done in the following order. It is important to use this order because if the changes are not performed in the correct order, the connection to the remote units will be lost:

1. Change the MRMC script on the standby unit of the remote pair.
2. Change the MRMC script on the active unit of the remote pair. This will cause the local-remote link to be lost.
3. Change the MRMC script on the active unit of the local pair. When the unit reboots, the local-remote link will be restored.
4. Perform copy-to-mate on the active unit of the local pair.

Running Commands in the Standby Unit (CLI)

You can run CLI commands in the standby unit.

To run CLI commands in the standby unit:

1. Use the following command to enter view context for the standby unit:

```
root> switch-to mate
mate/root>
```

2. Enter the specific CLI command you want to run in mate/root context.
3. To switch back to the active unit, enter the following command:

```
mate/root> switch-to local
root>
```

Viewing Link and Protection Status and Activity (CLI)

You can view link and protection status and activity any time.

- To view whether unit redundancy is enabled or disabled, enter the following command in root view:

```
root> platform management protection show admin
```

- To view whether unit redundancy is functional, enter the following command in root view. Note that protection is not functional if the management connection to the mate is down.

```
root> platform management protection show operational-state
```

- To view whether the unit you are managing is the active or standby unit, enter the following command in root view:

```
root> platform management protection show activity-state
```

- To view the status of the protection link to the mate, enter the following command in root view:

```
root> platform management protection show link-status
```

- To view the status of the last copy-to-mate operation, enter the following command in root view:

```
root> platform management protection show copy-to-mate status
```

- To view the current lockout status, enter the following command in root view:

```
root> platform management protection show lockout status
```

Switchover (CLI)

The following events trigger switchover for unit redundancy according to their priority, with the highest priority triggers listed first.

1. Loss of active unit
2. Force switch
3. Lockout
4. Radio Loss of Frame (LOF) on active unit
5. Change request from the remote unit. This takes place in the event of radio LOF on both units; a change request is sent to the active unit on the other side of the link.
6. Loss of Carrier (LOC) in any of the Ethernet interfaces or Loss of Signal (LOS) in any of the TDM interfaces
7. Manual switch

LOC takes place if the Admin status of the interface is Enabled and the Operational status is Down. If the interface is closed as a result of ASP, the interface is *not* considered to be in LOC state, and switchover is not triggered.

Following switchover triggered by LOC, there is an automatic timeout of one minute before any further switchover can take place due to LOC.

At any point, you can manually switch to the standby unit, provided that the highest protection fault level in the standby unit is no higher than the highest protection fault level on the active unit.

You can also perform a force switch to the standby unit, even if the protection fault level is higher in the standby unit. Force switch also implements lockout.

To perform a manual switch, enter the following command in root view:

```
root> platform management protection set manual-switch
```

To perform a force switch, enter the following command in root view:

```
root> platform management protection set force-switch
```

Performing Lockout (CLI)

At any point, you can perform lockout, which prevents switchover to the standby unit in all cases other than a force switch.

To perform lockout, enter the following command in root view:

```
root> platform management protection lockout set admin on
```

To release lockout, enter the following command in root view:

```
root> platform management protection lockout set admin off
```

Disabling Unit Redundancy (CLI)

You can disable unit redundancy at any time.

To disable protection, enter the following command in root view.

```
root> platform management protection set admin disable
```

If in-band management is being used, unit redundancy must be disabled in the following order to ensure that management is not lost:

1. Disable unit redundancy in the active unit of the remote pair. The link remains up and no switchover takes place.
2. Change the IP address of the active remote unit.
3. Disable all active traffic interfaces on the active remote unit. Line interfaces should be disabled first, followed by radio interfaces, since disabling a radio interface causes switchover. See [Enabling the Interfaces \(Interface Manager\) \(CLI\)](#). This causes switchover on the remote pair.
4. Disable unit redundancy in the active unit of the local pair. The link remains up and no switchover takes place.
5. Change the IP address of the active local unit.
6. Disable all active traffic interfaces on the active local unit. Line interfaces should be disabled first, followed by radio interfaces, since disabling a radio interface causes switchover. See [Enabling the Interfaces \(Interface Manager\) \(CLI\)](#). This causes switchover on the local pair.
7. Disable unit redundancy on the both the remote and the local units that were the standby units and have now become the active units.

**Note**

On some occasions, in links with TDM traffic, if you disable unit redundancy then re-enable unit redundancy later, a TDM-LIC configuration mismatch alarm may be raised (Alarm ID 2002). If this happens, you must reset the unit with the alarm, then perform copy-to-mate.

Configuring the Activation Key (CLI)

This section includes:

- [Activation Key Overview \(CLI\)](#)
- [Installing an Activation Key \(CLI\)](#)
- [Displaying Activation Key Information \(CLI\)](#)
- [Activating an Activation Key \(CLI\)](#)

Activation Key Overview (CLI)

PTP 820G and PTP 820F offers a pay-as-you-grow concept in which future capacity growth and additional functionality can be enabled with activation keys. For purposes of the activation keys, each PTP 820G or PTP 820F chassis is considered a distinct device, regardless of which cards are included in the chassis. Each device contains a single unified activation key cipher.

New PTP 820G and PTP 820F units are delivered with a default activation key that enables you to manage and configure the unit. Additional feature and capacity support requires you to enter an activation key. Contact your vendor to obtain your activation key cipher.

**Note**

To obtain an activation key cipher, you may need to provide the unit's serial number. See [Displaying Unit Inventory \(CLI\)](#).

Each required feature and capacity should be purchased with an appropriate activation key. It is not permitted to enable features that are not covered by a valid activation key. In the event that the activation-key-enabled capacity and feature set is exceeded, an Activation Key Violation alarm occurs and the Web EMS displays a yellow background and an activation key violation warning. After a 48-hour grace period, all other alarms are hidden until the capacity and features in use are brought within the activation key's capacity and feature set.

In order to clear the alarm, you must configure the system to comply with the activation key that has been loaded in the system. The system automatically checks the configuration to ensure that it complies with the activation-key-enabled features and capacities. If no violation is detected, the alarm is cleared.

When entering sanction state, the system configuration remains unchanged, even after power cycles. However, the alarms remain hidden until an appropriate activation key is entered or the features and capacities are re-configured to be within the parameters of the current activation key.

A demo activation key is available that enables all features for 60 days. When the demo activation key expires, the most recent valid activation key goes into effect. The 60-day period is only counted when the system is powered up. Ten days before the demo activation key expires, an alarm is raised indicating that the demo activation key is about to expire.

Installing an Activation Key (CLI)

To install an activation key, use the following command to enter the activation key cipher you have received from the vendor. The activation key cipher is a string that enables all features and capacities that have been purchased for the unit.

```
root> platform activation-key set key string <key string>
```

If the activation key cipher is not legal (e.g., a typing mistake or an invalid serial number), an Activation Key Loading Failure event is sent to the Event Log. When a legal activation key cipher is entered, an Activation Key Loaded Successfully event is sent to the Event Log.

Displaying Activation Key Information (CLI)

To display information about the currently installed activation key, enter the following command in root view:

```
root> platform activation-key show all
```

To display a list of features that your current activation key supports, and usage information about these features, enter the following command in root view:

```
root> platform activation-key show usage all
```

To display a list of the radio capacities that your current activation key supports and their usage information, enter the following command in root view:

```
root> platform activation-key show usage radio
```

Activating an Activation Key (CLI)

You can use a demo license to enable all PTP 820G and PTP 820F features for 60 days. The demo license expires 60 days from the time it was activated, and the most recent previously installed and valid license goes into effect. The 60-day period is only counted when the system is powered up. 48 hours before the demo license expires, an alarm is raised indicating that the demo license is about to expire.

To activate the demo license, enter the following command in root view:

```
root> platform activation-key set demo admin enable
```

To display the current status of the demo license, enter the following command in root view:

```
root> platform activation-key show demo status
```


Setting the Time and Date (Optional) (CLI)

Related Topics:

- [Configuring NTP \(CLI\)](#)

PTP 820G and PTP 820F uses the Universal Time Coordinated (UTC) standard for time and date configuration. UTC is a more updated and accurate method of date coordination than the earlier date standard, Greenwich Mean Time (GMT).

Every PTP 820G and PTP 820F unit holds the UTC offset and daylight savings time information for the location of the unit. Each management unit presenting the information uses its own UTC offset to present the information in the correct time.



Note

If the unit is powered down, the time and date are saved for 96 hours (four days). If the unit remains powered down for longer, the time and date may need to be reconfigured.

To set the UTC time, enter the following command in root view:

```
root> platform management time-services utc set date-and-time <date-and-time>
```

To set the local time offset relative to UTC, enter the following command in root view:

```
root> platform management time-services utc set offset hours-offset <hours-offset> minutes-offset <minutes-offset>
```

To display the local time configurations, enter the following command in root view:

```
root> platform management time-services show status
```

Table 129 Local Time Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
date-and-time	Number	dd-mm-yyyy, hh:mm:ss where: dd = date mm = month yyyy= year hh = hour mm = minutes ss = seconds	Sets the UTC time.
hours-offset	Number	-12 – 13	The required hours offset (positive or negative) relative to GMT. This is used to offset the clock relative to GMT, according to the global meridian location.

Parameter	Input Type	Permitted Values	Description
minutes-offset	Number	0 – 59	The required minutes relative to GMT. This is used to offset the clock relative to GMT, according to the global meridian location.

The following command sets the GMT date and time to January 30, 2014, 3:07 pm and 58 seconds:

```
root> platform management time-services utc set date-and-time 30-01-2014,15:07:58
```

The following command sets the GMT offset to 13 hours and 32 minutes:

```
root> platform management time-services utc set offset hours-offset 13 minutes-offset 32
```

To set the daylight savings time parameters, enter the following command in root view:

```
root> platform management time-services daylight-savings-time set start-date-month <start-date-month> start-date-day <start-date-day> end-date-month <end-date-month> end-date-day <end-date-day> offset <offset>
```

Table 130 Daylight Savings Time CLI Parameters

Parameter	Input Type	Permitted Values	Description
start-date-month	Number	1 - 12	The month when Daylight Savings Time begins.
start-date-day	Number	1 - 31	The date in the month when Daylight Savings Time begins.
end-date-month	Number	1 - 12	The month when Daylight Savings Time ends.
end-date-day	Number	1 - 31	The date in the month when Daylight Savings Time ends.
offset	Number	0 - 23	The required offset, in hours, for Daylight Savings Time. Only positive offset is supported.

The following command configures daylight savings time as starting on May 30 and ending on October 1, with an offset of 20 hours.

```
root> platform management time-services daylight-savings-time set start-date-month 5 start-date-day 30 end-date-month 10 end-date-day 1 offset 20
```

The following is a sample output of the platform management time-services show status command:

```
root> platform management time-services show status
Local Time 04-03-2014,03:07:01
UTC date & time 04-03-2014,08:07:01
UTC offset hours -5
UTC offset minutes 0

Daylight Saving Time (DST) settings:
Start-Date <month/day> 3/9
End-Date <month/day> 11/1
Offset in hours 1
root>
```

Enabling the Interfaces (Interface Manager) (CLI)

The following are the default settings for the unit's interfaces:

- Ethernet traffic interfaces, the second management interface, and the Synchronization interface are disabled, and must be manually enabled as described below.
- Radio interfaces, the first management interface, and the TDM interface (optional) are automatically enabled.

To enable or disable an interface, enter the following command in root view:

```
root> platform if-manager set interface-type <interface-type> slot <slot>
port <port> admin <admin>
```



Note

To enable or disable an E1/DS1 interface, use the `pwe3 tdm enable slot` command. See [Configuring the E1/DS1 Parameters \(CLI\)](#).

Table 131 Interface Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
interface-type	Variable	ethernet radio management sync stm1oc3	ethernet - An Ethernet interface. radio - A radio interface management - A management interface. sync - A synchronization interface. stm1oc3 - The STM-1/OC-3 interface.
slot	Number	1	Always enter 1.
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 sync: 1 tdm: 1	The interface you want to enable or disable.
admin	Variable	up down	Enter up to enable the interface or down to disable the interface.

The following command enables Ethernet port 1:

```
root> platform if-manager set interface-type ethernet slot 1 port 1 admin
up
```

The following command enables an STM-1/OC-3 card in expansion slot 2:

```
root> platform if-manager set interface-type stm1oc3 slot 2 port 1 admin
up
```

The following command displays the status of all the interfaces in the unit:

```
root> platform if-manager show interfaces
```

Enabling the Second Management Interface (CLI)

To enable the second management interface, enter the following command in root view:

```
root> platform management local-mngt admin state set enable port mng2
```

To disable the second management interface, enter the following command in root view:

```
root> platform management local-mngt admin state set disable port mng2
```

To display the status of both management interfaces, enter the following command in root view:

```
root> platform management local-mngt admin state show port all
```

Configuring Cascading Interfaces (Optional) (CLI)

Ethernet interfaces 1 and 2 (GbE1/CS1 and GbE2/CS2) can be configured as normal GE traffic interfaces or as cascading interfaces. When operating in cascading mode, these interfaces can handle hybrid Ethernet and Native TDM traffic, enabling operators to create links among multiple units in a node for multi-directional applications based on hybrid Ethernet and Native or pseudowire TDM services.



Note

You cannot change the status of an interface (Cascading or Ethernet) if a service point is configured on the interface.

You cannot change the status of an interface (Cascading or Ethernet) if the interface belongs to a LAG.

You cannot set Auto Negotiation to **On** while the interface is configured as a Cascading interface.

To configure an interface as a cascading interface, go to interface view for the interface and enter the following command:

```
eth type eth [1/2]> port-cascading-set cascading <cascading>
```

To display whether or not an interface is configured as a cascading interface, go to interface view for the interface and enter the following command:

```
eth type eth [1/1]> port-cascading-show
```

Table 132 Cascading Interface CLI Parameters

Parameter	Input Type	Permitted Values	Description
cascading	Boolean	Cascading ethernet	Cascading – The interface is configured as a cascading interface. ethernet – The interface is configured as a non-cascading Ethernet interface.

For example, the following commands configure Ethernet port 2 as a cascading interface:

```
root> ethernet interfaces eth slot 1 port 2
eth type eth [1/2]> port-cascading-set cascading Cascading
```

Entering Radio View (CLI)

To view and configure radio parameters, you must first enter the radio's view level in the CLI.

To enter a radio's view level, enter the following command in root view:

```
root> radio slot <slot> port <port>
```

The following command enters radio view for radio interface 1:

```
root> radio slot 1 port 1
```

The following prompt appears:

```
radio[1/1]>
```

The following command enters radio view for radio interface 2:

```
root> radio slot 1 port 2
```

The following prompt appears:

```
radio[1/2]>
```

Unmuting a Radio (CLI)

To mute or unmute the radio, go to radio view and enter the following command:

```
radio[x/x]>rf mute set admin <admin>
```

To display the mute status of a radio, go to radio view and enter the following command:

```
radio[x/x]>rf mute show status
```

Table 133 Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the radio.

The following command mutes radio interface 1:

```
radio[1/1]>rf mute set admin on
```

The following command unmutes radio interface 2:

```
radio[1/2]>rf mute set admin off
```

Configuring the Transmit (TX) Level (CLI)

To set the transmit (TX) level of a radio, go to radio view and enter the following command:

```
radio[x/x]>rf set tx-level <tx-level>
```

To display the maximum transmit (TX) level of a radio, go to radio view and enter the following command:

```
radio[x/x]>rf show max-tx-level
```

Table 134 Radio Transmit (TX) Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	PTP 820G units: -1 to 22	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of radio interface 1 to 10 dBm:

```
radio[2/1]>rf set tx-level 10
```

Configuring the Transmit (TX) Frequency (CLI)

To set the transmit (TX) frequency of a radio, enter the following command in radio view. This command automatically sets the remote RX frequency in parallel, unless you set the `local-remote` attribute to `disable`:

```
radio[x/x]>rf set tx-frequency <tx-frequency> local-remote <local-remote>
```

Table 135 Radio Transmit (TX) Frequency CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-frequency	Number	Depends on the MRMC script and the unit type.	The desired TX frequency (in KHz) and, if <local-remote> is set to enable, the desired RX frequency of the remote unit.
local-remote	Variable	enable disable	Optional. Determines whether to apply the configured TX frequency value to the RX frequency of the remote unit.

The following command sets the TX frequency of radio interface 1 to 12900000 KHz, and sets the RX frequency of the remote unit to the same value.

```
radio[1/1]>rf set tx-frequency 12900000
```

The following command sets the TX frequency of radio interface 2 to 12900000 KHz, but does not set the RX frequency of the remote unit.

```
radio[1/2]>rf set rx-frequency 12900000 local-remote disable
```

Configuring the Radio (MRMC) Script(s) (CLI)

Multi-Rate Multi-Constellation (MRMC) radio scripts define how the radio utilizes its available capacity. Each script is a pre-defined collection of configuration settings that specify the radio's transmit and receive levels, link modulation, channel spacing, and bit rate. Scripts apply uniform transmit and receive rates that remain constant regardless of environmental impact on radio operation.

To display all scripts that are available for a specific radio carrier in your unit, enter the following command in radio view:

```
radio[x/x]>mrmc script show script-type <script-type> acm-support <acm-support>
```



Note

The list of available scripts reflects activation-key-enabled features. Only scripts within your activation-key-enabled capacity will be displayed.

Displaying Available MRMC Scripts (CLI)

To display all scripts that are available for a specific radio carrier in your unit, go to radio view and enter the following command:

```
radio[x/x]>mrmc script show script-type <script-type> acm-support <acm-support>
```



Note

The list of available scripts reflects activation-key-enabled features. Only scripts within your activation-key-enabled capacity will be displayed.

Table 136 MRMC Script CLI Parameters

Parameter	Input Type	Permitted Values	Description
script-type	Variable	normal asymmetrical	Determines the type of scripts to be displayed: normal – Scripts for symmetrical bandwidth. asymmetrical – Scripts for asymmetrical bandwidth. Note: Asymmetrical scripts are not supported in this release.

Parameter	Input Type	Permitted Values	Description
acm-support	Boolean	yes no	Determines whether to display scripts that support Adaptive Coding Modulation (ACM). In ACM mode, a range of profiles determines Tx and Rx rates. This allows the radio to modify its transmit and receive levels in response to environmental conditions.

The following commands display available symmetrical (normal) scripts with ACM support for radio interface 1:

```

root> radio slot 1 port 1
radio [1/1]>mrmc script show script-type normal acm-support yes

Script |Script-Name
ID# |
-----
<1003> |mdN_A5656N_145_1003
<1004> |mdN_A2828N_149_1004
<1005> |mdN_A2828N_130_1005
<1006> |mdN_A5656N_129_1006
<1007> |mdN_A4040N_119_1007
<1008> |mdN_A0707N_121_1008
<1009> |mdN_A1414N_113_1009
<1010> |mdN_A5050N_111_1010
<1020> |mdN_A1010N_100_1020
<1021> |mdN_A2020N_100_1021
<1203> |mdN_A5656X_105_1203
<1204> |mdN_A2828X_113_1204
<1205> |mdN_A2828X_111_1205
<1206> |mdN_A5656X_101_1206
<1207> |mdN_A4040X_109_1207
<1210> |mdN_A5050X_104_1210
<1214> |mdN_A2828X_102_1214
<1217> |mdN_A4040X_102_1217
<1222> |mdN_A2525X_103_1222
-----
radio [1/1]>

```

Assigning an MRMC Script to a Radio Carrier (CLI)

Once you have a list of valid scripts, you can assign a script to the radio carrier. The command syntax differs depending on whether you are assigning a script with ACM support or a script without ACM support.



Note

When you enter a command to change the script, a prompt appears informing you that changing the script will reset the unit and affect traffic. To continue, enter **yes**. Changing the maximum or minimum profile does not reset the radio interface.

To assign a script with ACM enabled, go to radio view and enter the following command:

```
radio[x/x]> mrmc set acm-support script-id <script-id> modulation
adaptive max-profile <profile>
```

To assign a script without ACM enabled, go to radio view and enter the following command:

```
radio[x/x]> mrmc set acm-support script-id <script-id> modulation fixed
profile <profile>
```

To display the current MRMC script configuration, go to radio view and enter the following command:

```
radio[x/x]>mrmc show script-configuration
```

Table 137 MRMC Script Assignment to Radio Carrier CLI Parameters

Parameter	Input Type	Permitted Values	Description
script-id	Number	Depends on available scripts.	The ID of the script you want to assign to the radio carrier.
modulation	Variable	adaptive fixed	Determines whether ACM is enabled (adaptive) or disabled (fixed).
max-profile	Number	For fixed interfaces and RMC-B: 0 – 10 For RMC-A: 0 – 7	Adaptive ACM mode only: The maximum profile for the script. For example, if you select a maximum profile of 5, the system will not climb above profile 5, even if channel fading conditions allow it.
min-profile	Number	For fixed interfaces and RMC-B: 0 – 10 For RMC-A: 0 – 7	Adaptive ACM mode only: The minimum profile for the script. For example, if you select a minimum profile of 3, the system will not go below profile 3 regardless of the channel fading conditions. The minimum profile cannot be greater than the maximum profile, but it can be equal to it. If you do not include this parameter in the command, the minimum profile is set at the default value of 0.

Parameter	Input Type	Permitted Values	Description
profile	Number	For fixed interfaces and RMC-B: 0 – 10 For RMC-A: 0 – 7	Fixed ACM mode only: The profile in which the system will operate

The following command assigns MRMC script ID 1204, with ACM enabled, a minimum profile of 3 and a maximum profile of 8, to radio interface 2:

```
radio[1/2]>mrmc set acm-support script-id 1204 modulation adaptive max-profile 8 min profile 3
```

The following command assigns MRMC script ID 1204, with ACM disabled and a maximum profile of 5, to radio interface 1:

```
radio[1/1]>mrmc set acm-support script-id 1204 modulation fixed profile 5
```

Enabling ACM with Adaptive Transmit Power (CLI)

This feature requires:

- ACM script
- When working with RFU-C, requires RFU software version 2.17 or above

When planning ACM-based radio links, the radio planner attempts to apply the lowest transmit power that will perform satisfactorily at the highest level of modulation. During fade conditions requiring a modulation drop, most radio systems cannot increase transmit power to compensate for the signal degradation, resulting in a deeper reduction in capacity. The PTP 820G or PTP 820F is capable of adjusting power on the fly, and optimizing the available capacity at every modulation point.

To enable Adaptive TX Power for a radio, enter the following command in radio view:

```
radio[x/x]>rf adaptive-power admin enable
```

To disable Adaptive TX Power for a radio, enter the following command in radio view:

```
radio[x/x]>rf adaptive-power admin disable
```

To display whether Adaptive TX Power is enabled, enter the following command in radio view:

```
radio[x/x]>rf adaptive-power show status
```

The output of this command is:

```
radio [x/x]>rf adaptive-power show status
RF adaptive power admin status: [enable/disable]
RF adaptive power operational status: [up/down]
```

RF adaptive power operational status: Up means the feature is enabled and fully functional for that radio link. Note that the feature is configured and operates independently for each radio link.

Configuring the RSL Threshold Alarm (CLI)

You can enable an alarm to be triggered in the event that the RSL falls beneath a defined threshold. This alarm is alarm ID 1610, *Radio Receive Signal Level is below the configured threshold*. By default, the alarm is disabled.

To enable the RSL threshold alarm, enter the following command in radio view:

```
radio[x/x]> rf rsl-degradation set admin enable
```

To disable the RSL threshold alarm, enter the following command in radio view:

```
radio[x/x]> rf rsl-degradation set admin disable
```

To set the threshold of the RSL threshold alarm, enter the following command in radio view:

```
radio[x/x]> rf rsl-degradation set threshold <-99-0>
```

The default threshold is -68 dBm.

To display the current alarm configuration, enter the following command in radio view:

```
radio[x/x]> rf rsl-degradation show status
```

The following commands enable the RSL threshold alarm for fixed radio interface 1 and set the threshold to -55 dBm.

```
root> radio slot 1 port 1
radio [1/1]>rf rsl-degradation set admin enable
radio [1/1]>rf rsl-degradation set threshold -55
radio [1/1]>rf rsl-degradation show status

RSL degradation alarm admin: enable
RSL degradation threshold: -55
radio [1/1]>
```

The alarm is cleared when the RSL goes above the configured threshold. The alarm is masked if the radio interface is disabled, the radio does not exist, or a communication-failure alarm (Alarm ID #1703) is raised.

Operating in FIPS Mode (CLI)

From release 8.3, PTP 820G can be configured to be FIPS 140-2-compliant in specific hardware and software configurations, as described in this section.

**Note**

FIPS 140-2 compliance is only available with the PTP 820 Assured platform. System release 10.0 cannot be used in PTP 820 Assured platforms. For PTP 820 Assured, use System release 8.3

Requirements for FIPS Compliance (CLI)

It is the responsibility of the customer to ensure that these requirements are met.

For details on hardware requirements for operating in FIPS mode, see [Requirements for FIPS Compliance](#).

Enabling FIPS Mode (CLI)

To set the unit to operate in FIPS mode, enter the following command in root view:

```
root> platform security fips-mode set admin enable
```

To disable FIPS mode, enter the following command in root view:

```
root> platform security fips-mode set admin disable
```

**Note**

Changing the FIPS configuration causes a unit reset.

To display the unit's current FIPS setting, enter the following command in root view:

```
root> platform security fips-mode show
```

Status values are:

- **enable** – FIPS mode is enabled.
- **disable** – FIPS mode is disabled.

After enabling FIPS:

- The MD5 option for SNMPv3 is blocked.
- After any system reset, the length of time before users can log back into the system is longer than usual due to FIPS-related self-testing.

Chapter 15: Configuration Guide (CLI)

This section includes:

- [System Configurations \(CLI\)](#)
- [Configuring a 1+0 Link \(CLI\)](#)
- [Configuring Multi-Carrier ABC \(CLI\)](#)
- [Configuring Link Aggregation \(LAG\) and LACP \(CLI\)](#)
- [Configuring XPIC \(CLI\)](#)
- [Configuring HSB Radio Protection \(CLI\)](#)

System Configurations (CLI)

This section lists basic system configurations and their prerequisites, with links to configuration instructions.

This section includes:

- [Radio Configurations \(CLI\)](#)
- [TDM Configurations](#)



Note

For an up-to-date description of feature and configuration limitations, refer to the Release Notes for version 10.0.

Radio Configurations (CLI)

A PTP 820G or PTP 820F system can be used in the following radio configurations.



Note

One Multi-Carrier ABC group can be configured per unit.

Table 138 Radio Configuration PTP 820F

Configuration	Special Requirements	Link to Configuration Instructions
1+0		Configuring a 1+0 Link (CLI)
2+0 Single Polarization	Requires Multi-Carrier ABC or LAG	Configuring Multi-Carrier ABC (CLI) Configuring Link Aggregation (LAG) and LACP (CLI)
2+0 Dual Polarization (XPIC)	Requires Multi-Carrier ABC or LAG	Configuring XPIC (CLI) Configuring Multi-Carrier ABC (CLI) Configuring Link Aggregation (LAG) and LACP (CLI)

Table 139 Radio Configurations PTP 820G

Configuration	Special Requirements	Link to Configuration Instructions
1+0		Configuring a 1+0 Link (CLI)

Configuration	Special Requirements	Link to Configuration Instructions
2+0 Single Polarization	Requires Multi-Carrier ABC or LAG	<ul style="list-style-type: none"> • Configuring Multi-Carrier ABC (CLI) • Configuring Link Aggregation (LAG) and LACP (CLI)
2+0 Dual Polarization (XPIC)	Requires Multi-Carrier ABC or LAG	<ul style="list-style-type: none"> • Configuring Multi-Carrier ABC (CLI) • Configuring XPIC (CLI) • Configuring Link Aggregation (LAG) and LACP (CLI)
1+1 HSB Protection		Configuring HSB Radio Protection (CLI)
1+1 HSB Protection with BBS Space Diversity	Requires Multi-Carrier ABC	<ul style="list-style-type: none"> • Configuring HSB Radio Protection (CLI) • Configuring Multi-Carrier ABC (CLI)

TDM Configurations

PTP 820G provides integrated support for transportation of TDM (E1/DS1) services with integrated E1/DS1 interfaces.

Two types of TDM services are supported using the same hardware:

- Native TDM trails.
- TDM Pseudowire services (enabling interoperability with third party packet/PW equipment).

PTP 820G and PTP 820F also offers hybrid Ethernet and TDM services. Hybrid services can utilize either Native TDM or pseudowire.

PTP 820G and PTP 820F offers a variety of path protection options.

[Table 140](#) lists the basic TDM configuration options, with links to configuration instructions.

Table 140 TDM Configurations

Configuration	Special Requirements	Link to Configuration Instructions
Native TDM Services	Requires E1/DS1 interface.	Configuring Native TDM Trails (CLI)
Native TDM Services with Path Protection	Requires E1/DS1 interface.	Configuring Native TDM Trails (CLI)
Pseudowire TDM Services	Requires E1/DS1 interface.	Configuring TDM Pseudowire Services (CLI)
Pseudowire TDM Services with Path Protection	Requires E1/DS1 interface.	Configuring TDM Pseudowire Services (CLI)

Configuring a 1+0 Link (CLI)

To configure a 1+0 link, you must perform the following steps:

- 1 Unmute the radio. See [Unmuting a Radio \(CLI\)](#).
- 2 Configure the radio's TX level. See [Configuring the Transmit \(TX\) Level \(CLI\)](#).
- 3 Configure the radio's frequency. See [Configuring the Transmit \(TX\) Frequency \(CLI\)](#).
- 4 Configure the radio's MRMC script. See [Configuring the Radio \(MRMC\) Script\(s\) \(CLI\)](#).

Configuring Multi-Carrier ABC (CLI)

**Note**

For PTP 820F, Multi-Carrier ABC requires a MultiCore RFU-D.

This section includes:

- [Multi-Carrier ABC Overview \(CLI\)](#)
- [Configuring a Multi-Carrier ABC Group \(CLI\)](#)
- [Removing Members from a Multi-Carrier ABC Group \(CLI\)](#)
- [Deleting a Multi-Carrier ABC Group \(CLI\)](#)

Multi-Carrier ABC Overview (CLI)

Multi-Carrier Adaptive Bandwidth Control (ABC) enables multiple separate radio carriers to be shared by a single Ethernet port. This provides an Ethernet link over the radio with the total sum of the capacity of all the radios in the group, while still behaving as a single Ethernet interface. In Multi-Carrier ABC mode, traffic is dynamically divided among the carriers, at the Layer 1 level, without requiring Ethernet Link Aggregation.

Load balancing is performed regardless of the number of MAC addresses or the number of traffic flows. During fading events which cause ACM modulation changes, each carrier fluctuates independently with hitless switchovers between modulations, increasing capacity over a given bandwidth and maximizing spectrum utilization. The result is 100% utilization of radio resources in which traffic load is balanced based on instantaneous radio capacity per carrier.

One Multi-Carrier ABC group that includes both radio interfaces can be configured per unit.

**Note**

If the modulation of a radio carrier in the Multi-Carrier ABC group drops to Profile 0, that carrier is removed from the group until modulation returns to Profile 1 or higher.

In this version, one Multi-Carrier ABC group that includes both radio carriers can be configured per unit. The MRMC scripts for both radio carriers must be identical.

Configuring a Multi-Carrier ABC Group (CLI)

The Multi-Carrier ABC group configuration procedure is different for PTP 820F, on one hand, and PTP 820G, on the other.

For PTP 820F, Multi-Carrier ABC is configured between the two carriers of the same RFU (RFU-D or RFU-D-HP).

For PTP 820G, Multi-Carrier ABC is configured between different radio interfaces connected to different RFUs.

**Note**

Radio slot 2 port 1 should always be configured on channel 1 while Radio slot 2 port 2 should always be configured on channel 2.

Configuring Multi-Carrier ABC for PTP 820F (CLI)

To configure a Multi-Carrier ABC group for PTP 820F (CLI):

1. Create the group by entering the following command in root view.

```
root> multi-carrier-abc create group group_id 1 slot 1 type RFU
```

2. Add members to the group by entering the following commands to enter Multi-Carrier ABC Group view and attaching both carriers of the RFU (ports) to the group.

```
root> multi-carrier-abc group-id <1-4> slot <slot> type RFU
multi-carrier-abc group-id 1 slot 1
multi-carrier-abc group-id [x]> attach-member slot 1 port 1 channel-id <1-16>
multi-carrier-abc group-id [x]> attach-member slot 1 port 2 channel-id <1-16>
```

The Channel ID identifies the interface within the group.

3. To set the amount of bandwidth in the Multi-Carrier ABC group, in kbps, reserved for Ethernet traffic, enter the following command in Multi-Carrier ABC Group view:

```
multi-carrier-abc group-id 1 slot 1 high-pri-ethernet-bandwidth set <1-2147483647>
```

**Note**

If you are managing the unit using in-band management, it is strongly recommended to set this parameter to a value that will ensure that sufficient Ethernet bandwidth is available at all times for management traffic. The default value is 0..

The following commands create a Multi-Carrier ABC group with the two carriers of an RFU-D or RFU-D-HP, and assign 100000 kbps to Ethernet traffic.

```
root> multi-carrier-abc create group group_id 1 slot 1 type RFU
root> multi-carrier-abc group-id 1 slot 1 type RFU
multi-carrier-abc group-id [1] slot [1]>attach-member slot 1 port 1
channel-id 1
multi-carrier-abc group-id [1] slot [1]>attach-member slot 1 port 2
channel-id 2
multi-carrier-abc group-id [1] slot [1]>
multi-carrier-abc group-id [1] slot [1]> high-pri-ethernet-bandwidth set
100000
multi-carrier-abc group-id [1] slot [1]> exit
```

Configuring Multi-Carrier ABC for PTP 820G (CLI)

To configure a Multi-Carrier ABC group for PTP 820G (CLI):

- 1 Create the group by entering the following command in root view:

```
root> multi-carrier-abc create group group_id 1
multi-carrier-abc group-id [1]>
```

- 2 Enter Multi-Carrier ABC Group view by entering the following command in root view:

```
root> multi-carrier-abc group-id [1]
```

- 3 Add members to the group as follows:

- o To add a radio carrier to the group, enter the following command in Multi-Carrier ABC Group view. Repeat this command for each radio carrier you want to add.

```
multi-carrier-abc group-id [1]> attach-member slot 2 port <port> channel-
id <1-16>
```

The Channel ID identifies the interface within the group.

- 4 Repeat for the second radio carrier.

The following commands create a Multi-Carrier ABC group.

```
root> multi-carrier-abc create group group_id 1
multi-carrier-abc group-id[1]> attach-member slot 2 port 1 channel-id 1
multi-carrier-abc group-id[1]> attach-member slot 2 port 2 channel-id 2
multi-carrier-abc group-id[1]> exit
```

Removing Members from a Multi-Carrier ABC Group (CLI)

To remove members from a Multi-Carrier ABC group:

- 1 To remove an individual radio carrier from the Multi-Carrier ABC group, go to Multi-Carrier ABC group view and enter the following command:

```
multi-carrier-abc group-id[1]> detach-member channel-id <channel-id>
```

- 2 To remove a protection group member from the Multi-Carrier ABC group, go to Multi-Carrier ABC group view and enter the following command:

```
multi-carrier-abc group-id[1]> detach-group channel-id <channel-id>
```

Deleting a Multi-Carrier ABC Group (CLI)



Note

For instructions on deleting a Multi-Carrier ABC/HSB-SD group, see [Deleting an HSB Radio Protection Group with Space Diversity \(CLI\)](#).

To delete a Multi-Carrier ABC group:

2. 1 Remove the members from the group. See [Removing Members from a Multi-Carrier ABC Group \(CLI\)](#).

3. 2 To delete a Multi-Carrier ABC group on a PTP 820F enter the following command in root view:

```
root> multi-carrier-abc delete group group_id 1 slot 1 type RFU
```

4. To delete a Multi-Carrier ABC group on a PTP 820G enter the following command in root view:

```
root> multi-carrier-abc delete group group_id 1 slot 1
```

Configuring Link Aggregation (LAG) and LACP (CLI)

Link aggregation (LAG) enables you to group several physical Ethernet or radio interfaces into a single logical interface bound to a single MAC address. This logical interface is known as a LAG group. Traffic sent to the interfaces in a LAG group is distributed by means of a load balancing function. PTP 820G uses a distribution function of up to Layer 4 in order to generate the most efficient distribution among the LAG physical ports.

This section explains how to configure LAG and includes the following topics:

- [LAG Overview \(CLI\)](#)
- [Configuring a LAG Group \(CLI\)](#)
- [Configuring LACP \(CLI\)](#)
- [Configuring LACP \(CLI\)](#)
- [To enable LACP on a LAG group, go to interface view for the LAG and enter the following command:](#)
- `eth group [lagx]> lACP admin set enable`

To disable LACP on a LAG group, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> lACP admin set disable
```

To display whether or not LACP is enabled on a LAG group, go to interface view for the LAG and enter the following command:

```
eth group [lagx]>lACP admin show
```

The following commands enable LACP for LAG group 1:

```
root> ethernet interfaces group lag1  
eth group [lag1]>lACP admin set enable  
eth group [lag1]>
```

- [Enabling and Disabling the LAG Group Shutdown in case of Degradation Event Option \(CLI\)](#)
- [Configuring Enhanced LAG Distribution \(CLI\)](#)
- [Deleting a LAG Group \(CLI\)](#)
- [Displaying LACP Parameters and Statistics \(CLI\)](#)

LAG Overview (CLI)

Link aggregation (LAG) enables you to group several physical Ethernet or radio interfaces into a single logical interface bound to a single MAC address. This logical interface is known as a LAG group. Traffic sent to the interfaces in a LAG group is distributed by means of a load balancing function. PTP 820G uses a distribution function of up to Layer 4 in order to generate the most efficient distribution among the LAG physical ports.

LAG can be used to provide interface redundancy, both on the same card (line protection) and on separate cards (line protection and equipment protection).

LAG can also be used to aggregate several interfaces in order to create a wider (aggregate) link. For example, LAG can be used to create a 4 Gbps channel.

You can create up to four LAG groups. The following restrictions exist with respect to LAG groups:

- Only physical interfaces (including radio interfaces), not logical interfaces, can belong to a LAG group.
- Cascading interfaces cannot belong to a LAG group. See *Configuring Cascading Interfaces (Optional) (CLI)*.
- Interfaces can only be added to the LAG group if no services or service points are attached to the interface.
- Any classification rules defined for the interface are overridden by the classification rules defined for the LAG group.
- When removing an interface from a LAG group, the removed interface is assigned the default interface values.

There are no restrictions on the number of interfaces that can be included in a LAG. It is recommended, but not required, that each interface in the LAG have the same parameters (e.g., speed, duplex mode).



Note

To add or remove an Ethernet interface to a LAG group, the interface must be in an administrative state of “down”. This restriction does not apply to radio interfaces. For instructions on setting the administrative state of an interface, see [Enabling the Interfaces \(Interface Manager\) \(CLI\)](#)

PTP 820 supports LACP, which expands the capabilities of static LAG and provides interoperability with third-party equipment that uses LACP. LACP improves the communication between LAG members. This improves error detection capabilities in situations such as improper LAG configuration or improper cabling. It also enables the LAG to detect uni-directional failure and remove the link from the LAG, preventing packet loss.

LACP is enabled as part of the LAG configuration process. It should only be used if the LAG is in a link with another LACP-enabled LAG.



Note

- LACP is not supported with unit redundancy. For unit redundancy, a special, limited implementation is configured on the logical interface level. See *Configuring Unit Redundancy for the PTP 820 Split Mount (CLI)*.
- LACP can only be used with Ethernet interfaces.
- LACP cannot be used with Enhanced LAG Distribution or with the LAG Group Shutdown in Case of Degradation Event feature.

Configuring a LAG Group (CLI)

To create a LAG group, go to interface view for the first interface you want to assign to the LAG and enter the following command:

```
eth type eth [x/x]> static-lag add lagid <lag1|lag2|lag3|lag4>
```

Repeat this process for each interface you want to assign to the LAG.

To remove an Ethernet member interface from a LAG, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> port static-lag remove member interface eth slot <slot>  
port <port>
```

To remove a radio member interface from a LAG, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> port static-lag remove member interface radio slot
<slot> port <port>
```

To display the name of a LAG to which an interface belongs, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> static-lag show name
```

To enter interface view for a LAG, enter the following command in root view:

```
root> ethernet interfaces group <lag1|lag2|lag3|lag4>
```

To display details about a LAG, go to interface view for the LAG: and enter the following command:

```
eth group [lagx]> summary show
```

To display a LAG's operational state, go to interface view for the LAG: and enter the following command:

```
eth group [lagx]> operational state show
```

To display a list of interfaces that belong to a LAG, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> port static-lag show members
```

The following commands create a LAG with the ID lag2. The LAG includes Ethernet ports 1, 2, and 3:

```
root> platform if-manager set interface-type ethernet slot 1 port 1 admin
down
root> platform if-manager set interface-type ethernet slot 1 port 2 admin
down
root> platform if-manager set interface-type ethernet slot 1 port 3 admin
down
root> ethernet interfaces eth slot 1 port 1
eth type eth [1/1]>
eth type eth [1/1]> static-lag add lagid lag2
eth type eth [1/1]> exit
root>
root> ethernet interfaces eth slot 1 port 2
eth type eth [1/2]>
eth type eth [1/2]> static-lag add lagid lag2
eth type eth [1/2]> exit
root>
root> ethernet interfaces eth slot 1 port 3
eth type eth [1/3]>
eth type eth [1/3]> static-lag add lagid lag2
eth type eth [1/3]> exit
root> platform if-manager set interface-type ethernet slot 1 port 1 admin
up
root> platform if-manager set interface-type ethernet slot 1 port 2 admin
up
root> platform if-manager set interface-type ethernet slot 1 port 3 admin
up
```

The following command displays the name of the LAG to which Ethernet port 1 belongs:

```
eth type eth [1/1]> static-lag show name
Static-lag group name: lag2
```

The following commands display details about the LAG::

```

root> ethernet interfaces group lag2
eth group [lag2]>
eth group [lag2]> port static-lag show members

Static-lag members
-----
Eth#[1/1]
Eth#[1/2]
Eth#[1/3]]

eth group [lag2]> summary show

Group lag2 Summary: Value
Port Description:
Port Admin state: enable
Port Operational state: down
Port Edge state: non-edge-port
Member Port#(1) 1/1
Member Port#(2) 1/2
Member Port#(3) 1/3

eth group [lag2]> operational state show

Port operational state: up.

eth group [lag2]>

```

The following commands remove Ethernet port 2 from the LAG:

```

root> platform if-manager set interface-type ethernet slot 1 port 2 admin
down
root> ethernet interfaces group lag2
eth group [lag2]>
eth group [lag2]> port static-lag remove member interface eth slot 1 port
2

```

Configuring LACP (CLI)

To enable LACP on a LAG group, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> lacp admin set enable
```

To disable LACP on a LAG group, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> lacp admin set disable
```

To display whether or not LACP is enabled on a LAG group, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> lacp admin show
```

The following commands enable LACP for LAG group 1:

```

root> ethernet interfaces group lag1
eth group [lag1]> lacp admin set enable
eth group [lag1]>

```

Enabling and Disabling the LAG Group Shutdown in case of Degradation Event Option (CLI)

**Note**

LAG Group Shutdown in Case of Degradation Event cannot be used with LACP.

A LAG group can be configured to be automatically closed in the event of LAG degradation. This option is used if you want traffic from the switch to be re-routed during such time as the link is providing less than a certain capacity.

By default, the LAG group shutdown in case of degradation event option is disabled. When enabled, the LAG is automatically closed in the event that any one or more ports in the LAG fail. When all ports in the LAG are again operational, the LAG is automatically re-opened.

**Note**

Failure of a port in the LAG also triggers a lag-degraded alarm, Alarm ID 100.

To enable the LAG group shutdown in case of degradation event option, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> static-lag set lag-degrade-admin admin enable
```

To disable the LAG group shutdown in case of degradation event option, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> static-lag set lag-degrade-admin admin disable
```

To display the current the LAG group shutdown in case of degradation event option setting, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> static-lag show lag-degrade-admin
```

The following commands enable the LAG group shutdown in case of degradation event option for LAG group 1:

```
root> ethernet interfaces group lag1
eth group [lag1]>static-lag set lag-degrade-admin admin enable
eth group [lag1]>
```

Configuring Enhanced LAG Distribution (CLI)

You can change the distribution function by selecting from ten pre-defined LAG distribution schemes. The feature includes a display of the TX throughput for each interface in the LAG, to help you identify the best LAG distribution scheme for the specific link.

**Note**

Enhanced LAG distribution is only available for LAG groups that consist of exactly two interfaces, it cannot be used with LACP.

To configure enhanced LAG distribution, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> static-lag set df-pattern df <1-10>
```

The following commands set the LAG distribution scheme for LAG group 1 as distribution pattern 3.

```
root> ethernet interfaces group lag1  
eth group [lag1]>static-lag set df-pattern df 3
```

The default LAG distribution pattern is 1.

To display the current LAG distribution scheme, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> static-lag show df-pattern
```

It is recommended to experiment with the various schemes by monitoring the TX port PMs for each interface in the LAG for each LAG distribution scheme. In the Web EMS, the page in which you configure enhanced LAG distribution also displays TX throughput PMs per interface. See [Configuring Enhanced LAG Distribution](#). For information on monitoring Ethernet port PMs via the CLI, see [Displaying Ethernet Port PMs \(CLI\)](#).

Deleting a LAG Group (CLI)

In order to delete a LAG group, you must first make sure that no service points are attached to the LAG group.

To delete a LAG group, simply delete all the members from the LAG, as described above.

Displaying LACP Parameters and Statistics (CLI)

You can display the following LACP parameters and statistics:

- LACP Aggregation (per LAG)
- LACP Port Status
- LACP Port Statistics
- LACP Port Debug Statistics



Note

PTP 820 does not support any LACP write parameters

Displaying LACP Aggregation Status Parameters (CLI)

To display LACP aggregation status parameters, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> lacp show status
```

```
root> ethernet interfaces group lag1
eth group [lag1]>lacp show status
=====
|   LACP LAG Configuration   |
=====
Admin key :                      0
System ID :                      0:0:0:0:0:0
System Priority :                  0
Aggregate or Individual :         0
Actor Oper Key:                   0
Agg MAC address :                 0:0:0:0:0:0
Partner System ID :               0:0:0:0:0:0
Partner System Priority :         0
Partner Oper Key :                0
Collector Max Delay :             0
eth group [lag1]>
```

Table 141 LACP aggregation status parameters

Parameter	Definition
-----------	------------

Admin Key	The current administrative value of the key for the Aggregator.
System ID	The MAC address value used as a unique identifier for the system that contains this Aggregator.
System Priority	The priority value associated with the Actor's System ID.
Aggregate or Individual	Indicates whether the Aggregator represents an aggregate or an individual link.
Actor Oper Key	The current operational value of the Key for the Aggregator.
Agg MAC Address	The individual MAC address assigned to the Aggregator.
Partner System ID	The MAC address value consisting of the unique identifier for the current protocol Partner of this Aggregator.
Partner System Priority	The priority value associated with the Partner's System ID.
Partner Oper Key	The current operational value of the Key for the Aggregator's current Protocol partner.
Collector Max Delay	The maximum delay, in tens of microseconds.

Displaying LACP Port Status Parameters (CLI)

To display LACP port status parameters, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> lacp show ports status
```

```

root> ethernet interfaces group lag1
eth group [lag1]>lacp show ports status
=====
|   LACP LAG Ports Configuration   |
=====
-----
                Ethernet: Slot 1, Port 1
-----

Port :                11                Partner Oper Port :                0
System Priority : 32768                Partner Oper System Priority : 0
Admin Key :           1                Partner Oper Key :                 0
System ID :           0:a:25:40:1f:8c   Partner Oper System ID :           0:0:0:0:0:0
Port Priority :       32768                Partner Oper Port Priority :       0

Actor State :   Active+Aggregatable+Defaulted
Partner State : None
Last RX Time:   0 seconds
Age:            382 seconds
RX State :      Defaulted
MUX State :     Detached
MUX reason:     Selected = False

-----
                Ethernet: Slot 1, Port 2
-----

Port :                12                Partner Oper Port :                0
System Priority : 32768                Partner Oper System Priority : 0
Admin Key :           1                Partner Oper Key :                 0
System ID :           0:a:25:40:1f:8c   Partner Oper System ID :           0:0:0:0:0:0
Port Priority :       32768                Partner Oper Port Priority :       0

Actor State :   Active+Aggregatable+Defaulted
Partner State : None
Last RX Time:   0 seconds
Age:            382 seconds
RX State :      Defaulted
MUX State :     Detached
MUX reason:     Selected = False
eth group [lag1]>

```

Table 142 LACP port status parameters

Parameter	Definition
System Priority	The priority value associated with the Actor's System ID.
Admin Key	The current administrative value of the Key for the Aggregation Port.
System ID	The MAC Address value that defines the value of the System ID for the system that contains this Aggregation Port.
Port Priority	The priority value assigned to this Aggregation Port.
Actor State	The current operational values of the Actor's state as transmitted by the Actor via LACPDU.
Partner State	The current values of Actor State in the most recently received LACPDU transmitted by the protocol Partner.
Last RX Time	The value of a TimeSinceSystemReset (F.2.1) when the last LACPDU was received by this Aggregation port.

Parameter	Definition
RX State	<p>The state of the receive state machine for the Aggregation port.</p> <p>Possible values are:</p> <p>Current – An LACPDU was received before expiration of the most recent timeout period.</p> <p>Expired – No LACPDU was received before expiration of the most recent timeout period.</p> <p>Defaulted – No LACPDU was received during the two most recent timeout periods.</p>
Mux State	<p>The state of the Mux state machine for the Aggregation port. Possible values are Collecting, Distributing, Attached, and Detached.</p>
Mux Reason	A text string indicating the reason for the most reason change in the state of the Mux machine.
Partner Oper Port	The operational port number assigned to this Aggregation port by the Aggregation port's port Partner.
Partner Oper System Priority	The operational value of priority associated with the Partner's System ID.
Partner Oper Key	The current operational value of the Key for the protocol Partner.
Partner Oper System ID	The MAC Address value representing the current value of the Aggregation Port's protocol Partner's System ID.
Partner Oper Port Priority	The Priority value assigned to this Aggregation port by the Partner.

Displaying LACP Port Statistics (CLI)

To display LACP port statistics, go to interface view for the LAG and enter the following command:

```
eth group [lagx]> lacp show ports statistics
```

```

eth group [lag1]>lacp show ports statistics
=====
|   LACP LAG Ports Statistics   |
=====
-----
                Ethernet: Slot 1, Port 1
-----
LACPDU Rx : 0
LACPDU Tx : 192
Illegal Rx: 0
Unknown Rx: 0
-----
                Ethernet: Slot 1, Port 2
-----
LACPDU Rx : 0
LACPDU Tx : 58
Illegal Rx: 0
Unknown Rx: 0
eth group [lag1]>

```

The following table describes the LACP port statistics.

Table 143 LACP port statistics.

Parameter	Definition
LACPDU RX	The number of LACPDU s that this port has received.
LACPDU TX	The number of LACPDU s that this port has transmitted.
Illegal RX	The number of illegal protocol frames that this port has received.
Unknown RX	The number of unknown protocol frames that this port has received.

Configuring XPIC (CLI)

Cross Polarization Interference Canceller (XPIC) is a feature that enables two radio carriers to use the same frequency with a polarity separation between them. Since they will never be completely orthogonal, some signal cancelation is required.

In addition, XPIC includes an automatic recovery mechanism that ensures that if one carrier fails, or a false signal is received, the mate carrier will not be affected. This mechanism also assures that when the failure is cleared, both carriers will be operational.

This section includes:

- [Prerequisites for XPIC \(CLI\)](#)
- [Configuring the Carriers \(CLI\)](#)
- [Creating an XPIC Group \(CLI\)](#)
- [Performing Antenna Alignment \(CLI\)](#)
- [Deleting an XPIC Group \(CLI\)](#)

Related topics:

- [Configuring the XPI Thresholds and Displaying the XPI PMs \(CLI\)](#)

Prerequisites for XPIC (CLI)

- For PTP 820F, XPIC requires a MultiCore RFU-D.
- For PTP 820G, each radio interface must be connected to the same type of RFU.
- Each radio carrier must be assigned the same script. The script must be an XPIC script. The script must be an XPIC script. The letter X (XPIC) or N (Non-XPIC) in the script name indicates whether or not the script supports XPIC. For example:
 - The script mdN_A2828X_102_1205 supports XPIC.
 - The script mdN_A2828N_123-1005 does not support XPIC.

Configuring the Carriers (CLI)

To configure the radio carriers:

1. Configure the carriers on both ends of the link to the desired frequency channel. Both carriers must be configured to the same frequency channel.
2. Assign XPIC (CCDP operational mode) support-enabled script to both RMCs on both ends of the link. Each RMC must be assigned the same script. See [Assigning an MRMC Script to a Radio Carrier \(CLI\)](#).

**Note**

XPIC support is indicated by an X in the script name. For example, mdN_A2828X_111_1205 is an XPIC-enabled script. mdN_A2828N_130_100 is not an XPIC-enabled script. For a list of XPIC support-enabled scripts, refer to the most recent PTP 820G Release Notes.

3. Create an XPIC group that consists of the two radio carriers that will be in the XPIC group. See [Creating an XPIC Group \(CLI\)](#).

Creating an XPIC Group (CLI)

To create an XPIC group:

1. Create the XPIC group by entering the following command in root view:

```
root> radio xpic create group <group> radio <slot> port <port> radio
<slot> port <port>
```

2. Enable the group by entering the following command in root view:

```
root> radio xpic set group <group id> admin enable
```

The following commands create and enable XPIC group 1 consisting of the two radio carriers of an RFU-D being used with an PTP 820F:

```
root> radio xpic create group 1 radio 1 port 1 radio 1 port 2
root> radio xpic set group 1 admin enable
```

Table 144 XPIC Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
Group	Number	1-4	The group ID of the XPIC group.
slot	Number	1	
port	Number	1-2	The radio carrier you want to add to the XPIC group.

Performing Antenna Alignment for XPIC (CLI)

1. Align the antennas for the first carrier. While you are aligning these antennas, mute the second carrier. See [Unmuting a Radio \(CLI\)](#).
2. Adjust the antenna alignment until you achieve the maximum RSL for the first-carrier link (the “RSL_{wanted}”). This RSL should be no more than +/-2 dB from the expected level. Record the RSL of the first carrier as the RSL_{wanted}.
3. Measure the RSL of the second carrier and record it as the “RSL_{unwanted}”.
4. Determine the XPI, using either of the following two methods:
 - To calculate the XPI, subtract the RSL_{unwanted} from the RSL_{wanted}.
 - Read the XPI from the Modem XPI field of the Radio Parameters page in the Web EMS. See [Viewing the Radio Status and Settings \(CLI\)](#).

- The XPI should be between 25dB and 30dB. If it is not, you should adjust the OMT assembly on the back of the antenna at one side of the link until you achieve the highest XPI, which should be no less than 25dB. Adjust the OMT very slowly in a right-left direction. OMT adjustment requires very fine movements and it may take several minutes to achieve the best possible XPI.

**Note**

As an extra step, to check the veracity of the initial measurements, you can mute the first carrier and unmute the second carrier on the upper carriers on both sides of the link. Then measure the RSL of the second carrier link (the “RSL_{wanted}”), measure the RSL of the first carrier (the “RSL_{unwanted}”) and determine the XPI. The XPI should match the XPI with the second carriers muted.

- Unmute all the carriers and check the RSL levels of all the carriers on both sides of the link. The RSL of the horizontal carrier of the local unit should match the RSL of the vertical carrier of the remote unit, within ± 2 dB. The RSL of the vertical carrier of the local unit should match the RSL of the horizontal carrier of the remote unit, within ± 2 dB.
- Check the XPI levels of both carriers on both sides of the link by checking the **Modem XPI** field of the Radio Parameters page in the Web EMS. See *Viewing the Radio Status and Settings*. All four carriers should have approximately the same XPI value. Do not adjust the XPI at the remote side of the link, as this may cause the XPI at the local side of the link to deteriorate.

**Note**

In some cases, the XPI might not exceed the required 25dB minimum due to adverse atmospheric conditions. If you believe this to be the case, you can leave the configuration at the lower values, but be sure to monitor the XPI to make sure it subsequently exceeds 25dB. A normal XPI level in clear sky conditions is between 25 and 30dB.

Deleting an XPIC Group (CLI)

In order to delete an XPIC group, you must first disable the group. Disable the group by entering the following command in root view:

```
root> radio xpic disable group <group id>
```

To delete an XPIC group, enter the following command in root view:

```
root> radio xpic delete group <group id>
```

You must then assign non-XPIC MRMC scripts to the radio carriers that were included in the XPIC pair.

The following commands disable and delete XPIC group 1:

```
root> radio xpic disable group 1
root> radio xpic delete group 1
```

Configuring HSB Radio Protection (CLI)



Note

This section is only relevant for PTP 820G.

This section includes:

- [HSB Radio Protection Overview \(CLI\)](#)
- [Configuring 1+1 HSB without Space Diversity \(CLI\)](#)
- [Configuring 1+1 HSB with Space Diversity \(CLI\)](#)
- [Copying Configuration to Mate \(CLI\)](#)
- [Revertive Mode \(CLI\)](#)
- [Switchovers and Lockout \(CLI\)](#)
- [Deleting an HSB Radio Protection Group \(CLI\) without Space Diversity](#)
- [Deleting an HSB Radio Protection Group with Space Diversity \(CLI\)](#)

HSB Radio Protection Overview (CLI)

In dual-carrier systems, PTP 820G offers 1+1 HSB radio protection. With Multi-Carrier ABC, you can also configure 1+1 HSB radio protection with BBS Space Diversity.

You can configure the two radio interfaces as a protection group, which protects against hardware failure in the RFU. The CPU monitors the radio interfaces and initiates switchover upon indication of a hardware or signal failure.

The radios in a protected pair operate in active and standby mode. If there is a failure in the active radio, the standby radio switches to active mode.

Configuring 1+1 HSB without Space Diversity (CLI)

To create a 1+1 HSB radio protection group without Space Diversity, Multi-Carrier ABC may not be configured on the unit.

To create a protection group:

- 1 Enter the following command in root view. Radio interface 1 will automatically be the active radio carrier.

```
root>radio protection create group <group> radio <radio> port <port>
radio <radio> port <port> type 1-plus-1-HSB
```

Table 145 1+1 HSB CLI Parameters

Parameter	Input Type	Permitted Values	Description
group	Number	1-4	The group ID of the protection group.
radio	Number	1	

Parameter	Input Type	Permitted Values	Description
port	Number	1-2	The interface you want to add to the protection group.

The following example creates a 1+1 HSB protection group with Group ID 1. Radio interface 1 will be the active radio carrier.

```
root> radio protection create group 1 radio 1 port 1 radio 1 port 2 type 1-plus-1-HSB
```

- 2 Configure the active radio carrier and perform a copy-to-mate command to ensure that the radios in the HSB pair have the same configuration. See [Copying Configuration to Mate \(CLI\)](#).
- 3 Optionally, you can enable revertive mode so that following a switchover, the system initiates a revertive protection switchover back to the original receiver once proper link and/or equipment conditions are restored. See [Revertive Mode \(CLI\)](#).

Configuring 1+1 HSB with Space Diversity (CLI)

To configure 1+1 HSB protection with Space Diversity, you must perform the following steps:

- 1 Create a Multi-Carrier ABC group with no members, in Admin state **Disable**. For instructions, see [Configuring a Multi-Carrier ABC Group \(CLI\)](#).
- 2 Enable protection for the Multi-Carrier ABC group by entering the following command in Multi-Carrier ABC group view:

```
multi-carrier-abc group-id[1]> protection set enable
```

- 3 Create a 1+1 HSB-SD protection group by entering the following command in root view. Radio interface 1 will automatically be the active radio carrier:

```
root> radio protection create group 1 radio 1 port 1 radio 1 port 2 type 1-plus-1-HSB-SD
```

- 4 Configure the active radio carrier and perform a copy-to-mate command to ensure that the radios in the HSB pair have the same configuration. See [Copying Configuration to Mate \(CLI\)](#).
- 5 When you have finished configuring the 1+1 HSB group, unmute both radio carriers on both sides of the link. See .
- 6 Optionally, you can enable revertive mode so that following a switchover, the system initiates a revertive protection switchover back to the original receiver once proper link and/or equipment conditions are restored. See [Revertive Mode \(CLI\)](#).
- 7 Add the 1+1 HSB-SD group to the Multi-Carrier ABC group by entering the following command in Multi-Carrier ABC group view:

```
multi-carrier-abc group-id[1]> attach-group group-id 1 type 1-plus-1-HSB-SD channel-id 1
```

Copying Configuration to Mate (CLI)

In a 1+1 HSB configuration, it is necessary for both radio carriers to have the same configuration. PTP 820G includes a mismatch mechanism that detects if there is a mismatch between the radio configurations of the local and mate radio carriers. This mechanism is activated by the system periodically and independently of other protection mechanisms, at fixed intervals. It is activated asynchronously for both the active and the standby radio carriers. Once the mismatch mechanism detects a configuration mismatch, it raises a Mate Configuration Mismatch alarm. When the configuration of the active and standby radio carriers is changed to be identical, the mechanism clears the Mate Configuration Mismatch alarm.

In order to align the configuration between the active and standby radio carriers, you must verify that at least one of the radio carriers is properly configured, and then perform a copy to mate command. This command copies the entire configuration from a selected radio in the protection pair to the other radio in the pair to achieve full configuration alignment between the radios in the pair. The command also initiates a reset of the radio carriers to which the configuration is copied. As soon as the radio to which the configuration was copied is up and running, its configuration is aligned to the configuration of the other radio. This operation has no effect on the source radio.

To perform a copy-to-mate command, enter the following command in root view:

```
root> radio protection copy-to-mate group <group> source-radio <radio>
source-port <port>
```

Parameter	Input Type	Permitted Values	Description
group	Number	1-4	The group ID of the protection group.
radio	Number	1	
port	Number	1-2	

The following command copies the configuration of the active radio carrier in protection group 1 (radio interface 1) to its standby radio carrier (radio interface 2):

```
root> radio protection copy-to-mate group 1 source-radio 1 source-port 1
```

Revertive Mode (CLI)

When revertive mode is enabled, following a switchover the system initiates a revertive protection switchover back to the original receiver once proper link and/or equipment conditions are restored. This ensures that the primary path is used whenever possible.

For HSB-SD groups, an additional revertive mode option enables you to configure revertive mode for diversity. If a diversity switchover takes place and revertive mode is enabled for diversity, the system initiates a revertive diversity switchover back to the original receiver once a proper signal is restored on the primary receiver.

To configure revertive mode, enter the following command in root view:

```
root> radio protection revertive group <group> admin <enable|disable> primary-
radio-slot <slot> primary-radio-port <port>
```

The following command enables protection revertive mode for protection group 1, with radio interface 1 designated as the primary radio:

```
root> radio protection revertive group 1 admin enable primary-radio-slot
1 primary-radio-port 1
```

To configure revertive mode for space diversity, enter the following command in root view:

```
root> radio protection set revertive-space-div <enable|disable> group
<group>
```

The following command enables diversity revertive mode for protection group 1:

```
root> radio protection set revertive-space-div enable group 1
```

Table 146 HSB Revertive Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
group	Number	1-4	The group ID of the protection group.
radio	Number	1	
port	Number	1-2	

Switchovers and Lockout (CLI)

The following events trigger switchover for 1+1 HSB protection according to their priority, with the highest priority triggers listed first.

- 1 Card missing
- 2 Lockout
- 3 Force switch
- 4 Traffic failures
- 5 Manual switch

To perform a manual switchover, use the following command:

```
root> radio protection manual-switch group <group#>
```

For example, to perform a manual switchover on group 1, use the following command:

```
root> radio protection manual-switch group 1
```

To perform a force switchover, use the following command:

```
root> radio protection force-switch group <group#>
```

For example, to perform a force switchover on group 1, use the following command:

```
root>radio protection force-switch group 1
```

To perform a lockout of a protection group, use the following command:

```
root> radio protection lock group <group#>
```

For example, to perform a lockout on group 1, use the following command:

```
root>radio protection lock group 1
```

To unlock a protection group that is in lockout mode, use the following command:

```
root> radio protection unlock group <group#>
```

For example, to unlock group 1, use the following command:

```
root> radio protection unlock group 1
```

Deleting an HSB Radio Protection Group (CLI) without Space Diversity



Note

Before deleting an HSB radio protection group, both members of the group must be unmuted. See [Unmuting a Radio \(CLI\)](#).

To delete a radio protection group, enter the following command in root view:

```
root>r adio protection delete group <group#>
```

The following example deletes protection group 2:

```
root> radio protection delete group 2
```

Deleting an HSB Radio Protection Group with Space Diversity (CLI)



Note

Before deleting an HSB radio protection group, both members of the group must be unmuted. See [Unmuting a Radio \(CLI\)](#).

To delete an HSB radio protection group with space diversity:

- 1 Remove the HSB-SD group from the Multi-Carrier ABC group. See [Removing Members from a Multi-Carrier ABC Group \(CLI\)](#).
- 2 Disable protection for the Multi-Carrier ABC group by entering the following command in Multi-Carrier ABC group view:

```
multi-carrier-abc group-id[1]> protection set disable
```
- 3 Delete the HSB-SD group. See [Deleting an HSB Radio Protection Group \(CLI\)](#).
- 4 Delete the Multi-Carrier ABC group. See [Deleting a Multi-Carrier ABC Group \(CLI\)](#).

Chapter 16: Unit Management (CLI)

This section includes:

- [Defining the IP Protocol Version for Initiating Communications \(CLI\)](#)
- [Configuring the Remote Unit's IP Address \(CLI\)](#)
- [Configuring SNMP \(CLI\)](#)
- [Configuring the Internal Ports for FTP or SFTP \(CLI\)](#)
- [Upgrading the Software \(CLI\)](#)
- [Backing Up and Restoring Configurations \(CLI\)](#)
- [Editing CLI Scripts \(CLI\)](#)
- [Setting the Unit to the Factory Default Configuration \(CLI\)](#)
- [Performing a Hard \(Cold\) Reset \(CLI\)](#)
- [Configuring Unit Parameters \(CLI\)](#)
- [Configuring NTP \(CLI\)](#)
- [Displaying Unit Inventory \(CLI\)](#)

Related topics:

- [Setting the Time and Date \(Optional\) \(CLI\)](#)
- [Enabling the Interfaces \(Interface Manager\) \(CLI\)](#)
- **Error! Reference source not found.**
- [Changing the Management IP Address \(CLI\)](#)

Defining the IP Protocol Version for Initiating Communications (CLI)

Select which IP protocol version the unit will use when initiating communications, such as downloading software, sending traps, pinging, or exporting configurations. The options are IPv4 or IPv6. To do so, enter the following command in root view:

```
root> platform management ip set ip-address-family <ipv4|ipv6>
```

To show the IP protocol version the unit will use when initiating communications, enter the following command in root view:

```
root> platform management ip show ip-address-family
```

Configuring the Remote Unit's IP Address (CLI)

You can configure the remote radio's IP address, subnet mask and default gateway in IPv4 format and/or in IPv6 format. The remote unit will receive communications whether they were sent to its IPv4 address or its IPv6 address.



Note

If you want to change the **Remote IP Address** to a different subnet, you must first change the address of the **Remote Default Gateway** to 0.0.0.0, then set the **Remote IP Address** as desired, and the **Remote Default Gateway** as desired.

Similarly, if you want to change the **Remote IPv6 Address** to a different subnet, you must first change the address of the **Remote IPv6 Default Gateway** to 0:0:0:0:0:0:0:0, then set the **Remote IPv6 Address** as desired, and the **Remote IPv6 Default Gateway** as desired.

Configuring the Remote Radio's IP Address in IPv4 format (CLI)

To configure the remote radio's default gateway, enter the following command in radio view:

```
radio[x/x]>remote-unit set default-gateway IP <ipv4-address>
```

To display the remote radio's default gateway, enter the following command in radio view:

```
radio[x/x]>remote-unit show default-gateway
```

To set the remote radio's IP Address, enter the following command in radio view:

```
radio[x/x]>remote-unit set ip-address <ipv4-address>
```

To display the remote radio's IP Address, enter the following command in radio view:

```
radio[x/x]>remote-unit show ip-address
```

To set the remote radio's subnet mask, enter the following command in radio view:

```
radio[x/x]>remote-unit set subnet-mask IP <subnet-mask>
```

To display the remote radio's subnet mask, enter the following command in radio view:

```
radio[x/x]>remote-unit show subnet-mask
```

Table 147 Remote Unit IP Address (IPv4) CLI Parameters

Parameter	Input Type	Permitted Values	Description
ipv4-address	Dotted decimal format.	Any valid IPv4 address.	Sets the default gateway or IP address of the remote radio.
subnet-mask	Dotted decimal format.	Any valid subnet mask.	Sets the subnet mask of the remote radio.

The following command sets the default gateway of the remote radio as 192.168.1.20:

```
radio[2/1]>remote-unit set default-gateway IP 192.168.1.20
```

The following commands set the IP address of the remote radio as 192.168.1.1, with a subnet mask of 255.255.255.255.

```
radio[2/2]>remote-unit set ip-address 192.168.1.1
```

```
radio[2/2]>remote-unit set subnet-mask IP 255.255.255.255
```

Configuring the Remote Radio's IP Address in IPv6 format (CLI)

To configure the remote radio's default gateway, enter the following command in radio view:

```
radio[x/x]>remote-unit set default-gateway-ipv6 IPv6 <ipv6-address>
```

To display the remote radio's default gateway, enter the following command in radio view:

```
radio[x/x]>remote-unit show default-gateway-ipv6
```

To set the remote radio's IP Address, enter the following command in radio view:

```
radio[x/x]>remote-unit set ip-address-ipv6 <ipv6-address>
```

To display the remote radio's IP Address, enter the following command in radio view:

```
radio[x/x]>remote-unit show ip-address-ipv6
```

To set the remote radio's prefix length , enter the following command in radio view:

```
radio[x/x]>remote-unit set prefix-length <prefix-length >
```

To display the remote radio's prefix-length , enter the following command in radio view:

```
radio[x/x]>remote-unit show prefix-length
```

Table 148 Remote Unit IP Address (IPv6) CLI Parameters

Parameter	Input Type	Permitted Values	Description
ipv6-address	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	Sets the default gateway or IP address of the remote radio.
prefix-length	Number	1-128	Sets the prefix length of the remote radio.

The following command sets the default gateway of the remote radio as FE80:0000:0000:0000:0202:B3FF:FE1E:8329 :

```
radio[2/1]>remote-unit set default-gateway-ipv6 IPv6  
FE80:0000:0000:0000:0202:B3FF:FE1E:8329
```

The following commands set the IP address of the remote radio as FE80:0000:0000:0000:0202:B3FF:FE1E:8329, with a prefix length of 64:

```
radio[2/2]>remote-unit set ip-address-ipv6  
FE80:0000:0000:0000:0202:B3FF:FE1E:8329
```

```
radio[2/2]>remote-unit set prefix-length 64
```

Configuring SNMP (CLI)

This section includes:

- [Configuring SNMP \(CLI\)](#)
- [Defining the SNMP Parameters \(CLI\)](#)
- [Displaying the SNMP Settings \(CLI\)](#)
- [Configuring Trap Managers \(CLI\)](#)

Configuring SNMP (CLI)

PTP 820G and PTP 820F supports SNMP v1, V2c, and v3. You can set community strings for access to IDUs.

PTP 820G and PTP 820F supports the following MIBs:

- RFC-1213 (MIB II)
- RMON MIB
- MIB (proprietary)

Defining the SNMP Parameters (CLI)

The following commands are relevant for all SNMP versions.

To enable SNMP, enter the following command in root view:

```
root> platform security protocols-control snmp admin set <admin>
```

To specify the SNMP version, enter the following command in root view:

```
root> platform security protocols-control snmp version set <version>
```

To specify the SNMP read and write communities, enter the following command in root view:

```
root> platform security protocols-control snmpv1v2 set read-community  
<read-community> write-community <write-community>
```

The following commands are relevant for SNMPv3.

To block SNMPv1 and SNMPv2 access so that only SNMPv3 access will be enabled, enter the following command in root view:

```
root> platform security protocols-control snmp v1v2-block set <set-block>
```

To block SNMPv1 and SNMPv2 access so that only SNMPv3 access will be enabled, enter the following command in root view:

```
root> platform security protocols-control snmp v1v2-block set <set-block>
```

To add an SNMPv3 user, enter the following command in root view:

```
root> platform security protocols-control snmp v3-authentication add v3-  
user-name <v3-user-name> v3-user-password <v3-user-password> v3-security-  
mode <v3-security-mode> v3-encryption-mode <v3-encryption-mode> v3-auth-  
algorithm <v3-auth-algorithm> v3-access-mode <v3-access-mode>
```

To remove an SNMP v3 user, enter the following command in root view:

```
root> platform security protocols-control snmp v3-authentication remove
v3-user-name <user-name>
```

To display all SNMP v3 users and their authentication parameters, enter the following command in root view:

```
root> platform security protocols-control snmp v3-authentication show
```

Table 149 SNMPv3 CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	enable disable	Select enable to enable SNMP monitoring, or disable to disable SNMP monitoring.
version	Variable	v1 v2 v3	Select v1, v2, or v3 to specify the SNMP version.
read-community	Text String	Any valid SNMP read community.	The community string for the SNMP read community.
write-community	Text String	Any valid SNMP write community.	The community string for the SNMP write community.
set-block	Variable	yes no	yes - SNMPv1 and SNMPv2 access is blocked. no - SNMPv1 and SNMPv2 access is not blocked.
v3-user-name	Text String		A SNMPv3 user name.
v3-user-password	Text String	Must be at least eight characters.	A SNMPv3 user password.
v3-security-mode	Variable	authNoPriv authPriv noAuthNoPriv	Defines the security mode to be used for this user.
v3-encryption-mode	Variable	None DES AES	Defines the encryption (privacy) protocol to be used for this user.
v3-auth-algorithm	Variable	None SHA MD5	Defines the authentication algorithm to be used for this user.
v3-access-mode	Variable	readWrite readOnly	Defines the access permission level for this user.

The following commands enable SNMP v2 on the unit, and set the read community to “public” and the write community to “private”:

```
root> platform security protocols-control snmp admin set enable
root> platform security protocols-control snmp version set v2
root> platform security protocols-control snmpv1v2 set read-community
public write-community private
```

The following commands enable SNMP v3 on the unit, block SNMP v1 and SNMP v2 access, and define an SNMPv3 user with User Name=Geno, Password=abcdefgh, security mode authPriv, encryption mode DES, authentication algorithm SHA, and read-write access:

```
root> platform security protocols-control snmp admin set enable
root> platform security protocols-control snmp version set v3
root> platform security protocols-control snmp v1v2-block set yes
root> platform security protocols-control snmp v3-authentication add v3-
user-name geno v3-user-password abcdefgh v3-security-mode authPriv v3-
encryption-mode DES v3-auth-algorithm SHA v3-access-mode readwrite
```

Displaying the SNMP Settings (CLI)

To display the general SNMP parameters, enter the following command in root view:

```
root> platform security protocols-control snmp show-all
```

To display the current MIB version used in the system, enter the following command in root view:

```
root> platform security protocols-control snmp show-mib-version
```

To display details about the current MIB version used in the system, enter the following command in root view:

```
root> platform security protocols-control snmp show-mib-version-table
```

To display the SNMP read and write communities, enter the following command in root view:

```
root> platform security protocols-control snmpv1v2 show
```

Configuring Trap Managers (CLI)

In this version, trap manager configuration should be performed via the Web EMS. See [Configuring Trap Managers](#).

Configuring the Internal Ports for FTP or SFTP (CLI)

By default, the following PTP 820 ports are used for FTP and SFTP when the PTP 820 unit is acting as an FTP or SFTP client (e.g., software downloads, configuration file backup and restore operations):

- FTP – 21
- SFTP – 22

To change the port for either protocol, enter the following command in root view:

```
root> platform management file-transfer port-config protocol <ftp|sftp>
port-number <0-65535>
```

To display the ports that are currently configured for FTP and SFTP, enter the following command in root view:

```
root> platform management file-transfer port-show
```

These ports are configured globally, rather than per specific operation.

The following sequence of commands displays the current (default) FTP and SFTP port settings, changes the FTP port to 125 and the SFTP port to 126, and shows the new FTP and SFTP port settings.

```
root>platform management file-transfer port-show
Port config table:
=====
File transfer   File transfer port
protocol        number
=====
ftp             21
sftp           22

root> platform management file-transfer port-config protocol ftp port-
number 125

root> platform management file-transfer port-config protocol sftp port-
number 126

root>platform management file-transfer port-show
Port config table:
=====
File transfer   File transfer port
protocol        number
=====
ftp             125
sftp           126

root>
```

Upgrading the Software (CLI)

This section includes:

- [Software Upgrade Overview \(CLI\)](#)
- [Displaying Current Software Versions \(CLI\)](#)
- [Configuring a Software Download \(CLI\)](#)
- [Downloading a Software Package \(CLI\)](#)
- [Installing and Upgrading Software \(CLI\)](#)
- [Installing and Upgrading Software in the RFU \(CLI\)](#)

Software Upgrade Overview (CLI)

PTP 820G and PTP 820F software and firmware releases are provided in a single bundle that includes software and firmware for all components supported by the system, including RFU's. Software is first downloaded to the system, then installed. After installation, a reset is automatically performed on all components whose software was upgraded. RFU software must be installed separately.

When you download a software bundle, the system verifies the validity of the bundle. The system also compares the files in the bundle to the files currently installed in the PTP 820G or PTP 820F and its components, so that only files that need to be updated are actually downloaded. A message is displayed for each file that is actually downloaded.

**Note**

When downloading an older version, all files in the bundle may be downloaded, including files that are already installed.

Software bundles are downloaded via FTP or SFTP. After the software download is complete, you can initiate the installation. Although RFU software is included in the standard installation bundle, the current software version is not automatically updated in the RFU when an installation is performed. To upgrade the software in an RFU, you must perform the upgrade manually, per slot. This enables you to manage IDU and RFU software versions separately.

**Note**

Before performing a software upgrade, it is important to verify that the system date and time are correct. See [Setting the Time and Date \(Optional\) \(CLI\)](#).

Displaying Current Software Versions (CLI)

To display all current software versions, enter the following command in root view:

```
root> platform software show versions
```

For example:

```
root> platform software show versions

Current software versions table:
=====

Package Name Target Device Running Version Installed Downloaded Reset
Type
Version version
=====
=====
gns- Cleared N/A 7.7.0.0.0.42 7.7.0.0.0.42 main-board-cold-reset
ns-atp Cleared 7.7.0.0.0.42 1.38.5 1.38.5 main-board-cold-reset
ns-fpga-fw-elic Cleared N/A 1.7.1 1.7.1 main-board-cold-reset
ns-fpga-fw-rmc Cleared N/A 1.42 1.42 main-board-cold-reset
ns-fpga-fw-rmce Cleared N/A 2.32 2.32 main-board-cold-reset
ns-fpga-fw-tcc Cleared 40 1.42.13 1.42.13 main-board-cold-reset
ns-fpga-fw-xlic Cleared N/A 3 3 main-board-cold-reset
ns-management Cleared 1.7.0.19 1.7.0.19 1.7.0.19 main-board-cold-reset
ns-mctl Cleared 7.7.0.0.0.42 7.7.0.0.0.42 7.7.0.0.0.42 main-board-cold-
reset
ns-modem-fw Cleared N/A 3.40.2 3.40.2 main-board-cold-reset
ns-mrmc-b-scripts Cleared N/A 2.24 2.24 main-board-cold-reset
ns-mrmc-scripts Cleared N/A 7.16 7.16 main-board-cold-reset
ns-pwc Cleared N/A 5.8 5.8 main-board-cold-reset
ns-pwc-stm1 Cleared N/A 5.14 5.14 main-board-cold-reset
ns-rfu Cleared N/A 3.0.10 3.0.10 main-board-cold-reset
ns-rmc-b Cleared N/A 1.0.37 1.0.37 main-board-cold-reset
ns-vm-control Cleared N/A 1.0.2.11 1.0.2.11 main-board-cold-reset
ns_tcc-config Cleared N/A 1.0 1.0 main-board-cold-reset
ns_tcc-kernel Cleared 2.6.34.8 v2.6.34.8 v2.6.34.8 main-board-cold-
reset
ns-fpga-fw-hrzn Cleared N/A N/A N/A no-reset
root>
```

To display all current RFU software versions, enter the following command in root view:

```
root> platform software show rfu versions
```

For example:

```

root> platform software show rfu versions
=====
Installed Bundle Name:  gnss-rfu           Installed version:    3.0.11
=====
Available Versions
=====
Bundle Name           DSP SW           Configuration Tables  Constant Tables  RFU Scripts  Firmware
=====
rfu-HC                552F            N/A                  N/A              N/A          N/A
rfu-1500HP           813a2          N/A                  N/A              N/A          N/A
rfu-SP                N/A            N/A                  N/A              N/A          N/A
rfu-C                 2.17           N/A                  N/A              N/A          N/A
rfu-H                 5.14           N/A                  N/A              N/A          N/A
rfu_HP               5.14           N/A                  N/A              N/A          N/A
rfu-A                 5.14           N/A                  N/A              N/A          N/A
rfu-D                 N/A            N/A                  N/A              N/A          N/A
rfu-EVO-XCVR         6B01           N/A                  N/A              1A19         6A00/3A00
=====
Installed Versions
=====
Slot      Port      DSP SW           Configuration Tables  Constant Tables  RFU Scripts  Firmware
=====
7         1         N/A             N/A                  N/A              N/A          N/A
8         1         N/A             N/A                  N/A              N/A          N/A
=====
Running Versions
=====
Slot      Port      DSP SW           Configuration Tables  Constant Tables  RFU Scripts  Firmware
=====
7         1         N/A             N/A                  N/A              N/A          N/A
8         1         N/A             N/A                  N/A              N/A          N/A
root>

```

Configuring a Software Download (CLI)

You can download software using HTTP, HTTPS, FTP, or SFTP.

When downloading software via HTTP or HTTPS, the PTP 820F or PTP 820G functions as the server, and you can download the software directly to the PTP 820F or PTP 820G unit.



Note

HTTP and HTTPS software download is only supported using the Web EMS. For instructions, see *Downloading and Installing Software*.

When downloading software, the IDU functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the software upgrade. For details, see [Configuring the Internal Ports for FTP or SFTP \(CLI\)](#).

To set the file transfer protocol you want to use (FTP or SFTP), enter the following command:

```
root> platform software download version protocol <ftp|sftp>
```

If the IP protocol selected in `platform management ip set ip-address-family` is IPv4, enter the following command:

```
root> platform software download channel server set server-ip <server-ipv4>
directory <directory> username <username> password <password>
```

If the IP protocol selected in `platform management ip set ip-address-family` is IPv6, enter the following command:

```
root> platform software download channel server-ipv6 set server-ip
<server-ipv6> directory <directory> username <username> password
<password>
```

To display the software download channel configuration, enter one of the following commands:

```
root> platform software download channel server show  
root> platform software download channel server-ipv6 show
```

Table 150 Software Download CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 address.	The IPv4 address of the PC or laptop you are using as the FTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the FTP server.
server-ip	Dotted decimal format.	Any valid IP address.	The IP address of the PC or laptop you are using as the FTP server.
directory	Text String		The directory path from which you are downloading the files. Enter the path relative to the FTP user's home directory, not the absolute path. To leave the path blank, enter //.
username	Text String		The user name for the FTP session.

The following command configures a download from IP address 192.168.1.242, in the directory “current”, with user name “anonymous” and password “12345.”

```
root> platform software download channel server set server-
ip 192.168.1.242 directory \current username anonymous password 12345
```

Downloading a Software Package (CLI)

To initiate a software download, enter the following command in root view:

```
root> platform software download version protocol ftp
```

The following prompt appears:

```
You are about to perform a software management operation. This may cause
a system reset.
Are you sure? (yes/no)
```

Enter **Yes** at the prompt. When the prompt appears again, enter the following command to check the download status:

```
root> platform software download status show
```

Once the following message appears, proceed with the installation:

```
DOWNLOAD VERSION status: download success, process percentage: 100
```

Installing and Upgrading Software (CLI)

To install or upgrade the software, enter the following command in root view after downloading the software bundle:

```
root> platform software install version
```

To display the status of an IDU software installation or upgrade, enter the following command:

```
root> platform software install status show
```

Installing and Upgrading Software in the RFU (CLI)

RFU software is installed and upgraded per carrier. After downloading a new software bundle, you must enter the following two commands in root view to install the new RFU software version in a carrier:

```
root> platform software update rfu version slot <slot> radio-port <radio-port>
root> platform software install rfu version slot <slot> radio-port <radio-port>
```

To view the status of an RFU installation or upgrade procedure, enter the following command in root view:

```
root> platform software rfu status show
```

To display all RFU software versions currently running in the unit, enter the following command:

```
root> platform software show rfu versions
```

Table 151 RFU Software Upgrade CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	1-2	

After installing the new version, it is recommended that you verify the installation by entering the `platform software show rfu versions` command to verify that the new version has been properly installed.

The following sequence of commands installs RFU-C software version 2.13 in radio interface 1.

First, enter the following command to determine which software versions are available, and which software versions are installed and running:

```

root> platform software show rfu versions
=====
Installed Bundle Name: gnss-rfu Installed version: 3.0.7
=====
Available Versions
=====
Bundle Name      DSP SW      Configuration      Constant Tables  RFU Scripts      Firmware
Tables
=====
rfu-HC           5.52f      N/A                N/A              N/A              N/A
rfu-HP           N/A        N/A                N/A              N/A              N/A
rfu-SP           N/A        N/A                N/A              N/A              N/A
rfu-C            2.13      N/A                N/A              N/A              N/A
rfu-H            N/A        N/A                N/A              N/A              N/A
rfu_HP           N/A        N/A                N/A              N/A              N/A
rfu-A            N/A        N/A                N/A              N/A              N/A
rfu-D            N/A        N/A                N/A              N/A              N/A

Installed Versions
=====
Slot   Port   DSP SW      Configuration      Constant Tables  RFU Scripts      Firmware
Tables
=====
Slot   Port   DSP SW      Configuration      Constant Tables  RFU Scripts      Firmware
Tables
=====
1      1      2.10_B7     N/A                N/A              N/A              N/A

```

The Installed Versions table indicates which RFU software versions are installed in the IDU (first row) and in the RFUs (second row). The version must be installed in the IDU before it can be used to update the RFU itself. Note that in this example, the version you want to install (2.13) has been downloaded, since it appears in the Available Versions table. However, no versions are available in the IDU, as indicated by the fact that there is no data underneath the first row of the Installed Versions table. The last row of the table indicates that the RFU is running an older version of the software, version 2.10_B7.

The next step is to perform the update and install commands:

```

root> platform software update rfu version slot 1 radio-port 1
root> platform software install rfu version slot 1 radio-port 1

```

To check the status of an update or install operation, enter the following command:

```

root> platform software show rfu status
=====
Slot   Port   Install Status      Install Progress      Timed      Installation      Install Time      Time to Install
in Progress
=====
1 1 installation-success 1 no 00:00 00:00
root> platform software show rfu status
=====

```

Once the installation is complete, the Install Status column should indicate installation success and the In Progress column should indicate 100 (100%):

```

root> platform software show rfu status
=====
Slot   Port   Install Status      Install Progress      Timed      Installation      Install Time      Time to Install
in Progress
=====
1 1 installation-success 100 no 00:00 00:00
root> platform software show rfu status
=====

```

When the installation is complete, enter the `show rfu versions` command again to verify that the new version has been properly installed in both the IDU and the RFU:

```

root> platform software show rfu versions
=====
Installed Bundle Name: gss-rfu Installed version: 3.0.7
=====
Available Versions
=====
Bundle Name      DSP SW      Configuration      Constant Tables      RFU Scripts      Firmware
Tables
=====
rfu-HC          5.52f      N/A                N/A                  N/A              N/A
rfu-HP          N/A        N/A                N/A                  N/A              N/A
rfu-SP          N/A        N/A                N/A                  N/A              N/A
rfu-C           2.13      N/A                N/A                  N/A              N/A
rfu-H           N/A        N/A                N/A                  N/A              N/A
rfu_HP          N/A        N/A                N/A                  N/A              N/A
rfu-A           N/A        N/A                N/A                  N/A              N/A
rfu-D           N/A        N/A                N/A                  N/A              N/A

Installed Versions
=====
Slot    Post    DSP SW      Configuration      Constant Tables      RFU Scripts      Firmware
Tables
=====
3       1       2.13        N/A                N/A                  N/A              N/A

Slot    Post    DSP SW      Configuration      Constant Tables      RFU Scripts      Firmware
Tables
=====
1       1       2.13_B7     N/A                N/A                  N/A              N/A

```

Note that in the table above, the new version (2.13) is listed for both the IDU and the RFU.

Backing Up and Restoring Configurations (CLI)

This section includes:

- [Configuration Management Overview \(CLI\)](#)
- [Setting the Configuration Management Parameters \(CLI\)](#)
- [Backing up a Configuration File \(CLI\)](#)
- [Importing and Restoring a Configuration File \(CLI\)](#)

Configuration Management Overview (CLI)

You can import and export PTP 820G and PTP 820F configuration files. This enables you to copy the system configuration to multiple PTP 820G and PTP 820F units. You can also backup and save configuration files.

System configuration files consist of a zip file that contains three components:

- A binary configuration file which is used by the system to restore the configuration.
- A text file which enables users to examine the system configuration in a readable format. The file includes the value of all system parameters at the time of creation of the backup file.
- An additional text file which enables you to write CLI scripts in order to make desired changes in the backed-up configuration. This file is executed by the system after restoring the configuration.

The system provides three restore points to manage different configuration files. Each restore point contains a single configuration file. Files can be added to the restore points by creating backups of the current system state or by importing them from an external server. For example, you may want to use one restore point to keep a last good configuration, another to import changes from an external server, and the third to store the current configuration.

You can apply a configuration file to the system from any of the restore points.

You can only import PTP 820F configuration files into an PTP 820F unit, PTP 820G configuration files into an PTP 820G unit.

Setting the Configuration Management Parameters (CLI)

When importing and exporting configuration files, the PTP 820G functions as an FTP or SFTP client. You must install FTP or SFTP server software on the PC or laptop you are using to perform the import or export. For details, see [Configuring the Internal Ports for FTP or SFTP \(CLI\)](#).



Note

Before importing or exporting a configuration file, you must verify that the system date and time are correct. See [Setting the Time and Date \(Optional\) \(CLI\)](#).

To set the FTP or SFTP parameters for configuration file import and export, enter one of the following commands in root view:

- If the IP protocol selected in `platform management ip set ip-address-family` is IPv4, enter the following command:

```
root> platform configuration channel server set ip-address <server-ipv4>
directory <directory> filename <filename> username <username> password
<password>
```

- If the IP protocol selected in `platform management ip set ip-address-family` is IPv6, enter the following command:

```
root> platform configuration channel server-ipv6 set ip-address <server-
ipv6> directory <directory> filename <filename> username <username>
password <password>
```

To set the file transfer protocol you want to use (FTP or SFTP), enter the following command:

```
root>platform configuration channel set protocol <ftp|sftp>
```

To display the FTP channel parameters for importing and exporting configuration files, enter one of the following commands in root view:

```
root> platform configuration channel server show
root> platform configuration channel server-ipv6 show
```

Table 152 Configuration Management CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 address.	The IPv4 address of the PC or laptop you are using as the FTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the FTP server.
directory	Text String.		The directory path to which you are exporting or from which you are importing the configuration file. Enter the path relative to the FTP user's home directory, not the absolute path. To leave the path blank, enter //.
filename	Text String.		The name of the file you are importing, or the name you want to give the file you are exporting. Note: You must add the suffix <code>.zip</code> to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix <code>.zip</code> manually.
username	Text String.		The user name you configured in the FTP server.

Parameter	Input Type	Permitted Values	Description
password	Text String.		The password you configured in the FTP server. If you did not configure a password for your FTP user, simply omit this parameter.

Examples

The following command configures the FTP channel for configuration file import and export to IP address 192.168.1.99, in the directory “current”, with file name “version_8_backup.zip”, user name “anonymous”, and password “12345.”

```
root> platform configuration channel server set server-ip 192.168.1.99
directory \current filename version_8_backup.zip username anonymous
password 12345
```

Backing up a Configuration File (CLI)

When downloading software, the IDU functions as an FTP or SFTP client. You must install FTP server software on the PC or laptop you are using to perform the software upgrade. For details, see [Configuring the Internal Ports for FTP or SFTP \(CLI\)](#).

To set the file transfer protocol you want to use (FTP or SFTP), enter the following command:

```
root>platform configuration channel set protocol <ftp|sftp>
```

To set the FTP or SFTP parameters for configuration file import and export, enter one of the following commands in root view:

If the IP protocol selected in `platform management ip set ip-address-family` is IPv4, enter the following command:

```
root> platform configuration channel server set ip-address <server-ipv4>
directory <directory> filename <filename> username <username> password
<password>
```

If the IP protocol selected in `platform management ip set ip-address-family` is IPv6, enter the following command:

```
root> platform configuration channel server-ipv6 set ip-address <server-
ipv6> directory <directory> filename <filename> username <username>
password <password>
```

You must configure from 1 to 3 restore points:

- When you import a configuration file, the file is saved to the selected restore point, and overwrites whichever file was previously held in that restore point.
- When you export a configuration file, the file is exported from the selected restore point.
- When you back up the current configuration, the backup configuration file is saved to the selected restore point, and overwrites whichever file was previously held in that restore point.
- When you restore a configuration, the configuration file in the selected restore point is the file that is restored.

To display the FTP or SFTP channel parameters for importing and exporting configuration files, enter one of the following commands in root view:

```
root> platform configuration channel server show  
root> platform configuration channel server-ipv6 show
```

To save the current configuration as a backup file to one of the restore points, enter the following command in root view:

```
root> platform configuration configuration-file add <restore-point>
```

To export a configuration from a restore point to the external server location, enter the following command in root view:

```
root> platform configuration configuration-file export <restore-point>
```

Table 153 Configuration Management CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 address.	The IPv4 address of the PC or laptop you are using as the FTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the FTP server.
directory	Text String		The location of the file you are downloading or uploading. If the location is the root shared folder, it should be left empty. If the location is a sub-folder under the root shared folder, specify the folder name. If the shared folder is "C:\", this parameter can be left empty or populated with "//".
filename	Text String		The name of the file you are importing, or the name you want to give the file you are exporting. Note: You must add the suffix .zip to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix .zip manually.
username	Text String		The user name for the FTP session.
password	Text String		The password for the FTP session. To configure the FTP settings without a password, simply omit this parameter.
restore-point	Variable	restore-point-1 restore-point-2 restore-point-3	Identifies the restore point to or from which to perform the backup operation.

The following command configures the FTP channel for configuration file import and export to IP address 192.168.1.99, in the directory "current," with file name "version_8_backup.zip," user name "anonymous," and password "12345."

```
root> platform configuration channel server set ip-address 192.168.1.99
directory \current filename version_8_backup.zip username anonymous
password 12345
```

The following commands save the current configuration as a configuration at Restore Point 1, and export the file to the external server location:

```
root> platform configuration configuration-file add restore-point-1
root> platform configuration configuration-file export restore-point-1
```

Importing and Restoring a Configuration File (CLI)

You can import a configuration file from an external PC or laptop to one of the restore points. Once you have imported the file, you can restore the configuration. Restoring a saved configuration does not change the unit's FIPS mode or ETSI/ANSI mode.



Note

In order to import a configuration file, you must configure the FTP channel parameters and restore points, as described in [Setting the Configuration Management Parameters](#) and [Backing up a Configuration File](#).

To import a configuration file, enter the following command in root view:

```
root> platform configuration configuration-file import <restore-point>
```

To restore a configuration from a restore point to become the active configuration file, enter the following command in root view:

```
root> platform configuration configuration-file restore <restore-point>
```

Table 154 Configuration Import and Restore CLI Parameters

Parameter	Input Type	Permitted Values	Description
restore-point	Variable	restore-point-1 restore-point-2 restore-point-3	The restore point to which the file is imported, and from which it is applied to the PTP 820G or PTP 820F.

The following commands import a configuration file from an external PC or laptop to Restore Point 2 on the PTP 820G or PTP 820F, and restore the file to be the system configuration file for the PTP 820G or PTP 820F:

```
root> platform configuration configuration-file import restore-point-2  
root> platform configuration configuration-file restore restore-point-2
```

Editing CLI Scripts (CLI)

The configuration file package includes a text file that enables you to write CLI scripts in a backed-up configuration that are executed after restoring the configuration.

To edit a CLI script:

1. Back up the current configuration to one of the restore points. See [Backing up a Configuration File \(CLI\)](#).
2. Export the configuration from the restore point to a PC or laptop. See [Backing up a Configuration File \(CLI\)](#).
3. On the PC or laptop, unzip the file *Configuration_files.zip*.
4. Edit *the cli_script.txt* file using clish commands, one per line.
5. Save and close the *cli_script.txt* file, and add it back into the *Configuration_files.zip* file.
6. Import the updated *Configuration_files.zip* file back into the unit. See [Importing and Restoring a Configuration File \(CLI\)](#)
7. Restore the imported configuration file. See [Importing and Restoring a Configuration File \(CLI\)](#). The unit is automatically reset. During initialization, the CLI script is executed, line by line.



Note

If any specific command in the CLI script requires reset, the unit is reset when that that command is executed. During initialization following the reset, execution of the CLI script continues from the following command.

Setting the Unit to the Factory Default Configuration (CLI)

To restore the unit to its factory default configuration, while retaining the unit's IP address settings and logs, enter the following commands in root view:

```
root> platform management set-to-default
```

The following prompt appears:

```
WARNING: All database and configuration will be lost, unit will be
restart.
Are you sure? (yes/no):yes
```

At the prompt, type `yes`.

**Note**

This does not change the unit's IP address or FIPS configuration.

Performing a Hard (Cold) Reset (CLI)

To initiate a hard (cold) reset on the unit, enter the following command in root view:

```
root> platform management chassis reset
```

The following prompt appears:

```
You are about to reset the shelf  
Are you sure? :(yes/no):
```

Enter **yes**. The unit is reset.

Configuring Unit Parameters (CLI)

To configure a name for the unit, enter the following command in root view:

```
root> platform management system-name set name <name>
```

For example:

```
root> platform management system-name set name "My-System-Name"
```

To define a location for the unit, enter the following command in root view:

```
root> platform management system-location set name <name>
```

For example:

```
root> platform management system-location set name "My System Location"
```

To define a contact person for questions pertaining to the unit, enter the following command in root view:

```
root> platform management system-contact set name <name>
```

For example:

```
root> platform management system-contact set name "John Doe"
```

To define the unit's latitude coordinates, enter the following command in root view:

```
root> platform management system-latitude set <latitude>
```

For example:

```
root> platform management system-latitude set 40
```

To define the unit's longitude coordinates, enter the following command in root view:

```
root> platform management system-longitude set <longitude>
```

For example:

```
root> platform management system-longitude set 73
```

To define the type of measurement unit you want the system to use, enter the following command in root view:

```
root> platform management set unit_measure_format <unit_measure_format>
```

For example:

```
root> platform management set unit_measure_format metric
```

To display the type of measurement unit used by the system, enter the following command in root view:

```
root> platform management show unit_measure_format
```

To display the unit parameters, including current temperature and input voltage:

```
root> platform management unit-status
```

For example:

```

root> platform management unit-status
Unit name:                               Microwave radio
Unit Description:                         PTP 820G 1RU, 2 radio, 6 GbE, 16 TDM, dual
feed
Unit contact person:
Unit location:
Unit Latitude:
Unit Longitude:
Unit System Object ID:                   1.3.6.1.4.1.2281.1.20.1.3.2
Unit type:
Unit operational status:                 normal
System up time [seconds]:                4615
Unit Temperature [Celsius]:              11
Unit Temperature [Fahrenheit]:           51
Unit Input voltage port 1 [volts]:       45
Unit Input voltage port 2 [volts]:       0
root>

```

Table 155 Unit Parameters CLI Parameters

Parameter	Input Type	Permitted Values	Description
name	Text	Up to 64 characters.	Defines the system parameter specified by the command.
latitude	Text	Up to 256 characters.	Defines the system parameter specified by the command.
longitude	Text	Up to 256 characters.	Defines the system parameter specified by the command.
unit_measure _format	Variable	metric imperial	Defines the system parameter specified by the command.

Configuring NTP (CLI)

PTP 820G and PTP 820F supports Network Time Protocol (NTP). NTP distributes Coordinated Universal Time (UTC) throughout the system, using a jitter buffer to neutralize the effects of variable latency.

To configure NTP, enter the following command in root view:

```
root> platform management ntp set admin <admin> ntp-version <ntp-version>
ntp-server-ip-address-1 <ntp-server-ip-address>
```

To display the current NTP configuration, enter the following command in root view:

```
root> platform management ntp show status
```

Table 156 NTP CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable.	enable disable	Enter enable or disable to enable or disable the NTP server.
ntp-version	Variable.	v3 v4	Enter the NTP version you want to use. NTPv4 provides interoperability with NTP v3 and with SNTP.
ntp-server-ip-address	Dotted decimal format.	Any valid IP address.	Enter the IP address of the NTP server.

The following command enables NTP, using NTP v4, and sets the IP address of the NTP server as 62.90.139.210.

```
root> platform management ntp set admin enable ntp-version ntpv4 ntp-
server-ip-address-1
```

Displaying Unit Inventory (CLI)

To view inventory information, enter the following command in root view:

```
root> platform management inventory show-info
```

For example:

```
root> platform management inventory show info
```

```
System information:
```

```
card-name : PTP 820G
```

```
Subtype : 572792847
```

```
part number : 24-G009-1A
```

```
serial number : E095900075
```

```
company name : Cambium Networks Ltd.
```

```
product name : PTP 820G
```

```
product description : PTP 820G 1RU, 2 radio, 6 GbE, 16 TDM, dual  
feedroot>
```

Chapter 17: Radio Configuration (CLI)

This section includes:

- [Viewing the Radio Status and Settings \(CLI\)](#)
- [Configuring the Remote Radio Parameters \(CLI\)](#)
- [Configuring ATPC and Override Timer \(CLI\)](#)
- [Configuring Header De-Duplication \(CLI\)](#)
- [Configuring Frame Cut-Through \(CLI\)](#)
- [Configuring AES-256 Payload Encryption \(CLI\)](#)
- [Configuring and Viewing Radio PMs and Statistics \(CLI\)](#)

Related topics:

- [Entering Radio View \(CLI\)](#)
- [Unmuting a Radio \(CLI\)](#)
- [Configuring the Transmit \(TX\) Level \(CLI\)](#)
- [Configuring the Transmit \(TX\) Frequency \(CLI\)](#)
- [Configuring the Radio \(MRMC\) Script\(s\) \(CLI\)](#)
- [Radio Configurations \(CLI\)](#)
- [Configuring a 1+0 Link \(CLI\)](#)
- [Configuring Multi-Carrier ABC \(CLI\)](#)
- [Configuring Link Aggregation \(LAG\) and LACP \(CLI\)](#)
- [Configuring XPIC \(CLI\)](#)
- [Configuring HSB Radio Protection \(CLI\)](#)
- [Performing Radio Loopback \(CLI\)](#)

Viewing the Radio Status and Settings (CLI)

To display the RFU status, enter the following command in radio view:

```
radio[x/x]>rf module status show
```

The following commands display the RFU status for radio interface 1:

```
root> radio slot 1 port 1
radio [7/1]>rf module status show

TX Frequency(KHz): 18186250
RX Frequency(KHz): 18723750
TX RX Frequency separation(KHz): 537500

TX Level(dBm): 15
RX Level(dBm): -99
IF Combiner Mode: main
IF Combiner RX Level Diversity(dBm): 0
IF Combiner RX Level Combined(dBm): 0
Mute Configuration: on
Mute status: on
Temperature(Celsius): 32
Temperature(Fahrenheit): 89
Communication status: up
RSL connector: main
SW running version: C2.16_B5
XPIC mode: disable
radio [1/1]>
```

To display the RFU capabilities, enter the following command in radio view:

```
radio[x/x]>rf module capabilities show
```

The following commands display the RFU capabilities for radio interface 1:

```
root> radio slot 1 port 1
radio [7/1]>rf module capabilities show

Type: RFU-C
Part Number: 1C18020L0B
Serial Number: F42927471

Band: 18
Max bandwidth(KHz): 5600
Min bandwidth(KHz): 100
Max RX frequency(KHz): 19206250
Min RX frequency(KHz): 18723750
Max TX frequency(KHz): 18186250
Min TX frequency(KHz): 17713750

Max Available TX Power(dBm): 18
Min Available TX Power(dBm): 0
XPIC Support: yes

IF Combiner support: not-supported
radio [1/1]>
```

Configuring the Remote Radio Parameters (CLI)

This section includes:

- [Displaying Communication Status with the Remote Radio \(CLI\)](#)
- [Displaying the Remote Radio's Link ID and Location \(CLI\)](#)
- [Muting and Unmuting the Remote Radio \(CLI\)](#)
- [Displaying the Remote Radio's RX Level \(CLI\)](#)
- [Configuring the Remote Radio's TX Level \(CLI\)](#)
- [Configuring Remote ATPC \(CLI\)](#)

Related topics:

- [Configuring the Remote Unit's IP Address \(CLI\)](#)

Displaying Communication Status with the Remote Radio (CLI)

To display the communication status with the remote radio, go to radio view and enter the following command in radio view:

```
radio[x/x]>remote-unit communication status show
```

Displaying the Remote Radio's Link ID and Location (CLI)

To display the remote radio's Link ID, go to radio view and enter the following command:

```
radio[x/x]>remote-unit show link-id
```

To display the remote radio's slot ID (location in the chassis), enter the following command in radio view:

```
radio[x/x]>remote-unit show slot-id
```

Muting and Unmuting the Remote Radio (CLI)

To mute or unmute the remote radio, go to radio view and enter the following command:

```
radio[x/x]>remote-unit mute set admin <admin>
```

To display the mute status of the remote radio, go to radio view and enter the following command:

```
radio[x/x]>remote-unit mute show status
```

Table 157 Remote Radio Mute/Unmute CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	on off	Mutes (on) or unmutes (off) the remote unit.

The following command mutes the remote radio:

```
radio[2/1]>remote-unit mute set admin on
```

The following command unmutes the remote radio:

```
radio[2/1]>remote-unit mute set admin off
```

Displaying the Remote Radio's RX Level (CLI)

To display the remote radio's RX level, go to radio view and enter the following command:

```
radio[x/x]>remote-unit show rx-level
```

Configuring the Remote Radio's TX Level (CLI)

To set the transmit (TX) level of the remote radio, go to radio view and enter the following command:

```
radio[x/x]>remote-unit set tx-level <tx-level>
```

To display the transmit (TX) level of the remote radio, go to radio view and enter the following command:

```
radio[x/x]>remote-unit show tx-level
```

Table 158 Remote Radio TX Level CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-level	Number	Depends on the frequency and unit type.	The desired TX signal level (TSL), in dBm.

The following command sets the TX level of the remote radio to 10 dBm:

```
radio[2/1]>remote-unit set tx-level 10
```

Configuring Remote ATPC (CLI)

To set the RX reference level for ATPC on the remote radio, go to radio view and enter the following command:

```
radio[x/x]>remote-unit atpc set ref-level <ref-level>
```

To display the RX reference level for ATPC on the remote radio, go to radio view and enter the following command:

```
radio[x/x]>remote-unit atpc show ref-level
```

Table 159 Remote Radio ATPC CLI Parameters

Parameter	Input Type	Permitted Values	Description
ref-level	Number	-70 - -30	The RX reference level for the ATPC mechanism.

Configuring ATPC and Override Timer (CLI)

ATPC is a closed-loop mechanism by which each carrier changes the TX power according to the indication received across the link, in order to achieve a desired RSL on the other side of the link.

With ATPC, if the radio increases its TX power up to the configured TX power, it can lead to a period of sustained transmission at maximum power, resulting in unacceptable interference with other systems.

In order to minimize interference, PTP 820G and PTP 820F provides an ATPC override mechanism. When ATPC override is enabled, a timer begins when ATPC raises the TX power to its maximum. When the timer expires, the radio enters ATPC override state. In ATPC override state, the radio transmits no higher than the pre-determined ATPC override TX level, and an ATPC override alarm is raised. The radio remains in ATPC override state until the ATPC override state is manually cancelled by the user (or until the unit is reset). The radio then returns to normal ATPC operation.

In a configuration with unit redundancy or radio protection, the ATPC override state is propagated to the standby unit or radio in the event of switchover.

**Note**

When canceling an ATPC override state, you should ensure that the underlying problem has been corrected. Otherwise, ATPC may be overridden again.

To enable or disable ATPC, enter the following command in radio view:

```
radio[x/x]>atpc set admin <admin>
```

To display whether or not ATPC is enabled, enter the following command in radio view:

```
radio[x/x]>atpc show admin
```

To set the RX reference level for ATPC, enter the following command in radio view:

```
radio[x/x]>atpc set rx-level atpc_ref_rx_level <rx-level>
```

To display the RX reference level for ATPC, enter the following command in radio view:

```
radio[x/x]>atpc show rx-level  
radio[x/x]>atpc set override timeout <timeout>
```

**Note**

The next command actually enables ATPC override. However, it is recommended to set the timer before enabling ATPC override. Failure to do so can lead to unexpected reduction of the TX power with corresponding loss of capacity if TX override is enabled with the timer set to a lower-than-desired value.

To enable ATPC override, enter the following command in radio view. ATPC must be enabled before you enable ATPC override.

```
radio[x/x]>atpc override set admin <override admin>
```

To display whether or not ATPC override is enabled, enter the following command in radio view:

```
radio[x/x]>atpc override show admin
```

To display the ATPC override timeout, enter the following command in radio view:

```
radio[x/x]>atpc show override timeout
```

To set the TX power to be used when the unit is in an ATPC override state, enter the following command in radio view:

```
radio[x/x]>atpc set override-tx-level <override-tx-level>
```

To display the ATPC override TX power, enter the following command in radio view:

```
radio[x/x]>atpc show override tx-level
```

To display the current ATPC override state, enter the following command in radio view:

```
radio[x/x]>atpc show override
```

Possible values are:

- Normal – ATPC override is enabled, and there is no override.
- Disabled – ATPC override is not enabled.
- Override – ATPC override has been activated.

To cancel ATPC override, enter the following command in radio view:

```
radio[x/x]>atpc set override-cancel
```

Table 160 Radio ATPC CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	enable disable	Enables or disables ATPC mode.
rx-level	Number	-70 - -30	The RX reference level for the ATPC mechanism.
timeout	Number	0-1800	The amount of time, in seconds, the timer counts from the moment the radio reaches its maximum configured TX power until ATPC override goes into effect.
override admin	Variable	enable disable	Enables or disables ATPC override.
override-tx- level	Number	-50 - 50	The TX power, in dBm, to be used when the unit is in an ATPC override state. The range of values depends on the frequency, MRMC script, and RFU type.

The following commands enable ATPC mode for radio interface 1 and set the RX reference level to -55:

```
radio[2/1]>atpc set admin enable
```

```
radio[2/1]>atpc set rx-level atpc_ref_rx_level -55  
radio[1/1]>atpc set override timeout 900  
radio[1/1]>atpc override set admin enable  
radio[1/1]> atpc set override-tx-level 18
```

Configuring Header De-Duplication (CLI)

Header De-Duplication identifies traffic flows and replaces header fields with a flow ID. The Header De-Duplication module includes an algorithm for learning each new flow, and implements compression on the flow type starting with the next frame of that flow type.

You can determine the depth to which the compression mechanism operates, from Layer 2 to Layer 4. You must balance the depth of compression against the number of flows in order to ensure maximum efficiency. Multi-Layer (Enhanced) compression supports up to 256 flow types.

**Note**

The Header De-Duplication configuration must be identical on both sides of the link.

To configure Header De-Duplication, enter the following command in radio view:

```
radio[x/x]> compression header-compression set <mode>
```

To clear Ethernet port counters, including both Frame Cut-Through and Header De-Duplication counters, enter the following command in radio view:

```
radio[x/x]>clear-ethernet-port-counters
```

Table 161 Header De-Duplication CLI Parameters

Parameter	Input Type	Permitted Values	Description
mode	Variable	Disabled Layer2 MPLS Layer3 Layer4 Tunnel Tunnel-Layer3 Tunnel-Layer4	Disabled - Header De-Duplication is disabled. Layer2 - Header De-Duplication operates on the Ethernet level. MPLS - Header De-Duplication operates on the Ethernet and MPLS levels. Layer3 - Header De-Duplication operates on the Ethernet and IP levels. Layer4 - Header De-Duplication operates on all supported layers up to Layer 4. Tunnel - Header De-Duplication operates on Layer 2, Layer 3, and on the Tunnel layer for packets carrying GTP or GRE frames. Tunnel-Layer3 - Header De-Duplication operates on Layer 2, Layer 3, and on the Tunnel and T-3 layers for packets carrying GTP or GRE frames. Tunnel-Layer4 - Header De-Duplication operates on Layer 2, Layer 3, and on the Tunnel, T-3, and T-4 layers for packets carrying GTP or GRE frames.

The following command enables Layer 2 Header De-Duplication on fixed radio interface 1, with a defined flow type of 0x00:

```
root> radio slot 1 port 1
radio[1/1]> compression header-compression set mode Layer2
```

Displaying Header De-Duplication Information (CLI)

To display the current Header De-Duplication configuration, enter the following command in radio view:

```
radio[x/x]> compression show-configuration
```

To display counters for Header De-Duplication, enter the following command in radio view:

```
radio[x/x]> header-compression show-counters
```

The following counters are displayed:

- TX in octet count - Bytes on the TX side before Header De-Duplication.
- TX out octet count - Bytes on the TX side that were compressed by Header De-Duplication.
- TX frame in count - Frames on the TX side before Header De-Duplication.

- TX frame out compressed count - Frames on the TX side that were compressed by Header De-Duplication.
 - TX frame uncompressed count - The number of frames on the TX side that were not compressed due to exclusion rules.
-

**Note**

The use of exclusion rules for Header De-Duplication is planned for future release.

- TX frame uncompressed other count - Frames on the TX side that were not compressed for reasons other than the use of exclusion rules.
- TX out frame learning count - The number of frames that have been used to learn unique data flows. Once a particular flow type has been learned, subsequent frames with that flow type are compressed by Header De-Duplication.
- TX out number of active flows in count - The number of Header De-Duplication flows that are active on the TX side.

Configuring Frame Cut-Through (CLI)

Using the Frame Cut-Through feature, frames assigned to queues with 4th priority pre-empt frames already in transmission over the radio from other queues. After the 4th queue frames have been transmitted, transmission of the pre-empted frames resumes.



Note

The Frame Cut-Through configuration must be identical on both sides of the link.

If Frame Cut-Through is used together with 1588 Transparent Clock, the 1588 packets must be given a CoS that is not assigned to the fourth priority queue.

To enable Frame Cut-Through on a radio carrier, enter the following command in radio view:

```
radio[x/x]>cut-through mode <mode>
```

Table 162 Frame Cut-Through CLI Parameters

Parameter	Input Type	Permitted Values	Description
mode	Variable	yes	yes - Enables Frame Cut-Through
		no	no - Disables Frame Cut-Through

The following commands enable Frame Cut-Through on radio interface 1:

```
root> radio slot 1 port 1
radio[1/1]>cut-through mode yes
```

To display the current Frame Cut-Through mode for a radio carrier, enter the following command in radio view:

```
radio[x/x]>cut-through show-mode
```

To display counters for Frame Cut-Through for a radio carrier, enter the following command in radio view:

```
radio[x/x]>cut-through show-counters
```

Configuring AES-256 Payload Encryption (CLI)

**Note**

AES-256 is not supported with PTP 820F.

This feature requires:

- Requires an activation key. If no valid AES activation key has been applied to the unit, AES will not operate on the unit. See [Configuring the Activation Key](#).

**Note**

In order for the AES activation key to become active, you must reset the unit after configuring a valid AES activation key. Until the unit is reset, an alarm will be present if you enable AES. This is not the case for other activation keys.

PTP 820G supports AES-256 payload encryption. AES is enabled and configured separately for each radio carrier.

PTP 820 uses a dual-key encryption mechanism for AES:

- The user provides a master key. The master key can also be generated by the system upon user command. The master key is a 32-byte symmetric encryption key. The same master key must be manually configured on both ends of the encrypted link.
- The session key is a 32-byte symmetric encryption key used to encrypt the actual data. Each link uses two session keys, one for each direction. For each direction, the session key is generated by the transmit side unit and propagated automatically, via a Key Exchange Protocol, to the other side of the link. The Key Exchange Protocol exchanges session keys by encrypting them with the master key, using the AES-256 encryption algorithm. Session keys are regenerated at user-configured intervals.

AES key generation is completely hitless, and has no effect on ACM operation.

To display the current payload encryption status for all available radio links on the unit, enter the following command in root view:

```
root> payload encryption status show
```

The following is a sample output of this command in which payload encryption is enabled but not operational on radio interface 1, and disabled on radio interface 2.

```

root> payload encryption status show
Traffic Crypto configuration table:
=====
| Interface slot | Interface port | Admin mode | Master Key | Session Key Period |
|-----|-----|-----|-----|-----|
| 1 | 1 | AES-256 | 5QV_{Fm`v1iKgaQhnP#09As6&QA.#dH^ | 00:00 |
| 1 | 2 | Disable | | 00:00 |
Traffic Crypto status table:
=====
| Interface slot | Interface port | Crypto Validation State |
|-----|-----|-----|
| 1 | 1 | not-valid |
| 1 | 2 | not-valid |
root>

```

To configure payload encryption:

- 1 Verify that both the local and remote units are running with no alarms. If any alarm is present, take corrective actions to clear the alarms before proceeding.
- 2 If the link is using in-band management, identify which unit is local and which unit is remote from the management point of view.
- 3 In a link with HSB radio protection, enable protection lockout, first on the remote and then on the local unit. See [Switchovers and Lockout \(CLI\)](#).
- 4 To configure AES on a radio carrier, you must first enter Payload Encryption view for the specific radio. To enter Payload Encryption view, enter the following command in root view:

```
root> payload encryption slot <slot> port <port>
```

For example, to configure AES on fixed radio interface 2, enter the following command in root view:

```
root> payload encryption slot 1 port 2
Payload Encryption [1/2]>
```

To display the payload encryption mode of the radio interface, enter the following command in Payload Encryption view:

```
Payload Encryption [x/x]> payload encryption mode show
```

The following display indicates that payload encryption is enabled on fixed radio interface 2:

```
Traffic Encryption [1/2]> payload encryption mode show
Admin Mode: AES-256
```

The following display indicates that payload encryption is disabled on fixed radio interface 1:

```
Payload Encryption [1/1]> payload encryption mode show
Admin Mode: Disable
```

- 5 Configure the master key on the remote unit by doing one of the following:
 - o Enter a master key manually.
 - o Generate the master key automatically.

You must use the same AES master key on both sides of the link. This means that if you generate a master key automatically on one side of the link, you must copy that key and for use on the other side of the link. Once payload encryption has been enabled on both sides of the link, the Key Exchange Protocol periodically verifies that both ends of the link have the same master key. If a mismatch is detected, an alarm is raised and traffic transmission is stopped for the mismatched carrier at both sides of the link. The link becomes non-valid and traffic stops being forwarded.

To define the master key manually, enter the following command in Payload Encryption view:

```
Payload Encryption [x/x]> payload encryption mkey
```

When you press <Enter>, the following prompt appears:

```
Please enter key:
```

Enter the master key and press <Enter>. The master key must be between 8 and 32 ASCII characters. The characters *do not* appear as you type them. To display the master key and verify that you typed it correctly, enter the `payload encryption status show` command described above. You can copy the master key from the output of this command.

To generate the master key automatically, enter the following command in Payload Encryption view:

```
Payload Encryption [x/x]> master key generate
```

A random master key is generated. You must copy and paste this key to the other end of the link to ensure that both sides of the link have the same master key. To display and copy the master key, enter the `payload encryption status show` command described above. You can copy the master key from the output of this command.

6 On the local unit, follow the procedure described in Step 5 to configure the same master key configured on the remote unit also on the local unit.

7 Enable payload encryption on the remote unit:

i Enter the following command in Payload Encryption view:

```
Payload Encryption [x/x]> payload encryption mode admin AES-256
```

This step will cause the link status to be Down until payload encryption is successfully enabled on the local unit. However, the RSL measured on the link should remain at an acceptable level.

To disable payload encryption, enter the following command in Payload Encryption view:

```
Payload Encryption [x/1]> payload encryption mode admin Disable
```

ii The session key is automatically regenerated at defined intervals. To set the session key regeneration interval, enter the following command in Payload Encryption view:

```
Payload Encryption [x/1]> payload encryption session-key period set <00:00-00:00>
```

Enter the regeneration interval in hours and minutes (HH:MM). For example, the following command configures fixed radio interface 1 to regenerate the session key every 4 hours and 15 minutes:

```
Payload Encryption [2/1]> payload encryption session-key period set 04:15
```

To display the session key regeneration interval, enter the following command in Payload Encryption view:

```
Payload Encryption [x/1]> payload encryption session-key period show
```



Note

The session key regeneration interval must be the same on both sides of the link.

8 Enable payload encryption on the local unit by following the procedure described in Step 7. Verify that on both the local and remote active units, the link status returns to Up and user traffic is restored. In links using in-band management, verify also that in-band management returns.

- 9 In a link with HSB radio protection, perform copy-to-mate, first on the remote and then on the local unit. See [7](#). After the copy-to-mate operation, wait for both standby units to re-boot and verify that there are no alarms.

**Note**

The standby unit may have a *payload encryption failure* alarm for up to about one minute after the unit is up and running.

- 5 In a link with radio protection, remove the protection lockout, first on the remote and then on the local unit. See [Switchovers and Lockout \(CLI\)](#).
- 6 Verify that there are no alarms on the link.

You can set all master keys defined on the unit to zero value. To zeroize the master keys, enter the following command in root view:

```
root> payload encryption key zeroize
```

**Warning**

Executing this command on a FIPS enabled unit formats the unit's disk, and renders the unit non-operational. If it is necessary to use this command, contact Cambium Networks Technical Support for instructions how to re-configure the unit.

This command has no effect on units that are not enabled for FIPS.

**Note**

Any time payload encryption fails, the Operational status of the link is Down until payload encryption is successfully restored.

Configuring and Viewing Radio PMs and Statistics (CLI)

This section includes:

- [Displaying General Modem Status and Defective Block PMs\(CLI\)](#)
- [Displaying Excessive BER \(Aggregate\) PMs \(CLI\)](#)
- [Displaying BER Level and Configuring the Excessive BER Thresholds \(CLI\)](#)
- [Configuring RSL Thresholds \(CLI\)](#)
- [Configuring TSL Thresholds \(CLI\)](#)
- [Displaying RSL and TSL Levels \(CLI\)](#)
- [Configuring the Signal Level Threshold \(CLI\)](#)
- [Configuring the MSE Thresholds and Displaying the MSE PMs \(CLI\)](#)
- [Configuring the XPI Thresholds and Displaying the XPI PMs \(CLI\)](#)
- [Displaying ACM PMs \(CLI\)](#)

Displaying General Modem Status and Defective Block PMs(CLI)

To display the general status of the modem, go to radio view and enter the following command in radio view:

```
radio[x/x]>modem show status
```

The following is a sample output of the `modem show status` command:

```
MSE[db]: -99.00
Defective Blocks count: 0

Current Tx profile: 0
Current Tx QAM: 4
Current Tx rate(Kbps): 43389
Current Rx profile: 0
Current Rx QAM: 4
Current Rx rate(Kbps): 43389
radio [1/1]>modem show status

MSE[db]: -99.00
Defective Blocks count: 0

Current Tx profile: 0
Current Tx QAM: 4
Current Tx rate(Kbps): 43389
Current Rx profile: 0
Current Rx QAM: 4
Current Rx rate(Kbps): 43389
radio [1/1]>
```

To clear all radio PMs in the system, enter the following command in root view:

```
root> radio pm clear all
```

To clear defective blocks counters for a radio, go to radio view and enter the following command:

```
radio[x/x]>modem clear counters
```

Displaying Excessive BER (Aggregate) PMs (CLI)

You can display modem BER (Bit Error Ratio) PMs in either 15-minute or daily intervals.

To display modem BER PMs in 15-minute intervals, go to radio view and enter the following command:

```
radio [x/x]>framer pm-aggregate show interval 15min
```

The following is a partial sample output of the `framer pm-aggregate show interval 15min` command:

```
radio [1/1]>framer pm-aggregate show interval 15min
Modem BER PM table:
=====

Interval Integrity ES SES UAS BBE
=====
0 1 0 0 333 0
1 1 0 0 900 0
2 1 0 0 900 0
3 1 0 0 900 0
4 1 0 0 900 0
5 1 0 0 900 0
6 1 0 0 900 0
7 1 0 0 900 0
8 1 0 0 900 0

radio [1/1]>
```

To display modem BER PMs in daily intervals, go to radio view and enter the following command:

```
radio [x/x]>framer pm-aggregate show interval 24hr
```

The following is a sample output of the `framer pm-aggregate show interval 24hr` command:

```
radio [1/1]>framer pm-aggregate show interval 24hr
Modem BER PM table:
=====

Interval Integrity ES SES UAS BBE
=====
0 1 0 0 53843 0
4 1 0 0 37061 0
5 1 0 0 4034 0
6 1 0 0 85971 0
8 1 0 0 46171 0
11 1 0 0 24184 0
15 1 0 0 85978 0
17 1 0 0 54979 0
radio [1/1]>
```


Table 163 Aggregate PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.
ES	Indicates the number of seconds in the measuring interval during which errors occurred.
SES	Indicates the number of severe error seconds in the measuring interval.
UAS	Indicates the Unavailable Seconds value of the measured interval. The value can be between 0 and 900 seconds (15 minutes).
BBE	Indicates the number of background block errors during the measured interval.

Displaying BER Level and Configuring the Excessive BER Thresholds (CLI)

To display the current BER level, go to radio view and enter the following command:

```
radio [x/x]>modem show ber
```

The `excessive-ber` parameter determines whether or not excessive BER is propagated as a fault and considered a system event. For example, if `excessive-ber` is enabled, excessive BER can trigger a protection switchover.

To enable or disable Excessive BER Admin, enter the following command in root view:

```
root> radio excessive-ber set admin <admin>
```



Note

By default, Excessive BER Admin is disabled.

To display the current setting for `excessive-ber`, enter the following command in root view:

```
root> radio excessive-ber show admin
```

To set the level above which an excessive BER alarm is issued for errors detected over the radio link, go to radio view and enter the following command:

```
radio [x/x]>modem excessive-ber set threshold <threshold>
```

To display the excessive BER threshold, go to radio view and enter the following command:

```
radio [x/x]>modem excessive-ber show threshold
```

Table 164 Excessive BER CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	enable disable	Enables or disables propagation of excessive BER as a fault.

For example, the following command enables `excessive-ber`:

```
root> radio excessive-ber set admin enable
```

To set the level above which an excessive BER alarm is issued for errors detected over the radio link, enter the following command in radio view:

```
radio[x/x]>modem excessive-ber set threshold <threshold>
```

To display the excessive BER threshold, enter the following command in radio view:

```
radio[x/x]>modem excessive-ber show threshold
```

Table 165 Excessive BER Threshold Parameters (CLI)

Parameter	Input Type	Permitted Values	Description
threshold	Variable	1e -3 1e -4 1e -5	The level above which an excessive BER alarm is issued for errors detected over the radio link.

The following command sets the excessive BER threshold for radio interface 2 to 1e-5:

```
radio[1/2]>modem excessive-ber set threshold 1e-5
```

Configuring RSL Thresholds (CLI)

You can set two RSL (RX Signal Level) thresholds. The number of seconds during which the RSL exceeds these thresholds are counted as RSL Exceed Threshold Seconds. See [Displaying RSL and TSL Levels \(CLI\)](#).

To set the RSL thresholds, go to radio view and enter the following command:

```
radio [x/x]>rf pm-rsl set threshold1 <threshold1> threshold2 <threshold2>
```

Table 166 RSL Thresholds CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold1	Number	-75 - -15	The first RSL threshold (dBm).
threshold2	Number	-75 - -15	The second RSL threshold (dBm).

The following command sets the RSL thresholds to -30 dBm and -60 dBm, respectively.

```
radio [2/1]>rf pm-rs1 set threshold1 -30 threshold2 -60
```

Configuring TSL Thresholds (CLI)

The number of seconds during which the TX Signal Level exceeds the TSL threshold are counted as TSL Exceed Threshold Seconds. See [Displaying RSL and TSL Levels \(CLI\)](#).

To set the TSL threshold, go to radio view and enter the following command:

```
radio [x/x]>rf pm-ts1 set threshold -15
```

Table 167 TSL Thresholds CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold	Number	-10 - 34	The TSL threshold (dBm).

The following command sets the TSL threshold to 10 dBm:

```
radio [2/1]>rf pm-ts1 set threshold 10
```

Displaying RSL and TSL Levels (CLI)

You can display the RSL (RX Signal Level) and TSL (TX Signal Level) PMs in either 15-minute or daily intervals.

To display RSL and TSL PMs in 15-minute intervals, go to radio view and enter the following command:

```
radio [x/x]>rf pm-rs1-ts1 show interval 15min
```

To display RSL and TSL PMs in daily intervals, go to radio view and enter the following command:

```
radio [x/x]>rf pm-rs1-ts1 show interval 24hr
```

The following is the output format of the `rf pm-rs1-ts1 show` commands:

```

radio [1/1]>rf pm-rsl-tsl show interval 15min
RF PM table:
=====
Interval Integrity Min RSL (dBm) Max RSL (dBm) Min TSL (dBm) Max TSL (dBm) TSL exceed RSL exceed RSL exceed
threshold threshold1 threshold2
seconds seconds seconds
=====
radio [1/1]>

```

Table 168 RSL and TSL PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.
Min RSL (dBm)	The minimum RSL (Received Signal Level) that was measured during the interval.
Max RSL (dBm)	The maximum RSL (Received Signal Level) that was measured during the interval.
Min TSL (dBm)	The minimum TSL (Transmit Signal Level) that was measured during the interval.
Max TSL (dBm)	The maximum TSL (Transmit Signal Level) that was measured during the interval.
TSL exceed threshold seconds	The number of seconds the measured TSL exceeded the threshold during the interval. See Configuring TSL Thresholds (CLI) .
RSL exceed threshold1 seconds	The number of seconds the measured RSL exceeded RSL threshold 1 during the interval. See Configuring RSL Thresholds (CLI)
RSL exceed threshold2 seconds	The number of seconds the measured RSL exceeded RSL threshold 2 during the interval. See Configuring RSL Thresholds (CLI)

Configuring the Signal Level Threshold (CLI)

To set the BER (Bit Error Rate) level above which a Signal Degrade alarm is issued for errors detected over the radio link, go to radio view and enter the following command:

```
radio [x/x]>modem signal-degrade set threshold 1e-7
```

To display the Signal Degrade BER threshold, go to radio view and enter the following command:

```
radio [x/x]>modem signal-degrade show threshold
```

Table 169 Signal Level Threshold CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold	Variable	1e -6 1e -7 1e -8 1e -9 1e -10	The BER level above which a Signal Degrade alarm is issued for errors detected over the radio link.

The following command sets the Signal Degrade threshold at 1e-7:

```
radio [2/1]>modem signal-degrade set threshold 1e-7
```

Configuring the MSE Thresholds and Displaying the MSE PMs (CLI)

To configure the MSE (Mean Square Error) threshold, go to radio view and enter the following command:

```
radio [x/x]>modem set mse-exceed threshold <threshold>
```

To display the currently configured MSE threshold, go to radio view and enter the following command:

```
radio [x/x]>modem show threshold-mse-exceed
```

Table 170 MSE CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold	Number	-99 - -1	The MSE threshold.

The following command sets the MSE threshold for radio interface 1 to -30:

```
radio[1/1]>modem set mse-exceed threshold -30
```

To display MSE (Mean Square Error) PMs in 15-minute intervals, go to radio view and enter the following command:

```
radio [x/x]>modem pm-mse show interval 15min
```

The following is a partial sample output of the `modem pm-mse show interval 15min` command:

```

radio [1/1]>modem pm-mse show interval 15min

Modem MSE PM Table:
=====

Interval Integrity Min MSE (dB) Max MSE (dB) Exceed
threshold
seconds
=====
=====
0 1 0.00 0.00 708
1 1 0.00 0.00 900
2 1 0.00 0.00 900
3 1 0.00 0.00 900
4 1 0.00 0.00 900
5 1 0.00 0.00 900
6 1 0.00 0.00 900
7 1 0.00 0.00 900
8 1 0.00 0.00 900
9 1 0.00 0.00 900
10 1 0.00 0.00 900

radio [1/1]>

```

To display MSE (Mean Square Error) PMs in daily intervals, go to radio view and enter the following command:

```
radio [x/x]>modem pm-mse show interval 24hr
```

The following is sample output of the `modem pm-mse show interval 24hr` command:

```

radio [1/1]>modem pm-mse show interval 24hr

Modem MSE PM Table:
=====

Interval Integrity Min MSE (dB) Max MSE (dB) Exceed
threshold
seconds
=====
=====
0 1 0.00 0.00 63745
4 1 0.00 0.00 37062
5 1 0.00 0.00 3495
6 1 0.00 0.00 85976
8 1 0.00 0.00 46173
11 1 0.00 0.00 24185
15 1 0.00 0.00 85988
17 1 0.00 0.00 54981
radio [1/1]>modem

```

Table 171 MSE PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.
Min MSE (dB)	Indicates the minimum MSE in dB, measured during the interval.
Max MSE (dB)	Indicates the maximum MSE in dB, measured during the interval.
Exceed Threshold Seconds	Indicates the number of seconds the MSE exceeded the MSE PM threshold during the interval.

Displaying ACM PMs (CLI)

To display ACM PMs in 15-minute intervals, enter the following command in radio view:

```
radio [x/x]>mrmc pm-acm show interval 15min
```

The following is a partial sample output of the modem pm-acm show interval 15min command:

```
radio [1/1]>mrmc pm-acm show interval 15min
MRMC PM Table:
=====
Interval Integrity Min profile Max profile Min bitrate Max bitrate
=====
===
0 1 0 0 43389 43389
1 1 0 0 43389 43389
2 1 0 0 43389 43389
3 1 0 0 43389 43389
4 1 0 0 43389 43389
5 1 0 0 43389 43389
6 1 0 0 43389 43389
7 1 0 0 43389 43389
8 1 0 0 43389 43389
9 1 0 0 43389 43389
10 1 0 0 43389 43389
radio [1/1]>
```

To display ACM PMs in daily intervals, enter the following command in radio view:

```
radio [x/x]>mrmc pm-acm show interval 24hr
```

The following is sample output of the modem pm-acm show interval 24hr command:

```

radio [1/1]>mrmc pm-acm show interval 24hr
MRCM PM Table:
=====
Interval Integrity Min profile Max profile Min bitrate Max bitrate
=====
===
0 1 0 0 43389 43389
4 1 0 0 43389 43389
5 1 0 0 43389 43389
6 1 0 0 43389 43389
8 1 0 0 43389 43389
11 1 0 0 43389 43389
15 1 0 0 43389 43389
17 1 0 0 43389 43389

radio [1/1]>

```

Table 172 ACM PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.
Integrity	Indicates whether the values received at time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.
Min profile	Indicates the minimum ACM profile that was measured during the interval.
Max profile	Indicates the maximum ACM profile that was measured during the interval.
Min bitrate	Indicates the minimum total radio throughput (Mbps), delivered during the interval.
Max bitrate	Indicates the maximum total radio throughput (Mbps), delivered during the interval.

Configuring the XPI Thresholds and Displaying the XPI PMs (CLI)

To configure the modem XPI threshold for calculating XPI Exceed Threshold seconds, go to radio view and enter the following command:

```
radio[x/x]>modem set threshold-xpi-exceed threshold <threshold>
```

To display the currently configured XPI threshold, go to radio view and enter the following command:

```
radio[x/x]>modem show threshold-xpi-below
```

Table 173 XPI Threshold CLI Parameters

Parameter	Input Type	Permitted Values	Description
threshold	Number	0-99	The XPI threshold.

To display XPI PMs in 15-minute intervals, go to radio view and enter the following command:

```
radio[x/x]>modem pm-xpi show interval 15min
```

The following is a partial sample output of the `modem pm-xpi show interval 15min` command:

```
radio [1/1]>modem pm-xpi show interval 15min
Modem XPI PM Table:
=====

Interval Integrity Min XPI (dB) Max XPI (dB) XPI below
threshold
seconds
=====
===
0 1 55.00 0.00 0
1 1 55.00 0.00 0
2 1 55.00 0.00 0
3 1 55.00 0.00 0
4 1 55.00 0.00 0
5 1 55.00 0.00 0
6 1 55.00 0.00 0
7 1 55.00 0.00 0
8 1 55.00 0.00 0
9 1 55.00 0.00 0
10 1 55.00 0.00 0
radio [1/1]>
```

To display XPI PMs in daily intervals, go to radio view and enter the following command:

```
radio[x/x]>modem pm-xpi show interval 24hr
```

The following is a partial sample output of the `modem pm-xpi show interval 24hr` command:

```

radio [1/1]>modem pm-xpi show interval 24hr

Modem XPI PM Table:
=====

Interval Integrity Min XPI (dB) Max XPI (dB) XPI below
threshold
seconds
=====
===
0 1 55.00 0.00 0
1 1 55.00 0.00 0
2 1 55.00 0.00 0
3 1 55.00 0.00 0
4 1 55.00 0.00 0
5 1 55.00 0.00 0
6 1 55.00 0.00 0
7 1 55.00 0.00 0
8 1 0.00 0.00 38802
9 1 0.00 0.00 48647
10 1 0.00 0.00 9665
11 1 0.00 0.00 1605
12 1 55.00 0.00 0
radio [1/1]>

```

Table 174 XPI PMs (CLI)

Parameter	Description
Interval	The number of the interval: 1-30 for daily PM reports, and 1-96 for 15 minute PM reports.
Integrity	Indicates whether the values received at the time and date of the measured interval are reliable. "1" in the column indicates that the values are not reliable due to a possible power surge or power failure that occurred at that time.
Min XPI (dB)	Indicates the lowest XPI value in dB, measured during the interval.
Max XPI (dB)	Indicates the highest XPI value in dB, measured during the interval.
XPI Below Threshold Seconds	Indicates the number of seconds the XPI value was lower than the XPI threshold during the interval.

Chapter 18: Ethernet Services and Interfaces (CLI)

This section includes:

- [Configuring Ethernet Services \(CLI\)](#)
- [Setting the MRU Size and the S-VLAN Ethertype \(CLI\)](#)
- [Configuring Ethernet Interfaces \(CLI\)](#)
- [Configuring Automatic State Propagation and Link Loss Forwarding \(CLI\)](#)
- [Viewing Ethernet PMs and Statistics \(CLI\)](#)

Related topics:

- [Configuring Link Aggregation \(LAG\) and LACP \(CLI\)](#)
- [Quality of Service \(QoS\) \(CLI\)](#)
- [Ethernet Protocols \(CLI\)](#)
- [Performing Ethernet Loopback \(CLI\)](#)
- [Ethernet Traffic Interfaces](#)
- [Ethernet Pin-Outs and LEDs](#)

Configuring Ethernet Services (CLI)

This section includes:

- [Ethernet Services Overview \(CLI\)](#)
- [General Guidelines for Provisioning Ethernet Services \(CLI\)](#)
- [Defining Services \(CLI\)](#)
- [Configuring Service Points \(CLI\)](#)
- [Defining the MAC Address Forwarding Table for a Service \(CLI\)](#)

Ethernet Services Overview (CLI)

Users can define up to 64 Ethernet services. Each service constitutes a virtual bridge that defines the connectivity between logical ports in the PTP 820G or PTP 820F network element.

This version of PTP 820G and PTP 820F supports the following service types:

- Multipoint (MP)
- Point-to-Point (P2P)
- Management (MNG)

In addition to user-defined services, PTP 820G and PTP 820F contains a pre-defined management service (Service ID 257). By default, this service is operational.

**Note**

You can use the management service for in-band management. For instructions on configuring in-band management, see [Configuring In-Band Management \(CLI\)](#).

A service point is a logical entity attached to a physical or logical interface. Service points define the movement of frames through the service. Each service point includes both ingress and egress attributes. A Point-to-Point or Multipoint service can hold up to 32 service points. A Management service can hold up to 30 service points.

For a more detailed overview of the PTP 820G and PTP 820F service-oriented Ethernet switching engine, refer to the Technical Description for the PTP 820 product type you are using.

General Guidelines for Provisioning Ethernet Services (CLI)

When provisioning Ethernet services, it is recommended to follow these guidelines:

- Use the same Service ID for all service fragments along the path of the service.
- Do not re-use the same Service ID within the same region. A region is defined as consisting of all PTP 820G and PTP 820F devices having Ethernet connectivity between them.
- Use meaningful EVC IDs.

- Give the same EVC ID (service name) to all service fragments along the path of the service.
- Do not reuse the same EVC ID within the same region.

It is recommended to follow these guidelines for creating service points:

- Always use SNP service points on NNI ports and SAP service points on UNI ports.
- For each logical interface associated with a specific service, there should never be more than a single service point.
- The transport VLAN ID should be unique per service within a single region. That is, no two services should use the same transport VLAN ID.

Defining Services (CLI)

Use the commands described in the following sections to define a service and its parameters. After defining the service, you must add service points to the service in order for the service to carry traffic.

This section includes:

- [Adding a Service \(CLI\)](#)
- [Entering Service View \(CLI\)](#)
- [Showing Service Details \(CLI\)](#)
- [Configuring a Service's Operational State \(CLI\)](#)
- [Configuring a Service's CoS Mode and Default CoS \(CLI\)](#)
- [Configuring a Service's EVC ID and Description \(CLI\)](#)
- [Deleting a Service \(CLI\)](#)

Adding a Service (CLI)

To add a service, enter the following command in root view:

```
root> ethernet service add type <service type> sid <sid> admin <service
admin mode> evc-id <evc-id> description <evc-description>
```

Table 175 Adding Ethernet Service CLI Parameters

Parameter	Input Type	Permitted Values	Description
service type	Variable	P2P - Point-to-Point MP - Multipoint	Defines the service type.
sid	Number	Any unused value from 1-1024	A unique ID for the service. Once you have added the service, you cannot change the Service ID. Service ID 1025 is reserved for a pre-defined management service.

Parameter	Input Type	Permitted Values	Description
service admin mode	Variable	operational reserved	The administrative state of the service: operational - The service is functional. reserved - The service is disabled until this parameter is changed to operational . In this mode, the service occupies system resources but is unable to receive and transmit data.
evc-id	Text String	Up to 20 characters.	Defines an Ethernet Virtual Connection (EVC) ID. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.
evc description	Text String	Up to 64 characters.	A text description of the service. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.

The following command adds a Multipoint service with Service ID 18.

```
root> ethernet service add type mp sid 18 admin operational evc-id Ring_1
description east_west
```

The following command adds a Point-to-Point service with Service ID 10.

```
root> ethernet service add type p2p sid 10 admin operational evc-id
Ring_1 description east_west
```

These services are immediately enabled, although service points must be added to the services in order for the services to carry traffic.

Entering Service View (CLI)

To view service details and set the service's parameters, you must enter the service's view level in the CLI.

To enter a service's view level:

```
root> ethernet service sid <sid>
```

The following command enters service view for the service with Service ID 10:

```
root> ethernet service sid 10
```

The following prompt appears:

```
service[10]>
```

Showing Service Details (CLI)

To display the attributes of a service, go to service view for the service and enter the following command:

```
service[SID]>service info show
```

For example:

```

service[1]>service info show
  service info:
  service id: 1
  service type: p2p
  service admin: operational
  Maximal MAC address learning entries: 131072
  default cos: 0
  cos mode: preserve-sp-cos-decision
  EVC id: N.A.
  EVC description: N.A.
  split horizon group: disable
  configured multicast grouping: no
service[1]>

```

To display the attributes of a service and its service points, go to service view for the service and enter the following command:

```
service[SID]>service detailed-info show
```

For example:

```

service[1]>service detailed-info show
service info:
service id: 1
service type: mp
service admin: operational
Maximal MAC address learning entries: 131072
default cos: 0
cos mode: preserve-sp-cos-decision
EVC id: N.A.
EVC description: N.A.
split horizon group: disable
configured multicast grouping: no
service-points info:
+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+
|Service ID|Service Type|List of SP's|Attached to Interface|Attached
Interface Type|Service Admin|STP Instance|SP name|
+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+
|1 |mp |sap \2 |rj45 1/2|dot1q |operational |0 | N.A. |
|1 |mp |snp \3 |radio 3/1|s-tag |operational |0 | N.A. |
+-----+-----+-----+-----+-----+
-----+-----+-----+-----+
service[1]>

```

To display a list of service points and their attributes, enter the following command in root view:

```
root>ethernet service show info sid <sid>
```

Table 176 Displaying Ethernet Service Details CLI Parameters

Parameter	Input Type	Permitted Values	Default	Description
sid	Number	Any defined Service ID.	None	None

For example:

```

root> ethernet service show info sid 1
service-points info:
+-----+-----+-----+-----+-----+-----+
|Service ID|Service Type|List of SP's|Attached to Interface|Attached
Interface Type|Service Admin|STP Instance|SP name|
+-----+-----+-----+-----+-----+-----+
|1 |mp |sap \2 |rj45 1/2|dot1q |operational |0 | N.A. |
|1 |mp |snp \3 |radio 3/1|s-tag |operational |0 | N.A. |
+-----+-----+-----+-----+-----+-----+
root>
    
```

Configuring a Service’s Operational State (CLI)

To change the operational state of a service, go to service view for the service and enter the following command:

```

service[SID]>service admin set <service admin mode>
    
```

Table 177 Ethernet Service Operational State CLI Parameters

Parameter	Input Type	Permitted Values	Description
service admin mode	Variable	Operational reserved	The administrative state of the service: operational - The service is functional. reserved - The service is disabled until this parameter is changed to operational . In this mode, the service occupies system resources but is unable to receive and transmit data.

The following command sets Service 10 to be operational:

```

service[10]>service admin set operational
    
```

To display a service’s admin mode, go to service view for the service and enter the following command:

```

Service[SID]> service admin show state
    
```

Configuring a Service's CoS Mode and Default CoS (CLI)

The CoS mode determines whether or not frames passing through the service have their CoS modified at the service level. The CoS determines the priority queue to which frames are assigned.

The CoS of frames traveling through a service can be modified on the interface level, the service point level, and the service level. The service level is the highest priority, and overrides CoS decisions made at the interface and service point levels. Thus, by configuring the service to apply a CoS value to frames in the service, you can define a single CoS for all frames traveling through the service.

To set a service's CoS mode, go to service view for the service and enter the following command:

```
service[SID]>service cos-mode set cos-mode <cos-mode>
```

If the CoS mode is set to `default-cos`, you must define the Default CoS. Use the following command to define the Default CoS:

```
service[SID]>service default-cos set cos <cos>
```

Table 178 Ethernet Service CoS Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
cos-mode	Variable	default-cos preserve-sp-cos- decision	<code>default cos</code> - Frames passing through the service are assigned the default CoS defined below. This CoS value overrides whatever CoS may have been assigned at the service point or interface level. <code>preserve-sp-cos-decision</code> - The CoS of frames passing through the service is not modified by the service.

If the CoS mode is set to `default-cos`, you must define the Default CoS. Use the following command to define the Default CoS:

```
service[SID]>service default-cos set cos <cos>
```

Table 179 Ethernet Service Default CoS CLI Parameters

Parameter	Input Type	Permitted Values	Description
cos	Number	0–7	This value is assigned to frames at the service level if <code>cos-mode</code> is set to <code>default-cos</code> . Otherwise, this value is not used, and frames retain whatever CoS value they were assigned at the service point or logical interface level.

The following commands configure Service 10 to assign a CoS value of 7 to frames traversing the service:

```
service[10]>service cos-mode set cos-mode default-cos
service[10]>service default-cos set cos 7
```

The following command configures Service 10 to preserve the CoS decision made at the interface or service point level for frames traveling through the service:

```
service[10]>service cos-mode set cos-mode preserve-sp-cos-decision
```

Configuring a Service's EVC ID and Description (CLI)

To add or change the EVC ID of a service, go to service view for the service and enter the following command:

```
service[SID]>service evcid set <evcid>
```

To display a service's EVC ID, go to service view for the service and enter the following command:

```
service[SID]>service evcid show
```

To add or change the EVC description of a service, go to service view for the service and enter the following command:

```
service[SID]>service description set <evc description>
```

To display a service's EVC description, go to service view for the service and enter the following command:

```
service[SID]>service description show
```

Table 180 Ethernet Service EVC CLI Parameters

Parameter	Input Type	Permitted Values	Description
evcid	Text String	Up to 20 characters.	Defines an Ethernet Virtual Connection (EVC) ID. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.

To display a service's EVC ID, go to service view for the service and enter the following command:

```
service[SID]>service evcid show
```

To add or change the EVC description of a service, go to service view for the service and enter the following command:

```
service[SID]>service description set <evc description>
```

Table 181 Ethernet Service EVC Description CLI Parameters

Parameter	Input Type	Permitted Values	Description
evc description	Text String	Up to 64 characters.	A text description of the service. This parameter does not affect the network element's behavior, but is used by the NMS for topology management.

To display a service's EVC description, go to service view for the service and enter the following command:

```
service[SID]>service description show
```

For example, the following commands add the EVC ID "East_West" and the EVC description "Line-to-Radio" to Service 10:

```
service[10]>service evcid set East_West
service[10]>service description set Line-to-Radio
```

Deleting a Service (CLI)

Before deleting a service, you must first delete any service points attached to the service (refer to [Deleting a Service Point \(CLI\)](#)).

Use the following command to delete a service:

```
root>ethernet service delete sid <sid>
```

The following command deletes Service 10:

```
root>ethernet service delete sid 10
```

Configuring Service Points (CLI)

This section includes:

- [Service Points Overview \(CLI\)](#)
- [Service Point Classification \(CLI\)](#)
- [Adding a Service Point \(CLI\)](#)
- [Configuring Service Point Ingress Attributes \(CLI\)](#)
- [Configuring Service Point Egress Attributes \(CLI\)](#)
- [Displaying Service Point Attributes \(CLI\)](#)
- [Deleting a Service Point \(CLI\)](#)

Service Points Overview (CLI)

Service points are logical interfaces within a service. A service point is a logical entity attached to a physical or logical interface. Service points define the movement of frames through the service. Each service point includes both ingress and egress attributes.

Each service point for a Point-to-Point or Multipoint service can be either a Service Access Point (SAP) or a Service Network Point (SNP). A Point-to-Point service can also use Pipe service points.

- An SAP is equivalent to a UNI in MEF terminology and defines the connection of the user network with its access points. SAPs are used for Point-to-Point and Multipoint traffic services.
- An SNP is equivalent to an NNI or E-NNI in MEF terminology and defines the connection between the network elements in the user network. SNPs are used for Point-to-Point and Multipoint traffic services.
- A Pipe service point is used to create traffic connectivity between two ports in a port-based manner (Smart Pipe). In other words, all the traffic from one port passes to the other port.

Management services utilize Management (MNG) service points.

A Point-to-Point or Multipoint service can hold up to 32 service points. A management service can hold up to 30 service points.

[Table 182](#) summarizes the service point types available per service type.

Table 182 Service Points per Service Type

		Service Point Type			
		MNG	SAP	SNP	Pipe
Service Type	Management	Yes	No	No	No
	Point-to-Point	No	Yes	Yes	Yes
	Multipoint	No	Yes	Yes	No

[Table 183](#) shows which service point types can co-exist on the same interface. **Table 183** Service Point Types per Interface

	MNG	SAP	SNP	Pipe
MNG	Only one MNG SP is allowed per interface.	Yes	Yes	Yes
SAP	Yes	Yes	No	No
SNP	Yes	No	Yes	No
PIPE	Yes	No	No	Only one Pipe SP is allowed per interface.

Service Point Classification (CLI)

This section includes:

- [Overview of Service Point Classification \(CLI\)](#)
- [SAP Classification \(CLI\)](#)
- [SNP Classification \(CLI\)](#)
- [Pipe Service Point Classification \(CLI\)](#)
- [MNG Service Point Classification \(CLI\)](#)

Overview of Service Point Classification (CLI)

Service points connect the service to the network element interfaces. It is crucial that the network element have a means to classify incoming frames to the proper service point. This classification process is implemented by means of a parsing encapsulation rule for the interface associated with the service point. This rule is called the Interface Type, and is based on a key consisting of:

- The Interface ID of the interface through which the frame entered.
- The frame's C-VLAN and/or S-VLAN tags.

The Interface Type provides a definitive mapping of each arriving frame to a specific service point in a specific service. Since more than one service point may be associated with a single interface, frames are assigned to the earliest defined service point in case of conflict.

SAP Classification (CLI)

SAPs can be used with the following Interface Types:

- **All to one** – All C-VLANs and untagged frames that enter the interface are classified to the same service point.
- **Dot1q** – A single C-VLAN is classified to the service point.
- **QinQ** – A single S-VLAN and C-VLAN combination is classified to the service point.
- **Bundle C-Tag** – A set of multiple C-VLANs is classified to the service point.
- **Bundle S-Tag** – A single S-VLAN and a set of multiple C-VLANs are classified to the service point.

SNP Classification (CLI)

SNPs can be used with the following Attached Interface Types:

- **Dot1q** – A single C-VLAN is classified to the service point.
- **S-Tag** – A single S-VLAN is classified to the service point.

Pipe Service Point Classification (CLI)

Pipe service points can be used with the following Attached Interface Types:

- **Dot1q** – All C-VLANs and untagged frames that enter the interface are classified to the same service point.
- **S-Tag** – All S-VLANs and untagged frames that enter the interface are classified to the same service point.

MNG Service Point Classification (CLI)

Management service points can be used with the following Interface Types:

- **Dot1q** – A single C-VLAN is classified to the service point.
- **S-Tag** – A single S-VLAN is classified to the service point.
- **QinQ** – A single S-VLAN and C-VLAN combination is classified to the service point.

[Table 184](#) and [Table 185](#) show which service point – Interface Type combinations can co-exist on the same interface.

Table 184 Legal Service Point – Interface Type Combinations per Interface – SAP and SNP

SP Type	Attached Interface Type	SAP				SNP		
		802.1q	Bundle-C	Bundle-S	All to One	Q in Q	802.1q	S-Tag
SAP	802.1q	Yes	Yes	No	No	No	No	No
	Bundle-C	Yes	Yes	No	No	No	No	No
	Bundle-S	No	No	Yes	No	Yes	No	No
	All to One	No	No	No	Only 1 All to One SP Allowed	No	No	No
	Q in Q	No	No	Yes	No	Yes	No	No
SNP	802.1q	No	No	No	No	No	Yes	No
	S-Tag	No	No	No	No	No	No	Yes
Pipe	802.1q	No	No	No	No	No	No	No
	S-Tag	No	No	No	No	No	No	No
MNG	802.1q	Yes	Yes	No	No	No	Yes	No
	Q in Q	No	No	Yes	No	Yes	No	No
	S-Tag	No	No	No	No	No	No	Yes

Table 185 Legal Service Point – Interface Type Combinations per Interface – Pipe and MNG

	SP Type	Pipe		MNG		
SP Type	Attached Interface Type	802.1q	S-Tag	802.1q	Q in Q	S-Tag
SAP	802.1q	No	No	Yes	No	No
	Bundle-C	No	No	Yes	No	No
	Bundle-S	No	No	No	Yes	No
	All to One	No	No	No	No	No
	Q in Q	No	No	No	Yes	No
SNP	802.1q	No	No	Yes	No	No
	S-Tag	No	No	No	No	Yes
Pipe	802.1q	Only one Pipe SP Allowed	No	Yes	No	No
	S-Tag	No	Only one Pipe SP Allowed	No	No	Yes
MNG	802.1q	Yes	No	Only 1 MNG SP Allowed	No	No
	Q in Q	No	No	No	Only 1 MNG SP Allowed	No
	S-Tag	No	Yes	No	No	Only 1 MNG SP Allowed

Adding a Service Point (CLI)

The command syntax for adding a service point depends on the interface type of the service point. The interface type determines which frames enter the service via this service point.

To add a service point with an All-to-One interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type all-to-one spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> sp-name <sp-name>
```

To add a service point with a Dot1q interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type dot1q spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> vlan <vlan>
sp-name <sp-name>
```

To add a service point with an S-Tag interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type s-tag spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> vlan <vlan>
sp-name <sp-name>
```

To add a service point with a Bundle-C interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type bundle-c spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> sp-name <sp-
name>
```

To add a service point with a Bundle-S interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type bundle-s spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> [outer-
vlan <outer-vlan>|vlan <vlan>] sp-name <sp-name>
```



Note

In SAP service points, use the parameter `outer-vlan`. In SP service points, use the parameter `vlan`.

To add a service point with a Q-in-Q interface type, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type <sp-type> int-type qinq spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> outer-
vlan <outer-vlan> inner-vlan <inner-vlan> sp-name <sp-name>
```

To add a Pipe service point, go to service view for the service and enter the following command:

```
service[SID]>sp add sp-type pipe int-type <int-type> spid <sp-id>
[interface|group] <interface|group> slot <slot> port <port> sp-name <sp-
name>
```

Table 186 Add Service Point CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-type	Variable	sap	SAP – Service Access Point
		snp	SNP – Service Network Point
		pipe	PIPE – Pipe service point
		mng	MNG – Management service point

Parameter	Input Type	Permitted Values	Description
int-type	Variable	all-to-one dot1q s-tag bundle-c-tag bundle-s-tag qinq	<p>Determines which frames enter the service via this service point, based on the frame's VLAN tagging. Since more than one service point may be associated with a single interface, frames are assigned to the earliest defined service point in case of conflict.</p> <p>all-to-one – All C-VLANs and untagged frames that enter the interface are classified to the service point. Only valid for SAP service point types.</p> <p>dot1q – A single C-VLAN is classified to the service point. Valid for all service point types.</p> <p>s-tag – A single S- VLAN is classified to the service point. Valid for SNP and MNG service point types.</p> <p>bundle-c-tag – A set of multiple C-VLANs is classified to the service point. Only valid for SAP service point types.</p> <p>bundle-s-tag – A single S-VLAN and a set of multiple C-VLANs are classified to the service point. Only valid for SAP service point types.</p> <p>qinq – A single S-VLAN and C-VLAN combination is classified to the service point. Valid for SAP and MNG service point types.</p>
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	This ID is unique within the service.
interface	Variable	eth pwe radio	<p>The Interface type for the service point:</p> <p>eth – An Ethernet interface.</p> <p>pwe – A TDM interface.</p> <p>radio – A radio interface.</p> <p>When you are defining the service point on a group, such as a 1+1 HSB group or a LAG group, use the group parameter instead of the interface parameter.</p>

Parameter	Input Type	Permitted Values	Description
group	Variable	rp1 rp2 rp3 rp4 lag1 lag2 lag3 lag4 mc-abc1 mc-abc2 mc-abc3 mc-abc4	When you are defining the service point on a 1+1 HSB group, a LAG group, or a Multi-Carrier ABC group, use this parameter instead of the interface parameter to identify the group. The group must be defined before you add the service point. See: <ul style="list-style-type: none"> Configuring HSB Radio Protection (CLI) Configuring Link Aggregation (LAG) and LACP (CLI) Configuring Multi-Carrier ABC (CLI)
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 tdm: 1	The port on which the service point is located.
vlan	Number or Variable	1-4094, or Untagged	Defines the VLAN classified to the service point. This parameter should not be included for service points with an interface type of bundle-C-tag. For instructions on attaching a bundled VLAN, refer to Attaching a VLAN Bundle to a Service Point . This parameter is also not relevant for: Service points with an interface type of qinq and all-to-one. Pipe service points.
outer-vlan	Number	1-4094, or Untagged	Defines the S-VLAN classified to the service point. This parameter is only relevant for service points with the interface type bundle-s-tag or qinq.
inner-vlan	Number	1-4094, or Untagged	Defines the C-VLAN classified to the service point. This parameter is only relevant for service points with the interface type qinq.
sp-name	Text string	Up to 20 characters.	A descriptive name for the service point (optional).

Adding Service Point Examples (CLI)

The following command adds an SAP service point with Service Point ID 10 to Service 37, with interface type dot1q. This service point is located on radio interface 1. VLAN ID 100 is classified to this service point.

```
service[37]>sp add sp-type sap int-type dot1q spid 10 interface radio
slot 1 port 1 vlan 100 sp-name Radio
```

The following command adds an SAP service point with Service Point ID 10 to Service 37, with interface type bundle-c-tag. This service point is located on radio interface 2.

```
service[37]>sp add sp-type sap int-type bundle-c-tag spid 10 interface
radio slot 1 port 2 sp-name Radio
```

The following command adds an SAP service point with Service Point ID 10 to Service 37, with interface type qinq. This service point is located on radio interface 1. S-VLAN 100 and C-VLAN 200 are classified to the service point.

```
service[37]>sp add sp-type sap int-type qinq spid 10 interface radio slot
1 port 1 outer-vlan 100 inner-vlan 200 sp-name Radio
```

The following command adds an SAP service point with Service Point ID 10 to Service 37, with interface type all-to-one. This service point is located on radio interface 2. All traffic entering the system from that port is classified to the service point.

```
service[37]>sp add sp-type sap int-type all-to-one spid 10 interface
radio slot 1 port 2 sp-name all-to-one
```

The following command adds an SNP service point with Service Point ID 10 to Service 37, with interface type dot1q. This service point is located on radio interface 1. VLAN ID 100 is classified to this service point.

```
service[37]>sp add sp-type snp int-type dot1q spid 10 interface radio
slot 1 port 1 vlan 100 sp-name Radio
```

The following command adds an SAP service point with Service Point ID 7 to Service 36, with interface type dot1q. This service point is connected to Radio Group 1 (rp1). VLAN ID 100 is classified to the service point.

```
service[36]>sp add sp-type sap int-type dot1q spid 7 group rp1 vlan 100
sp-name test1
```

The following command adds a Pipe service point with Service Point ID 1 to Service 1, with interface type dot1q. This service point is located on Ethernet port 1.

```
service[1]>sp add sp-type pipe int-type dot1q spid 1 interface eth slot 1
port 1 sp-name pipe_dot1q
```

The following command adds a Pipe service point with Service Point ID 2 to Service 1, with interface type dot1q. This service point is located on Ethernet port 2.

```
service[1]>sp add sp-type pipe int-type dot1q spid 2 interface radio slot
1 port 2 sp-name pipe_dot1q_radio
```

The following commands create a Smart Pipe service between Ethernet port 1 and Multi-Carrier ABC group 1. This service carries S-VLANs and untagged frames between the two interfaces:

```

root> ethernet service add type p2p sid 10 admin operational evc-id test
description east_west
root>
root> ethernet service sid 10
service[10]>
service[10]>sp add sp-type pipe int-type s-tag spid 1 interface eth slot
1 port 1 sp-name test1
service[10]>
service[10]>sp add sp-type pipe int-type s-tag spid 2 group mc-abc1 sp-
name test2
service[10]>

```

Configuring Service Point Ingress Attributes (CLI)

A service point's ingress attributes are attributes that operate upon frames ingressing via the service point. This includes how the service point handles the CoS of ingress frames and how the service point forwards frames to their next destination within the service.

This section includes:

- [Enabling and Disabling Broadcast Frames \(CLI\)](#)
- [CoS Preservation and Modification on a Service Point \(CLI\)](#)
- [Enabling and Disabling Flooding \(CLI\)](#)

Enabling and Disabling Broadcast Frames (CLI)

To determine whether frames with a broadcast destination MAC address are allowed to ingress the service via this service point, go to service view for the service and enter the following command:

```
service[SID]>sp broadcast set spid <sp-id> state <state>
```

Table 187 Enable/Disable Broadcast Frames CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
state	Variable	Allow disable	Determines whether frames with a broadcast destination MAC address are allowed to ingress the service via this service point.

The following command allows frames with a broadcast destination MAC address to ingress Service 37 via Service Point 1.

```
service[37]>sp broadcast set spid 1 state allow
```

The following command prevents frames with a broadcast destination MAC address from ingressing Service 37 via Service Point 1.

```
service[37]>sp broadcast set spid 1 state disable
```

CoS Preservation and Modification on a Service Point (CLI)

The CoS of frames traversing a service can be modified on the logical interface, service point, and service level. The service point can override the CoS decision made at the interface level. The service, in turn, can modify the CoS decision made at the service point level.

To determine whether the service point modifies CoS decisions made at the interface level, go to service view for the service and enter the following command:

```
service[SID]> sp cos-mode set spid <sp-id> mode <cos mode>
```

Table 188 Service Point CoS Preservation CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
cos mode	Variable	sp-def-cos interface-decision	sp-def-cos – The service point re-defines the CoS of frames that pass through the service point, according to the Default CoS (below). This decision can be overwritten on the service level. interface-decision – The service point preserves the CoS decision made at the interface level. This decision can still be overwritten at the service level.

If you set `cos-mode` to `sp-def-cos`, you must then configure a default CoS. This CoS is applied to frames that ingress the service point, but can be overwritten at the service level.

To configure the default CoS, go to service view for the service and enter the following command:

```
service[SID]>sp sp-def-cos set spid <sp-id> cos <cos>
```

Table 189 Service Point Default CoS CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
cos	Number	0 – 7	If <code>cos-mode</code> is <code>sp-def-cos</code> , this is the CoS assigned to frames that pass through the service point. This decision can be overwritten on the service level.

The following commands configure Service Point 1 in Service 37 to apply a CoS value of 5 to frames that ingress the service point:

```
service[37]>sp cos-mode set spid 1 mode sp-def-cos
service[37]>sp sp-def-cos set spid 1 cos 5
```

The following command configures Service Point 1 in Service 37 to preserve the CoS decision made at the interface level for frames that ingress the service point:

```
service[37]>sp cos-mode set spid 1 mode interface-decision
```

Enabling and Disabling Flooding (CLI)

The ingress service point for a frame can forward the frame within the service by means of flooding or dynamic MAC address learning in the service.

To enable or disable forwarding by means of flooding for a service point, go to service view for the service and enter the following command:

```
service[SID]>sp flooding set spid <sp-id> state <flooding state>
```

Table 190 Service Point Enable/Disable Flooding CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
state	Variable	Allow disable	Determines whether incoming frames with unknown MAC addresses are forwarded to other service points via flooding.

The following command configures Service Point 1 in Service 37 to flood incoming frames with unknown MAC addresses to other service points:

```
service[37]>sp flooding set spid 1 state allow
```

The following command configures Service Point 1 in Service 37 not to flood incoming frames with unknown MAC addresses to other service points:

```
service[37]>sp flooding set spid 1 state disable
```

Configuring Service Point Egress Attributes (CLI)

A service point's egress attributes are attributes that operate upon frames ingressing via the service point. This includes VLAN preservation and marking attributes.

This section includes:

- [Configuring VLAN and CoS Preservation \(CLI\)](#)
- [Configuring Service Bundles \(CLI\)](#)

Configuring VLAN and CoS Preservation (CLI)

CoS and VLAN preservation determines whether the CoS and/or VLAN IDs of frames egressing the service via the service point are restored to the values they had when the frame entered the service.

This section includes:

- [Configuring C-VLAN CoS Preservation \(CLI\)](#)
- [Configuring C-VLAN Preservation \(CLI\)](#)
- [Configuring S-VLAN CoS Preservation \(CLI\)](#)

Configuring C-VLAN CoS Preservation (CLI)

To configure CoS preservation for C-VLAN-tagged frames, go to service view for the service and enter the following command:

```
service[SID]>sp cvlan-cos-preservation-mode set spid <sp-id> mode <c-
vlan cos preservation mode>
```

Table 191 C-VLAN CoS Preservation Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
c-vlan cos preservation mode	Variable	enable disable	Select enable or disable to determine whether the original C-VLAN CoS value is preserved or restored for frames egressing the service point. enable – the C-VLAN CoS value of frames egressing the service point is the same as the value when the frame entered the service. disable – the C-VLAN CoS value of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking (see Configuring Marking (CLI)).

The following command enables C-VLAN CoS preservation for Service Point 1 on Service 37:

```
service[37]>sp cvlan-cos-preservation-mode set spid 1 mode enable
```

The following command disables C-VLAN CoS preservation for Service Point 1 on Service 37:

```
service[37]>sp cvlan-cos-preservation-mode set spid 1 mode disable
```

Configuring C-VLAN Preservation (CLI)

To configure VLAN preservation for C-VLAN-tagged frames, go to service view for the service and enter the following command:

```
service[SID]>sp cvlan-preservation-mode set spid <sp-id> mode <c-
vlan preservation mode>
```

Table 192 C-VLAN Preservation CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
c-vlan preservation mode	Variable	enable disable	Determines whether the original C-VLAN ID is preserved or restored for frames egressing from the service point. enable – The C-VLAN ID of frames egressing the service point is the same as the C-VLAN ID when the frame entered the service. disable – The C-VLAN ID of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking (see Configuring Marking (CLI)).

The following command enables C-VLAN preservation for Service Point 1 on Service 37:

```
service[37]>sp cvlan-preservation-mode set spid 1 mode enable
```

The following command disables C-VLAN preservation for Service Point 1 on Service 37:

```
service[37]>sp cvlan-preservation-mode set spid 1 mode disable
```

Configuring S-VLAN CoS Preservation (CLI)

To configure CoS preservation for S-VLAN-tagged frames, go to service view for the service and enter the following command:

```
service[SID]>sp svlan-cos-preservation-mode set spid <sp-id> mode <svlan cos preservation mode>
```

Table 193 S-VLAN CoS Preservation CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
s-vlan cos preservation mode	Variable	enable disable	Select enable or disable to determine whether the original S-VLAN CoS value is preserved or restored for frames egressing the service point. enable – the S-VLAN CoS value of frames egressing the service point is the same as the value when the frame entered the service. disable – the S-VLAN CoS value of frames egressing the service point is set at whatever value might have been re-assigned by the interface, service point, or service, or whatever value results from marking (see Configuring Marking (CLI)).

The following command enables S-VLAN CoS preservation for Service Point 1 on Service 37:

```
service[37]>sp svlan-cos-preservation-mode set spid 1 mode enable
```

The following command disables S-VLAN CoS preservation for Service Point 1 on Service 37:

```
service[37]>sp svlan-cos-preservation-mode set spid 1 mode disable
```

Configuring Service Bundles (CLI)

You can use service bundles to personalize common sets of egress queue attributes that can be applied to multiple service points. In this version only one service bundle is supported.

To assign a service point to a service bundle, go to service view for the service and enter the following command:

```
service[SID]>sp egress-service-bundle set spid 1 service-bundle-id  
<service-bundle-id>
```

Table 194 Service Bundle CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle assigned to the service point.

The following command assigns Service Bundle 1 to Service Point 1 in Service 37.

```
service[37]>sp egress-service-bundle set spid 1 service-bundle-id 1
```

Attaching a VLAN Bundle to a Service Point (CLI)

For service points with an interface type of bundle-C-tag or bundle-S-tag, you must classify a group of VLANs (VLAN Bundle) to the service point.

To classify a VLAN Bundle to a bundle-c-tag or bundle s-tag service point, go to service view for the service and enter the following command:

```
service[SIP]>sp bundle cvlan attach spid <sp-id> vlan <vlan> to-vlan <to-vlan>
```

To remove a VLAN Bundle from a bundle-c-tag or bundle-s-tag service point, go to service view for the service and enter the following command:

```
service[SIP]>sp bundle cvlan remove spid <sp-id> vlan <vlan> to-vlan <to-vlan>
```

Table 195 VLAN Bundle to Service Point CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	This ID is unique within the service.
vlan	Number	1-4094	The C-VLAN at the beginning of the range of the VLAN Bundle.
to-vlan	Number	1-4094	The C-VLAN at the end of the range of the VLAN Bundle.

The following command classifies C-VLANs 100 through 200 to Service Point 1 in Service 37:

```
service[37]>sp bundle cvlan attach spid 1 vlan 100 to-vlan 200
```

The following command removes C-VLANs 100 through 200 from Service Point 1 in Service 37:

```
service[37]>sp bundle cvlan remove spid 1 vlan 100 to-vlan 200
```

Displaying Service Point Attributes (CLI)

To display a service point's attributes, go to service view for the service to which the service point belongs and enter the following command:

```
service[SID]>sp service-point-info show spid <sp-id>
```

Table 196 Display Service Point Attributes CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.

The following command displays the attributes of Service Point 1 in Service 37:

```
service[37]>sp service-point-info show spid 1
```

Deleting a Service Point (CLI)

You can only delete a service point if no VLAN bundles are attached to the service point. This is only relevant if the interface type of the service point is bundle-c-tag or bundle-s-tag. For more information, refer to [Attaching a VLAN Bundle to a Service Point \(CLI\)](#).

To delete a service point from a service, go to service view for the service and enter the following command:

```
service[SID]>sp delete spid <sp-id>
```

The following command deletes Service Point 10 from Service 37:

```
service[37]>sp delete spid 10
```

Defining the MAC Address Forwarding Table for a Service (CLI)

This section includes:

- [MAC Address Forwarding Table Overview \(CLI\)](#)
- [Setting the Maximum Size of the MAC Address Forwarding Table \(CLI\)](#)
- [Setting the MAC Address Forwarding Table Aging Time \(CLI\)](#)
- [Adding a Static MAC Address to the Forwarding Table \(CLI\)](#)
- [Displaying the MAC Address Forwarding Table \(CLI\)](#)
- [Flushing the MAC Address Forwarding Table \(CLI\)](#)
- [Enabling MAC Address Learning on a Service Point \(CLI\)](#)

MAC Address Forwarding Table Overview (CLI)

PTP 820G and PTP 820F performs MAC address learning per service. PTP 820G and PTP 820F can learn up to 131,072 MAC addresses.

If necessary due to security issues or resource limitations, you can limit the size of the MAC address forwarding table. The maximum size of the MAC address forwarding table is configurable per service in granularity of 16 entries.

When a frame arrives via a specific service point, the learning mechanism checks the MAC address forwarding table for the service to which the service point belongs to determine whether that MAC address is known to the service. If the MAC address is not found, the learning mechanism adds it to the table.

In parallel with the learning process, the forwarding mechanism searches the service's MAC forwarding table for the frame's MAC address. If a match is found, the frame is forwarded to the service point associated with the MAC address. If not, the frame is flooded to all service points in the service.

Setting the Maximum Size of the MAC Address Forwarding Table (CLI)

To limit the size of the MAC address forwarding table for a specific service, go to service view for the service and enter the following command:

```
service[SID]>service mac-limit-value set <mac limit>
```

Table 197 MAC Address Forwarding Table Maximum Size CLI Parameters

Parameter	Input Type	Permitted Values	Description
mac limit	Number	16 to 131,072, in multiples of 16	The maximum MAC address table size for the service. This maximum only applies to dynamic, not static, MAC address table entries.

The following command limits the number of dynamic MAC address forwarding table entries for Service 10 to 128:

```
service[10]>service mac-limit-value set 128
```

Setting the MAC Address Forwarding Table Aging Time (CLI)

You can configure a global aging time for dynamic entries in the MAC address forwarding table. Once this aging time expires for a specific table entry, the entry is erased from the table.

To set the global aging time for the MAC address forwarding table, enter the following command:

```
root> ethernet service learning-ageing-time set time <time>
```

Table 198 MAC Address Forwarding Table Aging Time CLI Parameters

Parameter	Input Type	Permitted Values	Description
time	Number	15 - 3825	The global aging time for the MAC address forwarding table, in seconds.

The following command sets the global aging time to 2500 seconds:

```
root> ethernet service learning-ageing-time set time 2500
```

To display the global aging time for the MAC address forwarding table, enter the following command:

```
root> ethernet service learning-ageing-time show
```

Adding a Static MAC Address to the Forwarding Table (CLI)

You can add static entries to the MAC forwarding table. The global aging timer does not apply to static entries, and they are not counted with respect to the maximum size of the MAC address forwarding table. It is the responsibility of the user not to use all the entries in the table if the user also wants to utilize dynamic MAC address learning.

To add a static MAC address to the MAC address forwarding table, go to service view for the service to which you want to add the MAC address and enter the following command:

```
service[SID]>service mac-learning-table set-static-  
mac <static mac> spid <sp-id>
```

To delete a static MAC address from the MAC address forwarding table, go to service view for the service from which you want to delete the MAC address and enter the following command:

```
service[SID]>service mac-learning-table del-static-  
mac <static mac> spid <sp-id>
```

Table 199 Adding Static Address to MAC Address Forwarding Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
static mac	Six groups of two hexadecimal digits		The MAC address.
sp-id	Number	1-32	The Service Point ID of the service point associated with the MAC address.

The following command adds MAC address 00:11:22:33:44:55 to the MAC address forwarding table for Service 10, and associates the MAC address with Service Point ID 1 on Service 10:

```
service[10]>service mac-learning-table set-static-  
mac 00:11:22:33:44:55 spid 1
```

The following command deletes MAC address 00:11:22:33:44:55, associated with Service Point 1, from the MAC address forwarding table for Service 10:

```
service[10]>service mac-learning-table del-static-  
mac 00:11:22:33:44:55 spid 1
```

Displaying the MAC Address Forwarding Table (CLI)

You can display the MAC address forwarding table for an interface, a service, or for the entire unit.

To display the MAC address forwarding table for a service, go to service view for the service and enter the following command:

```
service[SID]>service mac-learning-table show
```

To display the MAC address forwarding table for an interface, go to interface view for the interface and enter the following command:

```
eth type xxx[x/x]>mac-learning-table show
```

To display the MAC address forwarding table for the entire unit, enter the following command:

```
root> ethernet generalcfg mac-learning-table show
```

For example, to display the MAC address forwarding table for GbE 1, enter the following commands:

```
root> ethernet interfaces eth slot 1 port 1  
eth type eth[1/1]>mac-learning-table show
```

Flushing the MAC Address Forwarding Table (CLI)

You can perform a global flush on the MAC address forwarding table. This erases all dynamic entries for all services. Static entries are not erased.



Note

The ability to flush the MAC address forwarding table per-service and per-interface is planned for future release.

To perform a global flush of the MAC address forwarding table, enter the following command:

```
root> ethernet service mac-learning-table set global-flush
```

Enabling MAC Address Learning on a Service Point (CLI)

You can enable or disable MAC address learning for specific service points. By default, MAC learning is enabled.

To enable or disable MAC address learning for a service point, go to service view for the service and enter the following command:

```
service[SID]>sp learning-state set spid <sp-id> learning <learning>
```

Table 200 Enabling MAC Address Learning CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service point ID.
learning	Variable	enable disable	Select enable or disable to enable or disable MAC address learning for frames that ingress via the service point. When enabled, the service point learns the source MAC addresses of incoming frames and adds them to the MAC address forwarding table.

The following command enables MAC address learning for Service Point 1 on Service 37:

```
service[37]>sp learning-state set spid 1 learning enable
```

The following command disables MAC address learning for Service Point 1 on Service 37:

```
service[37]>sp learning-state set spid 1 learning disable
```

Setting the MRU Size and the S-VLAN Ethertype (CLI)

The following parameters are configured globally for the PTP 820G switch:

- **S-VLAN Ethertype** – Defines the ethertype recognized by the system as the S-VLAN ethertype.
- **C-VLAN Ethertype** – Defines the ethertype recognized by the system as the C-VLAN ethertype. PTP 820G and PTP 820F supports 0x8100 as the C-VLAN ethertype.
- **MRU** – The maximum segment size defines the maximum receive unit (MRU) capability and the maximum transmit capability (MTU) of the system. You can configure a global MRU for the system.



Note

The MTU is determined by the receiving frame and editing operation on the frame.

This section includes:

- [Configuring the S-VLAN Ethertype \(CLI\)](#)
- [Configuring the C-VLAN Ethertype \(CLI\)](#)
- [Configuring the MRU \(CLI\)](#)

Configuring the S-VLAN Ethertype (CLI)

To configure the S-VLAN Ethertype, enter the following command in root view:

```
root> ethernet generalcfg ethertype set svlan-value <ethertype>
```

To display the system S-VLAN ethertype, enter the following command in root view:

```
root> ethernet generalcfg ethertype show svlan
```

Table 201 Configure S-VLAN Ethertype CLI Parameters

Parameter	Input Type	Permitted Values	Description
ethertype	Hexadecimal	0x8100 0x88a8 0x9100 0x9200	Defines the ethertype recognized by the system as the S-VLAN ethertype.

For example, the following command sets the system S-VLAN ethertype to 0x88a8:

```
root> ethernet generalcfg ethertype set svlan-value 0x88a8
```

Configuring the C-VLAN Ethertype (CLI)

The system C-VLAN Ethertype is set by the system as 0x8100.

To display the system C-VLAN ethertype, enter the following command in root view:

```
root> ethernet generalcfg ethertype show cvlan
```

Configuring the MRU (CLI)

To define the global size (in bytes) of the Maximum Receive Unit (MRU), enter the following command in root view:

```
root> ethernet generalcfg mru set size <size>
```

To display the system MRU, enter the following command in root view:

```
root> ethernet generalcfg mru show
```

Table 202 Configure MRU CLI Parameters

Parameter	Input Type	Permitted Values	Description
size	Number	64 to 9612	Defines the global size (in bytes) of the Maximum Receive Unit (MRU). Frames that are larger than the global MRU will be discarded.

For example, the following command sets the system MRU to 9612:

```
root> ethernet generalcfg mru set size 9612
```

Configuring Ethernet Interfaces (CLI)

PTP 820G and PTP 820F's switching fabric distinguishes between physical interfaces and logical interfaces. Physical and logical interfaces serve different purposes in the switching fabric. In some cases, a physical interface corresponds to a logical interface on a one-to-one basis. For some features, such as 1+1 protection, a group of physical interfaces can be joined into a single logical interface.

The basic interface characteristics, such as media type, port speed, duplex, and auto-negotiation, are configured on the physical interface level. Ethernet services, QoS, VLAN Ethertype, and OAM characteristics are configured on the logical interface level.

This section includes:

- [Entering Interface View \(CLI\)](#)
- [Displaying the Operational State of the Interfaces in the Unit \(CLI\)](#)
- [Viewing Interface Attributes \(CLI\)](#)
- [Configuring an Interface's Media Type \(CLI\)](#)
- [Configuring an Interface's Speed and Duplex State \(CLI\)](#)
- [Configuring an Interface's Auto Negotiation State \(CLI\)](#)
- [Configuring an Interface's IFG \(CLI\)](#)
- [Configuring an Interface's Preamble \(CLI\)](#)
- [Adding a Description for the Interface \(CLI\)](#)

Related Topics:

- [Enabling the Interfaces \(Interface Manager\) \(CLI\)](#)
- [Performing Ethernet Loopback \(CLI\)](#)
- [Configuring Ethernet Services \(CLI\)](#)
- [Quality of Service \(QoS\) \(CLI\)](#)

Entering Interface View (CLI)

To view interface details and set the interface's parameters, you must enter the interface's view level in the CLI.

Use the following command to enter an Ethernet interface's view level:

```
root> ethernet interfaces eth slot <slot> port <port>
```

Use the following command to enter the radio interface's view level:

```
root> ethernet interfaces radio slot <slot> port <port>
```

Use the following command to enter the view level of a group, such as a Multi-Carrier ABC group, an HSB protection group, or a LAG:

```
root> ethernet interfaces group <group>
```

Table 203 Entering Interface View CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 tdm: 1	The port number of the interface.

For example, the following command enters interface view for Ethernet port 3:

```
root> ethernet interfaces eth slot 1 port 3
```

The following prompt appears:

```
eth type eth [1/3]>
```

The exact prompt depends on the type of interface. For example:

- **Radio interface:** `eth type radio [x/x]>`
- **Group interface** (e.g., 1+1 HSB-SD group): `eth type group [x/x]>`
- **TDM interface:** `eth type pwe [x/x]>`

For simplicity, the examples in the following sections show the prompt for an Ethernet interface.

Displaying the Operational State of the Interfaces in the Unit (CLI)

To display a list of all interfaces in the unit and their operational states, enter the following command:

```
root> platform if-manager show interfaces
```

The following is a sample output of this command:

```
root> platform if-manager show interfaces
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| Interface | slot | port | Type | Description | Admin | Operational | Secondary | Last change | Connector | Speed | MTU | MAC |
| type     |      |      |      |              | status | status       | operational-status |              | Present   |        |     | address |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| ethernet | 1   | 1   | 6   | Ethernet    | down  | down         | RX LOS/LOC | 01-01-1970,00:00:01 | false    | 1000000000 | 2000 | 0:a:25:40:1f:93 |
|          |     |     |     |              |       |              | Interface not ready |              |          |            |     |          |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| ethernet | 1   | 2   | 6   | Cascading   | down  | down         | RX LOS/LOC | 01-01-1970,00:00:01 | false    | 1000000000 | 2000 | 0:a:25:40:1f:94 |
|          |     |     |     |              |       |              | Interface not ready |              |          |            |     |          |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| ethernet | 1   | 5   | 6   | Ethernet    | down  | down         | RX LOS/LOC | 01-01-1970,00:00:01 | false    | 1000000000 | 2000 | 0:a:25:40:1f:95 |
|          |     |     |     |              |       |              | Interface not ready |              |          |            |     |          |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| ethernet | 1   | 6   | 6   | Ethernet    | down  | down         | RX LOS/LOC | 01-01-1970,00:00:01 | false    | 1000000000 | 2000 | 0:a:25:40:1f:96 |
|          |     |     |     |              |       |              | Interface not ready |              |          |            |     |          |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| radio    | 1   | 1   | 1   | Radio       | up    | down         | Rx LOP/LOP | 01-01-1970,00:00:01 | false    | 39978000   | 2000 | 0:a:25:40:1f:8f |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| radio    | 1   | 2   | 1   | Radio       | up    | down         | Rx LOP/LOP | 01-01-1970,00:00:01 | false    | 39978000   | 2000 | 0:a:25:40:1f:90 |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| management | 1 | 1 | 6 | Management | up    | up           | C'lear     | 12-04-2015,09:21:22 | false    | 1000000000 | 1632 | 0:0:0:0:0:0 |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| management | 1 | 2 | 6 | Management | down  | down         | RX LOS/LOC | 01-01-1970,00:00:01 | false    | 1000000000 | 1632 | 0:0:0:0:0:0 |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| synch    | 1   | 1   | 1   | Synchronization | down | down         | RX LOS/LOC | 01-01-1970,00:00:01 | false    | 2048000    | 0    | 0:0:0:0:0:0 |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| tdm      | 1   | 1   | 1   | pw-eth-port | up    | up           | C'lear     | 12-04-2015,09:22:30 | false    | 1000000000 | 2000 | 0:a:25:40:1f:a3 |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| group    | 68  | 1   | 1   | HSB 1+1     | up    | down         | C'lear     | 01-01-1970,00:00:01 | true     | 39978000   | 2000 | 0:a:25:40:1f:8f |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
| group    | 68  | 2   | 1   | HSB 1+1     | up    | down         | C'lear     | 01-01-1970,00:00:01 | true     | 40978000   | 2000 | 0:a:25:40:1f:91 |
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
root>
```

Viewing Interface Attributes (CLI)

To display an interface's attributes, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>summary show
```

To display an interface's current operational state (up or down), go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>operational state show
```

The following command shows the operational state of GbE 1:

```
eth type eth [1/1]>operational state show
```

Configuring an Interface's Media Type (CLI)

The Media Type attribute defines the physical interface Layer 1 media type. Permitted values are RJ-45 and SFP. Auto Type is only relevant for Ethernet interfaces. When Auto Type is selected, the system detects whether the optical or electrical port is being used. Auto Type can only be used when the interface speed is set to 1000 Mbps. To configure an Ethernet interface's Media Type, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>media-type state set <media type>
```

Table 204 Interface Media Type CLI Parameters

Parameter	Input Type	Permitted Values	Description
media type	Variable	auto-type rj45 sfp	Select the physical interface layer 1 media type: auto-type – Only relevant for Ethernet interfaces. The system detects whether the optical or electrical port is being used. Auto-type can only be used when the interface speed is set to 1000 Mbps. RJ45 – An electrical (RJ-45) Ethernet interface. SFP – An optical (SFP) Ethernet interface.

The following command sets Ethernet port 1 to auto-type:

```
eth type eth [1/1]>media-type state set auto-type
```

Configuring an Interface's Speed and Duplex State (CLI)

To configure an Ethernet interface's maximum speed and duplex state, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>speed-and-duplex state set <speed-and-duplex state>
```

Table 205 Interface Speed and Duplex State CLI Parameters

Parameter	Input Type	Permitted Values	Description
speed-and-duplex state	Variable	'10hd' '10fd' '100hd' '100fd' '1000fd'	This parameter sets the maximum speed and the duplex state of the interface. For RJ-45 interfaces, any of the permitted values can be configured. For SFP interfaces, only '1000fd' is supported.

**Note**

10HD is not supported in the current release.

The following command sets GbE 1 to 100 Mbps, full duplex:

```
eth type eth [1/1]>speed-and-duplex state set '100fd'
```

**Note**

Before performing this command, you must verify that the media-type attribute is set to rj45.

The following command sets GbE 1 to 1000 Mbps, full duplex:

```
eth type eth [1/1]>speed-and-duplex state set '1000fd'
```

Configuring an Interface's Auto Negotiation State (CLI)

To configure an Ethernet interface's auto-negotiation state, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>autoneg state set <autoneg state>
```

Table 206 Interface Auto Negotiation State CLI Parameters

Parameter	Input Type	Permitted Values	Description
autoneg state	Variable	On off	Enables or disables auto-negotiation on the physical interface.

The following command enables auto negotiation for Ethernet port 4:

```
eth type eth [1/4]>autoneg state set on
```

Configuring an Interface's IFG (CLI)

The IFG attribute represents the physical port Inter-frame gap. Although you can modify the IFG field length, it is strongly recommended not to modify the default value of 12 bytes without a thorough understanding of how the modification will impact traffic.

To configure an Ethernet interface's IFG, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>ifg set <ifg>
```

Table 207 Interface IFG CLI Parameters

Parameter	Input Type	Permitted Values	Description
ifg	Number	6 - 15	Sets the interface's IFG (in bytes).

The following command sets the ifg for Ethernet port 3 to 12:

```
eth type eth [1/3]>ifg set 12
```

The following displays the currently configured ifg for Ethernet port 1:

```
eth type eth [1/1]>ifg get
```

Configuring an Interface's Preamble (CLI)

Although you can modify an Ethernet interface's preamble, it is strongly recommended not to modify the default value of 8 bytes without a thorough understanding of how the modification will impact traffic.

To configure an Ethernet interface's preamble, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>preamble set <preamble>
```

Table 208 Interface Preamble CLI Parameters

Parameter	Input Type	Permitted Values	Description
preamble	Number	6 - 15	Sets the interface's preamble (in bytes).

The following command sets the preamble for Ethernet port 6 to 8:

```
eth type eth [1/6]>preamble set 8
```

The following command displays the current preamble for Ethernet port 5:

```
eth type eth [1/5]>preamble get
```

Adding a Description for the Interface (CLI)

You can add a text description for an interface. To add a description, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>description set <description>
```

To delete a description, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>description delete
```

To display an interface's description, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>description show
```

Table 209 Interface Description CLI Parameters

Parameter	Input Type	Permitted Values	Description
description	Text String	Up to 40 characters	Adds a text description to the interface.

The following command adds the description "Line" to Ethernet port 2:

```
eth type eth [1/2]>description set Line
```

Configuring Automatic State Propagation and Link Loss Forwarding (CLI)

Automatic state propagation enables propagation of radio failures back to the Ethernet port. You can also configure Automatic State Propagation to close the Ethernet port based on a radio failure at the remote carrier.

Automatic state propagation is configured as pairs of interfaces. Each interface pair includes a Monitored Interface and a Controlled Interface. The Monitored Interface is a radio or TDM interface, or a radio protection or Multi-Carrier ABC group. The Controlled Interface is an Ethernet interface LAG. Only one ASP pair can be configured per radio or TDM interface or radio protection or Multi-Carrier ABC group, and only one ASP pair can be configured per Ethernet interface.



Note

It is recommended to configure both ends of the link to the same Automatic State Propagation configuration.

Configuring Automatic State Propagation to an Ethernet Port (CLI)

To configure propagation of a radio interface failure to an Ethernet port, use the following commands:

```
root> auto-state-propagation add eth-port-to-radio eth-slot <eth-slot>  
eth-port <eth-port> radio-slot <radio-slot> radio-port <radio-port>
```

To enable automatic state propagation on an Ethernet port and determine whether remote interface failures are also propagated, use the following command:

```
root> auto-state-propagation configure eth-port eth-slot <eth-slot> eth-  
port <eth-port> asp-admin <asp-admin> remote-fault-trigger-admin <remote-  
fault-trigger-admin> csf-mode-admin <csf-mode-admin>
```

To delete automatic state propagation on an Ethernet port, use the following command:

```
root> auto-state-propagation delete eth-port eth-slot <eth-slot> eth-port  
<eth-port>
```

To display all automatic state propagation configurations on the unit, use the following command:

```
root> auto-state-propagation show-config all
```

To display the automatic state propagation configuration for a specific Ethernet port, use the following command:

```
root> auto-state-propagation show-config eth-port eth-slot <eth-slot>  
eth-port <eth-port>
```

Table 210 Automatic State Propagation to an Ethernet Port CLI Parameters

Parameter	Input Type	Permitted Values	Description
eth-slot	Number	1	
eth-port	Number	1-6	The interface to which you want to propagate faults from the selected radio or group.
radio-slot	Number	1	
radio-port	Number	1-2	The radio interface.
multi-radio-group	Number	1-4	The Multi-Carrier ABC group failure of which is propagated to the defined interface.
protection-group	Number	1-4	The HSB protection group failure of which is propagated to the defined interface.
asp-admin	Variable	enable disable	Enables or disables automatic state propagation on the Ethernet interface.
remote-fault-trigger-admin	Variable	enable disable	Determines whether faults on the remote radio interface or group are propagated to the local Ethernet interface.
csf-mode-admin	Variable	enable disable	Enables or disables Client Signal Failure (CSF) mode. In CSF mode, the ASP mechanism does not physically shut down the Controlled Interface when ASP is triggered. Instead, the ASP mechanism sends a failure indication message (a CSF message). The CSF message is used to propagate the failure indication to external equipment.

The following commands configure and enable automatic state propagation to propagate faults from radio interface 2 to Ethernet port 1. Faults on the remote carrier are also propagated to Ethernet port 1. CSF mode is disabled.

```
root> auto-state-propagation add eth-port-to-radio eth-slot 1 eth-port 1
radio-slot 1 radio-port 2
root> auto-state-propagation configure eth-port eth-slot 1 eth-port 1
asp-admin enable remote-fault-trigger-admin enable csf-mode-admin disable
```

The following commands configure and enable automatic state propagation to propagate faults from Multi-Carrier ABC group 1 to Ethernet port 1. Faults on the remote carrier are also propagated to Ethernet port 1. CSF mode is disabled.

```
root> auto-state-propagation add eth-port-to-multi-radio-group eth-slot 1  
eth-port 1 multi-radio-group 1  
root> auto-state-propagation configure eth-port eth-slot 1 eth-port 1  
asp-admin enable remote-fault-trigger-admin enable csf-mode-admin disable
```

The following commands configure and enable automatic state propagation to propagate faults from 1+1 HSB protection group 1 to Ethernet port 2. Faults on the remote carrier are not propagated to Ethernet port 2. CSF mode is disabled.

```
root> auto-state-propagation add eth-port-to-protection-group eth-slot 1  
eth-port 2 protection-group 1  
root> auto-state-propagation configure eth-port eth-slot 1 eth-port 2  
asp-admin enable remote-fault-trigger-admin disable csf-mode-admin  
disable
```

The following commands configure and enable automatic state propagation to propagate faults from radio interface 2 to LAG group 1. Faults on the remote carrier are also propagated to LAG group 1. CSF mode is disabled.

```
root> auto-state-propagation add lag-to-radio lag-id 1 radio-slot 1  
radio-port 2  
root> auto-state-propagation configure lag lag-id 1 asp-admin enable  
remote-fault-trigger-admin enable csf-mode-admin disable
```

Viewing Ethernet PMs and Statistics (CLI)

PTP 820G and PTP 820F stores and displays statistics in accordance with RMON and RMON2 standards. You can display various peak TX and RX rates (per second) and average TX and RX rates (per second), both in bytes and in packets, for each measured time interval. You can also display the number of seconds in the interval during which TX and RX rates exceeded the configured threshold.

This section includes:

- [Displaying RMON Statistics \(CLI\)](#)
- [Configuring Ethernet Port PMs and PM Thresholds \(CLI\)](#)
- [Displaying Ethernet Port PMs \(CLI\)](#)
- [Clearing Ethernet Port PMs \(CLI\)](#)

Displaying RMON Statistics (CLI)

To display RMON statistics for a physical interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rmon statistics show clear-on-read <clear-on-read>
layer-1 <layer-1>
```

Table 211 RMON Statistics CLI Parameters

Parameter	Input Type	Permitted Values	Description
clear-on-read	Boolean	Yes no	If you enter yes, the statistics are cleared once you display them.
layer-1	Boolean	Yes no	yes – Statistics are represented as Layer 1 statistics, including preamble and IFG. no – Statistics are represented as Layer 2 statistics.

The following commands bring you to interface view for Ethernet port 1, and clears the statistics after displaying them.

```
root> ethernet interfaces eth slot 1 port 1
eth type eth [1/1]>rmon statistics show clear-on-read yes layer-1 yes
```

The following commands bring you to interface view for radio interface 2, without clearing the statistics.

```
root> ethernet interfaces radio slot 2 port 1
eth type radio[2/2]>rmon statistics show clear-on-read no layer-1 no
```

Configuring Ethernet Port PMs and PM Thresholds (CLI)

To enable the gathering of PMs for an Ethernet interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm set admin <enable|disable>
```

You can configure thresholds and display the number of seconds these thresholds were exceeded during a specified interval.

To configure interface PM thresholds, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm set thresholds rx-layer1-rate-threshold <0-4294967295> tx-layer1-rate-threshold <0-4294967295>
```

To display whether or not PM gathering is enabled for an Ethernet interface, as well as the configured thresholds, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show configuration
```

Table 212 Port PM Thresholds CLI Parameters

Parameter	Input Type	Permitted Values	Description
rx-layer1-rate-threshold	Number	0-4294967295	The exceed threshold for port RX PMs, in bytes per second.
tx-layer1-rate-threshold	Number	0-4294967295	The exceed threshold for port TX PMs, in bytes per second.

The following commands bring you to interface view for Ethernet port 1, enable PM gathering, and set the thresholds for RX and TX PMs at 1,000,000,000 bytes per second:

```
root> ethernet interfaces eth slot 1 port 1
eth type eth [1/1]>pm set admin enable
eth type eth [1/1]>pm set thresholds rx-layer1-rate-threshold 1000000000
tx-layer1-rate-threshold 1000000000
```

Displaying Ethernet Port PMs (CLI)

To display RX packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-packets interval 15min
```

To display RX packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-packets interval 24hr
```

To display RX broadcast packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bcast-packets interval 15min
```

To display RX broadcast packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bcast-packets interval 24hr
```

To display RX multicast packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-mcast-packets interval 15min
```

To display RX multicast packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-mcast-packets interval 24hr
```

To display Layer 1 RX PMs, in bytes per second, in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bytes-layer1 interval 15min
```

To display Layer 1 RX PMs, in bytes per second, in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bytes-layer1 interval 24hr
```

To display Layer 2 RX PMs, in bytes per second, in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bytes-layer2 interval 15min
```

To display Layer 2 RX PMs, in bytes per second, in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show rx-bytes-layer2 interval 24hr
```

To display TX packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-packets interval 15min
```

To display TX packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-packets interval 24hr
```

To display TX broadcast packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bcast-packets interval 15min
```

To display TX broadcast packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bcast-packets interval 24hr
```

To display TX multicast packet PMs in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-mcast-packets interval 15min
```

To display TX multicast packet PMs in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-mcast-packets interval 24hr
```

To display Layer 1 TX PMs, in bytes per second, in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bytes-layer1 interval 15min
```

To display Layer 1 TX PMs, in bytes per second, in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bytes-layer1 interval 24hr
```

To display Layer 2 TX PMs, in bytes per second, in 15-minute intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bytes-layer2 interval 15min
```

To display Layer 2 TX PMs, in bytes per second, in 24-hour intervals, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm show tx-bytes-layer2 interval 24hr
```

Table 213 Ethernet Port PMs

Parameter	Definition
Interval	For 24-hour intervals, displays the date of the interval. For 15-minute intervals, displays the date and ending time of the interval.
Invalid data flag	Indicates whether the values received during the measured interval are valid. An x in the column indicates that the values are not valid (for example, because of a power surge or power failure that occurred during the interval).
Peak RX Packets	The peak rate of RX packets per second for the measured time interval.
Average RX Packets	The average rate of RX packets per second for the measured time interval.
Peak RX Broadcast Packets	The peak rate of RX broadcast packets per second for the measured time interval.
Average RX Broadcast Packets	The average rate of RX broadcast packets per second for the measured time interval.
Peak RX Multicast Packets	The peak rate of RX multicast packets per second for the measured time interval.
Average RX Multicast Packets	The average rate of RX multicast packets per second for the measured time interval.
Peak RX Bytes in Layer1	The peak RX rate, in bytes per second, for the measured time interval (including preamble and IFG).
Average RX Bytes in Layer1	The average RX rate, in bytes per second, for the measured time interval (including preamble and IFG).

Parameter	Definition
RX Bytes Layer1 Exceed Threshold (sec)	The number of seconds during the measured time interval that the RX rate exceeded the configured threshold.
Peak RX Bytes in Layer2	The peak RX rate, in bytes per second, for the measured time interval (excluding preamble and IFG).
Average RX Bytes in Layer2	The average RX rate, in bytes per second, for the measured time interval (excluding preamble and IFG).
Peak TX Packets	The peak rate of TX packets per second for the measured time interval.
Average TX Packets	The average rate of TX packets per second for the measured time interval.
Peak TX Broadcast Packets	The peak rate of TX broadcast packets per second for the measured time interval.
Average TX Broadcast Packets	The average rate of TX broadcast packets per second for the measured time interval.
Peak TX Multicast Packets	The peak rate of TX multicast packets per second for the measured time interval.
Average TX Multicast Packets	The average rate of TX multicast packets per second for the measured time interval.
Peak TX Bytes in Layer1	The peak TX rate, in bytes per second, for the measured time interval (including preamble and IFG).
Average TX Bytes in Layer1	The average TX rate, in bytes per second, for the measured time interval (including preamble and IFG).
TX Bytes Layer1 Exceed Threshold (sec)	The number of seconds during the measured time interval that the TX rate exceeded the configured threshold.
Peak TX Bytes in Layer2	The peak TX rate, in bytes per second, for the measured time interval (excluding preamble and IFG).
Average TX Bytes in Layer2	The average TX rate, in bytes per second, for the measured time interval (excluding preamble and IFG).

Clearing Ethernet Port PMs (CLI)

To clear all PMs for an Ethernet interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> pm clear-all
```

Chapter 19: Quality of Service (QoS) (CLI)

This section includes:

- [Configuring Classification \(CLI\)](#)
- [Configuring Policers \(Rate Metering\) \(CLI\)](#)
- [Configuring Marking \(CLI\)](#)
- [Configuring WRED \(CLI\)](#)
- [Configuring Shapers \(CLI\)](#)
- [Configuring Scheduling \(CLI\)](#)
- [Displaying Egress Statistics \(CLI\)](#)

Configuring Classification (CLI)

This section includes:

- [Classification Overview \(CLI\)](#)
- [Configuring Ingress Path Classification on a Logical Interface \(CLI\)](#)
- [Configuring VLAN Classification and Override \(CLI\)](#)
- [Configuring 802.1p Classification \(CLI\)](#)
- [Configuring DSCP Classification \(CLI\)](#)
- [Configuring MPLS Classification \(CLI\)](#)
- [Configuring a Default CoS \(CLI\)](#)
- [Configuring Ingress Path Classification on a Service Point \(CLI\)](#)
- [Configuring Ingress Path Classification on a Service \(CLI\)](#)

Classification Overview (CLI)

PTP 820G and PTP 820F supports a hierarchical classification mechanism. The classification mechanism examines incoming frames and determines their CoS and Color. The benefit of hierarchical classification is that it provides the ability to “zoom in” or “zoom out”, enabling classification at higher or lower levels of the hierarchy. The nature of each traffic stream defines which level of the hierarchical classifier to apply, or whether to use several levels of the classification hierarchy in parallel.

The hierarchical classifier consists of the following levels:

- Logical interface-level classification
- Service point-level classification
- Service level classification

Configuring Ingress Path Classification on a Logical Interface (CLI)

Logical interface-level classification enables you to configure classification on a single interface or on a number of interfaces grouped together, such as a LAG group.

The classifier at the logical interface level supports the following classification methods, listed from highest to lowest priority. A higher level classification method supersedes a lower level classification method:

- VLAN ID
- 802.1p bits.
- DSCP values.
- MPLS EXP field.
- Default CoS

PTP 820G and PTP 820F performs the classification on each frame ingressing the system via the logical interface. Classification is performed step by step from the highest priority to the lowest priority classification method. Once a match is found, the classifier determines the CoS and Color decision for the frame for the logical interface-level. For example, if the frame is an untagged IP Ethernet frame, a match will not be found until the third priority level (DSCP). The CoS and Color values defined for the frame's DSCP value will be applied to the frame. You can disable some of these classification methods by configuring them as un-trusted. For example, if 802.1p classification is configured as un-trusted for a specific interface, the classification mechanism does not perform classification by UP bits. This is useful, for example, if classification is based on DSCP priority bits. If no match is found at the logical interface level, the default CoS is applied to incoming frames at this level. In this case, the Color of the frame is assumed to be Green.

Configuring VLAN Classification and Override (CLI)

You can specify a specific CoS and Color for a specific VLAN ID. In the case of double-tagged frames, the match must be with the frame's outer VLAN. Permitted values are CoS 0 to 7 and Color Green or Yellow per VLAN ID. This is the highest classification priority on the logical interface level, and overrides any other classification criteria at the logical interface level.

To configure CoS and Color override based on VLAN ID, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>vlan-cos-override set outer-vlan-id <outer-vlan-id>
inner-vlan-id <inner-vlan-id> use-cos <use-cos> use-color <use-color>
```

To display configured VLAN-based CoS and Color override values, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>vlan-cos-override show outer-vlan-id <outer-vlan-id>
inner-vlan-id <inner-vlan-id>
```

To delete a set of VLAN-based CoS and Color override values, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>vlan-cos-override delete outer-vlan-id <outer-vlan-id>
inner-vlan-id <inner-vlan-id>
```

Table 214 VLAN Classification and Override CLI Parameters

Parameter	Input Type	Permitted Values	Description
outer-vlan-id	Number	1 – 4094	For double-tagged frames, the S-VLAN value mapped to the CoS and Color values defined in the command. For single-tagged frames, the VLAN value mapped to the CoS and Color values defined in the command.

Parameter	Input Type	Permitted Values	Description
inner-vlan-id	Number	1 – 4094	Optional. Include this parameter when you want to map double-tagged frames to specific CoS and Color values. When this parameter is included in the command, both the S-VLAN and the C-VLAN IDs must match the configured <code>outer-vlan-id</code> and <code>inner-vlan-id</code> values, respectively, in order for the defined CoS and Color values to be applied to the frame.
use-cos	Number	0 – 7	The CoS value applied to matching frames.
use-color	Variable	green yellow	The Color applied to matching frames.

The following command configures the classification mechanism on GbE 1 to override the CoS and Color values of frames with S-VLAN ID 10 and C-VLAN ID 30 with a CoS value of 6 and a Color value of Green:

```
eth type eth [1/1]>vlan-cos-override set outer-vlan-id 10 inner-vlan-id 30 use-cos 6 use-color green
```

The following command configures the classification mechanism on GbE 2 to override the CoS and Color values of frames with VLAN ID 20 with a CoS value of 5 and a Color value of Green:

```
eth type eth [1/2]>vlan-cos-override set outer-vlan-id 20 use-cos 5 use-color green
```

The following command displays the CoS and Color override values for frames that ingress on GbE 1, with S-VLAN ID 10 and C-VLAN ID 20:

```
eth type eth [1/1]>vlan-cos-override show outer-vlan-id 10 inner-vlan-id 20
```

The following command displays all CoS and Color override values for frames that ingress on GbE 2:

```
eth type eth [1/2]>vlan-cos-override show all
```

The following command deletes the VLAN to CoS and Color override mapping for frames that ingress on GbE 1, with S-VLAN ID 10 and C-VLAN ID 20:

```
eth type eth [1/1]>vlan-cos-override delete outer-vlan-id 10 inner-vlan-id 20
```

Configuring 802.1p Classification (CLI)

When 802.1p classification is set to Trust mode, the interface performs QoS and Color classification according to user-configurable tables for 802.1q UP bit (C-VLAN frames) or 802.1AD UP bit (S-VLAN frames) to CoS and Color classification.

This section includes:

- [Configuring Trust Mode for 802.1p Classification \(CLI\)](#)

- [Modifying the C-VLAN 802.1 UP and CFI Bit Classification Table \(CLI\)](#)
- [Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table \(CLI\)](#)

Configuring Trust Mode for 802.1p Classification (CLI)

To define the trust mode for 802.1p classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification set 802.1p <802.1p>
```

To display the trust mode for 802.1p classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification show 802.1p state
```

Table 215 802.1p Trust Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
802.1p	Variable	trust un-trust	Enter the interface's trust mode for user priority (UP) bits: trust – The interface performs QoS and color classification according to UP and CFI/DEI bits according to user-configurable tables for 802.1q UP bits (C-VLAN frames) or 802.1AD UP bits (S-VLAN frames). VLAN UP bit classification has priority over DSCP and MPLS classification, so that if a match is found with the UP bit of the ingressing frame, DSCP values and MPLS bits are not considered. un-trust – The interface does not consider 802.1 UP bits during classification.

The following command enables 802.1p trust mode for GbE 1:

```
eth type eth [1/1]>classification set 802.1p trust
```

The following command disables 802.1p trust mode for GbE 1:

```
eth type eth [1/1]>classification set 802.1p un-trust
```

Modifying the C-VLAN 802.1 UP and CFI Bit Classification Table (CLI)

The following table shows the default values for the C-VLAN 802.1 UP and CFI bit classification table.

Table 216 C-VLAN 802.1 UP and CFI Bit Classification Table Default Values

802.1 UP	CFI	CoS (configurable)	Color (configurable)
0	0	0	Green

802.1 UP	CFI	CoS (configurable)	Color (configurable)
0	1	0	Yellow
1	0	1	Green
1	1	1	Yellow
2	0	2	Green
2	1	2	Yellow
3	0	3	Green
3	1	3	Yellow
4	0	4	Green
4	1	4	Yellow
5	0	5	Green
5	1	5	Yellow
6	0	6	Green
6	1	6	Yellow
7	0	7	Green
7	1	7	Yellow

To modify the C-VLAN 802.1 UP and CFI bit classification table, enter the following command:

```
root> ethernet qos 802.1q-up-bits-mapping-tbl set 802.1p <802.1p> cfi
<cfi> cos <cos> color <color>
```

To display the C-VLAN 802.1 UP and CFI bit classification table, enter the following command:

```
root> ethernet qos 802.1q-up-bits-mapping-tbl show
```

Table 217 C-VLAN 802.1 UP and CFI Bit Classification Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
802.1p	Number	0 – 7	The User Priority (UP) bit to be mapped.
cfi	Number	0 – 1	The CFI bit to be mapped.
cos	Number	0 – 7	The CoS assigned to frames with the designated UP and CFI.
color	Variable	green yellow	The Color assigned to frames with the designated UP and CFI.

The following command maps frames with an 802.1p UP bit value of 1 and a CFI bit value of 0 to CoS 1 and Green color:

```
root> ethernet qos 802.1q-up-bits-mapping-tbl set 802.1p 1 cfi 0 cos 1
color green
```

Modifying the S-VLAN 802.1 UP and DEI Bit Classification Table (CLI)

The following table shows the default values for the S-VLAN 802.1 UP and DEI bit classification table.

Table 218 S-VLAN 802.1 UP and DEI Bit Classification Table Default Values

802.1 UP	CFI	CoS (configurable)	Color (configurable)
0	0	0	Green
0	1	0	Yellow
1	0	1	Green
1	1	1	Yellow
2	0	2	Green
2	1	2	Yellow
3	0	3	Green
3	1	3	Yellow
4	0	4	Green
4	1	4	Yellow
5	0	5	Green
5	1	5	Yellow
6	0	6	Green
6	1	6	Yellow
7	0	7	Green
7	1	7	Yellow

To modify the S-VLAN 802.1 UP and DEI bit classification table, enter the following command:

```
root> ethernet qos 802.1ad-up-bits-mapping-tbl set 802.1p <802.1p> dei
<dei> cos <cos> color <color>
```

To display the S-VLAN 802.1 UP and CFI bit classification table, enter the following command:

```
root> ethernet qos 802.1ad-up-bits-mapping-tbl show
```

Table 219 S-VLAN 802.1 UP and DEI Bit Classification Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
802.1p	Number	0 – 7	The User Priority (UP) bit to be mapped.
dei	Number	0 - 1	The DEI bit to be mapped.

Parameter	Input Type	Permitted Values	Description
cos	Number	0 – 7	The CoS assigned to frames with the designated UP and CFI.
color	Variable	green yellow	The Color assigned to frames with the designated UP and CFI.

The following command maps frames with an 802.1ad UP bit value of 7 and a DEI bit value of 0 to CoS 7 and Green color:

```
root> ethernet qos 802.1ad-up-bits-mapping-tbl set 802.1p 7 dei 0 cos 7
color green
```

Configuring DSCP Classification (CLI)

When DSCP classification is set to Trust mode, the interface performs QoS and Color classification according to a user-configurable DSCP to CoS and Color classification table. 802.1p classification has priority over DSCP Trust Mode, so that if a match is found on the 802.1p level, DSCP is not considered.

This section includes:

- [Configuring Trust Mode for DSCP Classification \(CLI\)](#)
- [Modifying the DSCP Classification Table \(CLI\)](#)

Configuring Trust Mode for DSCP Classification (CLI)

To define the trust mode for DSCP classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification set ip-dscp <ip-dscp>
```

To display the trust mode for DSCP classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification show 802.1p state
```

Table 220 Trust Mode for DSCP CLI Parameters

Parameter	Input Type	Permitted Values	Description
ip-dscp	Variable	trust un-trust	Select the interface's trust mode for DSCP classification: trust – The interface performs QoS and color classification according to a user-configurable table for DSCP to CoS and color classification. DSCP classification has priority over MPLS classification, so that if a match is found with the DSCP value of the ingress frame, MPLS bits are not considered. un-trust – The interface does not consider DSCP during classification.

The following command enables DSCP trust mode for GbE 1:

```
eth type eth [1/1]>classification set ip-dscp trust
```

The following command disables DSCP trust mode for GbE 1:

```
eth type eth [1/1]>classification set ip-dscp un-trust
```

Modifying the DSCP Classification Table (CLI)

The following table shows the default values for the DSCP classification table.

Table 221 DSCP Classification Table Default Values

DSCP	DSCP (bin)	Description	CoS (Configurable)	Color (Configurable)
0 (default)	000000	BE (CS0)	0	Green
10	001010	AF11	1	Green
12	001100	AF12	1	Yellow
14	001110	AF13	1	Yellow
18	010010	AF21	2	Green
20	010100	AF22	2	Yellow
22	010110	AF23	2	Yellow
26	011010	AF31	3	Green
28	011100	AF32	3	Yellow
30	011110	AF33	3	Yellow
34	100010	AF41	4	Green
36	100100	AF42	4	Yellow
38	100110	AF43	4	Yellow

DSCP	DSCP (bin)	Description	CoS (Configurable)	Color (Configurable)
46	101110	EF	7	Green
8	001000	CS1	1	Green
16	010000	CS2	2	Green
24	011000	CS3	3	Green
32	100000	CS4	4	Green
40	101000	CS5	5	Green
48	110000	CS6	6	Green
56	111000	CS7	7	Green
51	110011	DSCP_51	6	Green
52	110100	DSCP_52	6	Green
54	110110	DSCP_54	6	Green
56	111000	CS7	7	Green

To modify the DSCP classification table, enter the following command:

```
root> ethernet qos dscp-mapping-tbl set dscp <dscp> cos <cos> color <color>
```

To display the DSCP classification table, enter the following command:

```
root> ethernet qos dscp-mapping-tbl show
```

Table 222 Modify DSCP Classification Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
dscp	Number	Valid DSCP values. Refer to the DSCP column in the table above.	The DSCP value to be mapped.
cos	Number	0 – 7	The CoS assigned to frames with the designated DSCP value.
color	Variable	green yellow	The Color assigned to frames with the designated DSCP value.

The following command maps frames with DSCP value of 10 to CoS 1 and Green color:

```
root> ethernet qos dscp-mapping-tbl set dscp 10 cos 1 color green
```

Configuring MPLS Classification (CLI)

When MPLS classification is set to Trust mode, the interface performs QoS and Color classification according to a user-configurable MPLS EXP bit to CoS and Color classification table. Both 802.1p and DSCP classification have priority over MPLS Trust Mode, so that if a match is found on either the 802.1p or DSCP levels, MPLS bits are not considered.

This section includes:

- [Configuring Trust Mode for MPLS Classification \(CLI\)](#)
- [Modifying the MPLS EXP Bit Classification Table \(CLI\)](#)

Configuring Trust Mode for MPLS Classification (CLI)

To define the trust mode for MPLS classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification set mpls <mpls>
```

To display the trust mode for MPLS classification, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification show mpls state
```

Table 223 Trust Mode for MPLS CLI Parameters

Parameter	Input Type	Permitted Values	Description
mpls	Variable	Trust un-trust	Select the interface's trust mode for MPLS bits: trust – The interface performs QoS and color classification according to a user-configurable table for MPLS EXP to CoS and color classification. un-trust – The interface does not consider MPLS bits during classification.

The following command enables MPLS trust mode for Ethernet port 1:

```
eth type eth [1/1]>classification set mpls trust
```

The following command disables MPLS trust mode for Ethernet port 1:

```
eth type eth [1/1]>classification set mpls un-trust
```

Modifying the MPLS EXP Bit Classification Table (CLI)

The following table shows the default values for the MPLS EXP bit classification table.

Table 224 MPLS EXP Bit Classification Table Default Values

MPLS EXP bits	CoS (Configurable)	Color (Configurable)
0	0	Yellow
1	1	Green
2	2	Yellow
3	3	Green
4	4	Yellow
5	5	Green
6	6	Green
7	7	Green

To modify the MPLS EXP bit classification table, enter the following command:

```
root> ethernet qos mpls-exp-bits-mapping-tbl set mpls-exp <mpls-exp> cos
<cos> color <color>
```

To display the MPLS EXP bit classification table, enter the following command:

```
root> ethernet qos mpls-mapping-tbl show
```

Table 225 MPLS EXP Bit Classification Table Modification CLI Parameters

Parameter	Input Type	Permitted Values	Description
mpls-exp	Number	0 – 7	The MPLS EXP bit to be mapped.
cos	Number	0 – 7	The CoS assigned to frames with the designated MPLS EXP bit value.
color	Variable	green yellow	The Color assigned to frames with the designated MPLS EXP bit value.

The following command maps frames with MPLS EXP bit value of 4 to CoS 4 and Yellow color:

```
root> ethernet qos mpls-exp-bits-mapping-tbl set mpls-exp 4 cos 4 color
yellow
```

Configuring a Default CoS (CLI)

You can define a default CoS value for frames passing through the interface. This value can be overwritten on the service point and service level. The Color is assumed to be Green.

To define a default CoS value for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification set default-cos <default-cos>
```

To display the default CoS value for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>classification show default-cos
```

Table 226 Default CoS CLI Parameters

Parameter	Input Type	Permitted Values	Description
default-cos	Number	0 – 7	Enter the default CoS value for frames passing through the interface. This value can be overwritten on the service point and service level.

The following command sets the default CoS for GbE 1 as 7:

```
eth type eth [1/1]>classification set default-cos 7
```

Configuring Ingress Path Classification on a Service Point (CLI)

For instruction on configuring ingress path classification on a service point, see [CoS Preservation and Modification on a Service Point \(CLI\)](#).

Configuring Ingress Path Classification on a Service (CLI)

For instruction on configuring ingress path classification on a service, see [Configuring a Service's CoS Mode and Default CoS \(CLI\)](#).

Configuring Policers (Rate Metering) (CLI)

This section includes:

- [Overview of Rate Metering \(Policing\) \(CLI\)](#)
- [Configuring Rate Meter \(Policer\) Profiles \(CLI\)](#)
- [Displaying Rate Meter Profiles \(CLI\)](#)
- [Deleting a Rate Meter Profile \(CLI\)](#)
- [Attaching a Rate Meter \(Policer\) to an Interface \(CLI\)](#)
- [Configuring the Line Compensation Value for a Rate Meter \(Policer\) \(CLI\)](#)
- [Displaying Rate Meter Statistics for an Interface \(CLI\)](#)

Overview of Rate Metering (Policing) (CLI)

The PTP 820G and PTP 820F switching fabric supports hierarchical policing on the logical interface level. You can define up to 250 rate meter (policer) profiles.



Note

Policing on the service point level, and the service point and CoS level, is planned for future release.

The PTP 820G and PTP 820F's policer mechanism is based on a dual leaky bucket mechanism (TrTCM). The policers can change a frame's color and CoS settings based on CIR/EIR + CBS/EBS, which makes the policer mechanism a key tool for implementing bandwidth profiles and enabling operators to meet strict SLA requirements.

The output of the policers is a suggested color for the inspected frame. Based on this color, the queue management mechanism decides whether to drop the frame or to pass it to the queue.

Configuring Rate Meter (Policer) Profiles (CLI)

To add a rate meter (policer) profile, enter the following command:

```
root> ethernet qos rate-meter add profile-id <profile-id> cir <cir> cbs
<cbs> eir <eir> ebs <ebs> color-mode <color-mode> coupling-flag
<coupling-flag> rate-meter-profile-name <rate-meter-profile-name>
```

To edit an existing rate meter (policer) profile, enter the following command:

```
root> ethernet qos rate-meter edit profile-id <profile-id> cir <cir> cbs
<cbs> eir <eir> ebs <ebs> color-mode <color-mode> coupling-flag
<coupling-flag> rate-meter-profile-name <rate-meter-profile-name>
```

Table 227 Rate Meter Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 – 250	A unique ID for the rate meter (policer) profile.
cir	Number	0, or 64,000 - 1,000,000,000	The Committed Information Rate (CIR) defined for the rate meter (policer), in bits per second. If the value is 0, all incoming CIR traffic is dropped.
cbs	Number	0 - 128	The Committed Burst Rate (CBR) for the rate meter (policer), in Kbytes.
eir	Number	0, or 64,000 - 1,000,000,000	The Excess Information Rate (EIR) for the rate meter (policer), in bits per second. If the value is 0, all incoming EIR traffic is dropped.
ebs	Number	0 - 128	The Excess Burst Rate (EBR) for the rate meter (policer), in Kbytes.
color-mode	Variable	color-blind color-aware	Determines how the rate meter (policer) treats frames that ingress with a CFI or DEI field set to 1 (yellow). Options are: color aware – All frames that ingress with a CFI/DEI field set to 1 (yellow) are treated as EIR frames, even if credits remain in the CIR bucket. color blind – All ingress frames are treated as green regardless of their CFI/DEI value. A color-blind policer discards any former color decisions.
coupling-flag	Variable	enable disable	When enabled, frames that ingress as yellow may be converted to green when there are no available yellow credits in the EIR bucket. Only relevant in color-aware mode.
rate-meter-profile-name	Text string	Up to 20 characters.	A description of the rate meter (policer) profile.

The following command creates a rate meter (policer) profile with Profile ID 50, named “64k.”

```
root> ethernet qos rate-meter add profile-id 50 cir 64000 cbs 5 eir 64000
ebs 5 color-mode color-blind coupling-flag disable rate-meter-profile-
name 64k
```

This profile includes the following parameters:

- CIR – 64,000 bps

- CBS – 5 Kbytes
- EIR – 64,000 bps
- EBS – 5 Kbytes
- Color Blind mode
- Coupling Flag disabled

The following command edits the rate meter (policer) profile with Profile ID 50, and changes its name to “256 kBytes.”

```
root> ethernet qos rate-meter edit profile-id 50 cir 128000 cbs 5 eir
128000 ebs 5 color-mode color-aware coupling-flag enable rate-meter-
profile-name 256 kBytes
```

This edited profile includes the following parameters:

- CIR – 128,000 bps
- CBS – 5 Kbytes
- EIR – 128,000 bps
- EBS – 5 Kbytes
- Color Aware mode
- Coupling Flag enabled

Displaying Rate Meter Profiles (CLI)

You can display all configured rate meter (policer) profiles or a specific profile.

To display a specific profile, enter the following command:

```
root> ethernet qos rate-meter show profile-id <profile-id>
```

For example, the following command displays the parameters of Rate Meter Profile 50:

```
root> ethernet qos rate-meter show profile-id 50
```

To display all configured profiles, enter the following command:

```
root> ethernet qos rate-meter show profile-id all
```

Deleting a Rate Meter Profile (CLI)

You cannot delete a rate meter (policer) profile that is attached to a logical interface. You must first remove the profile from the logical interface, then delete the profile.

To delete a rate meter (policer) profile, use the following command:

```
root> ethernet qos rate-meter delete profile-id <profile-id>
```

The following command deletes Rate Meter Profile 50:

```
root> ethernet qos rate-meter delete profile-id 50
```

Attaching a Rate Meter (Policer) to an Interface (CLI)

On the logical interface level, you can assign rate meter (policer) profiles as follows:

- Per frame type (unicast, multicast, and broadcast)
- Per frame ethertype

This section includes:

- [Assigning a Rate Meter \(Policer\) for Unicast Traffic \(CLI\)](#)
- [Assigning a Rate Meter \(Policer\) for Multicast Traffic \(CLI\)](#)
- [Assigning a Rate Meter \(Policer\) for Broadcast Traffic \(CLI\)](#)
- [Assigning a Rate Meter \(Policer\) per Ethertype \(CLI\)](#)

Assigning a Rate Meter (Policer) for Unicast Traffic (CLI)

To assign a rate meter (policer) profile for unicast traffic to the interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter unicast add capability admin-state <admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for unicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter unicast edit admin-state <admin-state> profile-id <profile-id>
```

To display the current unicast rate meter (policer) profile for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter unicast show configuration
```

To delete the rate meter (policer) profile for unicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter unicast delete
```

Table 228 Assigning Rate Meter for Unicast Traffic CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Enables or disables rate metering on unicast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the rate meter profiles defined in the system.

The following command assigns Rate Meter Profile 1 to unicast traffic on GbE 1, and enables rate metering on the port:

```
eth type eth [1/1]>rate-meter unicast add capability admin-state enable profile-id 1
```

The following command changes the rate meter (policer) profile for unicast traffic on GbE 1 to 4:

```
eth type eth [1/1]>rate-meter unicast edit admin-state enable profile-id 4
```

Assigning a Rate Meter (Policer) for Multicast Traffic (CLI)

To assign a rate meter (policer) profile for multicast traffic to the interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter multicast add capability admin-state
<admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for multicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter multicast edit admin-state <admin-state>
profile-id <profile-id>
```

To display the current multicast rate meter (policer) profile for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter multicast show configuration
```

To delete the rate meter (policer) profile for multicast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter multicast delete
```

Table 229 Assigning Rate Meter for Multicast Traffic CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Enables or disables rate metering on multicast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the rate meter profiles defined in the system.

The following command assigns Rate Meter Profile 1 to multicast traffic on GbE 1, and enables rate metering on the port.

```
eth type eth [1/1]>rate-meter multicast add capability admin-state enable
profile-id 1
```

The following command changes the rate meter (policer) profile for multicast traffic on GbE 1 to 4:

```
eth type eth [1/1]>rate-meter multicast edit admin-state enable profile-
id 4
```

Assigning a Rate Meter (Policer) for Broadcast Traffic (CLI)

To assign a rate meter (policer) profile for broadcast traffic to the interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter broadcast add capability admin-state
<admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for broadcast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter broadcast edit admin-state <admin-state>
profile-id <profile-id>
```

To display the current broadcast rate meter (policer) settings for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter broadcast show configuration
```

To delete the rate meter (policer) profile for broadcast traffic, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter broadcast delete
```

Table 230 Assigning Rate Meter for Broadcast Traffic CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin-state	Variable	enable disable	Enables or disables rate metering on broadcast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the rate meter profiles defined in the system.

The following command assigns Profile 1 to broadcast traffic on GbE 1, and enables rate metering on the port.

```
eth type eth [1/1]>rate-meter broadcast add capability admin-state enable
profile-id 1
```

The following command changes the rate meter (policer) profile for broadcast traffic on GbE 1 to 4:

```
eth type eth [1/1]>rate-meter broadcast edit admin-state enable profile-
id 4
```

Assigning a Rate Meter (Policer) per Ethertype (CLI)

You can define up to three policers per Ethertype value.

To assign a rate meter (policer) profile for a specific Ethertype to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter <ethertype#> add capability ethertype-value
<ethertype-value> admin-state <admin-state> profile-id <profile-id>
```

To change the rate meter (policer) profile for a specific Ethertype, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter <ethertype#> edit ethertype-value
<ethertype-value> admin-state <admin-state> profile-id <profile-id>
```

To display the current Ethertype rate meter (policer) settings for an interface, go to interface view for the interface and enter the following commands:

```
eth type eth [x/x]>rate-meter ethertype1 show configuration
eth type eth [x/x]>rate-meter ethertype2 show configuration
eth type eth [x/x]>rate-meter ethertype3 show configuration
```

To delete the rate meter (policer) profile for an Ethertype, go to interface view for the interface and enter one or more of the following commands:

```
eth type eth [x/x]>rate-meter ethertype1 delete
eth type eth [x/x]>rate-meter ethertype2 delete
eth type eth [x/x]>rate-meter ethertype3 delete
```

Table 231 Assigning Rate Meter per Ethertype CLI Parameters

Parameter	Input Type	Permitted Values	Description
ethertype#	Variable	ethertype1 ethertype2 ethertype3	Identifies which of three possible policer-per-Ethertype combinations you are defining.
ethertype-value	Hexadecimal	1-65535	Identifies the Ethertype to which the profile applies.
admin-state	Variable	enable disable	Enables or disables policing on broadcast traffic flows from the logical interface.
profile-id	Number	1 – 250	Select from the policer profiles defined in the system. For instructions on defining rate meter (policer) profiles, refer to Configuring Rate Meter (Policer) Profiles (CLI) .

The following commands assign Rate Meter Profiles 1, 2, and 3 to Ethertypes 0x8000, 0x8100, and 0x9100, respectively, on GbE 1, and enable rate metering on the port.

```
eth type eth [1/1]>rate-meter ethertype1 add capability ethertype-value
0x8000 admin-state enable profile-id 1
eth type eth [1/1]>rate-meter ethertype2 add capability ethertype-value
0x8100 admin-state enable profile-id 2
eth type eth [1/1]>rate-meter ethertype3 add capability ethertype-value
0x9100 admin-state enable profile-id 3
```

The following commands change the rate meter (policer) profiles assigned in the examples above to 4, 5, and 6, respectively.

```
eth type eth [1/1]>rate-meter ethertype1 edit ethertype-value 0x8000
admin-state enable profile-id 4
eth type eth [1/1]>rate-meter ethertype2 edit ethertype-value 0x8100
admin-state enable profile-id 5
eth type eth [1/1]>rate-meter ethertype3 edit ethertype-value 0x9100
admin-state enable profile-id 6
```

Configuring the Line Compensation Value for a Rate Meter (Policer) (CLI)

A rate meter can measure CIR and EIR at Layer 1 or Layer 2 rates. Layer 1 capacity is equal to Layer 2 capacity plus 20 additional bytes for each frame due to the preamble and Inter Frame Gap (IFG). In most cases, the preamble and IFG equals 20 bytes, but other values are also possible. Line compensation defines the number of bytes to be added to each frame for purposes of CIR and EIR calculation. When Line Compensation is 20, the rate meter operates as Layer 1. When Line Compensation is 0, the rate meter operates as Layer 2. This parameter is very important to users that want to distinguish between Layer 1 and Layer 2 traffic.

To configure the rate meter (policer) line compensation value for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter-compensation-value set <value>
```

To display the rate meter (policer) line compensation value for an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>rate-meter-compensation-value get
```

Table 232 Assigning Line Compensation Value for Rate Meter CLI Parameters

Parameter	Input Type	Permitted Values	Description
value	Number	0 – 32	Policers attached to the interface use this value to compensate for Layer 1 non-effective traffic bytes.

The following command sets the line compensation value for policers attached to GbE 1 to 20:

```
eth type eth [1/1]>rate-meter-compensation-value set 20
```

Displaying Rate Meter Statistics for an Interface (CLI)

For the rate meter (policer) at the logical interface level, you can display the following statistics counters:

- Green Frames
- Green Bytes
- Yellow Frames
- Yellow Bytes
- Red Frames
- Red Bytes



Note

Rate meter (policer) counters are displayed in granularity of 64 bits.

The following commands display rate meter counters for the available frame types and Ethertypes:

```
eth type eth [x/x]>rate-meter unicast show statistics clear-on-read
<clear-on-read> layer-1 <layer-1>
eth type eth [x/x]>rate-meter multicast show statistics clear-on-read
<clear-on-read> layer-1 <layer-1>
eth type eth [x/x]>rate-meter broadcast show statistics clear-on-read
<clear-on-read> layer-1 <layer-1>
eth type eth [x/x]>rate-meter ethertype1 show statistics clear-on-read
<clear-on-read> layer-1 <layer-1>
eth type eth [x/x]>rate-meter ethertype2 show statistics clear-on-read
<clear-on-read> layer-1 <layer-1>
eth type eth [x/x]>rate-meter ethertype3 show statistics clear-on-read
<clear-on-read> layer-1 <layer-1>
```

Table 233 Displaying Rate Meter Statistics CLI Parameters

Parameter	Input Type	Permitted Values	Description
clear-on-read	Boolean	yes no	If you enter yes, the statistics are cleared once you display them.
layer 1	Boolean	yes no	yes – Statistics are represented as Layer 1 statistics, including preamble and IFG. no – Statistics are represented as Layer 2 statistics.

The following commands display rate meter counters for GbE 1, for each of the available frame types and Ethertypes. These commands clear the counters after displaying them.

```
eth type eth [1/1]>rate-meter unicast show statistics clear-on-read yes
layer-1 no
```

```
eth type eth [1/1]>rate-meter multicast show statistics clear-on-read yes
layer-1 no

eth type eth [1/1]>rate-meter broadcast show statistics clear-on-read yes
layer-1 no

eth type eth [1/1]>rate-meter ethertype1 show statistics clear-on-read
yes layer-1 no

eth type eth [1/1]>rate-meter ethertype2 show statistics clear-on-read
yes layer-1 no

eth type eth [1/1]>rate-meter ethertype3 show statistics clear-on-read
yes layer-1 no
```

Configuring Marking (CLI)

This section includes:

- [Marking Overview \(CLI\)](#)
- [Configuring Marking Mode on a Service Point \(CLI\)](#)
- [Marking Table for C-VLAN UP Bits \(CLI\)](#)
- [Marking Table for S-VLAN UP Bits \(CLI\)](#)

Marking Overview (CLI)

When enabled, PTP 820G and PTP 820F's marking mechanism modifies each frame's 802.1p UP bit and CFI/DEI bits according to the classifier decision. The CFI/DEI (color) field is modified according to the classifier and policer decision. The color is first determined by a classifier and may be later overwritten by a policer. Green color is represented by a CFI/DEI value of 0, and Yellow color is represented by a CFI/DEI value of 1. Marking is performed on egress frames that are VLAN-tagged.

The marking is performed according to global marking tables that describe the 802.1p UP bits and the CFI bits (for C-VLAN tags) or DEI bits (for S-VLAN tags). The marking mode attribute in the service point egress attributes determines whether the frame is marked as Green or Yellow according to the calculated color.



Note

The calculated color is sent to the queue manager regardless of whether the marking bit is set.

Regular marking is only performed when:

- The outer frame is S-VLAN, and S-VLAN CoS preservation is disabled
- The outer frame is C-VLAN, and C-VLAN CoS preservation is disabled

If marking and CoS preservation for the relevant outer VLAN are both disabled, special marking is applied. Special marking means that marking is performed, but only according to the values defined for Green frames in the 802.1Q and 802.1AD marking tables.

When marking is performed, the C-VLAN or S-VLAN 802.1p UP bits are re-marked according to the calculated CoS and Color.

Configuring Marking Mode on a Service Point (CLI)

To enable or disable marking mode on a service point, go to service view for the service and enter the following command:

```
service[SID]>sp marking set spid <sp-id> mode <mode>
```

Table 234 Marking Mode on Service Point CLI Parameters

Parameter	Input Type	Permitted Values	Description
sp-id	Number	1-32 for P2P and MP services. 1-30 for MNG services.	The Service Point ID.
mode	Variable	enable disable	<p>Determines whether re-marking of the outer VLAN (C-VLAN or S-VLAN) of tagged frames that pass through the service point is enabled.</p> <p>If <code>mode</code> is set to <code>enable</code>, and CoS preservation for the relevant outer VLAN is set to <code>disable</code>, the service point re-marks the C-VLAN or S-VLAN 802.1p UP bits of egress frames according to the calculated CoS and Color, and the user-configurable 802.1Q and 802.1AD marking tables.</p> <p>If <code>mode</code> is set to <code>enable</code> and CoS preservation for the relevant outer VLAN is also set to <code>enable</code>, re-marking is not performed.</p> <p>If <code>mode</code> is set to <code>disable</code> and CoS preservation for the relevant outer VLAN is also set to <code>disable</code>, re-marking is applied, but only according to the values defined for Green frames in the 802.1Q and 802.1AD marking tables.</p> <p>For information about configuring CoS Preservation, refer to CoS Preservation and Modification on a Service Point.</p>

The following command enables marking mode on Service Point 3 on Service 2:

```
service[2]>sp marking set spid 3 mode enable
```

The following command disables marking mode on Service Point 3 on Service 2:

```
service[2]>sp marking set spid 3 mode disable
```

Marking Table for C-VLAN UP Bits (CLI)

When marking is performed, the following table is used by the marker to decide which CoS and Color to use as the egress CoS and Color bits for C-VLAN-tagged frames.

Table 235 Marking Table for C-VLAN UP Bits

CoS	Color	802.1q (Configurable)	CFI Color (Configurable)
0	Green	0	0
0	Yellow	0	1
1	Green	1	0
1	Yellow	1	1
2	Green	2	0
2	Yellow	2	1
3	Green	3	0
3	Yellow	3	1
4	Green	4	0
4	Yellow	4	1
5	Green	5	0
5	Yellow	5	1
6	Green	6	0
6	Yellow	6	1
7	Green	7	0
7	Yellow	7	1

To modify the 802.1q CoS and Color to UP and CFI bit mapping table, enter the following command in root view:

```
root> ethernet qos 802.1q-up-bits-marking-tbl set cos <cos> color <color>
802.1p <802.1p> cfi <cfi>
```

To display the 802.1q CoS and Color to UP and CFI bit mapping table, enter the following command in root view:

```
root> ethernet qos 802.1q-up-bits-marking-tbl show
```

Table 236 802.1q CoS and Color to UP and CFI Bit Mapping Table CLI Parameters

Parameter	Input Type	Permitted Values	Description
cos	Number	0 – 7	The CoS value to be mapped.
color	Variable	green yellow	The Color to be mapped.

Parameter	Input Type	Permitted Values	Description
802.1p	Number	0 – 7	The UP bit value assigned to matching frames.
cfi	Number	0 – 1	The CFI bit value assigned to matching frames.

The following command maps CoS 0, Green, to 802.1p UP bit 0, and CFI bit 0:

```
root> ethernet qos 802.1q-up-bits-marking-tbl set cos 0 color green
802.1p 0 cfi 0
```

Marking Table for S-VLAN UP Bits (CLI)

When marking is performed, the following table is used by the marker to decide which CoS and Color to use as the egress CoS and Color bits for S-VLAN-tagged frames.

Table 237 802.1ad UP Marking Table (S-VLAN)

CoS	Color	802.1ad UP (Configurable)	DEI Color (Configurable)
0	Green	0	0
0	Yellow	0	1
1	Green	1	0
1	Yellow	1	1
2	Green	2	0
2	Yellow	2	1
3	Green	3	0
3	Yellow	3	1
4	Green	4	0
4	Yellow	4	1
5	Green	5	0
5	Yellow	5	1
6	Green	6	0
6	Yellow	6	1
7	Green	7	0
7	Yellow	7	1

To modify the 802.1ad CoS and Color to UP and DEI bit mapping table, enter the following command in root view:

```
root> ethernet qos 802.1ad-up-bits-marking-tbl set cos <cos> color
<color> 802.1p <802.1p> dei <dei>
```

To display the 802.1q CoS and Color to UP and CFI bit mapping table, enter the following command in root view:

```
root> ethernet qos 802.1ad-up-bits-marking-tbl show
```

Table 238 802.1ad UP Marking Table (S-VLAN) CLI Parameters

Parameter	Input Type	Permitted Values	Description
cos	Number	0 – 7	The CoS value to be mapped.
color	Variable	green yellow	The Color to be mapped.
802.1p	Number	0 – 7	The UP bit value assigned to matching frames.
dei	Number	0 – 1	The DEI bit value assigned to matching frames.

The following command marks CoS 5, Yellow, to 802.1p UP bit 5, and DEI bit 1:

```
root> ethernet qos 802.1ad-up-bits-marking-tbl set cos 5 color yellow
802.1p 5 dei 1
```

Configuring WRED (CLI)

This section includes:

- [WRED Overview \(CLI\)](#)
- [Configuring WRED Profiles \(CLI\)](#)
- [Assigning a WRED Profile to a Queue \(CLI\)](#)

WRED Overview (CLI)

Weighted Random Early Detection (WRED) enables differentiation between higher and lower priority traffic based on CoS. You can define up to 30 WRED profiles. Each profile contains a green traffic curve and a yellow traffic curve. These curves describe the probability of randomly dropping frames as a function of queue occupancy.

The system also includes two pre-defined read-only profiles. These profiles are assigned WRED profile IDs 31 and 32:

- Profile number 31 defines a tail-drop curve and is configured with the following values:
 - 100% Yellow traffic drop after 64kbytes occupancy.
 - 100% Green traffic drop after 128kbytes occupancy.
 - Yellow maximum drop is 100%
 - Green maximum drop is 100%
- Profile number 32 defines a profile in which all will be dropped. It is for internal use and should not be applied to traffic.

A WRED profile can be assigned to each queue. The WRED profile assigned to the queue determines whether or not to drop incoming frames according to the occupancy of the queue. As the queue occupancy grows, the probability of dropping each incoming frame increases as well. As a consequence, statistically more TCP flows will be restrained before traffic congestion occurs.

Configuring WRED Profiles (CLI)

To configure a WRED profile, enter the following command in root view:

```
root> ethernet qos wred-profile-tbl add profile-id <profile-id> green-  
min-threshold <green-min-threshold> green-max-threshold <green-max-  
threshold> green-max-drop <green-max-drop> yellow-min-threshold <yellow-  
min-threshold> yellow-max-threshold <yellow-max-threshold> yellow-max-  
drop <yellow-max-drop>
```

To edit an existing WRED profile, enter the following command in root view:

```
root> ethernet qos wred-profile-tbl edit profile-id <profile-id> green-  
min-threshold <green-min-threshold> green-max-threshold <green-max-  
threshold> green-max-drop <green-max-drop> yellow-min-threshold <yellow-  
min-threshold> yellow-max-threshold <yellow-max-threshold> yellow-max-  
drop <yellow-max-drop>
```

To display a WRED profile, enter the following command in root view:

```
root> ethernet qos wred-profile-tbl show profile-id <profile-id>
```

To delete a WRED profile, enter the following command in root view:

```
root> ethernet qos wred-profile-tbl delete profile-id <profile id>
```

You cannot delete a WRED profile that is assigned to a queue. You must first remove the WRED profile from the queue by replacing it with a different WRED profile. You can then delete the WRED profile.



Note

Each queue always has a WRED profile assigned to it. By default, WRED Profile 31 is assigned to every queue until a different profile is assigned.

Table 239 WRED Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 - 30	A unique ID to identify the profile.
green-min-threshold	Number	0 - 8192	The minimum throughput of green frames for queues with this profile, in Kbytes. When this value is reached, the system begins dropping green frames in the queue.
green-max-threshold	Number	0 - 8192	The maximum throughput of green frames for queues with this profile, in Kbytes. When this value is reached, all green frames in the queue are dropped.
green-max-drop	Number	1 - 100	The maximum percentage of dropped green frames for queues with this profile.
yellow-min-threshold	Number	0 - 8192	The minimum throughput of yellow frames for queues with this profile, in Kbytes. When this value is reached, the system begins dropping yellow frames in the queue.
yellow-max-threshold	Number	0 - 8192	The maximum throughput of yellow frames for queues with this profile, in Kbytes. After this value is reached, all yellow frames in the queue are dropped.
yellow-max-drop	Number	1 - 100	The maximum percentage of dropped yellow frames for queues with this profile.

The following command adds a WRED profile.

```
root> ethernet qos wred-profile-tbl add profile-id 2 green-min-threshold
8000 green-max-threshold 8000 green-max-drop 100 yellow-min-threshold
8000 yellow-max-threshold 8000 yellow-max-drop 100
```

The new profile has the following parameters:

- profile-id – 2
- green-min-threshold – 8000 Kbytes
- green-max-threshold – 8000 Kbytes
- green-max-drop – 100%
- yellow-min-threshold – 8000 Kbytes
- yellow-max-threshold – 8000 Kbytes
- yellow-max-drop – 100%

The following command edits the WRED profile created by the previous command:

```
root> ethernet qos wred-profile-tbl edit profile-id 2 green-min-threshold
8000 green-max-threshold 8000 green-max-drop 100 yellow-min-threshold
4000 yellow-max-threshold 4000 yellow-max-drop 100
```

The edited profile has the following parameters:

- green-min-threshold – 8000 Kbytes
- green-max-threshold – 8000 Kbytes
- green-max-drop – 100%
- yellow-min-threshold – 4000 Kbytes
- yellow-max-threshold – 4000 Kbytes
- yellow-max-drop – 100%

Assigning a WRED Profile to a Queue (CLI)

To assign a WRED profile to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> wred set service-bundle-id <service-bundle-id> cos
<cos> profile-id <profile-id>
```

To display the WRED profile assigned to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> wred show profile-id service-bundle-id <service-
bundle-id> cos <cos>
```

Table 240 Assigning WRED Profile to Queue CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	Assigns the WRED profile to a Service Bundle. Service Bundles are bundles of queues, grouped together in order to configure common egress characteristics for specific services.
cos	Number	0 – 7	Assigns the WRED profile to a queue in the designated service bundle.
profile-id	Number	1 – 32	A unique ID that identifies the profile.

The following command assigns WRED Profile 2 to the CoS 0 queue in Service Bundle 1, on GbE 1:

```
eth type eth [1/1]> wred set service-bundle-id 1 cos 0 profile-id 2
```

The following command displays the WRED profile assigned to the CoS 0 queue in Service Bundle 1, on Ethernet port 1:

```
eth type eth [1/1]> wred show profile-id service-bundle-id 1 cos 0
```

Configuring Shapers (CLI)

This section includes:

- [Overview of Egress Shaping \(CLI\)](#)
- [Configuring Shapers \(CLI\)](#)
- [Configuring Service Bundle Shapers \(CLI\)](#)
- [Configuring Egress Line Compensation for Shaping \(CLI\)](#)

Overview of Egress Shaping (CLI)

Egress shaping determines the traffic profile for each queue. PTP 820G and PTP 820F performs egress shaping on the following levels:

- **Queue level** – Single leaky bucket shaping
- **Service Bundle level** – Dual leaky bucket shaping

**Note**

Single leaky bucket shaping on the interface level is planned for future release.

You can configure up to 32 single leaky bucket queue shaper profiles. The CIR value can be set to the following values:

- 16,000 – 32,000,000 bps – granularity of 16,000 bps
- 32,000,000 – 131,008,000 bps – granularity of 64,000 bps

**Note**

You can enter any value within the permitted range. Based on the value you enter, the software automatically rounds off the setting according to the granularity. If you enter a value below the lowest granular value (except 0), the software adjusts the setting to the minimum.

You can attach one of the configured queue shaper profiles to each priority queue. If no profile is attached to the queue, no egress shaping is performed on that queue.

This section includes:

- [Configuring Queue Shaper Profiles \(CLI\)](#)
- [Attaching a Shaper Profile to a Queue \(CLI\)](#)

Configuring Queue Shaper Profiles (CLI)

To configure a queue shaper profile, enter the following command in root view:

```
root> ethernet qos queue-shaper-profile-tbl add profile-id <profile-id>
cir <cir> shaper-profile-name <shaper-profile-name>
```

To edit the parameters of an existing queue shaper profile, enter the following command in root view:

```
root> ethernet qos queue-shaper-profile-tbl edit profile-id <profile-id>
cir <cir> shaper-profile-name <shaper-profile-name> burst-type short
```



Note

The burst-type parameter is reserved for future use. However, you must enter this parameter in order for the command to execute.

To display the parameters of a queue shaper profile, enter the following command in root view:

```
root> ethernet qos queue-shaper-profile-tbl show profile-id <profile-id>
```

To delete a queue shaper profile, enter the following command in root view:

```
root> ethernet qos queue-shaper-profile-tbl delete profile-id <profile
id>
```

You cannot delete a queue shaper profile if it is attached to a queue. You must first remove the profile from the queue. You can then delete the profile.

Table 241 Queue Shaper Profiles CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 - 32	A unique ID that identifies the profile.
cir	Number	16000 – 131008000	The Committed Information Rate (CIR) assigned to the profile (in bps).
shaper-profile-name	Text String	Up to 20 characters.	A description of the profile.

The following command creates Queue Shaper 1, named “p1”, with a CIR value of 16000 bps.

```
root> ethernet qos queue-shaper-profile-tbl add profile-id 1 cir 16000
shaper-profile-name p1
```

The following command changes the CIR value of the profile created above from 16000 to 32000, and changes the profile name to p3.

```
root> ethernet qos queue-shaper-profile-tbl edit profile-id 1 cir 32000
shaper-profile-name p3 burst-type short
```

Attaching a Shaper Profile to a Queue (CLI)

You can attach one of the configured queue shaper profiles to each priority queue. If no profile is attached to the queue, no egress shaping is performed on that queue. Shapers are attached to queues based on the logical interface and service bundle to which the queue belongs, and the queue’s CoS value.

To attach a queue shaper profile to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> queue-shaper add capability service-bundle-id
<service-bundle-id> cos <cos> admin-state <admin-state> profile-id
<profile-id>
```

To change the queue shaper profile attached to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> queue-shaper edit service-bundle-id <service-bundle-
id> cos <cos> admin-state <admin-state> profile-id <profile-id>
```

To display the queue shaper profile attached to a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> queue-shaper show configuration service-bundle-id
<service-bundle-id> cos <cos>
```

To remove a queue shaper profile from a queue, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> queue-shaper delete service-bundle-id <service-
bundle-id> cos <cos>
```

Table 242 Attaching Shaper Profile to Queue CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle to which you are attaching the queue shaper profile.
cos	Number	0 – 7	The CoS queue ID of the queue to which you want to assign the shaper. Queues are numbered according to CoS value.
admin-state	Variable	enable disable	Select enable to enable egress queue shaping on the queue, or disable to disable egress queue shaping on the queue. If you set shaping to disable , the shaper profile remains attached to the queue, but does not affect traffic.
profile-id	Number	1 – 32	Enter the ID of one of the configured queue shaper profiles.

The following command adds Queue Shaper Profile 5 to queues with CoS 0, on Service Bundle 1, on Ethernet port 1, and enables shaping on these queues:

```
eth type eth [1/1]> queue-shaper add capability service-bundle-id 1 cos 0
admin-state enable profile-id 5
```

The following command changes the Queue Shaper Profile assigned in the previous command to Queue Shaper Profile 2:

```
eth type eth [1/1]> queue-shaper edit service-bundle-id 1 cos 0 admin-  
state enable profile-id 2
```

Configuring Service Bundle Shapers (CLI)

You can configure up to 256 dual leaky bucket service bundle shaper profiles. The profiles can be configured as follows:

Valid CIR values are:

- 0 – 32,000,000 bps, with granularity of 16,000 bps
- 32,000,000 – 1,000,000,000 bps, with granularity of 64,000 bps

Valid PIR values are:

- 16,000 – 32,000,000 bps, with granularity of 16,000 bps
- 32,000,000 – 1,000,000,000 bps, with granularity of 64,000 bps



Note

You can enter any value within the permitted range. Based on the value you enter, the software automatically rounds off the setting according to the granularity. If you enter a value below the lowest granular value (except 0), the software adjusts the setting to the minimum.

You can attach one of the configured service bundle shaper profiles to each service bundle. If no profile is attached to the service bundle, no egress shaping is performed on that service bundle.

This section includes:

- [Configuring Service Bundle Shaper Profiles \(CLI\)](#)
- [Attaching a Shaper Profile to a Service Bundle \(CLI\)](#)

Configuring Service Bundle Shaper Profiles (CLI)

To configure a service bundle shaper profile, enter the following command in root view:

```
root> ethernet qos service-bundle-shaper-profile-tbl add profile-id
<profile-id> cir <cir> pir <pir> shaper-profile-name <shaper-profile-
name>
```

To edit the parameters of an existing service bundle shaper profile, enter the following command in root view:

```
root> ethernet qos service-bundle-shaper-profile-tbl edit profile-id
<profile-id> cir <cir> pir <pir> shaper-profile-name <shaper-profile-
name>
```

To display the parameters of a service bundle shaper profile, enter the following command in root view:

```
root> ethernet qos service-bundle-shaper-profile-tbl show profile-id
<profile-id>
```

To display the parameters of all configured service bundle shaper profiles, enter the following command in root view:

```
root> ethernet qos service-bundle-shaper-profile-tbl show profile-id all
```

To delete a service bundle shaper profile, enter the following command in root view:

```
root> ethernet qos service-bundle-shaper-profile-tbl delete profile-id
<profile-id>
```

You cannot delete a service bundle shaper profile if it is attached to a service bundle. You must first remove the profile from the service bundle. You can then delete the profile.

Table 243 Service Bundle Shaper Profiles CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 - 256	A unique ID that identifies the profile.
cir	Number	1 - 1000000000	The Committed Information Rate (CIR) assigned to the profile (in bps).
pir	Number	16000 - 1000000000	The Peak Information Rate (PIR) assigned to the profile (in bps).
shaper-profile-name	Text String	Up to 20 characters.	A description of the profile.

The following command creates Service Bundle Shaper 1, named “p1”, with a CIR value of 100000000 bps and a PIR value of 200000000 bps:

```
root> ethernet qos service-bundle-shaper-profile-tbl add profile-id 1 cir
100000000 pir 200000000 shaper-profile-name p1
```

The following command changes the CIR value in the Service Bundle Shaper created above from 100000000 bps to 110000000 bps:

```
root> ethernet qos service-bundle-shaper-profile-tbl edit profile-id 1
cir 110000000 pir 200000000 shaper-profile-name p1
```

Attaching a Shaper Profile to a Service Bundle (CLI)

You can attach one of the configured service bundle shaper profiles to each service bundle. If no profile is attached to the service bundle, no egress shaping is performed on that service bundle.

To attach a service bundle shaper profile to a service bundle, go to interface view for the service bundle and enter the following command:

```
eth type eth [x/x]> service-bundle-shaper add capability service-bundle-id <service-bundle-id> admin-state <admin-state> profile-id <profile-id>
```

To change the service bundle shaper profile attached to a service bundle, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> service-bundle-shaper edit service-bundle-id <service-bundle-id> admin-state <admin-state> profile-id <profile-id>
```

To display the service bundle shaper profile attached to a service bundle, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> service-bundle-shaper show configuration service-bundle-id <service-bundle-id>
```

To remove a service bundle shaper profile from a service bundle, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> service-bundle-shaper delete service-bundle-id <service-bundle-id>
```

Table 244 Attaching Shaper Profile to Service Bundle CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle to which you are attaching the queue shaper profile.
admin-state	Variable	enable disable	Select enable to enable egress shaping on the service bundle, or disable to disable egress shaping on the service bundle.
profile-id	Number	1 – 256	Enter the ID of one of the configured service bundle shaper profiles.

The following command adds Service Bundle Shaper Profile 5 to Service Bundle 1, on Ethernet port 1, and enables shaping on this service bundle:

```
eth type eth [1/1]> service-bundle-shaper add capability service-bundle-id 1 admin-state enable profile-id 5
```

The following command changes the Service Bundle Shaper Profile assigned in the previous command to Service Bundle 1, from 5 to 4:

```
eth type eth [1/1]> service-bundle-shaper edit service-bundle-id 1 admin-
state enable profile-id 4
```

Configuring Egress Line Compensation for Shaping (CLI)

You can configure a line compensation value for all the shapers under a specific logical interface. This value is used to compensate for Layer 1 non-effective traffic bytes on egress.

To set the egress line compensation value, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>shaping-compensation-value set <value>
```

To display the egress line compensation value, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]>shaping-compensation-value get
```

Table 245 Egress Line Compensation for Shaping CLI Parameters

Parameter	Input Type	Permitted Values	Description
value	Number	0 – 26 (even numbers only)	Shapers attached to the interface use this value to compensate for Layer 1 non-effective traffic bytes on egress.

The following command sets the egress line compensation value to 0 on Ethernet port 1:

```
eth type eth [1/1]>shaping-compensation-value set 0
```

Configuring Scheduling (CLI)

This section includes:

- [Overview of Egress Scheduling \(CLI\)](#)
- [Configuring Queue Priority \(CLI\)](#)
- [Configuring Interface Priority Profiles \(CLI\)](#)
- [Attaching a Priority Profile to an Interface \(CLI\)](#)
- [Configuring Weighted Fair Queuing \(WFQ\) \(CLI\)](#)

Overview of Egress Scheduling (CLI)

Egress scheduling is responsible for transmission from the priority queues. PTP 820G and PTP 820F use a unique algorithm with a hierarchical scheduling model over the three levels of the egress path that enables compliance with SLA requirements.

The scheduler scans all the queues over all the service bundles, per interface, and determines which queue is ready to transmit. If more than one queue is ready to transmit, the scheduler determines which queue transmits first based on:

- **Queue Priority** – A queue with higher priority is served before lower-priority queues.
- **Weighted Fair Queuing (WFQ)** – If two or more queues have the same priority and are ready to transmit, the scheduler transmits frames from the queues based on a WFQ algorithm that determines the ratio of frames per queue based on a predefined weight assigned to each queue.

Configuring Queue Priority (CLI)

A priority profile defines the exact order for serving the eight priority queues in a single service bundle. When you attach a priority profile to an interface, all the service bundles under the interface inherit the profile.

The priority mechanism distinguishes between two states of the service bundle:

- Green State – Committed state
- Yellow state – Best effort state

Green State refers to any time when the service bundle rate is below the user-defined CIR. Yellow State refers to any time when the service bundle is above the user-defined CIR but below the PIR.

You can define up to four Green priority profiles, from 4 (highest) to 1 (lowest). An additional four Yellow priority profiles are defined automatically and cannot be changed or edited.

The following table provides a sample of an interface priority profile. This profile is also used as the default interface priority profile.

Table 246 Interface Priority Profile Example

Profile ID (1-9)			
CoS	Green Priority (user defined)	Yellow Priority (read only)	Description
0	1	1	Best Effort
1	2	1	Data Service 4
2	2	1	Data Service 3
3	2	1	Data Service 2
4	2	1	Data Service 1
5	3	1	Real Time 2 (Video with large buffer)
6	3	1	Real Time 1 (Video with small buffer)
7	4	4	Management (Sync, PDUs, etc.)

When the service bundle state is Green (committed state), the service bundle priorities are as defined in the Green Priority column. When the service bundle state is Yellow (best effort state), the service bundle priorities are system-defined priorities shown in the Yellow Priority column.



Note

CoS 7 is always marked with the highest priority and cannot be changed or edited, no matter what the service bundle state is, since it is assumed that only high priority traffic will be tunneled via CoS 7.

The system supports up to nine interface priority profiles. Profiles 1 to 8 are defined by the user, while profile 9 is the pre-defined read-only default interface priority profile.

Configuring Interface Priority Profiles (CLI)

To define an interface priority profile, enter the following command in root view:

```
root> ethernet qos port-priority-profile-tbl add profile-id <profile-id>
cos0-priority <cos0-priority> description <description> cos1-priority
<cos1-priority> description <description> cos2-priority <cos2-priority>
description <description> cos3-priority <cos3-priority> description
<description> cos4-priority <cos4-priority> description <description>
cos5-priority <cos5-priority> description <description> cos6-priority
<cos6-priority> description <description> cos7-priority <cos7-priority>
description <description>
```

To edit an existing interface priority profile, enter the following command in root view:

```
root> ethernet qos port-priority-profile-tbl edit profile-id <profile-id>
cos0-priority <cos0-priority> description <description> cos1-priority
<cos1-priority> description <description> cos2-priority <cos2-priority>
description <description> cos3-priority <cos3-priority> description
<description> cos4-priority <cos4-priority> description <description>
cos5-priority <cos5-priority> description <description> cos6-priority
<cos6-priority> description <description> cos7-priority <cos7-priority>
description <description>
```

To display the parameters of an interface priority profile, enter the following command in root view:

```
root> ethernet qos port-priority-profile-tbl show profile-id <profile-id>
```

To delete an interface priority profile, enter the following command in root view:

```
root> ethernet qos port-priority-profile-tbl delete profile-id <profile-id>
```

You can only delete an interface priority profile if the profile is not attached to any interface.

Table 247 Interface Priority Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 – 8	A unique ID to identify the profile.
cos0-priority	Number	1-4	The Green priority for the CoS 0 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 0 egressing the service bundle to which the profile is assigned.
description	Text String	Up to 20 characters.	A description of the priority level.
cos1-priority	Number	1-4	The Green priority for the CoS 1 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 1 egressing the service bundle to which the profile is assigned.
cos2-priority	Number	1-4	The Green priority for the CoS 2 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 2 egressing the service bundle to which the profile is assigned.
cos3-priority	Number	1-4	The Green priority for the CoS 3 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 3 egressing the service bundle to which the profile is assigned.
cos4-priority	Number	1-4	The Green priority for the CoS 4 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 4 egressing the service bundle to which the profile is assigned.

Parameter	Input Type	Permitted Values	Description
cos5-priority	Number	1-4	The Green priority for the CoS 5 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 5 egressing the service bundle to which the profile is assigned.
cos6-priority	Number	1-4	The Green priority for the CoS 6 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 6 egressing the service bundle to which the profile is assigned.
cos7-priority	Number	1-4	The Green priority for the CoS 7 queue, from 4 (highest) to 1 (lowest). This priority is applied to Green frames with CoS 7 egressing the service bundle to which the profile is assigned.

The following command configures a priority profile with Profile ID 1.

```
root> ethernet qos port-priority-profile-tbl add profile-id 1 cos0-
priority 1 description c0_p1 cos1-priority 1 description c1_p1 cos2-
priority 1 description c2_p1 cos3-priority 2 description c3_p2 cos4-
priority 2 description c4_p2 cos5-priority 3 description c5_p3 cos6-
priority 4 description c6_p4 cos7-priority 4 description c7_p4
```

This profile has the parameters listed in the following table.

Table 248 Interface Priority Sample Profile Parameters

CoS	Green Priority (user defined)	Yellow Priority (read only)	Description
0	1	1	c0_p1
1	1	1	c1_p1
2	1	1	c2_p1
3	2	1	c3_p2
4	2	1	c4_p2
5	3	1	c5_p3
6	4	1	c6_p4
7	4	4	c7_p4

The following command edits the profile you created in the previous command so that CoS 6 queues have a Green priority of 3 instead of 4, and a description of "c6_p3".

```
root> ethernet qos port-priority-profile-tbl edit profile-id 1 cos0-
priority 1 description c0_p1 cos1-priority 1 description c1_p1 cos2-
priority 1 description c2_p1 cos3-priority 2 description c3_p2 cos4-
priority 2 description c4_p2 cos5-priority 3 description c5_p3 cos6-
priority 3 description c6_p3 cos7-priority 4 description c7_p4
```

Attaching a Priority Profile to an Interface (CLI)

To attach a priority profile to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> priority set profile-id <profile-id>
```

Table 249 Attaching Priority Profile to Interface CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 – 9	Enter the ID of one of the configured logical interface priority profiles.

The following command attaches Interface Priority Profile 3 to GbE 1:

```
eth type eth [1/1]> priority set profile-id 3
```

To display which priority profile is attached to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> port-priority show profile-id
```

The following is a sample output from this command:

```
eth type eth [1/1]>port-priority show profile-id
Profile ID: 9
CoS Priority Priority Description
(When queue is green) When queue is yellow)
0 1 1 best effort
1 2 1 data service
2 2 1 data service
3 2 1 data service
4 2 1 data service
5 3 1 real time
6 3 1 real time
7 4 4 management
eth type eth [1/1]>
```

Configuring Weighted Fair Queuing (WFQ) (CLI)

This section includes:

- [Overview of WFQ \(CLI\)](#)
- [Configuring a WFQ Profile \(CLI\)](#)
- [Attaching a WFQ Profile to an Interface \(CLI\)](#)

Overview of WFQ (CLI)

The scheduler serves the queues based on their priority, but when two or more queues have data to transmit and their priority is the same, the scheduler uses Weighted Fair Queuing (WFQ) to determine the priorities within each priority. WFQ defines the transmission ratio, in bytes, between the queues. All the service bundles under the interface inherit the WFQ profile attached to the interface.

The system supports up to six WFQ interface profiles. Profile ID 1 is a pre-defined read-only profile, and is used as the default profile. Profiles 2 to 6 are user-defined profiles.

The following table provides an example of a WFQ profile.

Table 250 WFQ Profile Example

Profile ID (1-7)		
CoS	Queue Weight (Green)	Queue Weight (Yellow – not visible to users, and cannot be edited)
0	20	20
1	20	20
2	20	20
3	20	20
4	20	20
5	20	20
6	20	20
7	20	20

You can attach one of the configured interface WFQ profiles to each interface. By default, the interface is assigned Profile ID 1, the pre-defined system profile.

Configuring a WFQ Profile (CLI)

To define a WFQ profile, enter the following command in root view:

```
root> ethernet qos wfq-weight-profile-tbl add profile-id <profile.id>
cos0-weight <cos0-weight> cos1-weight <cos1-weight> cos2-weight <cos2-
weight> cos3-weight <cos3-weight> cos4-weight <cos4-weight> cos5-weight
<cos5-weight> cos6-weight <cos6-weight> cos7-weight <cos7-weight>
```

To edit an existing WFQ profile, enter the following command in root view:

```
root> ethernet qos wfq-weight-profile-tbl edit profile-id <profile.id>
cos0-weight <cos0-weight> cos1-weight <cos1-weight> cos2-weight <cos2-
weight> cos3-weight <cos3-weight> cos4-weight <cos4-weight> cos5-weight
<cos5-weight> cos6-weight <cos6-weight> cos7-weight <cos7-weight>
```

To display the parameters of a WFQ profile, enter the following command in root view:

```
root> ethernet qos wfq-weight-profile-tbl show profile-id <profile-id>
```

To delete a WFQ profile, enter the following command in root view:

```
root> ethernet qos wfq-weight-profile-tbl delete profile-id <profile-id>
```

You can only delete WFQ profile if the profile is not attached to any interface.

Table 251 WFQ Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	2 – 6	A unique ID to identify the profile.
cos0-weight	Number	1 - 20	The relative weight for the CoS 0 queue.
cos1- weight	Number	1 - 20	The relative weight for the CoS 1 queue.
cos2- weight	Number	1 - 20	The relative weight for the CoS 2 queue.
cos3- weight	Number	1 - 20	The relative weight for the CoS 3 queue.
cos4- weight	Number	1 - 20	The relative weight for the CoS 4 queue.
cos5- weight	Number	1 - 20	The relative weight for the CoS 5 queue.
cos6- weight	Number	1 - 20	The relative weight for the CoS 6 queue.
cos7- weight	Number	1 - 20	The relative weight for the CoS 7 queue.

The following command configures a WFQ profile with Profile ID 2.

```
root> ethernet qos wfq-weight-profile-tbl add profile-id 2 cos0-weight 15
cos1-weight 15 cos2-weight 15 cos3-weight 15 cos4-weight 15 cos5-weight
15 cos6-weight 15 cos7-weight 20
```

This profile has the parameters listed in the following table. Note that the yellow queue weight is constant and cannot be changed. This means that all best effort traffic (yellow) will always have the same weight, regardless of CoS.

Table 252 WFQ Sample Profile Parameters

CoS	Queue Weight (Green)	Queue Weight (Yellow – not visible to users, and cannot be edited)
0	15	20
1	20	20
2	20	20
3	20	20
4	20	20
5	20	20

CoS	Queue Weight (Green)	Queue Weight (Yellow – not visible to users, and cannot be edited)
6	20	20
7	20	20

The following command edits the profile you created in the previous command so that CoS 6 queues have a weight of 20 instead of 15:

```
root> ethernet qos wfq-weight-profile-tbl edit profile-id 2 cos0-weight 15 cos1-weight 15 cos2-weight 15 cos3-weight 15 cos4-weight 15 cos5-weight 15 cos6-weight 20 cos7-weight 20
```

Attaching a WFQ Profile to an Interface (CLI)

To attach a WFQ profile to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> port-wfq set profile-id <profile-id>
```

Table 253 Attaching WFQ Profile to Interface CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile-id	Number	1 – 6	Enter the ID of one of the configured WFQ profiles.

The following command attaches WFQ Profile 3 to Ethernet port 1:

```
eth type eth [1/1]> port-wfq set profile-id 3
```

To display which WFQ profile is attached to an interface, go to interface view for the interface and enter the following command:

```
eth type eth [x/x]> port-wfq show profile-id
```

The following is a sample display for this command:

```
eth type eth [1/1]>port-wfq show profile-id
Profile ID: 1
CoS Queue Weight
(Green)
0 20
1 20
2 20
3 20
4 20
5 20
6 20
7 20
eth type eth [1/1]>
```

Displaying Egress Statistics (CLI)

PTP 820G and PTP 820F collects egress PMs at the queue level and the service bundle level.

Displaying Queue-Level PMs (CLI)

PTP 820G and PTP 820F supports the following counters per queue at the queue level:

- Transmitted Green Packets (64 bits counter)
- Transmitted Green Bytes (64 bits counter)
- Transmitted Green Bits per Second (32 bits counter)
- Dropped Green Packets (64 bits counter)
- Dropped Green Bytes (64 bits counter)
- Transmitted Yellow Packets (64 bits counter)
- Transmitted Yellow Bytes (64 bits counter)
- Transmitted Yellow Bits per Second (32 bits counter)
- Dropped Yellow Packets (64 bits counter)
- Dropped Yellow Bytes (64 bits counter)

To display queue-level PMs, enter interface view for the interface and enter the following command:

```
eth type eth [x/x]> tm-queue show statistics service-bundle-id <service-  
bundle-id> cos <cos> clear-on-read <clear-on-read> layer-1 <layer-1>
```

To clear queue-level PMs for a specific service bundle, enter interface view for the interface and enter the following command:

```
eth type eth [x/x]> tm-queue clear statistics service-bundle-id <service-  
bundle-id>
```

Table 254 Egress Queue Level PMs CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle for which you want to display PMs.
cos	Number	0 - 7	The queue for which you want to display PMs.
clear-on-read	Boolean	yes no	If you enter yes, the statistics are cleared once you display them.

Parameter	Input Type	Permitted Values	Description
layer-1	Boolean	yes no	yes – Statistics are represented as Layer 1 statistics, including preamble and IFG. no – Statistics are represented as Layer 2 statistics.

The following command displays PMs for the CoS 0 queue in Service Bundle 1, on GbE 2. The PMs are cleared after they are displayed.

```
eth type eth [1/2]> tm-queue show statistics service-bundle-id 1 cos 0
clear-on-read yes layer-1 yes
```

The following command clears PMs for all queues in Service Bundle 1, on GbE 2.

```
eth type eth [1/2]> tm-queue clear statistics service-bundle-id 1
```

Configuring and Displaying Queue-Level PMs (CLI)

PTP 820 devices support advanced traffic PMs per CoS queue and service bundle. For each logical interface, you can configure thresholds for Green and Yellow traffic per queue. You can then display the following PMs for 15-minute and 24-hour intervals, per queue and color:

- Maximum bytes passed per second
- Minimum bytes passed per second
- Average bytes passed per second
- Maximum bytes dropped per second
- Minimum bytes dropped per second
- Average bytes dropped per second
- Maximum packets passed per second
- Minimum packets passed per second
- Average packets passed per second
- Maximum packets dropped per second
- Minimum packets dropped per second
- Average packets dropped per second
- Seconds bytes per second were over the configured threshold per interval

These PMs are available for any type of logical interface, including groups. To activate collection of these PMs, the user must add a PM collection rule on a logical interface and service bundle and set the relevant thresholds per CoS and Color. When the PM is configured on a group, queue traffic PMs are recorded for the group and not for the individual interfaces that belong to the group.

One collection rule is available per interface.

PMs for queue traffic are saved for 30 days, after which they are removed from the database. It is important to note that they are not persistent, which means they are not saved in the event of unit reset.

To configure and display queue-level PMs, you must first enter interface view. See **Error! Reference source not found.**

To display whether any service bundles are configured on an interface, enter the following command in interface view:

```
eth type eth [x/x]> eth type eth [1/2]>pm tm-queue show configuration all
```

If no service bundles have been configured, the following output is displayed:

```
eth type eth [x/x]>pm tm-queue show configuration all
Num entries: 0
```

If a service bundle has been configured and enabled, the following output is displayed:

```
eth type eth [x/x]>pm tm-queue show configuration all
Service bundle: 1  Admin: enable
Num entries: 1
```

If a service bundle has been configured but it's Admin status is disabled, the following output is displayed:

```
eth type eth [x/x]>pm tm-queue show configuration all
Service bundle: 1  Admin: disable
Num entries: 1
```

To configure a service bundle, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue create service-bundle-id <1-6> admin-state
<enable|disable>
```

To change the Admin state of a service bundle, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue set service-bundle-id <1-6> admin-state
<enable|disable>
```

To remove a service bundle, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue remove service-bundle-id <1-6>
```

For example:

```
eth type eth [1/1]>pm tm-queue remove service-bundle-id 1
WARNING: All PM history for that service bundle will be deleted.
Are you sure? (yes/no):yes
eth type eth [1/1]>
```

To display the threshold settings for a service bundle, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show configuration service-bundle-id <1-6>
```

For example:

```
eth type eth [1/1]>pm tm-queue show configuration service-bundle-id 1
Admin: enable
cos0 green bytes passed threshold: 675000 bytes
cos1 green bytes passed threshold: 675000 bytes
cos2 green bytes passed threshold: 675000 bytes
cos3 green bytes passed threshold: 675000 bytes
cos4 green bytes passed threshold: 675000 bytes
cos5 green bytes passed threshold: 675000 bytes
cos6 green bytes passed threshold: 675000 bytes
cos7 green bytes passed threshold: 675000 bytes
cos0 yellow bytes passed threshold: 675000 bytes
cos1 yellow bytes passed threshold: 675000 bytes
cos2 yellow bytes passed threshold: 100000 bytes
cos3 yellow bytes passed threshold: 675000 bytes
cos4 yellow bytes passed threshold: 675000 bytes
cos5 yellow bytes passed threshold: 675000 bytes
cos6 yellow bytes passed threshold: 675000 bytes
cos7 yellow bytes passed threshold: 675000 bytes
```

To set thresholds for green bytes, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue set service-bundle-id <1-6> cos <0-7> green-
bytes-passed-threshold <0-4294967295>
```

To set thresholds for yellow bytes, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue set service-bundle-id <1-6> cos <0-7> yellow-
bytes-passed-threshold <0-4294967295>
```

To display PMs for green bytes passed, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show counter green_bytes_passed service-bundle-id
1 cos <0-7> interval <15min|24hr>
```

For example:

```
=====
eth type eth [1/2]>exit
root> ethernet interfaces eth slot 1 port 1
eth type eth [1/1]>pm tm-queue show counter green_bytes_passed service-bundle-id 1 cos 1 interval 24hr

PM on TM counters:
=====
interval          integrity          max cos1 green    min cos1 green    avg cos1 green    cos1 seconds
                   bytes passed      bytes passed      bytes passed      passed
                   per second        per second        per second        green bytes
                   threshold
=====
```

To display PMs for green packets passed, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show counter green_packets_passed service-bundle-
id 1 cos <0-7> interval <15min|24hr>
```

For example:

```
eth type eth [1/1]>pm tm-queue show counter green_packets_passed service-bundle-id 1 cos 1 interval 24hr
PM on TM counters:
=====
interval          integrity          max cos1 green    min cos1 green    avg cos1 green
                  packets passed    packets passed    packets passed
                  per second       per second       per second
=====
```

To display PMs for green bytes dropped, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show counter green_bytes_dropped service-bundle-
id 1 cos <0-7> interval <15min|24hr>
```

For example:

```
eth type eth [1/1]>pm tm-queue show counter green_bytes_dropped service-bundle-id 1 cos 1 interval 24hr
PM on TM counters:
=====
interval          integrity          max cos1 green    min cos1 green    avg cos1 green
                  bytes dropped     bytes dropped     bytes dropped
                  per second       per second       per second
=====
```

To display PMs for green packets dropped, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show counter green_packets_dropped service-
bundle-id 1 cos <0-7> interval <15min|24hr>
```

For example:

```
eth type eth [1/1]>pm tm-queue show counter green_packets_dropped service-bundle-id 1 cos 1 interval 24hr
PM on TM counters:
=====
interval          integrity          max cos1 green    min cos1 green    avg cos1 green
                  packets           packets           packets
                  dropped per      dropped per      dropped per
                  second         second         second
=====
```

To display PMs for yellow bytes passed, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show counter yellow_bytes_passed service-bundle-
id 1 cos <0-7> interval <15min|24hr>
```

For example:

```
eth type eth [1/1]>pm tm-queue show counter yellow_bytes_passed service-bundle-id 1 cos 1 interval 15min
PM on TM counters:
=====
interval          integrity          max cos1          min cos1          avg cos1          cos1 seconds
                   yellow bytes      yellow bytes      yellow bytes      yellow bytes
                   passed per       passed per       passed per       passed
                   second          second          second          threshold
=====
```

To display PMs for yellow packets passed, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show counter yellow_packets_passed service-
bundle-id 1 cos <0-7> interval <15min|24hr>
```

For example:

```
eth type eth [1/1]>pm tm-queue show counter yellow_packets_passed service-bundle-id 1 cos 1 interval 15min
PM on TM counters:
=====
interval          integrity          max cos1          min cos1          avg cos1
                   yellow packets    yellow packets    yellow packets
                   passed per       passed per       passed per
                   second          second          second
=====
```

To display PMs for yellow bytes dropped, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show counter yellow_bytes_dropped service-bundle-
id 1 cos <0-7> interval <15min|24hr>
```

For example:

```
eth type eth [1/1]>pm tm-queue show counter yellow_bytes_dropped service-bundle-id 1 cos 1 interval 15min
PM on TM counters:
=====
interval          integrity          max cos1          min cos1          avg cos1
                   yellow bytes      yellow bytes      yellow bytes
                   dropped per       dropped per       dropped per
                   second          second          second
=====
```

To display PMs for yellow packets dropped, enter the following command in interface view:

```
eth type eth [x/x]> pm tm-queue show counter yellow_packets_dropped service-
bundle-id 1 cos <0-7> interval <15min|24hr>
```

For example:

```
eth type eth [1/1]>pm tm-queue show counter yellow_packets_dropped service-bundle-id 1 cos 1 interval 15min
PM on TM counters:
=====
interval          integrity          max cos1          min cos1          avg cos1
                  yellow packets   yellow packets   yellow packets
                  dropped per      dropped per      dropped per
                  second          second          second
=====
```

The integrity column indicates whether the PM is valid:

- 0 indicates a valid entry.

1 indicates an invalid entry. This can occur for a number of reasons, including but not limited to a disconnected cable, a missing SFP module, muting of a radio interface, and an operational status of Down

Displaying Service Bundle-Level PMs (CLI)

PTP 820G and PTP 820F supports the following counters per service bundle at the service bundle level:

- Transmitted Green Packets (64 bits counter)
- Transmitted Green Bytes (64 bits counter)
- Transmitted Green Bits per Second (32 bits counter)
- Dropped Green Packets (64 bits counter)
- Dropped Green Bytes (64 bits counter)
- Transmitted Yellow Packets (64 bits counter)
- Transmitted Yellow Bytes (64 bits counter)
- Transmitted Yellow Bits per Second (32 bits counter)
- Dropped Yellow Packets (64 bits counter)
- Dropped Yellow Bytes (64 bits counter)

To display service bundle-level PMs, enter interface view for the interface and enter the following command:

```
eth type eth [x/x]> tm-service-bundle show statistics service-bundle-id
<service-bundle-id> clear-on-read <clear-on-read> layer-1 <layer-1>
```

To clear service bundle-level PMs for all service bundles on an interface, enter interface view for the interface and enter the following command:

```
eth type eth [x/x]> tm-service-bundle clear statistics
```

Table 255 Egress Service Bundle Level PMs CLI Parameters

Parameter	Input Type	Permitted Values	Description
service-bundle-id	Number	1 – 63 Note: In the current release, only Service Bundle 1 is supported.	The service bundle for which you want to display PMs.
clear-on-read	Boolean	yes no	If you enter yes, the statistics are cleared once you display them.
layer-1	Boolean	yes no	yes – Statistics are represented as Layer 1 statistics, including preamble and IFG. no – Statistics are represented as Layer 2 statistics.

The following command displays service bundle PMs for Service Bundle 1, on GbE 1. The PMs are cleared after they are displayed.

```
eth type eth [1/1]> tm-service-bundle show statistics service-bundle-id 1
clear-on-read yes layer-1 yes
```

Chapter 20: Ethernet Protocols (CLI)

This section includes:

- [Configuring G.8032 \(CLI\)](#)
- [Configuring MSTP \(CLI\)](#)
- [Configuring LLDP \(CLI\)](#)

Configuring G.8032 (CLI)

This section includes:

- [Configuring the Destination MAC Address \(CLI\)](#)
- [Configuring ERPIs \(CLI\)](#)
- [Configuring the RPL Owner \(CLI\)](#)
- [Configuring Timers \(CLI\)](#)
- [Initiating a Manual or Forced Switch and Clearing the Switch or Initiating Reversion \(CLI\)](#)
- [Blocking or Unblocking R-APS Messages on a Service Point \(CLI\)](#)
- [Displaying the ERPI Attributes \(CLI\)](#)

Configuring the Destination MAC Address (CLI)

To set the destination MAC address for PDUs generated by the node, enter the following command in root view:

```
root> ethernet generalcfg g8032-dest-mac-address set MAC <MAC address>
```

To display the destination MAC address, enter the following command in root view:

```
root> ethernet generalcfg g8032-dest-mac-address show
```

To display the destination MAC address and the node ID, enter the following command in root view:

```
root> ethernet g8032 show-node-attributes
```

The node ID is the base MAC address for the node.

Table 256 G.8032 Destination MAC Address CLI Parameters

Parameter	Input Type	Permitted Values	Description
MAC address	Six groups of two hexadecimal digits	01:19:a7:00:00:x where x can be any number between 0 and 16.	The destination MAC address for PDUs generated by the node.

The following command sets the destination MAC address as 01:19:a7:00:00:02:

```
root> ethernet generalcfg g8032-dest-mac-address set MAC 01:19:a7:00:00:02
```

Configuring ERPIs (CLI)

You can configure up to 64 Ethernet Ring Protection instances (ERPIs). Each ERPI is associated with an Ethernet service defined in the system. An ERPI can be:

- **Ring:** A Ring is an Ethernet ring that is connected on two ports (East and West service points) to an interconnection node.

- **Sub-Ring:** A Sub-Ring is an Ethernet ring which is connected to another ring or network through the use of interconnection nodes (East and West service points). On their own, the Sub-Ring links do not form a closed physical loop. A closed loop may be formed by the sub-ring links and the link between interconnection nodes that is controlled by other ring or network.
- **Ring with Sub-Ring:** The ERPI includes both a ring, with East and West service points, and a connection to a sub-ring using a Sub-Ring service point.

To add a Ring ERPI, enter the following command in root view:

```
root> ethernet g8032 create-erpi erp-type ring erpi-id <erpi-id> erpi-
service-id <erpi-service-id> west-sp <west-sp> east-sp <east-sp> level
<level> version <version>
```

To add a Sub-Ring ERPI, enter the following command in root view:

```
root> ethernet g8032 create-erpi erp-type sub-ring erpi-id <erpi-id>
erpi-service-id <erpi-service-id> west-sp <west-sp> east-sp <east-sp>
level <level> version <version>
```

To add a Ring with Sub-Ring ERPI, enter the following command in root view:

```
root> ethernet g8032 create-erpi erp-type ring-with-sub-ring erpi-id
<erpi-id> erpi-service-id <erpi-service-id> west-sp <west-sp> east-sp
<east-sp> sub-ring-sp <sub-ring-sp> level <level> version <version>
```

To assign a name to an ERPI, enter the following command in root view:

```
root> ethernet g8032 set-erpi-name erpi-id <erpi-id> erpi-name <erpi-
name>
```

To delete an ERPI, enter the following command in root view:

```
root> ethernet g8032 delete-erpi erpi-id 1
```

Table 257 G.8032 ERPI Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
erpi-id	Number	1-64	A unique ID that identifies the ERPI.
erpi-service-id	Number	1-4095	The ID of the Ethernet service to which the ERPI belongs.
west-sp	Number	1-32	The first endpoint for the ERPI. This can be any service point that has been configured for the service.
east-sp	Number	1-32	The second endpoint for the ERPI. This can be any service point that has been configured for the service.
sub-ring-sp	Number	1-32	The service point that connects the Ring with the Sub-Ring. This can be any service point that has been configured for the service.

Parameter	Input Type	Permitted Values	Description
level	Number	0-7	Optional. The Maintenance Entity Group (MEG) level used for R-APS messages sent in the ERPI.
version	Number	1-2	Optional. The ERPI (G.8032) protocol version currently being used in the unit.
erpi-name	Text		A descriptive name for the ERPI.

The following commands create a Ring ERPI with ID 1, and name the ERPI "service_x". This ERPI is associated with Ethernet Service 1. The end points of the ERPI are Service Point 1 and Service Point 2. The ERPI is configured with MEG level 2

```
root> ethernet g8032 create-erpi erp-type ring erpi-id 1 erpi-service-id 1 west-sp 1 east-sp 2 level 2
root> ethernet g8032 set-erpi-name erpi-id 1 erpi-name service_x
```

The following commands create a Sub-Ring ERPI with ID 10, and name the ERPI "Sub_ring". This ERPI is associated with Ethernet Service 20. The end points of the ERPI are Service Point 1 and Service Point 2. The ERPI is configured with MEG level 4

```
root> ethernet g8032 create-erpi erp-type sub-ring erpi-id 10 erpi-service-id 20 west-sp 1 east-sp 2 level 4
root> ethernet g8032 set-erpi-name erpi-id 10 erpi-name Sub_ring
```

The following commands create a Ring with Sub-Ring ERPI with ID 20, and name the ERPI "RSRi". This ERPI is associated with Ethernet Service 30. The end points of the ERPI are Service Point 1 and Service Point 2, and the point of connection between the Ring and the Sub-Ring is Service Point 3. The ERPI is configured with MEG level 5

```
root> ethernet g8032 create-erpi erp-type ring-with-sub-ring erpi-id 20 erpi-service-id 30 west-sp 1 east-sp 2 sub-ring-sp 3 level 5
root> ethernet g8032 set-erpi-name erpi-id 20 erpi-name RSRi
```

The following command deletes ERPI 1:

```
root> ethernet g8032 delete-erpi erpi-id 1
```

Configuring the RPL Owner (CLI)

The RPL Owner Node is a node in the ERPI that is responsible for blocking traffic at one end of the ERPI.

To set the RPL Owner Node, enter the following command in root view:

```
root> ethernet g8032 set-rpl-owner erpi-id <erpi-id> SP <SP>
```

To remove the RPL Owner Node, enter the following command in root view:

```
root> ethernet g8032 remove-rpl-owner erpi-id <erpi-id>
```

Table 258 G.8032 RPL Owner CLI Parameters

Parameter	Input Type	Permitted Values	Description
erpi-id	Number	1-64	The ID of the ERPI for which you want to set or delete the RPL owner.
SP	Number or Variable	east west sub-ring	Specifies the service point you want to designate as the RPL owner.

The following command sets the East service point as the RPL owner for ERPI 1:

```
root> ethernet g8032 set-rpl-owner erpi-id 1 SP east
```

The following command sets the Sub-Ring service point as the RPL owner for ERPI 20:

```
root> ethernet g8032 set-rpl-owner erpi-id 20 SP sub-ring
```

The following command removes the RPL owner for ERPI 1:

```
root> ethernet g8032 remove-rpl-owner erpi-id 1
```

Configuring Timers (CLI)

You can configure timers per ERPI to control the ERPI's switching and convergence parameters. The following timers are available:

- **Wait to Restore (WTR) Timer** – Defines a minimum time the system waits after signal failure is recovered before reverting to idle state.
- **Guard Time** – Prevents unnecessary state changes and loops.
- **Hold-Off Time** – Determines the time period from failure detection to response.

To configure the WTR timer, enter the following command in root view:

```
root> ethernet g8032 set-wtr erpi-id <erpi-id> wtr <wtr>
```

To configure the guard time, enter the following command in root view:

```
root> ethernet g8032 set-guard-time erpi-id <erpi-id> guard-time <guard-time>
```

To configure the hold-off, enter the following command in root view:

```
root> ethernet g8032 set-holdoff-time erpi-id <erpi-id> holdoff-time <holdoff-time>
```

Table 259 G.8032 Timer Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
erpi-id	Number	1-64	The ID of the ERPI for which you want to set a timer.
wtr	Number	1-12	The minimum time (in minutes) the system waits after signal failure is recovered before reverting to idle state.

Parameter	Input Type	Permitted Values	Description
guard-time	Number	10-2000, in multiples of 10	The minimum time (in msec) the system waits after recovery from a signal failure before accepting new R-APS messages. The purpose of this timer is to prevent unnecessary state changes and loops.
holdoff-time	Number	0-10000, in multiples of 100	The minimum time (in msec) the system waits before reacting to a signal failure.

The following command sets the WTR timer for ERPI 1 to 2 minutes:

```
root> ethernet g8032 set-wtr erpi-id 1 wtr 2
```

The following command sets the guard time for ERPI 1 to 20 msec:

```
root> ethernet g8032 set-guard-time erpi-id 1 guard-time 20
```

The following command sets the hold-off time for ERPI 1 to 1000 msec:

```
root> ethernet g8032 set-holdoff-time erpi-id 1 holdoff-time 1000
```

Initiating a Manual or Forced Switch and Clearing the Switch or Initiating Reversion (CLI)

To initiate a forced switch, enter the following command in root view:

```
root> ethernet g8032 fs-erpi erpi-id <erpi-id> SP <SP>
```

To initiate a manual switch, enter the following command in root view:

```
root> ethernet g8032 ms-erpi erpi-id <erpi-id> SP <SP>
```

You can use a "clear" command to clear a forced or manual switch. You can also use a "clear" command to trigger convergence prior to the expiration of the relevant timer. To issue a "clear" command, enter the following command in root view:

```
root> ethernet g8032 clear-erpi erpi-id <erpi-id> SP <SP>
```

Table 260 G.8032 Switching and Reversion CLI Parameters

Parameter	Input Type	Permitted Values	Description
erpi-id	Number	1-64	The ID of the ERPI on which you want to perform or clear the switch or initiate convergence.
SP	Number or Variable	east west sub-ring	Specifies the service point on which to clear the manual or forced switch or to implement convergence.

The following command initiates a forced switch in the East service point of ERPI 1:

```
root> ethernet g8032 fs-erpi erpi-id 1 SP east
```

The following command initiates a manual switch in the Sub-Ring service point of ERPI 20:

```
root> ethernet g8032 ms-erpi erpi-id 20 SP sub-ring
```

The following command initiates convergence in the East service point of ERPI 1:

```
root> ethernet g8032 clear-erpi erpi-id 1 SP east
```

Blocking or Unblocking R-APS Messages on a Service Point (CLI)

To enable or disable transmission of R-APS messages on a service point, enter the following command in root view:

```
root> ethernet g8032 set-erpi-sp-tx-raps-cntrl erpi-id <erpi-id> SP <SP>  
tx-raps <tx-raps>
```

Table 261 G.8032 Switching and Reversion CLI Parameters

Parameter	Input Type	Permitted Values	Description
erpi-id	Number	1-64	The ID of the ERPI on which you want to perform or clear the switch or initiate convergence.
SP	Variable	east west sub-ring	Specifies the service point on which to clear the manual or forced switch or to implement convergence.
tx-raps	Variable	true false	true – R-APS message transmission is enabled on the service point. false – R-APS message transmission is blocked on the service point.

Displaying the ERPI Attributes (CLI)

To display a list of all ERPIs configured on the unit, enter the following command in root view:

```
root> ethernet g8032 show-all-erpi
```

The following is an example of this command's output.

```
root> ethernet g8032 show-all-erpi
```

ERPI id	ERPI name	Service	User instance	Ring state	West SP	East SP	Sub-ring SP
1		1	1	protecting	3	2	1
2		2	2	protecting	3	2	N/A
3		5	5	protecting	3	2	N/A
4		6	6	protecting	3	2	N/A
5		7	7	protecting	3	2	N/A
6		8	8	protecting	3	2	N/A
8		3	15	protecting	2	1	N/A
16		4	16	protecting	2	1	N/A

```
root> █
```

To display all ERPIs that include a service point on a specific port, enter the following command in root view:

```
root> ethernet g8032 show-all-port-erpi interface <interface> slot <slot>
port <port>
```

To display all ERPIs that include a service point on a specific group, enter the following command in root view:

```
root> ethernet g8032 show-all-port-erpi group <group>
```

The following command displays all ERPIs with a service point on port 1 of the TCC in slot 1:

```
root> ethernet g8032 show-all-port-erpi interface eth slot 1 port 1
```

The following command displays all ERPIs with a service point on LAG group 1:

```
root> ethernet g8032 show-all-port-erpi group lag1
```

The following command displays all ERPIs with a service point on HSB protection group 2:

```
root> ethernet g8032 show-all-port-erpi group rp2
```

The following command displays all ERPIs with a service point on Multi-Carrier ABC group 1:

```
root> ethernet g8032 show-all-port-erpi group mc-abc1
```

The following is an example of this command's output.

```

root> ethernet g8032 show-all-port-erpi interface radio slot 5 port 1
=====
|ERPI id |ERPI name |Service |User |Ring state |west SP |East SP |Sub-ring SP |
|-----|-----|-----|-----|-----|-----|-----|-----|
|1 | |1 |1 |protecting |3 |2 |1 |
|-----|-----|-----|-----|-----|-----|-----|-----|
|2 | |2 |2 |protecting |3 |2 |N/A |
|-----|-----|-----|-----|-----|-----|-----|-----|
|3 | |5 |5 |protecting |3 |2 |N/A |
|-----|-----|-----|-----|-----|-----|-----|-----|
|4 | |6 |6 |protecting |3 |2 |N/A |
|-----|-----|-----|-----|-----|-----|-----|-----|
|5 | |7 |7 |protecting |3 |2 |N/A |
|-----|-----|-----|-----|-----|-----|-----|-----|
|6 | |8 |8 |protecting |3 |2 |N/A |
|-----|-----|-----|-----|-----|-----|-----|-----|
|8 | |3 |15 |protecting |2 |1 |N/A |
|-----|-----|-----|-----|-----|-----|-----|-----|
|16 | |4 |16 |protecting |2 |1 |N/A |
|-----|-----|-----|-----|-----|-----|-----|-----|
root>
    
```

To display detailed information about a specific ERPI, enter the following command in root view:

```

root> ethernet g8032 show-erpi-config erpi-id <erpi-id>
    
```

The following command displays detailed output for ERPI 1:

```

root> ethernet g8032 show-erpi-config erpi-id 1
    
```

The following is an example of this command's output.

```

root> ethernet g8032 show-erpi-config erpi-id 1
=====
|ERPI id |ERPI name |Service |User |west SP |East SP |Sub-ring SP |ERPI type |MEG level |Version |Virtual |RPL owner |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|1 | |1 |1 |3 |2 |1 |ring |1 |2 |0 |none |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|Revertive |WTR |Guard time |Hold-off |SD handling |west SP SD |East SP SD |Sub-ring SP SD |
|true |5 |500 |0 |2 |50 |50 |50 |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
root>
    
```

To display state information about a specific ERPI, enter the following command in root view:

```

root> ethernet g8032 show-erpi-dynamic erpi-id <erpi-id>
    
```

The following command displays detailed output for ERPI 1:

```

root> ethernet g8032 show-erpi-dynamic erpi-id 1
    
```

The following is an example of this command's output.

```

root> ethernet g8032 show-erpi-dynamic erpi-id 1
=====
|ERPI id |Ring state |Local state |Remote state |Last HP request |Last change time |
|-----|-----|-----|-----|-----|-----|
|1 |protecting |clear-sf |raps-sf |nr |0 |
|-----|-----|-----|-----|-----|-----|
root> █
    
```

Table 262 G.8032 ERPI Display Command Input Parameters

Parameter	Input Type	Permitted Values	Description
interface	Variable	eth radio pwe	Enter the type of interface: eth – Ethernet radio – Radio pwe – TDM

Parameter	Input Type	Permitted Values	Description
group	Variable	rp1 rp2 rp3 rp4 lag1 lag2 lag3 lag4 mc-abc1 mc-abc2 mc-abc3 mc-abc4	To display ERPIs that include a service point on a 1+1 HSB group, a LAG group, or a Multi-Carrier ABC group, use this parameter instead of the interface, slot, and port parameters to identify the group. See: <ul style="list-style-type: none"> • Configuring HSB Radio Protection (CLI) • Configuring Link Aggregation (LAG) and LACP (CLI) • Configuring Multi-Carrier ABC (CLI)
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 tdm: 1	The interface for which you want to display ERPIs.
erpi-id	Number	1-64	The ID of the ERPI for which you want to perform or clear the switch, initiate convergence, or display information.

Table 263 G.8032 ERPI Display Command Output Parameters

Parameter	Description
ERPI ID	A unique ID that identifies the ERPI.
ERPI Name	A descriptive name for the ERPI.
Service	The ID of the Ethernet service to which the ERPI belongs.
User Instance	The MSTI to which the Ethernet service is mapped.
Ring State	Indicates the current ERPI state. Possible values are: Initializing Idle Pending Protecting FS (Forced Switch) MS (Manual Switch)
West SP	The interface to which the west ERPI service point belongs.
East SP	The interface to which the east ERPI service point belongs.

Parameter	Description
Sub-Ring SP	The interface to which the ERPI service point that connects the Ring to the Sub-Ring belongs.
ERPI Type	The ERPI type (Ring, Sub-Ring, or Ring with Sub-Ring).
MEG Level	The Maintenance Entity Group (MEG) level used for R-APS messages sent in the ERPI.
Version	The ERPI (G.8032) protocol version currently being used in the unit.
Virtual Channel	Reserved for future use.
RPL Owner	Indicates whether the ERPI is currently an RPL owner, and if it is, which ERPI port is the owner.
Revertive	Indicates whether the ERPI is currently in revertive mode.
WTR	The Wait to Restore (WTR) timer. This timer sets the minimum time (in minutes) the system waits after signal failure before entering revertive mode.
Guard Time	The minimum time (in msec) the system waits after recovery from a signal failure before accepting new R-APS messages. The purpose of this timer is to prevent unnecessary state changes that might be caused by outdated messages.
Hold-Off Time	The minimum time (in msec) the system waits before reacting to a signal failure.
SD Handling	Reserved for future use.
West SP SD Capacity Threshold	Reserved for future use.
East SP SD Capacity Threshold	Reserved for future use.
Sub-Ring SP SD Capacity Threshold	Reserved for future use.
Local State	The current local state input to the ERPI state machine.
Remote State	The last event received from the other end of the link.
Last HP Request	The last high priority request.
Last Change Time	The time of the last ring state transition.

To display the state of a specific service point, enter the following command in root view:

```
root> ethernet g8032 show-erpi-sp-state erpi-id <erpi-id> SP <SP>
```

The following command displays the current state of the East service point for ERPI 1:

```
root> ethernet g8032 show-erpi-sp-state erpi-id 1 SP east
```

The following is an example of this command's output.

```
root> ethernet g8032 show-erpi-sp-state erpi-id 1 SP east
-----
|ERPI id |SP index |SP ID |Active state |R-APS channel |Data |RPL link |Defect |TX R-APS |TX R-APS |TX R-APS |TX R-APS |TX R-APS |
|         |         |      |             |forwarding state |forwarding state |blocked state |state |Frames |SF |NR |RB |SD | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
|1      |east    |1     |true        |true          |true          |false         |no-defect|3      |0      |3      |0      |0      |0      |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|TX R-APS |TX R-APS |TX R-APS |RX R-APS |RX invalid |RX R-APS |
|FS       |MS       |event    |frames   |R-APS frames |SF        |NR        |RB        |SD        |FS        |MS        |event    |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|0       |0       |0       |11762    |0           |11756     |6         |0         |0         |0         |0         |0         |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
root>
```

Table 264 G.8032 Service Point Display Command Output Parameters

Parameter	Description
ERPI ID	A unique ID that identifies the ERPI.
SP Index	Identifies the service point in the ERPI.
SP ID	The Service Point ID.
Active State	Indicates whether or not the service point is active for traffic forwarding.
R-APS Channel Forwarding State	Indicates whether the service point is forwarding R-APS messages.
Data Forwarding State	Indicates whether the service point is in unblocked (forwarding) state.
RPL Link Blocked State	Only relevant if the ERPI to which the service point belongs is the RPL owner. Indicates whether the service point is in blocked state.
Defect State	Indicates whether the service point is in Signal Fail (SF) or Signal Defect (SD) state. Note: Support for Signal Defect state is planned for future release.
TX R-APS Frames	The number of R-APS frames that have been transmitted via the service point.
TX R-APS SF	The number of R-APS Signal Fail (SF) frames that have been transmitted via the service point.
TX R-APS NR	The number of R-APS No Request (NR) frames that have been transmitted via the service point.
TX R-APS RB	The number of R-APS RPL Blocked (RB) frames that have been transmitted via the service point.
TX R-APS SD	The number of R-APS Signal Degrade (SD) frames that have been transmitted via the service point.
TX R-APS FS	The number of R-APS Forced Switch (FS) frames that have been transmitted via the service point.
TX R-APS MS	The number of R-APS Manual Switch (MS) frames that have been transmitted via the service point.
TX R-APS Event	Reserved for future use.

Parameter	Description
RX R-APS Frames	The number of R-APS frames that have been received by the service point.
RX Invalid R-APS Frames	The number of R-APS frames with an invalid format that have been received by the service point.
RX R-APS SF	The number of R-APS Signal Fail (SF) frames that have been received by the service point.
RX R-APS NR	The number of R-APS No Request (NR) frames that have been received by the service point.
TX R-APS RB	The number of R-APS RPL Blocked (RB) frames that have been transmitted by the service point.
TX R-APS SD	The number of R-APS Signal Degrade (SD) frames that have been transmitted by the service point.
TX R-APS FS	The number of R-APS Forced Switch (FS) frames that have been transmitted by the service point.
TX R-APS MS	The number of R-APS Manual Switch (MS) frames that have been transmitted by the service point.
TX R-APS Event	Reserved for future use.

Configuring MSTP (CLI)

This section includes:

- [Configuring the MSTP Bridge Parameters \(CLI\)](#)
- [Configuring the MSTP Port Parameters \(CLI\)](#)

Configuring the MSTP Bridge Parameters (CLI)

This section includes:

- [Enabling and Disabling MSTP \(CLI\)](#)
- [Defining the Number of MSTIs \(CLI\)](#)
- [Setting the BPDU Destination MAC Address \(CLI\)](#)
- [Freezing MSTP \(CLI\)](#)
- [Resetting the MSTP Stack \(CLI\)](#)
- [Handling Signal Degrade \(SD\) Failures \(CLI\)](#)
- [Setting the Configuration ID \(CLI\)](#)
- [Mapping Services to MSTIs \(CLI\)](#)
- [Setting the Bridge Level Spanning Tree Parameters \(CLI\)](#)
- [Setting and Viewing the Bridge Level MSTI Parameters \(CLI\)](#)
- [Viewing the MSTP Parameters \(CLI\)](#)

Enabling and Disabling MSTP (CLI)

Enabling MSTP starts the protocol and sets all port states in all MSTP instances to Blocking. Convergence upon enabling the protocol generally takes less than two seconds.

**Note**

All mapping of Ethernet services to MSTP instances (MSTIs) should be performed *before* enabling MSTP. For instructions, see [Mapping Services to MSTIs \(CLI\)](#).

To enable MSTP on the unit, enter the following command in root view:

```
root> ethernet mstp mstp-enable
```

Disabling MSTP stops the MSTP protocol from running and sets all ports in all MSTP instances to Forwarding state.

To disable MSTP on the unit, enter the following command in root view:

```
root> ethernet mstp mstp-disable
```

To display whether MSTP is currently enabled or disabled on the unit, enter the following command in root view:

```
root> ethernet mstp show-mstp-enabled
```

Defining the Number of MSTIs (CLI)

PTP 820G and PTP 820F can support from 1 to 16 Multiple Spanning Tree Instances (MSTIs) on a single unit. This does not include the Common and Internal Spanning Tree (CIST).

To specify the number of MSTIs, enter the following command in root view:

```
root> ethernet mstp set number-of-instances <MSTI>
```



Note

Changing the number of MSTIs causes the MSTP stack to reset.

To display the number of MSTIs on the unit, enter the following command in root view:

```
root> ethernet mstp show-number-of-instances
```

Table 265 Defining Number of MSTIs CLI Parameters

Parameter	Input Type	Permitted Values	Description
MSTI	Number	2-16	The number of MSTIs on the unit. This number does not include the Common and Internal Spanning Tree (CIST).

The following command sets the number of MSTIs to 14:

```
root> ethernet mstp set number-of-instances 14
```

Setting the BPDU Destination MAC Address (CLI)

To specify the destination MAC address for BPDUs generated in the unit, enter the following command in root view:

```
root> ethernet mstp set bpdu-destination-mac <bpdu-destination-mac>
```

Table 266 BPDU Destination MAC Address CLI Parameters

Parameter	Input Type	Permitted Values	Description
bpdu-destination-mac	Variable	customer provider	customer – The destination MAC address of BPDUs is 0x0180-C200-0000. Provider BPDUs are either tunneled or discarded. provider – The destination MAC address of BPDUs is 0x0180-C200-0008. Customer BPDUs are either tunneled or discarded.

Freezing MSTP (CLI)

You can freeze MSTP in the unit. When MSTP is frozen, BPDUs are neither transmitted nor processed, and all port states are maintained as they were before MSTP was frozen.

To freeze MSTP, enter the following command in root view:

```
root> ethernet mstp mstp-freeze
```

To unfreeze MSTP, enter the following command in root view:

```
root> ethernet mstp mstp-defreeze
```

To display whether MSTP is or is not currently frozen in the unit, enter the following command in root view:

```
root> ethernet mstp show-mstp-frozen
```

Resetting the MSTP Stack (CLI)

To reset MSTP on the unit, enter the following command in root view:

```
root> ethernet mstp mstp-reset
```

Handling Signal Degrade (SD) Failures (CLI)

Signal Degrade failures (SD) can either be ignored or treated the same as SF, which means an SD failure triggers a topology change.



Note

This feature is planned for future release.

To determine how SD failures are treated, enter the following command in root view:

```
root> ethernet mstp set sd-handling <sd-handling>
```

Table 267 MSTP Signal Degrade Failure CLI Parameters

Parameter	Input Type	Permitted Values	Description
sd-handling	Variable	ignored same-as-SF	ignored – Signal Degrade (SD) failures are ignored in MSTP. same-as-SF – MSTP handles SD failures the same as Signal Failure, i.e., an SD failure triggers a topology change.

Setting the Configuration ID (CLI)

The configuration ID attributes include the Configuration Name and the Revision Level. These attributes are part of the Bridge Configuration Identifier.

To set the configuration ID attributes, enter the following command in root view:

```
root> ethernet mstp set configuration-name <configuration-name> revision-level <revision-level>
```

To display the configuration ID attributes, enter the following command in root view:

```
root> ethernet mstp show-config-id
```

Table 268 MSTP Configuration ID CLI Parameters

Parameter	Input Type	Permitted Values	Description
configuration-name	Text String		The IEEE 802.1Q Configuration Name. The Configuration Name is part of the bridge configuration Identifier.
revision-level	Number	0-65535	The IEEE 802.1Q Revision Level. The Revision Level is part of the bridge configuration Identifier.

Mapping Services to MSTIs (CLI)

By default, all Ethernet services are assigned to MSTI 0 (CIST). You can map Ethernet services to other MSTIs.



Note

All mapping of Ethernet services to MSTP instances (MSTIs) should be performed *before* enabling MSTP.

To assign a service to another MSTI, enter the following command in root view:

```
root> ethernet generalcfg instance-to-service-mapping set service sid <sid> instance-id <instance-id>
```

To assign a range of services to another MSTI, enter the following command in root view:

```
root> ethernet generalcfg instance-to-service-mapping set service sid
<sid> to <sid> instance-id <instance-id>
```

To display the service to MSTI mapping for a specific service, enter the following command in root view:

```
root> ethernet generalcfg instance-to-service-mapping show service sid
<sid>
```

To display the service to MSTI mapping for a range of services, enter the following command in root view:

```
root> ethernet generalcfg instance-to-service-mapping show service sid
<sid> to <sid>
```

Table 269 MSTP Service to MSTI Mapping CLI Parameters

Parameter	Input Type	Permitted Values	Description
sid	Number or Range	Any Ethernet service or range of services configured in the unit.	The service ID.
instance-id	Number	1-16, 4095	The MSTI to which you want to map the service.

The following command assigns Service 1 to MSTI 2:

```
root> ethernet generalcfg instance-to-service-mapping set service sid 1
instance-id 2
```

The following command assigns Services 1 through 10 to MSTI 2:

```
root> ethernet generalcfg instance-to-service-mapping set service sid 1
to 10 instance-id 2
```

The following command displays the service to MSTI mapping for services 1 through 1000:

```
root> ethernet generalcfg instance-to-service-mapping show service sid 1
to 1000
```

Setting the Bridge Level Spanning Tree Parameters (CLI)

The bridge level spanning tree parameters determine most of the bridge MSTP parameters, including parameters that are applied to all bridges when this bridge is acting as the root.

To set the CIST bridge priority, enter the following command in root view:

```
root> ethernet mstp set cist-bridge-priority <cist-bridge-priority>
```

To set the CIST hold time, enter the following command in root view:

```
root> ethernet mstp set cist-bridge-hold-time <cist-bridge-hold-time>
```

To set the CIST maximum age, enter the following command in root view:

```
root> ethernet mstp set cist-bridge-max-age <cist-bridge-max-age>
```

To set the CIST forward delay, enter the following command in root view:

```
root> ethernet mstp set cist-bridge-forward-delay <cist-bridge-forward-delay>
```

To set the CIST Hello Time, enter the following command in root view:

```
root> ethernet mstp set cist-bridge-hello-time <cist-bridge-hello-time>
```

To set the CIST maximum number of hops, enter the following command in root view:

```
root> ethernet mstp set cist-bridge-max-hops <cist-bridge-max-hops>
```

Table 270 MSTP Bridge Level Spanning Tree CLI Parameters

Parameter	Input Type	Permitted Values	Description
cist-bridge-priority	Number	0-61440, in steps of 4096.	Enter a value as the writeable portion of the Bridge ID. This value constitutes the first two octets of the Bridge ID.
cist-bridge-hold-time	Number	10-100	Enter a value (in cs) as the interval length during which no more than two configuration bridge PDUs will be transmitted by this node.
cist-bridge-max-age	Number	600-4000	Enter a value (in cs) that all bridges will use, when this bridge is the root, as the maximum age of MSTP information learned from the network on any port before the information is discarded.
cist-bridge-forward-delay	Number	400-3000	Enter a value (in cs) that all bridges will use, when this bridge is the root, as the speed at which ports change their spanning state when moving towards the Forwarding state. This value determines how long the port stays in Listening state and Learning state. This value is also used when a topology change has been detected and is underway for purposes of aging all dynamic entries in the filtering database.
cist-bridge-hello-time	Number	100-1000	Enter the value (in cs) that all bridges will use, when this bridge is the root, as the Hello Time. The Hello Time determines how often the switch broadcasts its hello message to other switches, and is the same for all MSTIs.
cist-bridge-max-hops	Number	6-40	Enter the value that all bridges will use, when this bridge is the root, as the maximum number of hops allowed for a BPDU within a region before it is discarded.

Setting and Viewing the Bridge Level MSTI Parameters (CLI)

To set the bridge priority for an MSTI, enter the following command in root view:

```
root> ethernet mstp set instance <msti-id> msti-bridge-priority <msti-bridge-priority>
```

To display the bridge parameters of an MSTI, enter the following command in root view:

```
root> ethernet mstp show-msti-attributes instance <msti-id>
```

Table 271 Bridge Level MSTI CLI Parameters

Parameter	Input Type	Permitted Values	Description
instance	Number	1-16	Enter the MSTI ID of the MSTI you want to configure.
msti-bridge-priority	Number	0-61440, in steps of 4096.	The MSTI writeable portion of the Bridge ID.
interface	Variable	eth radio pwe	Enter the type of interface: eth – Ethernet radio – Radio pwe – TDM
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 tdm: 1	The interface you want to configure.
group	Variable	rp1 rp2 rp3 rp4 lag1 lag2 lag3 lag4 mc-abc1 mc-abc2 mc-abc3 mc-abc4	To display bridge parameters for a 1+1 HSB group, a LAG group, or a Multi-Carrier ABC group, use this parameter instead of the interface, slot, and port parameters to identify the group. See: <ul style="list-style-type: none"> Configuring HSB Radio Protection (CLI) Configuring Link Aggregation (LAG) and LACP (CLI) Configuring Multi-Carrier ABC (CLI)

The following command sets the bridge priority for MSTI 15 to 28672:

```
root> ethernet mstp set instance 15 msti-bridge-priority 28672
```

The following command displays the bridge parameters of MSTI 10:

```
root> ethernet mstp show-msti-attributes instance 10
```

Viewing the MSTP Parameters (CLI)

To display the general MSTP parameters, enter the following command in root view:

```
root> ethernet mstp show-gen-attributes
```

Configuring the MSTP Port Parameters (CLI)

This section includes:

- [Configuring and Viewing the CIST Port Parameters \(CLI\)](#)
- [Configuring and Viewing the MSTI Port Parameters \(CLI\)](#)
- [Viewing and Resetting Port BPDU Counters \(CLI\)](#)

Configuring and Viewing the CIST Port Parameters (CLI)

To set the CIST port priority of a port, enter the following command in root view:

```
root> ethernet mstp set interface <interface> slot <slot> port <port>
cist-port-priority <cist-port-priority>
```

To set the CIST port priority of an interface group, enter the following command in root view:

```
root> ethernet mstp set group <group> cist-port-priority <cist-port-
priority>
```

To set the CIST path cost of a port, enter the following command in root view:

```
root> ethernet mstp set interface <interface> slot <slot> port <port>
cist-port-path-cost <cist-port-path-cost>
```

To set the CIST path cost of an interface group, enter the following command in root view:

```
root> ethernet mstp set group <group> cist-port-path-cost <cist-port-
path-cost>
```

To set a port's administrative edge port parameter for the CIST, enter the following command in root view:

```
root> ethernet mstp set interface <interface> slot <slot> port <port>
cist-port-edge-port <cist-port-edge-port>
```

To set an interface group's administrative edge port parameter for the CIST, enter the following command in root view:

```
root> ethernet mstp set group <group> cist-port-edge-port <cist-port-
edge-port>
```

To set a port's MAC Enabled parameter for the CIST, enter the following command in root view:

```
root> ethernet mstp set interface <interface> slot <slot> port <port>
cist-port-mac-enabled <cist-port-mac-enabled>
```

To set an interface group's MAC Enabled parameter for the CIST, enter the following command in root view:

```
root> ethernet mstp set group <group> cist-port-mac-enabled <cist-port-
mac-enabled>
```

To display a port's CIST parameters, enter the following command in root view:

```
root> ethernet mstp show-cist-port-attributes interface <interface> slot
<slot> port <port>
```

To display an interface group's CIST parameters, enter the following command in root view:

```
root> ethernet mstp show-cist-port-attributes group <group>
```

Table 272 CIST Port CLI Parameters

Parameter	Input Type	Permitted Values	Description
interface	Variable	eth radio pwe	Enter the type of interface: eth – Ethernet radio – Radio pwe – TDM
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 tdm: 1	The interface you want to configure.
group	Variable	rp1 rp2 rp3 rp4 lag1 lag2 lag3 lag4 mc-abc1 mc-abc2 mc-abc3 mc-abc4	To configure or display parameters for a LAG group, or a Multi-Carrier ABC group, use this parameter instead of the interface, slot, and port parameters to identify the group. See: <ul style="list-style-type: none"> • Configuring HSB Radio Protection (CLI) • Configuring Link Aggregation (LAG) and LACP (CLI) • Configuring Multi-Carrier ABC (CLI)
cist-port-priority	Number	0-240, in multiples of 16.	The priority contained in the first octet of the two-octet Port ID.
cist-port-path-cost	Number	1-200000000.	The configurable assigned value for the contribution of this port to the path cost of paths towards the spanning tree root. Note: Changing the value of this parameter is considered to be a topology change by the MSTP mechanism.
cist-port-edge-port	Variable	true false	true – The port is considered an edge port in the CIST. false – The port is considered a non-edge port in the CIST.

Parameter	Input Type	Permitted Values	Description
cist-port-mac-enabled	Variable	forceTrue forceFalse auto	<p>forceTrue – The MAC is treated as if it is connected to a point-to-point LAN, regardless of any indications to the contrary that are generated by the MAC entity.</p> <p>forceFalse –The MAC is treated as if it is connected to a non-point-to-point LAN, regardless of any indications to the contrary that are generated by the MAC entity.</p> <p>auto – The MAC Enabled parameter is set to True if the MAC is connected to a point-to-point or full-duplex LAN. The MAC Enabled parameter is set to False if the MAC is connected to a non-point-to-point and half-duplex LAN.</p>

The following command sets the CIST port priority for Ethernet port 2 to 192:

```
root> ethernet mstp set interface eth slot 1 port 2 cist-port-priority 192
```

The following command sets the CIST port priority for HSB protection group 1 to 192:

```
root> ethernet mstp set group rp1 cist-port-priority 192
```

The following command sets the CIST path cost for Ethernet port 1 to 20,000:

```
root> ethernet mstp set interface eth slot 1 port 1 cist-path-cost 20000
```

The following command sets the CIST path cost for LAG 1 to 20,000:

```
root> ethernet mstp set group lag1 cist-path-cost 20000
```

The following command sets radio interface 1 to be an Edge port in the CIST:

```
root> ethernet mstp set interface radio slot 3 port 1 cist-port-admin-edge true
```

The following command sets HSB protection group 1 to be an Edge port in the CIST:

```
root> ethernet mstp set group rp1 cist-port-admin-edge true
```

The following command displays the CIST parameters of radio interface 2:

```
root> ethernet mstp show-cist-port-attributes interface radio slot 1 port 2
```

The following command displays the CIST parameters of LAG 1:

```
root> ethernet mstp show-cist-port-attributes group lag1
```

Configuring and Viewing the MSTI Port Parameters (CLI)

To set the port priority for an MSTI and port, enter the following command in root view:

```
root> ethernet mstp set instance <instance> interface <interface> slot
<slot> port <port> msti-port-priority <msti-port-priority>
```

To set the port priority for an MSTI and an interface group, enter the following command in root view:

```
root> ethernet mstp set instance <instance> group <group> msti-port-
priority <msti-port-priority>
```

To set the path cost for a port in a specific MSTI, enter the following command in root view:

```
root> ethernet mstp set instance <instance> interface <interface> slot
<slot> port <port> msti-port-path-cost <msti-port-path-cost>
```

To set the path cost for an interface group in a specific MSTI, enter the following command in root view:

```
root> ethernet mstp set instance <instance> group <group> msti-port-path-
cost <msti-port-path-cost>
```

To display the MSTI parameters for a specific MSTI and port, enter the following command in root view:

```
root> ethernet mstp show-msti-port-attributes instance <instance>
interface <interface> slot <slot> port <port>
```

To display the MSTI parameters for a specific MSTI and interface group, enter the following command in root view:

```
root> ethernet mstp show-msti-port-attributes instance <instance> group
<group>
```

Table 273 MSTI Port CLI Parameters

Parameter	Input Type	Permitted Values	Description
instance	Number	1-16	Enter the MSTI ID of the MSTI you want to configure.
interface	Variable	eth radio pwe	Enter the type of interface: eth – Ethernet radio – Radio pwe – TDM
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 tdm: 1	The interface you want to configure.

Parameter	Input Type	Permitted Values	Description
group	Variable	rp1 rp2 rp3 rp4 lag1 lag2 lag3 lag4 mc-abc1 mc-abc2 mc-abc3 mc-abc4	To configure or display parameters for a LAG group, or a Multi-Carrier ABC group, use this parameter instead of the interface, slot, and port parameters to identify the group. See: <ul style="list-style-type: none"> • Configuring HSB Radio Protection (CLI) • Configuring Link Aggregation (LAG) and LACP (CLI) • Configuring Multi-Carrier ABC (CLI)
msti-port-priority	Number	0-240, in multiples of 16.	The priority contained in the first octet of the two-octet Port ID.
msti-port-path-cost	Number	1-200000000.	The port's Path Cost parameter for the MSTI. Note: Changing the value of this parameter may cause re-initialization of the MSTI for which the parameter is changed. No other MSTI should be affected.

The following command sets the MSTI port priority for MSTI 14 on Ethernet port 2 to 192:

```
root> ethernet mstp set instance 14 interface eth slot 1 port 2 msti-port-priority 192
```

The following command sets the MSTI port priority for MSTI 14 on LAG 1 to 192:

```
root> ethernet mstp set instance 14 group lag1 msti-port-priority 192
```

The following command sets the MSTI path cost for MSTI 12 on Ethernet port 3 to 20000:

```
root> ethernet mstp set instance 12 interface eth slot 1 port 3 msti-port-path-cost 20000
```

The following command sets the MSTI path cost for MSTI 12 on HSB protection group 1 to 20000:

```
root> ethernet mstp set instance 12 group rp1 msti-port-path-cost 20000
```

The following command displays the MSTI parameters for MSTI 10 and radio interface 1:

```
root> ethernet mstp show-msti-port-attributes instance 10 interface radio slot 1 port 1
```

The following command displays the MSTI parameters for MSTI 10 and LAG 1:

```
root> ethernet mstp show-msti-port-attributes instance 10 group lag1
```

Viewing and Resetting Port BPDU Counters (CLI)

To view the BPDU counters for a port, enter the following command in root view:

```
root> ethernet mstp show-port-counters interface <interface> slot <slot>
port <port>
```

To view the BPDU counters for an interface group, enter the following command in root view:

```
root> ethernet mstp show-port-counters group <group>
```

To reset the BPDU counters, enter the following command in root view:

```
root> ethernet mstp reset-counters
```

Table 274 Port BPDU Counters CLI Parameters

Parameter	Input Type	Permitted Values	Description
interface	Variable	eth radio pwe	Enter the type of interface: eth – Ethernet radio – Radio pwe – TDM
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 tdm: 1	The interface for which you want to display counters.
group	Variable	rp1 rp2 rp3 rp4 lag1 lag2 lag3 lag4 mc-abc1 mc-abc2 mc-abc3 mc-abc4	To display counters for a LAG group, or a Multi-Carrier ABC group, use this parameter instead of the interface, slot, and port parameters to identify the group. See: <ul style="list-style-type: none"> • Configuring HSB Radio Protection (CLI) • Configuring Link Aggregation (LAG) and LACP (CLI) • Configuring Multi-Carrier ABC (CLI)

Configuring LLDP (CLI)

Link Layer Discovery Protocol (LLDP) is a vendor-neutral layer 2 protocol that can be used by a network element attached to a specific LAN segment to advertise its identity and capabilities and to receive identity and capacity information from physically adjacent layer 2 peers. LLDP is a part of the IEEE 802.1AB – 2005 standard that enables automatic network connectivity discovery by means of a port identity information exchange between each port and its peer. Each port periodically sends and also expects to receive frames called Link Layer Discovery Protocol Data Units (LLDPDU). LLDPDUs contain information in TLV format about port identity, such as MAC address and IP address.

LLDP is used to send notifications to the NMS, based on data of the local unit and data gathered from peer systems. These notifications enable the NMS to build an accurate network topology.

This section includes:

- [Configuring the General LLDP Parameters \(CLI\)](#)
- [Displaying the General LLDP Parameters \(CLI\)](#)
- [Configuring LLDP Port Parameters \(CLI\)](#)
- [Displaying the LLDP Local System Parameters \(CLI\)](#)
- [Displaying the LLDP Remote System Parameters \(CLI\)](#)
- [Displaying LLDP Statistics \(CLI\)](#)

Configuring the General LLDP Parameters (CLI)

The Transmit Interval is the interval at which LLDP frames are transmitted.

The time-to-live (TTL) determines the length of time LLDP frames are retained by the receiving device. The TTL is determined by multiplying the Transmit Interval by the TTL Multiplier.

To define the Transmit Interval, enter the following command in root view:

```
root> ethernet lldp tx-interval-set tx-interval <tx-interval>
```

To define the TTL Multiplier, enter the following command in root view:

```
root> ethernet lldp tx-hold-multiplier-set hold-multiplier <hold-multiplier>
```

To define the interval between transmission of LLDP notifications during normal transmission periods, enter the following command in root view:

```
root> ethernet lldp notif-interval-set notif-interval <notif-interval>
```

Table 275 General LLDP CLI Parameters

Parameter	Input Type	Permitted Values	Description
tx-interval	Number	5-3600	The interval, in seconds, at which LLDP frames are transmitted. The default value is 30.
hold-multiplier	Number	2-10	The TTL Multiplier, which is multiplied by the Transmit Interval to determine the TTL, in seconds, of LLDP frames. The default value is 4.
notif-interval	Number	5-3600	The interval, in seconds, between transmission of LLDP notifications during normal transmission periods. The default value is 30.

Displaying the General LLDP Parameters (CLI)

To display the general LLDP parameters, enter the following command in root view:

```
root> ethernet lldp configuration-scalers-show
```

The following information is displayed:

- **Message Tx Interval** - The interval, in seconds, at which LLDP frames are transmitted, as defined by the `ethernet lldp tx-interval-set tx-interval` command. The default value is 30.
- **Message Tx Hold Multiplier** - The TTL Multiplier, as defined by the `ethernet lldp tx-hold-multiplier-set hold-multiplier` command. The TTL Multiplier is multiplied by the Transmit Interval to determine the TTL, in seconds, of LLDP frames. The default value is 4.
- **Reinit Delay** - The minimum time, in seconds, the system waits after the LLDP Admin status becomes Disabled until it will process a request to reinitialize LLDP. In this release, this parameter is set at 2.
- **Notification Interval** - The interval, in seconds, between transmission of LLDP notifications during normal transmission periods, as defined by the `ethernet lldp notif-interval-set notif-interval` command. The default value is 30.
- **Tx Credit Max** - The maximum number of consecutive LLDPDUs that can be transmitted at any one time. In this release, the Tx Credit Max is set at 5.
- **Message Fast Tx** - The interval, in seconds, at which LLDP frames are transmitted during fast transmission periods, such as when the unit detects a new neighbor. In this release, this parameter is set at 1.
- **Message Fast Init** - The initial value used to initialize the variable which determines the number of transmissions that are made during fast transmission periods. In this release, this parameter is set at 4.

The following commands set the Transmit Interval to 50 seconds with a TTL Multiplier of 5. This produces a TTL of 4 minutes and 10 seconds.

```
root> ethernet lldp tx-interval-set tx-interval 50
root> ethernet lldp tx-hold-multiplier-set hold-multiplier 50
```

The following command sets a Notification Interval of 20 seconds:

```
root> ethernet lldp notif-interval-set notif-interval 20
```

Configuring LLDP Port Parameters (CLI)

To define how the LLDP agent operates on a specific port, enter the following command in root view:

```
root> ethernet lldp agent-admin-set interface eth slot <slot> port <port>
agent-admin <agent-admin>
```

To enable or disable LLDP notifications to the NMS on a specific port, enter the following command in root view:

```
root> ethernet lldp agent-notif-enable interface eth slot <slot> port
<port> agent-notif-enable <agent-notif-enable>
```

To display the LLDP agent configuration on all ports, enter the following command in root view:

```
root> ethernet lldp agent-configuration-show
```

The following is a sample output of the ethernet lldp agent-configuration-show command:

```
root> ethernet lldp agent-configuration-show
-----
Interface      |slot|port | Mac DA   | Admin   | Notification | TLV TX
type           |     |     | Identifier| Status  | Enable       |
-----
ethernet      | 1  | 1  | 1        | txAndRx | false       | None
ethernet      | 1  | 2  | 1        | txAndRx | false       | None
ethernet      | 1  | 3  | 1        | disabled| false       | None
ethernet      | 1  | 4  | 1        | txAndRx | false       | None
ethernet      | 1  | 5  | 1        | txAndRx | false       | None
ethernet      | 1  | 6  | 1        | txAndRx | false       | None
-----
root>
```

Table 276 LLDP Port CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	1-6	The port for which you want to configure LLDP.

Parameter	Input Type	Permitted Values	Description
agent-admin Admin Status	Variable	txOnly rxOnly txAndRx disabled	<ul style="list-style-type: none"> • txOnly – The LLDP agent transmits LLDP frames on this port but does not update information about its peer. • rxOnly – The LLDP agent receives but does not transmit LLDP frames on this port. • txAndRx – The LLDP agent transmits and receives LLDP frames on this port (default value). • disabled – The LLDP agent does not transmit or receive LLDP frames on this port.
agent-notif- enable	Variable	true false	<ul style="list-style-type: none"> • true – The agent sends a Topology Change trap to the NMS whenever the system information received from its peer changes. • false – Notifications to the NMS are disabled (default value).

The following commands configure Ethernet port 2 to transmit and receive LLDP frames and to send a Topology Change trap to the NMS whenever the system information of its peer changes:

```
root> ethernet lldp agent-admin-set interface eth slot 1 port 2 agent-
admin txAndRx
root> ethernet lldp agent-notif-enable interface eth slot 1 port 2 agent-
notif-enable true
```

Displaying the LLDP Local System Parameters (CLI)

To display the local unit's unit parameters, as transmitted by the LLDP agents, enter the following command in root view:

```
root> ethernet lldp local-system-scalars-show
```

The following information is displayed:

- **local Chassis Id Subtype** – The type of encoding used to identify the local unit's chassis. In this release, this parameter is always set to MAC Address.
- **local Chassis Id** – The MAC Address of the local unit's chassis.
- **local System Name** – The system name included in TLVs transmitted by the LLDP agent. To define the system name, see. [Configuring Unit Parameters \(CLI\)](#).
- **local System Description** – The system description included in TLVs transmitted by the LLDP agent.

- **Local System Cap Supported** – A bitmap value used to identify which system capabilities are supported on the local system, as included in TLVs transmitted by the LLDP agent. The bitmap is defined by the following parameters:
 - 0 – other
 - 1 – repeater
 - 2 – bridge
 - 3 – wlanAccessPoint
 - 4 – router
 - 5 – telephone
 - 6 – docsisCableDevice
 - 7 – stationOnly
 - 8 – cVLANComponent
 - 9 – sVLANComponent
 - 10 – twoPortMACRelay
- **Local System Cap Enabled** – A bitmap value used to identify which system capabilities are enabled on the local system, as included in TLVs transmitted by the LLDP agent. The bitmap is defined by the following parameters:
 - 0 – other
 - 1 – repeater
 - 2 – bridge
 - 3 – wlanAccessPoint
 - 4 – router
 - 5 – telephone
 - 6 – docsisCableDevice
 - 7 – stationOnly
 - 8 – cVLANComponent
 - 9 – sVLANComponent
 - 10 – twoPortMACRelay

To display the local unit's management information, enter the following command in root view:

```
root> ethernet lldp local-mng-show
```

The following information is displayed:

- **Mng Addr SubType** – The format of the local unit's IP Address. In this release, only IPV4 is supported.
- **Management Address** – The local unit's IP address.
- **Mng Addr Length** – Reserved for future use.
- **Mng Addr IF SubType** – Reserved for future use.
- **Mng Addr IF** – Reserved for future use.
- **Mng Addr OID** – Reserved for future use.

To display the destination MAC address or range of MAC addresses associated with the unit, and their internal index, enter the following command in root view:

```
root> ethernet lldp mac-da-table-show
```

The following information is displayed:

- **LLDP DA Index** – The internal index associated with the unit's destination LLDP MAC address.
- **LLDP DA** – The unit's destination LLDP MAC address.

To display local port parameters, as transmitted by the LLDP agent, enter the following command in root view:

```
root> ethernet lldp local-port-show
```

The following information is displayed:

- **Interface type/slot/port** – The port type, slot number, and port number.
- **Port ID Subtype** – The type of encoding used to identify the port in LLDP transmissions. In this release, this parameter is always set to MAC Address.
- **Port ID** – The port's MAC address.
- **Description** – A text string that describes the port. In this release, this parameter is always set to ethPort.

To display the local unit's management information per port, enter the following command in root view:

```
root> ethernet lldp mng-addr-table-show
```

The following information is displayed:

- **Interface type/slot/port** – The port type, slot number, and port number.
- **Dest Mac Address** – Defines the MAC address associated with the port for purposes of LLDP transmissions.
- **Mng Address subType** – Defines the type of the management address identifier encoding used for the Management Address. In this release, only IPv4 is supported.
- **Management Address** – The unit's IP address.
- **Mng Address Tx Enable** – Indicates whether the unit's Management Address is transmitted with LLDPDUs. In this release, the Management Address is always sent.

Displaying the LLDP Remote System Parameters (CLI)

This section includes:

- [Displaying the LLDP Remote Unit Parameters \(CLI\)](#)
- [Displaying the LLDP Remote Management Data per Port \(CLI\)](#)



Note

Remote information is not displayed for ports that belong to a LAG group.

Displaying the LLDP Remote Unit Parameters (CLI)

To display the peer's LLDP unit parameter information, starting from a specific time, enter the following command in root view. If no time is specified, all data is displayed.

```
root> ethernet lldp agent-remote-table-show agent-start-time <agent-
start-time> interface eth slot <slot> port <port>
```

The following information is displayed:

- **Time Mark** – The time the entry was created.
- **Interface Type/Slot/Port** – The port for which you are displaying data about the peer.
- **Rem Dest Mac Address** – The peer LLDP agent's destination MAC Address.
- **Remote Index** – An arbitrary local integer value used by this agent to identify a particular connection instance, unique only for the indicated peer.
- **Remote Chassis ID subType** – The type of encoding used to identify the peer's chassis.
- **Remote Chassis ID** – An octet string used to identify the peer's chassis.
- **Rem Port ID subType** – The type of port identifier encoding used in the peer's Port ID.
- **Rem Port ID** – An octet string used to identify the port component associated with the peer.
- **Rem Port Description** – A description of the peer's port.
- **Rem System Name** – The peer's system name.
- **Rem System Description** – The peer's system description.



Note

The Rem Port Description, Rem System Name, and Rem System Description fields are not used in the current version.

- **Rem System Cap Supported** – The bitmap value used to identify which system capabilities are supported on the peer. The bitmap is defined by the following parameters:
 - 0 - other
 - 1 - repeater
 - 2 - bridge
 - 3 - wlanAccessPoint

- 4 - router
- 5 - telephone
- 6 - docsisCableDevice
- 7 - stationOnly
- 8 - cVLANComponent
- 9 - sVLANComponent
- 10 - twoPortMACRelay
- **Rem System Cap Enabled** - The bitmap value used to identify which system capabilities are enabled on the peer. The bitmap is defined by the following parameters:
 - 0 - other
 - 1 - repeater
 - 2 - bridge
 - 3 - wlanAccessPoint
 - 4 - router
 - 5 - telephone
 - 6 - docsisCableDevice
 - 7 - stationOnly
 - 8 - cVLANComponent
 - 9 - sVLANComponent
 - 10 - twoPortMACRelay
- **Remote Changes** - Indicates whether there are changes in the peer's MIB, as determined by the variable **remoteChanges**. Possible values are:
 - **True** - Changes have taken place in the peer's MIB since the defined agent-start-time.
 - **False** - No changes have taken place in the peer's MIB since the defined agent-start-time.

Displaying the LLDP Remote Management Data per Port (CLI)

To display remote LLDP management data from a specific port, starting from a specific time, enter the following command in root view. If no time is specified, all data is displayed.

```
root> ethernet lldp agent-remote-mng-show agent-start-time <agent-start-time> interface eth slot <slot> port <port>
```

The following information is displayed:

- **Time Mark** – The time the entry was created.
- **Interface Type/Slot/Port** – The port for which you are displaying data about the peer.
- **Rem Dest Mac Address** – The peer LLDP agent's destination MAC Address.
- **Remote Index** – An arbitrary local integer value used by this agent to identify a particular connection instance, unique only for the indicated peer.
- **Remote Mng Addr subType** – The type of management address identifier encoding used in the associated LLDP Agent Remote Management Address.
- **Remote Mng Address** – The octet string used to identify the management address component associated with the remote system. The purpose of this address is to contact the management entity.

- **Remote Mng IF subType** – The enumeration value that identifies the interface numbering method used for defining the interface number, associated with the remote system. Possible values are:
 - unknown(1)
 - ifIndex(2)
 - systemPortNumber(3)
- **Agent Rem OID** – The OID value used to identify the type of hardware component or protocol entity associated with the management address advertised by the remote system agent.

Table 277 LLDP Local System CLI Parameters

Parameter	Input Type	Permitted Values	Description
interface	Variable	eth radio pwe	Enter the type of interface: eth – Ethernet radio – Radio pwe – TDM
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 management: 1-2 tdm: 1	
agent-start-time	Number	dd-mm-yyyy,hh:mm:ss, where: dd = date mm = month yyyy= year hh = hour mm = minutes ss = seconds	A filter that enables you to view data that was added to the database starting from the defined time.

Displaying LLDP Statistics (CLI)

This section includes:

- [Displaying Statistics Regarding Changes in Peer Unit \(CLI\)](#)
- [Displaying LLDP Transmission Statistics \(CLI\)](#)
- [Displaying LLDP Received Frames Statistics \(CLI\)](#)

Displaying Statistics Regarding Changes in Peer Unit (CLI)

To display statistics about changes reported via LLDP by the remote unit, enter the following command in root view:

```
root> ethernet lldp statistics-scalars-show
```

The following information is displayed:

- **stats Rem Tables Last Change Time** – The time of the most recent change in the remote unit, as reported via LLDP.
- **stats Rem Tables Inserts** – The number of times the information from the remote system has changed.
- **stats Rem Tables Deletes** – The number of times the information from the remote system has been deleted.
- **stats Rem Tables Drops** – Reserved for future use.
- **stats Rem Tables Ageouts** – The number of times the information from the remote system has been deleted from the local unit's database because the information's TTL has expired. The RX Ageouts counter is similar to this counter, but is for specific ports rather than the entire unit.

Displaying LLDP Transmission Statistics (CLI)

To display statistics about LLDP transmissions and transmission errors, enter the following command in root view:

```
root> ethernet lldp statistics-port-tx-show
```

The following information is displayed:

- **LLDP TX Statistics Ifindex** – The index value used to identify the port in LLDP transmissions.
- **LLDP TX Statistics DA ID** – The LLDP MAC address associated with this entry.
- **LLDP TX Statistics Total Frames** – The number of LLDP frames transmitted by the LLDP agent on this port to the destination MAC address.
- **LLDP TX Statistics No. of Length Error** – The number of LLDPDU Length Errors recorded for this port and destination MAC address. If the set of TLVs that is selected in the LLDP local system MIB by network management would result in an LLDPDU that violates LLDPDU length restrictions, then the No. of Length Error statistic is incremented by 1, and an LLDPDU is sent containing the mandatory TLVs plus as many of the optional TLVs in the set as will fit in the remaining LLDPDU length.

Displaying LLDP Received Frames Statistics (CLI)

To display statistics about LLDP frames received by the unit, enter the following command in root view:

```
root> ethernet lldp statistics-port-rx-show
```

The following information is displayed:

- **RX Destination Port** – The index value used to identify the port in LLDP transmissions.
- **RX DA Index** – The index value used to identify the destination MAC address associated with this entry.
- **RX Total Discarded** – The number of LLDP frames received by the LLDP agent on this port, and then discarded for any reason. This counter can provide an indication that LLDP header formatting problems may exist with the local LLDP agent in the sending system or that LLDPDU validation problems may exist with the local LLDP agent in the receiving system.
- **RX Invalid Frames** – The number of invalid LLDP frames received by the LLDP agent on this port while the agent is enabled.
- **RX Valid Frames** – The number of valid LLDP frames received by the LLDP agent on this port.
- **RX Discarded TLVs** – The number of LLDP TLVs discarded for any reason by the LLDP agent on this port.
- **RX Unrecognized TLVs** – The number of LLDP TLVs received on the given port that are not recognized by LLDP agent.
- **RX Ageouts** – The number of age-outs that occurred on the port. An age-out is the number of times the complete set of information advertised by the remote system has been deleted from the unit's database because the information timeliness interval has expired. This counter is similar to the **LLDP No. of Ageouts** counter, except that it is per port rather than for the entire unit. This counter is set to zero during agent initialization. This counter is incremented only once when the complete set of information is invalidated (aged out) from all related tables on a particular port. Partial ageing is not allowed.

Chapter 21: TDM Services and Interfaces (CLI)

This section includes:

- [TDM Overview \(CLI\)](#)
- [Configuring the Unit to Operate in ANSI Mode \(CLI\)](#)
- [Configuring TDM Cards and Interfaces \(CLI\)](#)
- [Configuring Native TDM Trails \(CLI\)](#)
- [Configuring TDM Pseudowire Services \(CLI\)](#)
- [Displaying TDM PMs \(CLI\)](#)

Related topics:

- [Performing TDM Diagnostics \(CLI\)](#)

TDM Overview (CLI)

PTP 820G and PTP 820F provides integrated support for transportation of TDM (E1/DS1) services with an integrated E1/DS1 interface.

Two types of TDM services are supported using the same hardware:

- Native TDM trails
- TDM Pseudowire services (enabling interoperability with third party packet/PW equipment)

PTP 820G and PTP 820F also offers hybrid Ethernet and TDM services. Hybrid services can utilize either Native TDM or pseudowire.

Hybrid Ethernet and TDM services can also be transported via cascading interfaces. This enables the creation of links among multiple units in a node for multi-carrier and multi-directional applications

Configuring the Unit to Operate in ANSI Mode (CLI)

By default, the TDM interfaces in a PTP 820G or PTP 820F unit are set to operate according to the ETSI standard, in E1 mode.

To change the TDM interfaces to operate according to the ANSI (FCC) standard (DS1), enter the following command in root view.

**Note**

This command results in system reset and restores the default configuration.

```
root> platform management set tdm-interfaces-standard ansi
```

Configuring TDM Cards and Interfaces (CLI)

This section includes:

- [Configuring the E1/DS1 Interface \(CLI\)](#)
- [Configuring the E1/DS1 Parameters \(CLI\)](#)

Configuring the E1/DS1 Interface (CLI)

To enable the slot, enter the following command in root view:

```
root> platform shelf-manager admin set slot <slot> state enable
```

To enable the E1/DS1 interface, enter the following command in root view:

```
root> platform if-manager set interface-type tdm slot <slot> port <port>
admin <admin>
```



Note

To enable or disable an E1/DS1 interface, use the `pwe3 tdm enable slot` command. See [Configuring the E1/DS1 Parameters \(CLI\)](#).

Table 278 TDM Slot Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	For TDM cards in an expansion slot: 2-3 For the fixed E1/DS1 interface: 1	
type	Variable	LIC-T16-ACR LIC-T155-ACR	LIC-T16-ACR – A 16xE1/DS1 TDM card. LIC-T155-ACR – A 1 x ch-STM-1/OC-3 card.
port	Number	<ul style="list-style-type: none"> • STM-1: 1-63 • OC-3: 1-84 	The physical port number of the port.
admin	Variable	up down	Enter up to enable the port or down to disable the port.

To verify the parameters of the slot you just configured, enter the following command:

```
root> pwe3 pwc config show slot 3
```

Configuring the E1/DS1 Parameters (CLI)

You can use the following commands to configure the E1/DS1 parameters. You must enter these commands from pwe3 view:

```

root> pwe3
pwe3>
pwe3> pwe3 tdm config modify port slot <slot> tdm-port <tdm-port> line-
type <line-type> line-coding <line-coding> channelization
<channelization> timing-mode <timing-mode> clk-src-ref <clk-src-ref> clk-
src-ref-port <clk-src-ref-port> idle-code <idle-code> cable-length
<cable-length>
pwe3> pwe3 tdm enable slot <slot> tdm-port <tdm-port>

```

Table 279 E1/DS1 Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	For TDM cards in an expansion slot: 2-3 For the fixed E1/DS1 interface: 1	
tdm-port	Number	<ul style="list-style-type: none"> The fixed E1/DS1 interface or an LIC-T16 (16 x E1/DS1): 1-16 If the card is an LIC-T155 (1x ch-STM-1/OC-3): STM-1: 1-63 OC-3: 1-84 	The physical port number of the port.
line-type	Variable	unframed	The line type of this port. In this release, unframed is the only available option.
line-coding	Variable	hdb3-b8zs ami	The line coding for this port. Options are: hdb3-b8zs – hdb3 coding for E1, b8zs coding for DS1. ami – Only relevant for DS1 ports.
channelization	Variable	disable	Channelization is only relevant for CESoP mode, which is planned for future release.

Parameter	Input Type	Permitted Values	Description
timing-mode	Variable	loop absolute clock-recovery	<p>The clock reference for the outgoing TDM signal from the port. Options are:</p> <p>loop – The output signal uses the clock of the incoming lines. By default, each port is its will take itself as a reference.</p> <p>absolute – All ports are synchronized to a single common clock, as defined by the <code>clk-src-ref</code> parameter.</p> <p>clock-recovery – Adaptive Clock Recovery. Clock information is included in the TDM data stream at the point where the data is frameized. Extra information may be located in an RTP header that can be used to correct frequency offsets. The clock information is extracted at the point where the frames are received and reconverted to TDM. The extracted clock information is used for the reversion to TDM. If you configure the <code>timing-mode</code> as clock-recovery, you must use the <code>clk-src-ref-port</code> parameter to configure the clock source reference port.</p>
clk-src-ref	Variable	none front-panel sys-ref-clk	<p>If <code>timing-mode</code> is set to absolute, use this parameter to configure the clock source reference for the port. Options are:</p> <p>front-panel – An external clock reference from a dedicated front panel clock interface. This can be: An E1/DS1 line, or A Digital 2.048MHz/1.544MHz input</p> <p>sys-ref-clk – Clock is taken from the system reference clock defined for the entire unit.</p> <p>If the <code>timing-mode</code> parameter is set to loop or clock-recovery, set this parameter to none.</p>

Parameter	Input Type	Permitted Values	Description
clk-src-ref-port	Number	0-16	The recovery clock source reference port. If <code>timing-mode</code> is set to <code>loop</code> or <code>clock-recovery</code> , select the clock source reference for the port. By default, each port is its will take itself as a reference. Select a different port only if more than 16 clock domains are being used. If <code>timing-mode</code> is set to <code>absolute</code> , this parameter must be set to 0.
idle-code	Number	0-255	The value to be transmitted on this port for unused time slots.
cable-length	Variable	fixed-or-0-133ft 133-266ft/266-399ft 399-533ft 533-655ft	Reserved for future use.

The following commands configure and enable port 9 in the E1/DS1 interface.

```
pwe3> pwe3 tdm config modify port slot 1 tdm-port 9 line-type unframed
line-coding hdb3-b8zs channelization disable timing-mode loop clk-src-ref
none clk-src-ref-port 9 idle-code 0 cable-length fixed-or-0-133ft
pwe3> pwe3 tdm enable slot 1 tdm-port 9
```

To verify the configuration of the TDM port you use configured, enter the following command:

```
pwe3> pwe3 tdm config show slot 1 tdm-port 9
```

Configuring Native TDM Trails (CLI)

To configure native TDM services, it is recommended to use the Web EMS's simple, step-by-step workflow, which guides you through the configuration process. See [Configuring Native TDM Trails](#).

Configuring TDM Pseudowire Services (CLI)

To configure pseudowire services, it is recommended to use the Web EMS TDM Pseudowire Services interface, which provides a step-by-step workflow based on pre-configured pseudowire settings. See [Configuring TDM Pseudowire Services](#).

To manually configure the pseudowire parameters and services, follow the instructions in this section.

This section includes:

- [Configuring Pseudowire Tunnels \(CLI\)](#)
- [Configuring Pseudowire Profiles \(CLI\)](#)
- [Configuring Ethernet Services for TDM Traffic \(CLI\)](#)
- [Configuring Pseudowire Path Protection and Dual Homing \(CLI\)](#)
- [Manually Configuring Pseudowire Services \(CLI\)](#)

Configuring Pseudowire Tunnels (CLI)

Each TDM service must include an encapsulation tunnel to determine how traffic over the service passes through the network. In this version, encapsulation must use the MEF-8 protocol.

For PTP 820G: You can configure up to 32 tunnels per unit.

To configure a tunnel, you will need the MAC address of the TDM interface at the remote side of the tunnel. TDM tunnel configuration must be performed from pwe3 view:

```
root> pwe3
pwe3>
```



Note

UDP/IP and MPLS support are planned for future release.

To configure a TDM tunnel, enter the following commands:

```
pwe3> pwe3 tunnel eth add slot <slot> id <id> remote-mac-addr <remote-
mac-addr>
pwe3> pwe3 tunnel vlan modify slot <slot> tunnel <id> type <type> vid
<vid> p-bits <p-bits>
pwe3> pwe3 tunnel enable slot <slot> id <id>
```

To display the status of all tunnels configured on the unit, enter the following command in pwe3 view:

```
pwe3> pwe3 tunnel status show
```

The following is an example of a pwe3 tunnel status show command and its output:

```

root> pwe3
pwe3> pwe3 tunnel status show
=====
Slot Number: 1
PSN Tunnel Id: 1
Operational Status: down
Source MAC Address: 0:a:25:0:28:e8
Actual Remote MAC Address: 0:0:0:0:0:0
=====

Slot Number: 1
PSN Tunnel Id: 2
Operational Status: up
Source MAC Address: 0:a:25:0:28:e8
Actual Remote MAC Address: 0:a:25:0:32:ea

```

To display the status of a specific tunnel, enter the following command in pwe3 view:

```
pwe3> pwe3 tunnel status show slot <slot> id <id>
```

The following is an example of a pwe3 tunnel status show slot <slot> id <id> command and its output:

```

root> pwe3
pwe3> pwe3 tunnel status show slot 1 id 1
=====
Slot Number: 1
PSN Tunnel Id: 1
Operational Status: down
Source MAC Address: 0:a:25:0:28:e8
Actual Remote MAC Address: 0:0:0:0:0:0
pwe3>

```

Table 280 Pseudowire Tunnel CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
id	Number	1-168	A unique ID that identifies the tunnel.
remote-mac-addr	Six groups of two hexadecimal digits	Any valid MAC address	The MAC address of the interface at the other site of the link. This is only relevant for Ethernet (MEF-8) tunnels.
type	Variable	none s-type c-type	The outer VLAN type used by the tunnel.
vid	Number	0-4094	A VLAN ID (1-4094). This value will be assigned to frames passing through the tunnel.
p-bits	Number	0-7	A p-bit value. This value will be assigned to frames passing through the tunnel.

The following commands create and enable tunnel 7, from the E1/DS1 interface to MAC address 00:0a:25:00:25:5B:

```
pwe3> pwe3 tunnel eth add slot 1 id 7 remote-mac-addr 00:0a:25:00:25:5B
pwe3> pwe3 tunnel vlan modify slot 1 tunnel 7 type c-type vid 4070 p-bits
5
pwe3> pwe3 tunnel enable slot 1 id 7
```

To verify the configuration details of the tunnel you just created, enter the following command:

```
pwe3> pwe3 tunnel config show slot 1 id 7
```

To verify the tunnel status and MAC addresses of the tunnel you just created, enter the following command:

```
pwe3> pwe3 tunnel status show slot 1 id 7
```

**Note**

These examples assume that all hops between the unit you are configuring and the TDM interface on the remote unit are already configured. If they are not configured, you can still configure the tunnel, but the verification commands may produce unexpected results.

To configure a pseudowire tunnel on which the remote MAC address is dynamically learned the remote-mac-addr parameters must be configured to 00:00:00:00:00:00. In this case the remote MAC address is learned through CFM protocol. You have to create a Maintenance Domain (MD), a Maintenance Association (MA), to enable CCM Messages and to assign an MA to the tunnel. See [Adding a Maintenance Domain \(MD\) \(CLI\)](#), [Adding a Maintenance Association \(MA\) \(CLI\)](#), [Enabling CCM Messages \(CLI\)](#), and [Assigning an MA to a TDM Tunnel \(CLI\)](#).

The following commands create and enable tunnel 7, from the fixed E1/DS1 interface with the remote MAC address dynamically learned:

```
pwe3> pwe3 tunnel eth add slot 1 id 7 remote-mac-addr 00:00:00:00:00:00
pwe3> pwe3 tunnel vlan modify slot 1 tunnel 7 type c-type vid 4070 p-bits
5
pwe3> pwe3 tunnel enable slot 1 id 7
```

Configuring Pseudowire Profiles (CLI)

Each TDM service must include a profile. The profile determines the behavior of the service, including the buffer, payload suppression, and other parameters. A profile can be used by multiple services. You can configure up to 64 TDM profiles. TDM profile configuration must be performed from pwe3 view:

```
root> pwe3
pwe3>
```

To create and configure a TDM profile, use the following commands:

```
pwe3> pwe3 pw-profile add id <id>
pwe3> pwe3 pw-profile basic-params modify id <id> payload-size <payload-size> jitter-buffer-depth <jitter-buffer-depth> payload-suppression <payload-suppression>
```

Table 281 Pseudowire Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
id	Number	1-64	A unique ID that identifies the profile.
payload-size	Number	1-64	The number of times E1 should be sampled for each Ethernet packet.
jitter-buffer-depth	Number	1-32	The desired jitter buffer depth (in milliseconds). This is used to enable the network to accommodate PSN-specific packet delay variation. The jitter buffer can be increased if the network experiences a higher-than-normal level of jitter.
payload-suppression	Variable	enable disable	Enables or disables payload suppression. When enabled, the payload is suppressed upon incoming TDM failure.

The following commands add TDM profile 5, with a payload size of 2, jitter buffer depth of 4 milliseconds, and payload suppression disabled:

```
pwe3> pwe3 pw-profile add id 5
pwe3> pwe3 pw-profile basic-params modify id 5 payload-size 2 jitter-
buffer-depth 4 payload-suppression disable
```

To verify the details of the profile you just created, enter the following command:

```
pwe3> pwe3 pw-profile show id 5
```

Configuring Ethernet Services for TDM Traffic (CLI)

You can configure traffic services for TDM traffic using the same commands and parameters used for Ethernet services. For instructions, refer to [Ethernet Services Overview \(CLI\)](#).

The following commands add a multipoint service with an EVC ID of PW-Slot12_EVC-70. This service has the following service points:

- A service point on a 1+1 HSB group (rp3), with an s-tag interface type and VLAN 4070 classified to the service point.
- A service point on the E1/DS1 interface, port 1, with a dot1q interface type and VLAN 4070 classified to the service point.

```
root> ethernet service add type mp sid 970 admin operational evc-id PW-
Slot12_EVC-70
root> ethernet service sid 970
service[970]>
service[970]> sp add sp-type snp int-type s-tag spid 1 group rp3 vlan
4070 sp-name PwtoRadio_SP4070-1
service[970]> sp add sp-type sap int-type dot1q spid 2 interface pwe slot
1 port 1 vlan 4070 sp-name PwtoRadio_SP4070-1
service[970]> exit
```

Configuring Pseudowire Path Protection and Dual Homing (CLI)

Pseudowire path protection enables the operator to define two separate network paths for a single TDM service. Two different kinds of path protection are available, each suitable for a different network topology:

- 1:1 Pseudowire path protection is suitable for ring networks that consist entirely of PTP 820G and/or PTP 820G and/or PTP 820F elements with two end-point interfaces for the TDM trail.
- 1+1 Dual Homing Pseudowire path protection is suitable for networks in which the PTP 820G and/or PTP 820F elements are set up as a chain connected to the third party networks at two different sites. The ring is closed on one side by the PTP 820G and/or PTP 820F elements, and on the other by third party equipment supporting SNCP. In this case, there are three end-point interfaces in the PTP 820G and/or PTP 820F section of the network.

Both types of pseudowire path protection requires the use of SOAM (CFM) at both end-points. The TDM module sends two data streams to the CPU.

In 1:1 path protection, only the data stream for the active path contains actual traffic. Both data streams contain continuity messages (CCMs). This enables the TDM module to monitor the status of both paths without doubling the amount of data being sent over the network. In 1+1 Dual Homing path protection, both data streams contain actual traffic and CCMs. In both types of path protection, the TDM module determines when a switchover is necessary based on the monitored network status.

In order to achieve path protection, different provisioning should be made for the Ethernet service corresponding to each of the two data streams. In order to do this, it is recommended to map the corresponding Ethernet services to MSTP instance number 4095, which is meant for Traffic Engineering (ports are always forwarding) and to map the two different transport VLANs over two different paths.

Pseudowire path protection uses CFM to monitor the network paths. Because SOAM (CFM) is configured on the TDM module level, the TDM module can determine the status of the entire network path, up to and including the actual TDM interface.

This section describes the CLI commands required to configure CFM and tunnel groups, which are basic components of a pseudowire path protection configuration. This is followed by a sample configuration, which illustrates how to perform all the steps required to configure a TDM service with path protection.

This section includes:

- [Adding a Maintenance Domain \(MD\) \(CLI\)](#)
- [Adding a Maintenance Association \(MA\) \(CLI\)](#)
- [Enabling CCM Messages \(CLI\)](#)
- [Assigning an MA to a TDM Tunnel \(CLI\)](#)
- [Configuring a Pseudowire Tunnel Group \(CLI\)](#)
- [Configuring a Network Edge Node in a Dual Homing Configuration \(CLI\)](#)

Adding a Maintenance Domain (MD) (CLI)

You must define at least one MD. To define an MD, enter the following command in pwe3 view:

```
pwe3> pwe3 soam md add slot <slot> id <id> name <name> level <level>
```

The following command assigns MD 1 to the E1/DS1 interface. The name of the MD is "test", and its MD level is 5:

```
pwe3> pwe3 soam md add slot 1 id 1 name test level 5
```

Table 282 Pseudowire OEM MD CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
id	Number	1-8	An ID that identifies the MD. This ID is unique per slot.
name	Text String		Assigns a name to the MD, for informational purposes.
level	Number	1-7	The maintenance level of the MD. The maintenance level ensures that the CFM frames for each domain do not interfere with each other. Where domains are nested, the encompassing domain must have a higher level than the domain it encloses. The maintenance level is carried in all CFM frames that relate to that domain.

Adding a Maintenance Association (MA) (CLI)

Maintenance Associations (MAs) define Maintenance End Points (MEPs), and perform continuity checks by sending Continuity Check Messages (CCMs) between the MEPs. This is the mechanism by which PTP 820G or PTP 820F monitors the status of both paths in a protected TDM service and determines when a switchover is necessary.

For PTP 820F and PTP 820G, you can configure up to 64 MAs.

Each of the two TDM tunnels that make up a path-protected TDM service must be assigned its own MA. Each MA must have a unique local MEP ID and a unique remote MEP ID. Each MA must also include a defined VLAN, which corresponds to the VLAN that will be assigned to the TDM tunnel associated with the MA.

To add an MA, enter the following command in pwe3 view:

```
pwe3> pwe3 soam ma add slot <slot> id <id> name <name> md-id <md-id>
local-mep <local-mep> remote-mep <remote-mep> vlan-type <vlan-type> vid
<vid>
```

Table 283 Pseudowire OEM MA CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
id	Number	1-168	A unique ID that identifies the MA.
md-id	Number	Any configured MD ID.	The MD to which the MA belongs.
local-mep	Number	1-231	A unique ID for the local MEP.
remote-mep	Number	1-231	A unique ID for the remote MEP.
vlan-type	Variable	none s-type c-type	The outer VLAN type assigned to the tunnel to which the MA will be attached.
vid	Number	0-4094	A VLAN ID (1-4094). The VLAN assigned to the tunnel to which the MA will be attached.

To display the status of all MAs configured on the unit's TDM module, enter the following command in pwe3 view:

```
pwe3> pwe3 soam ma status show
```

The following is an example of a pwe3 soam ma status show command and its output:

```

root> pwe3
pwe3> pwe3 soam ma status show

=====
Slot Number: 1
Maintenance Association Id: 1
Remote MEP MAC Address: ff:ff:ff:ff:ff:ff
Defects:
rmep-ccm

=====

Slot Number: 1
Maintenance Association Id: 2
Remote MEP MAC Address: 0:a:25:0:32:ea
Defects:
no-alarm

=====

```

To display the status of a specific MA, enter the following command in pwe3 view:

```
pwe3> pwe3 soam ma status show slot <slot> id <id>
```

The following is an example of a pwe3 soam ma status show slot <slot> id <id> command and its output:

```

root> pwe3
pwe3> pwe3 soam ma status show slot 1 id 1

=====
Slot Number: 1
Maintenance Association Id: 1
Remote MEP MAC Address: ff:ff:ff:ff:ff:ff
Defects:
rmep-ccm
pwe3>

```

The following command creates MA 1 on the E1/DS1 interface. This MA includes a local MEP with ID 200 and a remote MEP with ID 1. This MA will later be assigned to a TDM tunnel using C-Type VLAN 100:

```
pwe3> pwe3 soam ma add slot 1 id 1 name MA1 md-id 1 local-mep 200 remote-
mep 1 vlan-type c-type vid 100
```

Enabling CCM Messages (CLI)

In order for an MA to check the connectivity of the network path, you must enable CCM on the MA. To enable CCM, enter the following command in pwe3 view:

```
pwe3> pwe3 soam ma ccm enable slot <slot> id <id>
```

Table 284 Pseudowire OEM CCM Messages CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
id	Number	The ID of any configured MA.	The MA on which you want to enable CCM.

The following command enables CCM on MA 1 on the E1/DS1 card:

```
pwe3> pwe3 soam ma ccm enable slot 4 id 1
```

Assigning an MA to a TDM Tunnel (CLI)

Once you have created at least two MAs and at least two TDM tunnels, you must assign the MAs to the tunnels. To assign an MA to a TDM tunnel, enter the following command in pwe3 view:

```
pwe3> pwe3 tunnel ma-id modify slot <slot> tunnel <tunnel> ma-id <ma-id>
```

Table 285 Assigning MA to TDM Tunnel CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
tunnel	Number	Any configured TDM tunnel ID.	The ID of the TDM tunnel.
ma-id	Number	Any configured MA ID.	The MA you want to assign to the tunnel.

The following command assigns MA 1 to TDM tunnel 1 on the E1/DS1 card:

```
pwe3> pwe3 tunnel ma-id modify slot 1 tunnel 1 ma-id 1
```

Configuring a Pseudowire Tunnel Group (CLI)

TDM 1:1 and 1+1 Dual Homing path protection are implemented by combining two pseudowire tunnels into a single tunnel group. One of the tunnels in the group is designated as the primary tunnel. The other tunnel is designated as the secondary tunnel.

CCM messages are sent from the TDM module to the CPU via both tunnels. In 1:1 path protection, only the primary tunnel sends actual traffic. In 1+1 Dual Homing path protection, both tunnels send traffic.

The CPU monitors both paths using the CCM messages, and determines when to perform a switchover from the primary tunnel to the secondary tunnel.

Path protection can be configured to operate in revertive mode. In revertive mode, the system monitors the availability of the protected path at all times. After switchover to the protecting path, once the active path is operational and available without any alarms, the system waits for the duration of the user-configured Wait to Restore (WTR) time and then, if the active path remains operational and available, initiates a revertive protection switch. A single WTR time is configured for all the TDM pseudowire services in the system. However, services with path protection can be configured individually as revertive or non-revertive. You can configure this in the revertive-admin parameter of the command for creating a tunnel group (see below).

**Note**

TDM pseudowire services with 1:1 path protection that were configured using software versions prior to T7.9 are non-revertive.

To set the WTR time for TDM pseudowire services with revertive path protection, enter the following command in root view:

```
root> platform wtr-timer set <wtr-timer>
```

To display the WTR time for TDM pseudowire services with revertive path protection, enter the following command in root view:

```
root> platform wtr-timer show
```

To create a Pseudowire tunnel group, enter the following command in pwe3 view:

```
pwe3> pwe3 tunnel-group add slot <slot> id <id> primary-id <primary-id>
secondary-id <secondary-id> lplus1 <lplus1> revertive-admin <revertive>
```

To enable a Pseudowire tunnel group, enter the following command in pwe3 view:

```
pwe3> pwe3 tunnel-group enable slot <slot> id <id>
```

Table 286 Pseudowire Tunnel Group CLI Parameters

Parameter	Input Type	Permitted Values	Description
wtr-timer	Number	10-720	The WTR time, in seconds, for TDM pseudowire services with revertive path protection.
slot	Number	1	
id	Number	1-84	The ID of the TDM tunnel group.
primary-id	Number	Any configured TDM tunnel.	The tunnel you want to assign as the primary tunnel.
secondary-id	Number	Any configured TDM tunnel.	The tunnel you want to assign as the secondary tunnel.

Parameter	Input Type	Permitted Values	Description
1plus1	Variable	enable disable	<p>Determines whether the tunnel group is configured for 1:1 path protection or 1+1 Dual Homing path protection:</p> <ul style="list-style-type: none"> enable – The tunnel group will perform 1+1 Dual Homing path protection. disable – The tunnel group will perform 1:1 path protection. <p>If you do not include this parameter in the command, the tunnel group will be configured as a 1:1 path protection group.</p>
revertive	Variable	enable disable	Determines whether services using the tunnel group will use revertive mode.

The following commands create and enable tunnel group 1 on the E1/DS1 interface. This group will perform 1:1 path protection. In this tunnel group, tunnel 1 is the primary tunnel and tunnel 2 is the secondary tunnel. Revertive mode is disabled for this tunnel group.

```
pwe3> pwe3 tunnel-group add slot 1 id 1 primary-id 1 secondary-id 2
revertive-admin disable
pwe3> pwe3 tunnel-group enable slot 1 id 1
```

The following commands set the revertive timer to 20 seconds, and create and enable tunnel group 2 on the E1/DS1 interface. This group will perform 1+1 Dual Homing path protection. In this tunnel group, tunnel 1 is the primary tunnel and tunnel 2 is the secondary tunnel. Revertive mode is enabled for this group.

```
root> platform wtr-timer set 20
root> pwe3
pwe3> pwe3 tunnel-group add slot 1 id 2 primary-id 1 secondary-id 2
1plus1 enable revertive-admin enable
pwe3> pwe3 tunnel-group enable slot 1 id 2
```

To display the status of all tunnel groups configured on the unit, enter the following command in pwe3 view:

```
pwe3> pwe3 tunnel-group status show
```

The following is an example of a pwe3 soam ma status show command and its output:

```

root> pwe3
pwe3> pwe3 tunnel-group status show
=====
Slot Number: 1
PSN Tunnel Group Id: 1
Operational Status: up
Active PSN Tunnel: secondary
Protection Switches: 3
=====
Slot Number: 1
PSN Tunnel Group Id: 2
Operational Status: up
Active PSN Tunnel: primary
Protection Switches: 0

```

To display the status of a specific tunnel group, enter the following command in pwe3 view:

```
pwe3> pwe3 tunnel-group status show slot <slot> id <id>
```

Table 287 Pseudowire Tunnel Group Display CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
id	Number	1-84	An ID that identifies the tunnel group. This ID is unique per slot.

The following is an example of a pwe3 tunnel-group status show slot <slot> id <id> command and its output:

```

root> pwe3
pwe3> pwe3 tunnel-group status show slot 1 id 1
=====
Slot Number: 1
PSN Tunnel Group Id: 1
Operational Status: up
Active PSN Tunnel: secondary
Protection Switches: 3
pwe3>

```

Configuring a Network Edge Node in a Dual Homing Configuration (CLI)

For a tunnel that is to be used as the network edge node in a 1+1 Dual Homing configuration, you must use the following command in pwe3 view to enable the propagation of defects to the service's end point:

```
pwe3> pwe3 tunnel prop-tdm-defect-to-soam admin enable slot <slot> id <tunnel>
```

**Note**

Since the edge node itself is part of the protected or protecting path, the node itself is essentially unprotected and you do not need to configure a tunnel group for the node.

Table 288 Network Edge Node for Dual Homing CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
tunnel	Number	Any configured TDM tunnel ID.	The ID of the TDM tunnel.

Manually Configuring Pseudowire Services (CLI)

**Note**

It is recommended to use the Web EMS TDM Pseudowire Services interface, which provides a step-by-step workflow based on pre-configured pseudowire settings. See [Configuring TDM Pseudowire Services](#).

For PTP 820F and PTP 820G, you can configure up to 16 TDM pseudowire services. Pseudowire service configuration must be performed from pwe3 view:

```
root> pwe3
pwe3>
```

**Caution**

Once a profile, tunnel, or bundle has been assigned to a service, you cannot modify that profile, tunnel, or bundle until you first disable the service.

To configure and enable a pseudowire service, use the following commands:

```
pwe3> pwe3 pws satop-eth add slot <slot> id <id> tdm-port <tdm-port> pw-
profile-id <pw-profile-id> psn-tunnel-id <psn-tunnel-id> src-ecid <src-
ecid> dst-ecid <dst-ecid> cr-master-pws <cr-master-pws> protected
<protected>
pwe3> pwe3 pws enable slot <slot> id <id>
```

To display the status of all pseudowire services, enter the following command in pwe3 view:

```
pwe3> pwe3 pws status show slot <slot>
```

The following is an example of a pwe3 pws status show slot command and its output:

```

root> pwe3
pwe3> pwe3 pws status show slot 1
=====
Slot Number: 1
SW Version: 2.10.18016
Ethernet Source MAC Address: 0:a:25:0:28:e8
Alarms:
Front Panel Clock LOS: cleared
Card Reset: cleared
Configuration Mismatch: cleared
Card Communication Disruption: cleared
Host Communication Disruption: cleared
HW Failure: cleared
LEDs:
Front Panel Clock Output: gray
Front Panel Clock Input: gray

```

To display the status of a specific pseudowire service, enter the following command in pwe3 view:

```
pwe3> pwe3 pws status show slot <slot> id <id>
```

The following is an example of a `pwe3 tunnel status show slot <slot> id <id>` command and its output:

```

root> pwe3
pwe3> pwe3 pws status show slot 1 id 1
=====
Slot Number: 1
PW Service Id: 1
Operational Status: down
Transmitted Packets: 83653910
Received Packets: 0
Transitions Normal LOPS: 1
Jitter Buffer Overruns: 0
Max Jitter Buffer Deviation: 900
Current Min Jitter Buffer: 0
Current Max Jitter Buffer: 0
Alarms:
Misconnection: cleared
Loss of Frames: raised
Late Frame: cleared
Malformed Frames: cleared
Jitter Buffer Overrun: cleared

```

Table 289 Pseudowire Service CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
id	Number	1-16	A unique ID that identifies the service.
tdm-port	Number	1-16	The port used with the service.

Parameter	Input Type	Permitted Values	Description
pw-profile-id	Number	1-64	The pseudowire profile used with the service. The pseudowire profile determines the behavior of the service, including the buffer, payload suppression, and other parameters. A profile can be used by multiple services.
psn-tunnel-id	Number	1-168	The pseudowire tunnel used with the service. The tunnel determines how traffic over the service passes through the network. In this version, encapsulation must use the MEF-8 protocol. Up to 16 tunnels can be configured for each TDM card in the chassis. If the <code>protected</code> parameter is set to <code>yes</code> , the <code>psn-tunnel-id</code> parameter identifies a tunnel group rather than a tunnel.
src-ecid	Number	1-1048575	The source ECID for the Ethernet tunnel.
dst-ecid	Number	1-1048575	The destination ECID for the Ethernet tunnel.
cr-master-pws	Variable	yes no	Enter <code>yes</code> to use this service as a reference for clock recovery. Otherwise, enter <code>no</code> .
protected	Variable	yes no	Enter <code>yes</code> to create a protected path service. Otherwise, enter <code>no</code> . If this parameter is set to <code>yes</code> , the <code>psn-tunnel-id</code> parameter identifies a tunnel group rather than a tunnel, and the service is configured as a path-protected service. For more information on pseudowire path protection, refer to Configuring Pseudowire Path Protection and Dual Homing (CLI) .

The following commands configure and enable service 12, on the E1/DS1 interface:

```
pwe3> pwe3 pws satop-eth add slot 1 id 12 tdm-port 9 pw-profile-id 5 psn-
tunnel-id 7 src-ecid 31 dst-ecid 131 cr-master-pws no protected no
pwe3> pwe3 pws enable slot 1 id 12
```

To verify the configuration of the service you just created, enter the following command:

```
pwe3> pwe3 pws config show slot 1 id 12
```

Displaying TDM PMs (CLI)



Note

Native TDM and pseudowire service PMs can only be displayed via the Web EMS. See [Displaying Native TDM Service PMs](#) and [Displaying Pseudowire Service PMs](#).

To display PMs for the E1/DS1 interface measured at 15 minute intervals, enter the following command in root view:

```
root> pwe3 pws line-pm-15 show slot <slot> id <id>
```

To display PMs for the E1/DS1 interface measured at daily intervals, enter the following command in root view:

```
root> pwe3 pws line-pm-24 show slot <slot> id <id>
```

Table 290 E1/DS1 PMs CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
id	Number	1-16	The interface

Chapter 22: Synchronization (CLI)

This section includes:

- [Configuring the Sync Source \(CLI\)](#)
- [Configuring the Outgoing Clock \(CLI\)](#)
- [Configuring SSM Messages \(CLI\)](#)
- [Configuring the Revertive Timer \(CLI\)](#)
- [Displaying Synchronization Status and Parameters \(CLI\)](#)
- [Configuring 1588 Transparent Clock \(CLI\)](#)
- [Configuring 1588 Boundary Clock \(CLI\)](#)

**Note**

By default, the unit is set to operate according to the ETSI standard. For instructions on configuring the system to operate according to the ANSI (FCC) standard (DS1), see [TDM Overview \(CLI\)](#).

Configuring the Sync Source (CLI)

Frequency signals can be taken by the system from Ethernet and radio interfaces. The reference frequency may also be conveyed to external equipment through different interfaces.

Frequency is distributed by configuring the following parameters in each node:

- **System Synchronization Sources** – These are the interfaces from which the frequency is taken and distributed to other interfaces. Up to 16 sources can be configured in each node. A revertive timer can be configured. For each interface, you must configure:
 - **Priority (1-16)** – No two synchronization sources can have the same priority.
 - **Quality** – The quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source.
- Each unit determines the current active clock reference source interface:
 - The interface with the highest available quality is selected.
 - From among interfaces with identical quality, the interface with the highest priority is selected.

When configuring a Sync source, the Sync mode must be set to its default setting of automatic. To display the current Sync mode, enter the following CLI command in root view:

```
root> platform sync mode show
```

If the Sync mode is set to pipe, you must set it to automatic by entering the following CLI command in root view:

```
root> platform sync mode set automatic
```

When configuring an Ethernet interface as a Sync source, the Media Type of the interface must be rj45 or sfp, *not* auto-type. To view and configure the Media Type of an Ethernet interface, see [Configuring an Interface's Media Type \(CLI\)](#).

This section includes:

- [Configuring an Ethernet Interface as a Synchronization Source \(CLI\)](#)
- [Configuring a Radio Interface as a Synchronization Source \(CLI\)](#)
- [Clearing All Sync Sources \(CLI\)](#)

Configuring an Ethernet Interface as a Synchronization Source (CLI)

You can configure Ethernet interfaces, including Cascading interfaces, to be synchronization sources.



Note

In order to select an Ethernet interface, you must first specify the media type for this interface. See [Configuring Ethernet Services \(CLI\)](#).

To configure an Ethernet interface as a synchronization source, enter the following command in root view:

```
root> platform sync source add eth-interface slot <slot> port <port>
priority <priority> quality <quality>
```

To edit the parameters of an existing Ethernet interface synchronization source, enter the following command in root view:

```
root> platform sync source edit eth-interface slot <slot> port <port>
priority <priority> quality <quality>
```

To remove an Ethernet interface as a synchronization source, enter the following command in root view:

```
root> platform sync source remove eth-interface slot <slot> port <port>
```

Table 291 Sync Source Ethernet CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	1 – 6	The interface to be configured as a synchronization source.
priority	Number	1 – 16	The priority of this synchronization source relative to other synchronization sources configured in the unit.
quality	Variable	For ETSI systems: <ul style="list-style-type: none"> • automatic • prc • ssu-a • ssu-b • g813.8262 For ANSI (FCC) systems: <ul style="list-style-type: none"> • automatic • prs • stratum-2 • transit-node • stratum-3e • stratum-3 • smc • unknown 	The quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source. If the quality is set to automatic, then the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes "failure." SSM must be enabled on the remote interface in order for the interface to receive SSM messages. If the quality is configured to a fixed value, then the quality status becomes "failure" upon interface failure (such as LOS, LOC, LOF).

The following command configures Ethernet port 2 as a synchronization source with priority = 8, and quality = automatic:

```
root> platform sync source add eth-interface slot 1 port 2 priority 8
quality automatic
```

The following command changes the priority of this synchronization source to 6:

```
root> platform sync source edit eth-interface slot 1 port 2 priority 6
```

The following command removes this synchronization source:

```
root> platform sync source remove eth-interface slot 1 port 2
```

Configuring a Radio Interface as a Synchronization Source (CLI)

To configure a radio interface as a synchronization source, enter the following command in root view:

```
root> platform sync source add radio-interface slot <slot> port <port>
radio-channel <radio-channel> priority <priority> quality <quality>
```

To edit the parameters of an existing radio interface synchronization source, enter the following command in root view:

```
root> platform sync source edit radio-interface slot <slot> port <port>
radio-channel <radio-channel> priority <priority> quality <quality>
```

To remove a radio interface as a synchronization source, enter the following command in root view:

```
root> platform sync source remove radio-interface slot <slot> port <port>
radio-channel <radio-channel>
```

Table 292 Sync Source Radio CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	1-2	
radio-channel	Number	0 – 85	A synchronization channel used for interoperability. For interoperability with other PTP 820G or PTP 820F units, this parameter must be set to 0.
priority	Number	1 – 16	The priority of this synchronization source relative to other synchronization sources configured in the unit.
quality	Variable	For ETSI systems: <ul style="list-style-type: none"> • automatic • prc • ssu-a • ssu-b • g813.8262 For ANSI (FCC) systems: <ul style="list-style-type: none"> • automatic • prs • stratum-2 • transit-node • stratum-3e • stratum-3 • smc • unknown 	The quality level applied to the selected synchronization source. This enables the system to select the source with the highest quality as the current synchronization source. If the quality is set to automatic, then the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes "failure." SSM must be enabled on the remote interface in order for the interface to receive SSM messages.

The following command configures radio interface 1 as a synchronization source with priority = 16, and quality = automatic:

```
root> platform sync source add radio-interface slot 1 port 1 radio-  
channel 1 priority 16 quality automatic
```

The following command changes the priority of this synchronization source to 14:

```
root> platform sync source edit radio-interface slot 1 port 1 radio-  
channel 1 priority 14
```

The following command removes this synchronization source:

```
root> platform sync source remove radio-interface slot 1 port 1 radio-  
channel 1
```

Clearing All Sync Sources (CLI)

To clear all synchronization sources that have been configured in the system, enter the following command in root view:

```
root> platform sync source remove all
```

Configuring the Outgoing Clock (CLI)

For each interface, you can choose between using the system clock or the interface's internal clock as its synchronization source. By default, interfaces use the system clock.



Note

You cannot edit the clock source of E1/DS1 interfaces.

To set the interface clock for a radio interface, enter the following command in root view:

```
root> platform sync interface-clock set radio-interface slot <slot> port
<port> radio-channel <radio-channel> source <source>
```



Note

To configure the interface clock on an Ethernet interface, the Media Type of the interface must be rj45 or sfp, not auto-type. To view and configure the Media Type of an Ethernet interface, see [Configuring an Interface's Media Type \(CLI\)](#).

To set the interface clock for an Ethernet interface, enter the following command in root view:

```
root> platform sync interface-clock set eth-interface slot <slot> port
<port> source <source>
```

Table 293 Outgoing Clock CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	ethernet: 1-6 radio: 1-2 tdm: 1	The port number of the interface.
radio-channel	Number	1 – 84	The radio-channel configured for the synchronization source.
source	Variable	system-clock local-clock	system-clock – The interface uses the system clock as its synchronization source. local-clock – The interface uses its internal clock as its synchronization source.

The following command sets the clock source for radio interface 2 to its internal clock:

```
root> platform sync interface-clock set radio-interface slot 1 port 2
radio-channel 1 source local-clock
```

The following command sets the clock source for Ethernet port 2 to the system clock:

```
root> platform sync interface-clock set eth-interface slot 1 port 2  
source system-clock
```

Configuring SSM Messages (CLI)

In order to provide topological resiliency for synchronization transfer, PTP 820G and PTP 820F implements the passing of SSM messages over the Ethernet and radio interfaces. SSM timing in PTP 820G and PTP 820F complies with ITU-T G.781.

In addition, the SSM mechanism provides reference source resiliency, since a network may have more than one source clock.

The following are the principles of operation:

- At all times, each source interface has a “quality status” which is determined as follows:
 - If quality is configured as fixed, then the quality status becomes “failure” upon interface failure (such as LOS, LOC, LOF).
 - If quality is automatic, then the quality is determined by the received SSMs. If no valid SSM messages are received or in case of interface failure (such as LOS, LOC, LOF), the quality becomes "failure."
- Each unit holds a parameter which indicates the quality of its reference clock. This is the quality of the current synchronization source interface.
- The reference source quality is transmitted through SSM messages to all relevant radio interfaces.
- In order to prevent loops, an SSM with quality “Do Not Use” is sent from the active source interface (both radio and Ethernet).

In order for an interface to transmit SSM messages, SSM must be enabled on the interface. By default, SSM is disabled on all interfaces. On radio interfaces, SSM messages with the quality DNU (Do not Use) are sent when SSM is disabled on the interface.

To enable SSM on a radio interface, enter the following command in root view:

```
root> platform sync ssm admin radio-interface slot <slot> port <port>
admin on
```

To disable SSM on a radio interface, enter the following command in root view:

```
root> platform sync ssm admin radio-interface slot <slot> port <port>
admin off
```

To enable SSM on an Ethernet interface, enter the following command in root view:

```
root> platform sync ssm admin eth-interface slot <slot> port <port> admin
on
```

To disable SSM on an Ethernet interface, enter the following command in root view:

```
root> platform sync ssm admin eth-interface slot <slot> port <port> admin
off
```

The following command enables SSM on radio interface 2:

```
root> platform sync ssm admin radio-interface slot 2 port 1 admin on
```

The following command enables SSM on Ethernet port 1:

```
root> platform sync ssm admin eth-interface slot 1 port 1 admin on
```

Configuring the Revertive Timer (CLI)

You can configure a revertive timer for the unit. When the revertive timer is configured, the unit will not switch to another synchronization source unless that source has been stable for at least the number of seconds defined in the revertive timer. This helps to prevent a situation in which numerous switchovers occur when a synchronization source reports a higher quality for a brief time interval, followed by a degradation of the source's quality. By default, the revertive timer is set to 0, which means that it is disabled.



Note

TDM trails with 1:1 path protection that were configured using software versions prior to T7.9 are non-revertive.

The Revertive timer must be configured before creating a protecting TDM trail so that the configured WTR time will be in effect for this trail.

To configure the revertive timer, enter the following command in root view:

```
root> platform sync revertive-timer set rev_time <rev_time>
```

Table 294 Synchronization Revertive Timer CLI Parameters

Parameter	Input Type	Permitted Values	Description
rev_time	Number	1-1800	The revertive timer, in seconds.

The following command sets the revertive timer as 7 seconds:

```
root> platform sync revertive-timer set rev_time 7
```

To display the revertive timer, enter the following command in root view:

```
root> platform sync revertive-timer show
```

Displaying Synchronization Status and Parameters (CLI)

To display the synchronization sources configured in the system, enter the following command in root view:

```
root> platform sync source config show
```

The following is a sample synchronization source display output:

```
number of configured sources = 4
=====|
| Slot | Port | Type | Instance | Priority | Quality |
=====|
| 1 | 1 | Ethernet | 11 | automatic |
-----|
| 1 | 1 | Radio | 3 | automatic |
-----|
| 1 | 2 | Radio | 5 | automatic |
-----|
```

To display the synchronization source status, enter the following command in root view:

```
root> platform sync source status show
```

The following is a sample synchronization source status display output:

```
number of configured sources = 4
=====|
| Slot | Port | Type | Instance | Active-Src | Act. Quality | Received
SSM | revert-time |
=====|
| 1 | 1 | ethernet | false | PRC | do-not-use | 0 |
-----|
| 1 | 1 | radio | false | do-not-use | do-not-use | 0 |
-----|
| 1 | 2 | radio | false | failure | do-not-use | 0 |
=====|
```

To display the current system reference clock quality, enter the following command in root view:

```
root> platform sync source show-reference-clock-quality
```

To display the current synchronization configuration of the unit's interfaces, enter the following command in root view:

```
root> platform sync interface config show
```

The following is a sample interface synchronization configuration display output:

```

number of configured clock-interfaces = 14
=====|
| Slot | Port | Type | Trail Radio | Source-Type | SSM-Admin |
=====|
| 1 | 1 | Ethernet | | System Clock | off |
| 1 | 2 | Ethernet | | System Clock | off |
| 1 | 3 | Ethernet | | System Clock | off |
| 1 | 4 | Ethernet | | System Clock | off |
| 1 | 5 | Ethernet | | System Clock | off |
| 1 | 6 | Ethernet | | System Clock | on |
| 1 | 1 | Radio | | System Clock | on |
| 1 | 2 | Radio | | System Clock | on |
=====|

```

To display the current system clock status, enter the following command in root view:

```
root> platform sync clu-state show
```

The following is a sample system clock status display output:

```
CLU is in Free-running mode
```

Configuring 1588 Transparent Clock (CLI)

**Note**

This section is only relevant for PTP 820G. 1588 Transparent Clock for PTP 820F is planned for future release.

PTP 820G uses 1588v2-compliant Transparent Clock to counter the effects of delay variation. Transparent Clock measures and adjusts for delay variation, enabling the PTP 820G to guarantee ultra-low PDV.

A Transparent Clock node resides between a master and a slave node, and updates the timestamps of PTP packets passing from the master to the slave to compensate for delay, enabling the terminating clock in the slave node to remove the delay accrued in the Transparent Clock node. The Transparent Clock node is itself neither a master nor a slave node, but rather, serves as a bridge between master and slave nodes.

Note that in release 10.0:

- 1588 TC is not supported when Master-Slave communication is using the IPv6 transport layer.
- 1588 TC cannot be used on 1+1 HSB links.
- 1588 TC is not supported with Frame Cut-Through.
- 1588 TC is supported with IPv4 UDP encapsulation only.
- Multicast PTP packets are only supported with Point-to-Point services. Unicast PTP packets are supported with both Point-to-Point and Multipoint services.

Before configuring Transparent Clock:

1. Add the port receiving synchronization from the customer side as a Sync source with Sync Interface Priority 1. See [Configuring an Ethernet Interface as a Synchronization Source \(CLI\)](#).
2. Add a radio interface as a second Sync source with lower priority than the port receiving synchronization from the customer side. See [Configuring a Radio Interface as a Synchronization Source \(CLI\)](#).
3. On the remote side of the radio link, add the radio interface facing the local device as a Sync source, with Sync Interface Priority 1. See [Configuring a Radio Interface as a Synchronization Source \(CLI\)](#).
4. Add the port receiving synchronization from the customer side as a Sync source, with Sync Interface Priority 1. See [Configuring a Radio Interface as a Synchronization Source \(CLI\)](#).
5. Verify that the Sync Interface Quality Status of the first Sync source is not Failure. See [Displaying Synchronization Status and Parameters \(CLI\)](#).

**Note**

Make sure to enable Transparent Clock on the remote side of the link before enabling it on the local side.

To enable Transparent Clock, enter the following command in root view to enable:

```
root> platform sync ptp-tc set admin enable
```

To disable Transparent Clock, enter the following command in root view :

```
root> platform sync ptp-tc set admin disable
```

Enter one of the following commands in root view to assign the radio or Multi-Carrier ABC group that will carry the PTP packets and determine the direction of the PTP packet flow.

For an individual radio, enter the following command:

```
root> platform sync ptp-tc set radio slot <slot> port <port> direction
<upstream|downstream>
```

For a Multi-Carrier ABC group, enter the following command:

```
root> platform sync ptp-tc set group id <group> direction
<upstream|downstream>
```

The direction parameter must be set to different values on the two sides of the link, so that if you set the local side to **upstream**, you must set the remote side to **downstream**, and vice versa. Otherwise than that, it does not matter how you set this parameter.

To display the Transparent Clock settings, enter the following command in root view:

```
root> platform sync ptp-tc show status
```

The following commands enable Transparent Clock on radio carrier 1 and configure the radio to send PTP packets downstream:

```
root> platform sync ptp-tc set admin enable
root> platform sync ptp-tc set radio slot 1 port 1 direction downstream
```

The following commands enable Transparent Clock on Multi-Carrier ABC group 1 and configure the radio to send PTP packets upstream:

```
root> platform sync ptp-tc set group id mc-abc1 direction upstream
```

Table 295 1588 Transparent Clock CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
port	Number	1-2	
group	Variables	mc-abc1	

1588 packets should be mapped to CoS 7. By default, 1588 packets are not mapped to any CoS. To map 1588 packets to CoS 7, you must disable CoS preservation for 1588 packets. This must be performed via CLI, using the following command:

```
root> ethernet generalcfg ptp-tc cos-preserve set admin disable
```

To map 1588 packets to CoS 7, enter the following command:

```
root> ethernet generalcfg ptp-tc cos-preserve cos value 7
```

After you enter these commands, 1588 packets will automatically be mapped to CoS 7.



Note

If necessary, you can use the `ethernet generalcfg ptp-tc cos-preserve cos value` command to map a different CoS value (0-7) to 1588 packets, but it is recommended to map 1588 packets to CoS 7.

Configuring 1588 Boundary Clock (CLI)

**Note**

This section is only relevant for PTP 820G. 1588 Boundary Clock for ptp 820F is planned for future release.

IEEE-1588v2 Boundary Clock enables the PTP 820 to regenerate phase synchronization via standard Ethernet. Boundary Clock complies with ITU-T Telecom Profile G.8275.1. This enables PTP 820, with Boundary Clock, to meet the rigorous synchronization requirements of LTE-Advanced (LTE-A) networks.

The Boundary Clock in PTP 820 supports up to four 1588 slave clock devices.

The Boundary Clock terminates the PTP flow it receives on the slave port, recovers the time and phase, and regenerates the PTP flow on the master ports.

The Boundary Clock node selects the best synchronization source available in the domain and regenerates PTP towards the slave clocks. This reduces the processing load from grandmaster clocks and increases the scalability of the synchronization network, while rigorously maintaining timing accuracy.

The PTP 820 Boundary Clock mechanism requires the use of untagged Ethernet multicast PTP packets.

**Note**

Boundary Clock and Transparent Clock can be used together in the same PTP 820 node.

Note that in release 10.0:

- 1588 BC cannot be configured on interface groups, such as LAG and Multi-Carrier ABC.
- 1588 BC can only be used in a chain or star topology. It cannot be used in a ring topology.
- 1588 BC is not supported when Master-Slave communication is using the IPv6 transport layer.
- 1588 BC is not supported with RMC-A.
- 1588 BC cannot be used on 1+1 HSB links.
- 1588 BC is not supported with Frame Cut-Through

Enabling Boundary Clock (CLI)

**Note**

Before configuring Boundary Clock, you must configure Transparent Clock. See *Configuring 1588 Transparent Clock (CLI)*.

To enable Boundary Clock, enter the following command in root view to enable:

```
root> platform sync ptp set admin enable
```

You can configure up to four interfaces per unit to be part of the Boundary Clock node. These interfaces can be radio and Ethernet interfaces, but not TDM interfaces or groups (e.g., LAG or Multi-Carrier ABC groups).

For each interface, use the following commands to enable and define Boundary Clock.

To enable Boundary Clock on a port, enter the following command in root view:

```
root> platform sync ptp-bc interfaces set interface-type <interface-type>
slot <slot> port <port> admin enable
```

To set the port's role in the Boundary Clock node, enter the following command in root view:

```
root> platform sync ptp-bc interfaces set interface-type <interface-type>
slot <slot> port <port> master-only <master-only>
```

Optionally, use the following command to set the Local Priority. The Local Priority value is taken into account when two identical announce messages are received by at least two different ports. In such a case, the Boundary Clock mechanism selects the slave port based on the best (lowest) Local Priority. The default value is 128.

```
root> platform sync ptp-bc interfaces set interface-type <interface-type>
slot <slot> port <port> local-priority <local-priority>
```

Use the following command to set a MAC address for multicast re-transmission of PTP packets:

```
root> platform sync ptp-bc interfaces set interface-type <interface-type>
slot <slot> port <port> dest-mac <dest-mac>
```

Table 296 Boundary Clock Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
interface-type	Variable	ethernet radio	
slot	Number	For interfaces on cards in an expansion slot: 2- 3 For fixed interfaces: 1	The slot in which the card resides.
port	Number	ethernet: 1-6 radio (fixed): 1-2 radio (expansion slot): 1	
admin	Variable	enable disable	Enables or disables Boundary Clock on the port.
master-only	Variable	yes no	yes – The port can only be used as the master port, which means the port acts as a PTP synchronization source for other nodes.

Parameter	Input Type	Permitted Values	Description
			no – The port can be used as either a master port or the slave port. The slave port receives PTP synchronization input from an external grandmaster clock. The Best Master Clock Algorithm (BMCA) determines the port's role, based on its determination of which is the best available grandmaster clock. Only one slave port can exist in a single PTP 820 node at any one time.
local-priority	Number	1-255	
dest-mac	Variable	01-1B-19-00-00-00 01-80-C2-00-00-0E	01-1B-19-00-00-00 – General group address. An 802.1Q VLAN Bridge would forward the frame unchanged. 01-80-C2-00-00-0E – Individual LAN Scope group address. An 802.1Q VLAN Bridge would drop the frame.

The following commands set up a Boundary Clock node that includes Ethernet interfaces 1 and 2, and fixed radio interface 1 and an RMC in expansion slot 2. The Ethernet interfaces can serve as master or slave; the slave role is allocated dynamically according to the interface receiving the best grandmaster announce message according to the BMCA. The radio interfaces can only serve in the master role, i.e., they distribute PTP synchronization but do not receive PTP synchronization from an external grandmaster.

```

root> platform sync ptp set admin enable

root> platform sync ptp-bc interfaces set interface-type
ethernet slot 1 port 1 admin enable
root> platform sync ptp-bc interfaces set interface-type ethernet slot 1
port 1 master-only no

root> platform sync ptp-bc interfaces set interface-type ethernet slot 1
port 2 admin enable
root> platform sync ptp-bc interfaces set interface-type ethernet slot 1
port 2 master-only no

root> platform sync ptp-bc interfaces set interface-type radio slot 1
port 1 admin enable
root> platform sync ptp-bc interfaces set interface-type radio slot 1
port 1 master-only yes

root> platform sync ptp-bc interfaces set interface-type radio slot 2
port 1 admin enable
root> platform sync ptp-bc interfaces set interface-type radio slot 2
port 1 master-only yes

```

In addition, you must perform the following steps to properly configure the Boundary Clock node:

1. To map PTP packets into the Boundary Clock node, a service point must be created on each interface in the Boundary Clock node. This service point must be defined to gather untagged packets. See [Adding a Service Point \(CLI\)](#).
2. Add a port receiving synchronization from the customer side as a Sync source, with Sync Interface Priority 1. See [Configuring the Sync Source \(CLI\)](#).
3. Add a radio interface as a Sync source, with lower priority than the port receiving synchronization from the customer side. See [Configuring the Sync Source \(CLI\)](#).
4. On the remote side of the radio link, add the radio interface facing the local device as a Sync source, with Sync Interface Priority 1. See [Configuring the Sync Source \(CLI\)](#).
5. On the remote side of the radio link, if there is an Ethernet port conveying synchronization, add this port as a Sync source, with lower priority than the radio interface. See [Configuring the Sync Source \(CLI\)](#).
6. Verify that the Sync Interface Quality Status of the first Sync source is not Failure. See [Displaying Synchronization Status and Parameters \(CLI\)](#).

Use the following command to display the current Boundary Clock configuration:

[Configuring the Sync Source \(CLI\)](#)

```
root> platform sync ptp-bc interfaces show config
```

Figure 428 1588 Boundary Clock – Current Configuration Sample Display (CLI)

```
root> platform sync ptp-bc interfaces show config
```

1588 BC ports config table:				
Interface location	Master Only	Local Priority	Admin	Destination Mac Address
Ethernet: Slot 1, Port 3	yes	128	enable	1:1b:19:0:0:0
Ethernet: Slot 1, Port 4	no	128	enable	1:1b:19:0:0:0
Ethernet: Slot 1, Port 5	yes	128	disable	1:1b:19:0:0:0
Ethernet: Slot 1, Port 6	yes	128	disable	1:1b:19:0:0:0
Radio: Slot 1, Port 1	yes	128	enable	1:1b:19:0:0:0
Radio: Slot 1, Port 2	yes	128	enable	1:1b:19:0:0:0

```
root>
```

Displaying and Setting the Boundary Clock Default Parameters (CLI)

The following commands set the Boundary Clock default parameters.

The Priority 2 value is one of the factors used by the BMCA to determine the grandmaster. The PTP 820 Boundary Clock node advertises this value when it is not locked on an external grandmaster. The default value is 128. The following command can be used to change the Boundary Clock node's Priority 2 value.

```
root> platform sync ptp-bc clock set priority2 <priority2>
```

The following command sets the Boundary Clock node's Domain Number. The default value is 24. The following command can be used to change the Boundary Clock node's Domain Number.

```
root> platform sync ptp-bc clock set domain-number <domain-number>
```

The Local Priority value is taken into account when two identical announce messages are received by at least two different ports. In such a case, the Boundary Clock mechanism selects the slave port based on the best (lowest) Local Priority. The default value is 128. The following command can be used to change the Boundary Clock node's default Local Priority.

```
root> platform sync ptp-bc clock set local-priority <local-priority>
```

You can select the maximum number of PTP clocks traversed from the grandmaster to the slave clock in the local PTP 820 Boundary Clock node. If the defined number is exceeded, packets from this grandmaster candidate are discarded and the grandmaster will not be eligible for use by the Boundary Clock node. The default value is 255. The following command can be used to change the Boundary Clock node's maximum number of PTP clocks traversed.

```
root> platform sync ptp-bc clock set max-steps-removed <max-steps-removed>
```

Table 297 Boundary Clock Default Settings – CLI Parameters

Parameter	Input Type	Permitted Values
priority2	Number	0-255
domain-number	Number	24-43
local-priority	Number	1-255
max-steps-removed	Number	1-255

Use the following command to display the Boundary Clock node's default parameters.

```
root> platform sync ptp-bc clock show default
```

Figure 429 1588 Boundary Clock – Default Parameters Sample Display (CLI)

```
root> platform sync ptp-bc clock show default
1588 BC Clock default DS table:
=====
Two Step Clock Identity      Number Of Ports Clock Class  Clock Accuracy      Offset Scaled Priority 1 Priority 2 Domain Slave Only Local Max Step Reset Port Clock
                           4                187                CLOCK_ACCURACY_WORSE_THAN_10s 52592 128    128    24    no    128    255    no    1
yes
root>
```

Table 298 Boundary Clock Default Parameters

Parameter	Definition
Two Step (read only)	Indicates whether the Boundary Clock node is operating in two-step mode. In PTP 820, this is always set to Yes .
Clock Identity (read only)	Identifies the system clock.
Number of Ports (read only)	Displays the number of ports on the unit on which Boundary Clock is enabled. The maximum is 4 per PTP 820 unit.
Clock Class (read only)	One of the elements of the clock quality, as defined in IEEE-1588.
Clock Accuracy (read only)	One of the elements of the clock quality, as defined in IEEE-1588.

Parameter	Definition
Offset Scaled Log Variance (read only)	One of the elements of the clock quality, as defined in IEEE-1588.
Priority 1 (read only)	Always displays 128.
Priority 2	One of the factors used by the BMCA to determine the grandmaster. The PTP 820's Boundary Clock node advertises this value when it is not locked on an external grandmaster. The default value is 128 (user-configurable).
Domain Number	The default value is 24 (user-configurable).
Slave Only (read only)	Indicates whether the Boundary Clock node is operating in slave mode only. In PTP 820, this is always set to no .
Max Step Removed	The maximum number of PTP clocks traversed from the grandmaster to the slave clock in the local PTP 820 Boundary Clock node. If the defined number is exceeded, packets from this grandmaster candidate are discarded and the grandmaster will not be eligible for use by the Boundary Clock node. The default value is 255 (user-configurable).
Reset Port Counters	In PTP 820, this is always set to no .
Clock Index	In PTP 820, this is always set to 1 .

Displaying the Boundary Clock Advanced Parameters (CLI)

Use the following command to display the Boundary Clock node's general advanced parameters.

```
root> platform sync ptp-bc clock show current
```

Figure 430 1588 Boundary Clock – Advanced (General) Parameters Sample Display (CLI)

```
root> platform sync ptp-bc clock show current
1588 BC Clock current DS table:
=====
Steps Removed   Offset From      Mean Path Delay  Clock Index
                Master
=====
0                0 s 0 ns        0 s 0 ns        1
root>
```

Use the following command to display information about the current master and grandmaster being used by the Boundary Clock node.

```
root> platform sync ptp-bc clock show parent
```

Figure 431 1588 Boundary Clock – Parent Clock Parameters Sample Display (CLI)

```
root> platform sync ptp-bc clock show parent
1588 BC Clock parent DS table:
=====
Master Clock      Master  Grandmaster      Grandmaster      Grandmaster      Grandmaster      Grandmaster      Grandmaster      Grandmaster      Clock Index
Identity          Port   Identity          Clock Class      Clock Accuracy   Offset Scaled    Priority 1        Priority 2
Number                                                    Log Variance
-----
000A25FFFE38094B  0      000A25FFFE38094B  187              CLOCK_ACCURACY_WORSE_THAN_10s  52592            128              128              1
root>
```

Use the following command to display information about the Boundary Clock node’s current time parameters.

```
root> platform sync ptp-bc clock show time
```

Figure 432 1588 Boundary Clock – Time Parameters Sample Display (CLI)

```
root> platform sync ptp-bc clock show time
1588 BC Clock time DS table:
=====
Current          Current          Leap 59          Leap 61          Time              Frequency          PTP              Time              Clock
UTC              UTC              Offset           Offset           Traceable         Traceable         Timescale        Source            Index
(Seconds)       Valid
-----
36              no              no              no              no              no              yes              INTERNAL_        1
                OSCILLATOR
root>
```

All of the advanced Boundary Clock parameters are read-only.

Table 299 Boundary Clock Advanced Parameters (CLI)

Parameter	Definition
Steps Removed	The number of PTP clocks traversed from the grandmaster to the slave clock in the local PTP 820 Boundary Clock node. You can define a maximum number of steps in the Clock Default Parameters page. See <i>Displaying and Setting the Boundary Clock Default Parameters (CLI)</i> .
Offset from Master (Nanoseconds)	The time difference between the master clock and the local slave clock (in ns).
Mean Path Delay (Nanoseconds)	The mean propagation time for the link between the master and the local slave (in ns).
Master Clock Identity	The clock identity of the current master clock.
Master Port Number	The clock identity of the current master port.
Grandmaster Identity	The clock identity of the current grandmaster.

Parameter	Definition
Grandmaster Clock Class	The clock class of the current grandmaster. The clock class is one of the elements of the clock quality, as defined in IEEE-1588.
Grandmaster Clock Accuracy	The clock accuracy of the current grandmaster. The clock accuracy is one of the elements of the clock quality, as defined in IEEE-1588.
Grandmaster Offset Scaled Log Variance	The offset scaled log variance of the current grandmaster. The offset scaled log variance is one of the elements of the clock quality, as defined in IEEE-1588.
Grandmaster Priority 1	The Priority 1 value of the current grandmaster.
Grandmaster Priority 2	The Priority 2 value of the current grandmaster.
Current UTC Offset (Seconds)	The current UTC offset value (in seconds).
Current UTC Offset Valid	Indicates whether the current UTC offset value is valid.
Leap 59	Indicates that the last minute of the current UTC day contains 59 seconds.
Leap 61	Indicates that the last minute of the current UTC day contains 61 seconds.
Time Traceable	Traceability to the primary time reference.
Frequency Traceable	Traceability to the primary frequency reference.
PTP Timescale	Indicates whether the clock time scale of the grandmaster clock is PTP.
Time Source	The source of the time used by the grandmaster clock.

Displaying the Boundary Clock Port Parameters (CLI)

Use the following command to display the Boundary Clock port parameters.

```
root> root> platform sync ptp-bc interfaces show status
```

Figure 433 1588 Boundary Clock Port Parameters (CLI)

```
root> platform sync ptp-bc interfaces show status
1588 BC ports status table:
=====
Interface location      Clock Identity      Port  Port State      Log Min Delay  Log Sync  Log Announce  Announce  Version  Delay
                        Number              State          Req Interval   Interval     Interval      Receipt   Number   Mechanism
=====
Ethernet: Slot 1, Port 3 000A25FFFE401F93   1      PORT_STATE_MASTER  -4 (16 pps)   -4 (16 pps)  -3 (8 pps)    8         2        1
Ethernet: Slot 1, Port 4 000A25FFFE401F93   2      PORT_STATE_MASTER  -4 (16 pps)   -4 (16 pps)  -3 (8 pps)    8         2        1
Ethernet: Slot 1, Port 5 0000000000000000    1      PORT_STATE_INITIALIZING  4294967293    2        1
Ethernet: Slot 1, Port 6 0000000000000000    1      PORT_STATE_INITIALIZING  4294967293    2        1
Radio: Slot 1, Port 1    000A25FFFE401F93   4      PORT_STATE_MASTER  -4 (16 pps)   -4 (16 pps)  -3 (8 pps)    8         2        1
Radio: Slot 1, Port 2    000A25FFFE401F93   3      PORT_STATE_MASTER  -4 (16 pps)   -4 (16 pps)  -3 (8 pps)    8         2        1
root>
```

Table 300 Boundary Clock Port Parameters (CLI)

Parameter	Definition
Clock Identity	The PTP 820 unit’s clock identity. The same value is used for every port that belongs to the Boundary Clock node.
Port Number	In this version, displays 1 for every port.
Port State	Indicates whether the port is currently acting as Master (distributing PTP to other nodes) or Slave (receiving PTP from a grandmaster).
Log Min Delay Req Interval	The minimum allowed interval between Delay Request messages.
Log Sync Interval	Interval between sync messages.
Log Announce Interval	The interval between Announce messages.
Announce Receipt Timeout	The maximum allowed number of intervals without receiving any Announce messages.
Version Number	Always displays 2.
Delay Mechanism	Always displays 1.

Displaying the Boundary Clock Port Statistics (CLI)

Use the following command to display the Boundary Clock statistics.

```
root> platform sync ptp-bc interfaces show statistics interface-type
<interface-type> slot <slot> port <port> clear-on-read <yes|no>
```

Table 301 Boundary Clock Configuration CLI Parameters

Parameter	Input Type	Permitted Values	Description
interface-type	Variable	ethernet radio	

Parameter	Input Type	Permitted Values	Description
slot	Number	For 1RU chassis: 1-6 For 2RU chassis: 1-12	The slot in which the card resides.
port	Number	Any port on the selected slot.	
clear-on-read	Boolean	yes no	If yes is selected, the interface statistics are cleared after the command is executed.

The following command displays statistics for Ethernet interface port 1 on an Ethernet LIC in slot 2, and clears the statistics after displaying them.

```
root> platform sync ptp-bc interfaces show statistics interface-type ethernet slot 2 port 1 clear-on-read yes
```

Figure 434 1588 Boundary Clock Statistics (CLI)

```
root> platform sync ptp-bc interfaces show statistics interface-type ethernet slot 1 port 3 clear-on-read yes
1588 BC ports counters table:
-----
Interface location      Announce Transmitted  Sync Transmitted  Follow-Up Transmitted  Delay Response Transmitted  Delay Request Transmitted  Dropped Messages  Lost Messages  Announce Received  Sync Received  Follow-Up Received  Delay Response Received  Delay Request Received
-----
Ethernet: Slot 1, Port 3  161                   323                323                    0                          0                          0                  0              0                  0              0                          0                          0
root>
```

Table 302 Boundary Clock Port Statistics (CLI)

Parameter	Definition
Announce Transmitted	The number of Announce messages that have been transmitted from the port.
Sync Transmitted	The number of Sync messages that have been transmitted from the port.
Follow-Up Transmitted	The number of Follow-Up messages that have been transmitted from the port.
Delay Response Transmitted	The number of Delay Response messages that have been transmitted from the port.
Delay Request Transmitted	The number of Delay Request messages that have been transmitted from the port.
Dropped Messages	The number of dropped messages.
Lost Messages	The number of lost messages.
Announce Received	The number of Announce messages that have been received by the port.
Sync Received	The number of Sync messages that have been received by the port.

Follow-Up Received	The number of Follow-Up messages that have been received by the port.
Delay Response Received	The number of Delay Response messages that have been received by the port.
Delay Request Received	The number of Delay Request messages that have been received by the port.

Disabling Boundary Clock (CLI)

Use the following command to disable each Boundary Clock interface in the node. It is important to disable Boundary Clock on the interfaces *before* disabling 1588 PTP.

```
root> platform sync ptp-bc interfaces set interface-type <interface-type>
slot <slot> port <port> admin disable
```

After disabling the Boundary Clock interfaces, enter the following command in root view:

```
root> platform sync ptp set admin disable
```



Note

Disabling 1588 PTP disables both Transparent Clock and Boundary Clock, and can drastically affect time synchronization performance in the entire network.

Chapter 23: Access Management and Security (CLI)

This section includes:

- [Configuring the General Access Control Parameters \(CLI\)](#)
- [Configuring the Password Security Parameters \(CLI\)](#)
- [Configuring Users \(CLI\)](#)
- [Configuring RADIUS \(CLI\)](#)
- [Configuring X.509 CSR Certificates and HTTPS \(CLI\)](#)
- [Configuring HTTPS Cipher Hardening \(CLI\)](#)
- [Uploading the Configuration Log \(CLI\)](#)

Related Topics:

- [Changing Your Password](#)
- [Operating in FIPS Mode \(CLI\)](#)
- [Configuring AES-256 Payload Encryption \(CLI\)](#)

Configuring the General Access Control Parameters (CLI)

To avoid unauthorized login to the system, the following parameters should be set:

- Inactivity Timeout
- Blocking access due to login failures
- Blocking unused accounts

This section includes:

- [Configuring the Inactivity Timeout Period \(CLI\)](#)
- [Configuring Blocking Upon Login Failure \(CLI\)](#)
- [Configuring Blocking of Unused Accounts \(CLI\)](#)

Configuring the Inactivity Timeout Period (CLI)

A system management session automatically times out after a defined period (in minutes) with no user activity. To configure the session timeout period, enter the following command in root view:

```
root> platform security protocols-control session inactivity-timeout set
<inactivity-timeout>
```

To display the currently configured session timeout period, enter the following command in root view:

```
root> platform security protocols-control session inactivity-timeout show
```

Table 303 Inactivity Timeout Period CLI Parameters

Parameter	Input Type	Permitted Values	Description
inactivity-timeout	Number	1 - 60	The session inactivity timeout period (in minutes).

The following command sets the session inactivity timeout period to 30 minutes:

```
root> platform security protocols-control session inactivity-timeout set
30
```

Configuring Blocking Upon Login Failure (CLI)

Upon a configurable number of failed login attempts, the system blocks the user from logging in for a configurable number of minutes.

To configure the number of failed login attempts that will temporarily block the user from logging into the system, enter the following command in root view:

```
root> platform security access-control block-failure-login attempt set
<attempt>
```

To define the period (in minutes) for which a user is blocked after the configured number of failed login attempts, enter the following command in root view:

```
root> platform security access-control block-failure-login period set
<period>
```

To display the current failed login attempt blocking parameters, enter the following command in root view:

```
root> platform security access-control block-failure-login show
```

Table 304 Blocking Upon Login Failure CLI Parameters

Parameter	Input Type	Permitted Values	Description
attempt	Number	1 - 10	If a user attempts to login to the system with incorrect credentials this number of times consecutively, the user will temporarily be prevented from logging into the system for the time period defined by the platform security access-control block-failure-login period set command.
period	Number	1 - 60	The duration of time, in minutes, that a user is prevented from logging into the system after the defined number of failed login attempts.

The following commands configure a blocking period of 45 minutes for users that perform 5 consecutive failed login attempts:

```
root> platform security access-control block-failure-login attempt set 5
root> platform security access-control block-failure-login period set 45
```

Configuring Blocking of Unused Accounts (CLI)

You can configure a number of days after which a user is prevented from logging into the system if the user has not logged in for the configured number of days. You can also manually block a specific user.

To configure the blocking of unused accounts period, enter the following command in root view:

```
root> platform security access-control block-unused-account period set
<period>
```

Once the user is blocked, you can use the following command to unblock the user:

```
root> platform security access-control user-account block user-name
<user-name> block no
```

To manually block a specific user, enter the following command in root view:

```
root> platform security access-control user-account block user-name
<user-name> block yes
```

To display the currently configured blocking of unused account period, enter the following command in root view:

```
root> platform security access-control block-unused-account show
```

Table 305 Blocking Unused Accounts CLI Parameters

Parameter	Input Type	Permitted Values	Description
period	Number	0, 30 - 90	The number of days after which a user is prevented from logging into the system if the user has not logged in for the configured number of days. If you enter 0, this feature is disabled.
user-name	Text String	Any valid user name.	The user account you want to block or unblock. See Configuring User Accounts (CLI) .

The following command configures the system to block any user that does not log into the system for 50 days:

```
root> platform security access-control block-unused-account period set 50
```

Configuring the Password Security Parameters (CLI)

You can configure enhanced security requirements for user passwords.

This section includes:

- [Configuring Password Aging \(CLI\)](#)
- [Configuring Password Strength Enforcement \(CLI\)](#)
- [Forcing Password Change Upon First Login \(CLI\)](#)
- [Displaying the System Password Settings \(CLI\)](#)

Configuring Password Aging (CLI)

Passwords remain valid from the first time the user logs into the system for the number of days (20-90) set by this command. If you set this parameter to 0, password aging is disabled, and passwords remain valid indefinitely.

To configure password aging, enter the following command in root view:

```
root> platform security access-control password aging set <password aging>
```

Table 306 Password Aging CLI Parameters

Parameter	Input Type	Permitted Values	Description
password aging	Number	0, 20 - 90	The number of days that user passwords will remain valid from the first time the user logs into the system.

The following command sets the password aging time to 60 days:

```
root> platform security access-control password aging set 60
```

Configuring Password Strength Enforcement (CLI)

To set password strength enforcement, enter the following command in root view:

```
root> platform security access-control password enforce-strength set <enforce-strength>
```

Table 307 Password Strength Enforcement CLI Parameters

Parameter	Input Type	Permitted Values	Description
enforce-strength	Boolean	Yes no	When yes is selected: <ul style="list-style-type: none"> • Password length must be at least eight characters. • Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted. • A password cannot be repeated within five changes in password.

The following command enables password strength enforcement:

```
root> platform security access-control password enforce-strength set yes
```

Forcing Password Change Upon First Login (CLI)

To determine whether the system requires users to change their password the first time they log into the system, enter the following command in root view.

```
root> platform security access-control password first-login set <first-login>
```

To require users to change their password the first time they log in, enter the following command in root view:

```
root> platform security access-control password first-login set yes
```

Table 308 Force Password Change on First Time Login CLI Parameters

Parameter	Input Type	Permitted Values	Description
first-login	Boolean	Yes no	When yes is selected, the system requires users to change their password the first time they log in.

Displaying the System Password Settings (CLI)

Use the following command to display the system password settings:

```
root> platform security access-control password show-all
```

Configuring Users (CLI)

User configuration is based on the Role-Based Access Control (RBAC) model. According to the RBAC model, permissions to perform certain operations are assigned to specific roles. Users are assigned to particular roles, and through those role assignments acquire the permissions to perform particular system functions.

In the PTP 820G and PTP 820F GUI, these roles are called user profiles. Up to 50 user profiles can be configured. Each profile contains a set of privilege levels per functionality group, and defines the management protocols that can be used to access the system by users to whom the user profile is assigned

This section includes:

- [User Configuration Overview \(CLI\)](#)
- [Configuring User Profiles \(CLI\)](#)
- [Configuring User Accounts \(CLI\)](#)

Related topics:

- [Logging On \(CLI\)](#)

User Configuration Overview (CLI)

User configuration is based on the Role-Based Access Control (RBAC) model. According to the RBAC model, permissions to perform certain operations are assigned to specific roles. Users are assigned to particular roles, and through those role assignments acquire the permissions to perform particular system functions.

In the PTP 820 GUI, these roles are called user profiles. Up to 50 user profiles can be configured. Each profile contains a set of privilege levels per functionality group, and defines the management protocols (access channels) that can be used to access the system by users to whom the user profile is assigned.

The system parameters are divided into the following functional groups:

- Security
- Management
- Radio
- TDM
- Ethernet
- Synchronization

A user profile defines the permitted access level per functionality group. For each functionality group, the access level is defined separately for read and write operations. The following access levels can be assigned:

- **None** – No access to this functional group.
- **Normal** – The user has access to parameters that require basic knowledge about the functional group.
- **Advanced** – The user has access to parameters that require advanced knowledge about the functional group, as well as parameters that have a significant impact on the system as a whole, such as restoring the configuration to factory default settings.

Configuring User Profiles (CLI)

User profiles enable you to define system access levels. Each user must be assigned a user profile. Each user profile contains a detailed set of read and write permission levels per functionality group.

To create a new user profile with default settings, enter the following command:

```
root> platform security access-control profile add name <profile-name>
```

To edit the settings of a user profile, enter the following command:

```
root> platform security access-control profile edit group name <profile-name> group <group> write-lvl <write-lvl> read-lvl <read-lvl>
```

Table 309 User Profile CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile--name	Text String	Up to 49 characters	The name of the user profile.
group	Variable	security management radio ethernet sync	The functionality group for which you are defining access levels.
write-lvl	Variable	none normal advanced	The read level for the functionality group.
read-lvl	Variable	none normal advanced	The read level for the functionality group.

The following commands create a user profile called “operator” and give users to whom this profile is assigned normal write privileges for all system functionality and advanced read privileges for all functionality except security features.

```
root> platform security access-control profile add name operator
root> platform security access-control profile edit group name operator
group security write-lvl normal read-lvl normal group management write-
lvl normal read-lvl advanced group radio write-lvl normal read-
lvl advanced group ethernet write-lvl normal read-lvl advanced group sync
write-lvl normal read-lvl advanced
```

Limiting Access Protocols for a User Profile (CLI)

The user profile can limit the access channels that users with the user profile can use to access the system. By default, a user profile includes all access channels.

Use the following command to limit the protocols users with this user profile can use to access the system.

```
root> platform security access-control profile edit mng-channel name
<profile-name> channel-type <channel-type> allowed <allowed>
```

Table 310 User Profile Access Protocols CLI Parameters

Parameter	Input Type	Permitted Values	Description
profile--name	Text String	Up to 49 characters	The name of the user profile.
channel-type	Variable	Serial Web NMS Telnet SSH	The access channel type allowed or disallowed by the command for users with this user profile.
allowed	Boolean	yes no	yes – Users with this user profile can access the access channel type defined in the preceding parameter. no - Users with this user profile cannot access the access channel type defined in the preceding parameter.

For example, the following command prevents users with the user profile “operator” from accessing the system via NMS:

```
root> platform security access-control profile edit mng-channel name
operator channel-type NMS allowed no
```

Configuring User Accounts (CLI)

Use the following command to create a new user account:

```
root> platform security access-control user-account add user-name <user-
name> profile-name <profile-name> expired-date <expired-date>
```

Table 311 User Accounts CLI Parameters

Parameter	Input Type	Permitted Values	Description
user-name	Text String	Up to 32 characters	The name of the user profile.
profile name	Text String	Up to 49 characters	The name of the User Profile you want to assign to the user. The User Profile defines the user's access permissions per functionality group.
expired-date	Date	Use the format: YYYY-MM-DD	Optional. The date on which the user account will expire. On this date, the user automatically becomes inactive.

The following command creates a user account named Tom_Jones, with user profile “operator”. This user's account expires on February 1, 2014.

```
root> platform security access-control user-account add user-name
Tom_Jones profile-name operator expired-date 2014-02-01
```

When you create a new user account, the system will prompt you to enter a default password. If Enforce Password Strength is activated (refer to [Configuring Password Strength Enforcement \(CLI\)](#)), the password must meet the following criteria:

- Password length must be at least eight characters.
- Password must include characters of at least three of the following character types: lower case letters, upper case letters, digits, and special characters. For purposes of meeting this requirement, upper case letters at the beginning of the password and digits at the end of the password are not counted.
- The last five passwords you used cannot be reused.

See [Configuring the Password Security Parameters \(CLI\)](#).

Configuring RADIUS (CLI)

This section includes:

- [RADIUS Overview \(CLI\)](#)
- [Activating RADIUS Authentication \(CLI\)](#)
- [Configuring the RADIUS Server Attributes \(CLI\)](#)
- [Viewing RADIUS Access Control and Server Attributes \(CLI\)](#)
- [Viewing RADIUS User Permissions and Connectivity \(CLI\)](#)

RADIUS Overview (CLI)

The RADIUS protocol provides centralized user management services. PTP 820G and PTP 820F support RADIUS server and provides a RADIUS client for authentication and authorization.

When RADIUS is enabled, a user attempting to log into the system from any access channel (CLI, WEB, NMS) is not authenticated locally. Instead, the user's credentials are sent to a centralized standard RADIUS server which indicates to the PTP 820G or PTP 820F whether the user is known, and which privilege is to be given to the user.

You can define up to two Radius servers. If you define two, one serves as the primary server and the other as the secondary server.

Activating RADIUS Authentication (CLI)

To enable or disable Radius access control, enter the following command:

```
root> platform security radius-admin set <admin>
```

Table 312 Activate RADIUS CLI Parameters

Parameter	Input Type	Permitted Values	Description
admin	Variable	enable disable	Enables or disables Radius access control.

Configuring the RADIUS Server Attributes (CLI)

To configure Radius server attributes, enter the following command:

```
root> platform security radius-server-communication-ipv4 set server-id
<server-id> ip-address <ip-address> port <radius-port> retries <retries>
timeout <timeout> secret <shared-secret>
```

Table 313 RADIUS Server CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-id	Number	1 2	1 – The primary RADIUS server 2 – The secondary RADIUS server.
ip-address	Dotted decimal format	Any valid IP address	The IP address of the RADIUS server.
radius-port	Number	0-65535	The port ID of the RADIUS server.
retries	Number	3-30	The number of times the device will try to communicate with the RADIUS server before declaring the server to be unreachable.
timeout	Number	1-10	The timeout (in seconds) that the agent will wait in each communication with the selected RADIUS server before retrying if no response is received.

The following command configures Radius server attributes for the primary Radius server:

```
root> platform security radius-server-communication-ipv4 set server-id 1
ip-address 192.168.1.99 port 1812 retries 5 timeout 10 secret
U8g1p3KJ6FKGksdgase4IQ9FMm
```

Viewing RADIUS Access Control and Server Attributes (CLI)

To display the Radius access control status, enter the following command:

```
root> platform security radius-admin show
```

To display Radius server attributes, enter the following command:

```
root> platform security radius-server-communication show
```

Viewing RADIUS User Permissions and Connectivity (CLI)

You can view Radius user connectivity and permissions information for all Radius users currently connected. To do so, enter the following command:

```
root> platform security radius-server-privileges show
```

The following user information is displayed, for each currently connected Radius user:

- **User ID** - The user name
- **Access Channels** - The permitted access channels.
- **User Instances** - The number of currently open sessions.
- **Security Func Group Read level** – The Read access level in the Security functional group: None, Regular or Advanced.

- **Security Func Group Write level** – The Write access level in the Security functional group: None, Regular or Advanced.
- **Management Func Group Read level** – The Read access level in the Management functional group: None, Regular or Advanced.
- **Management Func Group Write level** – The Write access level in the Management functional group: None, Regular or Advanced.
- **Radio Func Group Read level** – The Read access level in the Radio functional group: None, Regular or Advanced.
- **Radio Func Group Write level** – The Write access level in the Radio functional group: None, Regular or Advanced.
- **TDM Func Group Read level** – The Read access level in the TDM functional group: None, Regular or Advanced.
- **TDM Func Group Write level** – The Write access level in the TDM functional group: None, Regular or Advanced.
- **Eth Func Group Read level** – The Read access level in the Eth functional group: None, Regular or Advanced.
- **Eth Func Group Write level** – The Write access level in the Eth functional group: None, Regular or Advanced.
- **Sync Func Group Read level** – The Read access level in the Sync functional group: None, Regular or Advanced.
- **Sync Func Group Write level** – The Write access level in the Sync functional group: None, Regular or Advanced.

Configuring X.509 CSR Certificates and HTTPS (CLI)

The web interface protocol for accessing PTP 820G and PTP 820F can be configured to HTTP (default) or HTTPS. It cannot be set to both at the same time.

Before setting the protocol to HTTPS, you must:

- 1 Create and upload a CSR file. See [Generating a Certificate Signing Request \(CSR\) File \(CLI\)](#).
- 2 Download the certificate to the PTP 820G or PTP 820F and install the certificate. See [Downloading a Certificate \(CLI\)](#).
- 3 Enable HTTPS. See [Enabling HTTPS \(CLI\)](#).

When uploading a CSR and downloading a certificate, the PTP 820G or PTP 820F functions as an SFTP client. You must install SFTP server software on the PC or laptop you are using to perform the upload or download. For details, see [Configuring the Internal Ports for FTP or SFTP \(CLI\)](#).

**Note**

For these operations, SFTP must be used.

This section includes:

- [Generating a Certificate Signing Request \(CSR\) File \(CLI\)](#)
- [Downloading a Certificate \(CLI\)](#)
- [Enabling HTTPS \(CLI\)](#)

Generating a Certificate Signing Request (CSR) File (CLI)

To set the CSR parameters, enter the following command in root view:

```
root> platform security csr-set-parameters common-name <common-name>
country <country> state <state> locality <locality> organization
<organization> org-unit <org-unit> email <email> file-format <file-
format>
```

To display the currently-configured CSR parameters, enter the following command in root view:

```
root> platform security csr-show-parameters
```

If the IP address family is configured to be IPv4, enter the following command in root view to configure the SFTP server parameters for the CSR file upload:

```
root> platform security csr-set-server-parameters server-ipv4 <server-
ipv4> server-path <server-path> filename <filename> server-username
<username> server-password <password>
```

If the IP address family is configured to be IPv6, enter the following command in root view to configure the SFTP server parameters for the CSR file upload:

```
root> platform security csr-set-server-parameters server-ipv6 <server-
ipv6> server-path <server-path> filename <filename> server-username
<username> server-password <password>
```

To display the currently-configured SFTP parameters for CSR upload, enter the following command in root view:

```
root> platform security csr-show-server-parameters
```

To generate and upload a CSR, enter the following command in root view:

```
root> platform security csr-generate-and-upload
```

To display the status of a pending CSR generation and upload operation, enter the following command in root view:

```
root> platform security csr-generate-and-upload-show-status
```

Table 314 CSR Generation and Upload CLI Parameters

Parameter	Input Type	Permitted Values	Description
common name	String		The fully-qualified domain name for your web server. You must enter the exact domain name.
country	String		The two-letter ISO abbreviation for your country (e.g., US)
state	String		The state, province, or region in which the organization is located. Do not abbreviate.
locality	String		The city in which the organization is legally located.
organization	String		The exact legal name of your organization. Do not abbreviate.
org-unit	String		The division of the organization that handles the certificate.
email	String		An e-mail address that can be used to contact your organization.
file-format	Variable	PEM DER	The file format of the CSR. In this version, only PEM is supported.
server-ipv4	Dotted decimal format.	Any valid IPv4 IP address.	The IP address of the FTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the SFTP server.

Parameter	Input Type	Permitted Values	Description
server-path	Text String		The directory path to which you are uploading the CSR. Enter the path relative to the SFTP user's home directory, not the absolute path. To leave the path blank, enter //.
filename	Text String		The name you want to give the CSR.
username	Text String		The user name for the SFTP session.
password	Text String		The password for the SFTP session. To configure the SFTP settings without a password, simply omit this parameter.

Downloading a Certificate (CLI)

If the IP address family is configured to be IPv4, enter the following command in root view to configure the SFTP server parameters for downloading a certificate:

```
root> platform security certificate-set-download-parameters server-ipv4
<server-ipv4> server-path <server-path> filename <filename> server-
username <username> server-password <password>
```

If the IP address family is configured to be IPv6, enter the following command in root view to configure the SFTP server parameters for downloading a certificate:

```
root> platform security certificate-set-download-parameters server-ipv6 <
server-ipv6> server-path <server-path> filename <filename> server-
username <username> server-password <password>
```

To display the currently-configured SFTP parameters for downloading a certificate, enter the following command in root view:

```
root> platform security certificate-show-download-parameters
```

To download a certificate, enter the following command in root view:

```
root> platform security certificate-download
```

To display the status of a pending certificate download, enter the following command in root view:

```
root> platform security certificate-download-show-status
```

To install a certificate, enter the following command in root view:

```
root> platform security certificate-install
```

Table 315 Certificate Download and Install CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 IP address.	The IPv4 address of the PC or laptop you are using as the SFTP server.

Parameter	Input Type	Permitted Values	Description
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the SFTP server.
server-path	Text String		The directory path from which you are downloading the CSR. Enter the path relative to the SFTP user's home directory, not the absolute path. To leave the path blank, enter //.
filename	Text String		The certificate's file name in the SFTP server.
username	Text String		The user name for the SFTP session.
password	Text String		The password for the SFTP session. To configure the SFTP settings without a password, simply omit this parameter.

Enabling HTTPS (CLI)

By default, HTTP is used by PTP 820G and PTP 820F as its web interface protocol.

To change the protocol to HTTPS, enter the following command in root view:

```
root> platform security url-protocol-set url-protocol https
```

**Note**

Make sure you have installed a valid certificate in the PTP 820G or PTP 820F before changing the web interface protocol to HTTPS. Failure to do this may prevent users from accessing the Web EMS.

To change the protocol back to HTTP, enter the following command in root view:

```
root> platform security url-protocol-set url-protocol http
```

To display which protocol is currently enabled, enter the following command in root view:

```
root> platform security url-protocol-show
```

Configuring HTTPS Cipher Hardening (CLI)

You can configure the PTP 820 to operate in HTTPS strong mode. In HTTPS strong mode, SSLv3, TLSv1.0, and TLSv1.1 are disabled completely and only certain ciphers are supported in TLSv1.2.

For a list of supported HTTPS ciphers, including an indication of which ciphers are supported in HTTPS strong mode,

To set HTTPS strong mode, enter the following command:

```
root> platform security https-ciphers-hardening-level-set level strong
```

To set HTTPS normal mode, enter the following command:

```
root> platform security https-ciphers-hardening-level-set level normal
```

Note: The default HTTP cipher mode is normal.

To display the current HTTPS cipher mode, enter the following command:

```
root> platform security https-ciphers-hardening-level-show
```

Blocking Telnet Access (CLI)

You can block telnet access to the unit. By default, telnet access is not blocked.

To block telnet access, enter the following command:

```
root> platform security protocols-control telnet admin set disable
```

To unblock telnet access, enter the following command:

```
root> platform security protocols-control telnet admin set enable
```

To display whether telnet is currently allowed (enable) or blocked (disable), enter the following command:

```
root> platform security protocols-control telnet show
```

Note: When you block telnet, any current telnet sessions are immediately disconnected.

Uploading the Security Log (CLI)

The configuration log lists actions performed by users to configure the system. This file is mostly used for security, to identify suspicious user actions. It can also be used for troubleshooting.

In order to read the security log, you must upload the log to an FTP or SFTP server. PTP 820G and PTP 820F works with any standard FTP or SFTP server. For details, see [Configuring the Internal Ports for FTP or SFTP](#).

To set the FTP parameters for security log upload, enter the following command in root view:

```
root> platform security file-transfer set server-path <server-path> file-name <file-name> ip-address <ip-address> protocol <protocol> username <username> password <password>
```

To display the FTP channel parameters for uploading the security log, enter the following command in root view:

```
root> platform security file-transfer show configuration
```

To upload the security log to your FTP server, enter the following command in root view:

```
root> platform security file-transfer operation set upload-security-log
```

To display the progress of a current security log upload operation, enter the following command in root view:

```
root> platform security file-transfer show operation
```

To display the result of the most recent current security log upload operation, enter the following command in root view:

```
root> platform security file-transfer show status
```

Table 316 Security Log CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-path	Text String		The directory path to which you are uploading the security log. Enter the path relative to the FTP user's home directory, not the absolute path. To leave the path blank, enter //.
file-name	Text String		The name you want to give the file you are uploading.
ip-address	Dotted decimal format.	Any valid IP address.	The IP address of the FTP server.
protocol	Variable	ftp sftp	
username	Text String		The user name for the FTP or SFTP session.

Parameter	Input Type	Permitted Values	Description
password	Text String		The password for the FTP or SFTP session. To configure the FTP settings without a password, simply omit this parameter.

The following commands configure an FTP channel for security log upload to IP address 192.168.1.80, in the directory “current”, with file name “security_log_Oct8.zip”, user name “anonymous”, and password “12345”, and initiate the upload:

```
root> platform security file-transfer set server-path \current file-name
security_log_Oct8.zip ip-address 192.168.1.80 protocol ftp username
anonymous password 12345
root> platform security file-transfer operation set upload-security-log
```

Uploading the Configuration Log (CLI)

The configuration log lists actions performed by users to configure the system. This file is mostly used for security, to identify suspicious user actions. It can also be used for troubleshooting.

In order to upload the configuration log, you must install an FTP or SFTP server on the laptop or PC from which you are performing the upload. PTP 820G works with any standard FTP or SFTP server. For details, see [Configuring the Internal Ports for FTP or SFTP](#).

To set the FTP or SFTP parameters for configuration log export, enter the following command in root view:

```
root> platform security configuration-log-upload-params set path <path>
file-name <file-name> ip-address <ip-address> protocol <protocol>
username <username> password <password>
```

To display the FTP or SFTP parameters for configuration log export, enter the following command in root view:

```
root> platform security configuration-log-upload-params show
```

To export the configuration log, enter the following command in root view:

```
root> platform security configuration-log upload
```

To display the status of a configuration log export operation, enter the following command in root view

```
root> platform security configuration-log-upload-status show
```

Table 317 Configuration Log CLI Parameters

Parameter	Input Type	Permitted Values	Description
path	Text String		The directory path to which you are exporting the configuration log. Enter the path relative to the FTP user's home directory, not the absolute path. To leave the path blank, enter //.
file-name	Text String		The name you want to give the file you are exporting. Note: You must add the suffix .zip to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix .zip manually. For example: UnitInfo.zip If the Unit Information file is exported several times consecutively, the file itself will not be replaced. Instead, the filename will be updated by time stamp. For example: UnitInfo.zip.11-05-14 03-31-04
ip-address	Dotted decimal format.	Any valid IP address.	The IP address of the PC or laptop you are using as the FTP or SFTP server.

Parameter	Input Type	Permitted Values	Description
protocol	Variable	ftp sftp	The file transfer protocol.
username	Text String		The user name for the FTP or SFTP session.
password	Text String		The password for the FTP or SFTP session. To configure the FTP or SFTP settings without a password, simply omit this parameter.

**Note**

The path and file name, together, cannot be more than:

If the IP address family is configured to be IPv4: 236 characters

If the IP address family is configured to be IPv6: 220 characters

The following commands configure an FTP channel for configuration log export to IP address 192.168.1.99, in the directory “current”, with file name “cfg_log”, user name “anonymous”, and password “12345.”

```
root> platform security configuration-log-upload-params set path \file-
name cfg_log ip-address 192.168.1.99 protocol ftp username anonymous
password 12345
root> platform unit-info channel set protocol ftp
```

The following command exports the configuration log to the external server location:

```
root> platform security configuration-log upload
```

Chapter 24: Alarm Management and Troubleshooting (CLI)

This section includes:

- [Viewing Current Alarms \(CLI\)](#)
- [Viewing the Event Log \(CLI\)](#)
- [Editing Alarm Text and Severity \(CLI\)](#)
- [Configuring a Timeout for Trap Generation \(CLI\)](#)
- **Error! Reference source not found.**
- [Activating the Radio Logger \(CLI\)](#)

The Radio Logger is available for PTP 820F. By default, the Radio Logger is inactive. When it is activated, it gathers technical data about the radio and its operation. It should only be activated by technical support personnel, or by the customer upon request of Cambium Customer Support team. Data gathered by the Radio Logger is added to the Unit Info file, which can be exported from the unit and sent to Customer Support upon their request. See **Error! Reference source not found..**

Note: In order to conserve CPU resources, do not activate the Radio Logger unless it is necessary for unit diagnostic purposes, and do not leave it active longer than necessary.

To activate the Radio Logger, enter the following command in root view:

```
root> logger start logger-type radio logger-duration <1-1440> slot1 1 port1 <1-2> slot2 1 port2 <1-2> slot3 1 port3 <1-2> slot4 1 port4 <1-2>
```

The `logger-duration` parameter is set in minutes. You can activate the logger on up to four radios in a single command. For example, the following command activates the logger for 40 minutes on carrier one of the RFUs connected to RFU1 and RFU2:

```
root> logger start logger-type radio logger-duration 40 slot1 1 port1 1 slot2 1 port2 3
```

For RFU-D and RFU-D-HP, you can activate the logger on one or both radio carriers. For example, the following command activates the logger for 60 minutes on both carriers on both of the RFUs connected to RFU1 and RFU2:

```
root> logger start logger-type radio logger-duration 40 slot1 1 port1 1 slot2 1 port2 2 slot3 1 port1 3 slot4 1 port2 4
```

To display whether the Radio Logger is currently active, enter the following command in root view:

```
root> logger get status logger-type radio
```

For example, the following display indicates the Radio Logger has been set for 20 minutes on both carriers of an RFU-D or RFU-D-HP connected to RFU1, and that the Logger is set to run for an additional 1191 seconds:

```
root> logger get status logger-type radio
Logger status:
Logger duration(in minutes): 20
Logger time left(in seconds): 1191
Active instances list:
Slot 1 Port 1
Slot 1 Port 2
root>
```

To stop the Radio Logger manually, enter the following command in root view:

```
root> logger stop logger-type radio
```

To delete all data that has been saved by the Radio Logger, enter the following command in root view:

```
root> logger delete logger files<logger-type>.
```

Important Note: Whenever you activate the Radio Logger, any previous Radio Logger results are deleted.

- [Performing Diagnostics \(CLI\)](#)
- [Working in CW Mode \(Single or Dual Tone\) \(CLI\)](#)

Related Topics:

- [Ethernet Pin-Outs and LEDs](#)
- [Uploading the Configuration Log \(CLI\)](#)



Note

External alarms can only be configured via the Web EMS. See [Configuring External Alarms](#).

Viewing Current Alarms (CLI)

To display all alarms currently raised on the unit, enter the following command in root view:

```
root> platform status current-alarm show module unit
```

To display the most severe alarm currently raised in the unit, enter the following command in root view:

```
root> platform status current-alarm show most-severe-alarm module unit
```

For example:

```
root> platform status current-alarm show most-severe-alarm module slot
all
Most Severe Alarm Table:
=====
Slot          Severity
=====
1             critical
64            cleared
68            cleared
root>
```

Modules are identified as follows:

- 1 – Fixed Interfaces
- 64 – LAG
- 66 – Multi-Carrier ABC
- 67 – XPIC
- 68 – HSB Radio Protection

To display the most severe alarm currently raised in the unit, enter the following command in root view:

```
root> platform status current-alarm show most-severe-alarm module unit
```

Viewing the Event Log (CLI)

The Event Log displays a list of current and historical events and information about each event.

To display the event log, enter the following command in root view:

```
root> platform status event-log show module unit
```

To clear the event log, enter the following command in root view:

```
root> platform status event-log clear module unit
```

Editing Alarm Text and Severity (CLI)

You can view a list of alarm types, edit the severity level assigned to individual alarm types, and add additional descriptive text to individual alarm types.

This section includes:

- [Displaying Alarm Information \(CLI\)](#)
- [Editing an Alarm Type \(CLI\)](#)
- [Setting Alarms to their Default Values \(CLI\)](#)

Displaying Alarm Information (CLI)

To display a list of all alarm types and their severity levels and descriptions, enter the following command in root view:

```
root> platform status alarm-management show alarm-id all
```

Editing an Alarm Type (CLI)

To edit an alarm type's severity level, enter the following command in root view:

```
root> platform status alarm-management set alarm-id <alarm-id> severity-level <severity-level>
```

To add descriptive information to an alarm type, enter the following command in root view:

```
root> platform status alarm-management set alarm-id <alarm-id> additional-text <additional-text>
```

Table 318 Editing Alarm Text and Severity CLI Parameters

Parameter	Input Type	Permitted Values	Description
alarm-id	Number	All valid alarm type IDs, depending on system configuration	Enter the unique Alarm ID that identifies the alarm type.
severity-level	Variable	indeterminate critical major minor warning	The severity of the alarm, as displayed to users.
additional-text	Text String	255 characters	An additional text description of the alarm type.

The following command changes the severity level of alarm type 401 (Ethernet Loss of Carrier) to minor:

```
root> platform status alarm-management set alarm-id 401 severity-level
minor
```

Setting Alarms to their Default Values (CLI)

To restore an alarm type's severity level and description to their default values, enter the following command in root view:

```
root> platform status alarm-management set alarm-id <alarm-id> restore
default
```

To restore the severity levels and descriptions of all alarm types to their default values, enter the following command in root view:

```
root> platform status alarm-management set all default
```

Table 319 Restoring Alarms to Default CLI Parameters

Parameter	Input Type	Permitted Values	Description
alarm-id	Number	All valid alarm type IDs, depending on system configuration	Enter the unique Alarm ID that identifies the alarm type.

The following command restores alarm type 401 (Ethernet Loss of Carrier) to its default severity level:

```
root> platform status alarm-management set alarm-id 401 restore default
```

Configuring a Timeout for Trap Generation (CLI)

You can configure a wait time of up to 120 seconds after an alarm is cleared in the system before the alarm is actually reported as being cleared. This prevents traps flooding the NMS in the event that some external condition causes the alarm to be raised and cleared continuously.

This means that when the alarm is cleared, the alarm continues to be displayed and no *clear alarm* trap is sent until the timeout period is finished. The timeout for trap generation can be configured via CLI. By default, the timeout is 10 seconds. If the timeout is set to 0, there is no timeout.

**Note**

If the unit is upgraded from an earlier version to System release 10.0 or higher, the timeout retains its previous value until it is changed. That means if it was never configured, it retains its previous default value of 0. If the unit is set to its factory default configuration, the timeout is set to 10 seconds.

To configure the timeout (in seconds) for trap generation, enter the following command in root view:

```
root> platform status alarm-management alarm-stabilization-set time <0-120>
```

To disable the timeout for trap generation, enter the following command in root view:

```
root> platform status alarm-management alarm-stabilization-set time 0
```

To display the current trap generation timeout, enter the following command in root view:

```
root> platform status alarm-management alarm-stabilization-show
```

The following command sets a trap generation timeout of 60 seconds:

```
root> platform status alarm-management alarm-stabilization-set time 60
```

Disabling Alarms and Events (CLI)

You can choose to disable selected alarms and events. Any alarm or event can be disabled, so that no indication of the alarm is displayed, and no traps are sent for the alarm.

If you disable an alarm that is currently raised, the alarm is treated as if it has been cleared. If an alarm that has been disabled is enabled while it is in a raised state, the alarm is treated as if it has just been raised when it is enabled.

If a timeout for trap generation is configured, and a disabled alarm is enabled while the alarm is raised, the timeout count begins to run when the alarm is enabled. If an alarm is disabled while raised, the timeout count begins to run upon disabling the alarm, and an alarm cleared trap is sent when the timeout expires.

To disable an alarm or event, enter the following command in root view:

```
root> platform status alarm-management set alarm-id <alarm ID> admin disable
```

To enable an alarm or event, enter the following command in root view:

```
root> platform status alarm-management set alarm-id <alarm ID> admin enable
```

To display a list of all disabled alarms and events, and their attributes, enter the following command in root view:

```
root> platform status alarm-management show all admin disable attributes
```

To display a list of all enabled alarms and events and their attributes, enter the following command in root view:

```
root> platform status alarm-management show all admin enable attributes
```

To enable all alarms and events, enter the following command in root view:

```
root> platform status alarm-management set all admin default
```

The alarm status commands `platform status alarm-management show alarm-id all` and `platform status alarm-management show alarm-id <alarm-id> attributes` display alarms, even if they are disabled. The Alarm Admin column in the output displays whether the alarm or event is enabled or disabled.

Configuring Voltage Alarm Thresholds and Displaying Voltage Threshold PMs (CLI)

You can configure undervoltage and overvoltage alarm thresholds. The default thresholds for FibeAir PTP 820F, PTP 820G are:

- Undervoltage Raise Threshold: 40V
- Undervoltage Clear Threshold: 42V
- Overvoltage Raise Threshold: 60V
- Overvoltage Clear Threshold: 58V

These thresholds determine when the following alarms are raised and cleared:

- Alarm #32000: Under voltage
- Alarm #32001: Over voltage

To display the current thresholds, enter the following command in root view.

```
root> platform management voltage thresholds show
```

To change the threshold for raising an undervoltage alarm, enter the following command in root view:

```
root> platform management undervoltage set raise-threshold <0-100>
```

To change the threshold for clearing an undervoltage alarm, enter the following command in root view:

```
root> platform management undervoltage set clear-threshold <0-100>
```

To change the threshold for raising an overvoltage alarm, enter the following command in root view:

```
root> platform management overvoltage set raise-threshold <0-100>
```

To change the threshold for clearing an overvoltage alarm, enter the following command in root view:

```
root> platform management overvoltage set clear-threshold <0-100>
```

You can display voltage PMs that indicate, per 15-minute and 24-hour periods:

- The number of seconds the unit was in an undervoltage state during the measured period.
- The number of seconds the unit was in an overvoltage state during the measured period.
- The lowest voltage during the measured period.
- The highest voltage during the measured period.

For PTP 820F, PTP 820G devices with two power inputs, the PMs are displayed for both inputs.

To display voltage PMs, enter the following command in root view:

```
root> platform management voltage pm show pm-interval-type <all|15min|24hr>
```

The IDF column indicates whether the PM is valid:

- 0 indicates a valid entry.
- 1 indicates an invalid entry. This can be caused by a power surge or power failure that occurred during the interval.

Uploading Unit Info (CLI)

You can generate a unit information file, which includes technical data about the unit. This file can be forwarded to customer support, at their request, to help in analyzing issues that may occur.



Note

For troubleshooting, it is important that an updated configuration file be included in User Info files that are sent to customer support. To ensure that an up-to-date configuration file is included, it is recommended to back up the unit's configuration before generating the Unit Info file.

In order to export a unit information file, you must install an FTP or SFTP server on the laptop or PC from which you are performing the upload. PTP 820G and PTP 820F works with any standard FTP or SFTP server. For details, see [Configuring the Internal Ports for FTP or SFTP](#).

To set the FTP or SFTP parameters for unit information file export, enter one of the following commands in root view. If the IP protocol selected in `platform management ip set ip-address-family` is IPv4, enter the destination IPv4 address. If the selected IP protocol is IPv6, enter the destination IPv6 address.

```
root> platform unit-info channel server set ip-address <server-ipv4>
directory <directory> filename <filename> username <username> password
<password>

root> platform unit-info channel server-ipv6 set ip-address <server-ipv6>
directory <directory> filename <filename> username <username> password
<password>
```

To set the protocol for unit information file export, enter the following command in root view.

```
root> platform unit-info channel set protocol <protocol>
```

To display the FTP or SFTP parameters for unit information file export, enter one of the following commands in root view:

```
root> platform unit-info-file channel show
root> platform unit-info-file channel-ipv6 show
```

To create a unit information file based on the current state of the system, enter the following command in root view:

```
root> platform unit-info-file create
```

To export the unit information file you just created, enter the following command in root view:

```
root> platform unit-info-file export
```

To display the status of a unit information file export operation, enter the following command in root view

```
root> platform unit-info-file status show
```

Table 320 Uploading Unit Info CLI Parameters

Parameter	Input Type	Permitted Values	Description
server-ipv4	Dotted decimal format.	Any valid IPv4 address.	The IPv4 address of the PC or laptop you are using as the FTP or SFTP server.
server-ipv6	Eight groups of four hexadecimal digits separated by colons.	Any valid IPv6 address.	The IPv6 address of the PC or laptop you are using as the FTP or SFTP server.
directory	Text String		The directory path to which you are exporting the unit information file. Enter the path relative to the FTP or SFTP user's home directory, not the absolute path. To leave the path blank, enter //.
filename	Text String		The name you want to give the file you are exporting. Note: You must add the suffix .zip to the file name. Otherwise, the file import may fail. You can export the file using any name, then add the suffix .zip manually.
username	Text String		The user name for the FTP or SFTP session.
password	Text String		The password for the FTP or SFTP session. To configure the FTP or SFTP settings without a password, simply omit this parameter.
protocol	Variable	ftp sftp	The file transfer protocol.

The following commands configure an FTP or SFTP channel for configuration log export to IP address 192.168.1.99, in the directory "current", with file name "cfg_log", user name "anonymous", and password "12345."

```
root> platform security configuration-log-upload-params set path \\ file-
name cfg_log ip-address 192.168.1.99 protocol ftp username anonymous
password 12345
root> platform unit-info channel set protocol ftp
```

The following commands create a unit information file and export the file to the external server location:

```
root> platform unit-info-file create
root> platform unit-info-file export
```

Activating the Radio Logger (CLI)

The Radio Logger is available for PTP 820F. By default, the Radio Logger is inactive. When it is activated, it gathers technical data about the radio and its operation. It should only be activated by technical support personnel, or by the customer upon request of Cambium Customer Support team. Data gathered by the Radio Logger is added to the Unit Info file, which can be exported from the unit and sent to Customer Support upon their request. See **Error! Reference source not found.**

Note: In order to conserve CPU resources, do not activate the Radio Logger unless it is necessary for unit diagnostic purposes, and do not leave it active longer than necessary.

To activate the Radio Logger, enter the following command in root view:

```
root> logger start logger-type radio logger-duration <1-1440> slot1 1 port1 <1-2> slot2 1 port2 <1-2> slot3 1 port3 <1-2> slot4 1 port4 <1-2>
```

The `logger-duration` parameter is set in minutes. You can activate the logger on up to four radios in a single command. For example, the following command activates the logger for 40 minutes on carrier one of the RFUs connected to RFU1 and RFU2:

```
root> logger start logger-type radio logger-duration 40 slot1 1 port1 1 slot2 1 port2 3
```

For RFU-D and RFU-D-HP, you can activate the logger on one or both radio carriers. For example, the following command activates the logger for 60 minutes on both carriers on both of the RFUs connected to RFU1 and RFU2:

```
root> logger start logger-type radio logger-duration 40 slot1 1 port1 1 slot2 1 port2 2 slot3 1 port1 3 slot4 1 port2 4
```

To display whether the Radio Logger is currently active, enter the following command in root view:

```
root> logger get status logger-type radio
```

For example, the following display indicates the Radio Logger has been set for 20 minutes on both carriers of an RFU-D or RFU-D-HP connected to RFU1, and that the Logger is set to run for an additional 1191 seconds:

```
root> logger get status logger-type radio
Logger status:
Logger duration(in minutes): 20
Logger time left(in seconds): 1191
Active instances list:
Slot 1 Port 1
Slot 1 Port 2
root>
```

To stop the Radio Logger manually, enter the following command in root view:

```
root> logger stop logger-type radio
```

To delete all data that has been saved by the Radio Logger, enter the following command in root view:

```
root> logger delete logger files<logger-type>.
```

Important Note: Whenever you activate the Radio Logger, any previous Radio Logger results are deleted.

Performing Diagnostics (CLI)

This section includes:

- [Performing Radio Loopback \(CLI\)](#)
- [Performing Ethernet Loopback \(CLI\)](#)
- [Performing TDM Diagnostics \(CLI\)](#)
- [Configuring Service OAM \(SOAM\) Fault Management \(FM\) \(CLI\)](#)

Performing Radio Loopback (CLI)



Note

To perform traffic-level diagnostics on a Multi-Carrier ABC group, the loopback must be activated for all members of the group. Radio-level diagnostics can still be performed on individual members of the group. For more information about Multi-Carrier ABC groups, see [Configuring Multi-Carrier ABC \(CLI\)](#).

To set the timeout for a radio loopback, go to radio view and enter the following command:

```
radio[x/x]> radio loopbacks-timeout set duration <duration>
```

To display the radio loopback timeout, go to radio view and enter the following command:

```
radio[x/x]>radio loopbacks-timeout show
```

To activate an IF loopback on the modem, enter the following command in radio view:

```
radio[x/x]>modem loopback-if set admin towards-system
```

To deactivate an IF loopback on the modem, enter the following command in radio view:

```
radio[x/x]>modem loopback-if set admin off
```

To display whether there is currently an active IF loopback on the radio level, enter the following command in radio view:

```
radio[x/x]>modem loopback-if show
```

To activate an RF loopback, enter the following command in radio view:

```
radio[x/x]> rf loopback-rf set admin <admin>
```

Table 321 Radio Loopback CLI Parameters

Parameter	Input Type	Permitted Values	Description
duration	Number	0 – 1440	The timeout, in minutes, for automatic termination of a loopback. A value of 0 indicates that there is no timeout.
admin	Variable	on off	Set on to initiate an RF loopback.

The following commands initiate an IF loopback on radio interface 2, with a timeout of two minutes:

```
radio[2/1]> radio loopbacks-timeout set duration 2
radio[2/1]>rf loopback-rf set admin on
```

Performing Ethernet Loopback (CLI)

Ethernet loopbacks can be performed on any logical Ethernet interface except a LAG. When Ethernet loopback is enabled on an interface, the system loops back all packets ingressing the interface. This enables loopbacks to be performed over the link from other points in the network.

To configure loopback on an Ethernet interface, go to interface view for the interface and enter the following command:

```
eth type eth[x/x]> loopback admin <loopback-admin-state>
```

To configure the loopback duration time, go to interface view for the interface and enter the following command:

```
eth type eth[x/x]> loopback set duration <loopback-duration>
```

You can select whether to swap DA and SA MAC addresses during the loopback. Swapping addresses prevents Ethernet loops from occurring. It is recommended to enable MAC address swapping if LLDP is enabled.

To configure MAC address swapping, go to interface view for the interface and enter the following command:

```
eth type eth[x/x]> loopback swap-mac-address admin <MAC_swap-admin-state>
```

To view loopback status, go to interface view for the interface and enter the following command:

```
eth type eth[x/x]> loopback status show
```

Table 322 Ethernet Loopback CLI Parameters

Parameter	Input Type	Permitted Values	Description
loopback-admin-state	Variable	enable disable	Enter enable to enable Ethernet loopback on the interface, or disable to disable Ethernet loopback on the interface.
loopback-duration	Number	1 - 900	The loopback duration time, in seconds.
MAC_swap-admin-state	Variable	enable disable	Enter enable to enable MAC address swapping, or disable to disable MAC address swapping.

The following command enables Ethernet loopback on Ethernet interface 2.

```
eth type eth [1/2]> loopback admin enable
```

The following command sets the loopback duration time to 900 seconds.

```
eth type eth [1/2]> loopback set duration 900
```

The following command enables MAC address swapping during the loopback.

```
eth type eth [1/2]> loopback swap-mac-address admin enable
```

The following command displays Ethernet port loopback status.

```
eth type eth [1/2]> loopback status show
```

Performing TDM Diagnostics (CLI)

This section includes:

- [Performing Loopback on E1/DS1s \(CLI\)](#)

Performing Loopback on E1/DS1s (CLI)

To configure a loopback on an E1/DS1 interface, enter the following command in pwe3 view:

```
pwe3> pwe3 tdm loopback set slot <slot> tdm-port <tdm-port> type <type>
```

Table 323 E1/DS1 Loopback CLI Parameters

Parameter	Input Type	Permitted Values	Description
slot	Number	1	
tdm-port	Number	1-16	The E1/DS1 port on which to run the loopback.
type	Variable	towards-line towards-system none	Determines the type of loopback.

Configuring Service OAM (SOAM) Fault Management (FM) (CLI)

This section includes:

- [SOAM Overview \(CLI\)](#)
- [Configuring MDs \(CLI\)](#)
- [Configuring MA/MEGs \(CLI\)](#)
- [Configuring MEPs \(CLI\)](#)
- [Displaying MEP and Remote MEP Attributes \(CLI\)](#)
- [Displaying Detailed MEP Error Information \(CLI\)](#)
- [Performing Loopback \(CLI\)](#)

SOAM Overview (CLI)

The Y.1731 standard and the MEF-30 specifications define Service OAM (SOAM). SOAM is concerned with detecting, isolating, and reporting connectivity faults spanning networks comprising multiple LANs, including LANs other than IEEE 802.3 media.

Y.1731 Ethernet FM (Fault Management) consists of three protocols that operate together to aid in fault management:

- Continuity check
- Link trace
- Loopback

**Note**

Link trace is planned for future release.

PTP 820 utilizes these protocols to maintain smooth system operation and non-stop data flow.

The following are the basic building blocks of FM:

- MD (Maintenance Domain) – An MD defines the management space on a network, typically owned and operated by a single entity, for which connectivity faults are managed via SOAM.
- MA/MEG (Maintenance Association/Maintenance Entity Group) – An MA/MEG contains a set of MEPs or MIPs.
- MEP (MEG End Points) – Each MEP is located on a service point of an Ethernet service at the boundary of the MEG. By exchanging CCMs (Continuity Check Messages), local and remote MEPs have the ability to detect the network status, discover the MAC address of the remote unit/port where the peer MEP is defined, and identify network failures.
- MIP –(MEG Intermediate Points) – Similar to MEPs, but located inside the MEG and can only respond to, not initiate, CCM messages.

- CCM (Continuity Check Message) – MEPs in the network exchange CCMs with their peers at defined intervals. This enables each MEP to detect loss of connectivity or failure in the remote MEP.

Configuring MDs (CLI)

In the current release, you can define one MD, with an **MD Format of None**.

To add an MD, enter the following command in root view:

```
root> ethernet soam md create md-id <md-id> md-format none md-name <md-name> md-level <md-level>
```



Note

Support for MDs with the MD format Character String is planned for future release. In this release, the software enables you to configure such MDs, but they have no functionality.

The following command creates MD 5, named TR-988 with maintenance level 5.

```
root> ethernet soam md create md-id 5 md-format none md-name TR-988 md-level 5
```

To delete an MD, enter the following command in root view. Before deleting an MD, you must delete any MA/MEG associated with the MD.

```
root> ethernet soam md delete md-id <md-id>
```

To display a list of MDs and their attributes, enter the following command in root view:

```
root> ethernet soam md show
```

Table 324 Maintenance Domain CLI Parameters

Parameter	Input Type	Permitted Values	Description
md-id	Number	1-4294967295	
md-name	String	Up to 43 alphanumeric characters.	An identifier for the MD. The MD Name should be unique over the domain.
md-level	Number	0-7	The maintenance level of the MD. The maintenance level ensures that the CFM frames for each domain do not interfere with each other. Where domains are nested, the encompassing domain must have a higher level than the domain it encloses. The maintenance level is carried in all CFM frames that relate to that domain. The maintenance level must be the same on both sides of the link. Note: In the current release, the maintenance level is not relevant to the SOAM functionality.

Configuring MA/MEGs (CLI)

You can configure up to 448 MEGs per network element. MEGs are classified as Fast MEGs or Slow MEGs according to the CCM interval (see [Table 325](#)):

- Fast MEGs have a CCM interval of 1 second.
- Slow MEGs have a CCM interval of 10 seconds, 1 minute, or 10 minutes.

You can configure up to 64 MEP pairs per network element.

To add an MA/MEG, enter the following command in root view:

```
root> ethernet soam meg create meg-id <meg-id> meg-fmt charString meg-name <meg-name> meg-level <meg-level> service-id <0-4095>
```



Note

In the current release, charString is the only available MEG name format.

The following command creates MEG ID 1, named FR-10, with MEG level 4, assigned to Ethernet service 20.

```
root> ethernet soam meg create meg-id 1 meg-fmt charString meg-name FR-10 meg-level 4 service-id 20
```

To set the interval at which CCM messages are sent within the MEG, enter the following command in root view:

```
root> ethernet soam meg ccm-interval set meg-id <meg-id> ccm <ccm>
```

The following command sets an interval of one second between CCM messages for MEG 1.

```
root> ethernet soam meg ccm-interval set meg-id 1 ccm intervals
```

To determine whether MIPs are created on the MEG, enter the following command in root view:

```
root> ethernet soam meg mip set meg-id <meg-id> mhf <1-4|defMHFnone|defMHFdefault|defMHFexplicit|defMHFdefer>
```

For example, the following command creates MIPs on any service point in the MEG:

```
root> ethernet soam meg mip set meg-id 1 mhf defMHFdefault
```

To delete a MEG, enter the following command in root view:

```
root> ethernet soam meg delete <meg-id> ccm <ccm>
```



Note

You can only delete a MEG if no MEPs or MIPs are attached to the MEP.

To display a list of all MEGs configured on the unit, enter the following command in root view:

```
root> ethernet soam meg show
```

To display MEG attributes, including the number of MEPS, local MEPS, and MIPs attached to the MEG, enter the following command in root view:

```
root> ethernet soam meg attributes show meg-id <meg-id>
```

Table 325 SOAM MEG CLI Configuration Parameters

Parameter	Input Type	Permitted Values	Description
meg-id	Number	1-4294967295	Enter an ID for the MEG.
meg-name	String	Up to 44 alphanumeric characters	A name to identify the MEG.
meg-level	Number	0-7	<p>The MEG level must be the same for MEGs on both sides of the link. Higher levels take priority over lower levels.</p> <p>If MEGs are nested, the OAM flow of each MEG must be clearly identifiable and separable from the OAM flows of the other MEGs. In cases where the OAM flows are not distinguishable by the Ethernet layer encapsulation itself, the MEG level in the OAM frame distinguishes between the OAM flows of nested MEGs.</p> <p>Eight MEG levels are available to accommodate different network deployment scenarios. When customer, provider, and operator data path flows are not distinguishable based on means of the Ethernet layer encapsulations, the eight MEG levels can be shared among them to distinguish between OAM frames belonging to nested MEGs of customers, providers and operators. The default MEG level assignment among customer, provider, and operator roles is:</p> <ul style="list-style-type: none"> • The customer role is assigned MEG levels 6 and 7 • The provider role is assigned MEG levels 3 through 5 • The operator role is assigned MEG levels: 0 through 2 <p>The default MEG level assignment can be changed via a mutual agreement among customer, provider, and/or operator roles.</p> <p>The number of MEG levels used depends on the number of nested MEGs for which the OAM flows are not distinguishable based on the Ethernet layer encapsulation.</p>
service-id	Number	0-4095	Assign the MEG to an Ethernet service. You must define the service before you configure the MEG.

Parameter	Input Type	Permitted Values	Description
ccm	Variable	interval1s interval10s interval1min interval10min	interval1s – One second (default) interval10s – 10 seconds interval1min – One minute interval10min – 10 minutes It takes a MEP 3.5 times the CCM interval to determine a change in the status of its peer MEP. For example, if the CCM interval is 1 second, a MEP will detect failure of the peer 3.5 seconds after it receives the first CCM failure message. If the CCM interval is 10 minutes, the MEP will detect failure of the peer 35 minutes after it receives the first CCM failure message.
mhf	Variable	defMHFnone defMHFdefault defMHFexplicit defMHFdefer	Determines whether MIPs are created on the MEG. Options are: defMHFnone – No MIPs are created. defMHFdefault – MIPs are created on any service point in the MEG. defMHFexplicit – MIPs are created on the service points of the MEG when a lower-level MEP exists on the service point. This option is usually used when the operator’s domain is encompassed by another domain. defMHFdefer – No MIPs are created.

Configuring MEPs (CLI)

Each MEP is attached to a service point in an Ethernet service. The service and service point must be configured before you configure the MEP. See [Configuring Ethernet Services \(CLI\)](#).

Each MEP inherits the same VLAN, C-VLAN, or S-VLAN configuration as the service point on which it resides. See [Configuring Service Points \(CLI\)](#).

In order to set the VLAN used by CCM/LBM/LTM if the service point is defined ambiguously (for example PIPE, Bundle-C, Bundle-S, or All-to-One), the service point’s C-VLAN/S-VLAN parameter should *not* be set to N.A.

To configure a MEP, you must:

- 1 Add MEPs to the relevant MA/MEG. In this stage, you add both local and remote MEPs. The only thing you define at this point is the MEP ID. See [Adding Local and Remote MEPs \(CLI\)](#).
- 2 Configure the local MEPs. At this point, you determine which MEPs are local MEPs. The system automatically defines the other MEPs you configured in the previous step as remote MEPs. See [Configuring the Local MEPs \(CLI\)](#).
- 3 Enable the Local MEPs. See [Enabling Local MEPs \(CLI\)](#).

Adding Local and Remote MEPs (CLI)

To add a MEP, enter the following command in root view:

```
root> ethernet soam meg mep add meg-id <meg-id> mep-id <mep-id>
```

The following command adds MEP 25 on MEG 2.

```
root> ethernet soam meg mep add meg-id 2 mep-id 25
```

To remove a MEP, enter the following command in root view:

```
root> ethernet soam meg mep remove meg-id <meg-id> mep-id <mep-id>
```

The following command removes MEP 25 from MEG 2.

```
root> ethernet soam meg mep remove meg-id 2 mep-id 25
```

To display a list of all MEPs that belong to a specific MEG, enter the following command in root view:

```
root> ethernet soam meg mep show meg-id <meg-id>
```

Configuring the Local MEPs (CLI)

Once you have added local and remote MEPs, you must configure the MEPs and determine which are the local MEPs.

To make a defined MEP a local MEP, you must assign the MEP to a service point on the Ethernet service on which the MEG resides.

To assign a MEP to a service point, enter the following command in root view:

```
root> ethernet soam mep create meg-id <meg-id> mep-id <mep-id> sp-id <sp-id> mep-dir <mep-dir>
```

The following command assigns MEP 35 on MEG 2 to Service Point 3 on the service on which MEG 2 resides.

```
root> ethernet soam mep create meg-id 2 mep-id 35 sp-id 3 mep-dir down
```

To change a MEP from a local to a remote MEP, enter the following command in root view:

```
root> ethernet soam mep delete meg-id <meg-id> mep-id <mep-id>
```

The following command changes MEP 35 from a local to a remote MEP.

```
root> ethernet soam mep delete meg-id 2 mep-id 35
```

To display a list of local MEPs for a specific MEG, enter the following command in root view:

```
root> ethernet soam meg local-mep show meg-id <meg-id>
```

For example:

```

root> ethernet soam meg local-mep show meg-id 2
MEG:
=====
|MA ID|Format      |Name          |Level |Service|
-----|-----|-----|-----|-----|
|2    |charString    |TR-98         |0     |1     |
-----|-----|-----|-----|-----|
MEP:
=====
|MepId  |Interface |Direction |Active  |SP ID |
-----|-----|-----|-----|-----|
|25     |eth 1/1   |down      |true   |1     |
-----|-----|-----|-----|-----|
|35     |eth 1/2   |down      |false  |3     |
-----|-----|-----|-----|-----|
root> _

```

Enabling Local MEPs (CLI)

Once you have added a MEP and defined it as a local MEP, you must enable the MEP by setting the MEP to Active, enabling CCM messages from the MEP, and assigning a CCM-LTM priority to the MEP.

To set a MEP to Active, enter the following command in root view:

```
root> ethernet soam mep active set meg-id <meg-id> mep-id <mep-id> mep-active <mep-active>
```

The following command sets MEP 35 on MEG 2 to Active.

```
root> ethernet soam mep active set meg-id 2 mep-id 35 mep-active true
```

To enable or disable the sending of CCM messages on a MEP, enter the following command in root view:

```
root> ethernet soam mep ccm-enable set meg-id <meg-id> mep-id <mep-id> enabled <ccm-enabled>
```

The following command assigns enables CCM messages for MEP 35 on MEG 2.

```
root> ethernet soam mep ccm-enable set meg-id 2 mep-id 35 enabled true
```

To set a MEP's CCM-LTM priority, enter the following command in root view:

```
root> ethernet soam mep ccm-ltm-prio set meg-id <meg-id> mep-id <mep-id> ccm-ltm-priority <ccm-ltm-priority>
```

The following command sets the CCM-LTM priority of MEP 35 in MEG 2 to 5.

```
root> ethernet soam mep ccm-ltm-prio set meg-id 2 mep-id 35 ccm-ltm-priority 5
```

Table 326 MEP CLI Configuration Parameters

Parameter	Input Type	Permitted Values	Description
meg-id	Number	1-4294967295	Enter an ID for the MEG.
mep-id	Number	1-8191	A name to identify the MEG.
sp-id	Number	0-32	The Service Point ID of the service point to which you want to assign the MEP.
mep-dir	Variable	up down	The MEP direction.

Parameter	Input Type	Permitted Values	Description
ccm-enabled	Variable	true false	true – CCM messages are enabled on the MEP. false – CCM messages are disabled on the MEP.
ccm-ltm-priority	Number	0-7	The p-bit included in CCMs sent by this MEP.
mep-active	Variable	true false	true – The MEP is Active. false – The MEP is Inactive.

Displaying MEP and Remote MEP Attributes (CLI)

To display the attributes of a specific MEP, enter the following command in root view:

```
root> ethernet soam mep configuration general show meg-id <meg-id <meg-id> mep-id <mep-id>
```

For example:

```
root> ethernet soam mep configuration general show meg-id 2 mep-id 25
MEG:
=====
|MA ID|Format      |Name                    |Level |Service|
|-----|-----|-----|-----|-----|
|2     |charString    |TR-98                   |0     |1     |
|-----|-----|-----|-----|-----|
SOAM MEP Table:
=====
Interface  MEP      MEP Active  MEP CCM   CCM and  MEP MAC      MEP Lowest  MEP Alarm  MEP Alarm
Location  Direction  TX Enable  LTM      Priority  Address      priority    on time    Clear Time
|-----|-----|-----|-----|-----|-----|-----|-----|-----|
eth 1/1 |down      |true       |true      |7         |0:a:25:38:9:4b |allDef     |250       |1000
|-----|-----|-----|-----|-----|-----|-----|-----|-----|
root>
```

To display a list of remote MEPs (RMEPs) and their parameters per MEG and local MEP, enter the following command in root view:

```
root> ethernet soam mep rmep list show meg-id <meg-id <meg-id> mep-id <mep-id>
```

For example:

```

root> ethernet soam mep rmep list show meg-id 2 mepid 25
MD:
-----
|MD ID|MD Name                |MD Format  |MD Level|
-----
|1   |TR-995                    |none      |5      |
-----

MEG:
-----
|MA ID|Format      |Name      |Level |Service|CCM Interval  |Number of MEPs |Number of Local MEPs |Number of MIPs|
-----
|2   |charString |TR-98    |0     |1     |intervals    |4             |2                 |0             |
-----

SOAM MEP Table:
=====
MEP ID   Interface Location  MEP Direction  MEP Active  MEP CCM TX Enable  CCM and LTM Priority
-----
25      |eth 1/1 |down     |true       |true       |7
-----

RMEPs:
=====
| RmepId | State      | MAC                | Rdi |
-----
|45      |rMepFailed|ff:ff:ff:ff:ff:ff|false|
-----
|55      |rMepFailed|ff:ff:ff:ff:ff:ff|false|
-----

```

To display a list of remote MEPs (RMEPs) and their parameters per MEG and local MEP, enter the following command in root view:

```

root> ethernet soam mep rmep show meg-id meg-id < meg-id <meg-id> mep-id
<mep-id> rmep-id <rmep-id>

```

For example:

```

root> ethernet soam mep rmep show meg-id 2 mep-id 35 rmep-id 45
MD:
-----
|MD ID|MD Name                |MD Format  |MD Level|
-----
|1   |TR-995                    |none      |5      |
-----

MEG:
-----
|MA ID|Format      |Name      |Level |Service|CCM Interval  |Number of MEPs |Number of Local MEPs |Number of MIPs|
-----
|2   |charString |TR-98    |0     |1     |intervals    |4             |2                 |0             |
-----

SOAM MEP Table:
=====
MEP ID   Interface Location  MEP Direction  MEP Active  MEP CCM TX Enable  CCM and LTM Priority  MEP MAC Address  MEP Lowest priority fault alarm  MEP Alarm on time  MEP Alarm Clear Time  Sequence Errors CCM Frames  CCM Messages TX
-----
35      |eth 1/2 |down     |true       |true       |5              |0:a:25:38:9:50  |allDef              |250                 |1000                |0                 |389
-----

RMEP:
=====
|MepId|RmepId|operState |OKorFail Time| MAC                | Rdi | port Status  |interface Status  | ChassisID format | Chassis ID  | Mng Addr Domain |
-----
|35  |45   |rMepFailed|6874         |ff:ff:ff:ff:ff:ff|false|psNoPortStateTLV|isNoInterfaceStatus|None              |              |0                 |
-----
root> _

```

Table 327 MEP and Remote MEP Status Parameters (CLI)

Parameter	Definition
MD Parameters	
MD ID	The MD ID.
MD Name	The MD name (44 characters).
MD Format	The MD format (None).

Parameter	Definition
MD Level	The maintenance level of the MD (0-7).
MEG Parameters	
MA ID	The MA/MEG ID.
Format	charString in the current release.
Name	The MA/MEG name (43 characters).
Level	The MEG Level (0-7).
Service	The Service ID of the Ethernet service to which the MEG belongs.
CCM Interval	The interval at which CCM messages are sent within the MEG.
Number of MEPs	The number of MEPs that belong to the MEG.
Number of Local MEPs	The number of local MEPs that belong to the MEG.
Number of MIPs	The number of MIPs that belong to the MEG.
SOAM MEP Table Parameters	
MEP ID	The MEP ID.
Interface Location	The interface on which the service point associated with the MEP is located.
MEP Direction	Up or Down.
MEP Active	Indicates whether the MEP is enabled (true) or disabled (false).
MEP CCM TX Enable	Indicates whether the MEP is configured to send CCMs (true or false).
CCM and LTM Priority	The p-bit included in CCMs sent by the MEP (0-7).
MEP MAC Address	The MAC address of the service point associated with the MEP.
MEP Lowest priority fault alarm	The lowest defect priority that can trigger alarm generation. Defects with a lower priority will not trigger alarms.
MEP Alarm on time	The amount of time that defects must be present before an alarm is generated, in msec intervals (250-1000).
MEP Alarm Clear Time	The amount of time that defects must be absent before an alarm is cleared, msec intervals (250-1000).
Sequence errors CCM Frames	The number of out-of-sequence CCM messages received.
CCM Messages TX	The number of transmitted CCM messages.
RMEP Parameters	
MepId	The MEP ID of the local MEP paired with the remote MEP.
Rmep Id	The remote MEP ID.

Parameter	Definition
operState	The operational state of the remote MEP.
OKorFail Time	The timestamp marked by the remote MEP indicating the most recent CCM OK or failure it recorded. If none, this field indicates the amount of time, in msec intervals, since SOAM was activated.
MAC	The MAC Address of the interface on which the remote MEP is located.
Rdi	Displays the state of the RDI (Remote Defect Indicator) bit in the most recent CCM received by the remote MEP: <ul style="list-style-type: none"> • True – RDI was received in the last CCM. • False – No RDI was received in the last CCM.
Port Status	The Port Status TLV in the most recent CCM received from the remote MEP. Reserved for future use.
Interface Status	The Interface Status TLV in the most recent CCM received from the remote MEP. Indicates the operational status of the interface (Up or Down).
Chassis ID Format	Displays the address format of the remote chassis (in the current release, MAC Address).
Chassis ID	Displays the MAC Address of the remote chassis.
Mng Addr Domain	Displays the BASE MAC address of the remote unit (the unit on which the remote MEP resides),.

Displaying Detailed MEP Error Information (CLI)

To display the entire frame of the last CCM error message and the last CCM cross-connect error message received by a specific local MEP, along with other detailed information, enter the following command in root view:

```
root> ethernet soam mep status general show meg-id <meg-id> mep-id <mep-id> detailed yes
```

For example:

```
root> ethernet soam mep status general show meg-id 2 mep-id 25 detailed yes
MEG:
=====
|MA ID|Format      |Name                                     |Level |Service|
|-----|-----|-----|-----|-----|
|2     |charString    |TR-98                                   |0     |1     |
|-----|-----|-----|-----|-----|

SOAM MEP Table:
=====
MEP Fault      MEP highest  MEP Defects  Sequence    CCM Messages TX
Notification State priority    fault alarm  Errors      CCM Frames
-----
fngDefectReported defRemoteCCM bDefRemoteCCM 0          10469

SOAM MEP Table:
=====
Last RX error CCM message          Last RX Xcon fault message
-----
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000
00000000000000000000000000000000 00000000000000000000000000000000

SOAM MEP MEF Status Table:
=====
MEP Operational  Connectivity  Last Sent Port status TLV  Last Sent Interface  Last MEP  RDI TX
State           Status                               status TLV              status TLV            Defects    indication
-----
enabled         inactive     psNoPortStateTLV         isDown                None       false
root> _
```

To display the same information without the last RX error CCM and fault messages, enter the following command in root view:

```
root> ethernet soam mep status general show meg-id <meg-id> mep-id <mep-id> detailed no
```

The **Last RX error CCM message** field displays the frame of the last CCM that contains an error received by the MEP.

The **Last RX Xcon fault message** field displays the frame of the last CCM that contains a cross-connect error received by the MEP.



Note

A cross-connect error occurs when a CCM is received from a remote MEP that has not been defined locally.

Performing Loopback (CLI)

To set the interval between loopback message transmissions in a loopback session, enter the following command in root view:

```
root> ethernet soam loopback interval set meg-id <meg-id> mep-id <mep-id>
interval <0-60000>
```

For example, the following command sets the loopback interval for MEP 25 on MEG 1 to 5 seconds:

```
root> ethernet soam loopback interval set meg-id 1 mep-id 25 interval
5000
```

To set the loopback message frame size and data pattern, enter the following command in root view:

```
root> ethernet soam loopback data set meg-id <meg-id> mep-id <mep-id>
size <size> pattern <pattern>
```

For example, the following command sets the loopback frame size to 128 and the pattern to zero for MEP 25 on MEG 1 to 5 seconds:

```
root> ethernet soam loopback data set meg-id 1 mep-id 25 size 128 pattern
zeroPattern
```

To set the loopback priority bit size and drop-enable parameters, enter the following command in root view:

```
root> ethernet soam loopback prio set meg-id <meg-id> mep-id <mep-id>
prio <priority> drop <drop>
```

For example, the following command sets a priority bit size of 5 and enables frame dropping for MEP 25 on MEG 1 to 5 seconds:

```
root> ethernet soam loopback prio set meg-id 1 mep-id 25 prio 5 drop true
```

To set the loopback destination by MAC address, set the number of loopback messages to transmit and the interval between messages, and initiate the loopback, enter the following command in root view:

```
root> ethernet soam loopback send meg-id <meg-id> mep-id <mep-id> dest-
mac-addr <dest-mac-addr> tx-num <tx-num> tx-interval <interval>
```

For example, the following command initiates a loopback session with the interface having MAC address 00:0A:25:38:09:4B. The session is configured to send 100 loopback messages at six-second intervals.

```
root> ethernet soam loopback send meg-id 1 mep-id 25 dest-mac-addr
00:0A:25:38:09:4B tx-num 100 tx-interval 6000
```

To set the loopback destination by MEP ID, set the number of loopback messages to transmit and the interval between messages, and initiate the loopback, enter the following command in root view:

```
root> ethernet soam loopback send meg-id <meg-id> mep-id <mep-id> dest-
mep-id <dest-mac-addr> tx-num <tx-num> tx-interval <interval>
```

For example, the following command initiates a loopback session with the interface having MAC address 00:0A:25:38:09:4B. The session is configured to send 100 loopback messages at six-second intervals.

```
root> ethernet soam loopback send meg-id 1 mep-id 25 dest-mac-addr
00:0A:25:38:09:4B tx-num 100 tx-interval 6000
```



Note

If you initiate the loopback via MEP ID, the loopback will only be activated if CCMs have already been received from the MEP. For this reason, it is recommended to initiate loopback via MAC address.

To display the loopback attributes of a MEP, enter the following command in root view:

```
root> ethernet soam loopback config show meg-id <meg-id> mep-id <mep-id>
```

For example:

```

root> ethernet soam loopback config show meg-id 1 mep-id 25
SOAM MEP LBM Attributes Table:
=====
Loopback Messages Loopback Messages Loopback Drop Loopback Loopback Loopback Loopback
messages to be Messages Messages Enable Messages Messages Messages Replies
transmitted Destination Priority MAC Address Interval Frame Size Data Pattern Age-out
Type
=====
1 0:0:0:0:0:0 5 true 5000 128 zeroPattern 5
root> _

```

To stop a loopback that is already in progress, enter the following command in root view:

```
root> ethernet soam loopback stop meg-id <meg-id> mep-id <mep-id>
```

Table 328 Loopback CLI Parameters

Parameter	Input Type	Permitted Values	Description
meg-id	Number	1-4294967295	The MEG ID of the MEG on which the loopback is being configured or run.
mep-id	Number	1-8191	The MEP ID of the MEP on which the loopback is being configured or run.
interval	Number	0-60000	The interval (in ms) between each loopback message. Note that the granularity for this parameter is 100 ms. If you enter a number that is not in multiples of 100, the value will be rounded off to the next higher multiple of 100. Also, the lowest interval is 1000 ms (1 second). If you enter a smaller value, it will be rounded up to 1000 ms.
size	Number	64-1518	The frame size for the loopback messages. Note that for tagged frames, the frame size will be slightly larger than the selected frame size.
pattern	Variable	zeroPattern onesPatter	The type of data pattern to be sent in an OAM PDU Data TLV.
priority	Number	0-7	The priority bit for tagged frames.
drop	Boolean	true false	true – Frame dropping is enabled. false – Frame dropping is disabled.
dest-mac-addr	Six groups of two hexadecimal digits		The MAC address of the interface to which you want to send the loopback. If you are not sure what the interface's MAC address is, you can get it from the Interface Manager by entering the <code>platform if-manager show interfaces</code> command in root view.

Parameter	Input Type	Permitted Values	Description
dest-mep-id	Number	1-8191	The MEP ID of the interface to which you want to send the loopback.
tx-num	Number	0-1024	The number of loopback messages to transmit. If you enter 0, loopback will not be performed.

To display loopback results, enter the following command in root view:
`root> ethernet soam loopback status show meg-id <meg-id> mep-id <mep-id>`

The following is a sample output for this command on MEG ID 127, MEP ID 1.

```

root> ethernet soam loopback status show meg-id 127 mep-id 1

SOAM MEP LBM Attributes Table:
=====
Loopback   Loopback   Loopback   Transacti   Loopback   Next       Loopback   Loopback   Valid     Loopback   Valid     Bad MSDU   Loopback   Loopback
messages  messages  replies   on ID of   session   transacti  messages  messages  in-order  replies   out-of-or  Loopback  messages  replies
transmitt left to    received  1st       state     on ID      transmitt  received  loopback  transmitt  der        Replies   recieved  recieved
ed in     transmit  in session loopback   message  ed         ed         replies   ed         loopback  loopback  with bad  with bad
session  in session  message  message  message  message  message  message  received  received  loopback  loopback  sender id sender id
-----
9         114       9         1         soamLbAct 10        9         0         9         0         0         0         0         0
ive
root>
    
```

Working in CW Mode (Single or Dual Tone) (CLI)

CW mode enables you to transmit a single or dual frequency tones, for debugging purposes.

To work in CW mode, go to radio view and enter the following command:

```
radio[x/x] modem tx-source set admin enable
```

Once you are in CW mode, you can choose to transmit in a single tone or two tones.

To transmit in a single tone, enter the following command in radio view:

```
radio[x/x] modem tx-source set mode one-tone freq-shift <freq-shift>
```

To transmit two tones, enter the following command in radio view:

```
radio[x/x] modem tx-source set mode two-tone freq-shift <freq-shift>  
freq-shift2 <freq-shift>
```

To exit CW mode, go to radio view and enter the following command:

```
radio[x/x] modem tx-source set admin disable
```

Table 329 CW Mode CLI Parameters

Parameter	Input Type	Permitted Values	Description
freq-shift	Number	0-7000	Enter the frequency you want to transmit, in KHz.

The following commands set a single-tone transmit frequency of 5050 KHz on radio interface 1, then exit CW mode and return the interface to normal operation:

```
root> radio slot 2 port 1  
radio[2/1] modem tx-source set admin enable  
radio[2/1] radio[x/x] modem tx-source set mode one-tone freq-shift 5050  
radio[2/1] modem tx-source set admin disable
```

Chapter 25: Fault Finding

The equipment designed to be highly reliable and relatively maintenance free. In the event of a system failure, the system will provide detailed indications to assist troubleshooting and fault isolation. This chapter explains the alarm indications, and contains procedures for troubleshooting and fault isolation.

To ensure simple and efficient system maintenance, the on-site technician will only replace IDU or RFU modules, and not repair them. Under no circumstance will the technician be permitted to open the equipment in order to repair a module or circuit board. Opening equipment will terminate the warranty.

Maintenance procedures the technician can perform include visual inspection, cleaning, cable/connector repair, link alignment/adjustment, and re-torquing antenna mount bolts.

The following table lists the suggested preventive maintenance procedures, which include visual inspection of the equipment and verification of operational parameters.

It is recommended to perform the procedures as often as local environmental conditions require. It is recommended to notify the end customer prior to performing any preventive maintenance procedures that could affect service on the circuit.

Table 330 Fault Finding Checklist

What to Check	Check for...	Comments
IDU alarm LEDs	All green	If not, perform troubleshooting
Coax cable connection	Tight, no corrosion or moisture	Clean/repair as required
Coax cable	No cracks or kinks	Replace as required
All equipment	Dust or dirt	Clean as required
Receive level (voltage in IDU/ODU/RFU, or using management)	Per installation records	Align/adjust as required
Torque on antenna mount bolts	Tight mount	Adjust as required

Corrective maintenance consists of the steps described below. The steps provide a logical, sequential method for diagnosing and resolving system problems.

Step 1: Define the Symptom

This step is generally performed by the customer's field technician or supervisor. Examples of symptoms include "IDU alarm is red", "complete loss of service", and "excessive errors".

Symptoms may be constant or intermittent. Constant symptoms require immediate troubleshooting attention. Intermittent symptoms may require circuit monitoring or robust test procedures prior to troubleshooting.

Step 2: Isolate the Problem

After you have a clear definition of the symptom, the malfunction can be isolated using diagnostics, loopback testing, fault isolation tables/flow charts, test equipment, and manual procedures.

This step will identify the specific piece of equipment that is failing.

Although it may be difficult at times to immediately determine which part of a radio link is causing the fault, the initial suspicion should be focused on one of the following near-end or far-end issues:

- Power supplies
- Fading (due to heavy rain, new obstacle in path, antenna misalignment)
- External equipment (SDH/SONET, ATM, Fast Ethernet, etc.)
- Indoor Unit (IDU)
- Radio Frequency Unit (RFU)
- RF cable between the RFU and IDU
- Exposure of equipment to severe conditions (high temperature, etc.)
- System configuration

Temperature Ranges

The following are the permissible IDU temperature ranges:

- **-5°C to 55°** – Temperature range for continuous operating temperature with high reliability.
- **-25°C to 65°C** – Temperature range for exceptional temperatures, tested successfully, with limited margins.

An extreme temperature alarm is raised if the IDU temperature goes above 65°C or below -20°C. The alarm is cleared when the temperature goes below 60°C or above -15°C.

To display the current IDU temperature, see [Configuring Unit Parameters](#) or [Configuring Unit Parameters \(CLI\)](#).

The permissible IDU humidity range is 5%RH to 95%RH.

The following are the permissible RFU temperature ranges:

- **-33°C to +55°C** – Temperature range for continuous operating temperature with high reliability:
- **-45°C to +60°C** – Temperature range for exceptional temperatures; tested successfully, with limited margins:

To display the current RFU temperature, see [Viewing the Radio Status and Settings](#) or [Viewing the Radio Status and Settings \(CLI\)](#).

The permissible RFU humidity range is 5%RH to 100%RH.

Troubleshooting Tips

- For dual-polarization and XPIC links, if one of the polarizations has significantly reduced performance, check to make sure the antenna's rectangular interface was replaced with a circular adaptor.
- For dual-polarization and XPIC links, the RSL should be similar for both polarizations. For XPIC links, the XPI value should be similar for both polarizations; the difference should not be more than 2 dB.
- In case of a *Radio loss of frame* alarm on an PTP 820F unit, the problem is most likely with the RFU or the RFU-antenna connection rather than the IDU.
- For PTP 820F, a *Radio unit communication failure* alarm generally means a problem with the radio cable, faulty cable grounding, or faulty cable quality. If in addition to this alarm a *Cable open* is raised and the RFU is receiving power via an external power source rather than PoE from the IDU, check the Radio Unit configuration to make sure **Power Admin** is set to **Disable**. See *Configuring the IDU-RFU Connection (PTP 820F only)*. Check also for a *Cable short* alarm, which would indicate a problem with the IDU-RFU cable.
- For PTP 820F, a *Radio unit communication failure* alarm is often the result of a physical cable failure. If the interface LED on the RFU (RJ-45 or SFP) displays Orange, it means this alarm is raised without Loss of Carrier. This probably means the cable is not connected well. Otherwise, problem is probably with the IDU.
- For PTP 820F, there is an automatic software upgrade process to ensure that the RFU is always aligned to the IDU. Sometimes, usually due to excessive switching of the physical RFU unit by the user, this process fails. When this happens, the IDU makes five recovery attempts. If the failure persists, a *Radio unit not aligned to IDU* alarm is raised. To resolve this alarm: (i) Disable, then enable the RFU in the Radio Unit page (*Configuring the IDU-RFU Connection (PTP 820F only)*), and (ii) Reset the IDU chassis.

If this alarm occurs *other than* as part of a hardware installation or after a software upgrade, there is probably a problem with the RFU, and the RFU should be replaced. After replacing the RFU, Disable, then enable the RFU in the Radio Unit page (*Configuring the IDU-RFU Connection (PTP 820F only)*).

- For RFU-D, RFU-D-HP, RFU-E, and RFU-S: If there is a problem with the RFU while using an RJ-45 connection, try using an SFP connection. If the problem is eliminated, the problem was probably with the cable or cable grounding.
- If during or right after a software upgrade the message *Your session has expired, please login again* appears and you cannot log in, it is recommended to refresh the Web EMS page (F5) after completion of the upgrade. If pressing F5 does not help, clear the browser's cache by pressing Ctrl+Shift+Delete.

Chapter 26: Replacing an IDU or SM card

**Caution**

When a complete IDU is replaced, the traffic through this IDU will be interrupted.

If you need to replace the PTP 820G or PTP 820F IDU, you must first remove the SM-Card Cover so that you can insert it into the new IDU.

The SM-Card holds the configuration and software for the IDU. The SM-Card is embedded in the SM-Card Cover, so re-using the existing SM-Card Cover is necessary to ensure that the unit's software and configuration is maintained.


In some cases, you may need to replace the SM-Card itself in order to upgrade the unit's configuration.

Replacing an IDU or SM-Card on an PTP 820F IDU

To remove the SM-Card Cover of an PTP 8210F IDU:


- 1 Switch the unit power off.
- 2 Loosen the screws of the SM-Card Cover and remove it from the IDU.

Figure 435 Removing the SM-Card Cover of a PTP 820F



- 3 In the new IDU or, if you are upgrading the SM-Card, the old IDU, make sure that there is no foreign matter blocking the sockets in the opening where the SM-Card is installed.

Figure 436 Checking the Sockets for Foreign Matter




- 4 Gently place the SM-Card module in its place and tighten the captive screws, using a flat screwdriver.

Replacing an IDU or SM-Card on an PTP 820G IDU

To remove the SM-Card Cover of an PTP 820G IDU:


1. Switch the unit power off.
2. Loosen the screws of the SM-Card Cover and remove it from the IDU.

Figure 437 Removing the PTP 820G SM-Card Cover



3. In the new IDU or, if you are upgrading the SM-Card, the old IDU, make sure that there is no foreign matter blocking the sockets in the opening where the SM-Card is installed.

Figure 438 Checking the Sockets for Foreign Matter



4. Gently place the SM-Card module in its place and tighten the captive screws, using a flat screwdriver.

Chapter 27: Pin-Outs and LEDs – PTP 820G

This section describes the pin-outs and LEDs on each PTP 820G interface.

- [Ethernet Pin-Outs and LEDs](#)
- [E1/DS1 Pin-Outs and LEDs](#)
- [Radio Interface LEDs](#)
- [Synchronization Interface Pin-Outs and LEDs](#)
- [Power Interface LEDs](#)
- [Terminal Interface Pin-Outs](#)
- [External Alarms](#)
- [Unit/ACT LED](#)


Ethernet Pin-Outs and LEDs – PTP 820G

The front panel of the PTP 820G contains four electrical and two optical GE Ethernet traffic interfaces:

- 2 x GE dual mode electrical or cascading interfaces (RJ-45) – GbE1/CS1, GbE2/CS2
- 2 x GE electrical interfaces (RJ-45) – GbE3, GbE4
- 2 x GE optical interfaces (SFP) – SFP5, SFP6

Ethernet Traffic Interface Pin-Outs

Table 331 GbE Interface Pin-Out Diagram (GbE1, GbE2, GbE3, GbE4)


RJ45	Pin no.	Description
	1	BI_DA+ (Bi-directional pair +A)
	2	BI_DA- (Bi-directional pair -A)
	3	BI_DB+ (Bi-directional pair +B)
	4	BI_DC+ (Bi-directional pair +C)
	5	BI_DC- (Bi-directional pair -C)
	6	BI_DB- (Bi-directional pair +B)
	7	BI_DD+ (Bi-directional pair +D)
	8	BI_DD- (Bi-directional pair -D)

Ethernet Traffic Interface LEDs

Each electrical interface has the following LEDs:

- **Port Status LED** – Located on the upper left of each interface. Indicates the link status of the interface:
 - **Off** – The interface is shut down or the signal is lost.
 - **Green** – The interface is enabled and the link is operational.
 - **Blinking Green** – The interface is transmitting and/or receiving traffic.
- **Port Rate LED** – Located on the upper right of each interface. Indicates the speed of the interface:
 - **Off** – 100Base-TX
 - **Green** – 1000Base-T
 - **Blinking Green** – 10Base-T


Figure 439 Electrical GE Interface LEDs



Each optical interface has the following LED:


- **Port Status LED** – A Port Status LED is located on the lower left of SFP5 and the lower right of SFP6. Each LED indicates the link status of the interface:
 - **Off** – The interface is shut down or the signal is lost.
 - **Green** – The interface is enabled and the link is operational.
 - **Blinking Green** – The interface is transmitting and/or receiving traffic.

Figure 440 Optical GE Interface LED



Ethernet Management Interface Pin-Outs

Table 332 Management Interface Pin-Out Diagram (MGMT)


RJ45	Pin no.	Description
	1	Port 1 – TX+
	2	Port 1 – TX-
	3	Port 1 – RX+
	4	Port 2 – TX+
	5	Port 2 – TX-
	6	Port 1 – RX-
	7	Port 2 – RX+
	8	Port 2 – RX-

Ethernet Management Interface LEDs

The MGMT interface has the following LEDs:

- **Port Status LED** – The LED for management interface 1 is located on the upper left of the MGMT interface. The LED for management interface 2 is located on the upper right of the MGMT interface. Each LED indicates the link status of the interface:
 - **Off** – The cable is not connected or the signal is lost.
 - **Green** – The interface is enabled and the link is operational.
 - **Blinking Green** – The interface is transmitting and/or receiving management traffic.

Figure 441 Management FE Interface LEDs



E1/DS1 Pin-Outs and LEDs – PTP 820G

E1/DS1 Interface Pin-Outs

The 16 x E1/DS1 connector is a SCSI 68-pin connector.

Table 333 E1/DS1 Interface Pin-Out Diagram (E1/DS1 1-16)

Pin #	Signal	Label on the Twisted Pair	Type
1	OUT - TIP1	Ch1 Tx	TWISTED PAIR
35	OUT - RING1		
2	OUT - TIP2	Ch2 Tx	TWISTED PAIR
36	OUT - RING2		
3	OUT - TIP3	Ch3 Tx	TWISTED PAIR
37	OUT - RING3		
4	OUT - TIP4	Ch4 Tx	TWISTED PAIR
38	OUT - RING4		
5	OUT - TIP5	Ch5 Tx	TWISTED PAIR
39	OUT - RING5		
6	OUT - TIP6	Ch6 Tx	TWISTED PAIR
40	OUT - RING6		
7	OUT - TIP7	Ch7 Tx	TWISTED PAIR
41	OUT - RING7		
8	OUT - TIP8	Ch8 Tx	TWISTED PAIR
42	OUT - RING8		
9	OUT - TIP9	Ch9 Tx	TWISTED PAIR
43	OUT - RING9		
10	OUT - TIP10	Ch10 Tx	TWISTED PAIR
44	OUT - RING10		
11	OUT - TIP11	Ch11 Tx	TWISTED PAIR
45	OUT - RING11		
12	OUT - TIP12	Ch12 Tx	TWISTED PAIR

Pin #	Signal	Label on the Twisted Pair	Type
46	OUT - RING12		
13	OUT - TIP13	Ch13 Tx	TWISTED PAIR
47	OUT - RING13		
14	OUT - TIP14	Ch14 Tx	TWISTED PAIR
48	OUT - RING14		
15	OUT - TIP15	Ch15 Tx	TWISTED PAIR
49			
16		Ch16 Tx	TWISTED PAIR
50			
19		Ch1 Rx	TWISTED PAIR
53			
20		Ch2 Rx	TWISTED PAIR
54			
21	IN - TIP3	Ch3 Rx	TWISTED PAIR
55	IN - RING3		
22	IN - TIP4	Ch4 Rx	TWISTED PAIR
56	IN - RING4		
23	IN - TIP5	Ch5 Rx	TWISTED PAIR
57	IN - RING5		
24	IN - TIP6	Ch6 Rx	TWISTED PAIR
58	IN - RING6		
25	IN - TIP7	Ch7 Rx	TWISTED PAIR
59	IN - RING7		
26	IN - TIP8	Ch8 Rx	TWISTED PAIR
60	IN - RING8		
27	IN - TIP9	Ch9 Rx	TWISTED PAIR
61	IN - RING9		
28	IN - TIP10	Ch10 Rx	TWISTED PAIR
62	IN - RING10		


Pin #	Signal	Label on the Twisted Pair	Type
29	IN - TIP11	Ch11 Rx	TWISTED PAIR
63	IN - RING11		
30	IN - TIP12	Ch12 Rx	TWISTED PAIR
64	IN - RING12		
31	IN - TIP13	Ch13 Rx	TWISTED PAIR
65	IN - RING13		
32	IN - TIP14	Ch14 Rx	TWISTED PAIR
66	IN - RING14		
33	IN - TIP15	Ch15 Rx	TWISTED PAIR
67	IN - RING15		
34	IN - TIP16	Ch16 Rx	TWISTED PAIR
68	IN - RING16		
17	SHELL	-	SHIELD
18	SHELL	-	SHIELD
51	SHELL	-	SHIELD
52	SHELL	-	SHIELD

E1/DS1 Interface LEDs

The E1/DS1 interface has the following LEDs

- **ACT LED** – Remains grey.
- **E1/DS1 LED** – Indicates whether the interfaces are enabled with no alarms (Green), with alarms (Red), or no interfaces enabled (Off).

Figure 442 TDM Interface LEDs




Radio Interface LEDs – PTP 820G

Each radio interface has the following set of LEDs. The LEDs for Radio 1 are located to the right of the interface. The LEDs for Radio 2 are located to the left of the interface.

The LEDs indicate the following:

- **ACT** – Indicates the status of the radio:
 - **Off** – The radio is disabled.
 - **Green** – The radio is active and operating normally.
- **LNK** – Indicates the status of the radio link:
 - **Off** – The radio is disabled.
 - **Green** – The radio link is operational.
 - **Red** – There is an LOF or Excessive BER alarm on the radio.
 - **Blinking Green** – An IF loopback is activated, and the result is OK.
 - **Blinking Red** – An IF loopback is activated, and the result is Failed.
- **RFU** – Indicates the status of the RFU:
 - **Off** – The radio is disabled.
 - **Green** – The RFU is functioning normally.
 - **Orange** – A minor RFU alarm or a warning is present, or the RFU is in TX mute mode, or, in a protected configuration, the RFU is in standby mode.
 - **Red** – A cable is disconnected.
 - **Blinking Red** – An RF loopback is active.


Figure 443 Radio Interface LEDs



Synchronization Interface Pin-Outs and LEDs – PTP 820G

Synchronization Interface Pin-Outs

Table 334 Synchronization Interface Pin-Out Diagram

RJ45	Pin no.	Description
 <p>8.....1</p>	1	T3_IN_N
	2	T3_IN_P
	3	1PPS_P
	4	T4_OUT_N
	5	T4_OUT_P
	6	1PPS_N
	7	ToD_P (or PPS_IN_P)
	8	ToD_N (or PPS_IN_N)

Synchronization Interface LEDs

The synchronization interface contains two LEDs, one on the upper left of the interface and one on the upper right of the interface:

- **T3 Status LED** – Located on the upper left of the interface. Indicates the status of T3 input clock:
 - **Off** – There is no T3 input clock, or the input is illegal.
 - **Green** – There is legal T3 input clock, and a sync source for this interface is configured.
- **T4 Status LED** – Located on the upper right of the interface. Indicates the status of T4 output clock:
 - **Off** – T4 output clock is not available.
 - **Green** – There is a legal T4 output clock and no sync source is configured for this interface.
 - **Blinking Green** – The clock unit is in a holdover state.




Note

Support for T3 input and T4 output is planned for future release.

Table 335 Sync Interface LEDs


T3 Status LED **T4 Status LED**



Power Interface LEDs – PTP 820G

There is an ACT LED for each power interface. The LED is Green when power is being fed to that interface.


Figure 444 Power Interface LEDs



Terminal Interface Pin-Outs – PTP 820G

PTP 820G includes an RJ-45 terminal interface (RS-232). A local craft terminal can be connected to the terminal interface for local CLI management of the unit.

Table 336 Terminal Interface Pin-Out Diagram

RJ45	Pin no.	Description
	1	NC
	2	NC
	3	NC
	4	GND
	5	Terminal-RX (System TX)
	6	Terminal-TX (System RX)
	7	NC
	8	NC

External Alarms – PTP 820G

PTP 820G includes a DB9 dry contact external alarms interface. The external alarms interface supports five input alarms and a single output alarm.

The input alarms are configurable according to:

- 1 Intermediate
- 2 Critical
- 3 Major
- 4 Minor
- 5 Warning

The output alarm is configured according to predefined categories.

External Alarm Pin-Outs

Table 337 External Alarm Interface Pin-Out Diagram


RJ45	Pin no.	Description
	1	External input alarm #1
	2	External input alarm #2
	3	External input alarm #3
	4	External input alarm #4
	5	External input alarm #5
	6	Relay #1, normally closed pin
	7	Relay #1, common pin
	8	Relay #1, normally open pin
	9	GND

Unit/ACT LED PTP 820G

A general ACT LED for the unit is located on the lower left of the PTP 820G front panel. This LED is labeled UNIT/ACT, and indicates the general status of the unit:

Off – Power is off.

Green – Power is on.



Chapter 28: Pin-Outs and LEDs – PTP 820F


This section describes the pin-outs and LEDs on each PTP 820F interface.

- [Ethernet LEDs and Pin-Outs](#)
- [E1/DS1 LEDs and Pin-Outs](#)
- [Radio Interface LEDs and Pin-Outs](#)
- [Power Interface LEDs](#)
- [Synchronization Interface LEDs and Pin-Outs](#)
- [Terminal Interface Pin-Outs](#)
- [External Alarms](#)
- [Unit/ACT LED](#)

Ethernet LEDs and Pin-Outs – PTP 820F

Ethernet Traffic Interface Pin-Outs


Table 338 GbE Interface Pin-Out Diagram (GbE1, GbE2, GbE3, GbE4, 2.5GE5, 2.5GE6)

RJ45	Pin no.	Description
 <p>8.....1</p>	1	BI_DA+ (Bi-directional pair +A)
	2	BI_DA- (Bi-directional pair -A)
	3	BI_DB+ (Bi-directional pair +B)
	4	BI_DC+ (Bi-directional pair +C)
	5	BI_DC- (Bi-directional pair -C)
	6	BI_DB- (Bi-directional pair -B)
	7	BI_DD+ (Bi-directional pair +D)
	8	BI_DD- (Bi-directional pair -D)


Ethernet Traffic Interface LEDs

Each electrical interface has the following LEDs:

- **Port Status LED** – Located on the upper left of each interface. Indicates the link status of the interface:
 - **Off** – The interface is shut down or the signal is lost.
 - **Green** – The interface is enabled and the link is operational.
 - **Blinking Green** – The interface is transmitting and/or receiving traffic.
- **Port Rate LED** – Located on the upper right of each interface. Indicates the speed of the interface:
 - **Off** – 100Base-TX
 - **Green** – 1000Base-T
 - **Blinking Green** – 10Base-T

Figure 446 Electrical Ethernet Interface LEDs

For optical interfaces SFP1 through SFP4, the LEDs are located between the two rows of interfaces, each LED pointing to its interface as shown in the figure below.

Figure 447 Optical Ethernet Interface LEDs – SFP1 through SFP4


For optical interfaces SFP5 and SFP6, the LEDs are located between RFU and RFU2 on the left and RFU3/SFP5 and SFP6 on the right.

Each optical interface has the following LED:

- **Port Status LED** – A Port Status LED is located on the lower left of SFP5 and the lower right of SFP6. Each LED indicates the link status of the interface:
 - **Off** – The interface is shut down or the signal is lost.
 - **Green** – The interface is enabled and the link is operational.
 - **Blinking Green** – The interface is transmitting and/or receiving traffic.

Management Interface Pin-Outs

Table 339 Management Interface Pin-Out Diagram (MGMT)

RJ45	Pin no.	Description
	1	Port 1 – TX+
	2	Port 1 – TX-
	3	Port 1 – RX+
	4	Port 2 – TX+
	5	Port 2 – TX-
	6	Port 1 – RX-
	7	Port 2 – RX+
	8	Port 2 – RX-


Management Interface LEDs

The MGMT interface has the following LEDs:

Port Status LED – The LED for management interface 1 is located on the upper left of the MGMT interface. The LED for management interface 2 is located on the upper right of the MGMT interface. Each LED indicates the link status of the interface:

- **Off** – The cable is not connected or the signal is lost.
- **Green** – The interface is enabled and the link is operational.
- **Blinking Green** – The interface is transmitting and/or receiving management traffic.

Figure 448 Management FE Interface LEDs



E1/DS1 Interface LEDs and Pin-Outs – PTP 820F

PTP 820F includes an MDR69 connector in which 16 E1 interfaces are available (ports 1 through 16).

E1/DS1 Interface Pin-Outs

The 16 x E1/DS1 connector is a SCSI 68-pin connector.

Table 340 E1/DS1 Interface Pin-Out Diagram (E1/DS1 1-16)

Pin #	Signal	Label on the Twisted Pair	Type
1	OUT - TIP1	Ch1 Tx	TWISTED PAIR
35	OUT - RING1		
2	OUT - TIP2	Ch2 Tx	TWISTED PAIR
36	OUT - RING2		
3	OUT - TIP3	Ch3 Tx	TWISTED PAIR
37	OUT - RING3		
4	OUT - TIP4	Ch4 Tx	TWISTED PAIR
38	OUT - RING4		
5	OUT - TIP5	Ch5 Tx	TWISTED PAIR
39	OUT - RING5		
6	OUT - TIP6	Ch6 Tx	TWISTED PAIR
40	OUT - RING6		
7	OUT - TIP7	Ch7 Tx	TWISTED PAIR
41	OUT - RING7		
8	OUT - TIP8	Ch8 Tx	TWISTED PAIR
42	OUT - RING8		
9	OUT - TIP9	Ch9 Tx	TWISTED PAIR
43	OUT - RING9		
10	OUT - TIP10	Ch10 Tx	TWISTED PAIR
44	OUT - RING10		
11	OUT - TIP11	Ch11 Tx	TWISTED PAIR
45	OUT - RING11		

Pin #	Signal	Label on the Twisted Pair	Type
12	OUT - TIP12	Ch12 Tx	TWISTED PAIR
46	OUT - RING12		
13	OUT - TIP13	Ch13 Tx	TWISTED PAIR
47	OUT - RING13		
14	OUT - TIP14	Ch14 Tx	TWISTED PAIR
48	OUT - RING14		
15	OUT - TIP15	Ch15 Tx	TWISTED PAIR
49	OUT - RING15		
16	OUT - TIP16	Ch16 Tx	TWISTED PAIR
50	OUT - RING16		
19	IN - TIP1	Ch1 Rx	TWISTED PAIR
53	IN - RING1		
20	IN - TIP2	Ch2 Rx	TWISTED PAIR
54	IN - RING2		
21	IN - TIP3	Ch3 Rx	TWISTED PAIR
55	IN - RING3		
22	IN - TIP4	Ch4 Rx	TWISTED PAIR
56	IN - RING4		
23	IN - TIP5	Ch5 Rx	TWISTED PAIR
57	IN - RING5		
24	IN - TIP6	Ch6 Rx	TWISTED PAIR
58	IN - RING6		
25	IN - TIP7	Ch7 Rx	TWISTED PAIR
59	IN - RING7		
26	IN - TIP8	Ch8 Rx	TWISTED PAIR
60	IN - RING8		
27	IN - TIP9	Ch9 Rx	TWISTED PAIR
61	IN - RING9		
28	IN - TIP10	Ch10 Rx	TWISTED PAIR


Pin #	Signal	Label on the Twisted Pair	Type
62	IN - RING10		
29	IN - TIP11	Ch11 Rx	TWISTED PAIR
63	IN - RING11		
30	IN - TIP12	Ch12 Rx	TWISTED PAIR
64	IN - RING12		
31	IN - TIP13	Ch13 Rx	TWISTED PAIR
65	IN - RING13		
32	IN - TIP14	Ch14 Rx	TWISTED PAIR
66	IN - RING14		
33	IN - TIP15	Ch15 Rx	TWISTED PAIR
67	IN - RING15		
34	IN - TIP16	Ch16 Rx	TWISTED PAIR
68	IN - RING16		
17	SHELL	-	SHIELD
18	SHELL	-	SHIELD
51	SHELL	-	SHIELD
52	SHELL	-	SHIELD

E1/DS1 Interface LEDs

The E1/DS1 interface has the following LEDs

- **ACT LED** – Indicates whether the TDM card is working properly (Green) or if there is an error or a problem with the card's functionality (Red).
- **E1/DS1 LED** – Indicates whether the interfaces are enabled with no alarms (Green), with alarms (Red), or no interfaces enabled (Off).


Figure 449 E1/DS1 Interface LEDs



Radio Interface LEDs and Pin-Outs – PTP 820F

Radio RJ-45 Interface Pin-Outs

Table 341 Radio Interface Pin-Out Diagram (RFU1, RFU2, RFU3)


RJ45	Pin no.	Description	Power Polarity
	1	BI_DA+ (Bi-directional pair +A)	+
	2	BI_DA- (Bi-directional pair -A)	+
	3	BI_DB+ (Bi-directional pair +B)	-
	4	BI_DC+ (Bi-directional pair +C)	+
	5	BI_DC- (Bi-directional pair -C)	+
	6	BI_DB- (Bi-directional pair -B)	-
	7	BI_DD+ (Bi-directional pair +D)	-
	8	BI_DD- (Bi-directional pair -D)	-

Radio Interface LEDs

The radio interfaces have the following LEDs:

- Optical Interfaces – Four LEDs are located between the SFP connectors. These LEDs indicate the status of the radio interfaces and the SFP5 and SFP6 Ethernet interfaces. For the radio interfaces, the LEDs indicate:


Figure 450 Optical Interface LEDs



- Off – The Admin status of the radio unit is Disabled or the interface’s media type is set to RJ-45.
- Green – A cable is connected between the interface and the RFU and the Operational status of the radio unit is Up. This LED does not, however, show the status of the radio link.

- Orange – A cable is connected between the interface and the RFU, but communication has not been established between the IDU and the RFU. This can be a temporary state while IDU-RFU communication is being established.
- Red – The Admin status of the radio unit is Enabled and the interface’s media type is set to SFP, but the cable is not connected. And a Loss of Signal (LoS) state exists.
- Electrical Interfaces – There are two LEDs next to each electrical interface, on the upper left and the upper right of each interface.

Figure 451 Electrical Interface LEDs



The LED on the upper left of the interface indicates the radio unit status and the status of the IDU-RFU connection:

- Off – The Admin status of the radio unit is Disabled or the interface’s media type is set to SFP.
- Green – A cable is connected between the interface and the RFU and the Operational status of the radio unit is Up. This LED does not, however, show the status of the radio link.
- Orange – A cable is connected between the interface and the RFU, but communication has not been established between the IDU and the RFU. This can be a temporary state while IDU-RFU communication is being established.
- Red – The Admin status of the radio unit is Enabled and the interface’s media type is set to RJ-45, but the cable is not connected. And a Loss of Carrier (LoC) state exists.


The LED on the upper right of the interface indicates the status of the PoE power supply from the IDU to the RFU:

- Off – PoE is disabled.
- Green – PoE is enabled on the interface and the IDU is supplying power to the RFU.
- Blinking Green – PoE is enabled on the interface, and the interface is in PoE Detecting state. This state may be temporary upon RFU connection, or permanent if the RFU is not detected or has been disconnected.
- Red – PoE fault. This can mean that a short circuit exists on the cable. In a fault condition, the LED may alternate between Red and Blinking Green.

Power Interface LEDs – PTP 820-F

There is an ACT LED for each power interface. The LED is Green when the voltage being fed to the power interface is within range, and Red if the voltage is not within range or if a power cable is not connected.

Figure 452 Power Interface LEDs




Synchronization Interface LEDs and Pin-Outs – PTP 820F

PTP 820F includes an RJ-45 synchronization interface for T3 clock input and T4 clock output. The interface is the lower RJ-45 interface in a pair of interfaces labeled MGMT/SYNC.

Synchronization Interface Pin-Outs

Table 342 Synchronization Interface Pin-Out Diagram


RJ45	Pin no.	Description
	1	T3_IN_N
	2	T3_IN_P
	3	1PPS_P
	4	T4_OUT_N
	5	T4_OUT_P
	6	1PPS_N
	7	ToD_P (or PPS_IN_P)
	8	ToD_N (or PPS_IN_N)

Synchronization Interface LEDs

The synchronization interface contains two LEDs, one on the upper left of the interface and one on the upper right of the interface:



- **T3 Status LED** – Located on the upper left of the interface. Indicates the status of T3 input clock:
 - **Off** – There is no T3 input clock, or the input is illegal.
 - **Green** – There is legal T3 input clock.
- **T4 Status LED** – Located on the upper right of the interface. Indicates the status of T4 output clock:
 - **Off** – T4 output clock is not available.
 - **Green** – T4 output clock is available.
 - **Blinking Green** – The clock unit is in a holdover state.

Figure 453 Sync Interface LEDs



Terminal Interface Pin-Outs – PTP 820F

Table 343 Terminal Interface Pin-Out Diagram

RJ-45	Pin no.	Description	Pin no.	DB-9
 8.....1	4	GND	5	 5 1 9 6
	5	Terminal-RX (System TX)	2	
	6	Terminal-TX (System RX)	3	

External Alarm Pin-Outs – PTP 820F

Table 344 External Alarm Interface Pin-Out Diagram


DB-9	Pin no.	Description
	1	External input alarm #1
	2	External input alarm #2
	3	External input alarm #3
	4	External input alarm #4
	5	External input alarm #5
	6	Relay #1, normally closed pin
	7	Relay #1, common pin
	8	Relay #1, normally open pin
	9	GND

Unit/ACT LED – PTP 820F

A general ACT LED for the unit is located on the lower left of the PTP 820F front panel. This LED is labeled UNIT/ACT, and indicates the general status of the unit:

- **Off** – Power is off.
- **Green** – Power is on.

Figure 454 Unit/ACT LED



Chapter 29: Alarms List

The following table lists all alarms used in the PTP 820G and PTP 820F products.

Alarm ID	Name	Type	Description	Severity	Probable Cause	Corrective Action
10	radio-digital-loopback	Alarm	Framer digital loopback	Warning	User enabled framer digital loopback.	Disable framer digital loopback.
25	main-board-extreme-temperature-alarm	Alarm	Unit Temperature is out of system specified limits.	Warning		
26	main-board-low-voltage-alarm	Alarm	Unit input voltage is too low.	Warning		
27	main-board-high-voltage-alarm	Alarm	Unit input voltage is too high.	Warning		
28	main-board-warm-reset	Event	Unit warm reset.	Indeterminate		
29	main-board-cold-reset	Event	Unit reset.	Warning		
30	main-board-poe-low-voltage-alarm	Alarm	POE input voltage is too low	Warning		
31		Event	Change Remote request was sent	Major		
32		Event	Protection switchover due to remote request	Major		

33	protection-mimo-misconfiguration-alarm	Alarm		Major	Unit Redundancy and MIMO 4x4 can not operate simultaneously.	
100	lag-degraded	Alarm	LAG is not fully functional - LAG Degraded.	Major		
101	lag-down	Alarm	LAG operational state is down	Critical		
102	ethernet-loopback-active-alarm	Alarm	Loopback is active	Major	Ethernet loopback is active.	Wait till loopback timeout expires or disable loopback.
103	port-mirroring-is-active	Alarm	Slot X port XX is mirrored to slot Y port YY	Minor	Mirroring is enabled by user configuration.	Disable mirroring.
120	port-speed-mismatch-alarm	Alarm	Port speed mismatch	Major	System reset is required after the port speed was changed.	Change the port speed to its previous value, OR Reset the system.
150	auto-state-propagation-interface-down-alarm	Alarm	Interface is down due to automatic state propagation.	Major	Failure of the radio interface which is monitored for automatic state propagation causes automatic shutdown of the controlled interface.	Check adjacent radio interface for failure conditions that caused automatic state propagation.
200	protection-communication-down-alarm	Alarm	Protection communication is down	Major	Mate unit is absent/failure. Protection cable is disconnected. Unit failure.	Check existence of mate unit. Check protection cable connection between units. Reset mate unit. Replace mate unit.

201	protection-lockout-alarm	Alarm	Protection in Lockout State	Major		
202	protection-switch-command	Event	Protection switchover due to local failure	Major		
203	protection-mate-not-present-alarm	Alarm	Mate does not exist	Major	Mate does not exist or cable unplugged.	
204	protection-hsb-insufficient-alarm	Alarm	HSB insufficient configuration	Critical	External Protection configured both with HSB.	Remove External Protection and HSB configuration.
307	tdm-link-up	Event	TDM interface is up	Warning		
308	tdm-link-down	Event	TDM interface is down	Warning		
401	TrafficPhyLocAlarm	Alarm	Loss of Carrier	Major	Cable disconnected. Defective cable.	Check connection of cable Replace cable.
407	ethernet-link-up	Event	Ethernet interface is up	Warning		
408	ethernet-link-down	Event	Ethernet interface is down	Warning		
601	radio-excessive-ber	Alarm	Radio excessive BER	Major	Fade in the link. Defective IF cable. Fault in RFU. Fault in RMC (Radio Modem Card).	Check link performance. Check IF cable and replace if required. Replace RFU. Replace RMC (Radio Modem Card).
602	remote-link-id-mismatch	Alarm	Link ID mismatch	Major	Link ID is not the same at both sides of link	Configure same Link ID for both sides of link
603	radio-lof	Alarm	Radio loss of frame	Critical	Fade in the link. Defective IF cable.	Check link performance.

					Fault in RFU. Fault in RMC (Radio Modem Card). Different radio scripts at both ends of the link.	Check IF cable and replace if required. Replace RFU. Replace RMC (Radio Modem Card). Make sure same script is loaded at both ends of the link.
604	radio-signal-degrade	Alarm	Radio signal degrade	Minor	Fade in the link. Defective IF cable. Fault in RFU. Fault in RMC (Radio Modem Card).	Check link performance. Check IF cable and replace if required. Replace RFU. Replace RMC (Radio Modem Card).
605	radio-link-up	Event	Radio interface is up	Warning		
606	radio-link-down	Event	Radio interface is down	Warning		
607	rfu-frequency-scanner-in-process	Alarm	Frequency scanner in progress	Warning	The frequency scanner activated.	Stop the frequency scanner process.
801	corrupted-file	Alarm	Corrupted inventory file	Warning	The inventory file is corrupted	Reset the system. Reinstall the software.
802	file-not-found	Alarm	Inventory file not found	Warning	The inventory file is missing	Reset the system. Reinstall the software.
901	demo-license-alarm	Alarm	Demo mode is active	Warning	Demo mode has been activated by the user	Disable demo mode
902	license-demo-expired	Event	Demo mode is expired	Warning		
903	license-demo-start-by-user	Event	Demo mode is started	Warning		

904	license-demo-stop-by-user	Event	Demo mode is stopped	Warning		
905	license-load-fail	Event	Activation key loading failure	Major		
906	license-load-successful	Event	Activation key loaded successfully	Warning		
907	license-violation-alarm	Alarm	Activation key violation	Critical	The current configuration does not match the activation-key-enabled feature set. 48 hours after an "activation-key-violation" alarm is raised, sanction mode is activated in which all alarms except the activation key violation alarm are cleared and no new alarms are raised.	Get the list of features' configurations that are violated via the "activation key information report". Install a new activation key that allows the use of all required features.
908	demo-license-about-to-expire-alarm	Alarm	Demo mode is about to expire	Major	Demo mode allowed period is about to end within 10 days	Disable demo mode and install a new valid activation key.
910	license-signature-failed-alarm	Alarm	Activation key signature failure	Major	Activation key validation has failed due to invalid product serial number	Replace the IDU
911	license-violation-runtime-counter-expired	Event	Activation key violation sanction is enforced	Major		

913	license-bad-xml-file-alarm	Alarm	Activation key components are missing or corrupted	Major	Essential internal activation key components are missing or corrupted.	Reinstall software
1002	radio-protection-configuration-mismatch	Alarm	Radio protection configuration mismatch	Major	The configuration between the radio protection members is not aligned	Apply a copy-to-mate command to copy the configuration from the required radio to the other one
1006	radio-protection-switchover-event	Event	Radio protection switchover - reason	Warning	Protection decision machine initiated switchover due to local failure or user command	Check the system for local failures
1007	radio-protection-no-mate	Alarm	Radio protection no mate	Major	Radio protection function is missing radio module, module defected or disabled	Add radio module. Replace a defective existing radio module. Make sure all radio interfaces are enabled.
1008	radio-protection-remote-switch-request	Event	Remote switchover request was sent - reason	Warning		
1009	radio-protection-lockout	Alarm	Radio protection lockout command is on	Major	The user has issued a lockout command	Clear the lockout command
1010	ethernet-protection-switchover	Event	Ethernet Interface Group protection switchover	Warning	LOC event on an Ethernet interface. Protection group member was disabled or pulled out of the shelf.	Check the system for local failures. Check external equipment.

1011	interface-protection-lockout	Alarm	Interface protection lockout is on	Major	The user has issued a lockout command	Clear the lockout command
1012	interface-protection-no-mate	Alarm	Interface protection no mate: mate interface is missing or disabled	Major	Interface protection function is missing interface module, module defected or disabled.	Add interface module. Replace a defective existing interface module. Make sure all interface interfaces are enabled.
1102	software-installation-status	Event	Software installation status:	Warning		
1105	software-new-version-installed	Event	New version installed	Warning	A software version has been installed but system has not been reset.	
1111	software-user-confirmation-for-version	Event	User approved download of software version file	Warning		
1112	software-download-status	Event	Software download status:	Warning		
1113	software-download-missing-components	Event	Missing SW components:	Warning		
1114	software-management-incomplete-bundle	Event	Incomplete file set; missing components	Warning	Software bundle is missing components.	Get a complete software bundle
1150	backup-started	Event	Configuration file backup generation started	Warning	User command	
1151	backup-succeeded	Event	Configuration file backup created	Warning	Backup file creation finished successfully	

1152	backup-failure	Event	Failure in configuration file backup generation	Warning	System failed in attempt to create backup configuration file	
1153	restore-succeeded	Event	Configuration successfully restored from file backup	Warning	Configuration restore finished successfully	
1154	restore-failure	Event	Failure in configuration restoring from backup file	Warning	System failed in attempt to restore configuration from backup file	Configuration file system type mismatch Invalid or corrupted configuration file
1155	restore-canceled	Event	Configuration restore operation cancelled	Warning	Restore operation cancelled because of user command or execution of another configuration management operation	Try again
1156	file-transfer-issued	Event	User issued command for transfer of configuration file	Warning	User command	
1157	file-transfer-succeeded	Event	Configuration file transfer successful	Warning	Configuration file transfer successful	
1158	file-transfer-failure	Event	Configuration file transfer failure	Warning	Communications failure. File not found in server	Mark sure protocol details are properly configured. Make sure file exists.
1159	file-transfer-in-progress	Event	Configuration file transfer in progress	Warning	File transfer started	
1163	cli-script-activation-started	Event	CLI configuration script activation started	Warning	User command	
1164	cli-script-activation-succeeded	Event	CLI Configuration script executed successfully	Warning		

1165	cli-script-activation-failure	Event	CLI Configuration script failed	Warning	Syntax Error. Error returned by system during runtime	Verify script in the relevant line, and run again. Note that script may assume pre-existing configuration.
1166	unit-info-file-transfer-status-changed	Event	Unit info file transfer status:	Warning		
1167	unit-info-file-creation-status-changed	Event	Unit info file creation status:	Warning		
1169	restore-started	Event	Configuration restore operation started	Warning	Restore operation started because of user command	
1201	file-missed	Alarm	Modem firmware file not found	Critical	Modem file is missing	Download software package. Reset the system.
1202	load-failed	Alarm	Modem firmware was not loaded successfully	Critical	Modem firmware file is corrupted. System failure.	Download software package. Reset the system.
1203	modem-wd-reset	Event	Modem watch-dog reset event	Warning		
1301	fpga-file-currupt-alarm	Alarm	Radio MRMC script LUT file is corrupted	Critical	Damaged radio MRMC script LUT file	Download the specific radio MRMC script LUT file
1302	fpga-file-not-found-alarm	Alarm	Radio MRMC script LUT file is not found	Critical	Missing radio MRMC script LUT file	Download the specific radio MRMC script LUT file

1304	modem-script-file-corrupt-alarm	Alarm	Radio MPMC script modem file is corrupted	Critical	Damaged radio MPMC script modem file	Download the specific radio MPMC script modem file
1305	modem-script-file-not-found-alarm	Alarm	Radio MPMC script modem file is not found	Critical	Missing radio MPMC script modem file	Download the specific radio MPMC script modem file
1308	rfu-file-corrupt-alarm	Alarm	Radio MPMC file is corrupted	Critical	Damaged Radio MPMC script LUT file	Download the specific radio MPMC RFU file
1309	rfu-file-not-found-alarm	Alarm	Radio MPMC RFU file is not found	Major	Missing radio MPMC RFU file	Download the specific radio MPMC RFU file
1312	script-loading-failed	Alarm	Radio error! MPMC script loading failed	Major	Damaged hardware module	Replace the radio hardware module
1401	incompatible-rfu-tx-calibration	Alarm	Incompatible RFU TX calibration	Major	RFU calibration tables require SW upgrade	Upgrade IDU SW
1501	remote-communication-failure	Alarm	Remote communication failure	Critical	Fade in the link	Check the link performance
1601	if-loopback	Alarm	IF loopback	Warning	User enabled IF loopback	Disable IF loopback
1602	lock-detect	Alarm	IF synthesizer is unlocked.	Critical	Extreme temperature condition. HW failure.	Check installation. Reset the RMC (Radio Modem Card) module. Replace the RMC (Radio Modem Card).
1610	rsl-degradation-threshold-out-of-range	Alarm	Radio Receive Signal Level is below the configured threshold	Warning	RSL is very low due to:	Check for obstruction in link path.

					Weather conditions, obstruction in antenna line of sight, antennae alignment. Configured threshold needs to be adjusted.2.	Check the antennae alignment and link planning. Recalculate the Path Loss and set the threshold accordingly. Check link settings - Tx Power and Tx Frequency. Hardware problem.
1651	atpc-override	Alarm	ATPC overridden: Tx level has been equal to the Max Tx level for a longer time than allowed	Warning	Actual transmitted signal level has been at its maximum value for longer than allowed. This is probably caused by a configuration error or link planning error.	Correct the transmission levels. The alarm will be cleared only upon manual clearing.
1697	radio-unit-extreme-temperature	Alarm	Radio unit extreme temperature	Warning	Installation conditions. Defective RFU.	Check installation conditions. Verify operation as per product's specs. Replace RFU.
1698	radio-unit-low-voltage	Alarm	Radio unit input voltage is too low	Warning	Power supply output too low. Power cable to RFU.	Check Power supply. Replace cable.
1699	radio-unit-high-voltage	Alarm	Radio unit input voltage is too high	Warning	Power Supply output too high.	Check power supply.

1700	fw-download-failure	Alarm	Radio unit not aligned to IDU	Critical	FW alignment interrupted, power disruption, ODU cable malfunction. Damaged ODU.	Reinitiate FW download by disable/enable the corresponding port. Replace RFU.
1701	cable-open	Alarm	Cable open	Major	Cable is not connected to the IDU's radio interface or the RFU.	Check IF cable and connectors. Verify that the N-Type connector inner pin is not spliced. Replace RMC (Radio Modem Card). Replace RFU.
1702	cable-short	Alarm	Cable short	Major	Physical short at the IF cable	Check IF cable and connectors. Verify that the N-Type connector inner pin is not spliced. Replace RMC (Radio Modem Card). Replace RFU.
1703	communication-failure	Alarm	RFU communication failure	Warning	Defective IF cable. IF cable not connected properly. Defective RMC (Radio Modem Card). Defective RFU. RFU software download in progress.	Check IF cable and connectors. Verify that N-Type connector inner pin is not spliced. Replace RMC (Radio Modem Card). Replace RFU.

						For a high power RF Unit: Check BMA connector on OCB Check BMA connector on RFU.
1704	delay-calibration-failure-1	Alarm	RFU delay calibration failure 1	Warning	Defective RFU	Reset the RMC (Radio Modem Card) / RFU. Replace RFU.
1705	delay-calibration-failure-2	Alarm	RFU delay calibration failure 2	Warning	Calibration cannot be completed due to notch detection	Enter delay calibration value manually.
1706	extreme-temp-cond	Alarm	RFU extreme temperature	Warning	Installation conditions. Defective RFU.	Check installation conditions. Verify operation as per product's specs. Replace RFU.
1707	radio-unit-abc-incompatible-rfu	Alarm	RFU is incompatible with ABC configuration	Warning	The RFU type does not support the type of Multi-Carrier ABC the user has configured.	Replace the RFU with an RFU type that supports the configured Multi-Carrier ABC type.
1708	freq-set-automatically	Event	RFU frequency was set automatically	Warning	Defective RFU	Check if problem repeats and if errors/alarms reported. Replace RFU.
1709	hardware-failure-1	Alarm	RFU hardware failure 1	Critical	Defective RFU.	Replace RFU.
1710	hardware-failure-2	Alarm	RFU hardware failure 2	Critical	Defective RFU.	Replace RFU.
1711	low-if-signal-to-rfu	Alarm	Low IF signal to RFU	Major	IF cable connection.	Check IF cable connectors.

					Defective RFU. Defective RMC (Radio Modem Card).	Verify that N-Type connector inner pin is not spliced. Replace RMC (Radio Modem Card). Replace RFU.
1712	no-signal-from-rfu	Alarm	Low IF signal from RFU	Warning	Low RX IF signal (140 MHz) from RFU.	Check IF cable and connectors. Verify that N-Type connector inner pin is not spliced. Replace RMC (Radio Modem Card). Replace RFU.
1713	pa-extreme-temp-cond	Alarm	RFU PA extreme temperature	Warning	Installation conditions. Defective RFU.	Check installation conditions. Replace RFU.
1721	reset-occurred	Event	RFU reset	Major		
1722	rfu-loopback-active	Alarm	RFU loopback is active	Major	User has activated RFU loopback.	Disable RFU loopback.
1723	rfu-mode-changed-to-combined	Event	RFU mode changed to Combined	Indeterminate		
1724	rfu-mode-changed-to-diversity	Event	RFU mode changed to Diversity	Indeterminate		
1725	rfu-mode-changed-to-main	Event	RFU mode changed to Main	Indeterminate		

1726	rfu-power-supply-failure	Alarm	RFU power supply failure	Major	At least one of the RFU's power supply voltages is too low.	Replace RFU.
1727	rx-level-out-of-range	Alarm	RFU RX level out of range	Warning	RSL is very low, link is down.	Check antenna alignment & link planning. Check link settings (TX power, TX frequency). Check antenna connections. Replace local/remote RFU.
1728	rx-level-path1-out-of-range	Alarm	RFU RX level path1 out of range	Warning	Improper installation. Fading event. Defective RFU.	Check that the fault is not due to rain/multi-path fading or lack of LOS. Check link settings (TX power, TX frequency). Check antenna alignment. Check antenna connections. Replace local/remote RFU.
1729	rx-level-path2-out-of-range	Alarm	RFU RX level path2 out of range	Warning	Improper installation. Fading event. Defective RFU.	Check that the fault is not due to rain/multi-path fading or lack of LOS. Check link settings (TX power, TX frequency). Check antenna alignment.

						Check antenna connections. Replace local/remote RFU.
1730	radio-unit-communication-failure	Alarm	Radio unit communication failure	Critical	Defective RFU cable. RFU cable not connected properly. Defective RIC (Radio Interface Card). Defective RFU. RFU initialization in progress. RFU powered off.	Check RFU power supply. Check RFU cable and connectors. Replace RIC (Radio Interface Card). Replace RFU.
1731	power-supply-radio-unit-cable-open	Alarm	Power supply cable open	Major	Power is enabled but consumption is lower than threshold.	Check ETH cable and connectors. Verify RFU is connected. If RFU connected with optical cable, disable power interface.
1732	power-supply-radio-unit-cable-short	Alarm	Power supply cable short	Major	Power is enabled but consumption reached the threshold. Physical short at the ETH cable.	Check ETH cable and connectors. Replace RIC (Radio Interface Card) Replace RFU. If RFU connected with optical cable, disable power interface.

1733	synthesizer-unlocked	Alarm	RFU synthesizer unlocked	Major	At least one of the RFU synthesizers is unlocked	Replace RFU. In XPIC mode, replace mate RFU as well.
1734	tx-level-out-of-range	Alarm	RFU TX level out of range	Minor	Defective RFU (the RFU cannot transmit the requested TX power)	Replace RFU. Intermediate solution - reduce TX power.
1735	tx-mute	Alarm	RFU TX Mute	Warning	RFU Transmitter muted by user	Unmute the RFU transmitter
1736	unknown-rfu-type	Alarm	IDU SW does not support this type of RFU	Major	IDC SW does not support the RFU	Upgrade IDC SW
1737	card-extracted-from-slot	Event	Card was extracted from slot	Warning	Card was extracted from slot	NA
1738	card-failure	Alarm	Card is in Failure state	Major	Card is down as a result of card failure	Reset Card. Check if slot was disabled.
1739	card-fpga-fw-not-found	Alarm	FPGA Firmware file not found	Critical	There is no FPGA file found on the Main Board for the card on the slot	NA
1740	card-fw-load-fail	Alarm	Download card firmware has failed	Major	Firmware download was unsuccessful.	Reset Card. Download software package. Try to insert another Card.
1741	card-inserted-to-slot	Event	Card was inserted to slot	Warning	Card was inserted to slot	NA
1742	card-intermediate-channel-failure	Alarm	Card is in interconnection failure state	Major	Card is down as a result of card interconnection failure	Reset Card. Check if the slot was disabled.

1743	card-missing	Alarm	Expected Card is missing in slot	Major	Card is missing. Expected Card Type configured on empty slot.	Insert Expected Card. Clear Expected Card Type.
1744	card-not-supported-for-slot	Alarm	This Card type is not supported in this slot	Major	The card is not on the Allowed Card Types list for this slot.	Reset. Insert Card belongs to Allowed Card Types list.
1745	card-state-is-down	Event	Card operational state is Down	Indeterminate	Card state was change to Down state	NA
1746	card-state-is-up	Event	Card operational state is Up	Indeterminate	Card state was change to Up state	NA
1747	card-state-is-up-with-alarms	Event	Card operational state is Up with Alarms	Indeterminate	Card state was change to Up state but with Alarms indication	NA
1748	card-unexpected	Alarm	Unexpected Card Type in slot	Minor	Expected card type is different than the actual card type	Insert Expected Card. Change Expected Card Type.
1749	slot-disabled	Event	Slot was Disabled	Indeterminate	The user Disabled slot	NA
1750	slot-enabled	Event	Slot was Enabled	Indeterminate	The user Enabled slot	NA
1751	slot-reseted	Event	Card on slot was Reset	Indeterminate	The user Reset slot	NA
1752	fan-card-extraction-event	Event	FAN Card was extracted from slot	Warning	FAN Card was extracted from slot	
1753	fan-card-failure-event	Event	FAN failure	Major		
1754	fan-card-insertion-event	Event	FAN Card was inserted to slot	Warning	FAN Card was inserted to slot	

1755	fan-card-missing	Alarm	FAN Card is missing in slot	Critical	FAN Card is missing. Slot enabled when empty.	Insert FAN Card. Disable slot.
1756	fan-extreme-temperature	Alarm	Extreme Temperature	Major	System Temperature not in allowed range.	NA
1757	fan-failure	Alarm	FAN Card is in Failure state	Major	FAN Card is in Failure state	Change FAN Card
1758	pdc-card-extraction-event	Event	Power Supply was extracted from slot	Warning	Power Supply was extracted from slot	
1759	pdc-card-insertion-event	Event	Power Supply was inserted to slot	Warning	Power Supply was inserted to slot.	
1760	pdc-card-missing	Alarm	Power Supply is missing in slot	Major	Power Supply is missing. Slot enabled when empty.	Insert Power Supply. Disable slot.
1761	pdc-over-voltage	Alarm	Over voltage	Major	System Power Voltage higher than allowed.	NA
1762	pdc-under-voltage	Alarm	Under voltage	Major	System Power Voltage Lower than allowed.	NA
1763	TCC-fpga-fw-not-found	Alarm	The Main board firmware is not found	Warning		
1764	TCC-fw-load-fail	Alarm	Download Main Board firmware has failed	Major	Firmware download was unsuccessful.	Reset board. Download software package. Try to insert another board.
1765	tcc-powerup-reset-event	Event	Main Board was reset	Warning		

1766	upload-software-failed	Event	RFU installation failure	Warning	Unsupported RFU type. IDU-RFU communications problem. RFU failure.	Make sure RFU is supported by SW version. Check IDU-RFU cable. Replace RFU.
1767	upload-software-started	Event	RFU installation in progress	Warning	User command	
1768	upload-software-succeeded-event	Event	RFU installation successfully completed	Warning	User command	
1769	unit-cold-reset-event	Event	Unit Perform Power up	Warning		
1770	cable-lof-rfu	Event	Unit performing power-up.	Major		
1771	cable-error-rfu	Alarm	RFU cable error.	Major	Errors in signal from IDU to XCVR.	Check the IF cable and connectors. Verify that the N-Type/TNC connector inner pin is not spliced. Replace RMC. Replace XCVR.
1772	xpic-data-los	Alarm	Radio XPIC sync loss	Major	Signalling between RMCs (Radio Modem Cards) for XPIC functionality has failed	Check that the RMCs are in allowed slots. Populate the RMCs in different allowed location in the chassis. Replace RMC/s. Replace chassis.
1773	early-warning	Alarm	Radio early warning.	Warning	The estimated radio BER (Bit Error Rate) is above 10E-12.	Check link performance. Check IF cable, and replace if required.

						Replace XCVR. Replace RMC.
1774	sw-download-incompatible-rfu	Alarm	RFU software download cannot be initiated.	Critical	The hardware of the XCVR is OK, but is it running with METRO radio application.	Upgrade the XCVR software application via XPAND-IP and then reinitiate software download..
1775	hw-incompatible-rfu	Alarm	RFU software download is not possible.	Critical	Wrong type of XCVR, the XCVR hardware is METRO.	Replace the XCVR
1776	pll-rmc	Alarm	RMC hardware failure.	Major	RMC hardware failure of the clock distributor.	Replace the RMC.
1780	mrmc-running-script-deleted	Event	MRMC running script is deleted	Warning	New installed software package does not include the running MRMC radio script	Make sure the required software package include the running MRMC radio script. Download and install the correct software package.
1781	mrmc-running-script-updated	Event	MRMC running script is updated	Warning	New installed software package does has an updated version of the running MRMC radio script	Reset the radio carrier to reacquire the new updated MRMC radio script
1782	radio-2_5gbps-mismatch-configuration	Alarm	2.5Gbps mismatch configuration	Warning	The card can not function outside of an ABC group in 2.5Gbps mode.	Add the card to an ABC group, or change the Slot Section to 1Gbps.
1783	remote-fault-indication	Alarm	Radio remote fault indication (RFI)	Minor		

1790	np-hw-failure	Alarm	Hardware failure	Critical	An internal hardware failure has been detected by the system.	Replace the card or unit reporting the hardware failure.
1800	t3-loc-alarm	Alarm	T3 sync interface Loss of Carrier	Major	Cable disconnected. Defective cable.	Check connection of the cable. Replace the cable.
2001	pwe3-pwc-s-card-reset	Alarm	TDM-LIC has rebooted and is not in service now	Major	Recent TDM-LIC card reset; System malfunction.	Wait for card to reboot. Reset the TDM-LIC card.
2002	pwe3-pwc-s-config-mismatch	Alarm	TDM-LIC configuration mismatch	Major	Recent warm reset of TDM-LIC; System malfunction.	Power cycle the TDM-LIC.
2003	pwe3-pwc-s-front-panel-clock-los	Alarm	Loss of Signal (LOS) on TDM-LIC's front panel clock port	Major	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2004	pwe3-pwc-s-host-pw-lic-comm-disrupt	Alarm	Communication with TDM-LIC is disrupted in Host-Card direction	Minor	System malfunction	Reset the TDM-LIC.
2005	pwe3-pwc-s-hw-failure	Alarm	TDM-LIC hardware failure	Major	System malfunction	Reset the TDM-LIC.
2006	pwe3-pwc-s-pw-lic-host-comm-disrupt	Alarm	No communication with TDM-LIC	Major	System malfunction	Reset the TDM-LIC.
2007	pwe3-pws-s-jitter-buffer-overflow	Alarm	Jitter-buffer-overflow alarm on TDM service	Major	Something wrong on TDM service synchronization	Check TDM service configuration

2008	pwe3-pws-s-late-frame	Alarm	Late-frame alarm on TDM service	Warning	Something wrong on TDM service	Check TDM service configuration
2009	pwe3-pws-s-loss-of-frames	Alarm	Loss-of-frames alarm on TDM service	Major	Failure along the network path of TDM service	Check network or configuration for errors in the network transport side of the service
2010	pwe3-pws-s-malformed-frames	Alarm	Malformed-frames alarm on TDM service	Major	Payload size does not correspond to the defined value. Mismatch in PT value in RTP header (if used)	Check TDM service configuration
2011	pwe3-pws-s-misconnection	Alarm	Misconnection alarm on TDM service	Major	Stray packets with wrong RTP configurations are received and dropped.	Check TDM service configuration
2012	pwe3-tdm-port-s-ais	Alarm	Alarm Indication Signal (AIS) on TDM-LIC TDM port	Major	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment.
2013	pwe3-tdm-port-s-lof	Alarm	Loss Of Frame (LOF) on TDM-LIC TDM port	Major	Line is not properly connected. External equipment is faulty.	
2014	pwe3-tdm-port-s-lomf	Alarm	Loss Of Multi-Frame (LOMF) on TDM-LIC TDM port	Major	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment.
2015	pwe3-tdm-port-s-loopback-alarm	Alarm	Loopback on TDM-LIC TDM port	Warning	Line is not properly connected.	Reconnect line. Check line cables.

					External equipment is faulty.	Check external equipment.
2016	pwe3-tdm-port-s-los	Alarm	Loss Of Signal (LOS) on TDM-LIC TDM port	Major	Line is not properly connected. Cable is faulty. External equipment is faulty. Defective TDM-LIC.	Reconnect line. Check line cables. Check external equipment.
2017	pwe3-tdm-port-s-rai	Alarm	Remote Alarm Indication (RAI) on TDM-LIC TDM port	Minor	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment.
2018	pwe3-tdm-port-s-unexpected-signal-alarm	Alarm	E1/DS1 Unexpected signal on TDM-LIC TDM port	Warning	Port is disabled. Line is connected to a disabled port.	Enable relevant port. Disconnect cable from relevant port.
2021	pwe3-pwc-s-ssm-rx-changed	Event	SSM received pattern change was discovered	Warning		No action is required.
2022	pwe3-stm1oc3-s-excessive-ber-alarm	Alarm	Excessive BER on TDM-LIC STM1/OC3 port	Major	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2023	pwe3-stm1oc3-s-lof-alarm	Alarm	Loss Of Frame (LOF) on TDM-LIC STM1/OC3 port	Major	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.

2024	pwe3-stm1oc3-s-loopback-alarm	Alarm	Loopback on TDM-LIC STM1/OC3 port	Warning	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2025	pwe3-stm1oc3-s-los-alarm	Alarm	Loss Of Signal (LOS) on TDM-LIC STM1/OC3 port	Critical	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2026	pwe3-stm1oc3-s-mute-override-alarm	Alarm	SFP is muted on TDM-LIC STM1/OC3 port	Warning		
2027	pwe3-stm1oc3-s-sfp-absent-alarm	Alarm	SFP absent in TDM-LIC STM1/OC3 port	Critical	SFP is not properly installed. SFP is faulty.	Install SFP properly. Replace the card.
2028	pwe3-stm1oc3-s-sfp-failure-alarm	Alarm	SFP failure on TDM-LIC STM1/OC3 port	Critical	SFP is not properly installed. SFP is faulty.	Install SFP properly. Replace the card.
2029	pwe3-stm1oc3-s-sfp-tx-fail-alarm	Alarm	SFP transmit failure on TDM-LIC STM1/OC3 port	Critical	SFP is not properly installed. SFP is faulty.	Install SFP properly. Replace the card.
2030	pwe3-stm1oc3-s-signal-degrade-alarm	Alarm	Signal Degrade on TDM-LIC STM1/OC3 port	Minor	Line is not properly connected. SFP is not properly installed. SFP is faulty.	Install SFP properly. Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.

					External equipment is faulty	
2031	pwe3-stm1oc3-s-slm-alarm	Alarm	J0 Trace Identifier Mismatch on TDM-LIC STM1/OC3 port	Minor	J0 misconfiguration. Line is not properly connected. SFP is not properly installed. External equipment is faulty.	Make sure expected and received J0 match. Install SFP properly. Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2032	pwe3-stm1oc3-s-ssm-rx-changed	Event	SSM pattern received on TDM-LIC STM1/OC3 port changed	Warning		
2033	pwe3-vc12vt15-s-ais-alarm	Alarm	Alarm Indication Signal (AIS) on TDM-LIC VC12/VT1.5	Minor	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2034	pwe3-vc12vt15-s-excessive-ber-alarm	Alarm	Excessive BER on TDM-LIC VC12/VT1.5	Minor	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2035	pwe3-vc12vt15-s-loopback-alarm	Alarm	Loopback on TDM-LIC VC12/VT1.5	Warning	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment.

						Power cycle the TDM-LIC.
2036	pwe3-vc12vt15-s-rcv-plm-alarm	Alarm	Payload Mismatch Path (PLM) received on TDM-LIC VC12/VT1.5	Minor	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2037	pwe3-vc12vt15-s-rcv-rdi-alarm	Alarm	Remote Defect Indication (RDI) received on TDM-LIC VC12/VT1.5	Minor	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2038	pwe3-vc12vt15-s-rcv-slm-alarm	Alarm	Signal Label Mismatch (SLM) received on TDM-LIC VC12/VT1.5	Minor	J2 misconfiguration. Line is not properly connected. External equipment is faulty.	Make sure expected and receive J2 match. Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2039	pwe3-vc12vt15-s-signal-degrade-alarm	Alarm	Signal Degrade on TDM-LIC VC12/VT1.5	Minor	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2040	pwe3-vc12vt15-s-unequipped-alarm	Alarm	Unequipped on TDM-LIC VC12/VT1.5	Minor	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment.

						Power cycle the TDM-LIC.
2041	pwe3-card-group-s-config-mismatch	Alarm	TDM-LIC card protection configuration mismatch	Major	The configuration between the TDM-LIC card protection members is not aligned	Apply a copy-to-mate command to copy the configuration from the required TDM-LIC to the other one
2042	pwe3-card-group-s-lockout	Alarm	TDM-LIC card protection group lockout command is on	Minor	The user has issued a lockout command	Clear the lockout command
2043	pwe3-card-group-s-no-mate	Alarm	A member of TDM-LIC card protection group is missing	Minor	TDM-LIC card is not installed in the shelf	Install the missing TDM-LIC card
2044	pwe3-card-group-s-protection-switch-evt	Event	TDM-LIC card protection switch over, priority	Warning	LOS alarm on a STM1 interface of the TDM-LIC card protection group member; A TDM-LIC card protection group member was disabled or pulled out of the shelf	Check line cables. Check external equipment.
2045	pwe3-vc12vt15-s-lop-alarm	Alarm	Loss Of Pointer (LOP) received on TDM-LIC VC12/VT1.5	Minor	Line is not properly connected. External equipment is faulty.	Reconnect line. Check line cables. Check external equipment. Power cycle the TDM-LIC.
2046	pwe3-tunnel-groups-s-protection-switch	Event	Path protection switch on TDM service	Minor	Failure along service primary path. User command.	Check errors along primary path Check local service configuration.

2047	pwe3-tunnel-groups-s-revertive-switch	Event	Path protection revertive switch on TDM service	Minor	Primary path has been operational for the duration of the defined WTR time	-
2200	MC-ABC-Local-LOF	Alarm	Multi Carrier ABC LOF.	Critical	All channels in Multi Carrier ABC group are down.	Check link performance on all radio channels in Multi Carrier ABC group. Check radio alarms for channels in Multi Carrier ABC group. Check configuration of Multi Carrier ABC group.
2201	MC-ABC-local-cap-below	Alarm	Multi Carrier ABC bandwidth is below the threshold	Major	One of the radio channels in the Multi Carrier ABC group has a lower capacity than expected Minimum bandwidth threshold configuration is wrong	Check link performance on all radio channels in Multi Carrier ABC group Check radio alarms for channels in Multi Carrier ABC group Check configuration of Multi Carrier ABC group Minimum bandwidth threshold
2203	MC-ABC-Lvds-Error-SI2	Alarm	LVDS RX Error Slot 2.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.
2204	MC-ABC-Lvds-Error-SI3	Alarm	LVDS RX Error Slot 3.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.

2205	MC-ABC-Lvds-Error-SI4	Alarm	LVDS RX Error Slot 4.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.
2206	MC-ABC-Lvds-Error-SI5	Alarm	LVDS RX Error Slot 5.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.
2207	MC-ABC-Lvds-Error-SI6	Alarm	LVDS RX Error Slot 6.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.
2208	MC-ABC-Lvds-Error-SI7	Alarm	LVDS RX Error Slot 7.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.
2209	MC-ABC-Lvds-Error-SI8	Alarm	LVDS RX Error Slot 8.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.
2210	MC-ABC-Lvds-Error-SI9	Alarm	LVDS RX Error Slot 9.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.
2211	MC-ABC-Lvds-Error-SI10	Alarm	LVDS RX Error Slot 10.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.
2212	MC-ABC-Lvds-Error-SI12	Alarm	LVDS RX Error Slot 12.	Major	Hardware failure between RMC and TCC cards.	Replace RMC. Replace TCC. Replace chassis.

2219	MC-ABC-Ch-Id-Mismatch-Ch1	Alarm	Multi Carrier ABC Channel Id Mismatch Ch1.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.
2220	MC-ABC-Ch-Id-Mismatch-Ch2	Alarm	Multi Carrier ABC Channel Id Mismatch Ch2.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.
2221	MC-ABC-Ch-Id-Mismatch-Ch3	Alarm	Multi Carrier ABC Channel Id Mismatch Ch3.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.
2222	MC-ABC-Ch-Id-Mismatch-Ch4	Alarm	Multi Carrier ABC Channel Id Mismatch Ch4.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.
2223	MC-ABC-Ch-Id-Mismatch-Ch5	Alarm	Multi Carrier ABC Channel Id Mismatch Ch5.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.
2224	MC-ABC-Ch-Id-Mismatch-Ch6	Alarm	Multi Carrier ABC Channel Id Mismatch Ch6.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.
2225	MC-ABC-Ch-Id-Mismatch-Ch7	Alarm	Multi Carrier ABC Channel Id Mismatch Ch7.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.
2226	MC-ABC-Ch-Id-Mismatch-Ch8	Alarm	Multi Carrier ABC Channel Id Mismatch Ch8.	Warning	Configuration failure.	Compare Channel ID configuration with remote side.
2235	MC-ABC-Ch-Id-Disabled-Ch1	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch1.	Warning	Admin state for channel is down.	Enable admin state for channel.
2236	MC-ABC-Ch-Id-Disabled-Ch2	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch2.	Warning	Admin state for channel is down.	Enable admin state for channel.

2237	MC-ABC-Ch-Id-Disabled-Ch3	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch3.	Warning	Admin state for channel is down.	Enable admin state for channel.
2238	MC-ABC-Ch-Id-Disabled-Ch4	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch4.	Warning	Admin state for channel is down.	Enable admin state for channel.
2239	MC-ABC-Ch-Id-Disabled-Ch5	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch5.	Warning	Admin state for channel is down.	Enable admin state for channel.
2240	MC-ABC-Ch-Id-Disabled-Ch6	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch6.	Warning	Admin state for channel is down.	Enable admin state for channel.
2241	MC-ABC-Ch-Id-Disabled-Ch7	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch7.	Warning	Admin state for channel is down.	Enable admin state for channel.
2242	MC-ABC-Ch-Id-Disabled-Ch8	Alarm	Multi Carrier ABC Channel Id Manual Disabled Ch8.	Warning	Admin state for channel is down.	Enable admin state for channel.
2300	protection-configuration-mismatch	Alarm	Protection configuration mismatch!	Major	The configuration between the protected devices is not aligned.	Apply copy-to-mate command to copy the configuration from the required device to the other one.
2301	protection-copytomate-started	Event	Copy to mate started	Indeterminate	The copy-to-mate command has just begun!	This is a notification
2302	protection-copytomate-completed	Event	Copy to mate completed	Indeterminate	The copy-to-mate command was completed.	This is a notification
3000	chassis-reset-event	Event	Chassis was reset	Warning	User issued a command to reset the chassis.	Wait until the reset cycle is ended and the system is up and running.

3001	10gbps-mode-front-panel-ports-unavailable	Alarm	Reset chassis to activate front panel Ethernet ports	Warning	Front panel Ethernet ports cannot work when slot 12 is configured in 10Gbps mode.	Reset chassis.
3002	slot-mode-front-panel-ports-not-functional	Alarm	Front panel Ethernet port cannot function in current configured capacity mode	Warning	Front panel Ethernet port cannot work in a mode other than 1Gbps.	Configure the relevant capacity mode to 1 Gbps mode.
3003	abc-mode-not-functional	Alarm	Multi Carrier ABC group is not functional in current configured capacity mode	Warning	Multi Carrier ABC group does not support the configured capacity mode.	Configure the relevant capacity mode to 1 Gbps mode.
3004	abc-mode-not-functional-until-reset	Alarm	Multi Carrier ABC group is not functional in current configured capacity mode until chassis is reset	Warning	Multi Carrier ABC group capacity mode is different than the configured capacity mode.	Reset chassis.
4000	hw-failure	Alarm	Card has one or more HW failures	Critical	One or more HW faults.	Replace card.
4001	slotsection-2_5gbps-compatibility	Alarm	Card can not function in 2.5Gbps mode.	Warning	The user set an expected card that does not support 2.5Gbps.	Change the Slot Section to 1Gbps.
4002	slot-slotsection-10gbps-card-not-functional	Alarm	Card is not functional until chassis is reset	Warning	Slot is not in 10Gbps mode.	Reset chassis.
5000	failure-login-event	Event	User blocked due to consecutive failure login	Indeterminate	User blocked due to consecutive failure login	The user should wait few minutes until it account will be unblock

5001	g8032-protection-switching-alarm	Alarm	ERPI is either in protection state or forced protection state	Minor	Either user "force switch" command or one of the ring links has failed	Either clear force command or recover the link
5002	g8032-failure-of-protocol-pm-alarm	Alarm	More than a single RPL is configured in a ring	Warning	User configuration	Reconfigure the RPL
5003	lldp-topology-change	Event	LLDP topology change	Warning	New neighbor	None
5004	security-log-upload-started-event	Event	Security log upload started	Indeterminate	Security log upload started	
5005	security-log-upload-failed-event	Event	Security log upload failed	Indeterminate	Security log upload failed	
5006	security-log-upload-succeeded-event	Event	Security log upload succeeded	Indeterminate	Security log upload succeeded	
5010	force-mode-alarm	Alarm	System is in sync force mode state	Warning	User command	
5011	sync-quality-change-event	Event	The sync-source quality level was changed	Major		
5012	system-clock-in-holdover-mode	Alarm	System Synchronization Reference in Holdover Mode	Critical		
5013	sync-T0-quality-change-event	Event	System sync reference T0 quality has changed	Major		
5014	sync-pipe-invalid-interface-clock-source	Alarm	The pipe interface clock-source in signal-interface table is not system-clock	Major		
5015	sync-pipe-missing-edge	Alarm	The pipe is missing an edge interface	Major	Regenerator contains less than 2 interfaces	Accomplish configuration by assigning second interface

5016	sync-pipe-interface-op-state-down	Alarm	Pipe interface operational state is down	Major	At least one of Regenerator Interfaces status is down	Checking regenerator Admin status
5017	sync-pipe-invalid-pipe	Alarm	Pipe is invalid	Major	Interfaces has Configuration or Operation fails	Configuration not accomplished
5018	sync-1588-tc-not-operational	Alarm	1588TC is not operational	Major	System Failure	Reboot the unit
5020	sync-T3-remote-loopback	Alarm	T3 interface at loopback mode	Warning		
5021	sync-T4-analog-loopback	Alarm	T4 interface at loopback mode	Warning		
5030	soam-connectivity-failure	Alarm	A connectivity failure in MA/MEG	Minor	Wrong link configurations.	Check the link in the traffic path
5031	soam-def-error-failure	Alarm	Error CCM received	Major	Invalid CCMs has been received	Check the link in the traffic path
5032	soam-def-mac-failure	Alarm	Remote mep MAC status not up	Minor	Remote MEP's associated MAC is reporting an error status	Check remote MEP's MAC status
5033	soam-def-rdi-failure	Alarm	Mep Rdi received	Minor	Remote Defect indication has been received from remote MEP	Check the SOAM configurations
5034	soam-remote-ccm-failure	Alarm	Remote mep CCMs are not received	Major	The MEP is not receiving CCMs from at least one of the remote MEPs	Check that all remote MEPs are configured or enabled

5035	soam-def-xcon-failure	Alarm	Cross Connect CCM received	Major	CCM from another MAID or lower MEG level have been received	Check MA/MEG and MEP configurations
5036	ptp-stream-state-change	Event	1588-BC port state changed	Warning		
5037	ptp-bmca-update	Event	1588-BC BMCA has been updated.	Warning		
5038	ptp-output-squelch	Event	1588-BC outputs are squelched.	Warning		
5039	ptp-parent-data-set-change	Event	1588-BC parent dataset has changed.	Warning		
5040	ptp-utc-offset-change	Event	1588-BC UTC offset value changed.	Warning		
5041	ptp-leap-seconds-flag-change	Event	1588-BC one of the leap seconds flags have changed.	Warning		
5042	ptp-message-interval-change	Event	1588-BC message interval change detected.	Warning		
5043	ptp-message-rate-announce	Alarm	1588-BC announce message rate is below expected.	Major	Misconfiguration of the peer system.	Check the configuration of the peer system.
5044	ptp-message-rate-sync	Alarm	1588-BC sync message rate is below expected.	Major	Misconfiguration of the peer system.	Check the configuration of the peer system.
5045	ptp-message-rate-delay-req	Alarm	1588-BC delay request message rate is below expected.	Major	Misconfiguration of the peer system.	Check the configuration of the peer system.
5046	ptp-no-syncE	Alarm	1588-BC performance is degraded due to loss of system clock reference.	Critical	Loss of system clock reference.	Restore the system clock synchronization to a PRC-traceable source.

5100	mkey-mismatch	Alarm	Master key mismatch cross over the link	Critical	Master Key was not set correctly.	Verify the Master Key.
5101	mkey-no-exist	Alarm	No Master Key set, default value used	Warning	Crypto module has been enabled, but no Master Key has been loaded.	Set the Master Key.
5102	general-encryption-failure	Alarm	Payload Encryption failure	Critical	Radio LOF on Tx/Rx direction. The session key does not match across the link. The AES admin setting does not match across the link.	Validate the MSE on both sides of the link. Validate the session key on both sides of the link. Validate the AES admin setting on both sides of the link.
5104	kep-initiated	Event	Key Exchange Protocol in progress, Traffic has been blocked	Indeterminate		
5105	kep-remote-initiated	Event	Key Exchange Protocol initiated by remote side	Indeterminate		
5107	bypass-self-test-alarm	Alarm	FIPS Bypass Self-Test failed	Critical	Disk failure	
5108	post-fail-alarm	Alarm	Power On Self-Test Failed	Critical	System failure	Reboot the unit.
5109	main-board-non-fips-alarm	Alarm	Main Board is not FIPS certified	Critical	Main Board used is not FIPS certified	Use a FIPS-certified TCC.
5110	radio-non-fips-alarm	Alarm	Radio card is not FIPS certified	Major	Radio Card used is not FIPS certified	Use a FIPS-certified RMC.
5111	aes-self-test-fail-alarm	Alarm	Radio crypto module fail	Critical	FIPS Radio Encryption Self-Test failed	Use different FIPS supported radio card
5112	hw-not-supported-alarm	Alarm	Radio Encryption not supported	Major	No Payload Encryption Activation Key inserted	Insert suitable Activation Key and reboot the unit

30007	Clock-source-sharing-failure-event	Event	Clock source sharing failure	Critical	Faulty coaxial cable between master and slave RFUs. Hardware failure in Master RFU. Hardware failure in Slave RFU.	Try re-initiation of MIMO. If still fails: Replace faulty coaxial cable and reset Master RFU. Replace faulty RFU.
31000	Insufficient-conditions-for-MIMO-alarm	Alarm	Insufficient conditions for MIMO	Critical	Insufficient conditions for MIMO. Hardware failure.	Make sure all cables between master and slave are connected (MIMO 4x4 only). Replace faulty units and check that cables are plugged.
31003	Unsuitable-hardware-for-MIMO-alarm	Alarm	Unsuitable hardware for MIMO	Critical	Unsuitable hardware for MIMO operation requirements. Dual carrier RFUs (MIMO 2x2 and 4x4). RFUs with MIMO bus interface (MIMO 4x4). Clock source sharing capability (MIMO 4x4).	Make sure both RFUs are compatible for MIMO operation.
31004	Unsuitable-software-configuration-for-MIMO-alarm	Alarm	Unsuitable software configuration for MIMO	Critical	Not all MIMO carriers are set to same radio script or script is not compatible for MIMO. Radio TX and RX frequency is not identical on all MIMO carriers.	Load same MIMO compatible radio script to all MIMO carriers. Set same TX and RX frequency on all MIMO carriers.

					XPIC or Multi radio or ATPC features are enabled.	Disable XPIC, Multi radio and ATPC on all MIMO carriers.
31005	Clock-source-sharing-failure-alarm	Alarm	Clock source sharing cable unplugged	Critical	Faulty coaxial cable between master and slave RFUs Mate does not exist	Replace faulty coaxial cable and reset Master RFU. Replace faulty RFU.
31100	AMCC-Incompatible-radio-script-alarm	Alarm	Radio script is incompatible to AMCC	Critical	MRMC Script selected does not support AMCC Group type/subtype	Set AFR Script in both Agg1 & Agg2 carriers
31101	AMCC-Inconsistent-MRMC-Script-alarm	Alarm	Inconsistent MRMC script between members	Critical	All members of a group must be configured to the same MRMC Script	Set the members to the appropriate MRMC script
31102	AMCC-Inconsistent-radio-frequency-alarm	Alarm	Inconsistent radio frequency	Critical	Radio TX/RX frequency is not identical on all AMCC carriers	Set same radio TX/RX frequency on all AMCC carriers
31103	AMCC-Failed-To-Load-Alarm	Alarm	Agg 1 failed Bring-up procedure	Critical	Agg1 did not complete Bring-up successfully	Drop both Agg1 & Agg2 into single carrier mode (Pre-Init)
31104	AMCC-Invalid-ACM-Configuration-alarm	Alarm	Invalid ACM configuration	Critical	AMCC member have been set to fixed profile	Set AMCC member to adaptive ACM profiles

Glossary

Term	Definition
ABC	Adaptive Bandwidth Control
ACAP	Adjacent Channel Alternate Polarization
ACCP	Adjacent Channel Co-Polarization
ACM	Adaptive Coded Modulation
ACR	Adaptive Clock Recovery
AES	Advanced Encryption Standard
AIS	Alarm Indicating Signal
ANSI	American National Standards Institute
ATPC	Automatic Transmit Power Control
BBS	Baseband Switching
BER	Bit Error Rate
BPDU	Bridge Protocol Data Units
CBS	Committed Burst Size
CCDP	Co-Channel Dual Polarization
CCITT	Comité Consultatif International de Télégraph et des Télécommunications (ITU)
CET	Carrier-Ethernet Transport
CFM	Connectivity Fault Management
CIR	Committed Information Rate
CIST	Common and Internal Spanning Tree
CLI	Command Line Interface
CoS	Class of Service
CSR	Certificate Signing Request
DA	Destination Address
DC	Direct Current
DSCP	Differentiated Services Code Point
EBS	Excess Burst Size

Term	Definition
EIR	Excess Information Rate
EMC	Electromagnetic Compatibility
EOW	Engineering Order Wire
EPROM	Erasable Programmable Read Only Memory
ERPI	Ethernet Ring Protection Instance
ESD	Electrostatic Discharge
ETSI	European Telecommunications Standards Institute
FCC	Federal Communications Commission
FCS	Frame Check Sequence
FTP	File Transfer Protocol
GbE	Gigabit Ethernet
GND	Ground
HSB	Hot-Standby
HTTP	Hypertext Transfer Protocol
HTTPS	Secured Hypertext Transfer Protocol
IDC	Indoor Controller
IDU	Indoor Unit
IF	Intermediate Frequency
ISO	International Organization for Standardization
ITU	International Telecom. Union
ITU-R	International Telecom. Union (former CCIR)
ITU-T	International Telecom. Union (former CCITT)
LACP	Link Aggregation Control Protocol
LAG	Link Aggregation Group
LAN	Local Area Network
LED	Light Emitting Diode
LIC	Line Interface Card
LLDP	Link Layer Discovery Protocol
LLDPU	Link Layer Discovery Protocol Data Unit
LOC	Loss of Carrier

Term	Definition
LOF	Loss of Frame
LOS	Loss of Signal
MAID	Maintenance Association Identifier
MEG	Maintenance Entity Group
MFN	MEP Fault Notification
MHF	MIP Half Function
MIP	Maintenance Association Intermediate Point
MPLS	Multi Protocol Label Switching
MSP	Multiplex Section Protection
MSTI	MSTP Instance
MSTP	Multiple Spanning Tree Protocol
MUX	Multiplexer
NE	Network Element
NMS	Network Management System
NTP	Network Time Protocol
OAM	Operation Administration & Maintenance (Protocols)
OCB	Outdoor Circulator Box
PBS	Peak Burst Rate
PC	Personal Computer
PCB	Printed Circuit Board
PDV	Packed Delay Variation
PIR	Peak Information Rate
PM	Performance Monitoring
PSN	Packet Switched Network
PTP	Precision Timing Protocol
QoS	Quality of Service
RBAC	Role Based Access Control
RDI	Reverse Defect Indication
RF	Radio Frequency
RFU	Radio Frequency Unit

Term	Definition
RMC	Radio Modem Card
RMON	Remote Network Monitoring
RSL	Received Signal Level
RSTP	Rapid Spanning Tree Protocol
SAP	Service Access Point
SD	Space Diversity
SDH	Synchronous Digital Hierarchy
SFTP	Secure FTP
SLA	Service Level Agreements
SNCP	Simple Network Connection Protection
SNMP	Simple Network Management Protocol
SNP	Service Network Point
SNTP	Simple Network Time Protocol
SOAM	Service Operations, Administration, and Maintenance
SONET	Synchronous Optical NETWORK
SP	Service Point
SSH	Secured Shell (Protocol)
SSM	Synchronization Status Message
STP	Spanning Tree Protocol
SyncE	Synchronous Ethernet
SVCE	Service Channel Equipment
TC	Traffic Class
TCN	Topology Change Notification
TDM	Time Division Multiplexing
TIM	Trace Identifier Mismatch
TLV	Time-Length-Value Structure
TTL	Time-To-Live
VC	Virtual Container
Web EMS	Web-Based Element Management System
WFQ	Weighted Fair Queue

Term	Definition
WRED	Weighted Random Early Detection
XPIC	Cross Polarization Interference Cancellation