



USER GUIDE

Intelligent Positioning System for Nomadic Wireless Broadband Devices



Accuracy

While reasonable efforts have been made to assure the accuracy of this document, Cambium Networks assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. Cambium reserves the right to make changes to any products described herein to improve reliability, function, or design, and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Cambium does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others. It is possible that this publication may contain references to, or information about Cambium products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Cambium intends to announce such Cambium products, programming, or services in your country.

Copyrights

This document, Cambium products, and 3rd Party software products described in this document may include or describe copyrighted Cambium and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Cambium, its licensors, and other 3rd Party supplied software certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Cambium, its licensors, or the 3rd Party software supplied material contained in the Cambium products described in this document may not be copied, reproduced, reverse engineered, distributed, merged or modified in any manner without the express written permission of Cambium. Furthermore, the purchase of Cambium products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Cambium or other 3rd Party supplied software, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

Restrictions

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Cambium.

License Agreements

The software described in this document is the property of Cambium and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

High Risk Materials

Cambium and its supplier(s) specifically disclaim any express or implied warranty of fitness for any high-risk activities or uses of its products including, but not limited to, the operation of nuclear facilities, aircraft navigation or aircraft communication systems, air traffic control, life support, or weapons systems ("High Risk Use").

This product is not restricted in the EU. Any High Risk is unauthorized, is made at your own risk and you shall be responsible for any and all losses, damage or claims arising out of any High-Risk Use.

Contents

Contents.....	4
About This User Guide.....	7
Purpose.....	7
Cross-references	7
Feedback.....	7
Problems and warranty	7
Reporting problems	7
Repair and service.....	7
Hardware warranty	8
Security advice	8
Warnings, cautions, and notes.....	8
Warnings	8
Cautions.....	9
Notes.....	9
Caring for the environment.....	9
In EU countries	9
Disposal of Cambium equipment.....	9
Disposal of surplus packaging	9
In non-EU countries	9
About This User Guide.....	10
Purpose	10
Cross-references.....	10
Feedback.....	10
Problems and warranty	10
Reporting problems	10
Repair and service	10
Hardware warranty.....	11
Security advice.....	11

Warnings, cautions, and notes	11
Caring for the environment	12
In EU countries	12
In non-EU countries.....	12
Chapter 1: Overview	13
Intelligent Positioning System Overview	13
Overview	13
Specifications	13
Chapter 2: Configuration	16
Configuring the Management PC.....	16
Intelligent Positioning System Configuration.....	19
Chapter 3: System Installation	23
Installing the Intelligent Positioning System	23
Chapter 4: Antenna Alignment Operations.....	26
Aligning the Antenna using the Intelligent Positioning System.....	26
How the Compass Calibration Works	28
How Seek and Peak Works	29
Chapter 5: User Interface.....	31
Main Page.....	31
Geo Position panel.....	31
Compass panel.....	32
Controls panel	32
Message Center panel	32
GPS/Target Location panel.....	33
Stored Location window panel.....	33
Radio Panel.....	33
Advanced Page.....	34
Geo/Pedestal Position panel	34
Fixed Locations panel	35
GPS/Target location panel	35

Auto Peak panel	36
Auto Peak Settings panel.....	37
Manual Controls panel.....	38
Operating Mode panel	40
Local Map panel.....	40
Chapter 6: Maintenance Operation.....	42
Optional System Settings	42
System Recovery	43
Updating Software	43
User Administration	45

About This User Guide

This document explains how to deploy a Intelligent Positioning Systems for Nomadic Wireless Broadband Devices along with important safety measures. It is intended for use by the system designer, system installer and system administrator.

Purpose

Cambium Networks Intelligent Positioning Systems for Nomadic Wireless Broadband Devices documents are intended to instruct and assist personnel in the operation, installation, and maintenance of the Positioner equipment and ancillary devices. It is recommended that all personnel engaged in such activities be properly trained.

Cambium Networks disclaims all liability whatsoever, implied or express, for any risk of damage, loss or reduction in system performance arising directly or indirectly out of the failure of the customer, or anyone acting on the customer's behalf, to abide by the instructions, system parameters, or recommendations made in this document.

Cross-references

References to external publications are shown in *italics*. Other cross-references, emphasized in blue text in electronic versions, are active links to the references.

This document is divided into numbered chapters that are divided into sections. Sections are not numbered but are individually named at the top of each page and are listed in the table of contents.

Feedback

We appreciate feedback from the users of our documents. This includes feedback on the structure, content, accuracy, or completeness of our documents. To provide feedback, visit our support website: <https://support.cambiumnetworks.com>.

Problems and warranty

Reporting problems

If any problems are encountered when installing or operating this equipment, follow this procedure to investigate and report:

1. Search this document and the software release notes of supported releases.
2. Visit the support website.
3. Ask for assistance from the Cambium product supplier.
4. Gather information from affected units, such as any available diagnostic downloads.
5. Escalate the problem by emailing or telephoning support.

Repair and service

If unit failure is suspected, obtain details of the Return Material Authorization (RMA) process from the support website (<http://www.cambiumnetworks.com/support>).

Hardware warranty

Cambium's standard hardware warranty is for one (1) year from date of shipment from Cambium Networks or a Cambium distributor. Cambium Networks warrants that hardware will conform to the relevant published specifications and will be free from material defects in material and workmanship under normal use and service. Cambium shall within this time, at its own option, either repair or replace the defective product within thirty (30) days of receipt of the defective product. Repaired or replaced product will be subject to the original warranty period but not less than thirty (30) days.

To register positioner products or activate warranties, visit the support website. For warranty assistance, contact the reseller or distributor. The removal of the tamper-evident seal will void the warranty.



Caution

Using non-Cambium parts for repair could damage the equipment or void warranty. Contact Cambium for service and repair instructions.

Portions of Cambium equipment may be damaged from exposure to electrostatic discharge. Use precautions to prevent damage.

Security advice

Cambium Networks systems and equipment provide security parameters that can be configured by the operator based on their particular operating environment. Cambium recommends setting and using these parameters following industry recognized security practices. Security aspects to be considered are protecting the confidentiality, integrity, and availability of information and assets. Assets include the ability to communicate, information about the nature of the communications, and information about the parties involved.

In certain instances, Cambium makes specific recommendations regarding security practices, however the implementation of these recommendations and final responsibility for the security of the system lies with the operator of the system.

Warnings, cautions, and notes

The following describes how warnings and cautions are used in this document and all Cambium Networks document sets:

Warnings

Warnings precede instructions that contain potentially hazardous situations. Warnings are used to alert the reader to possible hazards that could cause loss of life or physical injury. A warning has the following format:



Warning

Warning text and consequence for not following the instructions in the warning.

Cautions

Cautions precede instructions and are used when there is a possibility of damage to systems, software, or individual items of equipment within a system. However, this damage presents no danger to personnel. A caution has the following format:



Caution

Caution text and consequence for not following the instructions in the caution.

Notes

A note means that there is a possibility of an undesirable situation or provides additional information to help the reader understand a topic or concept. A note has the following format:



Note

Note text.

Caring for the environment

The following information describes national or regional requirements for the disposal of Cambium Networks supplied equipment and for the approved disposal of surplus packaging.

In EU countries

The following information is provided to enable regulatory compliance with the European Union (EU) directives identified and any amendments made to these directives when using Cambium equipment in EU countries.

Disposal of Cambium equipment

European Union (EU) Directive 2002/96/EC Waste Electrical and Electronic Equipment (WEEE)

Do not dispose of Cambium equipment in landfill sites. For disposal instructions, refer to

<http://www.cambiumnetworks.com/support/weee-compliance>

Disposal of surplus packaging

Do not dispose of surplus packaging in landfill sites. In the EU, it is the individual recipient's responsibility to ensure that packaging materials are collected and recycled according to the requirements of EU environmental law.

In non-EU countries

In non-EU countries, dispose of Cambium equipment and all surplus packaging in accordance with national and regional regulations.

About This User Guide

This document explains how to deploy a Intelligent Positioning Systems for Nomadic Wireless Broadband Devices along with important safety measures. It is intended for use by the system designer, system installer and system administrator.

Purpose

Cambium Networks Intelligent Positioning Systems for Nomadic Wireless Broadband Devices documents are intended to instruct and assist personnel in the operation, installation, and maintenance of the Positioner equipment and ancillary devices. It is recommended that all personnel engaged in such activities be properly trained.

Cambium Networks disclaims all liability whatsoever, implied or express, for any risk of damage, loss or reduction in system performance arising directly or indirectly out of the failure of the customer, or anyone acting on the customer's behalf, to abide by the instructions, system parameters, or recommendations made in this document.

Cross-references

References to external publications are shown in italics. Other cross-references, emphasized in blue text in electronic versions, are active links to the references.

This document is divided into numbered chapters that are divided into sections. Sections are not numbered but are individually named at the top of each page, and are listed in the table of contents.

Feedback

We appreciate feedback from the users of our documents. This includes feedback on the structure, content, accuracy, or completeness of our documents. To provide feedback, visit our support website: <https://support.cambiumnetworks.com>.

Problems and warranty

Reporting problems

If any problems are encountered when installing or operating this equipment, follow this procedure to investigate and report:

1. Search this document and the software release notes of supported releases.
2. Visit the support website.
3. Ask for assistance from the Cambium product supplier.
4. Gather information from affected units, such as any available diagnostic downloads.
5. Escalate the problem by emailing or telephoning support.

Repair and service

If unit failure is suspected, obtain details of the Return Material Authorization (RMA) process from the support website (<http://www.cambiumnetworks.com/support>).

Hardware warranty

Cambium's standard hardware warranty is for one (1) year from date of shipment from Cambium Networks or a Cambium distributor. Cambium Networks warrants that hardware will conform to the relevant published specifications and will be free from material defects in material and workmanship under normal use and service. Cambium shall within this time, at its own option, either repair or replace the defective product within thirty (30) days of receipt of the defective product. Repaired or replaced product will be subject to the original warranty period but not less than thirty (30) days.

To register positioner products or activate warranties, visit the support website. For warranty assistance, contact the reseller or distributor. The removal of the tamper-evident seal will void the warranty.



Caution

Using non-Cambium parts for repair could damage the equipment or void warranty. Contact Cambium for service and repair instructions.

Portions of Cambium equipment may be damaged from exposure to electrostatic discharge. Use precautions to prevent damage.

Security advice

Cambium Networks systems and equipment provide security parameters that can be configured by the operator based on their particular operating environment. Cambium recommends setting and using these parameters following industry recognized security practices. Security aspects to be considered are protecting the confidentiality, integrity, and availability of information and assets. Assets include the ability to communicate, information about the nature of the communications, and information about the parties involved.

In certain instances, Cambium makes specific recommendations regarding security practices, however the implementation of these recommendations and final responsibility for the security of the system lies with the operator of the system.

Warnings, cautions, and notes

The following describes how warnings and cautions are used in this document and all Cambium Networks document sets:

Warnings

Warnings precede instructions that contain potentially hazardous situations. Warnings are used to alert the reader to possible hazards that could cause loss of life or physical injury. A warning has the following format:



Warning

Warning text and consequence for not following the instructions in the warning.

Cautions

Cautions precede instructions and are used when there is a possibility of damage to systems, software, or individual items of equipment within a system. However, this damage presents no danger to personnel. A caution has the following format:



Caution

Caution text and consequence for not following the instructions in the caution.

Notes

A note means that there is a possibility of an undesirable situation or provides additional information to help the reader understand a topic or concept. A note has the following format:



Note

Note text.

Caring for the environment

The following information describes national or regional requirements for the disposal of Cambium Networks supplied equipment and for the approved disposal of surplus packaging.

In EU countries

The following information is provided to enable regulatory compliance with the European Union (EU) directives identified and any amendments made to these directives when using Cambium equipment in EU countries.

Disposal of Cambium equipment

European Union (EU) Directive 2002/96/EC Waste Electrical and Electronic Equipment (WEEE)

Do not dispose of Cambium equipment in landfill sites. For disposal instructions, refer to

<http://www.cambiumnetworks.com/support/weee-compliance>

Disposal of surplus packaging

Do not dispose of surplus packaging in landfill sites. In the EU, it is the individual recipient's responsibility to ensure that packaging materials are collected and recycled according to the requirements of EU environmental law.

In non-EU countries

In non-EU countries, dispose of Cambium equipment and all surplus packaging in accordance with national and regional regulations.

Chapter 1: Overview

Intelligent Positioning System Overview

Overview

The Cambium Intelligent Positioning System for Nomadic Wireless Broadband Devices is designed to align Point-to-Multipoint or Point-to-Point deployments, where one end of the network is fixed with an antenna beamwidth greater than 10 degrees, and the other end is typically a PMP 450 subscriber module or a remote module that is usually installed on a vehicle providing a nomadic network for the end-users.

When the vehicle is parked at a location, the operator can use the Intelligent Positioning System to automatically align the remote module's antenna with the Access Point, providing optimized wireless connectivity without manual alignment.

The following diagram shows a typical installation setup of a PMP 450i attached to the Intelligent Positioning System.



Specifications

Supported Models:	PMP 450, PMP 450i
-------------------	-------------------

Azimuth:	400° (+/-200°) and Elevation 40° (+/-20°) Up to 4.5° / second in Azimuth Up to 4° / second in Elevation
Dimension:	17"(H) x 9"(W) x 11"(D)
Weight:	18.0 lbs
Payload:	45 lbs
Mounting:	Clamps to 2" diameter mast Optional Table mount with four holes in a square
Temperature:	Operational: -22 to 140F° Survival: -40 to 158F°
Power:	Passive PoE with -48 VDC to -56 VDC
Management:	HTTP web interface, SNMPv2
Ethernet:	10/100

Standard parts required for the Intelligent Positioning System installation include:

Quantity	Part Number	Description
1	C000000H002A	Intelligent Positioner for Nomadic Wireless Broadband
1	N000000L143A	Intelligent Positioning Systems PoE Cable with a weather-tight end, 30 meters
1	N000000L144A	Intelligent Positioning Systems PTP450/670 Radio adapter bracket
1	N000065L001C	AC Power Injector 56V
1	N000065L003A	US Line Cord
1	N000065L004A	UK Line Cord
1	N000065L005A	EU Line Cord
1	N000065L006A	Australia Line Cord
2	C000000L033A	Gigabit Surge Suppressor (56V)



Note

Depends on the region of installation, use different lines (instead of N000065L003A) for the following markets:

- N000065L004A for UK
- N000065L005A for EU
- N000065L006A for Australia

**Note**

Additional components required are:

- Mounting Mast
- Radio and accessories including LPU
- Switch

Chapter 2: Configuration

Configuring the Management PC

Configure the management PC settings to communicate with the Intelligent Positioning System.


1. Configure your computer IP address

Set the management PCs wired Ethernet RJ-45 connection to a static IP address of 192.168.0.200. The Cambium Intelligent Positioning System uses a default IP address of 192.168.0.245.

Note: The steps to change IP addresses vary based on the operating systems used on the management PCs.

a. In Windows 7 and above, go to Control Panel > Network and Internet > Network and Sharing > Change Adapter Settings > Ethernet > Properties.

b. Select Internet Protocol Version 4 (TCP/IP IPv4) and click Properties.




c. In the General dialog box, click the Use the following IP Address radio button.


d. Enter an IP address of 192.168.0.200.

e. Enter a subnet mask of 255.255.255.0.

f. Click the **OK** button.




2. Connect the Management PC to the Intelligent Positioning system as shown.



3. Access the Intelligent Positioning system's user interface using a web browser.

- Launch a browser of your choice (Google Chrome, Safari, or Mozilla Firefox).
- Enter the Intelligent Positioning System's IP address (192.168.0.245) in the address bar.
- An authentication required window will be displayed in the browser.




d. Enter the default user name and password and click the OK button.

User Name: admin

Password: cambium

e. The user interface will open to the Main GUI screen upon successful login.



Intelligent Positioning System Configuration

The following configuration steps are required for the Intelligent Positioning system to work with PMP 450.


Tip: Perform these steps prior to mounting the devices on a pole.

Procedure

- Configure the Intelligent Positioning System's IP address.
- Configure the radio's IP address (radio that is attached to the Intelligent Positioning System). Set the SNMP version and SNMP credentials, and the Radio Type (this is the type of radio that is attached to the Intelligent Positioning System).
- Load a list of Access Point Coordinates to the Intelligent Positioning System (if you are using the system in a PMP 450 deployment environment).

1. Configure the Intelligent Positioning System's IP address.

a. Click the **Advanced** tab > Click the **Settings** (Gears) button.



c. Click the **Network** Tab and enter the IP address settings.

e. Click the **Save & Close** button.

System	Network	Serial	Status	Users	I/O	Localization
<h3>IP Settings</h3> <p> IP Address: <input type="text" value="10.120.109.245"/> Subnet Mask: <input type="text" value="255.255.255.0"/> Gateway: <input type="text" value="10.120.109.254"/> NTP Server: <input type="text"/> Time Source: <input type="text" value="GPS"/> </p>						
<p> <input type="button" value="Reboot"/> <input type="button" value="Save & Close"/> <input type="button" value="Close"/> </p>						

2. Next, configure the radio's IP address, set the radio type, and the SNMP Settings.

Click the **Advanced** Tab and click the **Settings** button on the **Auto Peak** panel.

Cambium Networks™
NMT 2.9.3

Main **Advanced**

Auto Peak

☒ Connected **Settings**
☐ In Progress

 RSSI:

Operating Mode

Standby ☒
 Stow ☐
 Manual ☐
 Calibrate ☐

Local Map

Map showing locations: Topgolf, Renaissance Schaumburg Convention Center, The Preserve at Woodfield, Windy Point, IKEA, Costco Wholesale, Woodfield Village Green, Best Buy, Kuma's Corner Schaumburg, Macy's, Woodfield Mall, McConaghy Plaza.

b. Click the **Radio Mfg** drop-down list to select the radio type (for ex. PMP 450).

c. Enter the radio's IP address in the **Radio IP** settings section.

d. Select the **SNMP version** and the SNMP credentials.

Radio/Antenna
Scan
Peak
Advanced

Radio

Radio Model
PMP 450
Radio IP
10.120.109.200
Community String
Canopy
SNMP Version
v2c

Antenna

Beam Width (Deg)
10

Restore Defaults
Save & Close
Cancel

3. Load the Access Point Coordinates list to the Intelligent Portioning System. The information circled in red is filled in by customers. The rest should be hard-coded as is. The UniqueID column lists the Access Points' MAC addresses. The AP coordinates list can be exported from a LinkPlanner file and reformatted as shown.

Name	Type	Az or Lat	El or Long	Pol or Alt (m)	UniqueID
Rolling Me	LatLng	42.04493	-88.025755	0	0a-00-3e-a1-93-0e
corner acc	LatLng	42.06166	-88.001082	0	0a-00-3e-bc-38-b6
Cork : N Al	LatLng	35.46183	-118.96665	0	0a-00-3e-03-4f-11
Cork : NW	LatLng	35.46183	-118.96665	0	0a-00-3e-03-28-2c
Cork : S AP	LatLng	35.46183	-118.96665	0	03-00-3e-bc-38-b6



Note

The UniqueID/MAC address must be in lower case in format (eg. 0a-00-3e-03-28-40).

The Az or Lat/ El or Long can be formatted as 42.044932 -88.025755 or 42.044932N 88.025755W.

- Once the Access Point Coordinates file is formatted, the next step is to upload the list to the Intelligent Positioning System.
- Navigate to the Main Screen, click the **Upload** button in the **Stored Locations** panel and follow the Graphical user interface directions for uploading the file.

Cambium Networks™

Intelligent Positioner

by

Nomadic Wireless Broadband

1.28.0

Main

Advanced

STOP

Store

Azimuth

10.9°

-200

200

Elevation

2.1°

-10

10

Heading 10.9°

Calibration

Override

Calibrate

Connected In Progress

Status idle

RSSI -49.0

URD 0a-00-3e-bc-30-b6

Repeak

Local Coordinates

Deg Min Sec

Lat: 42 3 11 N

Long: 88 1 31 W

Alt: 233 m #Sat: 8

GPS Status

Stored Locations

Name	Type	Az or Lat	El or Long	Aux or Alt	Bearing	Elevation	Ons Dist	Unique ID		
Rolling Meadows	Lat / Long	42.044932	-88.025755	235 m	181.1°	0.1°	0.9 km	0a-00-3e-a1-93-0a	<div></div>	Delete
corner	Lat / Long	42.064018	-88.017415	233 m	27.7°	0°	1.4 km	0a-00-3e-3c-38-34	<div></div>	Delete
Cork : N AP	Lat / Long	35.44193	-118.96665	90 m	264.9°	-0°	2764.5 km	0A-00-3E-03-4F-11	<div></div>	Delete
Cork : NW AP	Lat / Long	35.44193	-118.96665	90 m	264.9°	-0°	2764.5 km	0A-00-3E-03-2B-2C	<div></div>	Delete
Cork : S AP NEW -5.1GHz	Lat / Long	35.44193	-118.96665	90 m	264.9°	-0°	2764.5 km	03-00-3E-BC-38-06	<div></div>	Delete
Cork : W AP NEW -5.1GHz	Lat / Long	35.44193	-118.96665	90 m	264.9°	-0°	2764.5 km		<div></div>	Delete
Cork : N AP NEW -5.1GHz	Lat / Long	35.44193	-118.96665	90 m	264.9°	-0°	2764.5 km		<div></div>	Delete
Sec.33 : N AP	Lat / Long	35.44007	-118.96388	90 m	264.9°	-0°	2764.8 km	0A-00-3E-03-2B-3A	<div></div>	Delete
Sec.33 : NW AP	Lat / Long	35.44007	-118.96388	90 m	264.9°	-0°	2764.8 km	0A-00-3E-03-04-09	<div></div>	Delete
Sec.33 : S AP	Lat / Long	35.44007	-118.96388	90 m	264.9°	-0°	2764.8 km	0A-00-3E-03-56-DF	<div></div>	Delete
Sec.33 : SE AP	Lat / Long	35.44007	-118.96388	90 m	264.9°	-0°	2764.8 km	0A-00-3E-01-20-2E	<div></div>	Delete
Sec.33 : NE AP	Lat / Long	35.44007	-118.96388	90 m	264.9°	-0°	2764.8 km	0A-00-3E-03-4E-04	<div></div>	Delete
Sec.33 : N AP	Lat / Long	35.44007	-118.96388	90 m	264.9°	-0°	2764.8 km		<div></div>	Delete

Upload

Download

Add

Upload ignores Duplicates

0


Message Center

Chapter 3: System Installation


Installing the Intelligent Positioning System

Follow the steps to assemble and install the Intelligent Positioning System to a radio.

1: Mount the Intelligent Positioning System's Antenna Bracket to the radio.



2. Mount the radio assembly to the Intelligent Positioning System.




3. Secure the radio assembly by hand-tightening the screws inside the system.



4. Install the Intelligent Positioning System to the Mast Pole. Connect the cables to the system as shown.


Positioner Grounding

Grounding of the positioner is accomplished through the 2-inch I.D. socket mount base. For installations with grounding, use a conductive metal pole such as aluminum or steel.



Considerations for concern of cable wrap around

If the cables are tied to the mast, it is recommended to leave 6 ~ 8 inches of cable slack, and tie it between 9 inches and a foot down the mounting pole, allowing the cable to wrap around the pole with the Intelligent Positioning System.



5. Power the system by applying mains power to the PoE supply.

Chapter 4: Antenna Alignment Operations

Aligning the Antenna using the Intelligent Positioning System

Once the Intelligent Positioning System is properly installed and stationary at the deployment site, perform the following steps to complete the alignment.

Procedure

- Calibrate the Compass (Optional)
- Point to the target AP

1. Calibrate the compass.

Check the compass status in the Compass panel to confirm the LED icon status is green. If the LED icon color is amber, compass calibration is required.



Click the **Calibrate Compass** button in the **Controls** panel. The Intelligent Positioning System will rotate 360 degrees to perform the calibration.



2. Point to the target AP.

At the target location, the Intelligent Positioning System automatically arranges the AP sites list based on distances from the system's current location. Click the **Go** button for the first AP site on the list (this is the closest AP to the Intelligent Positioning System).

Cambium Networks™

Intelligent Positioner
for
Nomadic Wireless Broadband

1.28.0

MainAdvanced

Connected to UID 0a-00-3e-bc-38-b6

STOP

Show

Geo Position

Azimuth 10.9°

Elevation 2.1°

Compass

Heading 10.9°

Calibration

Overrides

Calibrate

Radio

Connected In Progress

Status idle

RSSI -49.0

UID 0a-00-3e-bc-38-b6

Repeat

GPS

Local Coordinates

Lat: 42 3 11 N

Long: 88 1 31 W

Alt: 232 m #Sat: 8

GPS Status

Stored Locations

	Name	Type	Az or Lat	El or Long	Aux or Alt	Bearing	Elevation	Grid Dist	Unique ID	
Go	Rolling Meadows	Lat / Long	42.044032	-88.025755	235 m	181.1°	8.1°	0.9 km	0a-00-3e-bc-38-b6	Delete
Go	corner	Lat / Long	42.064010	-88.017415	233 m	27.7°	0°	1.4 km	0a-00-3e-bc-38-b6	Delete
Go	Cork : N AP	Lat / Long	35.45183	-113.96605	90 m	264.3°	0°	2764.5 km	0a-00-3e-bc-38-b6	Delete
Go	Cork : NW AP	Lat / Long	35.45183	-113.96605	90 m	264.3°	0°	2764.5 km	0a-00-3e-bc-38-b6	Delete
Go	Cork : S AP NEW -5.1GHz	Lat / Long	35.45183	-113.96605	90 m	264.3°	0°	2764.5 km	0a-00-3e-bc-38-b6	Delete
Go	Cork : W AP NEW -5.1GHz	Lat / Long	35.45183	-113.96605	90 m	264.3°	0°	2764.5 km		Delete
Go	Cork : N AP NEW -5.1GHz	Lat / Long	35.45183	-113.96605	90 m	264.3°	0°	2764.5 km		Delete
Go	Sec33 : N AP	Lat / Long	35.44907	-113.96300	90 m	264.3°	0°	2764.5 km	0a-00-3e-bc-38-b6	Delete
Go	Sec33 : NW AP	Lat / Long	35.44907	-113.96300	90 m	264.3°	0°	2764.5 km	0a-00-3e-bc-38-b6	Delete
Go	Sec33 : S AP	Lat / Long	35.44907	-113.96300	90 m	264.3°	0°	2764.5 km	0a-00-3e-bc-38-b6	Delete
Go	Sec33 : SE AP	Lat / Long	35.44907	-113.96300	90 m	264.3°	0°	2764.5 km	0a-00-3e-bc-38-b6	Delete
Go	Sec33 : NE AP	Lat / Long	35.44907	-113.96300	90 m	264.3°	0°	2764.5 km	0a-00-3e-bc-38-b6	Delete

0 Message Center

How the Compass Calibration Works

1. Why is compass calibration needed?

The Intelligent Positioning System uses a triple-axis magnetometer as a compass. The compass relies on the Earth's magnetic field to determine the North/South orientation.

As local electric magnetic environments (such as mines, metal buildings, etc.) can affect the accuracy of the Earth's magnetic field strength reading, resulting in errors in determining the North/South direction, compass calibration is required when the Intelligent Positioning system is relocated.

2. How does it work?

The Intelligent Positioning System rotates 360 degrees and stops 7 times (roughly every 50 degrees) to measure the magnetic field strength/density. The ideal magnetic measurement of the earth (without any interference) is a sphere for 3-D and a circle for 2-D.

Due to interference from local magnetic environments, the magnetic density measurement becomes distorted. Using a complex algorithm, the system uses the data measured from the calibration to adjust the direction of North/South orientation.

True North is determined using the magnetic north information and GPS coordinates to determine magnetic declination for the current location. On completion of calibration, the system points back to its last commanded azimuth position.

3. When is compass calibration required?

Compass calibration is recommended when the system is relocated and re-installed, or if the Intelligent Positioning System's compass LED status is not green.

Compass calibration is required.



Compass calibration is not required



How Seek and Peak Works

When the positioning system is set up correctly and has a radio connected to it, and the base station is in place, the system will go through the following steps.

The positioning system is waiting for the user's input with a message displaying "Select Target from Stored Locations".

Select Target from Stored Locations

The message is displayed once the user has selected a target and will move to latitude/longitude using the on-board magnetic compass.

Moving to Target

The positioning system sends an SNMP message to the radio to reset and waits until it sees a registration.

Resetting radio

The system will wait for up to 600 seconds for the radio to register.

Waiting for link registration

The positioning system has connected to the base station with a matching ID or an Unknown ID and performs a +/- 25 deg scan to find the highest signal.

Note: if it lands on a radio with a different UID, it will display "**Alternate Target Identified, Recalculating Heading**".

The positioning system will still perform a +/- 25-degree scan and peak on the alternate link, and then update the heading with an override based on knowing where that radio is located and then calculate the proper azimuth offset to get exactly to the other OID.

Azimuth scan in process

This is the second scan centered around the hottest point from the first scan. This scan is also a +/- 25-degree scan.

Mainlobe Scan 1 in process

The radio has the proper UID identified from the initial list it was connected to and is performing a peak to optimize signal.

Connected Peaking

The positioning system is done and the link is up. No further action is taken from the system.

Connected Peak complete

Error Signal


This message is displayed where the signal had peaked but dropped due to the noise floor. This error usually indicates that the base station power went away or has reset.

Error, signal lost

Chapter 5: User Interface


Main Page

This section provides a basic introduction to the Main page of the Intelligent Positioning System User Interface (UI). The Main Page provides key controls used for daily operations.



Geo Position panel


The GEO Position panel displays the Positioning systems Geo Position and pedestals position for Azimuth and Elevation. The LED turns Green if the system is moving, and turns Red if it is not moving.



Compass panel

The Compass panel displays the current status of the compass including Geo Azimuth heading. It also displays the calibration status. If the LED icon is amber, it means calibration is needed. Green means calibration is NOT required.

Calibrate - click “Calibrate Compass” to perform a compass calibration.



Controls panel

The Control panel consists of two features:


STOP Button - click on “STOP” to stop the movement of the positioning system.

Stow Button- click on “Stow” when the user wants to tear down the deployment and place the positioning system for shipping and storage.



Message Center panel

The Message Center panel displays the status of the alignment operation and prompt user to take next actions.



GPS/Target Location panel

Under normal operation, users do not need to interact with this panel. Users can enter the target location and click the Goto button to point the antenna to the target. The target location can then be stored.

If a user determines the GPS information provided by the Positioning System's GPS sensor is not accurate or if there is an error in the GPS (ex. the GPS LED icon is not displayed as green), the user can click the **GPS Override** button and enter the GPS information manually to override the readings provided by the Positioning system.

Stored Location window panel


When the Positioning system is in Idle state, click on any **GoTo** buttons on the list to point the antenna to the target direction. The location list can be uploaded from a spreadsheet and downloaded to the system. The list is sorted automatically based on distance from the current location, to target locations, with the nearest target listed at the beginning.

Stored Locations										
	Name	Type	Az or Lat	El or Long	Aux or Alt	Bearing	Elevation	Grid Dist	Unique ID	
Go	Rolling Meadows	Lat / Long	42.044932	-88.025755	235 m	181°	0.1°	8.9 km	0a:00:3a:a1:93:8a	Delete
Go	corner	Lat / Long	42.064818	-88.017415	233 m	27.7°	0°	1.4 km	0a:00:3a:a1:93:8a	Delete
Go	Cork : N AP	Lat / Long	35.46183	-118.36665	90 m	264.3°	-0°	2764.5 km	0A:00:3E:03:4F:11	Delete
Go	Cork : NW AP	Lat / Long	35.46183	-118.36665	90 m	264.3°	-0°	2764.5 km	0A:00:3E:03:2B:2C	Delete
Go	Cork : S AP NEW -5.1GHz	Lat / Long	35.46183	-118.36665	90 m	264.3°	-0°	2764.5 km	03:00:3E:0C:38:05	Delete
Go	Cork : W AP NEW -5.1GHz	Lat / Long	35.46183	-118.36665	90 m	264.3°	-0°	2764.5 km		Delete
Go	Cork : N AP NEW -5.1GHz	Lat / Long	35.46183	-118.36665	90 m	264.3°	-0°	2764.5 km		Delete
Go	Sec.33 : N AP	Lat / Long	35.44907	-118.36388	90 m	264.3°	-0°	2764.8 km	0A:00:3E:01:20:5A	Delete
Go	Sec.33 : NW AP	Lat / Long	35.44907	-118.36388	90 m	264.3°	-0°	2764.8 km	0A:00:3E:03:04:99	Delete
Go	Sec.33 : S AP	Lat / Long	35.44907	-118.36388	90 m	264.3°	-0°	2764.8 km	0A:00:3E:03:56:DF	Delete
Go	Sec.33 : SE AP	Lat / Long	35.44907	-118.36388	90 m	264.3°	-0°	2764.8 km	0A:00:3E:01:20:2E	Delete
Go	Sec.33 : NE AP	Lat / Long	35.44907	-118.36388	90 m	264.3°	-0°	2764.8 km	0A:00:3E:03:4E:EE	Delete
Go	Sec.33 : N AP -5.1GHz	Lat / Long	35.44907	-118.36388	90 m	264.3°	-0°	2764.8 km		Delete
Upload Download Add Upload ignores Duplicates Delete All										

Radio Panel


The Radio panel displays the status of the positioning system, the RSSI of the Subscriber Module (SM), and the MAC address of the Access Point (AP) that the SM is connected to. Click the **Repeak** button to determine if better performance can be achieved.

The positioning system will not perform final alignment if it doesn't have a TCP connection with the SM attached to it. Please ensure the Connected LED icon is green.




Advanced Page

The Advanced page is used by users to configure the system parameters, fine-tune the scan degree range, etc. to optimize the alignment performance.



Geo/Pedestal Position panel


The Geo/Pedestal panel displays the antenna's current GEO and Pedestal position for azimuth and elevation. Users can enter the target azimuth, elevation, and optional polarization angles. Use the slide button to switch between the Geo Position and Pedestal position parameter screens.



An operator can enter the target Azimuth/Elevation parameters and click the Go button to point the Positioning system to the target. Operators can also click the Store button to store the target point for future reference and use.

Fixed Locations panel

The Fixed Locations panel allows user-defined entry of Azimuth and Elevation pairs, or the Latitude and Longitude pairs to quickly recall and return to the stored entry point. This is the same window as the main Stored Location panel on the Main page.



GPS/Target location panel

The GPS/Target Location panel displays the current latitude and longitude of the antenna position and allows manual entry of desired target latitude and longitude.

GPS / Target Location									
Local Coordinates					Target Coordinates				
	Deg	Min	Sec			Deg	Min	Sec	
Lat:	42	3	11	N	Lat:	42	3	11	N
Long:	88	1	32	W	Long:	88	1	31	W
Alt:	233 m		#Sat:	11	Alt:	90 m	EL: -74.3 deg		
GPS Status					Bearing 139 0 km				
<div style="display: flex; align-items: center;"> <div style="width: 10px; height: 10px; background-color: green; border-radius: 50%; margin-right: 5px;"></div> GPS Override </div>					<div style="display: flex; justify-content: space-around;"> Go Store </div>				


Auto Peak panel

The Auto Peak function requires a Radio Signal Strength feedback loop between the antenna positioning system and the installed radio. The positioning system queries the radio for an RSSI value via the SNMP protocol, and adjusts the direction accordingly to receive the maximum RSSI signal based on the SNMP value.

Auto Peak	
<div style="display: flex; align-items: center;"><div style="width: 10px; height: 10px; background-color: green; border-radius: 50%; margin-right: 5px;"></div>Connected</div>	Settings
<div style="display: flex; align-items: center;"><div style="width: 10px; height: 10px; background-color: red; border-radius: 50%; margin-right: 5px;"></div>In Progress</div>	Reset
<div style="border: 1px solid black; padding: 2px; text-align: center;">idle</div>	
RSSI: <div style="border: 1px solid black; padding: 2px; display: inline-block;">-50.0</div>	
Scan & Peak	
Peak Only	
Heat Map	

- **Connected LED:** The Connected LED reports whether the Positioning system can use SNMP to communicate with the attached radio. Green indicates that it is able to connect.
- **In Progress LED:** The In Progress LED reports when a peak, or seek process is in progress. The red color indicates there is no activity, and green color indicates the seek or peak activity is in progress.
- **Status window:** A Status window provides progress status to the user while the In Progress LED is green and display the message Seeking when it is in a seek mode, and changes to Peaking once it finishes seeking.
- **RSSI:** Displays the current Receive Signal Strength Indication (RSSI) value from the radio.
- **Scan & Peak:** Scans around the current heading to acquire a link. The scan area is specified in degrees under the Settings icon.
- **Peak Only:** The Peak Only setting executes an auto peak function to locate the highest signal.

- **Settings:** Allows set up of the radio connected to the Positioning system.
- **Heatmap:** Opens the RF Mapping window which plots a color-coded signal strength when the Positioning system is performing the alignment.



Auto Peak Settings panel

Click the **Setting** button in the Auto Peak panel to launch the Auto Peak Setting window.

The Auto Peak Settings panel consists of four tabs: Radio/Antenna, Scan, Peak, and Advanced. The Radio/Antenna tab is currently selected, showing the following settings: Radio Model (PMP 450), Radio IP (10.120.100.200), Community String (Community), SNMP Version (v2c), and Antenna (Beam Width: 10). The Scan tab shows settings for Type (CN 430), Width (50), Step Size (5), Step Delay (5), and Step Delay (5). The Peak tab shows settings for Az (1), El (1), Dwell (5), and Threshold Repeat (Even). The Advanced tab shows settings for RSSI (13.8, 13.8, 13.8, 13.8, 13.8, 13.8), Connection State (13.8, 13.8, 13.8, 13.8, 13.8, 13.8), Peer ID (13.8, 13.8, 13.8, 13.8, 13.8, 13.8), and Peer Radio (13.8, 13.8, 13.8, 13.8, 13.8, 13.8).

Radio Settings

- **Radio Model:** Select the radio type that will be used with the network. When the radio type is selected, the correlated radio RSSI MIB ID field will be populated automatically in the Object ID field. The user selects "Custom" and manually enters the object ID to be used to gain signal strength.
- **Radio IP:** The IP address of the radio that is attached to the positioning system.
- **SNMP Community String:** SNMP community string.
- **SNMP Version:** Select the SNMP version here.
- **Antenna:** Radio antenna's beam width.

Scan/Peak Settings

- **Type:** The algorithm used by the Positioning system for scanning.
 - For wide beam antenna pattern (> 10 degrees beam width), use Linear Scan Type.
 - For narrow beam antenna pattern (< 2-degree beam width), use the Cochlear scan type. Otherwise, select based on the trial result.
- **Width:** Sets the scan width in degrees used for the Seek and Peak in the Auto Peak Control window on the Main control page.
- **Scan Step Az:** Sets the Azimuth step size in degrees used for the Seek and Peak in the Auto Peak Control window on the Main control page.
- **Reg Dwell:** The maximum amount of time the positioning system should wait for the radio to register. Note, the positioning system will move on if the radio registers before the timer expires.
 - Channel scan takes ~200ms for per channel. For example, if the PMP450 Subscriber Module is configured to scan 100 channels, you can change the dwell time to be ~20 seconds.
- **Step Dwell:** The amount of time the positioning system should wait for each step of Azimuth move.

Peak Settings

- **Peak Step Az:** Sets the Azimuth step size in degrees that are used for the final peaking in the Auto Peak control window on the main control page.
- **Peak Step El:** Sets the Elevation step size in degrees that are used for the final peaking in the Auto Peak control window on the main control page
- **Dwell Time:** Sets the dwell time between step sizes. It is used to let the positioning system settle in a location and to allow the radio to update its signal strength. The dwell time will vary with each radio type update rate for the radio signal strength.
- **Sidelobe Check:** If the main antenna beamwidth value is known, entering it in the system and enabling the Sidelobe check option can help verify that the main antenna beamwidth is on the main antenna lobe, and not on the sidelobe.


Threshold Re-peak

This setting allows the setup of a scheduled or routine peak process to maintain the highest quality of service. This is generally used with links that have motion such as Satellite, or Microwave links on an unstable platform. This is not recommended for a wide beamwidth radio such as a PMP 450i with integrated antenna.

- **Threshold Repeaking checkbox:** Places the peak process into a peaking mode of operation when threshold signal strength is detected.
- **Start:** RSSI value to trigger automatic repeaking.
- **Stop:** RSSI value to stop automatic repeaking.
- **Time Block:** Time interval to check for the need of repeaking.
- **Diversity:** In a link, while there is a Positioning system at both ends, one end should be configured as Even, and the other should be configured as Odd.
- **Advanced Settings:** Settings for MIB Object IDs (should not be changed unless necessary).

Manual Controls panel

Manual Controls window provides manual slew and step-size control for manual up, down, clockwise, and counter-clockwise commands. Optional polarization rotation is provided when installed.



Step/Slew select

It allows the user to select between a step or slew command control. The functions outlined in this table identify how the positioning system responds with Step selected in the manual controls window.

Step Size Selection (applicable only to Step selection)

Allows users to define step sizes in degrees. Users enter step size values that are applied to manual arrow direction commands. The example shows 1 degree per step.

Up Arrow

If the Step option is selected, the Up Arrow button moves the Positioning system's elevation antenna position in a positive direction (up) in step sizes equal to the defined step size. The system moves by the defined step size amount and then stops each time this button is pressed and will continue to accept this command until the travel limit in this direction is met.

If the Slew option is selected, pressing the Up Arrow button moves the elevation axis antenna's position in a positive direction (up). Press and hold the button to continue moving the system in an upwards direction until the travel limit is met or when the button is released.

Down Arrow

If the Step option is selected, the Down Arrow button moves the Positioning system's elevation antenna position in a negative (down) direction in step sizes equal to the defined step size. Each time the arrow is pressed, the system moves by the defined step size amount and then stops. The system continues to accept this command until the travel limit in this direction is met.

If the Slew option is selected, pressing the Down Arrow button moves the elevation axis antenna position in a positive direction (up). Press and hold the Down Arrow to continue moving in a downward direction until the travel limit is met or the directional arrow is released.

Left Arrow

If a step option is selected, moves the Positioning system's azimuth antenna position in a counter-clockwise direction in step sizes equal to the defined step size. Each time the arrow is pressed, the positioning system moves by the defined step size amount and then stops. The system continues to accept this command until the travel limit in this direction is met.

If slew is selected, moves the azimuth antenna position in a counter-clockwise direction (left). Press and hold the CCW arrow and the positioning system continues to move in a Counter-Clockwise direction until the travel limit is met or the directional arrow is released.

Right Arrow

If a step is selected, moves the positioning system's azimuth antenna's position in a clockwise direction in step sizes equal to the defined step size. Each time the arrow is pressed the system moves by the defined step size amount and then stops. The system continues to accept this command until the travel limit in this direction is met.

If slew is selected, moves the azimuth antenna position in a clockwise direction (right). Press and hold the CW arrow and the system continues to move in a clockwise direction until the travel limit is met or the directional arrow is released.

Emergency Stop Button

The emergency stop button stops travel in all directions when selected.

Speed Control

The speed control slider bar selects the velocity of the antenna positioning system. The far-right as shown in the manual is the fastest and the far left is the slowest. The slider bar has 4-speed locations. The speed control slider bar can change the system's velocity range from 2°/sec, 3.75°/sec, 5°/sec, and 7 degrees per second.


Operating Mode panel

The Operating Mode panel displays different modes and states of the Positioning system operations.



Local Map panel

The Local Map panel provides a visual representation of both ends of a link. The panel also displays the antenna positioning system's heading. The map is centered by default on the local end and available if the Positioning system has internet access.




Chapter 6: Maintenance Operation

Optional System Settings

Delete this text and replace it with your own content.

Procedure

1. Navigate to the **Advanced** page. Click the **Gears** button.



Unit Name Setting: Unit Name setting allows setting the unit name so that it will be shown on the main page.

Limits: User-configurable travel limits. All entries are in degrees. Allows software adjustment to travel limits in Azimuth and Elevation. The default travel limits for each axis is the maximum physical travel limits. The "Save & Close" button must be clicked before updates are applied.

Reboot: Forces the on-board CPU to reboot.

Serial Number: Displays the Positioning system's serial number. This field is non-configurable and is the unique identifier used by Cambium to track warranty and software revisions.

Model Number: Displays the Model Number of the unit.


Software Version Number: Display's current software revision running on the LinkAlign digital controller.

System Recovery

If you forget the Intelligent Positioning System's IP address, you can access the system by using the IP address 169.254.1.101 to access the system's Web UI to recover the information.

Procedure

1. Configure the management PC with the following IP address:



2. Connect the management PC to the Intelligent Positioning System.
3. Launch a web browser of your choice and enter **http://169.254.1.101** in the web browser's address bar.
4. Enter the log in credentials

User name: admin

Password: cambium

Updating Software


The Intelligent Positioning System's firmware is updated from the Settings page > Status tab.

Procedure


1. Go to the **Advanced** page, click the **Gears** icon.



2. Click the **Status** tab and select a file from your computer.
3. Click the **Choose File** button. Navigate to the folder to where the software file is located and select it.



3. Click the **Upload File** button to upload the file.
4. Once the software has fully uploaded, a message **Firmware Uploaded Successfully** will be displayed.
5. The Install button will appear below this message. Press the **Install** button to complete the update process.




6. Reboot the system to complete the installation.

User Administration


Operators can add or remove users, change user passwords from the Settings page > Users page.

Procedure

1. Navigate to the **Advanced** page. Click the **Gears** button.



2. Click the **Users** tab to open the User administration page.



Adding Users

1. Click the **Add User** button
2. Enter user's first name and last name.
3. Click the **Save & Close** button to save the settings.

Deleting Users

1. Select a user from the list.
2. Click the **Delete** button.
3. Click the **Save & Close** button to save the settings.

Changing Users Passwords

1. Select a user from the list.
2. Click the **Password** button.
3. Enter a new password.
4. Click the **Save & Close** button to save the settings.